EUROCARGO TECTOR

I 2 TO 26 t REPAIR MANUAL



This publication describes the characteristics, data and correct methods for repair operations on each component of the vehicle.

If the instructions provided are followed and the specified equipment is used, correct repair operations in the programmed time will be ensured, safeguarding against possible accidents.

Before starting to perform whatever type of repair, ensure that all accident prevention equipment is available and efficient.

All protections specified by safety regulations, i.e.: goggles, helmet, gloves, boot, etc. must be checked and worn.

All machining, lifting and conveying equipment should be inspected before use.

The data contained in this publication was correct at the time of going to press but due to possible modifications made by the Manufacturer for reasons of a technical or commercial nature or for adaptation to the legal requirements of the different countries, some changes may have occurred.

No part of this publication, including the pictures, may be reproduced in any form or by any means.

Publication Edited by: IVECO S.p.A. T.C.O. - B.U. Customer Service Lungo Stura Lazio 15/19 10156 Torino (Italy)

Print 603.93.111 - 1st Ed. 2003

Produced by:



B.U. TECHNICAL PUBLISHING C.so Svizzera, 185 10149 Torino (Italy)

SPECIAL REMARKS

Workshop Manuals - concerning the mechanical part - are divided into several Sections. Each Section is characterised by a number and its content is shown on the general index to be found at the beginning of each workshop manual.

Each section deals generally with one of the main Assemblies (engine, transmission, etc.)

Each section deals with the following topics:

Specifications and technical data, Tightening torques, Special tools, Troubleshooting (fault diagnosis), Component removal/refitting, Repair operations.

To facilitate manual consultation, the different subjects are generally dealt with (where possible), following the same sequence. This manual also provides graphs and symbols instead of description of parts, operations or operating procedures (see next page), to give a more immediate and friendly reference.

Example:

Ø I Ø I = Housing for connecting rod small end bush
 Ø Z Ø Z = Housing for big end bearings



Tighten to torque + angle value

Furthermore, within each section, every heading or sub-heading concerning the operations to be carried out is preceded by a six digit number. This number is the **Product Code** that is to be found in the repair operation described in the FLAT RATE MANUALS and in the FAILURE CODES publication.

For quick reference the indication for reading this code is described below (see also the Flat Rate Manuals).

Product cod	de:	5 0 PRODUCT	ASSEMBLY	SUBASSEMBLY COMPONENT
Example : Product Product	50 = 52 =		DUCT with	nin the vehicle.
Assembly c	ode:	PRODUCT	O I ASSEMBLY	SUBASSEMBLY COMPONENT
Figure three a Example :	ind four	identify the AS	SEMBLY wit	thin the PRODUCT
Product Assembly		,	r run-bars, e	etc.
Subassemb	ly cod∉	PRODUCT	ASSEMBLY	40 SUBASSEMBLY COMPONENT
Figure five and Example :	d six ide	entify exactly the	SUB-ASSEN	MBLY and the Assembly Component within the PRODUCT
Assembly		Chassis;		
		Chassis cross m	embers, etc	2.

Graph and symbols

	Removal Disconnection		Intake
	Refitting Connection		Exhaust
	Removal Disassembly		Operation
	Fitting in place Assembly	<i>Q</i>	Compression ratio
	Tighten to torque	*	Tolerance Weight difference
$\overrightarrow{\mathcal{P}_{a}}$	Tighten to torque + angle value		Rolling torque
	Press or caulk	IVECO	Replacement Original spare parts
848	Regulation Adjustment		Rotation
	Warning Note	\triangleleft	Angle Angular value
	Visual inspection Fitting position check		Preload
	Measurement Value to find Check		Number of revolutions
R	Equipment		Temperature
<u> </u>	Surface for machining Machine finish	bar	Pressure
Ś	Interference Strained assembly	>	Oversized Higher than Maximum, peak
	Thickness Clearance	<	Undersized Less than Minimum
	Lubrication Damp Grease		Selection Classes Oversizing
	Sealant Adhesive		Temperature < 0 °C Cold Winter
	Air bleeding		Temperature > 0 °C Hot Summer

EUROCARGO Tector 12-26t

Print 603.93.111 - 1st edition Base - February 2003

UPDATING DATE

Section	Description	Page	Revision date

INDEX OF SECTIONS

	Section
General Specifications	I
Engine	2
Clutch	3
Gearbox	4
Propeller shafts	5
Rear axles	6
Axles	7
Suspensions	8
Wheels and tyres	9
Steering system	10
Pneumatic system – brakes	11
Body and chassis	12
Scheduled maintenance	13

SECTION I

General Specifications

	Page
COMPOSITION OF THE MODELS	3
IDENTIFICATION DATA AND LOCATION ON VEHICLE	
FILLING UP	12
INTERNATIONAL LUBRICANT DESIGNATION	13

GENERAL SPECIFICATIONS COMPOSITION OF THE MODELS

		MODELS 4 X 2				പ				Ч				4				۵.		
		17(2	2	MLI 10ELI 7/P	I 7R	MLI IOELI 7R/P	5	MLI 10EL2 1/P	2 I R	MLI I 0EL2 I R/P	2	MLI 20ELI 7/P	MLI 20ELI 7/R	MLI 20ELI 7R/P	21	MLI 20EL2 I/P	2 I R	MLI 20EL2 I R/P	ω	Ć
			OEL	OEL	OEL	OEL	OEL	OEL	OEL	OEL	DEL	POEL	OEL	DEL	DEL	OEL	DEL	OEL	DEI	Ľ
JNITS			MLI 10EL	1	MLI I OELI 7R	4L	MLI 10EL2 I	4L	MLI 10EL2 IR	7	MLI 20ELI 7	41E12	1L12	41L12	MLI 20EL2 I	1LI 2	MLI 20EL2 I R	1L12	MLI 20E18	
JINITS	F4AE0481A	(170 HP)	•	•	•	•	~	~	~	~	•	•	•	•	~	~	~	~		ť
	F4AE0681E	(170 HP)	-	-	-						-	-	-	-					•	
	F4AE0681D	(210 HP)					•	•	•	•					•	•	•	•	-	+
	F4AE0681B	(240 HP)																		╋
	F4AE0681A	(275 HP)																		+
Ν		13"	•	•	•	•					•	•	•	•						+
		4''					•	•	•	•					•	•	•	•	•	
Ţ	Single plate —	3''/ 4''																	•	T
V		15''/16''																		T
	2855.6		•	•							•	•							•	
	2865.6						•	•							•	•				T
	2870.9		٠	•	•	٠	•	•	•	•	•	•	•	•	٠	٠	٠	•	•	Ī
آ	2895.9																			T
v	FSO 5206B																			T
	MD 3060P																			
	5845		•	•	•	•	•	•	•	•	•	•	•	•	•	٠	•	•		
	5842/5																		٠	
	5851/5																			
	5871/5																			
	MS08-125		•	•	•	٠	•	٠	•	•	٠	•	•	٠	•	٠	٠	•		
	MS10-144																		•	
	MS10-164																			_
	MS13-165																			_
	SPI45E																			4
	ZF 8095																		•	
	ZF 8098																			
L	TRW-TAS 55		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		T
8 9	Mechanical front		٠	•	•	٠	•	•	•	•	•	•	•	٠	•	٠	٠	•	•	1
	Mechanical rear		٠		•		•		•		•		•		•		٠		•	Ī
\bigcap	Pneumatic front																			T
\bigcirc	Pneumatic rear			•		•		•		•		•		•		•		•		t
~	Disk front		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	1
	Disk rear		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	t
	Drum rear													1						t

K = Dump body; R = Trailing vehicle; T = Tractor; P = Vehicles with pneumatic suspension on rear axle; FP = Vehicles with front and rear pneumatic suspension; D = Double cabin (6 + 1); RS* = Road Sweeper

COMPOSITION OF THE MODELS

			1	1	1	1	1	1	-	1	1	<u> </u>	1	1	<u> </u>	1	1	1	—	
		MODELS																		
		4 x 2	£	~	٩V	VFP		Ŕ		d/C	ЛR	ML120E18DR/P	×	JKR		Ъ	£	~	۲P	VFP
			ML 20E 8/FP	MLI20E18R	ML120E18R/P	MLI 20EI 8R/FP	MLI20E18K	ML120E18KR	ML120E18D	ML120E18D/P	MLI20E18DR	EI 8	ML 20E 8DK	ML120E18DKR	51	ML120E21/P	ML120E21/FP	ML120E21R	ML120E21R/P	ML120E21R/FP
			I 20E	120E	I 20E	120E	I 20E	I 20E	I 20E	I 20E	I 20E	I 20E	I 20E	I 20E	ML120E21	I 20E	I 20E	I 20E	I 20E	I 20E
UNITS			Σ	Σ	Σ	Σ	Σ	Σ	Σ	Ę	Σ	Σ	Σ	Ę	Σ	Σ	Σ	Σ	Σ	Σ
	F4AE0481A	(170 HP)																		1
	F4AE0681E	(180 HP)	•	•	•	•	•	•	•	•	•	•	•	•						\square
	F4AE0681D	(210 HP)													•	•	•	•	•	٠
	F4AE0681B	(240 HP)																		
	F4AE0681A	(275 HP)																		
		3"																		
	- Single plate	4"	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	٠	٠	•
	Single plate —	3''/ 4''	•	•	٠	•	•	•	•	•	٠	•	•	•						
		15"/16"		1						1										
	2855.6		•	1			•		•	•			•							Γ
	2865.6														•	•	•			
	2870.9		•	•	٠	•	•	•	•	•	٠	•	•	•	•	٠	•	٠	٠	•
	2895.9																			
V	FSO 5206B																			
	MD 3060P																			
	5845																			
i i i i i i i i i i i i i i i i i i i	5842/5		•	•	•	•	•	•	•	•	•	٠	•	•	•	•	•	٠	•	•
	5851/5																			
	5871/5																			
	MS08-125																			
	MS10-144		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	٠	•	•
	MS10-164																			
	MSI3-165																			
	SP145E																			
	ZF 8095		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	ZF 8098			1			1			1										\vdash
LKg	TRW-TAS 55			-						-									-	-
	Mechanical front			•	•		•	•	•	•	•	•	•	•	•	•		•	•	┝
	Mechanical Rear			•	-	-	•	•	•	+	•	ŀ	•	•	•	-	-	•	Ļ.	+
	Pneumatic front		•	-			-	-	-	•		-	-	•			•		⊢	•
				_	<u> </u>									-					⊢	
	Pneumatic rear		•		•	•				•		•				•	•		•	•
	Disk front		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	Disk rear		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	Drum rear																			

K = Dump body; R = Trailing vehicle; T = Tractor; P = Vehicles with pneumatic suspension on rear axle; FP = Vehicles with front and rear pneumatic suspension; D = Double cabin (6 + 1); $RS^* = Road Sweeper$

COMPOSITION OF THE MODELS

			1											1				1		
		MODELS														д.		~		
		4 X 2	\leq	Ж		ď,	d L	Ŕ	RVP	MLI 20E24R/FP	¥	Ϋ́	Ģ	MLI 20E24D/P	ЧŪ	MLI 20E24DR/P	Ă	MLI 20E24DKR		P/P
			ML120E21K	MLI 20E2 I KR	MLI 20E24	MLI 20E24/P	MLI20E24FP	MLI 20E24R	MLI 20E24R/P)E24	MLI 20E24K	MLI 20E24KR	MLI 20E24D)E24	MLI 20E24DR)E24	MLI 20E24DK)E24	MLI 20E28	MLI 20E28/P
			LI 20	LI 20	LI 20	LI 20	LI 20	LI 20	LI 20	LI 20	LI 20	LI 20	LI 20	LI 20	LI 20	LI 20	LI 20	LI 20	LI 20	LI 20
UNITS			Σ	Σ	Σ	Σ	Σ	Σ	Σ	Σ	Σ	Σ	Σ	Σ	Σ	Σ	Σ	Σ	Σ	Σ
	F4AE0481A	(170 HP)																		
	F4AE0681E	(180 HP)																		
	F4AE0681D	(210 HP)	•	•																
	F4AE0681B	(240 HP)			•	•	•	•	•	•	•	•	•	•	•	٠	•	•		
	F4AE0681A	(275 HP)																	•	•
	-	13"																		
	Single plate –	4"	٠	•	•	•	•				•		•	•			•			
		3''/ 4''																		
		15"/16"			•	•	•	•	•	•	•	•	•	•	•	٠	•	•	•	•
	2855.6																			
N -	2865.6		•																	
	2870.9		•	•																
	2895.9				•	•	•	•	٠	•	•	•	•	•	•	•	•	•	•	•
	FSO 5206B				•	•	•				•		•	•			•			
	MD 3060P																			
	5845																			
	5842/5		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	5851/5																			
	5871/5																			
	MS08-125																			
	MS10-144		٠	•	•	•	•	٠	٠	•	•	٠	•	•	٠	•	•	•	٠	•
	MS10-164																			
	MS13-165																			
	SP145E																			
E	ZF 8095		٠	•	•	•	•	•	٠	•	•	•	•	•	٠	•	٠	•	•	•
	ZF 8098																			<u> </u>
L L L	TRW-TAS 55																			
	Mechanical front		•	•	•	•		•	•	-	•	•	•	•	•	•	•	•	•	•
	Mechanical Rear		•	•	•	-		•	-	-	•	•	•		•	-	•	•	•	
	Pneumatic front		$\left \right $																	<u> </u>
	Pneumatic rear					•	•		•	•				•		•				•
	Disk front		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	Disk rear		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	Drum rear																			

K = Dump body; R = Trailing vehicle; T = Tractor; P = Vehicles with pneumatic suspension on rear axle; FP = Vehicles with front and rear pneumatic suspension; D = Double cabin (6 + 1); RS* = Road Sweeper

1

COMPOSITION OF THE MODELS

		MODELS 4 X 2	d.		/P	/FP		£			<u>д</u> .		P	/FP		£	S*		0/P	R	R/P
			MLI 20E28/FP	ML120E28R	ML I 20E28R/P	MLI20E28R/FP	ML120E28K	MLI 20E28KR	MLI 30E18	MLI30E18/P	MLI 30E I 8/FP	MLI 30E18R	ML130E18R/P	MLI 30EI 8R/FP	MLI 30E18K	ML130E18KR	ML130E18RS*	ML130E18D	MLI 30E18D/P	MLI 30EI 8DR	MLI 30E I 8DR/P
UNITS			Σ	Σ	Σ	Σ	Σ	Σ	Σ	Σ	Σ	Σ	Σ	Σ	Σ	Σ	Σ	Σ	Σ	Σ	Σ
	F4AE0481A	(170 HP)																			
	F4AE0681E	(180 HP)							•	•	•	•	•	•	•	•	•	•	٠	•	•
	F4AE0681D	(210 HP)																			
	F4AE0681B	(240 HP)																			
	F4AE0681A	(275 HP)	•	•	•	•	•	•													
\mathbf{N}	-	13"																			
	Single plate –	4"																			_
	-	3"/ 4"							•	•	•	•	•	•	•	•	•	•	•	•	•
		15''/16''	•	٠	•	•	•	•													_
	2855.6								•	•	•				•			•	•		
ΝΛ	2865.6																•				
	2870.9								•	•	•	•	•	•	•	•		•	•	•	•
n	2895.9		•	•	•	•	•	•													
	FSO 5206B																				
	MD 3060P																				<u> </u>
	5845																				<u> </u>
	5842/5		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	5851/5 5871/5									-											
	MS08-125																				_
	MS10-144																				-
1 - A	MS10-144 MS10-164		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	MSI3-165																				
	SP145E										-										
													•			•	•	•	•	•	•
	ZF 8095 ZF 8098		•	•	•	•	•	•	•	•	•	•	•	•	•	-	•	•	-	•	-
LKngs	TRW-TAS 55																				
	Mechanical front			•	•		•	•	•	•		•	•		•	•	•	•	•	•	•
	Mechanical Rear			•	-	-	•	•	•	-	-	•			•	•	•	•	-	•	+
\bigcirc	Pneumatic front		•			•					•			•							
	Pneumatic rear		•		•	•				•	•		•	•					•		•
<u> </u>	Disk front		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	Disk rear		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	Drum rear																		1		

K = Dump body; R = Trailing vehicle; T = Tractor; P = Vehicles with pneumatic suspension on rear axle; FP = Vehicles with front and rear pneumatic suspension; D = Double cabin (6 + 1); $RS^* = Road Sweeper$

COMPOSITION OF THE MODELS

		MODELS 4 X 2	\mathbf{r}	KR			6		Ь	FP		~			<u>م</u>		٩.	FP		Ī
JNITS			MLI 30E I 8DK	MLI 30EI 8DKR	MLI 30E2 I	MLI 30E2 I /P	MLI 30E2 I /FP	MLI 30E2 I R	MLI 30E2 I R/P	MLI 30E2 I R/FP	MLI 30E2 I K	MLI 30E2 I KR	MLI 30E24	MLI 30E24/P	MLI 30E24/FP	ML130E24R	MLI 30E24R/P	MLI 30E24R/FP	MLI 30E24K	
	F4AE0481A	(170 HP)	~	~	2	~	~	~	2	~	~	~	~	~	2	~	~	~		+
	F4AE0681E	(170 HP)	•	•			-												┝	╉
	F4AE0681D	(100 HP)			•	•	•	•	•	•	•	•							-	╉
	F4AE0681B	(240 HP)											•	•	•	•	•	•	•	╉
	F4AE0681A	(275 HP)																	-	┥
		13"						1												1
	-	4''			•	•	•	•	•	•	•	•								-
	Single plate -	3''/ 4''	•	•																-
\mathcal{V}	-	15''/16''											•	•	•	•	•	•	•	-
	2855.6		•																	-
	2865.6				•	•	•				•									-
	2870.9		•	•	•	•	•	•	•	•	•	•								
أر	2895.9												•	•	•	•	•	•	•	
V	FSO 5206B												•	•	•				•	
	MD 3060P																			-
	5845																			
	5842/5		٠	•	•	٠	•	٠	•	•	٠	٠	٠	٠	•	٠	٠	•	•	
	5851/5																			
	5871/5																			
	MS08-125																			
	MS10-144		•	•	•	٠	•	٠	•	•	•	•	٠	٠	•	•	٠	•	•	
HOH	MS10-164																			
	MS13-165																			
	SP145E																			_
	ZF 8095		•	•	•	•	•	٠	•	•	•	•	•	•	•	٠	•	•	•	
	ZF 8098																			
L ~p	TRW-TAS 55																			
0 0	Mechanical front		•	•	•	•		•	•		•	•	•	•		•	•		•	-
	Mechanical Rear		•	•	•			•			•	•	•			•			•	-
\bigcirc	Pneumatic front						•			•					•			•		-
	Pneumatic rear					•	•		•	•				•	•		•	•	-	
	Disk front		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	-
	Disk rear		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	-
	Drum rear		-				<u> </u>			-						<u> </u>	<u> </u>		⊢	_

K = Dump body; R = Trailing vehicle; T = Tractor; P = Vehicles with pneumatic suspension on rear axle; FP = Vehicles with front and rear pneumatic suspension; D = Double cabin (6 + 1); RS* = Road Sweeper

		MODELS																			\square
		4 X 2		D/P	DR	MLI 30E24DR/P	Ă	DKR		ŕ	ΈΡ	æ	RVP	RVFP		К К		ŕ	ΈΡ	۲ ۲	RVP
			ML I 30E24D	MLI 30E24D/P	MLI 30E24DR	0E24I	MLI 30E24DK	MLI 30E24DKR	ML I 30E28	ML I 30E28/P	ML I 30E28/FP	ML I 30E28R	ML I 30E28R/P	ML I 30E28R/FP	ML I 30E28K	ML I 30E28KR	0E21	ML I 50E2 I /P	ML I 50E2 I /FP	ML150E21R	ML I 50E2 I R/P
UNITS			4L I 3	4L13	4L13	4L13	4L13	4L I 3	4L I 3	4L I 3	1L I 3	1L I 3	1L I 3	1L I 3	1L I 3	1L I 3	ML150E21	1L15	1L15	1L15	1L15
	F4AE0481A	(170 HP)		~	~	~	~	~	~	~	2	~	~	~	~	~	2	~	~	~	~
	F4AE0681E	(170 HII) (180 HP)																			
	F4AE0681D	(210 HP)															•	•	•	•	•
	F4AE0681B	(240 HP)	•	•	•	•	•	•									-	-	-	-	-
	F4AE0681A	(275 HP)							•	•	•	•	•	•	•	•					
		3''																			
		4"															•	•	•	•	•
	Single plate —	3''/ 4''																			
		15''/16''	•	•	•	•	•	•	•	•	•	•	•	•	•	•					
	2855.6																				
	2865.6		1														•	•	•		
	2870.9																•	•	•	•	•
	2895.9		•	•	•	•	•	•	•	•	•	•	•	•	•	•					
V	FSO 5206B		•	•			•														
	MD 3060P																•	•	•		
	5845																				
	5842/5		•	٠	•	٠	•	•	•	٠	•	•	٠	٠	•	•					
	5851/5																•	٠	٠	٠	•
	5871/5																				
	MS08-125																				
	MS10-144		•	•	•	٠	•	٠	٠	•	•	•	•	•	•	•					
	MS10-164																•	٠	•	٠	•
	MS13-165																				
	SP145E																				
	ZF 8095		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	ZF 8098																				
L L P	TRW-TAS 55																				
<u> </u>	Mechanical front		•	•	•	•	•	•	•	•		•	•		•	•	•	•		•	•
	Mechanical Rear		•		•		•	•	•			•			•	•	•			•	
\bigcirc	Pneumatic front										•			•					•		
	Pneumatic rear		1	•		•				•	•		•	•				•	•		•
	Disk front		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	Disk rear		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	Drum rear																				

K = Dump body; R = Trailing vehicle; T = Tractor; P = Vehicles with pneumatic suspension on rear axle; FP = Vehicles with front and rear pneumatic suspension; D = Double cabin (6 + 1); $RS^* = Road Sweeper$


		MODELS 4 X 2	MLI 50E2 I R/FP	MLI 50E2 I K	MLI 50E2 I KR	MLI50E21RS*	MLI 50E24	MLI 50E24/P	MLI 50E24/FP	MLI 50E24R	MLI 50E24R/P	MLI 50E24R/FP	MLI 50E24K	MLI 50E24KR	MLI 50E28	MLI 50E28/P	MLI 50E28/FP	MLI 50E28R	MLI 50E28R/P	MLI 50E28R/FP	ML150E28K
UNITS			ML15	MLIS	MLIS	MLI5	MLI5	MLIS	MLIS	ML15	MLI5	MLIS	MLI5	MLI5	MLI5	MLIS	MLI5	MLI5	MLI5	MLI5	MLI5
	F4AE0481A	(170 HP)																			
	F4AE0681E	(180 HP)																			
	F4AE0681D	(210 HP)	•	•	•	•															
	F4AE0681B	(240 HP)					•	•	•	•	•	•	•	•							
	F4AE0681A	(275 HP)													•	•	•	•	•	•	•
		13''																			
		4''	•	٠	•	•															
Ī	Single plate –	3''/ 4''																			
	-	15''/16''					•	•	•	•	•	•	٠	•	•	•	•	•	•	•	•
	2855.6																				
	2865.6			٠																	
	2870.9		•	•	•	•															
	2895.9						•	•	•	•	٠	٠	•	•	•	•	٠	•	٠	•	•
v	FSO 5206B						•	•	•				٠								
	MD 3060P			٠			•	•	•				٠								
	5845																				
	5842/5																				
	5851/5		٠	٠	•	٠	•	•	•	•	•	٠	٠	•	٠	٠	٠	٠	٠	•	•
	5871/5																				
	MS08-125																				
	MS10-144																				
	MS10-164		•	٠	•	٠	•	•	•	•	•	٠	•	•	•	•	٠	٠	٠	•	•
	MS13-165																				
	SP145E																				Ш
	ZF 8095		•	•	•	•	•	•	•	•	•	•	٠	•	•	•	•	•	•	•	•
	ZF 8098																				
L Lagr	TRW-TAS 55																				
8 9	Mechanical front			•	•	•	•	•		•	•		•	•	•	•		•	•		•
	Mechanical Rear			•	•	•	•			•			٠	•	•			•			•
	Pneumatic front		•						•			•					•			•	
	Pneumatic rear		•					•	•		•	•				•	•		•	•	
	Disk front		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	Disk rear		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	Drum rear																				

K = Dump body; R = Trailing vehicle; T = Tractor; P = Vehicles with pneumatic suspension on rear axle; FP = Vehicles with front and rear pneumatic suspension; D = Double cabin (6 + 1); RS* = Road Sweeper

$\begin{array}{c c c c c c c c c c c c c c c c c c c $	MLI 80E28KR MI 760F78KF (6x4)
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	• •
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	• •
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	• •
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	• •
$\begin{array}{ c c c c c c c c c c c c c c c c c c c$	
$\begin{array}{ c c c c c c c c c c c c c c c c c c c$	
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	
F4AE0681A (275 HP) Image: Constraint of the second se	
I3" I3" I <td></td>	
Image: Single plate Image: Id'' Image: Id''' Image: Id''''	•
Single plate 13"/14" Image: Constraint of the second	•••
13 /14 13 /14 14 15 /16 1	• •
2855.6 • • • • • • 2865.6 • • • • • • 2870.9 • • • • • • 2895.9 • • • • • • FSO 5206B • • • • • •	• •
2865.6 • <td< td=""><td>┝──┼─</td></td<>	┝──┼─
2870.9 • <td< td=""><td></td></td<>	
Image: September 2895.9 • <	
FSO 5206B	
	• •
MD 3060P	
5845	
5871/5 • <td< td=""><td>• •</td></td<>	• •
MS08-125	
MS10-125	
MS10-164 •	
MS13-165	•
SPI45E	•
■ ZF 8095	
ZF 8098	• •
TRW-TAS 55	
O O Mechanical front	• •
Mechanical Rear	•
Pneumatic front	\vdash
Pneumatic rear	•
Disk front •	• •
Disk rear • • • • • • • • • • • • • • • • • • •	1
Drum rear	•

K = Dump body; R = Trailing vehicle; T = Tractor; P = Vehicles with pneumatic suspension on rear axle; FP = Vehicles with front and rear pneumatic suspension; D = Double cabin (6 + 1); $RS^* = Road Sweeper$; KE = HENDRICKSON rear suspensions

IDENTIFICATION DATA AND LOCATION ON VEHICLE




FILLING UP

LUBRICANTS RECOMMENDED BY IVECO		PARTS TO	FILLED UP	Quantity		
				_	Litres	kg
	Urania Turbo Urania LD5		Engine – 4 cyli	nders		
-			_	min.	5.3	4.8
				max	8.3	7.5
			[Ι	0.9
			Engine – 6 cyli	nders		
			_	min.	8	7.2
				max	10.8	9.7
			[I	0.9
0			Gearbox	2855.5	5.5	5
	Tutela ZC 90	٦		2865.6	9	8.1
-				2870.9	5	4.5
				2895.9	8.3	7.5
				FSO5206B	7	6.5
				MD3060P	28	25
	Tutela W140/M - DA		Front hubs (ind	dividual)	0.2	0.18
•			Rear axle	MS08-125 MS10-125 MS10-164 MS13-165 SP145E	6.5 ** .5/ 2* ** 2.2/ .7* ** 8/ 9*	5.85 ** 0.3/ 0.8* ** 0/ 0.5* ** 6.2/ 6.7*
	le with mechanical suspens le with pneumatic suspensi			Intermediate Rear	6.2 2.2	4.5
	Tutela GI/A		Power steering	ZF 8095 ZF 8098 TRWTAS5!	- -	- - -
Inclusion 100	Tutela TRUCK DOT SPECIAL		Clutch circuit		-	-
^{50%} (H₂0)+	Paraflu		Cooling systen Total capacity	١	-	-
	Tutela LHM	E.	Cab tipping sys	tem	-	-


INTERNATIONAL LUBRICANT DESIGNATION

Description	FL Products			
Engine oil Compliant with ACEA E2 specifications		Urania Turbo		
Engine oil Compliant with ACEA E3 and ACEA E5 speci	fications	Urania LD5		
Differential and wheel hub oil Compliant with MIL-L-2105 C and API GL-5 specifications	SAE 80W/90 SAE 85W/140	Tutela W 90/M-DA(Cold climates)Tutela W 140/M-DA(Hot and temperate climates)		
Manual gearbox oilSAE 80W/90Contains non EP wear resistant additivesCompliant with MIL-L2105 or API GL 3 specifications		Tutela ZC 90		
Automatic gearbox and power steering oil Compliant with A.T.F. DEXRON II specificatio	ns	Tutela GI/A		
Grease for general use Lithium-soap base grease, N.L.G.I. n. 2	Tutela MR 2			
Specific grease for bearings and wheel hubs Lithium-soap base grease, N.L.G.I. n. 3		Tutela MR 3		
Non-mineral base grease, compatible with bra suitable to lubricate brake system components	ake system materials and	SP 349		
Grease for general use, suitable for compone grease (e.g., joints, pins and pivots, levers, tie r callipers, etc.) Lithium-soap base grease, N.L.G.I. n. 2		Tutela Zeta 2		
Hydraulic brakes and clutch fluid Compliant with N.H.T.S.A. N. 116 ISO 4295 – SAE J 1703 CUNA NC 956-01 specifications and IVECO STANDARD 18-1820		Tutela TRUCK DOT SPECIAL		
Mineral oil for hydraulic circuits Wear resistant and very low pour point		Tutela LHM		
Window liquid, mixture of alcohols, water and CUNA NC 956-11	d surface-actives,	Arexons DPI		
Antifreeze, 50% concentration for temperatur	result to -35°	Paraflu I		

SECTION 2 Engine Page ENGINE IDENTIFICATION CODES 3 MAIN SERVICING OPERATIONS TO BE PERFORMED ON ENGINE FITTED ON 4 WARNINGS 4 High pressure CP3 pump 4 4 Rail and fittings 4 Injector 4 Low pressure tubing High pressure tubing 4 ENGINE REMOVAL-REFITTING 5 5 Removal 7 Refitting Tests and checks 7 7 Engine cooling filling system Air bleeding from fuel system 8 Air bleeding from hydraulic power steering system 8 INIECTORS REPLACEMENT 9 9 Removal 9 Refitting REPLACING SEAL RING FRONT COVER DRIVING SHAFT REPLACING SEAL RING FLYWHEEL 12 CYLINDER HEAD REMOVAL/REFITTING 13 13 Removal Refitting 15 Tests and checks 15 ENGINE F4 AE 0481 19 ENGINE F4 AE 0681 115 TROUBLESHOOTING GUIDE |4|



Base - February 2003



The flow limiter and the pressure limiting valve can be assembled 5 times consecutively before being replaced. They shall be lubricated with a little oil before assembling.

Lubricate the overpressure valve as well before assembling and always replace its gasket.

Injector

4

ENGINE

It is not necessary and permitted to disassemble the fuel nozzle or the electromagnet.

Always replace each high pressure tubing after disassembling it once.

Replace each fuel manifold after disassembling it once.

In case of clamping or loosening of the fixing connections, keep fuel manifolds, hydraulic accumulator (rail) and high pressure pump firmly fixed and the component-side hexagon firm, if there is enough space.

Replace involved piping in case of drippings.

ENGINE REMOVAL-REFITTING



Before removal/refitting disconnect battery cables and place the vehicle in safety conditions.

Removal




Lift the radiator cowling and overturn the cab. Remove gearbox as described in the relevant section and proceed as follows:


- Drain the engine coolant in a proper container.
- Drain the hydraulic steering system oil in a proper container.

From the engine left side:

- Disconnect tubings (18) from the compressor (13), the air cleaner and the turbine suction tubing (on the right side).
- Remove the suction tube (16) and its support by unscrewing the frame fastening nuts.
- Disconnect air tubing (15).
- Unscrew fastening screws (6), the nut (5), remove the clamp (4) and move the gear lever rightwards (17).
- Disconnect delivery (11) and return (10) tubing from the hydraulic steering pump.
- Loosen clamps (1) and remove the after-cooler tube (2).
- Disconnect fuel tubings; delivery tubings (9) from the control unit support and return ones (12) from the fuel filter support.
- Disconnect the oil pan tubing (3).
- Disconnect the connector (8) from the control unit and all those connections coming from the harness.










ENGINE


6








INJECTORS REPLACEMENT Removal






The disassembled fuel manifolds (4) shall never be used again but replaced with new ones.




Loosen fastening tappet register nuts (1) and unscrew registers.

Remove screws (2), rocker unit (3) consisting of support (6), rockers (4) and shafts (5) and remove bonds (7) from the valves.





Remove injector fastening screws and with the tool 99342101 (1) remove also the injectors (2) from cylinder heads.

Refitting




Assemble a new ring (2) lubricated with vaseline and a new washer (3) on the injector (1).





Fasten gradually and alternatively the injector fastening screws (1) to 8.5 ± 0.8 Nm torque with a dynamometrical wrench.

Fasten fuel manifold (3) fastening screws (2) to the 50 Nm torque.




Check that the tappet registers (1) are unscrewed to avoid problems with rods (7) during rocker unit (2) assembling. Place the bond on the valve (6).



The notches (\bullet) on the bonds shall be turned towards the exhaust manifold.

After, assemble rocker units (2) consisting of support (5), rockers (3) and shafts (4) and fix them to cylinder heads fastening the screws (8) to the Nm 36 torque.



Adjust clearance between rockers and valves through a setscrew wrench (1), box wrench (3) and feeler gauge (2).

The clearance amounts to:

± 0.05

 \Box suction valves 0.25 ± 0.05

exhaust valves 0.51 ± 0.05

To adjust more quickly the rocker-valve clearance, operate as follows:

Rotate driving shaft, balance cylinder No. I valves and adjust the valves marked with * as described in the tables:

4- cylinder engine

Cylinder No.		2	3	4
Suction	-	-	*	*
Exhaust	-	*	-	*

Rotate driving shaft, balance cylinder No. 4 valves and adjust the valves marked with * as described in the tables:

Cylinder No.		2	3	4
Suction	*	*	-	-
Exhaust	*	-	*	-

6-cylinder engine

Cylinder No.	Ι	2	3	4	5	6
Suction	-	-	*	-	*	*
Exhaust	-	*	-	*	-	*

Rotate driving shaft, balance cylinder No. 6 valves and adjust the valves marked with * as described in the tables:

Cylinder No.	Ι	2	3	4	5	6
Suction	*	*	-	*	-	-
Exhaust	*	-	*	-	*	-

Complete assembling inverting the operations requested for | removal, bearing in mind to:

- Fasten injector connector nuts to the prescribed torque;
- Assemble high and low pressure tubings according to the procedures described in the paragraph "main service operations to be performed on engine fitted on vehicle ";
- Fill the cooling system with cooling fluid and bleed as described before.



Check that the cooling fluid does not contain filth before using it; if it does, filter with appropriate net filters; in case of filling-ups, see the table REFUELING in the section "GENERAL".


Tests and checks



Start the engine, leave it in motion at a running rate little more than the minimum and wait that the cooling fluid temperature reaches the rate for the thermostat to be opened , then check that:


There are no water drippings from the connecting manifolds of the engine cooling tubing and the cab heating, fasten blocking collars further if necessary.

REPLACING SEAL RING FRONT COVER DRIVING SHAFT




Apply on the front tang (2) of the driving shaft fixture 99340055 (4) and through the guiding holes of the fixture itself, drill the internal seal ring (1) with a drill (\varnothing 3,5 mm) to a depth of 5 mm.


Fix fixture (4) to the ring (1) by means of the 6 screws in the kit e proceed with the removal of the ring by screwing up the screw (3).



Apply the proper rod (3) of fixture 99363204 to the external seal ring (2) as shown in the figure and use lever (4), to remove it from the front cover (1).



Apply on the front tang (6) of the driving shaft part (5) of fixture 99346252, fix it with screws (4) and key on it the new seal ring (3). Position part (1) on part (5), tighten nut (2) till complete assembly of seal ring (3) on the front cover (7).




Apply fixture 99340056 (3) on the rear tang (5) of the driving shaft and through the guiding holes of the fixture, drill the internal seal ring (1) with a drill (\emptyset 3,5 mm) to a depth of 5 mm.

Fix fixture (3) to the ring (1) by means of the 6 screws (4) in the kit e proceed with the removal of the ring by tightening the screw (2).

Perform the removal of the external seal ring as shown and described in figure 16/2.





Apply on the rear tang (6) of the driving shaft part (5) of 'fixture 99346253, fix it with screws (4) and key on it the new seal ring (3).

Position part (1) on part (5) tighten nut (2) until seal ring (3) is fully assembled into the flywheel housing box (7).


/!`

as follows:

Lift the radiator cowling, overturn the cab and operate

Drain partially the cooling fluid in an appropriate tin;

Disconnect the cooling fluid tubing (2) from



- thermostat cover; Disconnect the air tubing (3) from the suction
- manifold;
- Disconnect electrical connections;
 - (4), for heater

conditions.

- (12), for injectors
- (13), for water temperature sensor;
- (5) air temperature/pressure sensor;
- (14), air from the rail pressure sensor;
- Remove the part of air tubing (15) from the remaining tubing, from the compressor (8) and from the bracket;
- Remove the cooling fluid tubing (9) from the compressor (8);
- Remove oil breathe pipes (11) from tappet cover (|);
- Disconnect exhaust fuel tubing (10) from pressure adjusting valve;
- Remove high pressure tubing (7) from the rail and high pressure pump (6).

- Remove air-conveyor (9) from turbosupercharger (3) and intercooler radiator (10);
- Disconnect cooling fluid tubings (1)
- For vehicles with air-conditioning:
- Operating on the automatic tightener (11), loosen the compressor (13) belt tension (12);
- Remove compressor fastening screws (13) to the support and fix the compressor (13) accurately to avoid gas tubing damages in the air-conditioning system;

For all types of vehicles:

14 ENGINE

Remove heat protection (8);

Remove exhaust tubing fastening screws (5) and exhaust brake throttle valve (4) from the turbosupercharger (3), taking care to fasten the latter to the frame;

Remove the air tubing bracket fastening screws (2);

- Disconnect oil tubing from the turbosupercharger (3);
- Remove exhaust manifold fastening screws (14) from the cylinder heads and remove it with the turbosupercharger (3).


Close the oil and air inlet/outlet holes in the turbosupercharger to avoid damages caused by external bodies in it.

Remove injectors as described before;

Remove rocker control rods (6);

Remove cylinder head fastening screws (7).

Place the rocker 99360585 to the cylinder head lifting bracket. Hook it to the lifter and remove cylinder heads.




Refitting

For refitting invert the operations requested for removal and follow these warnings:

Check that the cylinder head attack surface and the base are clean;

Do not dirty the cylinder head gasket;

Assemble cylinder head, fasten and clamp the screws in three steps, as described in the following figures.



Assemble injectors as described in the appropriate chapter.

Assemble high and low pressure tubing as described in the paragraph "main service operations to be performed on engine fitted on vehicle".

- Check manifold, cooling fluid and air-conveyor conditions and replace them in case of damage;
- Fasten the screw to the prescribed torque;
- Fill the cooling system with cooling fluid and bleed as described before.

Check that the cooling fluid does not contain filth before using it; if it does, filter with appropriate net filters; in case of filling-ups, see the table REFUELING in the section "GENERAL".


Tests and checks



Start the engine, leave it in motion at a running rate little more than the minimum and wait that the cooling fluid temperature reaches the rate for the thermostat to be opened , then check that:

- ☐ There are no water drippings from the connecting manifolds of the engine cooling tubing and the cab heating, and fasten by blocking collars further if necessary.
- Low pressure fuel tubing connections and its unions are correct, as described in "main interventions on an assembled vehicle".
- There are no oil drippings between cylinder cover and head, oil pan and base, heat exchanger oil filter and lubrication circuit tubings.
- There are no fuel leakages from fuel tubings.
- There are no air losses from pneumatic tubings.
- The warning lights on the instrument panel and the devices disassembled during the engine removal work correctly.

ENGINE F4 AE 0481



Engine F4 AE 0481

GENERAL SPECIFICATIONS	Page 21
ASSEMBLY DATA – CLEARANCES	24
TIGHTENING TORQUE	30
AUXILIARY COMPONENTS	32
TOOLS	33
ENGINE OVERHAUL	40
DISASSEMBLY OF THE ENGINE AT THE BENCH	40
REPAIR INTERVENTIONS	48
CYLINDER GROUP	48
Controls and measurements	48
Head face check on the cylinder group	49
	49
🔲 Camshaft	49
Cam lift check and pin alignment check	50
BUSHES	50
Bush replacement	51
 Tappets	51
Fitting tappets – camshaft	51
OUTPUT SHAFT	52
Measuring journals and crankpins	52
Replacing oil pump control gear	54
Fitting main bearings	54
Finding journal clearance	54
Checking output shaft shoulder clearance	55
CONNECTING ROD – PISTON ASSEMBLY	55
Pistons	56
Measuring piston diameter	56
Piston pins	57
Conditions for proper pin-piston coupling	57
Split rings	57
Connecting rods	58
Bushes	58
Checking connecting rods	59
Checking torsion	59

	Checking bending	Page 59					
	Fitting connecting rod-piston assembly	59					
	Connecting rod-piston coupling						
	Fitting split rings	60					
	Fitting connecting rod-piston assembly into cylinder barrels	60					
	Finding crankpin clearance	61					
	Checking piston protrusion	62					
	Timing gear case	62					
	Timing	63					
	Flywheel housing	63					
EN	GINE FLYWHEEL	64					
	Replacing engine flywheel ring gear	64					
CYI	INDER HEAD	68					
	Removing the valves	68					
	Checking cylinder head wet seal	69					
	Checking cylinder head supporting surface	69					
VAI	_VES	70					
	Removing carbon deposits, checking and grinding valves	s 70					
	Checking clearance between valve stem and valve guide and valve centering	70					
VAI	_VE GUIDE	71					
VAI	_VE SEATS	71					
	Regrinding – replacing the valve seats	71					
VAI	_VE SPRINGS	73					
FIT	TING CYLINDER HEAD	73					
	Refitting the cylinder head	73					
	Fitting injectors	74					
RO	DS	75					
	Rocker assembly	75					
	Tappet clearance adjustment	76					
	Intake manifold	77					
	Wiring support	79					
LUE	BRICATION	83					
	. PUMP	85					
-	AT EXCHANGER	85					
	Oil pressure relief valve	86					

	Page
Oil vapour recycling	87
	89
U Water Pump	91
Viscous fan	91
Thermostat	92
BOOSTER	92
Turbosupercharger	92
Description	92
TURBOSUPERCHARGER ACTUATOR	93
Check and adjustment	93
Actuator replacement	93
TURBOSUPERCHARGER LAYOUT	95
COMMON RAIL	97
General Specifications	97
FEED SYSTEM	99
FEED SYSTEM LAYOUT	101
FUEL PREFILTER	103
FUEL FILTER	103
MECHANICAL SUPPLY PUMP	104
Normal operating conditions	104
Overpressure condition at outlet	104
Drain conditions	104
CP3 HIGH-PRESSURE PUMP	105
HIGH-PRESSURE PUMP - INSIDE S TRUCTURE	106
• Operating principle	107
Operation	109
RAIL	109
OVERPRESSURE VALVE	110
FLOW LIMITERS	110
INJECTOR	111

Injector in rest position

Injection start

Injection end PRESSURE LIMITER FOR FUEL RETURN

Base - February 2003

||||

GENERAL SPECIFICATIONS

	Туре		F4AE0481A (.17)
≜	Cycle		4 –stroke Diesel
	Power Supply		Intercooler supercharged
	Injection		Direct
	Cylinder number		4 in line
	Bore	mm	102
	Stroke	mm	120
ĨĨ +]Ĩ +]Ĩ + =	Total displacement	cm ³	3900
<u>Q</u>	Compression ratio		17:1
	Max power	kW (CV)	25 (170)
		rpm	2700
	Max. torque	Nm (kgm)	560 (57.1)
		rpm	1200
	Idle engine minimum rpm	rpm	750
	Idle engine peak		
	rpm	rpm	3000

	Туре			0481A 7)
	SUPERCHARGER		With int	ercooler
UB	Turbosupercharger ty	ре	GARRET	T GT 22
Furbosupercharger shaft ra Furbosupercharger shaft e Pressure relief valve min. o	nd play	mm		-
Pressure relief valve max. c	opening stroke:			
Pressure corresponding to Pressure corresponding to		mm bar bar		- - -
	LUBRICATION		Forced by gear pump , prostage c	essure relief valve, double bil filter
bar	Oil pressure with wan engine: - idling - peak rpm	m bar bar		.2 .8
COOLING	F		By centrifugal p thermostat, radiato	ump, regulating
	Water pump control		Throu	gh belt
	Thermostat - start of opening - maximum opening			2° C ° C
👝 Urania Turbo	FILLING Total capacity I st filling:			
Urania LD5		liters kg		-
-	- engine sump	liters kg	Min. level. 5.3 4.8	Max. level 8.3 7.5
	- engine sump + filter	liters	6.3	9.3
		kg	5.7	8.4

Туре		F4AE0481A (.17)
TIMING		
start before T.D.C. end after B.D.C.	A B	8.5° 8.5°
start before T.D.C. end after B.D.C.	D C	51° 12.5°
Checking timing X	mm mm	-
Checking operation X	mm mm	0.20 ÷ 0.30 0.46 ÷ 0.56
FUEL FEED		
Injection	Bosch	high pressure common rail EDC7 ECU
Nozzle type		Injectors
Injection sequence		- 3 - 4 - 2
Injection pressure	bar	250 - 1450
	TIMING start before T.D.C. end after B.D.C. start before T.D.C. end after B.D.C. Checking timing X Checking operation X FUEL FEED Injection Type: Nozzle type Injection sequence	TIMING start before T.D.C. end after B.D.C. Start before T.D.C. end after B.D.C. Checking timing X Checking operation X Injection Type: Bosch Injection sequence

ASSEMBLY DATA – CLEARANCES

	Туре		F4AE0481A (.17)
CYLINDER UNIT AND CRA	ANKSHAFT COMPONE	NTS	mm
	Cylinder barrels –	ØI	02.009 ÷ 02.03
	Spare pistons type: Size Outside diameter Pin housing	X Ø I Ø 2	60,5 0 .78 ÷ 0 .799 40.008 ÷ 40.0 4
	Piston – cylinder barrels	5	0.116 ÷ 0.134
	Piston diameter	ØI	0.5
	Piston protrusion	Х	0.28 ÷ 0.52
Ø3	Piston pin	Ø 3	39.9938 ÷ 40.0002
	Piston pin – pin housing	5	0.0078 ÷ 0.0202

	Туре		F4AE0481A (.17)	
CYLINDER UNIT AND CR	ANKSHAFT COMPO	NENTS	mm	
	Split ring slots	X * X 2 X 3	2.705 ÷ 2.735 2.420 ÷ 2.440 4.020 ÷ 4.040	
$\square \square \square \blacksquare \blacksquare$	Split rings	S * S 2 S 3	2.560 ÷ 2.605 2.350 ÷ 2.380 3.975 ÷ 4.000	
	* measured on 98 m	m Ø		
	Split rings - slots	 2 3	0.100 ÷ 0.175 0.040 ÷ 0.90 0.020 ÷ 0.065	
	Split rings		0.5	
$\mathbf{b} = \begin{bmatrix} \mathbf{x}_1 \\ \mathbf{x}_2 \\ \mathbf{x}_3 \end{bmatrix}$	Split ring end openin in cylinder barrel:	g X I X 2 X 3	$030 \div 0.40$ $0.60 \div 0.80$ $0.25 \div 0.55$	
ØI ØI	Small end bush housing Big end bearing housing	Ø I Ø 2	42.987 ÷ 43.013 72.987 ÷ 73.013	
	Small end bush diam Outside Inside Spare big end half bearings	eter Ø4 □Ø3 S	43.279 ÷ 43.553 40.019 ÷ 40.033 1.955 ÷ 1.968	
Ś	Small end bush – hou	using	0.266 ÷ 0.566	
	Piston pin – bush		0.0188 ÷ 0.0392	
	Big end half bearings		0.250 ÷ 0.500	

	Туре		F4AE0481A (.17)
	ANKSHAFT COMPONE	NTS	mm
	Size Max. tolerance on connecting rod axis alignment	×	-
	Journals Crankpins Main half bearings Big end half bearings *provided as spare part	Ø I Ø 2 S I S 2	82.99 ÷ 83.01 68.997 ÷ 69.013 2.456 ÷ 2.464 1.955 ÷ 1.968
Ø 3	Main bearings No. 1-3-4-5 No. 2	Ø 3 Ø 3	87.982 ÷ 88.008 87.982 ÷ 88.008
	Half bearings – Journals No. 1-3-4-5 No. 2 Half bearings - Crankpir	15	0.04 ÷ 0.103 0.04 ÷ 0.103 0.033 ÷ 0.04
NECO	Main half bearings Big end half bearings		0.250 ; 0.500
	Shoulder journal	ХІ	37.475 ÷ 37.545
×2	Shoulder main bearing	X 2	32.23
<u>×3</u>	Shoulder half-rings	Х 3	32.30
	Output shaft shoulder		0.07

	Туре		F4AE0481A
	C SYSTEM		(.17) mm
	Valve guide seats on cylinder head	ØI	7.042 ÷ 7.062
Ø 4	Valves:		
		Ø2 α	6.970 ÷ 6.990 60° ± 0.25°
α		Ø2 α	6.970 ÷ 6.990 45° ± 0.25°
	Valve stem and guide		0.052 ÷ 0.092
10 - 10	Housing on head for valve seat:		
		ØI	34.837 ÷ 34.863
Ø I		ØI	34.837 ÷ 34.863
Ø 2	Valve seat outside valve seat angle on head:		
		Ø2 α	34.917 ÷ 34.931 60°
α	\succ	Ø2 α	34.917 ÷ 34.931 45°
		$\times \Box$	0.59 ÷ 1.11
×	Sinking	\times	0.96 ÷ 1.48
	Between valve seat		0.054 ÷ 0.094
ـــــــــــــــــــــــــــــــــــــ	and head		0.054 ÷ 0.094
	Valve seats		-

	Туре	F4AE0481A (.17)
CYLINDER HEAD - TIMIN	G SYSTEM	mm
Û	Valve spring height:	
	free spring H	47.75
	under a load equal to: 339.8 ± 19 N H1 741 ± 39 N H2	35.33 25.2
× ¥	Injector protrusion X	It cannot be adjusted
	Camshaft bush housings No. 1-5	59.222 ÷ 59.248
	Camshaft housings No. 2-3-4	59.222 ÷ 59.248
	Camshaft journals: I ⇒ 5 Ø I-2-3	53.995 ÷ 54.045
Ø	Camshaft bush outside diameter with a load of 3.3 kN: Ø	59,222 ÷ 59,248
Ø	Bush inside diameter after ramming Ø	54.083 ÷ 54.147
Ś	Bushes and housings on block	0,113 ÷ 0,165
	Bushes and journals	0.038 ÷ 0.152
	Cam lift:	
H H	н	6.045
\bigcirc	⊏∑ н	7.582

	Туре	F4AE0481A (.17)
YLINDER HEAD - TIMI	NG SYSTEM	mm
ØI	Tappet cap housing on block Ø I	16.000 ÷ 16.030
	Tappet cap outside diameter: Ø 2 Ø 3	15.924 ÷ 15.954 15.960 ÷ 15.975
	Between tappets and housings	0.025 ÷ 0.070
	Tappets	-
	Rocker shaft Ø I	21.965 ÷ 21.977
Ø 2	Rockers Ø 2	22.001 ÷ 22.027
	Between rockers and shaft	0.024 ÷ 0.162


TIGHTENING TORQUE


PART		TORQUE	
		Nm	kgm
Cylinder barrel lubrication nozzle fixing screw M8		15 ± 3	1.5 ± 0.3
Engine shaft cap fixing screw M12	l st phase	50 ± 6	5 ± 0.6
	2 nd phase	80 ± 6	8 ± 0.6
	3 rd phase	90° ± 5°	
Stud bolts M6 for camshaft sensors		8 ± 2	0.8 ± 0.2
Stud bolts M8 for power supply pump		12 ± 2	1.2 ± 0.2
Rear gearcase fixing screw M12		77 ± 12	7.7 ± 1.2
Rear gearcase fixing screw M10 Rear gearcase fixing screw M8		47 ± 5 24 ± 4	4.7 ± 0.5 2.4 ± 0.4
Camshaft sensor fixing nut M6		10 ± 2	1 ± 0.2
	l st phase	8 ± 1	1 ± 0.2 0.8 ± 0.1
Oil pump fixing screw M8	2 nd phase	24 ± 4	0.8 ± 0.1 2.4 ± 0.4
Front cover fixing screw M8	2 p.1000	24 ± 4	2.4 ± 0.4
Screw M8 for camshaft longitudinal check plate fixing		24 ± 4	2.4 ± 0.4
Camshaft gear fixing screw M8		36 ± 4	3.6 ± 0.4
Connecting rod cap fixing screw M11	I st phase	60 ± 5	6 ± 0.5
Connecting for cap inving screw () ()	2 nd phase		° ± 5°
Underblock plate fixing screw M10		43 ± 5	4.3 ± 0.4
Nut M8 for high pressure pump gear fixing		105 ± 5	10.5 ± 0.5
Fuel pump fixing nuts M8		24 ± 4	2,4 ± 0,4
1⁄2 inch plug on the cylinder head		24 ± 4	2.4 ± 0.4
$\frac{1}{4}$ inch plug on the cylinder head		36 ± 5	3.6 ± 0.5
$\frac{3}{4}$ inch plug on the cylinder head		12 ± 2	1.2 ± 0.2
Injector fixing screws M6		8.5 ± 0.35 0.35 ± 0.035 75° ± 5°	
		50 ± 5	2 ± 5° 5 ± 0.5
Union fixing nut for injector power supply Pre-heating grid nut M6 on the suction manifold		8 ± 2	0.8 ± 0.2
Suction manifold fixing screw M8		24 ± 4	0.8 ± 0.2 2.4 ± 0.4
Rear bracket fixing screw M12 for engine lifting		77 ± 12	7.7 ± 1.2
Common rail fixing M8 screws		24 ± 4	7.7 ± 1.2 2.4 ± 0.4
High-pressure fuel pipe unions M14		20 ± 2	2.4 ± 0.4 2 ± 0.2
Cylinder head fixing M12 screw (12x1.75x 130)		35 ± 5	2 ± 0.2 3.5 ± 0.5
, 3	I st phase		
Cylinder head fixing M12 screw (12x1.75x 150)	J	55 ± 5	5.5 ± 0.5
	2 nd phase	90° ± 5° 90° ± 5°	
	3 rd phase		
Equalizer support fixing screw		36 ± 5	3.6 ± 0.5
Valve clearance adjustment nut		24 ± 4 20 ± 2	2.4 ± 0.4
Power supply pipe fixing nuts M14 from common rail hig	gn pressure pump		2 ± 0.2 2.4 ± 0.4
High pressure pipe union fixing screw M8		24 ± 4 10 ± 2	2.4 ± 0.4 ± 0.2
Head bulkhead fixing screw M6 for harness	workupply	10 ± 2 24 ± 4	1 ± 0.2 2.4 ± 0.4
Electric harness support fixing screw M8 for injector power supply		1.5 ± 0.25	2.4 ± 0.4 0.15 ± 0.025
Harness fixing nuts on individual injector		1.5 ± 0.25	0.15 ± 0.025 7.7 ± 0.8
Fuel filter-holder bracket fixing screw M8			
Fuel filter-holder fixing screw M8		24 ± 4 2.4 ± 0.4 contact + $\frac{3}{4}$ turn	
Fuel filter	il filton auna art		
Oil pressure adjustment valve fixing screw M22 on the oil filter support		80 ± 8	8 ± 0.8
Oil filter support and gasket radiator fixing screw M8		24 ± 4	2.4 ± 0.4 + $\frac{3}{4}$ turn


PART		TORQUE	
		Nm	kgm
I I/8 inch connection on filter support for turbine lub	prication	24 ± 4	2.4 ± 0.4
Pipe fixing nut M12 for turbine lubrication		10 ± 2	1 ± 0.2
Engine coolant input connection fixing screw M10		43 ± 6	4.3 ± 0.6
90° curve fixing (as necessary) on engine fluid input o	connection	24 ± 4	2.4 ± 0.4
Pipe on cylinder head for supercharger cooling		22 ± 2	2.2 ± 0.2
Union fixing screw M6 for engine coolant exhaust		10 ± 2	± 0.2
Pin fixing on engine block for exhaust manifold		10 ± 2	± 0.2
Exhaust manifold fixing screw M10 on cylinder head		53 ± 5	5.3 ± 0.5
Adapter fixing screw M12 for damper and damper on engine shaft	l st phase 2 nd phase	50 ± 5	5 ± 0.5 90°
Pulley fixing screw M10 on engine shaft		68 ± 7	6.8 ± 0.7
Water pump fixing screw M8		24 ± 4	2.4 ± 0.4
Auxiliary part control belt screw coupling fixing screv	v MIO	43 ± 6	4.3 ± 0.6
Fixed pulley fixing screw M10 for auxiliary part contr	ol belt	43 ± 6	4.3 ± 0.6
Flywheel housing fixing screw M10		85 ± 10	8.5 ± 1
Flywheel housing fixing screw M12		49 ± 5	4.9 ± 0.5
Heating exchanger fixing screw M6 for control unit		10 ± 2	± 0.2
Heating exchanger fixing screw M8 for control unit		24 ± 4	2.4 ± 0.4
Input-output connection M12 for fuel on the heating exchanger		12 ± 2	1.2 ± 0.2
Valve cover fixing nut M8		24 ± 4	2.4 ± 0.4
Camshaft sensor fixing screw M6		8 ± 2	0.8 ± 0.2
Engine shaft sensor fixing screw M6		8 ± 2	0.8 ± 0.2
Engine coolant temperature sensor fixing screw M14		20 ± 3	2 ± 0.3
Oil temperature-pressure sensor fixing screw M5		6 ± 1	0.6 ± 0.1
Fuel pressure sensor fixing screw		35 ± 5	3.5 ± 0.5
Fuel temperature sensor fixing screw M14		20 ± 3	2 ± 0.3
Air pressure/temperature sensor fixing screw on suction manifold		6 ±	0.6 ± 0.1
Engine oil level sensor fixing screw M12		2 ± 2	1.2 ± 0.2
6 cylinders { pins nut Turbine fixing to the exhaust manifold	pins MIO nuts MIO	7 ±	0.7 ± 0.1
		43 ± 6	4.3 ± 0.6 0.7 ± 0.1
4 cylinders	f pins M8 Linuts M8	7 ± I 24 ± 4	0.7 ± 0.1 2.4 ± 0.4
		35 ± 5	3.5 ± 0.5
Adapter M12 on turbine for (input) lubricant oil pipes Pipe fixing on adapter M10 for turbine lubrication		35 ± 5	3.5 ± 0.5 3.5 ± 0.5
		43 ± 6	3.3 ± 0.3 4.3 ± 0.6
Oil pipe fixing on adapter M10 for block turbine lubrication		24 ± 4	$+.3 \pm 0.8$ 2.4 ± 0.4
M8 oil exhaust pipe fixing on turbine		10 ± 2	2.4 ± 0.4
Fixing union M6 for oil return from the cylinder head to the flywheel housing		10 ± 2 30 ± 4	1 ± 0.2 3 ± 0.4
Engine flywheel fixing screw M12	l st phase 2 nd phase		3 ± 0.4 ' ± 5°
Front bracket fixing screw M8 for engine lifting		24 ± 4	2.4 ± 0.4
Engine oil torque fixing screw		24 ± 4	2.4 ± 0.4


AUXILIARY COMPONENTS


PART	TORQUE		
	Nm	kgm	
Air supercharger:			
Control gear 5/8 inch fixing nut on the supercharger shaft	125 ± 19	2.5 ± .9	
Fixing nut MI2 to the flywheel housing	77 ± 12	7.7 ± 1.2	
Alternator:			
Bracket fixing nut M12 on the water input union	43 ± 6	4.3 ± 0.6	
Alternator fixing nut MI0	43 ± 6	4.3 ± 0.6	
Climate control:			
Bracket fixing screw M10	43 ± 6	4.3 ± 0.6	
Supercharger fixing screw M10	24 ± 4	2.4 ± 0.4	
Starter:			
Starter fixing screw	43 ± 6	4.3 ± 0.6	
























The pipe (3) from the union (4) and from the supercharger (8).

Remove the fuel pipe (2) from the rail and from the high-pressure pump (9) and remove it from the engine block, by removing the fixing screws (4 and 6)

Whe to pr pum

When unlocking the pipe (2) union (7), it is necessary to prevent the union (10) rotation of the high-pressure pump (9), by using the proper wrench.

On the right side




Remove the screws (2) and remove the oil pipe (3) from the supercharger pipe (1) and from the engine block.

Remove the starting engine (5) from the flywheel cover (4).


Apply to the block the bracket 99361037 and fix by means of these latter the engine to the revolving stand 99322205. Drain the engine oil by removing the plug from the sump.

Remove the fan from the engine shaft pulley.



 Connections for injectors - 2. Engine coolant temperature sensor - 3. Fuel pressure sensor - 4. Engine oil pressure and temperature sensor - 5. Engine shaft sensor - 6. Injector - 7. Temperature-air pressure sensor - 8. Timing phase sensor -9. Fuel temperature sensor and fuel heater - 10. Pressure adjuster - 11. Control unit EDC7

Disconnect the engine wire by disconnecting the connectors: (1) from the injector harness (6); (7) air temperature /pressure sensor: (3) fuel pressure sensor; (11) control unit; (10) high pressure pump sensor; (8) timing phase sensor; (2) engine coolant temperature sensor on thermostat (5) rpm sensor;




procedures described in Figure 4. Remove the fuel pipe (5) from the rail (2) and from the manifolds (6) for injectors.



During the unlocking operation of the pipe (6) fixing unions (4) from the rail (2), it is necessary to prevent the possible flow limiting device rotation (3) by means of a proper wrench.

Remove the screws (1) and the rail (2).




Remove from the fuel return pressure limiting device (1), the pipe (2) as described in Figure 4.

Remove the pipe (4) from the air supercharger (3) and from the union (5). Remove the nut (10) Loosen the elastic hose clamp (6) and remove the oil vapor pipe (9).

Remove the unions (13-11) and remove the pipe (12).

Remove the nuts (7) and remove the tappet (8) cover complete of gasket.




Remove the nuts (7) and disconnect the electric wires from the injectors (8).

Remove the screws (1) and remove the injector harness support (2) complete of gasket.

Remove the screws (5) and remove the air pressure/temperature sensor (6).


Remove the nuts (3) and withdraw the fuel manifolds (4).

The removed fuel manifold (4) shall not be used again and they must be replaced by new ones.




Loosen the tappet adjuster fixing nuts (1) and unscrew the adjuster.


Remove the screws (2), remove the equalizer unit (3) composed by the support (6), equalizers (4), shafts (5) and remove the bonds (7) from the valves. Remove the rods (8)



Remove the injector fixing screws and by means of tool 99342101 (1) withdraw the injectors (2) from the cylinder head.



Remove the screw (4), loosen the clamp (2) and remove the air conveyor (1) from the turbosupercharger (3)




Remove the oil pipe (5) check clamp fixing screw (4) from the exhaust manifold (1).

Remove the oil pipe (5) from the oil filter/ heating exchanger support (7).

Remove the nuts (2) and remove the turbosupercharger (3) from the exhaust manifold (1).

Remove the screws (6) and remove the exhaust manifold (1) from the cylinder head.




Remove the screws (1) and remove the air conveyor (2) complete of heater. Remove the screws (4), remove the cover (3) and the relevant thermostat.

Remove the head cylinder (6) fixing screws (5).




The external screws pointed out are shorter.



70137


Hook the brackets (1) with metal ropes and remove the cylinder head (2) from the block by means of a hoister.





Remove the cylinder head gasket (1).


Loosen the stretch of the belt (2) by means of a proper wrench, operating the automatic belt tightener (3) and remove the belt.

Remove the screw (4) and the automatic tightener (3).













Remove the screws (5) and remove the rpm sensor (6).











Remove the screws (1) and remove the camshaft (3) check plate (2)




Write down the plate (2) assembling position.



Carefully withdraw the camshaft (1) from the engine block.



Withdraw the tappets (1) from engine block. Base - February 2003



70166


Carefully clean the cylinder-block group, when performed the engine disassembly.

Use the proper rings to transfer the cylinder group.

Carefully check that the block does not present any cracks. Check the working plug conditions. Replace them if they are rusty or in case of doubt about their conditions.

Examine the cylinder barrel surfaces; they must not present any seizing, scoring, ovalization, taper, and excessive wearing traces.


The internal diameter check of the cylinder barrels, to verify the ovalization, taper and wearing entity, is performed by means of bore meter 99395687 (1) equipped with comparator previously set to zero on the ring gauge (2) of the cylinder barrel diameter.



The measurements must be performed for each individual cylinder at three different heights from the barrel and on two perpendicular surfaces: one parallel to the longitudinal engine axis (A) and the other one perpendicular (B); usually the max wear is detected on this latter surface and in correspondence with the first measurement.

If you detect any ovalization, taper or wear, ream and grind the cylinder barrels. The cylinder barrel regrinding must be performed in relation to the diameter of the spare pistons oversized of 0.5 mm in respect of the nominal value and prescribed assembling clearance.


70170




70169

541211 Cam lift check and pin alignment check

Position the shaft on counterpoints and, by means of a centesimal gauge, located on the central support, check that the alignment error is not higher than 0.04 mm: on the contrary, replace the shaft. Then, check the cam lifting: it must result of 6.045 mm for the exhaust ones and of 7.582 mm for the suction ones; if you detect different values, replace the shaft.



Check the camshaft (2) support pin diameter by means of a micrometer (1) on two perpendicular surfaces.




The camshaft bushes (2) must result forced in their relevant seats.

The inner surfaces must result without seizing and wearing traces.

By means of a bore meter (3), measure the diameter of the rear and front bushes (2) and intermediate seats (1) for camshaft.

The measurements must be performed on two perpendicular axes.

Figure 52




* Dimensions to be obtained after the bush driving


70176


L


70164



70238








549215 Replacing oil pump control gear

Check that gear toothing (1) is not damaged or worn, otherwise remove it using the proper puller (3).

When fitting the new gear, heat it to 180°C for 10 minutes in an oven and then key it to the output shaft.

Fitting main bearings



Main bearings (1) are supplied spare with $0.250-0.500\;\text{mm}$ undersize on the internal diameter.




Do not try to adapt the bearings.

Clean accurately the main half bearings (1) having the lubricating hole and fit them into their housings.


The second last main half bearing (1) is fitted with shoulder half rings.

540811 Finding journal clearance




Refit the output shaft (2).

Check the backlash between output shaft main journals and the relevant bearings as follows:




- $\hfill\square$ Clean accurately the parts and remove any trace of oil;
- position a piece of calibrated wire (3) on the output shaft pins (4) so that it is parallel to the longitudinal axis;

fit caps (1), including the half bearings (2) on the relevant supports.




Tighten the pre-lubricated screws (1) in the following three successive stages:

Ist stage, with dynamometric wrench to 50 ± 6 Nm.
 2nd stage, with dynamometric wrench to 80 ± 6 Nm.




Checking output shaft shoulder clearance





This check is performed by setting a magnetic-base dial gauge (2) on the output shaft (3) as shown in the figure, standard value is 0.068 - 0.41 mm.


If higher value is found, replace main thrust half bearings of the second last rear support (1) and repeat the clearance check between output shaft pins and main half bearings.

540830 CONNECTING ROD – PISTON ASSEMBLY









Check the clearance between the sealing rings (3) of the 2^{nd} and 3^{rd} slot and the relevant housings on the piston (2), using a feeler gauge (1).






DIAGRAM FOR MEASURING THE CLEARANCE X BETWEEN THE FIRST PISTON SLOT AND THE TRAPEZOIDAL RING

Since the first sealing ring section is trapezoidal, the clearance between the slot and the ring shall be measured as follows: make the piston (1) protrude from the engine block so that the ring (2) protrudes half-way from the cylinder barrel (3).


In this position, use a feeler gauge to check the clearance (X) between ring and slot: found value shall be the specified one.






- fit the connecting rod (1) on tool 99395363 (5) spindle and lock it with screw (4);
- set the spindle (3) on V-blocks by resting the connecting rod (1) on the stop bar (2).

Checking torsion



Check connecting rod (5) torsion by comparing two points (A and B) of pin (3) on the horizontal plane of the connecting rod axis.

Position the dial gauge (2) support (1) to obtain a preload of approx. 0.5 mm on the pin (3) in point A and then set the dial gauge (2) to zero. Move the spindle (4) with the connecting rod (5) and compare any deviation on the opposite side (B) of the pin (3): the difference between A and B shall not exceed 0.08 mm.




Check connecting rod (5) bending by comparing two points C and D of the pin (3) on the vertical plane of the connecting rod axis.

Position the vertical support (1) of the dial gauge (2) to rest the latter on pin (3), point C.


Move the connecting rod forwards and backwards to find pin top position, then in this condition reset the dial gauge (2). Move the spindle with the connecting rod (5) and repeat the check of the top point on the opposite side D of the pin (3). The difference between point C and point D shall not exceed 0.08 mm.

Fitting connecting rod-piston assembly Connecting rod-piston coupling



The piston crown is marked as follows:

- 1. Part number and design modification number;
- 2. Arrow showing piston assembling direction into cylinder barrel, this arrow shall face the front key of the engine block;
- 3. Marking showing 1st slot insert testing;
- 4. Manufacturing date.





2

0 0

0

0






If a different clearance value is found, replace the half bearings and repeat the check.

Once the specified clearance has been obtained, lubricate the main half bearings and fit them by tightening the connecting rod cap fastening screws to the specified torque.

Before the final fitting of the connecting rod cap fastening screws, check that their diameter measured at the centre of the thread length is not < 0.1 mm than the diameter measured at approx. 10 mm from screw end.


Check manually that the connecting rods (1) are sliding axially on the output shaft pins and that their end float, measured with feeler gauge (2) is 0.10 - 0.33 mm.

Checking piston protrusion



Once connecting rod-piston assemblies refitting is over, use dial gauge 99395603 (1) fitted with base 99370415 (2) to check piston (3) protrusion at T.D.C. with respect to the top of the engine block.

Protrusion shall be 0.28 - 0.52 mm.



IVECO N. 2992545 SEALANT APPLICATION AREAS

Clean accurately the timing gear case (1) and the engine block.

Perfect seal is only obtained by cleaning accurately the surface to seal.

Smear the case with IVECO N. 2992545 to obtain a bead of few mm diameter.

It shall be uniform (no clots), without air bubbles, thin areas or discontinuities.

Any imperfection shall be corrected as soon as possible.

Avoid to use excess material to seal the joint.

Excessive sealant could come out from joint sides and cause lubricant passage clogging.

After applying the sealant, the joint shall be assembled immediately (10 - 20 minutes).




DIAGRAM FOR TIGHTENING THE REAR TIMING GEAR CASE FASTENING SCREWS


Refit the case (1) to the engine block.

Screw the fastening screws in the same position found at removal and tighten them to the following torque values in the sequence shown in the figure:


Screws MI2	65 - 89 Nm
Screws M8	20 - 28 Nm
Screws MI0	42 - 52 Nm

Timing Figure 103 I CO I CO CO TOULING T

Use a felt pen to mark the driving gear (1) tooth fitted on the output shaft (2) having the mark (\rightarrow) for timing on the side surface.



Direct the output shaft (4) and the camshaft (2) so that when fitting the driven gear (1) on the camshaft the marks on the gears (1 and 3) are coinciding.



540460 Flywheel housing Figure 106

70214

IVECO N. 2992545 SEALANT APPLICATION AREAS

Clean accurately the flywheel housing (1) and timing gear case coupling surfaces.

Perfect seal is only obtained by cleaning accurately the surface to seal.

Smear housing (1) with IVECO N. 2992545 to obtain a bead of few mm diameter.


It shall be uniform (no clots), without air bubbles, thin areas or discontinuities.

Any imperfection shall be corrected as soon as possible.

Avoid to use excess material to seal the joint.


Excessive sealant could come out from joint sides and cause lubricant passage clogging.

After applying the sealant, the joint shall be assembled immediately (10 - 20 minutes).




Refit the housing (1) to the engine block and screw the fastening screws in the same position found at removal and tighten them to the following torque values in the sequence shown in the figure:

Screws MI2	75 - 95 Nm
Screws M10	44 - 53 Nm




Apply tool 99346253 part (5) to the rear output shaft tang (6), secure it by screws (4) and fit the new sealing ring (3). Position part (1) on part (5), screw nut (2) until completing sealing ring (3) fitting into flywheel housing (7).

540850 ENGINE FLYWHEEL




540853 Replacing engine flywheel ring gear

Check ring gear teeth (2), if breakage or excessive wear is found remove the ring gear from the engine flywheel (1, Figure 109) using a generic beater and fit the new one, previously heated to 150° C for 15-20 minutes. Chamfering on ring gear inside diameter shall be facing the engine flywheel.




Screw two pins (2) having suitable length into shaft holes (3) and remove the engine flywheel (1) using proper sling and hoister.


Figure 111




Tighten the screws (4) fastening the engine flywheel (3) to the output shaft. Apply tool 99360351 (2) to the flywheel housing (1) to stop engine flywheel (3) rotation.


Figure 112









Remove the sealing ring (2) from the front cover (1), clean accurately the coupling surfaces and smear them with IVECO N. 2992545.





Clean accurately the front cover (2) surface and refit it. Tighten the screws (1) to the specified torque.



Apply tool 99346252 part (5) to the front output shaft tang (6), secure it by screws (4) and fit the new sealing ring (3). Position part (1) on part (5), screw nut (2) until completing sealing ring (3) fitting into front cover (7).









Position the alternator support (1) so that pins (3 and 4) are set against the engine block.

Tighten the screws (2) to the specified torque.




Refit the alternator (1).


Tighten the screw (2) to the specified torque.




Refit the automatic belt tensioner (2). Tighten the screw (3) to the specified torque using the proper wrench, turn the automatic belt tensioner (2) to fit the belt (1) on pulleys and guide rollers.




Refit the high pressure pump (5) including the feed pump (6) and tighten the nuts (3) to the specified torque. Fit the support (4) with a new sealing ring, the timing sensor (2) with a new sealing ring and tighten the relevant fastening nut (1) to the specified torque.



Refit the air compressor (3). Tighten the screws (2) and the nuts (1 and 4) to the specified torque.



Refit the hydraulic power steering pump (2) including the oil tank (4) to the air compressor (5). Use wrench 99355019 to tighten the fastening screws (3) to the specified torque.




Refit the ECU (3) including the heat exchanger to the engine block and tighten the screws (2) to the specified torque.



Replace support elastic elements (1).

540610 CYLINDER HEAD 540662 Removing the valves

Figure 133




70319

Intake (1) and exhaust (2) values have heads with the same diameter.

The central notch (\rightarrow) of the exhaust value (2) head distinguishes it from the intake value.

Should cylinder head valves be not replaced, number them before removing in order to refit them in the same position.


A = intake side - S = exhaust side



Valve removal shall be performed using tool 99360268 (1) and pressing the cap (3) so that when compressing the springs (4) the cotters (2) can be removed. Then remove the cap (3) and the springs (4).

Repeat this operation for all the valves.


Overturn the cylinder head and withdraw the valves (5).



Remove the sealing rings (1 and 2) from the relevant value guides.

70322


Sealing rings (1) for intake valves are yellow. Sealing rings (2) for exhaust valves are green. Checking cylinder head wet seal



This check shall be performed using the proper tools.


Use a pump to fill with water heated to approx. 90°C and 2 - 3 bar pressure.

Replace the cup plugs (1) if leaks are found, use the proper beater for their removal/refitting.



Replace the cylinder head if leaks are found.


Checking cylinder head supporting surface




Use a rule (2) and a feeler gauge (3) to check the cylinder head (1) supporting surface.

Distortion found along the whole cylinder head shall not exceed 0.20 mm.

If higher values are found grind the cylinder head according to values and indications shown in the following figure.






Use a magnetic base dial gauge (1) set as shown in the figure, the assembling clearance shall be 0.052 ± 0.092 mm.

O

Turn the valve (2) and check that the centering error is not exceeding 0.03 mm.

70327


70330



85486

VALVE SEAT MAIN DATA


Print 603.93.111



MAIN DATA CONCERNING THE SEATS ON THE CYLINDER HEAD


Should valve seats be not reset just by regrinding, replace them with the spare ones. Use tool 99305018 (Figure 144) to remove as much material as possible from the valve seats (take care not to damage the cylinder head) until they can be extracted from the cylinder head using a punch. Heat the cylinder head to 80° - 100° C and using the proper beater, fit the new valve seats, previously cooled, into the cylinder head.

Use tool 99305018 to regrind the valve seats according to the values shown in Figure 145.



After regrinding, check that value (3) sinking value is the specified one by using the base 99370415 (2) and the dial gauge 99395603 (1).


540665 VALVE SPRINGS



Before refitting use tool 99305047 to check spring flexibility. Compare load and elastic deformation data with those of the new springs shown in the following table.

Height		Under a load of		
mm		N		
Н	47.75		Free	
HI	35.33	ΡI	339.8 ± 19	
H2	25.2	P2	741 ± 39	


FITTING CYLINDER HEAD



Lubricate the valve stems (1) and fit them into the relevant valve guides according to the position marked at removal.


Fit the sealing rings (2 and 3) on the valve guide.

Sealing rings (2) for intake valves are yellow and sealing rings (3) for exhaust valves are green.



Position on the cylinder head: the spring (4), the upper cap (3); use tool 99360268 (1) to compress the spring (4) and lock the parts to the valve (5) by the cotters (2).

Refitting the cylinder head



Check cleanness of cylinder head and engine block coupling surface.


Take care not to foul the cylinder head gasket.

Set the cylinder head gasket (1) with the marking "TOP" (1) facing the head.


The arrow shows the point where the gasket thickness is given.



Before reusing the cylinder head fastening screws check whether they are free from damages or distortions, otherwise replace.




Fitting injectors





70338

Fit a new sealing ring (2) lubricated with vaseline and a new sealing washer (3) on injector (1).




Fit injectors (1) on the cylinder head seats, directed so that the fuel inlet hole (2) is facing the fuel manifold seat (3) side.







Tighten the fuel manifold (3) fastening nuts (2) to 50 Nm torque.



Rocker control rods shall not be distorted; the ball seats in touch with the rocker adjusting screw and with tappets (arrows) shall not show seizing or wear; otherwise replace them. Intake and exhaust valve control rods are identical and are therefore interchangeable.






Check that tappet adjusters (1) are loosen to prevent their balking on the rods (2, Figure 162) when refitting the rocker assembly.

Then refit the rocker assembly consisting of: bracket (5), rockers (3), shafts (4) and secure them to the cylinder head by tightening the fastening screws (2) to 36 Nm torque.

Tappet clearance adjustment



70520

Adjust clearance between rockers and valves using setscrew wrench (1), box wrench (3) and feeler gauge (2).

Working clearance shall be as follows:

- intake valves 0.25 ± 0.05 mm
- exhaust valves 0.51 ± 0.05 mm




To carry out rocker-valve clearance adjustment more quickly, proceed as follows:


rotate the output shaft, balance the valves of cylinder No. I and adjust the valves marked with an asterisk in the tables below:


cylinder No.	I	2	3	4
intake	-	-	*	*
exhaust	-	*	-	*


Rotate the output shaft, balance the valves of cylinder No. 4 and adjust the valves marked with an asterisk in the table below:

cylinder No.	I	2	3	4
intake	*	*	-	-
exhaust	*	-	*	-











Reconnect the turbosupercharger (3) with a new gasket to the exhaust manifold (1) and tighten the fastening nuts (2) to the specified torque.

Connect the oil pipe (5) to the heat exchanger support (6) and secure it to the exhaust manifold (1) by screw (4).



Connect the air duct (1) to the turbosupercharger (3) and lock it by clamp (2).

Secure the air duct (1) to the alternator support by screws (4).




Connect pipe (14) to tappet cover (10) and timing case (6) with connections (13-15) and new copper washers.

Connect pipe (7) to timing case (6) connection and lock it by the elastic clamp (8).

Fit a new sealing ring on pipe (11) connection and fit it on the tappet cover (10).

Secure the pipe (11) to the tappet cover (10) with the clip and the nut (12), connect pipe (4) to connection (5) and air compressor (3).

Connect the pipe (2) to the pressure limiter (1) as shown in the following figure.




70126


Press the clamp (1) in arrow direction (Figure B) and connect the pipe.

Reset the clamp to the initial locking position A.



Check proper fuel pipe connection.






Complete engine refitting as follows:

Form the right side:

Refit the starter (5) to the flywheel housing (4) and tighten the fastening nuts to the specified torque.

Fit the oil pipe (3) with a new sealing ring into the engine block and secure it to the turbosupercharger (1) by the screws (2) tightened to the specified torque.




From the left side:

Connect the fuel pipe (2) to rail and to high pressure pump (9), secure it by screws (4 and 6) tightened to the specified torque.




Pipe connections (2) shall be tightened to 20 Nm torque using the proper dynamometric wrench 99389834.


Connection (7) shall be tightened by holding at the same time the high pressure pump hexagon (10). When removed pipe (2) shall always be replaced. Connect pipe (3) to connection (4) and air compressor (8).



Refit the bracket (2) including the fuel filter support (1) to the engine block, tighten the screws (3) to the specified torque.





Screw manually the fuel filter to the support (1), screw the filter by $\frac{3}{4}$ turn, connect the pipes (2-3-4) to the relevant support connections (1) as shown in the following figure.




Press the clamp (1) as shown in figure B. After disconnecting the pipe, reset the clamp (1) to the initial locking position A, to prevent deformations.

When refitting is over, fill engine with the prescribed lubricating oil in the specified quantity.






70479



Clean accurately the heat exchanger components

Always replace the sealing gaskets.

543075 **Oil pressure relief valve** Figure 190 U Í 2 6 3 \bigcirc Þ \bigcirc $\left(\right)$ 4 0 5 Loosen the plug (1), withdraw the spring (3) and the relief valve (4) from the support (5). Check whether the valve (4) is not scored and is sliding smoothly into its seat. The spring (3) shall not be broken or 70481 yielded. Pressure regulation at 100°C oil temperature: - 1.2 bar min pressure; By-pass valve to cut out clogged oil filter. - 3.8 bar max. pressure Figure 191 Figure 192 Flow 65 I39,9 N ±I0,5 N 25 4 70482 Max blow-by: 6432 22 cm³/l' at 0.8 bar pressure and 26.7°C temperature MAIN DATA TO CHECK OIL PRESSURE RELIEF VALVE SPRING



I. Pre-separator - 2. Exhaust to the outside (temporary) - 3. Filter - 4. Return to engine


The tappet cover houses the pre-separator (1), whose shape and position determines an increase in oil vapour outlet speed and condenses a part of vapours at the same time.


Condensate oil returns to the oil sump whereas the residual vapours are ducted, collected and filtered in the blow-by (3).


In the blow-by (3), part of the vapours condense and return to the oil sump whereas the remaining part is put into cycle again through pipe (2).


The closed loop forced-circulation cooling system consists of the following components:

- expansion tank with plug, with two built-in valves: exhaust valve (2) and intake valve (1) to control system pressure;
- radiator, for dissipating the heat subtracted to engine by coolant;
- viscous fan;
- heat exchanger to cool the lubricating oil (see lubrication);
- centrifugal water pump set in the front part of the engine block;
- thermostat to control coolant circulation.









The thermostat of the by-pass type is located in the cylinder head and doesn't need regulations.

Whenever doubts on its operation are present, replace it.

On the thermostat body are fitted the thermometric transmitter/switch and water temperature sensor.


A= stroke beginning: 79.4 – 83.3° C

B= stroke at 100° C: ≥ 6.6 mm

BOOSTER

542410 Turbosupercharger





GARRET TURBOSUPERCHARGER

Booster pressure: 1.5 bar.. Actuator (WASTEGATE) opening start: 1600 rpm

Description

The booster system is composed of: air cleaner, turbosupercharger and intercooler.

The air cleaner is a dry type composed of a filtering cartridge that is periodically changeable.

The turbosupercharger has got the function of using the energy of engine exhaust gas in order to send pressure air to the cylinders.

- It is essentially composed of:
- a main body where a shaft supported by bushes is located. At the ends of the bushes the turbine rotor and compressor rotor are fitted;
- a turbine body and a compressor body fitted on the end of the main body;
- a waste gate valve applied on the turbine body used for determining the portion of exhaust gases and sending a part of them directly to the exhaust pipe, when the booster pressure downstream the supercharger reaches the calibration value;
- ☐ the intercooler is composed of a radiator applied on the engine coolant radiator, and it is used for lowering the temperature of the air coming out from the turbosupercharger to send it to the cylinders.



Verifying an anomalous operation of the engine, due to the booster system, it is recommended, before performing controls on the turbosupercharger, to check the efficiency of the sealing gaskets and the fixing of the connection sleeves, making sure of clogging absence inside intake sleeves, air cleaner or inside radiators. If the turbosupercharger damage is due to a lack of lubrication, check that the oil circulation pipes are not broken or obstructed, in such case replace them or eliminate the trouble.

Bearing end play check


Position the tracer point of the magnetic-base dial gauge on the turbosupercharger shaft end and set to zero the dial gauge.

Move the turbosupercharger shaft axially and check that the clearance is not higher than the prescribed value.

Replace the turbosupercharger if a different value is found.

542418 TURBOSUPERCHARGER ACTUATOR

Check and adjustment



Cover the air, exhaust gas and lubrication oil inlets and outlets.

Carry out an accurate external cleaning of the turbosupercharger, using the anticorrosive and antioxidant solution and perform the check on the actuator (6).

Clamp the turbosupercharger in a vice.

Disconnect the pipe of the actuator (6) and apply to the actuator union, the pipe of pump 99367121 (1).

Apply the magnetic-base dial gauge (2) on the exhaust gas inlet flange in the turbine.

Position the tracer point of the gauge (2) on the tie rod (3) end and set to zero the gauge (2).

Through the pump (1) let in compressed air, in the actuator (6), at the prescribed pressure and make sure that such value is kept constant for the whole check time, otherwise replace the actuator (6).


In the above-mentioned conditions, the tie rod must have carried out the prescribe stroke.



During the operation, beat slightly the actuator (6) in order to eliminate possible sticking of the actuator internal spring.

If a different value is found, loosen the nut (5) and operate properly the knurled ring nut (4).

Actuator replacement




Remove the elastic clip (4) and withdraw the tie rod (3) from the lever (5).

Remove the nuts (2) and remove the actuator (1) from the supporting bracket. Fit the new actuator following the removal operations in reverse order and fitting a new clip (4), tighten the nuts (2) to 5.6 - 6.8 Nm torque.


Check and adjust the actuator (1), if required, as described in the relevant chapter.

Then, paint the nut (6) with safety paint.

Before refitting the turbosupercharger on engine, fill the central body with engine oil.



ENGINE F4 AE 0481 95



Inlet air

- Hot compressed air
- Cooled compressed air
- Exhaust

70491


COMMON RAIL General Specifications

In order to reduce PARTICULATES emissions, very high injection pressures are required. The Common Rail system allows injecting the fuel up to pressures reaching 1450 bar, at the same time, the injection precision, obtained by the electronic system control, optimizes the engine performance, reducing emissions and consumption.

System description

Electric system

Figure 202



1. Injectors connections - 2. Engine coolant temperature sensor - 3. Fuel pressure sensor - 4. Engine oil temperature and pressure sensor - 5. Output shaft sensor - 6. Injector - 7. Air pressure/temperature sensor - 8. Camshaft sensor - 9. Fuel heater and fuel temperature sensor - 10. Pressure regulator - 11. EDC 7 control unit.

Through the sensors, present on the engine, the ECU controls the engine operation.

Air pressure/temperature sensor

It is a component integrating a temperature sensor and a pressure sensor.

Fitted on the intake manifold, it measures the max. inlet air capacity to calculate precisely the fuel quantity to inject at every cycle.

The outlet tension is proportional to the pressure or temperature obtained by the sensor.

Engine oil temperature and pressure sensor

Same as air pressure/temperature sensor, it is fitted on the engine oil filter, in a horizontal position.

It measures engine oil temperature and pressure.

Fuel pressure sensor

Assembled on a rail end, it measures the fuel pressure in the rail in order to determine the injection pressure.

The injection pressure value is used to control the pressure and to determine the electric injection control length.

Fuel temperature sensor

It is a sensor that is equal to the previous one.

It measures fuel temperature to provide the control unit with an index of the diesel fuel thermal state.

Coolant temperature sensor

It is a variable-resistance sensor suitable to measure the coolant temperature to provide the control unit with an index of the engine thermal state.

Output shaft sensor

It is an inductive sensor placed on the front engine part. Signals generated through the magnetic flow that is closed on the phonic wheel, change their frequencies depending on output shaft rotation speed.

Timing sensor

It is an inductive sensor placed on the engine rear left part. It generates signals obtained from magnetic flow lines that are closed through holes obtained on the keyed gear on the camshaft. The signal generated by this sensor is used by the ECU as injection phase signal.

Though being equal to the flywheel sensor, it is NOT interchangeable since it has a different outside shape.

System functionality

Self-diagnosis

The ECU self-diagnostic system checks signals coming from sensors by comparing them with threshold data.

IVECO Code recognition

The EDC7 control unit communicates with the Immobilizer control unit to obtain the startup consent.

Engine pre-heating resistance check

The pre-post heating is activated when even only one of the water, air or fuel temperature sensors signals a temperature that is less than 5 °C.

Timing recognition

By means of signals coming from camshaft sensor and flywheel sensor, the cylinder on which fuel must be injected is recognised upon startup.

Injection control

The control unit, depending on information coming from sensors, controls the pressure regulator, and changes pre-injection and main injection modes.

Closed-loop control for injection pressure

Depending on engine load, measured by processing signals coming from various sensors, the control unit controls the regulator in order to always have the optimum pressure.

Pilot and main injection spark advance control

The control unit, depending on signals coming from various sensors, computes the optimum injection point according to an internal mapping.

Idle speed control

The control unit processes signals coming from various sensors and adjusts the amount of injected fuel.

It controls the pressure regulator and changes the injection time of injectors.

Within certain thresholds, it also takes into account the battery voltage.

Maximum speed limiting

At 2700 rpm, the control unit limits fuel flow-rate by reducing the injectors opening time.

Over 3000 rpm it deactivates the injectors.

Cut Off

Fuel cut off upon release is controlled by the control unit performing the following logics:

it cuts off injectors supply;

it re-activates the injectors shortly before idle speed is reached;

it controls fuel pressure regulator.

Smoke control upon acceleration

With strong load requests, the control unit, depending on signals received by air inlet meter and engine speed sensor, controls the pressure regulator and changes the injectors actuation time, in order to avoid exhaust smokes.

Fuel temperature control

When the fuel temperature exceeds 75 °C (measured by the sensor placed on fuel filter) the control unit intervenes by reducing injection pressure.

If the temperature exceeds 90 °C, the power is reduced to 60%.


AC compressor engagement control

The control unit is able to drive engagement and disengagement of the electromagnetic compressor clutch depending on coolant temperature.

If the coolant temperature reaches about 150 °C, it disengages the clutch.

After Run

The control unit microprocessor allows storing certain EPROM data, among which failure memory and Immobilizer information, in order to make them available upon the following startup.



FEED SYSTEM LAYOUT

This Common Rail injection system, with CP3 pump, is mostly different from the one adopted on the Daily range with CP1 pump due to the different pressure regulator position and due to the gear supply pump.

The pressure regulator, placed upstream of the high-pressure pump, adjusts the fuel flow that is necessary on the low-pressure system. Afterwards, the high-pressure pump takes care of supplying the rail properly. This arrangement, by pressurising the necessary fuel only, improves the energetic efficiency and limits fuel heating in the system.

Function of the pressure relief valve (2), assembled on the high-pressure pump, is keeping the pressure, at the pressure regulator inlet, constant at 5 bars, independently from the efficiency of the fuel filter and of the system set upstream.


The pressure relief valve (2) intervention brings about a fuel flow increase in the high-pressure pump cooling circuit, through inlet and drain piping (16) from piping (8).

The pressure relief valve housed on the cylinder head, assembled on injector return (3), limits the fuel return flow from injectors at a pressure of 1.3 to 2 bars.


Two by-pass valves are placed in parallel with the mechanical supply pump.

The by-pass valve (18) allows fuel to flow from mechanical pump outlet to its inlet, when the fuel filter inlet pressure exceeds the allowed threshold value.

The by-pass valve (17) allows filling the supply system through the manual priming pump (10).



High-pressure pump. – 2. Pressure relief valve on high-pressure pump, 5 bars. – 3. Pressure relief valve assembled on fuel return from injectors, 1.3 to 2 bars. – 4. Rail overpressure valve.
 – 5. Common Rail. – 6. Pressure sensor. – 7. Injector. – 8. Return piping. – 9. Control unit heat exchanger. – 10. Mechanical priming pump. – 11. Prefilter assembled on chassis. – 12. Fuel tank. – 13. Mechanical supply pump. – 14. Fuel filter. – 15. Pressure regulator. – 16. High-pressure pump cooling piping. – 17. By-pass valve. – 18. By-pass valve.




The fuel filter is of the high water separation type, is assembled on the right side of the vehicle chassis, and has the sensor (4) for detecting water in fuel placed on the cartridge (3) base.

Manual priming pump (5) and air bleeding screw (2) from system are placed on filter support.

The presence of condensate into filter is signalled by sensor (4) when a warning light on the instrument panel is lit.

If the warning light is on, it is necessary to immediately operate to remove its cause; the common rail system components are quickly damaged by the presence of water or impurities in the fuel.



I. Fuel filter support - 2. Fuel temperature sensor -

3. Electric fuel heater - 4. Fuel filter - 5. Heater connector.


It is placed on engine block in the circuit between supply pump and high-pressure pump (CP3).


Cartridge filtering degree: 4 microns, Pressure delta 2 bars.

The following are placed on the support: fuel temperature sensor and heater resistances.

Fuel temperature, signalled by the related sensor to EDC7 control unit, allows a very accurate computation of the fuel flow-rate to be injected into the cylinders.

The electric heater is activated when fuel temperature is below 5 $^{\circ}\mathrm{C}.$





The by-pass valve (2) cuts in when, with engine off, the fuel system shall be filled through the priming pump. In this situation the by-pass valve (1) stays closed whereas by-pass valve (2) opens due to inlet pressure, and fuel is drained out through **B**.



The mechanical supply pump cannot be replaced individually, therefore it cannot be removed from the high pressure pump.


CP3 HIGH-PRESSURE PUMP Pump with 3 radial pistons controlled by the timing gear, without needing any setting. On the rear side of the high pressure pump is fitted the mechanical supply pump controlled by the high pressure pump shaft. The high pressure pump-mechanical supply pump unit cannot be overhauled and therefore it must not be disassembled nor its fastening screws must be tampered with. The only admitted operation is control gear replacement. Figure 210 9 8 I 7 2 6 3 5

72595

4


Fuel outlet fitting to rail - 2. High-pressure pump - 3. Pressure regulator - 4. Control gear - 5. Fuel inlet fitting from filter Fuel outlet fitting to filter support - 7. Fuel inlet fitting from control unit heat exchanger - 8. Fuel outlet fitting from supply pump to filter - 9. Mechanical supply pump

HIGH-PRESSURE PUMP - INSIDE STRUCTURE Figure 211 Sec. B-B <mark>⊸</mark>B L_C 7 I 5 0 = ► B С Sec. C-C 2 6 3 4 $(\bigcirc$ O 0 \cap 8 70498 I. Cylinder. – 2. Three-lobe element. – 3. Cap intake valve. – 4. Ball delivery valve. – 5. Piston. – 6- Pump shaft. – 7. Low-pressure fuel inlet. - 8. Pumping elements supplying fuel ducts. Every pumping unit is composed of: translated in a circular movement along a wider radius, with the resulting alternate actuation of the three pumping a piston (5) actuated by a three-lobe element (2) floating elements; on the pump shaft (6). The element (2), being floating on a misaligned part of the shaft (6), when the shaft \Box cap intake value (3); rotates, does not rotate therewith but is only ball delivery valve (4).



Pumping element (3) is oriented to pump shaft (4) cam. During intake, the pumping element is supplied through supply duct (5). The fuel amount to be sent to the pumping element is set by the pressure regulator (7). The pressure regulator meters fuel flow to pumping element according to the PWM signal received from ECU. During pumping element compression stage, fuel reaches the pressure required to open the delivery valve to common rail (2) and to feed it through outlet (1).

Print 603.93.111




 Pumping element inlet - 2. Pump lubrication ducts -3. Pumping element inlet - 4. Main pumping element supply duct - 5. Pressure regulator - 6. Pumping element inlet - 7. Regulator exhaust duct - 8. 5 bar pressure relief valve - 9. Fuel drain from regulator inlet

Figure 213 shows low pressure fuel paths inside the path and highlights: main pumping element supply duct (4), pumping element supply ducts (1 - 3 - 6), pump lubrication ducts (2), pressure regulator (5), 5 bar pressure relief valve (8) and fuel drain duct (7).

Pump shaft is lubricated by fuel through delivery and return ducts (2).

Pressure regulator (5) establishes the fuel amount to send to pumping elements; excess fuel is drained out through duct (9).

5 bar pressure relief valve acts as fuel exhaust manifold and keeps 5 bar constant pressure at regulator inlet.



ec. A - A

I. Fuel outlet duct - 2. Fuel outlet duct - 3. Fuel outlet from pump with high pressure pipe fitting for common rail

Figure 214 shows high pressure fuel flow through pumping element outlet ducts.

Operation

The cylinder is filled through the cap intake valve only if the supply pressure is suitable to open the delivery valves set on the pumping elements (about 2 bars).

The amount of fuel supplying the high-pressure pump is metered by the pressure regulator, placed on the low-pressure system; the pressure regulator is controlled by the EDC7 control unit through a PWM signal.

When fuel is sent to a pumping element, the related piston is moving downwards (suction stroke). When the piston stroke is reversed, the intake valve closes and the remaining fuel in the pumping element chamber, not being able to come out, is compressed above the supply pressure value existing in the rail.

The thereby-generated pressure makes the exhaust valve open and the compressed fuel reaches the high-pressure circuit.

The pumping element compresses the fuel till the top dead center (delivery stroke) is reached. Afterwards, the pressure decreases till the exhaust valve is closed.

The pumping element piston goes back towards the bottom dead center and the remaining fuel is decompressed.

When the pumping element chamber pressure becomes less than the supply pressure, the intake valve is again opened and the cycle is repeated.


The delivery valves must always be free in their movements, free from impurities and oxidation.

The rail delivery pressure is modulated between **250** and **1350** bars by the electronic control unit, through the pressure regulator solenoid valve.

The pump is lubricated and cooled by the fuel.

The radialjet pump disconnection – reconnection time on the engine is highly reduced in comparison with traditional injection pumps, because it does not require setting.

If the pipe between fuel filter and high-pressure pump is to be removed-refitted, be sure that hands and components are absolutely clean.



I. Rail. – 2. Flow limiters. – 3. Fuel inlet from high-pressure pump. – 4. Pressure sensor. – 5. Overpressure valve.


The rail volume is of reduced sizes to allow a quick pressurisation at startup, at idle and in case of high flow-rates.

It anyway has enough volume as to minimise use of plenum chambers caused by injectors openings and closings and by the high-pressure pump operation. This function is further enabled by a calibrated hole being set downstream of the high-pressure pump.


A fuel pressure sensor (4) is screwed to the rail. The signal sent by this sensor to the electronic control unit is a feed-back information, depending on which the rail pressure value is checked and, if necessary, corrected.

OVERPRESSURE VALVE


The overpressure valve (1750 bars) on the rail is used to protect system components in case of flow limiter interventions.



- A The passage of fuel from rail to injectors is implemented through holes obtained on the small piston diameter. Under normal conditions, fuel pressure operates on the two piston sides, kept opened by the spring.
- B In case of strong pressure leaks downstream of the limiter, the inlet pressure becomes preponderant and displaces the piston to the opposite side, closing fuel outlet.



 Pressure rod – 2. Plunger – 3. Nozzle – 4. Coil – 5. Pilot valve – 6. Ball shutter – 7. Control area – 8. Pressure chamber – 9. Control volume – 10. Control duct – 11. Supply duct – 12. Control fuel outlet – 13. Electric connection – 14. Spring – 15. High-pressure fuel inlet.



When coil (4) is energised, it makes shutter (6) move upwards. The control volume (9) fuel flows towards flow duct (12) making a pressure drop occur in control volume (9). Simultaneously the fuel pressure into pressure chamber (8) makes plunger (2) lift, with following fuel injection into the cylinder.

Injection end


When coil (4) is de-energised, shutter (6) goes back to its closing position, in order to re-create such a force balance as to make plunger (2) go back to its closing position and end the injection.




The injector cannot be overhauled and therefore it must not be disassembled.

PRESSURE LIMITER FOR FUEL RETURN

It is housed on the rear cylinder head part, and adjusts the pressure of fuel returning from injectors at a pressure included between 1.3 and 2 bars. By guaranteeing this pressure to the return fuel, the fuel vapours formation inside injectors is avoided, optimising fuel spraying and combustion.



ENGINE F4 AE 0681



Engine F4 AE 0681

	Page
GENERAL SPECIFICATIONS	117
ASSEMBLY DATA – CLEARANCES	120
ENGINE F4AE0681 OVERHAUL	128
Engine removal at the bench	128
TIMING SYSTEM	129
Camshaft	129
BUSHES	129
CYLINDER HEAD VALVE SEATS	3
Cylinder head fastening screw tightening	133
LUBRICATION	135
COOLING SYSTEM	136
BOOSTER	137
Turbosupercharger	137
TURBOSUPERCHARGER ACTUATOR	137
Check and adjustment	137
TURBOSUPERCHARGER LAYOUT	139

GENERAL SPECIFICATIONS

	Туре		F4AE 0681E (.18)	F4AE0681D (.21)	F4AE 0681B (.24)	F4AE 0681A (.28)		
	Cycle			Four-stroke	l diesel engine	<u> </u>		
	Power			Supercharged v	vith intercoole	-		
	Injection	Direct						
	Number of cylinders		6 in	-line				
	Bore	mm	102					
	Stroke	mm		12	20			
	Total displacement cm ³		5900					
<u>Q</u>	Compression ratio		17:1					
	Max. output	kW (HP)	32 (180)	54 (2 0)	176 (240)	202 (275)		
		rpm	2700	2700	2700	2500		
((A))	Max. torque	Nm (kgm)	600 61.2	600 61.2	600 61.2	680 69.3		
		rpm	200÷2 00	200÷2 00	1250÷2100	1250÷2100		
	Loadless engine idling							
×.		rpm	650	650	-	-		
	Loadless engine peak							
		rpm	3000	3000	-	-		

	Туре		F4AE0681E (.18)	F4AE0681D (.21)	F4AE0681B (.24)	F4AE0681A (.28)	
7	SUPERCHARGING			With int	ercooler		
	Turbosupercharger t	уре	Borg War System	ner Turbo 1s K27.2	HOLSET	HX 35 W	
Turbosupercharger shaft radia Turbosupercharger shaft end Pressure relief valve min. oper	play			-		-	
Pressure relief valve max. ope				-	0.		
Pressure corresponding to min Pressure corresponding to ma	n. stroke: ba x. stroke: ba	r		-	. - -	04 - -	
	LUBRICATION		Forced b	y gear pump double sta	, pressure reli ge oil filter	ief valve,	
bar	Oil pressure with war - idling - peak rpm	m engine: bar bar		I.2 3.8			
COOLING				By centrifugal pump, regulating thermostat, radiator, heat exchanger, intercooler			
	Water pump contro	1		Throu	gh belt		
	Thermostat - start of opening - maximum opening				2° C ° C		
	FILLING Total capacity I st filling:						
		liters kg			-		
👝 Urania Turbo		1.2	Min.	level	Max	. level	
Urania LD 5	- engine sump	liters kg		8 .2		0.8 9.7	
	- engine sump + filte	er liters kg		9 .I		l8 0.6	

	Туре		F4AE0681E (.18)	F4AE0681D (.21)	F4AE0681B (.24)	F4AE0681A (.28)
A	TIMING			1	1	I
	start before T.D.C. end after B.D.C.	A B			5° 5°	
	start before T.D.C. end after B.D.C.	D C			° .5°	
	Checking timing X	mm			_	
	Checking operation	mm		0.20 -		
	l	mm		0.45 -	÷ 0.55	
	FUEL FEED					
	Injection Type:	Bosch		high pressure EDC7	common rail 7 ECU	
	Nozzle type		Injectors			
	Injection sequence		- 5 - 3 - 6 - 2 - 4			
bar	Injection sequence Injection pressure	bar bar	250 - 1450			

ASSEMBLY DATA – CLEARANCES

	Туре		F4AE0681E (.18)	F4AE0681D (.21)	F4AE0681B (.24)	F4AE0681A (.28)	
	SHAFT COMPONENTS			m	l Im		
	Cylinder barrels: 🖄 Ø I			02.009 ÷ 02.03			
	Spare pistons: type: Size Outside diameter Pin housing	X Ø I Ø 2		60 + 101.739 + 40.016		÷ 0 .799 ÷ 40.0 4	
	Piston – cylinder barrels	5		0.260 -	÷ 0.300		
	Piston diameter	ØI		0	.5		
X	Piston protrusion	×	0.28 ÷ 0.52				
Ø 3	Piston pin	Ø 3		39.9938 -	÷ 40.0002		
	Piston pin – pin housing	5	0.0098 -	÷ 0.0222	0.0078 -	+ 0.0202	


	Туре		F4AE0681E (.18)	F4AE0681D (.21)	F4AE0681B (.24)	F4AE0681A (.28)	
	HAFT COMPONENTS			l m	l m		
	Split ring slots X 1* X 2 X 3			2.705 - ÷ 2.450 ÷ 4.060	2.420 -	÷ 2.440 ÷ 4.040	
X3	* measured on 99 mm						
$\square \square $	Split rings	S * S 2 S 3	2.560 ÷ 2.605 2.350 ÷ 2,380 3.975 ÷ 4.000				
	* measured on 99 mm	Ø					
	Split rings - slots	 2 3		0.100 + • 0.100 • 0.085	0.040 -	÷ 0.090 ÷ 0.065	
	Split rings		0.5				
→ < { × × 2	Split ring end opening i barrel:						
$ \begin{array}{c} $			0.30 ÷ 0.40 0.60 ÷ 0.80 0.25 ÷ 0.55				
ØI ØZ	Small end bush housing Big and bearing housing	g Ø 1 Ø 2	42.987 ÷ 43.013 72.987 ÷ 73.013				
	Small end bush diamete Outside <u> </u>	\sim 1	43.279 ÷ 43.553 40.019 ÷ 40.033 1.955 ÷ 1.968				
	Small end bush – housi	ng	0.266 ÷ 0.566				
	Piston pin - bush			0.0188 -	÷ 0.0392		
	Big end half bearings		-				


	Туре		F4AE0681E (.18)	F4AE0681D (.21)	F4AE0681B (.24)	F4AE0681A (.28)
	CYLINDER UNIT AND CRANKSHAFT COMPONENTS					
	Size	Х			-	
	Max. tolerance on connecting rod axis alignment				-	
	Journals Crankpins	Ø Ø 2			÷ 83.013 ÷ 69.013	
	Main half bearings Big end half bearings	S I S 2			÷ 2.464 ÷ 1.968	
	*provided as spare part					
Ø 3	Main bearings No. 1–3–4-5- 6-7 No. 2	Ø 3 Ø 3			÷ 88.008 ÷ 88.008	
	Half bearings – Journals No. 1–3–4-5- 6-7 No. 2				+ 0.103 + 0.103	
	Half bearings - Crankpins			0.033 -	+ 0.041	
	Main half bearings Big end half bearings			0.250 -	÷ 0.500	
	Shoulder journal	ХI		37.475 -	÷ 37.545	
× 2	Shoulder main bearing	Х2		32	.23	
<u>× 3</u>	Shoulder half-rings	X 3		32	.30	
	Output shaft shoulder			0.	07	

	Туре	(.18)	F4AE0681D (.21)	F4AE0681B (.24)	F4AE06817 (.28)
CYLINDER HEAD – TIMING SY	STEM		r m	l Im	
	Valve guide seats on cylinder head Ø I		7.042 -	÷ 7.062	
	Valves: \swarrow α		60° ±	÷ 6.990 ± 0.25° ÷ 6.990 ± 0.25°	
	Valve stem and guide		0.052 -	÷ 0.092	
Ø	Housing on head for valve seat ØI ØI			÷ 34.863 ÷ 34.863	
α 2 α	Valve seat outside diameter; valve seat angle on cylinder head: \swarrow \bigotimes 2 α α \bigotimes 2 α		6 34.917 -	÷ 34.931 0° ÷ 34.931 5°	
×	X 🛋 Sinking X			÷ . ÷ .48	
-¢⊐	Between valve seat and head			÷ 0.094 ÷ 0.094	
	Valve seats			-	


	Туре		F4AE0681E (.18)	F4AE0681D (.21)	F4AE0681B (.24)	F4AE0681A (.28)
CYLINDER HEAD – TIMING SYSTEM			m	m		
	Valve spring height:					
	free spring	Н		47	.75	
$H \qquad H \qquad H \qquad H \qquad H \qquad 2$		HI H2			.33 5.2	
×	Injector protrusion	×		lt cannot b	be adjusted	
	Camshaft bush housings No. 1-7			59.222 -	• 59.248	
Ø Ø Ø I 234-5-67	Camshaft housings No. 2-3-4-5-6			59.222 -	: 59.248	
	Camshaft journals: ⇒ 7 Ø -	2-3		53.995 -	: 54.045	
Ø	Camshaft bush outside diameter: with a load of 3.3 kN	Ø		59.222 -	÷ 59.248	
Ø	Bush inside diameter after ramming	Ø		54.083 -	: 54.147	
	Bushes and housings on block			0.113 -	÷ 0.165	
	Bushes and journals			0.038 -	÷ 0.152	
	Cam lift:					
Н Н		Н		6.0)45	
\bigcirc		Н		7.5	582	


	Туре		F4AE0681E (.18)	F4AE0681D (.21)	F4AE0681B (.24)	F4AE0681A (.28)
CYLINDER HEAD – TIMING SYS	TEM			m	ım	
	Tappet cap housing on block	ØI		I 6.000 -	÷ 16.030	
	Tappet cap outside d	15.924 ÷ 15.954 15.960 ÷ 15.975				
	Between tappets and	housings	0.025 ÷ 0.070			
	Tappets			-		
	Rocker shaft	ØI		21.965 -	÷ 21.977	
	Rockers	Ø 2		22.001 -	÷ 22.027	
	Between rockers and	shaft		0.024 -	÷ 0.162	






ENGINE F4AE0681 OVERHAUL







Assemble brackets 99341009 (1) to engine block and secure them to overhaul stand 99322225 (2).


Proceed then to overhaul the engine complying, unless otherwise stated, with what is described for four-cylinder engine F4AE0481.




Remove fastening screws (1) and disconnect exhaust manifold into two sections (2-3) with related gaskets.











70332


If valve seats cannot be restored just by regrinding, it is possible to assemble the spare inserts provided.

In this case, it is necessary to obtain seats into the cylinder head sized as shown in the figure and to assemble the valve seats. In order to assemble the valve seats into the cylinder head, it is necessary to heat the cylinder head to 80° - 100° C and, through a suitable beater, to assemble the new, previously cooled valve seats (2) into the head.

Then, with tool 99305018, adjust valve seats according to the values shown in Figure 14.







70520

Adjust the clearance between rocker arms and valves through setscrew wrench (1), box wrench (3) and feeler gauge (2).

The operating clearance is:

- ± 0.05
- intake valves 0.25 ± 0.05 mm
- exhaust valve 0.51 ± 0.05 mm



In order to more quickly perform the operating clearance adjustment for rocker arms - valves, proceed as follows:

rotate the drive shaft, balance cylinder I valves and adjust the valves marked by the asterisk as shown in the table:

cylinder n.		2	3	4	5	6
intake	-	-	*	-	*	*
exhaust	-	*	-	*	-	*

Rotate the drive shaft, balance cylinder 6 valves and adjust the valves marked by the asterisk as shown in the table:

cylinder n.		2	3	4	5	6
intake	*	*	-	*	-	-
exhaust	*	-	*	-	*	-


Print 603.93.111

5450 LUBRICATION

The forced-circulation lubrication is carried out by the following components:

- rotor oil pump (5), housed in the front block part, controlled by the straight-tooth gear keyed to the output shaft tang;
- water/oil heat exchanger (3), housed in engine block, with oil filter support;
- oil pressure relief valve (1) embedded into filter support;
- by-pass valve (4) to cut off clogged oil filter, embedded into filter support;
- **c**artridge oil filter (2).





LUBRICATION SYSTEM LAYOUT


70516

Figure 19


5432 COOLING SYSTEM

The engine cooling system, of the closed-loop forced-circulation type, is composed of the following components:


- expansion tank whose plug embeds two valves: an exhaust valve (2) and an intake valve (1), that adjust the system pressure;
- radiator, whose task is dissipating heat subtracted to engine by coolant;
- viscous fan;
- an heat exchanger to cool lubricating oil (see lubrication);
- a water pump of the centrifugal type housed in the front engine block part;
- a thermostat adjusting coolant circulation.




COOLING SYSTEM LAYOUT





BOOSTER 542410 Turbosupercharger



TURBOSUPERCHARGER LAYOUT







70518

Troubleshooting Guide

	Page
FOREWORD	143
Diagnosis through instruments	143
DIAGNOSTICS	145

FOREWORD

A good diagnosis is carried out above all with electronic diagnostic instruments (Modus/IWT/IT200) developed by Iveco. When a vehicle enters the workshop, information provided by vehicle driver are kept under right consideration, but the first thing to do is connecting Modus/IWT/IT2000 and carefully performing a complete diagnosis.

- failure memory reading
- parameters reading
- engine test
- etc.

It is useful to print the results, especially in case the Help Desk assistance has to be requested.

Diagnosis through instruments

MODUS

Computerised diagnostic station aimed to provide a diagnosis for braking systems, pneumatic suspensions, electronically-controlled engines and systems.

The station is equipped with auxiliary functions such as electronic control units programming, spare parts catalogue searching, time schedules, etc.

The vehicle is equipped with the "30-pole" diagnosis socket placed aside the U.C.I.

IWT

The IVECO WIRING TESTER expands and integrates MODUS.

This instrument has been implemented by IVECO to improve vehicle electric and electronic systems diagnosis.

The vehicle is equipped with the "**30-pole**" diagnosis socket placed aside the U.C.I., therefore it is necessary to use cable "**4**".

IT2000

IT2000 is a diagnostic instrument of all Electronic Systems for IVECO vehicles.

It allows an immediate intervention on the vehicle recognising it from its chassis number.


It stores the results of performed diagnostic interventions.

It can be used also as portable Personal Computer and is preset for the remote diagnosis.


By using MODUS as mother station, it is possible to update and configure the IT2000.

IT2000 is interfaced with the vehicle through a 30-pole diagnosis socket placed aside the UCI.







70729





(continued)

(continued)














(continued)











SECTION 3

Clutch

	Page
DESCRIPTION	3
Clutch	3
SPECIFICATIONS AND DATA	3
DIAGNOSTICS	7
TIGHTENING TORQUES	10
TOOLS	10
REMOVAL AND REFITTING	11
🔲 Removal	11
Refitting	11
DRIVEN PLATE OVERHAUL	11
Damper hub check	
Friction gaskets	11
BLEEDING AIR FROM CLUTCH CIRCUIT	12
THRUST BEARING REMOVAL - REFITTING	12
REPLACING CLUTCH SHAFT SUPPORT BEARING	12
HYDRAULIC CONTROL	13
• Operating cylinder (14" - 13"/14" clutches)	13
Connections	13
• Operating cylinder (15''/16'' clutches)	14
Clutch wear layout (14" - 13"/14" clutches)	14
Clutch wear layout (13''/14'' - 14'' clutches)	15
Operating cylinder (15''/16'' clutches)	15
WEAR INDICATOR REFITTING AND ADJUSTMENT (15/16'' clutches)	16
ADJUSTING OPERATING CYLINDER PUSH ROD (New 15/16'' clutch)	17
CHECKING AND ADJUSTING THE CLUTCH PEDA (14" - 13"/14" clutches)	4L 18
Clutch pedal stop	18
Clutch pedal idle stroke	18
CHECKING AND ADJUSTING THE CLUTCH PEDA (15"/16" clutches)	AL 19
Clutch pedal stop	19
Clutch pedal idle stroke	19

DESCRIPTION

Clutch

The clutch is of the single-plate, dry-operating type, with engagement mechanism of the pull type with baffle spring. The

SPECIFICATIONS AND DATA

engagement control is hydraulic and comprises the master cylinder, with embedded oil tank, and the operating cylinder.

3" CLUTCH ith gearboxes: 2855.	6 – 2870.9		VALEO	A.P. BORG & BECK
	Туре	Dry single-plate		
	Engagement mechanism		Pull with I	paffle spring
	🛥 Driven plate		With frict	ion gaskets
	Driven plate hub		With spi	ring drives
	Ø External gaskets	mm	3	30
	Ø Internal gaskets	mm	194.5	200
<u>∔</u>	(New) plate thickness	mm	8.5	± 0.3
← + ←	Max. driven plate mismatching	mm	~	0.2
	Load on plate-pusher	Ν	10100	10500
	Disengagement load	N	2500	2000
	Minimum plate-pusher lift	mm		1.5
	Detachment stroke	Detachment stroke mm		12
	Max. consumption stroke	mm	14	3.6
	Hydraulic control		Master cylinder with operating	embedded oil tank – g cylinder
With the second	Oil type		Tutela TRUCK	DOT SPECIAL

4 CLUTCH			Euro
13"/14" CLUTCH with gearboxes: 2855	.6 – 2870.9		VALEO
	Туре		Dry single-plate
	Engagement mechanism		Pull with baffle spring
	🛲 Driven plate		With friction gaskets
	Driven plate hub		With spring drives
	External gaskets Ø	mm	330
	Internal gaskets Ø	mm	194.5
	(New) plate thickness	mm	9.4 ± 0.3
₩← + ₩←	Max. driven plate mismatching	mm	~ 0.2
	Load on plate-pusher	N	12000
	Disengagement load	N	2600
tt			

Trunt rad	Oil type		Tutela TRUCK DOT SPECIAL
	Hydraulic control		Master cylinder with embedded oil tank – operating cylinder
	Max. consumption stroke	mm	12.2
	Detachment stroke	mm	10 ⁺² ₀
	Minimum plate-pusher lift	mm	1.5
	Disengagement load	Ν	2600
	Load on plate-pusher	Ν	12000
← = ←	Max. driven plate mismatching	mm	\sim 0.2
<u>∔</u> ।. =	(New) plate thickness	mm	9.4 ± 0.3
	Internal gaskets Ø	mm	194.5
	External gaskets Ø	mm	330
	Driven plate hub		With spring drives
	Driven plate		With friction gaskets
	Engagement mechanism		Pull with baffle spring
	Туре		Dry single-plate
13"/14" CLUTCH with gearboxes: 2855.6	- 2870.9		VALEO

4" CLUTCH /ith gearboxes: 2865.	6 – 2870.9		VALEO
	Туре		Dry single-plate
	Engagement mechanism		Pull with baffle spring
	 Driven plate 		With friction gaskets
	Driven plate hub		With spring drives
	External gaskets Ø	mm	350
	Internal gaskets Ø	mm	195
<u>∔</u> ++ = ↑	(New) plate thickness	mm	9.4 ± 0.3
← + ←	Max. driven plate mismatching	mm	~ 0.2
	Load on plate-pusher	N	12000
	Disengagement load	Ν	2600
	Minimum plate-pusher lift	mm	1.5
	Detachment stroke	mm	10 ⁺²
	Max. consumption stroke	mm	12.2
	Hydraulic control		Master cylinder with embedded oil tank – operating cylinder
With the second	Oil type		Tutela TRUCK DOT SPECIAL

TUTRLA DOT STVECIME

6 CLUTCH				Euro	Са
15" /16" CLUTCH with gearboxes: 2895.5	9 - FSO 5206B		FICHTEL & SACHS	VALEO	
	Туре			Dry single-plate	
	Engagement mechanism			Pull with baffle spring	g
	 Driven plate 			With friction gaskets	5
	Driven plate hub			With spring drives	
	External gaskets Ø	mm	380	380	
	Internal gaskets \varnothing	mm	220	220	
<u>↓</u> =	(New) plate thickness	mm	10 ± 0.3	10 ± 0.3	
↓ + ↓	Max. driven plate mismatching	mm	-	-	
	Load on plate-pusher	Ν	7400	19000	
	Disengagement load	Ν	4000	4000	
	Minimum plate-pusher lift	mm	1.7	1.7	
	r inimum plate-pusher int	111111	1.7	1.7	

Detachment stroke

Hydraulic control

Oil type

Max. consumption stroke

A.P. BORG & BECK

380

220

10 ± 0.2

 \sim 0.3

20000

3950

1.7

 12^{+2}_{0}

15

Tutela TRUCK DOT SPECIAL

12⁺²

12.5


Master cylinder with embedded oil tank – operating cylinder


 12^{+2}_{0}

16


mm

mm






THE CLUTCH JERKS



TIGHTENING TORQUES

PART	TOR	QUE
	Nm	(kgm)
Flanged hexagonal-head screw for securing plate-pusher to flywheel M8	23.5 ± 2.5	(2.4 ± 0.2)
Flanged hexagonal-head screw for securing plate-pusher to flywheel MI0	46.5 ± 4.5	(4.7 ± 0.4)
Hexagonal nut for securing clutch timing case to engine M8	46 ± 5	(4.6 ± 0.4)


TOOLS




505210 REMOVAL AND REFITTING

Removal

After removing the gearbox propeller shaft as described in the relevant sections, remove the clutch assembly as follows:



Insert clutch-centering pin 99370306 (for 12" - 13", 14"/15" clutches) or 99370280 (for 15/16" clutches) (1), unscrew assembly-securing screws (2) and withdraw the assembly.



Withdraw pin (1) and remove the driven plate (2).

Refitting

For refitting, reverse the removal operations.

Check conditions of fastening screws and replace the faulty ones.

Clean accurately threads and contact surfaces.

DRIVEN PLATE OVERHAUL

Upon overhauling the clutch plate, no repair is provided since components are only submitted to visual inspection to determine their wear conditions.

These checks and the overhauling procedures are specified in the following paragraphs.


Damper hub check

Visually inspect the hub and check absence of breaks; spring drives shall not rotate into their seats and hub outline shall be within the tolerance values specified on drawing.

Replace the entire plate if the hub shows one of the above faults or hub grooved coupling sizes are out of tolerance values.


Friction gaskets

Replace the entire driven plate if gaskets are excessively worn or dirty with oil or grease, or burning traces or removal from the driving plate are visible.




Before fitting a new driven plate, check its centring as follows: Place the driven plate (1) on a lathe, then using a magnetic-base gauge (2), check that the plate surface is not out of line at any point.

Max. tolerance for driven plate is 0.20 mm.



If plate is out-of-line, use a fork wrench (1) as shown in the figure.




33699


HYDRAULIC CONTROL


The hydraulic control to disengage the clutch can, depending on the model, be solely hydraulic or pneumatically servo-assisted. The fluid required by the system to work is contained in a reservoir integrated in the master cylinder.

Servo-assisted master cylinder (14" - 13"/14" clutches)

This cylinder uses a pneumatically servo-assisted operating system whose action is modulated by a spring load sensor with a threshold. The first portion of the piston stroke, under the triggering threshold, is not assisted; whereas, above this threshold, the air pressure, suitably modulated by a system of valves, is triggered to produce an action with constant pressure.








61272


62451


OPERATING CYLINDER SECTION

WEAR INDICATOR REFITTING AND ADJUSTMENT (15/16" clutches)




Remove the plastic rod, the rubber seal and the metal stop. Turn "worn clutch" mark (3) on the new servo clutch from rest position to 90° LH or RH, according to clutch manufacturer.






Fit the plastic rod (1) against the servo clutch stop. Push the seal (2).



Remove the plastic rod (1) from the servo clutch; the rubber seal (2) shall not move.


Secure the seal (2) with the metal stop (3).






When the clutch plate is worn the plastic rod moves to the wear mark.


When replacing the clutch, fit a new wear indicator kit and adjust it as previously described.



505272 ADJUSTING OPERATING CYLINDER PUSH ROD (New 15/16" clutch)

CHECKING AND ADJUSTING THE CLUTCH PEDAL (14" - 13"/14" clutches)





72865

Clutch pedal stop


Check distance X between support and screw (4) end; it must be 30 to 31.5 mm, otherwise tighten or loosen screw (4).

Clutch pedal idle stroke

Depress the clutch pedal (6) so as to bring rod (7) in contact with master cylinder piston (8).

Under such condition, check distance \mathbf{Y} between clutch pedal (6) and screw (5) that must be 1-2 mm, otherwise tighten or loosen screw (5).

Distance \mathbf{Y} corresponds to 0.5 to 1 mm clearance between rod (4) and piston (8) when clutch pedal (6) is in contact with screw (5).



39696

Clutch pedal stop

Check distance \mathbf{A} between pedal support (1) and screw (2) end; it must be approx. 32.5 mm, otherwise tighten or loosen the screw.

Clutch pedal idle stroke

Depress the clutch pedal (8) so as to bring rod (6) in contact with master cylinder piston (5).

Under such condition, check distance **B** between clutch pedal (8) and screw (7) that must be 1-2 mm, otherwise tighten or loosen screw (7).

Distance **B** corresponds to 0.5 to 1 mm clearance between rod (6) and piston (5) when the clutch pedal (8) is in contact with screw (7).

SECTION 4


Gearbox


	Page
DIAGNOSTICS	3
Gears control connection	5
Gearbox control tie-rods adjustment	5
GEARBOX 2855.6	9
GEARBOX 2865.6	45
GEARBOX 2870.9	79
GEARBOX 2895.9	123
GEARBOX MD3060P	163
GEARBOX FSO5206B	185

DIAGNOSTICS

Main gearbox operating anomalies:


- I Noises;
- 2 Spontaneous gears disengagement and engagement irregularities;







Gears control connection

The gears-controlling tie-rods bearing support is secured in the same chassis point on all models in the EuroCargo range, while the adjustment tie-rod reaction plate is secured to the gearbox gears control in different positions according to the gearbox itself.





 Gears control lever – 2. Reaction plate secured to gears control – 3. Adjustment tie-rod – 4. Bearing support – 5. Adjustable fixed tie-rod – 6. Telescopic tie-rod – 7. Gears lever







- Check or position, if disassembled, the gears control lever on the transverse control: upon assembling the lever, the milling (1) must correspond with the reference notch (2) punched on the transverse shaft;
- position the gearbox in idle;
- in order to be sure about such operation, it is enough to longitudinally push the transverse rod: if the rod performs the movement, it means that it is in idle.











MODELS 120EL21



70993



5302 Gearbox 2855.6	
	Page
DESCRIPTION	11
SPECIFICATIONS AND DATA	12
TIGHTENING TORQUES	15
TOOLS	16
GEARBOX 2855.6 DISENGAGEMENT/RE-ENGAGEMENT	21
Disengagement	. 21
Re-engagement	. 21
GEARBOX DISASSEMBLY	23
Checks	. 26
GEARBOX ASSEMBLY	27
Bearings pre-load adjustment for secondary sh	aft 27
PRIMARY SHAFT DISASSEMBLY	33
PRIMARY SHAFT ASSEMBLY	35
MOTION INLET SHAFT DISASSEMBLY	38
MOTION INLET SHAFT ASSEMBLY	38
Motion inlet shaft bearing adjustment	. 38
SECONDARY SHAFT DISASSEMBLY	39
SECONDARY SHAFT ASSEMBLY	39
INTERNAL DRIVE SHAFT DISASSEMBLY	39
INTERNAL DRIVE SHAFY ASSEMBLY	39
EXTERNAL DRIVE BOX DISASSEMBLY	40
EXTERNAL DRIVE BOX ASSEMBLY	41
Idle-R.M. switch adjustment	. 43

DESCRIPTION

The IVECO 2855.6 gearbox is of the mechanical type with 1st, 2nd gear engagement through a double-cone synchronising ring and 3rd, 4th, 5th and 6th gear engagement with free-ring synchronising rings. The reverse motion engagement is with a quick-connection sliding sleeve.

The gearbox case is made of light alloy and is composed of a front half-case and a rear half-case.

Three openings are obtained in the rear half-case for the possible application of a power takeoff.

Motion transmission is realised through a series of gears, always meshed and with helical teeth.

The gears are keyed or obtained on four shafts: motion entry, primary, secondary and reverse motion shafts.


The gear obtained on the motion entry shaft and those keyed on primary and reverse motion shafts idly rotate on cylindrical roller cages.

Motion entry shaft and primary shaft are supported by ball bearings in the gearbox case.

The secondary shaft is front and rear supported by tapered-roller bearings that are axially adjustable through an adjustment ring.

The gears engagement and selection control is mechanical.

Figure I




79431

IVECO 2855.6 GEARBOX ASSEMBLY

SPECIFICATIONS AND DATA

	GEARBOX	2855.6	
	Туре	Mechanical	
	Gears	6 forward gears and reverse gear	
Ľ	Gears engagement control	Mechanical Upon request	
	Power takeoff		
	Gears engagement:		
	$I^{st} \Longrightarrow 2^{nd}$	Double-cone synchronizer	
	$3^{rd} \Rightarrow 6^{th}$	Free-ring synchronizer	
	Reverse gear Gears anti-disengagement	Quick-connection type Sliding sleeve holding through rollers and springs.	
00	Gears	With helical teeth	
	Gear ratio		
	First	I : 6.433	
	Second	: 3.643	
	Third	: 2.308	
	Fourth	: .484	
	Fifth	1 : 1.000	
	Sixth	I : 0.783	
	Reverse gear	I : 5.630	
	Oil type Amount	TUTELA ZC 90 5 kg. (5.5 litres)	
	Fixed hubs assembly temperature	100°C to 130°C	

	Secondary shaft bearings	With tapered rollers
	Secondary shaft bearings pre-loading adjustment	Through rings
IVECO	Secondary shaft pre-loading adjustment rings thickness	4.0 - 4.1 - 4.2 - 4.3 - 4.4 - 4.5 - 4.6 - 4.7 - 4.8 - 4.9 - 5.0 - 5.1 - 5.2 - 5.3 Supplied in a kit
	Secondary shaft bearings assembly temperature	85°C
VECO Phase	Secondary shaft bearings adjusting rings thicknesses	2.40 - 2.45 - 2.50 - 2.55 - 2.60 - 2.65 -2.70 - 2.75 - 2.80




TIGHTENING TORQUES

			RQUE
PART –		Nm	(kgm)
I	Flanged hexagonal head screw for securing front cover	32 ± 3	(3.3 ± 0.3)
2	Flanged hexagonal head screw for joining half-boxes	45.5 ± 4.5	(4.6 ± 0.5)
3	Release-proof tip cover fastening screw	22.5 ± 2.5	(2.3 ± 0.2)
4	Screw for securing hub to fork control rod	39 ± 2	(4.0 ± 0.2)
5	Flanged hexagonal head screw for pin on 5th - 6th fork	14.5 ± 1.5	(1.5 ± 0.1)
6	Threaded plug with external driving hexagon for oil level	27.6 ± 2,5	(2.8 ± 0.3)
7	Flanged hexagonal head screw for securing covers on side power takeoff connection windows	38 ± 4	(3.9 ± 0.4)
8	Flanged hexagonal head screw for securing transverse axle cover on control	19 ± 2	(1.9 ± 2)
9	Transverse axle screw	30 ± 3	(3.0 ± 0.3)
10	Threaded plug with external driving hexagon for oil discharge	27.5 ± 2.5	(2.8 ± 0.3)
	Flanged hexagonal head screw for securing rear cover on secondary shaft	58 ± 6	(5.9 ± 0.6)
12	Flanged hexagonal head screw for securing rear cover on primary shaft	43 ± 4	(4.4 ± 0.4)
13	Output flange locking nut on primary shaft	467 ± 23	(47.6 ± 2.3)
14	Flanged hexagonal head screw for securing upper cover supporting external controls	33.5 ± 3.5	(3.4 ± 0.4)
15	Flanged hexagonal head screw for securing spring check flange on external control	19 ± 2	(1.9 ± 2)
-	Flanged hexagonal head screw for securing upper cover for internal controls (only for right-hand drive)	45.5 ± 4.5	(4.6 ± 0.5)
-	Flanged hexagonal head screw for securing clutch disengagement lever support	45.5 ± 4.5	(4.6 ± 0.5)


* Apply thread-braking LOCTITE 270 on the screw
• Apply liquid gasket LOCTITE 510 sealant
• Apply liquid gasket LOCTITE 518 sealant.

TOOLS		
TOOL No.		DENOMINATION
99305121		Hot-air apparatus
99322205		Rotating stand for assembly revision (capacity 1000 daN, couple 120 daN/m)
99222225		Assembly bearing support (to be applied on stand 99322205)
99340205	and the	Percussion extractor
99341003		Simple-effect bridge
99341009		Pair of brackets




TOOLS TOOL No. DENOMINATION 99348004 Universal extractors for interiors 5 to 70 99370006 Handle for interchangeable beaters 99370007 Handle for interchangeable beaters 99370317 Reaction lever with flange check extension 99370349 Keyer for drive shaft front gasket assembling (use with 99370006) - BB 99370466 Comparator-holder basis for secondary shaft bearings adjustment (use with 99395604)

TOOLS	
TOOL No.	DENOMINATION
99370629	Gearbox bearing support during vehicle disconnection and re-connection
99374092	Beater for external bearings race assembling (69-91) (use with 99370007)
99374201	Keyer for assembling gasket on rear gearbox cover
9939603 I	Calibrated rings for secondary shaft bearings adjustment (use with 99370466).
99395604	Comparator (0 – 10 mm)



Upon re-engaging the gearbox, pay attention that

the clutch control lever fork is correctly meshed to




 \bigwedge

the thrust bearing.

EuroCargo Tector 12-26 t


GEARBOX DISASSEMBLY Figure 4 I 2 đ 3 71666 Place gearbox (2) on rotating stand 99322205 (3) equipped with brackets 99322225 (1) and discharge lubrication oil. Figure 5 6 6 71667 Disassemble the external control box (1). Figure 6 3 (DE) 2 L 78685 Apply reaction lever 99370317 (1) on motion outlet flange (3) and unscrew nut on primary shaft with wrench 99355081 (2).




Remove flange (2), unscrew securing screws (3) and remove cover (1).




Disassembling rear cover from gearbox to replace the sealing gasket can also be carried out with a gearbox assembled on the vehicle by disconnecting the transmission shaft and proceeding as shown for the gearbox assembled on a rotating stand.







Unscrew screws (1), leaving a safety one (\rightarrow) to be removed after having vertically placed the gearbox.

cylindric roller bearing.







Unscrew screws (1) and remove cover (2) on motion inlet shaft.




Remove cylindric roller bearing from motion inlet shaft (1) and heat contact surface (2) of front half-case. With a plastic hammer extract motion inlet shaft (1) completed with ball bearing.




Extract rolling race (2) of tapered roller bearing of secondary shaft, from front half-case (3) with extractor 99348004 (1). Remove the adjustment ring.



With a suitable beater, extract from rear half-case the external race (2) of roller bearing and spacer (1). From inside the half-case, towards the outside, extract ball bearing (3).



Extract sealing gasket (2) from motion inlet shaft cover (1).



Checks

GEARBOX CASE

Gearbox case and related covers must not show cracks. Contact surfaces between covers and gearbox case must not be damaged or distorted.

Bearing seats must not be damaged or excessively worn.

SHAFTS - GEARS

Shaft seats for bearings and gear toothings must not be damaged or worn.

HUBS - SLIDING SLEEVES - FORKS

Grooves on hubs and related sliding sleeves must not be damaged. The sliding sleeve must freely slide on the hub. Sliding sleeve positioning rollers must not be damaged or worn. Engagement toothing of sliding sleeves must not be damaged.

Forks must be healthy and must not show any sign of wear.

BEARINGS

Roller bearings or roller cages must be in perfect conditions and not show traces of wear or overheatings. By keeping bearings manually pressed and making them

By keeping bearings manually pressed and making them simultaneously rotate along two directions, no roughness or noise when sliding must be detected.



Upon assembling, the following must always be replaced: rings, sealing gasket and springs for sliding sleeves positioning rollers.

SYNCHRONIZERS - COUPLING BODIES

Check wear of synchronising rings and respective coupling bodies: they must not show any sign of wear.



Upon assembling, do not mutually exchange the checked parts.

GEARBOX ASSEMBLY




Butter with hermetic type "B" the threaded part of all screws that must be screwed in the through-holes.

Clean the joining surfaces of case and covers and apply "LOCTITE 510" putty, before assembling, on one of the two components.


Upon assembling, make sure that the sealing gaskets are already lubrified, or butter with oil or grease the sealing lip of inlet and primary shafts gaskets.

Do not insert oil before 20 min and do not try the gearbox before 1h and 30 min.

Assemble bearing cages into their respective seats and oil with TUTELA ZC 90.




Butter, with hermetic type "B", the coupling seat surface of cover (2) with sealing gasket and with keyer 99374201 (1) assemble the sealing gasket itself.




Butter, with hermetic type "B", the coupling seat surface of cover (3) with sealing gasket and with keyer 99370349 (2) and handle 99370006 (1) assemble the sealing gasket itself.

Bearings pre-load adjustment for secondary shaft

The bearings pre-load adjustment for the secondary shaft can be carried out with two procedures.



Assemble comparator 99395604 (1) on base 99370466 (2), pre-load it by 5 mm and zero it on an abutment plane.




61957

Place calibrated ring 99396031 (2) into its seat, without adjustment ring, of bevel roller bearing on front half-case; place base 99370466 completed with comparator (1), previously zeroed, as shown in Figure 25.


First method - Take note of the value read on the comparator (Example: 2.43 mm).

Second method - Take note of the value read on the comparator and add it to calibrated ring thickness. [Example: 2.43 + 50.5 = 52.93 mm (Dimension **B**)].



Assemble on rear half-case (1) cover (2), spacer (1, Figure 20) and with beater 99374092 equipped with handle 99370007, assemble external race (3) of roller bearing, settling it till it abuts.

See Figure 30 for adjusting beater 99374092.




Assemble and simultaneously rotate, till it abuts, the secondary shaft completed with bearings in rear half-case (3). Place calibrated rings 99396032 (2) on half-case (3). Arrange, as shown in the figure, base 99370466 completed with previously-zeroed comparator (1); the comparator rod must abut on the external bearing ring. Carry out the measure on two diametrically-opposite points and perform the arithmetic mean.


	First method -	Take note of the value read on the comparator (Example 1.84 mm). The adjustment ring value is obtained by summing the two measured values (Example $2.43 + 1.84 = 4.27$ mm)
	Second method -	Take note of the value read on the comparator and subtract it from the calibrated ring thickness [Example: $50.5 - 1.84 = 48.66 \text{ mm}$ (Dimension A)].
	The adjustment ri S = B - A	ing value is obtained with formula Example: 52.93 - 48.66 = 4.27 mm.


The adjustment ring rounding is always carried out in excess. Example; thickness S = 4.27: thickness S = 4.3 is taken. Measuring of dimension "A", carried out with secondary shaft in vertical position, that, in addition to facilitating the measure itself, allows having an axial load on the rear bearing.


After having computed the thickness value of the adjustment ring, disassemble again secondary shaft and cover from rear half-case.




Place adjustment ring (1), whose thickness is equal to the previously-obtained one, into the secondary shaft bearing seat on the front half-case (2).









Insert cylinder roller bearing into motion inlet shaft and assemble on front half-case (1) the three shafts together. Apply LOCTITE 510 sealant on contact surface (\rightarrow) between the two half-cases.



Disassemble previously-assembled flange and nut and assemble rear half-case (1). Screw union screw between rear half-case and front half-case and tighten them at the required torque.




Assemble fork pins (1) on both gearbox sides and screw screws (2) by tightening them at the required torque.





Apply sealer LOCTITE 510 on the surface (\rightarrow) without staining the push rod supporting area (4). Insert tip (4), spring (3), then mount cover (1) and fasten

screws (2) by tightening them to the specified torque.




Assemble shoulder rings, placing them into their own seat and reverse gear (3) with cylindric roller bearing. Assemble reverse gear supporting shaft (2) with a suitable beater, paying attention that the arrow (1) punched on the shaft is facing the peg insertion hole.






Apply LOCTITE 510 sealant on contact surface (\rightarrow) between rear half-case and covers.





71671

Assemble covers (2 and 4), screw screws (1 and 3) and tighten them at the required torque.




Slightly heat ball bearing (1) half-race and assemble it in its own seat on primary shaft. Assemble phonic wheel (2) for controlling the odometer.







Print 603.93.111

Base - February 2003






PRIMARY SHAFT ASSEMBLY



Assemble on primary shaft (1) 2^{nd} speed gear (4), coupling body (5) and synchronising ring (3). Heat fixed hub (6) for 1st and 2nd speed gears at a


Heat fixed hub (6) for 1^{st} and 2^{nd} speed gears at a temperature of 100 °C ÷ 130 °C and assemble it on primary shaft (1) with the internal diameter chamfering facing the opposite part of 2^{nd} speed gear.


When keying the hub, pay attention that synchronising ring tangential stops are inserted into respective hub seats. Assemble elastic ring (2) with an apporpriate thickness so that the fixed hub has no axial clearance (max allowed 0.03 mm).





Assemble sliding sleeve (1) for 1st and 2nd speed gears, springs and rollers in fixed hub seats. Assemble synchronising ring and coupling body for 1st speed gear.

(1) and clamp 99341015 (6).











INTERNAL DRIVE SHAFT DISASSEMBLY





Mark fork (3) assembling position. Unscrew screw (4) and withdraw all forks (3) together with fork positioning rods (2) and hub (1).

INTERNAL DRIVE SHAFY ASSEMBLY




Place on a bench forks (4) and hub (2) according to the position marked upon disassembling. Place the two rods (3) inside fork holes and insert drive shaft (1). Tighten hub screw (2) at the required torque.







Unscrew screw (1) and remove spacer, upper cup (3) and spring (2). Remove lower cup.




Remove the snap ring (4) and use a punch tool (5) having the right diameter to push the extraction washer (1) and remove flexible plugs (2) and (3).






L



L



Idle-R.M. switch adjustment

The below-described sequence must	t be compulsorily complied with.	
Figure 103		
gearbox with engaged reverse gear	idle gearbox!	gearbox with engaged gears
		62456
S	WITCH ENGAGEMENT POSITIONS	
 For switch adjustment, it is necessary to carry apply silicone sealant on the threading; set gearbox in engaged reverse gear posi screw the switch till the reverse motion I screw again the switch by 45-60° corresp tighten securing lock nut with a 24 wrend 	ition; lamp turns on; ponding to a stroke of 0.19-0.25 mm;	

530	02 Gearbox 2865.6	
		Page
DES	CRIPTION	47
SPEC	CIFICATIONS AND DATA	49
TIGł	HTENING TORQUES	51
тос	DLS	52
	RBOX 2865.5 DISENGAGEMENT/ E-ENGAGEMENT	57
	Disengagement	57
	Re-engagement	57
GEA	RBOX DISASSEMBLY	59
	Rear cover sealing gasket replacement	62
	Checks	63
GEA	RBOX ASSEMBLY	63
	Bearings pre-loading adjustment for secondary shaft	64
PRIM	1ARY SHAFT DISASSEMBLY	68
PRIM	1ARY SHAFT ASSEMBLY	71
MO	TION ENTRY SHAFT DISASSEMBLY	73
MO	TION ENTRY SHAFT ASSEMBLY	74
SEC	ONDARY SHAFT DISASSEMBLY	74
SEC	ONDARY SHAFT ASSEMBLY	74
	ERNAL CONTROL SHAFT DISASSEMBLY	75
INTE	ERNAL CONTROL SHAFT ASSEMBLY	75
ext	ERNAL CONTROL BOX DISASSEMBLY	75
EXT	ERNAL CONTROL BOX ASSEMBLY	76
	Idle-R.M. switch adjustment	78

DESCRIPTION

The IVECO 2865.6 gearbox is of the mechanical type with 1^{st} , 2^{nd} gear engagement through a double-cone synchronising ring and 3^{rd} , 4^{th} , 5^{th} and 6^{th} gear engagement with free-ring synchronising rings. The reverse motion engagement is with a quick-connection sliding sleeve.

The gearbox case is made of light alloy and is composed of a front half-case and a rear half-case.

Three openings are obtained in the rear half-case for the possible application of a power takeoff.

Motion transmission is realised through a series of gears, always meshed and with helical teeth.

The gears are keyed or obtained on four shafts: motion entry, primary, secondary and reverse motion shafts.


The gear obtained on the motion entry shaft and those keyed on primary and reverse motion shafts idly rotate on cylindrical roller cages.

Motion entry shaft and primary shaft are supported by ball bearings in the gearbox case.

The secondary shaft is front and rear supported by tapered-roller bearings that are axially adjustable through an adjustment ring.


The gears engagement and selection control is mechanical.






79436

IVECO 2865.6 GEARBOX ASSEMBLY



SPECIFICATIONS AND DATA


	GEARBOX	2865.6	
	Туре	Mechanical	
	Gears	6 forward gears and reverse gear	
\angle	Gears engagement control	Mechanical	
	Power takeoff	Upon request	
	Gears engagement:		
	I st – 2 nd	Double-cone synchronizer	
	$3^{rd} - 4^{th} - 5^{th} - 6^{th}$	Free-ring synchronizer	
	Reverse gear	Quick-connection type	
	Gears anti-disengagement	Sliding sleeve holding through rollers and springs.	
00	Gears	With helical teeth	
	Gear ratio		
	First	I : 9.007	
	Second	1:5.015	
	Third	I : 3.206	
	Fourth	I : 2.066	
	Fifth	1 : 1.370	
	Sixth	1 : 1.000	
	Reverse gear	1:8.170	
	Oil type Amount	TUTELA ZC 90 8.1 Kg. (9 lt)	
	Fixed hubs assembly temperature	100°C to 130°C	
	Secondary shaft bearings	With tapered rollers	
	Secondary shaft bearings pre-loading adjustment	By means of rings	
NECO	Secondary shaft pre-loading adjustment rings thickness mm	4.0-4.1-4.2-4.3-4.4-4.5-4.6 4.7-4.8-4.9-5.0-5.1-5.2-5.3 Supplied in a kit	
	Secondary shaft bearingsassembly temperature	85°C	




TIGHTENING TORQUES Т

PART –			TORQUE	
			(kgm)	
	Flanged hexagonal head screw for securing front cover	32 ± 3	(3.3 ± 0.3)	
2	Ring nut for securing entry shaft bearing	545 ± 55	(55.5 ± 5.6)	
3	Flanged hexagonal head screw for joining clutch and case	45.5 ± 4.5	(4.6 ± 0.5)	
4	Release-proof tip cover fastening screw	22.5 ± 2.5	(2.3 ± 0.2)	
5	Screw for securing fork control rod hub	39 ± 2	(4.0 ± 0.2)	
6	Threaded plug with external operating hexagon for oil level	27.5 ± 2.5	(2.8 ± 0.3)	
7	Flanged hexagonal head screw for securing covers on side power takeoffs connection windows	38 ± 4	(3.9 ± 0.4)	
8	Screw with plane washer for securing transverse axle cover on external control	19 ± 2	(1.9 ± 0.2)	
9	Transverse axle screw	30 ± 3	(3.0 ± 0.3)	
10	Threaded plug with external operating hexagon for oil discharge	27.5 ± 2.5	(2.8 ± 0.3)	
	Flanged hexagonal head screw for securing rear cover on secondary shaft	58 ± 6	(5.9 ± 0.6)	
12	Flanged hexagonal head screw for securing rear cover on primary shaft	43 ± 4	(4.4 ± 0.4)	
13	Locking nut for outlet primary shaft flange	467 ± 23	(47.6 ± 2.3	
14	Flanged hexagonal head screw for securing upper external controls support cover	33.5 ± 3.5	(3.4 ± 0.4)	
15	Flanged hexagonal head screw for securing spring check flange on external control	19 ± 2	(1.9 ± 0.2)	
-	Flanged hexagonal head screw for securing clutch disengagement lever support	46.5 ± 4.5	(4.6 ± 0.4)	

* Apply thread-braking LOCTITE 270 on the screw
• Apply liquid gasket LOCTITE 510 sealant
• Apply liquid gasket LOCTITE 518 sealant.






TOOL No.	DENOMINATION
99342143	Peg for removing reverse gear shaft (use with 99340205)
99348004	Universal extractors for interiors 5 to 70 mm
99355081	Bush for disassembling and re-assembling motion outlet flange nut (use with 99370317)
99355174	Wrench for disassembling and re-assembling ring nut, gearbox top gear shaft
99370006	Handle for interchangeable beaters
99370007	Handle for interchangeable beaters


TOOLS		
TOOL No.		DENOMINATION
99370317		Reaction lever with flange check extension
99370349		Keyer for drive shaft front gasket assembling (use with 99370006)
99370466	200 80	Comparator basis
99370629		Gearbox bearing support during vehicle disconnection and re-connection
99374092		Beater for external bearings race assembling (69-91) (use with 99370007)
99374201		Keyer for assembling gasket on rear gearbox cover


TOOLS	
TOOL No.	 DENOMINATION
99395604	Comparator (0 – 10 mm)
99396032	Calibrated rings for secondary shaft bearings adjustment (use with 99370466)





EuroCargo Tector 12-26 t













530514 Rear cover sealing gasket replace-





Butter with sealing compound type "B", the coupling seat surface of cover (1), and with keyer 99374201 (2) assemble the sealing gasket.

Checks

GEARBOX CASE

Gearbox case and related covers must not show cracks. Contact surfaces between covers and gearbox case must not be damaged or distorted.

Bearing seats must not be damaged or excessively worn.

SHAFTS – GEARS

Shaft seats for bearings and gear toothings must not be damaged or worn.

HUBS - SLIDING SLEEVES - FORKS

Grooves on hubs and related sliding sleeves must not be damaged. The sliding sleeve must freely slide on the hub. Sliding sleeve positioning rollers must not be damaged or worn. Sliding sleeves engagement toothings must not be damaged.

Forks must be intact and not show any sign of wear.

BEARINGS

Roller bearings or roller cages must be in perfect conditions and not show traces of wear or overheating.

Keeping the bearings pressed with a hand and making them simultaneously rotate along the two directions, no roughnesses or noises when sliding must be detected.



Upon assembling, the following must always be replaced: rings, sealing gaskets and springs for sliding sleeves positioning rollers.

SYNCHRONIZERS – COUPLING BODIES

Check wear of synchronizing rings and respective coupling bodies: they must not have any sign of wear.



Upon assembling, do not mutually exchange the controlled parts.

GEARBOX ASSEMBLY




Butter with sealing compound type "B" the threaded part of all screws that have to be screwed into the through-holes.

Clean joining surface of case and covers and apply "LOCTITE 510" adhesive, before assembling, on one of the two components.

Do not insert oil before 20 min. and do not try the gearbox before 1 h and 30 min.


Assemble bearing cages into their respective seats and oil with TUTELA ZC 90.

In order to guarantee oil seal upon assembly, make sure that sealing gaskets are already lubricated, or: butter with oil or grease the gasket sealing lip for entry and primary shafts.



33573


Butter, with sealing compound type "B", the coupling seat surface of cover (2) and with keyer 99370349 (1) and handle 99370006 (3) assemble the sealing gasket.



Assemble cover (1), spacer and with a suitable beater, the external race (3) of tapered roller bearing. Slightly heat the case contact surface with ball bearing and assemble the bearing itself.


Bearings pre-loading adjustment for secondary shaft

The pre-loading adjustment for secondary shaft bearings can be carried out with two procedures.



[Example: 2.43 + 50.5 = 52.93 mm

(dimension **B**)].



Place calibrated rings 99396032 (2) on case (3). Arrange, as shown in Figure 30, base 99370466 completed with previosuly zeroed comparator (1): the comparator rod must abut on external bearing ring. Carry out the measure on two diametrally-opposed points and carry out the arithmetic mean.

First method –	Take note of the value read on comparator (Example: 1.84 mm). The adjustment ring value is obtained by adding the two measured values (Example: 2.43 + 1.84 = 4.27 mm)		
Second method –Take note of the value read on comparator and subtract it from calibrated ring thickness [Example: 50.5 – 1.84 = 48.66 mm (dimension A)].			
The adjustment wing value is obtained through formalle			


The adjustment ring value is obtained through formula S = B - A Example: 52.93 - 48.66 = 4.27 mm.





The adjustment ring rounding is carried out always in excess. Example: thickness S = 4.27: thickness S = 4.3 is taken.

The measure for dimension "A" is carried out with secondary shaft in vertical position that, in addition to making the measure itself easier, allows having an axial load on rear bearing.


After having computed the adjustment ring thickness value, disassemble again secondary shaft from rear case.









Assemble shoulder rings, placing them into their own seat and reverse gear (1) with the cylindrical roller bearing. Assemble reverse gear supporting shaft with a suitable beater.







Assemble cover (1) by tightening the screws at the required torque.




Slightly heat ball bearing half-race and assemble it into its own seat on primary shaft. Assemble the odometer controlling phonic wheel (1).




Assemble rear cover (1), completed with sealing gasket, by tightening the securing screws at the required torque. Assemble motion outlet flange (2).




Assemble reaction bar 99370317 (1), motion outlet flange locking nut (3), wrench 99355081 (2) and tighten the locking nut at the required torque.



Lock motion outlet flange rotation with bar 99370317, engage a gear and with wrench 99355174 (1) tighten the ring nut on motion inlet shaft at the required torque.




Assemble cover (1), completed with sealing gasket, on motion inlet shaft and tighten securing screws at the required torque. Assemble clutch disengagement lever and tighten securing screws at the required torque.




Assemble the complete external control box (1). Insert lubrication oil in the required amount, after about 20 min from application of LOCTITE 510 sealant. Remove gearbox from rotating stand.


PRIMARY SHAFT DISASSEMBLY




33618


Tighten primary shaft (3) in a clamp. Remove coupling body (1), 6^{th} speed synchronising ring (4) and sliding sleeve (2) for 5^{th} and 6^{th} speed gears, recovering check springs and rollers.









Remove 3^{rd} and 4^{th} gear sliding sleeve (1) recovering check springs and rollers.




Extract 3rd and 4th speed fixed hub (2) and 3rd speed synchronising ring with holds 99341025 (5), tie-rods 99341019 (7), bridge 99341003 (1) and clamp 99341015 (6). Remove 3rd speed coupling body (4).



Remove 3rd speed gear (1) and roller bearing below it.




PRIMARY SHAFT ASSEMBLY



Assemble on primary shaft (1) 2^{nd} speed gear (4), coupling body (5) and synchronising ring (3). Heat fixed hub (6) for 1st and 2nd speed gears at a

Heat fixed hub (6) for 1^{st} and 2^{nd} speed gears at a temperature of 100 °C to 130 °C and assemble it on primary shaft (1) with the internal diameter chamfering facing the opposite part of 2^{nd} speed gear.

When keying the hub, pay attention that synchronising ring tangential stops are inserted into respective hub seats. Assemble elastic ring (2) with an apporpriate thickness so that the fixed hub has no axial clearance (max allowed 0.03 mm).








Figure 67

elastic ring (3).




Turn the shaft over in a clamp, assemble roller bearing and 3^{rd} speed gear (1).


33638




Assemble coupling body (2) and synchronising ring (3). Heat fixed hub (1) at a temperature of 100 $^{\circ}$ C to 130 $^{\circ}$ C and assemble it on shaft (4) paying attention that synchronising ring tangential stops are inserted into respective hub seats.




Assemble sliding sleeve (2) for 3^{rd} and 4^{th} speed gears, springs and rollers into fixed hub seats. Assemble synchronising ring (3) and coupling body (1) for 4th speed gear.




Assemble roller bearing and 4^{th} speed gear (2). Heat bush (3) at a temperature of 100 °C to 130 °C, and assemble it on primary shaft (4). Assemble elastic ring (1).




Assemble roller bearing, 5^{th} speed gear (2), coupling body (1) and synchronising ring (3) for 5^{th} speed gear.



MOTION ENTRY SHAFT DISASSEMBLY




Abut bearing (2), motion entry shaft (1) on a clamp and by beating the shaft extract ball roller bearing (2) and a rolling half-race of motion entry shaft (1).



Extract the other rolling half-race (2) from motion entry shaft (1) with a suitable punch.


1

2




1

INTERNAL CONTROL SHAFT DISASSEMBLY




Mark fork (3) assembly position. Unscrew screw (4) and withdraw all forks (3) together with fork positioning rods (2) and hub (1).







Place on a bench forks (4) and hub (2) according to the position marked upon disassembling. Place the two rods (3) inside fork holes and insert drive shaft (1). Tighten hub screw (2) at the required torque.




Tighten the shaft going out of the box in a clamp, remove plug (1) and disassemble cover (2).




Remove control box pin (2) and spring (1). Do not mix removed elements with those of the anti-release push rod.




Unscrew screws (1) and disassemble cover (2).



Base - February 2003





53(02 Gearbox 2870.9	
		Page
DES	SCRIPTION	81
SPE	CIFICATIONS AND DATA	82
TIG	HTENING TORQUES	85
TO	OLS	86
	ARBOX 2870.9 DISENGAGEMENT/RE-ENGAGEMENT	91
	Disengagement	91
	Re-engagement	91
GEA	ARBOX DISASSEMBLY	93
	Checks	97
GEA	ARBOX ASSEMBLY	98
	Bearings pre-load adjustment for secondary shaft	98
	Idle-Reverse Gear switch adjustment	104
PRI	MARY SHAFT DISASSEMBLY	105
PRI	MARY SHAFT ASSEMBLY	107
MO	TION INLET SHAFT DISASSEMBLY	107
MO	TION INLET SHAFT ASSEMBLY	108
	Motion inlet shaft bearing adjustment	108
SEC	ONDARY SHAFT DISASSEMBLY	108
SEC	ONDARY SHAFT ASSEMBLY	108
INT	ERNAL DRIVE SHAFT DISASSEMBLY	108
INT	ERNAL DRIVE SHAFT ASSEMBLY	109
EXT	ERNAL DRIVE CASE DISASSEMBLY	109
EXT	FERNAL DRIVE CASE ASSEMBLY	110
EPIC	CYCLIC REDUCTION GEAR ASSEMBLY	3
	Operating diagrams about pneumatic epicyclic reduction gear drive circuit	3
DIS	ASSEMBLY	115
	Checks	7
ASS	EMBLY	8

DESCRIPTION

The 2870.9 gearshift is of the mechanic type, with nine speeds and engagement of the 1st, 4th, 5th, 8th and 9th speeds by means of free-ring synchronizing rings, whereas the 2nd, 3rd, 6th and 7th speeds are engaged by means of a double-cone synchronizing gear.

The reverse gear engagement is with quick-engagement sliding sleeve.


SEC A-A


It is composed of a front section, comprising five ratios and reverse gear, and of a rear section comprising two ratios obtained through epicyclic reduction gear.

The gear switch is carried out mechanically through double-"H" control; the epicyclic reduction gear engagement is carried out mechanically with pneumatic switching.

The gearbox is equipped with an oil pump for its lubrication.

Figure I





78684

2870.9 GEARBOX LONGITUDINAL SECTION AND REVERSE GEAR SHAFT SECTION


ī

SPECIFICATIONS AND DATA

	GEARBOX	2870.9
	Туре	Mechanical
$\begin{array}{c} R & 1 & 3 & 5 & 7 \\ \hline & & & & & & \\ r & & \\ $	Gears	9 forward gears and reverse gear
Ľ	Gears engagement control	Mechanical
	Power takeoff	Upon request
	Gears engagement: l^{st} $2^{nd} \Rightarrow 3^{rd}$ $4^{th} \Rightarrow 5^{th}$	Free-ring synchronizer Double-cone synchronizer
	$6^{\text{th}} \Longrightarrow 7^{\text{th}}$	Free-ring synchronizer Double-cone synchronizer
	$8^{th} \Rightarrow 9^{th}$	Free-ring synchronizer
	Reverse gear Gears anti- disengagement	Quick-connection type Sliding sleeve holding through rollers and springs.
00	Gears	With helical teeth
÷÷ 00	Gear ratio	
	First Second Third Fourth Fifth Sixth Seventh Eighth Ninth Reverse gear	: 13.200 : 9.036 : 6.473 : 4.691 : 3.548 : 2.547 : 1.824 : 1.322 : 1.000 : 1.650

SPECIFICATIONS AND DATA

	Oil type Amount	TUTELA ZC 90 4.5 Kg. (5lt)
	Fixed hubs assem- bly temperature	100°C ÷ 130°C
	Secondary shaft bearings	With tapered rollers
	Secondary shaft bearings pre-loading adjustment	Through rings
IVECO PHATS	Secondary shaft pre-loading adjustment rings thickness	2.5 - 2.7 - 2.8 - 2.9 - 3.1 - 3.2 3.3 - 3.4 - 3.5 - 3.6 - 3.7 - 3.8 Supplied in a kit
	Secondary shaft bearings assembly temperature	85°C
IVECO PRES	Motion entry shaft bearings adjusting rings thicknesses	2.40 - 2.45 - 2.50 - 2.55 - 2.60 - 2.65 - 2.70 - 2.75 - 2.80



PART		TORQUE	
		Nm	(kgm)
	Flanged hexagonal head screw for securing spring check flange on external control	19 ± 2	(1.9 ± 0.2)
2	Flanged hexagonal head screw for securing upper external control support cover	33.5 ± 3.5	(3.4 ± 0.4)
3	Screw for securing reduction gear control valve	23.5 ± 2.5	(2.5 ± 0.3)
4	Ring nut for securing sun gear on primary shaft	372.5 ± 19.5	(38 ± 2)
5	Flanged hexagonal head screw for securing pneumatic reduction gear control cylinder to rear half-case	35.5 ± 3.5	(3.6 ± 0.4)
6	Flanged hexagonal head screw for securing rear cover on primary shaft	44.5 ± 4.5	(4.4 ± 0.5)
7	Output flange locking ring nut on planetary gear-holder shaft	559.5 ± 29.5	(57 ± 3)
8	Flanged hexagonal head screw for securing read cover on secondary shaft	58 ± 6	(5.9 ± 0.6)
9	Oil filter on half-case	320 ± 30	(32.6 ± 3.1)
10	Threaded plug with external manoeuvre hexagon for oil discharge	27.5 ± 2.5	(2.8 ± 0.3)
	Hexagonal head screw for securing oil pump body to case	33.5 ± 3.5	(3.4 ± 0.4)
12	Flanged hexagonal head screw for securing transverse axle cover on drive*	19 ± 2	(1.9 ± 0.2)
13	Transverse axle screw*	30 ± 3	(3.1 ± 0.3)
14	Flanged hexagonal head screw for securing covers on side power takeoff connection windows	38 ± 4	(3.9 ± 0.4)
15	Screw for securing fork control rod hub	39 ± 2	(4.0 ± 0.2)
16	Idle positioner	78 ± 8	(8.0 ± 0.8)
17	Flanged hexagonal head screw for joining clutch cup and case	45.5 ± 4.5	(4.6 ± 0.6)
18	Flanged hexagonal head screw for securing front cover	32 ± 3	(3.3 ± 0.3)
-	Flanged hexagonal head screw for securing clutch disengagement lever support	46.5 ± 4.5	(4.6 ± 0.4)
-	Oval-headed screw for securing reduction gear reaction plate	21 ± 2	(2.1 ± 0.2)
-	Threaded plug with external manoeuvre hexagon for oil level	27.5 ± 2.5	(2.8 ± 0.3)
-	Flanged hexagonal head screw for securing upper internal controls cover (only for right-hand drive)	45.5 ± 4.5	(4.6 ± 0.5)

* Apply thread-braking LOCTITE 270 on the screw

♦ Apply liquid gasket LOCTITE 510 sealant

▲ Apply thread-braking LOCTITE 242 sealant

• Apply liquid gasket LOCTITE 518 sealant.

• Apply liquid gasket LOCTITE 5910 sealant

TOOLS TOOL No. DESCRIPTION 99305121 Hot-air equipment 99322205 Revolving stand for overhauling units (capacity 1000 daN, couple 120 daN/m) 99322225 Unit bearing support (to be applied to stand 99322205) -D-D-T-99340205 Percussion puller 99341003 Single acting puller 99341004 Single acting puller

TOOLS	
TOOL No.	DESCRIPTION
99341009	Pair of brackets
99341015	Clamp
99341017	Pair of brackets with hole
99341019	Pair of tie rods for grips
99341020	Pair of tie rods for grips
99341025	Grips

TOOLS TOOL No. DESCRIPTION 99342143 Peg for removing reverse gear shaft (to use with 99340205) 99345058 Thrust block for pullers 99348004 Universal extractor for interiors 5 to 70 mm 99355081 Bush for disassembling and assembling motion outlet flange nut (use with 99370317) 99355131 Wrench (55 mm) for gearbox sun gear retaining nut 99370006 Handle for interchangeable beaters

TOOLS		
TOOL No.		DESCRIPTION
99370007		Handle for interchangeable beaters
99370130	e and e	Tool for holding the sun gear during nut removal and refitting
99370317		Reaction lever with extension for retaining flanges
99370349		Tool for fitting gasket on gearbox front cover (to use with 99370006)
99370466	0.0	Gauge base for transmission shaft bearing adjustment (to use with 99395604)
99370629		Support for holding gearbox during removal and refitting from/on vehicle

TOOLS TOOL No. DESCRIPTION 99374092 Beater for outer bearing race assembling (69-91) (use with 99370007) 99374229 Tool for refitting gasket on gearbox rear cover H 99381125 Pliers for removing gearbox split rings 99395604 Comparator (0-10 mm) 9939603 I Gauged rings for adjusting transmission shaft bearings (to use with 99370466)

GEARBOX 2870.9 DISENGAGEMENT/RE-ENGAGEMENT



Before carrying out disengagement/re-engagement operations, disconnect battery cables and place the vehicle under safety conditions.

Disengagement



Lift the calender and turn the cabin over.


- loosen securing bolt (23), unscrew securing nuts (24) and detach air piping supporting bracket (22);
- unscrew securing nut (2) and detach air piping supporting bracket (1);
- unscrew securing nuts (19) and detach bracket (20) of reaction tie-rod (18);
- □ loosen securing screw (6) and detach from gearbox the gears control lever completed with tie-rod (3) and reaction tie-rod (18);
- disconnect reverse gear switch electric connection (16) and range-change switch electric connection (8);
- unscrew securing nuts (21) of clutch bell to engine that will be able to be reached with difficulty from the lower vehicle part.
- rotate deadening guard locking rivets below the gearbox and remove the deadening guard;
- detach transmission shaft (9) as described in the related section;
- disconnect air piping (13) from exhaust piping (11);
- detach terminal exhaust piping, operating on securing clip (14) bolt and on support band (12) bolt (10);
- unscrew securing screws (4) and detach clutch control operating cylinder (5);
- disconnect electric connection (15) of odometer sensor;
- unscrew securing screw (17) and detach air piping support bracket;
- place an hydraulic jack equipped with support 99370629 under the gearbox;
- unscrew the remaining securing nuts of clutch bell to engine, move the gearbox backwards and lowering the jack remove it from below the vehicle.

Re-engagement

Suitably reverse the operations carried out for disengagement and tighten securing screws and nuts at the required torque.




Upon re-engaging the gearbox, pay attention that the clutch control lever fork is correctly meshed to the thrust bearing.




71005

EuroCargo Tector 12-26 t


GEARBOX DISASSEMBLY




Place gearbox (2) on rotating stand 99322205 (1) equipped with brackets 99322225 (3) and discharge lubricating oil.




Disconnect pneumatic pipings (1) of epicyclic reduction gear. Unscrew the two screws securing clutch disengagement lever support and remove lever from gearbox.








71886


Unscrew securing screws and with the help of a lifting device, remove epicyclic reduction gear assembly (1).











Checks

GEARBOX CASE

Gearbox case and related covers must not show cracks. Contact surfaces between covers and gearbox case must not be damaged or distorted.

Bearing seats must not be damaged or excessively worn.

SHAFTS – GEARS

Shaft seats for bearings and gear toothings must not be damaged or worn.

HUBS – SLIDING SLEEVES – FORKS

Grooves on hubs and related sliding sleeves must not be damaged. The sliding sleeve must freely slide on its hub. Sliding sleeve positioning rollers must not be damaged or worn. Sliding sleeve engagement toothings must not be damaged.

Forks must be healthy and not show any sign of wear.

BEARINGS

Roller bearings or roller cages must be in perfect conditions and not show traces of wear or overheatings.

By keeping bearings manually pressed and making them simultaneously rotate along two directions, no roughness or noise when sliding must be detected.



Upon assembling, the following must always be replaced: rings, sealing gasket and springs for sliding sleeves positioning rollers.

SYNCHRONIZERS - COUPLING BODIES

Check wear of synchronising rings and respective coupling bodies: they must not show any sign of wear.



Upon assembling, do not mutually exchange the checked parts.

GEARBOX ASSEMBLY




Butter with hermetic type "B" the threaded part of all screws that must be screwed in the through-holes.

Clean the joining surfaces of case and covers and apply "LOCTITE 510" putty, before assembling, on one of the two components.

Do not insert oil before 20 min and do not try the gearbox before 1 h and 30 min.

Assemble bearing cages into their respective seats and oil with TUTELA ZC 90.


To guarantee assembly oil seal, make sure that sealing gaskets are already lubricated, or butter with oil or grease the sealing lip of inlet and primary shafts gaskets.




Butter, with hermetic type "B", the coupling seat surface of cover (3) with sealing gasket and with keyer 99370349 (2) and handle 99370006 (1) assemble the sealing gasket itself.

Bearings pre-load adjustment for secondary shaft

The bearings pre-load adjustment for the secondary shaft can be carried out with two procedures.




Assemble comparator 99395604 (1) on base 99370466 (2), pre-load it by 5 mm and zero it on an abutment plane.




Place calibrated ring 99396031 (2) into its seat, without adjustment ring, of bevel roller bearing on front half-case; place base 99370466 completed with comparator (1), previously zeroed, as shown in the figure.

First method - Take note of the value read on the comparator (Example: 2.43 mm).

Second method - Take note of the value read on the comparator and add it to calibrated ring thickness [Example: 2.43 + 50.5 = 52.93 mm (Dimension **B**)].






Assemble and simultaneously rotate, till it abuts, the secondary shaft (3, Figure 30) completed with bearings in rear case. Place calibrated rings 99396031 (2, Figure 30) on the case (4, Figure 30). Arrange, as shown in the figure, base 99370466 completed with previously-zeroed comparator (1, Figure 30); the comparator rod must abut on the external bearing ring. Carry out the measure on two diametrically-opposite points and perform the arithmetic mean.


- First method Take note of the value read on the comparator (Example 1.84 mm). The adjustment ring value is obtained by summing the two measured values (Example 2.43 + 1.84 = 4.27 mm)
- Second method Take note of the value read on the comparator and subtract it from the calibrated ring thickness [Example: 50.5 - 1.84 = 48.66 mm (Dimension **A**, Figure 31)].
- The adjustment ring value is obtained with formula S = B A Example: 52.93 48.66 = 4.27 mm.




The adjustment ring thickness choice is always carried out in excess. Example; thickness S = 4.27: thickness S = 4.3 is taken. Measuring of dimension "A", carried out with secondary shaft in vertical position, that, in addition to facilitating the measure itself, allows having an axial load on the rear bearing.


After having computed the thickness value of the adjustment ring, disassemble again secondary shaft (3, Figure 30) and oil pump (1, Figure 29).









Assemble reducing gear engagement safety pin (3, Figure 23). Assemble intermediate case (1) and screw the screws at the required torque.




Apply sealer LOCTITE 510 on the surface (\rightarrow) without staining the push rod supporting area (4, Figure 43).





Insert tip (4), spring (3), then mount cover (1) and fasten screws (2) by tightening them to the specified torque.




Assemble shoulder rings, placing them into their own seat and reverse gear (3) with cylindric roller bearing. Assemble reverse gear supporting shaft (2) with a suitable beater, paying attention that the arrow (1) punched on the shaft is facing the peg insertion hole.









Apply LOCTITE 510 sealant and assemble external gear drive (1) tightening screws (2) at the required torque.





Apply tool 99370130 (1) and, through wrench 99355131 (2) and dynamometric wrench (3), screw sun gear check nut, tightening it at the required torque.




Assemble epicyclic reduction gear assemble (1) after having applied LOCTITE 510 sealant and tighten securing screws at the required torque.









Remove synchronising ring and coupling body (1), withdraw sliding sleeve (2) recovering springs, pins and rollers.




Through extractor 99341003 (1) completed with tie-rods (2), grips (4) and clamp (6), extract $2^{nd}-3^{rd}$ gear fixed hub (3) together with synchronising ring, coupling body and 2^{nd} speed gear (5); recover the roller bearing.




Turn primary shaft over, then through extractor 99341003 (1) completed with tie-rods (2), grips (3) and clamp (7), withdraw reverse gear (4) together with internal bearing (6) ring and shoulder ring (5).




Withdraw roller bearing (1), synchronising ring and coupling body (2).




Through suitable pliers, remove elastic ring (1).




Through extractor 99341003 (1), reaction block (2), tie-rods (3), clamp (4), grips (5), withdraw 1st speed gear (6) completed with sliding sleeve, synchronising ring and roller bearing.





MOTION INLET SHAFT DISASSEMBLY





Remove elastic ring (2) and adjustment ring (1).











PARTS COMPOSING GEARS DRIVE


Selection rod – 2. Shaft – 3. Synchronising rod – 4. Hub –
 Screw – 6. 4th-5th fork – 7. 2nd-3rd fork – 8. 1st and reverse gear fork

INTERNAL DRIVE SHAFT ASSEMBLY


Arrange on a bench forks (6-7-8) and hub (4) according to the position marked upon disassembling.

Place selection rod (1) so that the grooves are inserted into forks and hub; repeat the operation with synchronisation rod (3) and keeping them in position, insert shaft (2). Screw the hub (4) screw (5) at the required torque.


EXTERNAL DRIVE CASE DISASSEMBLY




Secure the assembly in a vice, unscrew the four screws (1) and disassemble valve (2) of epicyclic reduction gear drive.





Tighten the shaft going out of the box in a clamp, remove plug (1) and disassemble cover (2).




Do not mix removed elements with those of the anti-release push rod.










The pin abuts on piston (C) valve and by lifting it, closes the supply to union **21**.


By discharging air contained into the cylinder through the vent hole (D), air will then go out of union **22** thereby keeping gearbox piston in slow gears.




The pin abuts on piston (C) value and, by lifting it, closes the supply to union 22 discharging air contained into the cylinder through vent hole (D).

Air will then go out of union **21** pushing the piston in reverse and allowing to insert quick gears.


DISASSEMBLY




Abut epicyclic reduction gear assembly on a bench, unscrew nut (1) and remove flange (2). Unscrew screws (3) and remove cylinder (4).




Unscrew screw (2) and remove piston (1).



Lift case (2) in order to free outlet shaft (3) and rod (1) for synchronising drive fork.




Remove rod with fork (1), withdraw phonic wheel (3) and remove synchronising ring (2).




Make three reference marks (1) on sliding sleeve-crown assembly (2) next to the three central seats, on fixed hub, for positioning rollers.


Manually lift complete crown (2) and remove it, recovering rollers, pins and springs.




Through suitable pliers, remove elastic ring (1).









ASSEMBLY




Settle pin (1) on planetary gear-holder shaft (2) by using a plastic hammer.




By using a punch (2), assemble elastic peg (2) checking pin (3).




Turn planetary gear-holder shaft (1) over, assemble synchronising rings (2) and arrange elastic check ring (4).




Through a feeler gauge (1), check the clearance between the two synchronising rings (2) and (3) that must be included between 0.5 and 1.9 mm. Otherwise, replace the synchronising rings.



Arrange springs, pins and rollers (1), apart from the central ones (\rightarrow) , into the hub.



Key-in the crown, by placing it in a neutral position with marks (1) next to the seats without rollers. Arrange the three central rollers (2) and with a punch (3) push them into their seats.



71937


Insert spacer ring (1) into its seat in case (2).

4


3

71940

2



71941




71958

Abundantly pre-lubricate gaskets (1 and 2) of oil piston equal to the one used for gearbox and assemble them into their respective seats, using suitable toolings in order to guarantee a correct assembly.




Pay attention to the correct assembly of sealing gaskets (1) placed on external piston diameter.




Assemble cover (1) and screw screws (2) tightening them at the required torque.


Assemble piston (3) completed with sealing rings, screw the screw (4) by tightening it at the required torque.




Apply LOCTITE 510 sealant on contact surface (\rightarrow) between case and cylinder.



Assemble cylinder (2) and screw screws (1) tightening them at the required torque.



Butter with hermetic type "B" the coupling surface of cover (1) with sealing gasket and with keyer 99574229 (2), assemble the sealing gasket itself.




5302 Gearbox 2895.9

	Page
DESCRIPTION	125
SPECIFICATIONS AND DATA	126
TOOLS	130
GEARBOX DISENGAGEMENT/ RE-ENGAGEMENT	135
Disengagement	135
Re-engagement	135
GEARBOX DISASSEMBLING	135
Checks	139
GEARBOX ASSEMBLING	139
Adjusting transmission shaft bearing pre - load	139
Idle-R.M. switch adjustment	44
MAIN SHAFT DISASSEMBLING	
MAIN SHAFT ASSEMBLING	147
INPUT SHAFT DISASSEMBLING	148
INPUT SHAFT ASSEMBLING	148
TRANSMISSION SHAFT	148
Bearing replacement	148
INTERNAL CONTROL SHAFT DISASSEMBLING	149
INTERNAL CONTROL SHAFT ASSEMBLING	149
EXTERNAL CONTROL BOX DISASSEMBLING	149
EXTERNAL CONTROL BOX ASSEMBLING	150

DESCRIPTION

The 2870.9 gearshift is of the mechanic type, with nine speeds and engagement of the 1st, 4th, 5th, 8th and 9th speeds by means of free-ring synchronizing rings, whereas the 2nd, 3rd, 6th and 7th speeds are engaged by means of a double-cone synchronizing gear. It consists of a front part featuring five forward gears and reverse gear and a rear part featuring two gears obtained through epicyclic reduction gear unit (E.R.U.).


Gearshifting is performed through double H mechanical control, E.R.U. switching is through pneumatic system. Gearbox is fitted with oil pump for lubrication.



SPECIFICATIONS AND DATA

	GEARBOX	2895.9
	Туре	Mechanical
$\begin{array}{c} R & 2 & 4 & 6 & 8 \\ \hline & & & & & & \\ \hline & & & & & & \\ \hline & & & &$	Gears	9 forward gears and reverse gear
	Gears engagement control	Mechanical
	Power takeoff	On request
	Gears engagement: I st 2 nd ⇒ 3 rd 4 th ⇒ 5 th 6 th ⇒ 7 th 8 th ⇒ 9 th Reverse gear Gears anti-disengagement	Free-ring synchronizer Double-cone synchronizer Free-ring synchronizer Double-cone synchronizer Free-ring synchronizer Quick-connection type Sliding sleeve holding through rollers and springs.
00 ()	Gears	Helical toothing
	Gear ratio First Second Third Fourth Fifth Sixth Seventh Eighth Ninth Reverse gear	: 3.56 : 9.00 : 6.54 : 4.76 : 3.54 : 2.53 : .84 : .34 : .00 : 3.15
	Oil type Amount	Tutela ZC 90 7.5 kg (8.3 liters)

	Assembling temperature for fixed hubs	100 ÷ 130°C
	Transmission shaft bearings	Tapered rollers
	Transmission shaft bearings pre-load adjust- ment	Through rings
weco press mm	Transmission shaft axial backlash adjustment rings thickness	2.5 - 2.6 - 2.7 - 2.8 - 2.9 - 3.0 - 3.1 3.2 - 3.3 - 3.4 - 3.5 - 3.6 - 3.7 - 3.8 3.9 - 4.0 - 4.1 Provided in kit
	Assembling temperature for transmission shaft bearings	85°C



TIGHTENING TORQUE

PAF	T	TORQUE	
FAI		Nm	(kgm)
Ι	Flanged hexagonal head screw for securing spring retaining flange on external control	19 ± 2	(1.9 ± 0.2)
2	Flanged hexagonal head screw for securing upper external controls support cover	33.5 ± 3.5	(3.4 ± 0.4)
3	Screw for securing reduction unit control valve	23.5 ± 2.5	(2.4 ± 0.3)
4	Ring nut for securing sun gear on main shaft	372.5 ± 19.5	(37.5 ± 2)
5	Flanged hexagonal head screw for securing reduction unit control pneumatic cylinder to rear half box	35.5 ± 3.5	(3.6 ± 0.4)
6	Flanged hexagonal head screw for securing rear cover on main shaft	44.5 ± 4.5	(4.5 ± 0.5)
7	Ring nut for fastening output shaft on spider shaft	559.5 ± 29.5	(57 ± 3)
8	Flanged hexagonal head screw for securing rear cover on transmission shaft	58 ± 6	(5.9 ± 0.6)
9	Oil filter on rear half box	320 ± 30	(32.6 ± 3.1
10	Threaded plug with external operating hexagon for oil drain	27.5 ± 2.5	(2.8 ± 0.3)
	Hexagonal head screw for securing oil pump body to box	33.5 ± 3.5	(3.4 ± 0.4)
12	Flanged hexagonal head screw for securing transverse axle cover on external control*	19 ± 2	(1.9 ± 0.2)
13	Transverse axle screw*	30 ± 3	(3.1 ± 0.3)
14	Threaded plug with external operating hexagon for oil level	27.5 ± 2.5	(2.8 ± 0.3)
15	Flanged hexagonal head screw for securing covers on PTO connection openings	38 ± 4	(3.9 ± 0.4)
16	Screw for securing fork control rod hub	39 ± 2	(4.0 ± 0.2)
17	Idle positioning device	78 ± 8	(8.0 ± 0.8)
18	Ring nut for securing input shaft bearing	545 ± 55	(55.6 ± 5.6
19	Flanged hexagonal head screw for securing front cover	31 ± 3	(3.1 ± 0.3)
20	Flanged hexagonal head screw for securing tangential stops block	24.5 ± 2.5	(2.5 ± 0.2)
21	Screw for securing gearbox clutch housing	77 ± 7	(8 ± .8)
22	Flanged hexagonal head screw for securing rear intermediate front half box	45.5 ± 4.5	(4.6 ± 0.5)
-	Countersunk screw for securing reduction unit reaction plate	21 ± 2	(2.1 ± 0.2)


* Apply thread-braking LOCTITE 270 on the screw

• Apply liquid gasket LOCTITE 510 sealant


▲ Apply liquid gasket LOCTITE 518 sealant

• Apply thread-braking LOCTITE 242 on the screw

1



TOOLS	
TOOL No.	DESCRIPTION
99341009	Pair of brackets
99341015	Clamp
99341017	Pair of brackets with hole
99341019	Pair of tie rods for grips
99341020	Pair of tie rods for grips
99341023	Grips



τοοι s
IOOLS

TOOLS		DESCRIPTION
99370006	(°))	Handle for interchangeable beaters
99370130	e provide e	Tool for holding the sun gear during nut removal and refitting
99370317		Reaction lever with extension for retaining flanges
99370349		Tool for fitting gasket on gearbox front cover (to use with 99370006)
99370466	0.0	Gauge base for transmission shaft bearing adjustment (to use with 99395604)
99370629		Support for holding gearbox during removal and refitting from/on vehicle

TOOLS TOOL No. DESCRIPTION 99374229 Tool for refitting gasket on gearbox rear cover 99381125 Pliers for removing gearbox split rings 99395604 Dial gauge (0 – 10 mm) 99396032 Gauged rings for adjusting transmission shaft bearings (to use with 99370466)

GEARBOX DISENGAGEMENT/ RE-ENGAGEMENT

Disengagement



In order to disengage the gearbox, operate as follows:

put the vehicle on a pit or an elevator bridge;

disconnect battery cables to avoid possible short-circuits.

Proceed by removing the following parts:

exhaust silencer, transmission shaft, servo clutch cylinder for electric and pneumatic connections, gear control tie rods.


Place under the gearbox an hydraulic lifting device equipped with support 99370629, unscrew the nut securing gearbox to engine, move back and withdraw the gearbox.

Re-engagement




Suitably reverse the performed operations for the engagement and tighten securing screws and nuts at the required torque.


Upon re-engaging the gearbox, pay attention that the clutch control lever fork is correctly meshed to the thrust bearing.



Apply reaction lever 99370317 (2) and using wrench 99355081 (1) loosen the output flange fastening nut.




Loosen the fastening screws and remove the E.R.U. box (1).





GEARBOX DISASSEMBLING




Before setting the gearbox on the revolving stand, remove the entire clutch assembly with fork lever and drain out oil.









Checks

GEARBOX CASE

Gearbox case and related covers must not show cracks. Contact surfaces between covers and gearbox case must not be damaged or distorted.

Bearing seats must not be damaged or excessively worn.

SHAFTS - GEARS

Shaft seats for bearings and gear toothings must not be damaged or worn.

HUBS – SLIDING SLEEVES – FORKS

Grooves on hubs and sliding sleeves must not be damaged. The sliding sleeve must slide freely on the hub. Sliding sleeve positioning rollers must not be damaged or worn. Sliding sleeves engagement teeth must not be damaged. Forks must be intact and not show any sign of wear.

BEARINGS

Roller bearings or roller cages must be in perfect conditions and not show traces of wear or overheating.

When keeping the bearings pressed by hand and making them rotate simultaneously along both directions, no roughness or noise must be detected.



At refitting always replace: rings, sealing gaskets and springs for sliding sleeves positioning rollers.

SYNCHRONISERS – COUPLING BODIES

Check wear of synchronising rings and coupling bodies: they must not show signs of wear.

At assembling stage, do not mistake the components with each other.

GEARBOX ASSEMBLING



Smear with sealing compound type "B" the threaded part of all screws that have to be screwed into the through-holes.



Clean joining surface of boxes and covers and apply "LOCTITE 510" adhesive on one of the two components before refitting.


Do not fill with oil before 20 min. and do not operate the gearbox before 1h and 30 min.

Fit bearing cages into their seats and oil with TUTELA ZC 90.

In order to guarantee oil seal at refitting, make sure that sealing gaskets are already lubricated, or: smear with oil or grease the sealing lip of input and main shafts.

Adjusting transmission shaft bearing pre - load


Transmission shaft bearing pre-load can be adjusted with two procedures.




Fit gauge (1) on base 99370466 (2). Pre-load it at 5 mm and set it to zero on a surface plate.

Figure 26


Use a micrometer (2) to check gauged ring thickness (1).






After calculating the adjustment ring thickness value,


disassemble again transmission shaft (3, Figure 32) and cover



Fit input shaft (2) and transmission shaft outer ring (1) on front cover.




Fit roller bearing into input shaft then fit the main shaft (1) including gear engagement control.




Fit the transmission shaft (1), smear LOCTITE 510 adhesive (arrow).


(2, Figure 27).




Fit the intermediate box (1) and tighten screws (2) to the specified torque.



Apply sealer LOCTITE 510 on the surface (\rightarrow) without staining the push rod supporting area (4, Figure 39).




Insert tip (4), spring (3), then mount cover (1) and fasten screws (2) by tightening them to the specified torque.





Fit tool 99370130 on the main shaft, engage a gear and with wrench 99355174(1) and dynamometric wrench tighten ring nut to the specified torque.


Figure 41




Fit the adjustment ring, smear cover (1) with LOCTITE 510, fit cover and tighten the screws (2) to the specified torque.









Print 603.93.111




Remove 3rd speed gear (5) together with bush (6) and needle bearing using puller 99341003 (1), tie rods (2), grips (4) and clamp 99341015 (3).




Remove synchronising ring and coupling body (1) and withdraw sliding sleeve (2) recovering springs, pins and rollers (1).



Extract 2^{nd} and 3^{rd} speed gear fixed hub (3), synchronising ring, coupling body (5), and 2^{nd} speed gear (5) using puller 99341003 (1), tie rods (2), grips (4) and clamp (6). Recover the needle bearing.



Upset the main shaft and remove the reverse speed gear (4) with bearing outer ring (6) and the shoulder ring (5) using puller 99341003 (1), tie rods (2), grips (3) and clamp (7).




Remove the needle bearing (1), the synchroniser ring and the coupling body (2).


2

35490


I

35491






Base - February 2003




EXTERNAL CONTROL BOX DISASSEMBLING

79446

Secure the unit in a vice, unscrew the four screws (1), then disassemble epicyclic reduction gear control valve (2).




Tighten the shaft going out of the box in a clamp, remove plug (1) and disassemble cover (2).




Remove control box pin (2) and spring (1). Do not mix removed elements with those of the anti-release push rod. Figure 74


2




Unscrew screws (1) and disassemble cover (2).




Unscrew screw (1) and remove spacer, upper cup (3) and spring (2). Remove lower cup.



right diameter to push the extraction washer (1) and remove flexible plugs (2) and (3).




Extract, from the control shaft (2), control selector (1) and box (3).





Extract, from the control box (3), sealing gasket (1) and bushes (2) with a suitable beater.


EXTERNAL CONTROL BOX ASSEMBLY



Assemble sealing gasket (1) and bushes (2) into drive case (3) with a suitable beater.








By pressing the clutch, operate on the gearbox lever to engage a gear (1-2-3-4-5-RG); cam (A) is moved upwards and pushes pin (B) leftwards.


The pin abuts on piston (C) valve and by lifting it, closes the supply to union $\mathbf{21}$.

By discharging air contained into the cylinder through the vent hole (D), air will then go out of union **22** thereby keeping gearbox piston in slow gears.



The pin abuts on piston (C) value and, by lifting it, closes the supply to union 22 discharging air contained into the cylinder through vent hole (D).

Air will then go out of union **21** pushing the piston in reverse and allowing to insert quick gears.




71916 Remove rod with fork (1), withdraw phonic wheel (3) and remove synchronising ring (2). Figure 96 71917 Make three reference marks (1) on sliding sleeve-crown assembly (2) next to the three central seats, on fixed hub, for positioning rollers. Manually lift complete crown (2) and remove it, recovering rollers, pins and springs. Figure 97


 [71915]


 Lift case (2) in order to free outlet shaft (3) and rod (1) for synchronising drive fork.

Through suitable pliers, remove elastic ring (1).

71918







Check that ball bearing (2), when rotating along the two directions, does not show roughness or noise when sliding. In case of a replacement of the bearing itself, slightly heat support (1) seat before disassembling it.


Checks

Check that all parts composing the epicyclic reduction gear assembly do not shown traces of excessive wear, seizures or breakages.


Replace the affected parts.




Upon assembling, the following must always be replaced: rings, sealing gaskets and springs for sliding sleeves positioning rollers.




Pre-assemble roller bearing (3) and shoulder rings (1) into planetary gear (2).




Assemble complete planetary gear (1) into planetary gear-holder shaft (2) and key-in pin (3).




Settle pin (1) on planetary gear-holder shaft (2) by using a plastic hammer.




By using a punch (2), assemble elastic peg (2) checking pin (3).




Turn planetary gear-holder shaft (1) over, assemble synchronising rings (2) and arrange elastic check ring (4).




Through a feeler gauge (1), check the clearance between the two synchronising rings (2) and (3) that must be included between 0.5 and 1.9 mm. Otherwise, replace the synchronising rings.




Assemble hub (1) on planetary gear-holder shaft and arrange elastic check ring (2).




Arrange springs, pins and rollers (1), apart from the central ones (\rightarrow) , into the hub.




Key-in the crown, by placing it in a neutral position with marks (1) next to the seats without rollers. Arrange the three central rollers (2) and with a punch (3) push them into their seats.




Key-in synchronising ring (1).





Place control fork (1) completed with rod as shown in the figure.



Key-in box (2) on planetary gear-holder shaft (1) and on rod for control fork (3). Key-in phonic wheel (4) on planetary gear-holder shaft (I).

Apply LOCTITE 510 sealant on contact surface (\rightarrow) between case (2) and support.






Figure 124



Assemble support (1) completed with ball bearing (2). Apply LOCTITE 510 sealant on contact surface (\rightarrow) between support and cover.




71958

Abundantly pre-lubricate gaskets (1 and 2) of oil piston equal to the one used for gearbox and assemble them into their respective seats, using suitable toolings in order to guarantee a correct assembly.




Pay attention to the correct assembly of sealing gaskets (1) placed on external piston diameter.




Assemble cover (1) and screw screws (2) tightening them at the required torque.


Assemble piston (3) completed with sealing rings, screw the screw (4) by tightening it at the required torque.



Apply LOCTITE 510 sealant on contact surface (\rightarrow) between case and cylinder.



Assemble cylinder (2) and screw screws (1) tightening them at the required torque.



Butter with hermetic type "B" the coupling surface of cover (1) with sealing gasket and with keyer 99574229 (2), assemble the sealing gasket itself.

 Figure 130


 Image: Provide the sequired torque after having assembled the reduction gear onto the

gearbox.

5302 Allison gearbox **MD 3060P** Page DESCRIPTION 165 CHARACTERISTICS AND DATA 168 MAIN OPERATION ANOMALIES 169 TIGHTENING TORQUES 177 TOOLS 177 DISCONNECTING AND CONNECTING GEARBOX CONTROL MODULE AGAIN 179 179 Refitting 179 REPLACING SPEED SENSORS 179 179 Replacing turbine speed sensor 180 Engine revolutions sensor replacement Replacing the output speed sensor REPLACING OIL LEVEL SENSOR

Replacing the output speed sensor180REPLACING OIL LEVEL SENSOR180REPLACING OIL SUCTION FILTER181REPLACING THE SOLENOID VALVES181REPLACING PLANE GASKETS IN GEARBOX
CONTROL MODULE182

REPLACING PRESSURE SWITCH F3183REPLACING THE SEAL RING ON THE OUTPUT
SHAFT183



Clutches are pressure-balanced on both piston sides to prolong the clutch life and for a more accurate control on the whole range of gearbox gears.


Planetary gears always being engaged are of the helical teeth type to allow a more silent gearbox operation.

The hydrodynamic torque converter, in addition to being mandatory for vehicle start-up, allows a gearbox operation without shakes reducing wear of members composing the vehicle kinematic chain. The torsional forces emitted by the engine are absorbed due to the clutch/damper lockup so that they are not transmitted to gears and the remaining parts of the transmission. The wide lockup operation reduces fuel consumption and improves braking efficiency.

Both gearboxes are equipped with the power takeoff gear. (5 - Figure 2).


The power takeoff can be installed on the left or on the right side of the converter box (8 - Figure 3; 3 - Figure 4).

Figure 2



ALLISON MD 3060 P AUTOMATIC GEARBOX

Exclusion clutch/torsional damper lockup - 2. Converter turbine - 3. Converter pump - 4. Converter box Power takeoff gear - 6. Front support - 7. Clutch box - 8. Clutch - 9. Main box - 10. Brake - 11. Front planetary gear I2. Brake - 13. Central planetary gear - 14. Brake - 15. Rear planetary gear - 16. Rear cover - 17. Output shaft I8. Main shaft - 19. Hydro-electric controls - 20. Clutch - 21. Oil pump - 22. Oil pump driving stub 23. Front support sleeve - 24. Converter distributor - 25. Turbine shaft.



Gear selection is controlled by an electronic transmission control system with a microcomputer.

The closed-loop control logic employed by the electronic control system allows the transmission to adapt to changes in the load, terrain or ambient conditions and to automatically compensate for fluctuations in engine power output and for component wear.

Electronic sensors provide information about the throttle position, the driving range selected by the driver, the engine speed and the turbine speed, the transmission output shaft speed and the various system pressures.

CHARACTERISTICS AND DATA

	TRANSMISSION	ALLISON MD 3060 P
	Туре	Automatic
R R N D S 4 3 2 1	Forward runnings Reverse running	6 forward gears and 1 reverse gears
	Power take-off	Optional
00	Gears	With always-engaged helical teeth
<u>∓</u> 	Gear ratios (*) First Second Third Fourth Fifth Sixth Reverse	3.49 1.86 1.41 1.00 0.75 0.65 5.03
	Type of oil Quantity	Tutela GI/A (28 litres)

(*) The gear ratio does not include torque converter gearing up

MAIN OPERATION ANOMALIES

This paragraph lists main operation anomalies that are not identified by a diagnostic code.


For every problem, causes and related remedies are shown.


For the search of failures through a diagnostic code, refer to section ''Electric/electronic system'' of ''Allison automatic gearboxes'' Manual (printout No. 603.42.409)


The operation anomalies being examined in this section are as follows:


- I The vehicle fails to start (engine is not started up);
- 2 The gearbox does not perform forward range or reverse gear selections (it remains idle);
- 3 The gearbox does not remain in forward gear or in reverse gear;


- 4 The gearbox does not insert a specific selection;
- 5 The gearbox does not correctly perform the selections;
- 6 No response from gear selector;
- 7 Clutch slippage and vibration in all ranges;
- 8 Low main pressure in all ranges;
- 9 Low lubrication pressure;
- 10 Overheatings in all ranges;
- 11 Some oil emerges from filling pipe and/or exhaust;
- 12 Intermittent noises (hum);
- 13 Oil leakage from output shaft;
- 14 Dirty oil.





















TIGHTENING TORQUES

PART	TORQUE	
	Nm	(kgm)
Screws securing converter box to engine	49 to 58	(4.9 to 5.8)
Screws securing adapter - flexible plate	34	(3.4)
Hose fittings for gearbox-exchanger connection	54 to 68	(5.4 to 6.8)
Connection ring nut of external wiring to electric gearbox connector	2 to 3	(0.2 to 0.3)
Screws securing control module to gearbox	57 to 68	(5.7 to 6.8)
Oil filter covers screws	51 to 61	(5.1 to 6.1)
Oil drain plug	25 to 32	(2.5 to 3.2)
Turbine speed sensor securing screw	2 to 4	(1.2 to 1.4)
Engine revolution sensor securing screw	30 to 35	(3 to 3.5)
Output speed sensor securing screw	30 to 35	(3 to 3.5)
Suction filter cover securing screw	2 to 4	(1.2 to 1.4)
Screw securing valve bodies to control module	2 to 4	(1.2 to 1.4)
Screws connecting pressure switch to valve body	5 to 8	(0.5 to 0.8)
Electronic gearbox connector screws	5 to 7	(0.5 to 0.7)
Pressure plugs on gearbox bottom	10 to 13	(to .3)
Output flange screws	30 to 35	(3.0 to 3.5)
Vent	2 to 6	(1.2 to 1.6)


TOOLS

TOOL No.	DENOMINATION
99360322	Engine flywheel rotation tool
99370629	Gearbox bearing support during vehicle disconnection and re-connection
99374013	Keying device for sealing ring assembly



DISCONNECTING AND CONNECTING GEARBOX CONTROL MODULE AGAIN





Position vehicle on a bridge.

Drain gearbox oil at operating temperature $(71^\circ \div 93^\circ\text{C})$ removing the drain plug (2) of the control module (1). After having discharged the oil, re-assemble the plug (2) with a tightening torque equal to $25 \div 32$ Nm.

Disassemble oil filter covers (3) by unscrewing the 12 screws securing the gearbox control module. Remove filters and gaskets.

Disconnect the electric connector connecting external wiring to gearbox.

Hold gearbox control module with a proper hydraulic jack fitted with a support (module weighs 25 kg.).

Unscrew all the screws securing the gearbox control module to the main box.

By adequately operating, remove control module from gearbox compartment.

Refitting



To assemble gearbox control module, properly reverse operations described at disconnecting.

Comply with torque shown in table on page 177.


At the end of assembly check whether oil drain plug is well tightened, then introduce 28 litres of Tutela GI/A oil through filling pipe.



The below-described repair interventions deal only with replacement of faulty components: for possible diagnostics information pertaining there to, refer to Section "Electric/electronic system" of "Allison automatic gearboxes" Manual (printout No. 603.42.409).

REPLACING SPEED SENSORS

Replacing turbine speed sensor



To replace turbine speed sensor (2), disassemble gearbox control module complying with the previously described procedure.


Disconnect wiring from sensor (3).

Unscrew the two screws (1) connecting sensor to valve casings.


Install the new sensor by tightening screws (1) to a torque of 12 to 14 Nm.

Connect wiring (3) to sensor.

Assemble gearbox control module again according to the previously described procedure. **Engine revolutions sensor replacement**



REPLACING OIL LEVEL SENSOR



To replace oil level sensor (1) disassemble gearbox control module according to the procedure described in this Section


Disconnect wiring from sensor (1).

Unscrew screws (2) an d remove sensor.

Install the the new sensor by tightening the connecting screws according to the prescribed torque.


Assemble gearbox control module again according to the procedure described in this Section on page 179.

REPLACING OIL SUCTION FILTER



Disassemble gearbox control module according to the procedure described in this Section on page 179.

Disassemble filter cover (1) by unscrewing the screws securing it to oil sump (2).




Remove cover (1) and replace filter (2), gasket (3) and seal (4).

Install cover (1) and tighten securing screws to a torque of 12 to 14 Nm.

Assemble gearbox control module again according to the procedure described in this Section on page 179.

REPLACING THE SOLENOID VALVES

Disassemble gearbox control module according to the procedure described in the present Section on page 179.




- a) Solenoid valves (1), (2) and (3) belong to the N/C type (Normally Closed). To operate on these solenoid valves disconnect the wiring corresponding to the valves and disassemble valve casings (6) from the gearbox control module by unscrewing the screws connecting it to the oil sump (4).
- b) Solenoid valves (9) and (11) belong to the N/O type (Normally open); solenoid valve (10) belongs to the N/C type (Normally Closed). For operating on these solenoid valves, disconnect the wiring corresponding to the different valves and disassemble valve casings (7) from the gearbox control module by unscrewing the screws connecting it to the oil sump (4).
- c) To replace solenoid valve (8) (N/C type), disconnect wiring from all the solenoid valves and disassemble valve casing (6) and (7), by unscrewing the screws securing them to the oil sump (4). Remove separating plate dividing valve casings (6) and (7) from valve casing (5): Remove casing (5) from gearbox control module.


In the three case (a, b, c) proceed as follows with replacing the failed solenoid valve after disassembling the valve casing containing it:

- Remove the pin securing the solenoid valve from the valve casing bottom.
- Remove the failed solenoid valve from the valve casing.
- Install the new solenoid valve with the two O-rings in the kit.
- Use the pin to lock the solenoid valve.

After replacing the solenoid valve assemble the solenoid valve casings again by properly reversing the operations described in items a, b, c, and tighten screws to a torque of 12 to 14 Nm. Re-assemble the control module according to the procedure described in the present Section on page 179.



REPLACING PRESSURE SWITCH F3



Disassemble the control module according to the procedure described in this Section on page 179.

Disconnect connector (2) in pressure switch (1).

Remove pressure switch (1) by unscrewing the two screws connecting it to valve casing (3).


Install the new pressure switch and use the O-ring in the kit.

Tighten the securing screws to a torque of 5 to 8 Nm.

Connect the pressure switch connector again.

Assemble the control switch again according to the procedure described in this Section on page 179.

REPLACING THE SEAL RING ON THE OUTPUT SHAFT



Disconnect the transmission shaft from gearbox flange (2).

Unscrew screws (1) connecting securing plate (3) to the gearbox output shaft.

Remove the safety plate, the securing plate, the O-ring and the gasket.

Remove flange (2) from the rear cover (4) and use a proper tool to remove the seal ring.

Clean the seal ring seat and remove any slag present.

Replace the seal ring and the O-ring. Use keying device 99374013 to insert the seal ring in its seat.

Assemble gearbox flange again by properly reversing the above mentioned operations.

Tighten screws (1) to a torque of 30 to 35 Nm.

Connect the transmission shaft to the gearbox again.

Base - February 2003

5302 Gearbox EATON FSO 5206B	
	Page
DESCRIPTION	187
POSITION OF GEARSHIFT IDENTIFICATION TAG	188
SPECIFICATIONS AND DATA	189
Gear selection and engagement grid	192
TIGHTENING TORQUES	193
TOOLS	195
EXPERIMENTAL TOOLS	199
GEARSHIFT OVERHAUL	200
Checks	200
GEAR DRIVE CASE	200
Disassembling	200
Assembling	201
Refitting	203
Disassembling the gearbox	204
MOTION INLET SHAFT	207
Disassembling	207
Assembling	207
OUTPUT SHAFT	207
Disassembling	207
Assembling	211
INTERNAL DRIVING SHAFT	215
Disassembling	215
Assembling	216
Gearbox assembling	217
Adjusting the axial play of countershaft bearings	220

DESCRIPTION

Figure I

The Eaton FSO 5206 B gearshift is of the mechanic type, with synchronized forward gear engagement.

The gearbox is made of light alloy and is made up of a front half case, a rear half case (which incorporates the gear engagement gearing and controls), a drive case and a clutch bell.

The rear half case has, on its sides and rear portions, special openings for insertion of power takeoffs (where required).

Motion is transmitted by means of a constant-mesh gear set with helicoidal teeth (for $6^{th}/5^{th} - 4^{th}/3^{rd}$ speeds) and straight teeth (for 1^{st} speed and reverse).


The gears force-fitted onto the output shaft and the gear on the reverse gear shaft rotate idle on cylindrical roller cages.

The motion inlet shaft and the output shaft are supported, in the gearbox, by non-adjustable roller bearings.

The countershaft is supported, in the gearbox, by tapered-roller bearings that can be adjusted axially by means of ring shims.


Gear engagement synchronization is obtained by means of free-ring synchronizers with single cone (for 5th, 4th, 3rd speeds and reverse) and double cone (for 1st and 2nd speeds).

The gear engagement and selection control is of the mechanic type and is obtained by a rod on which the three engaging forks and the 4^{th} - 5^{th} speed engagement fork control block are force-fitted.



84438

POSITION OF GEARSHIFT IDENTIFICATION TAG



SPECIFICATIONS AND DATA

	GEARBOX	Eaton FSO 5206B
	Туре	Mechanical
(1) (3) (5) N AR (2) (4) (6)	Gears	6 forward gears reverse gear
	Gears engagement control	Mechanical
	Power takeoff (optional)	-1, On rear part -1, On side part
	Gears engagement:	
	5 th – 6 th / 3 rd – 4 th	Double-cone synchronizer
	□ I st – 2 nd	Free-ring synchronizer
U V	Reverse gear	Quick-connection type
	Gears anti-disengagement -	Retention of sliding sleeves by means of springs, pins, balls and dowels springs, pins and rollers
00	Gears - I st – 2 nd - 3 rd – 4 th / 5 th – 6 th	constant-mesh straight teeth helicoidal teeth
= ■ 00	Gear ratio First Second Third Fourth Fifth Sixth (overdrive) Reverse gear	6.08 3.52 2.09 1.35 1.00 0.79 5.43
Ĩ	Oil type Amount	TUTELA ZC 90 6.5 Kg. (7 lt)


SPECIFICATIONS AND DATA

Output shaft		
	Output shaft bearings	cylindrical roller type
	Assembling temperature: - fixed hubs - bushings - bearings - motion outlet flange	85°C
	Gear axial play: - I st speed - 2 nd - 3 rd - 4 th speeds - 5 th - 6 th speeds	0.40 to 0.57 0.35 to 0.48 0.31 to 0.53
	Play, in the seat, of fixed hub retaining snap rings	as near to zero as possible
	Fixed hub retaining snap ring thickness	
Motion inlet shaft		
	Motion inlet shaft bearing	cylindrical roller type
	Motion inlet shaft bearing	85°C
	Play, in the seat, of bearing retaining snap rings	as near to zero as possible
	Bearing retaining snap ring axial play adjusting ring thickness mm	3.70 - 3.75 - 3.80 - 3.85 - 3.90 - 3.95
Countershaft		
	Countershaft bearings	tapered-roller type
	Countershaft bearing assembling temperature	85°C
	Countershaft bearing axial play adjustment	by means of shims
	Play, in the seat, of bearing retaining snap rings	as near to zero as possible
	Bearing retaining snap ring thickness	2.12 - 2.07 - 2.02 - 1.97 - 1.92 - 1.87 - 1.82 - 1.77

SPECIFICATIONS AND DATA

Countershaft				
	HHI		Bearing axial play: - new - used	0.075 to 0.125 0.00 to 0.05
			Countershaft bearing preload adjustment	By means of rings
	A	IVECO	Countershaft preload adjustment rings thickness	mm 0.051 - 0.127 - 0.254 - 0.508 - 2.40 Supplied in special kits
			Countershaft gear assembling temperature	150°C
Synchronizers				
	F		Synchronizing ring wear limit check dimension mm	0.5 to 1.9
			LOCTITE sealant:	
			 for mating surfaces between cases and covers 	5900
			- matching body on motion inlet shaft	648

Gear selection and engagement grid




TIGHTENING TORQUES

	TOF	QUE
	Nm	(kgm)
PART	· -	6.9 ÷ 7.8
I Screws fastening the clutch bell to the front case	69 ÷ 78	3.5 ÷ 3.9
 I Screws fastening the clutch bell to the front case 2 Screws fastening the cover to the case 	35 ÷ 39	2 24
 Screws fastening the clutch bell to the front case Screws fastening the cover to the case Screw fastening the 6th - 5th speed fork trunnions 	35 ÷ 39 20 ÷ 24	2 ÷ 2.4
 Screws fastening the clutch bell to the front case Screws fastening the cover to the case Screw fastening the 6th - 5th speed fork trunnions Oil level check cap 	35 ÷ 39 20 ÷ 24 32 ÷ 37	3.2 ÷ 3.7
 Screws fastening the clutch bell to the front case Screws fastening the cover to the case Screw fastening the 6th - 5th speed fork trunnions Oil level check cap Screws or nuts for the screws fastening the front half case to the rear half case 	35 ÷ 39 20 ÷ 24 32 ÷ 37 51 ÷ 58	3.2 ÷ 3.7 5.1 ÷ 5.8
 Screws fastening the clutch bell to the front case Screws fastening the cover to the case Screw fastening the 6th - 5th speed fork trunnions Oil level check cap Screws or nuts for the screws fastening the front half case to the rear half case Screws fastening the cover to the half case 	35 ÷ 39 20 ÷ 24 32 ÷ 37 51 ÷ 58 35 ÷ 39	3.2 ÷ 3.7 5.1 ÷ 5.8 3.5 ÷ 3.9
 Screws fastening the clutch bell to the front case Screws fastening the cover to the case Screw fastening the 6th - 5th speed fork trunnions Oil level check cap Screws or nuts for the screws fastening the front half case to the rear half case Screws fastening the cover to the half case Reverse light switch 	35 ÷ 39 20 ÷ 24 32 ÷ 37 51 ÷ 58 35 ÷ 39 16 ÷ 22	3.2 ÷ 3.7 5.1 ÷ 5.8 3.5 ÷ 3.9 1.6 ÷ 2.2
 Screws fastening the clutch bell to the front case Screws fastening the cover to the case Screw fastening the 6th - 5th speed fork trunnions Oil level check cap Screws or nuts for the screws fastening the front half case to the rear half case Screws fastening the cover to the half case Reverse light switch Screw fastening the small cover to the case 	35 ÷ 39 20 ÷ 24 32 ÷ 37 51 ÷ 58 35 ÷ 39 16 ÷ 22 20 ÷ 24	3.2 ÷ 3.7 5.1 ÷ 5.8 3.5 ÷ 3.9 1.6 ÷ 2.2 2 ÷ 2.4
 Screws fastening the clutch bell to the front case Screws fastening the cover to the case Screw fastening the 6th - 5th speed fork trunnions Oil level check cap Screws or nuts for the screws fastening the front half case to the rear half case Screws fastening the cover to the half case Reverse light switch Screw fastening the small cover to the garbox drive case 	35 ÷ 39 20 ÷ 24 32 ÷ 37 51 ÷ 58 35 ÷ 39 16 ÷ 22 20 ÷ 24 20 ÷ 24	3.2 ÷ 3.7 5.1 ÷ 5.8 3.5 ÷ 3.9 1.6 ÷ 2.2 2 ÷ 2.4 2 ÷ 2.4
 Screws fastening the clutch bell to the front case Screws fastening the cover to the case Screw fastening the 6th - 5th speed fork trunnions Oil level check cap Screws or nuts for the screws fastening the front half case to the rear half case Screws fastening the cover to the half case Reverse light switch Screw fastening the small cover to the case 	35 ÷ 39 20 ÷ 24 32 ÷ 37 51 ÷ 58 35 ÷ 39 16 ÷ 22 20 ÷ 24	3.2 ÷ 3.7 5.1 ÷ 5.8 3.5 ÷ 3.9 1.6 ÷ 2.2 2 ÷ 2.4

	TO	
ART		RQUE
	Nm	RQUE (kgm)
Screw fastening the cover to the case	Nm 69 ÷ 78	RQUE (kgm) 6.9 ÷ 7.
Screw fastening the cover to the case Screws fastening the cover to the case	Nm 69 ÷ 78 69 ÷ 78	RQUE (kgm) 6.9 ÷ 7. 6.9 ÷ 7.
Screw fastening the cover to the caseScrews fastening the cover to the caseOil drain cap	Nm 69 ÷ 78 69 ÷ 78 32 ÷ 37	RQUE (kgm) 6.9 ÷ 7. 6.9 ÷ 7. 3.2 ÷ 3.
Screw fastening the cover to the caseScrews fastening the cover to the caseOil drain capOdometer revs sensor	Nm 69 ÷ 78 69 ÷ 78 32 ÷ 37 16 ÷ 22	RQUE (kgm) 6.9 ÷ 7. 6.9 ÷ 7. 3.2 ÷ 3. 1.6 ÷ 2.
Screw fastening the cover to the caseScrews fastening the cover to the caseOil drain cap	Nm 69 ÷ 78 69 ÷ 78 32 ÷ 37	RQUE (kgm) 6.9 ÷ 7. 6.9 ÷ 7. 3.2 ÷ 3.
Screw fastening the cover to the case Screws fastening the cover to the case Oil drain cap Odometer revs sensor M8 M10	Nm 69 ÷ 78 69 ÷ 78 32 ÷ 37 16 ÷ 22 20 ÷ 27	RQUE (kgm) 6.9 ÷ 7. 6.9 ÷ 7. 3.2 ÷ 3. 1.6 ÷ 2. 2 ÷ 2.7
Screw fastening the cover to the case Screws fastening the cover to the case Oil drain cap Odometer revs sensor M8 M10 Locknut fastening the motion outlet flange to the output shaft	Nm 69 ÷ 78 69 ÷ 78 32 ÷ 37 16 ÷ 22 20 ÷ 27 35 ÷ 39 490 ÷ 588	RQUE (kgm) 6.9 ÷ 7. 3.2 ÷ 3. 1.6 ÷ 2. 2 ÷ 2.7 3.5 ÷ 3. 49 ÷ 58
Screw fastening the cover to the case Screws fastening the cover to the case Oil drain cap Odometer revs sensor M8 M10 Locknut fastening the motion outlet flange to the output shaft Screws fastening the gearbox drive case to the front case	Nm 69 ÷ 78 69 ÷ 78 32 ÷ 37 16 ÷ 22 20 ÷ 27 35 ÷ 39 490 ÷ 588 35 ÷ 39	RQUE (kgm) 6.9 ÷ 7. 3.2 ÷ 3. 1.6 ÷ 2. 2 ÷ 2.7 3.5 ÷ 3.
Screws fastening the cover to the case Oil drain cap Odometer revs sensor M8 M10 Locknut fastening the motion outlet flange to the output shaft	Nm 69 ÷ 78 69 ÷ 78 32 ÷ 37 16 ÷ 22 20 ÷ 27 35 ÷ 39 490 ÷ 588 35 ÷ 39 20 ÷ 24	RQUE (kgm) 6.9 ÷ 7. 3.2 ÷ 3. 1.6 ÷ 2. 2 ÷ 2.7 3.5 ÷ 3. 49 ÷ 58 3.5 ÷ 3.

Base - February 2003

TOOLS	
TOOL No.	DENOMINATION
99305121	Hot-air apparatus
99322205	Rotating stand for assembly revision (capacity 1000 daN, couple 120 daN/m)
99322225	Assembly bearing support (to be applied on stand 99322205)
99340205	Percussion extractor
99341003	Simple-effect bridge
99341009	Pair of brackets




TOOLS	
TOOL No.	DENOMINATION
99342143	Peg for removing reverse gear shaft (use with 99340205)
99348004	Universal extractors for interiors 5 to 70
99370006	Handle for interchangeable beaters
99370007	Handle for interchangeable beaters
99370317	Reaction lever with flange check extension
99370349	Keyer for drive shaft front gasket assembling (use with 99370006)

TOOLS	
TOOL No.	DENOMINATION
99370629	Gearbox bearing support during vehicle disconnection and re-connection
99374092	Beater for external bearings race assembling (69-91) (use with 99370007)
99374201	Keyer for assembling gasket on rear gearbox cover

EXPERIMENTAL TOOLS

This chapter illustrates the technical working drawing of the experimental tools (S.P. 2413) used in the gearshift overhaul described in this section, which can be manufactured by the repair workshop operators themselves.



530210 GEARSHIFT OVERHAUL



The unit must be washed thoroughly prior to overhauling. The specific and/or general equipment must be used for the purpose for which they are intended. The disassembled parts must be put in the special container by following the disassembling

sequence, in order to facilitate re-assembling. Upon re-assembling, the parts must always be replaced with new ones: the gaskets and seal rings, elastic pins, safety snap rings and springs. The nuts and screws must be tightened to the specified torque, and their threads must be dry, degreased and spread with LOCTITE 641. The lubricant and detergents must be disposed of in compliance with the specific regulations in force.

Overhaul operations must be carried out by means of the specific tools indicated. On disassembling, parts must be put aside by following the disassembling sequence, to facilitate later re-assembling.

Checks

The gears, synchronizing rings, matching bodies and engagement sliding sleeves must not show faults or excessive tooth wear.

The output shaft must be free from dents, especially on the gear roller cage rotating surface.

The reverse speed idler gear shaft surface must be smooth and free from scoring.


The gearbox half cases must not show cracks and the bearing seats must not be damaged nor worn, to prevent the bearing outer races from rotating in the seats.

Verify that the shoulder spacers are not damaged nor worn.

The gear engaging forks must not show cracks and must slide freely, yet with no notable play, on the control rod.

Verify that the control forks are in full working order.


Verify that the bearings and bushings are not worn, damaged or overheated.




Use ropes, hooks and a hoist to position and secure gearbox (1) on support 99322225 (5) of rotary stand 99322205 (4). Put the gear lever in neutral.

Remove screws (2) and take gear drive case (3) off the gearbox.


Disassembling




If no reference mark is found on rod (2), mark the assembling position of lever (4). Loosen screw (1) and remove lever (4). Remove sleeve (3).





Remove the neutral gear signalling switch (3) with cap (2) below and oil vapour vent (1).




Remove screws (1) and take off small cover (2) with gasket (5). Take out spring (3) and pin (4).








Remove cap (1), with punch (6), take off plug (2) linking selector (5) to rod (4).




Take note of the assembly position of selector (2) on rod (3). Take rod (3) out of case (1) and selector (1), then remove the latter.

Assembling




Use a suitable beater and coupler to replace, where necessary, bushings (2 and 3) and seal ring (4). Gasket (1) must be replaced only if it is damaged.




Place selector (3) in case (1) in the same position taken note of upon disassembling, then insert rod (4) and link with plug (2).

When removing plug (2), properly support rod (4) to prevent blows caused by ramming from affecting the case bushings.




Mount snap ring (1), cup (3), springs (4 and 5), cup (6) and snap ring (7) on rod (2).

Fit new snap rings.




Fit a new seal ring (3) on cover (4), then mount the same with a new gasket (2) and bracket (6) on case (1). Fasten the screws by means of washers (5) and tighten them to the specified torque.




Insert pin (4) and spring (3) into the case.


Mount small cover (2) with a new gasket (5), then fasten screws (1) to the specified torque.




Insert cap (2) in the case, then fasten switch (3) by tightening it to the specified torque. Fasten vent (1) and tighten it to the specified torque.



Disassembling the gearbox



Stop rotation of flange (1) by applying lever 99370317 (2) to the same, then remove retaining nut (3).



Take flange (3) out of the output shaft by means of an extractor made up of bridge 99341003 (1) and brackets 99341017 (2) applied as shown.





Figure 27

84462

Take off arbor (2) by means of striking extractor 99340205 (1).


Remove reverse gear (4) complete with shoulder rings (3), roller bearings (5) and spacer ring (6).




Turn the gearbox upside down.

Eject the elastic pin by means of a suitable punch (4). Remove protecting cap (6). Use a punch and take, by acting in the direction of the arrow, arbor (5) out of clutch bell (1) and fork (3), then remove the latter.


Remove screws (2) and take clutch bell (1) off the front case.




Remove snap ring (2) retaining bearing (4) to the motion inlet shaft (1), then remove spacer (3).



Remove screws (1) and take gear drive case (2) off the gearbox.




Remove screws (1), take off small cover (2) with gasket (3), then take out spring (4) and pin (5).




Remove screws (1) with the washers and take out fork trunnions (2) complete with seal ring (3).

Take note of the position of screws (7) and screws with nuts (4), then remove them. Take front half case (5) off rear half case (6).



Remove fork (2) complete with dowels (1) from sliding sleeve (4) and selector (3).



4

5

Page Figure 40 Image: Comparison of the page Image: Compage Image: Compage </t

Use ordinary tools to take the cylindrical roller bearing inner race (5) and matching body (7) off the motion inlet shaft (6).

Assembling

Heat roller bearing inner race (5) to ~ 85 °C, then fit it onto motion inlet shaft (6).

Apply LOCTITE 648 on inner teeth (\rightarrow) of matching body (7), then mount the latter onto motion inlet shaft (6).


OUTPUT SHAFT

Disassembling

All snap rings are provided with replacement parts of different thickness in order to obtain correct assembly play. Snap rings must be disassembled and re-assembled with care so as not to score the output shaft surface.


Prior to taking apart the output shaft, verify that the axial play of every single gear falls within the prescribed values.

Take note of the assembling position of synchronizers - matching bodies, hubs and sliding sleeves, so as to be able to fit them back in the same positions.




Take $5^{th} - 6^{th}$ gear engagement sliding sleeve (2) off hub (1); pay attention to the escape of rollers (3), pins (4) and springs (5), then recover the same.

Remove snap ring (6).




Take off matching body (1), 6th speed gear (2) and roller cage (3). Remove spap ring (4)

Remove snap ring (4).




Turn the output shaft upside down.


Use an extractor made up of bridge 99341003 (1), tie bars 99341019 (7), grips 99341025 (2) and clamp 99341015 (6), to remove reverse gear (5), shoulder ring (4) and roller bearing inner race (3), then take out the roller bearing below.




Take off snap ring (1).




Use an extractor made up of grips 99341023 (4), tie bars 99341020 (6), bridge 99341003 (1) and clamp 99341015 (5) to remove 1st speed gear (3) and fixed hub (2) for reverse gear.




Remove matching body (1), inner ring (2), intermediate ring (3), synchronizing ring (4) and roller cage (5).



Take 1st - 2nd gear engagement sliding sleeve (2) off hub (1); pay attention to the escape of balls (5), springs (3) and dowels (4), then recover the same. Remove dowels (6) and take off snap ring (7).




Use a hydraulic press to remove 1st speed gear (7) together with matching body (6), synchronizing ring (3), intermediate ring (4), ring (5) and hub (2) from output shaft (1).




84482


Turn output shaft (1) upside down. Remove snap ring (2). Use a hydraulic press to remove 4th speed gear (11), matching body (10), synchronizing ring (6), synchronizing unit (8), synchronizing ring (7), matching body (6), 3rd speed gear (5), roller cage (4) and bushing (3).




Take 3rd - 4th gear engagement sliding sleeve (2) off hub (1); pay attention to the escape of hub of rollers (3), pins (2) and springs (5), then recover the same.










Mount synchronizing ring (7) so that its projections (8) are inserted into the narrowest openings of hub (9).


Mount inner ring (5) and intermediate ring (3) so that the inner tabs (4) of the latter match with the outer side openings of synchronizing ring (7).

Mount matching body (1) so that the slots (2) of the same are inserted in the tabs of ring (5).


Mount snap ring (2), the thickness of which produces axial play of the same into its own seat (3), as near to zero as possible. Check axial play of 1^{st} speed gear (5), which must fall within the range of 0.40 \div 0,57 mm.




Lubricate roller cage (3), then fit it onto output shaft (1) and mount reverse gear (2).



Heat the rear roller bearing inner race (2) to \sim 85 °C, then fit it onto output shaft (1).




Turn the shaft (placed in the vice) upside down, mount roller cage (1) and 3^{rd} speed gear (2).




Mount matching body (2) and synchronizing ring (3). Heat hub (1) to a temperature of 85° C, then fit it onto shaft (4), taking care that the synchronizing ring tangent stops are inserted into the respective seats of the hub.


Check axial play of 3rd speed gear, which must fall within the range of 0.35 \div 0.48 mm.




Mount springs (5) and small pins (4) on hub (2). Mount $3^{rd} - 4^{th}$ gear engagement sliding sleeve (1) on hub (2), then place the former so that it is slightly lifted compared to hub (2), then insert rollers (3) between small pins (4) and sliding sleeve (2).




Mount synchronizing ring (1) so that the tangent stop projections of the same are positioned in the wheel hub, then mount matching body (2).




Lubricate roller cage (3) and insert it into the 4^{th} speed gear (2), then mount the same on output shaft (1).








Mount snap ring (1), the thickness of which produces axial play of the same into its own seat (2), as near to zero as possible.



Lubricate roller cage (3), then fit it, together with 6^{th} speed gear (2), onto output shaft (1).









Gearbox assembling

Prior to assembling the gearbox, verify that the half cases and the covers are clean, and that all the gaskets and sealing materials have been removed from the mating surfaces. When fitting the fastening screws to the clearance holes, apply LOCTITE 641 sealant to the threads.




tapered-roller bearing outer race (3) into rear half case (1), so that it is slightly embedded compared to the case plane. Mount spacer ring (2).




Apply LOCTITE 5900 on cover (2) mating surface, then mount the cover on rear half case (1).


Tighten fastening screws (3) to the specified torque. Mount output shaft roller bearing (4).



Temporarily mount output shaft rear cover (2) on rear case (1), then tighten fastening screws (3) to the specified torque.




Place internal driving shaft (2) onto output shaft (1), then secure it firmly by means of a suitable rope.




Place countershaft (2) in rear half case (3). Lift the unit (1) thus assembled. Apply tool SP. 2413 (4) to the output shaft end, secure it by means of nut (5) and insert it into the rear half case.

While performing this operation, verify that the output shaft is inserted into the support bearing, the internal driving shaft is inserted into its respective bushing, and that the countershaft can be matched with the output shaft.




Mount synchronizing ring (3) and roller bearing (2) on output shaft (1).



Mount motion inlet shaft (2) by slightly lifting output shaft (5) and opening out countershaft (1). Remove the rope.


Place fork (4) pads (3) on sliding sleeve (7), then connect fork (4) to selector (8) pin.

Force-fit tool SP. 2413 (6) onto motion inlet shaft (2).




Use beater 99374092 and handle 99370007 to mount the countershaft tapered-roller bearing outer race (2) into front half case (1), so that it is slightly embedded compared to half case (1) outer plane by \sim 5 mm.

Mount cylindrical roller bearing (3) for the motion inlet shaft.




Apply LOCTITE 5900 on rear half case (3) mating surface, then mount front half case (2). Remove tool SP. 2413 (1).




Fasten screws (7) and the screws with nuts (4) in the original assembly position, then tighten them to the specified torque. Mount a new seal ring (3) on pins (2).

Apply LOCTITE 5900 on the mounting flange of pins (2), then insert the latter into the front half case so that they fit into the $5^{\text{th}} - 6^{\text{th}}$ speed engagement fork seats.


Fasten screws (1) with washers, then tighten them to the specified torque.




Insert pin (5) with spring (4) into the front half case. Mount small cover (2) with a new gasket (3). Fasten screws (1) and tighten them to the specified torque.




Mount spacer (3) on cylindrical roller bearing (4), then secure it to motion inlet shaft (1) by means of a new snap ring (2).





Apply LOCTITE 5900 on motion inlet shaft cover (1) mating surface, then mount it on front half case (3). Fasten screws (2) and tighten them to the specified torque.


Adjusting the axial play of countershaft bearings



Mount adjusting ring (4) (of the greatest thickness among those of the replacement parts supplied) on tapered-roller bearing outer race (5), then mount spacer (3).

With the tapered-roller bearing embedded, spacer (3) must jut out of half case (6) plane.

Mount cover (2) on half case (6), fasten screws (1) without the safety washers, tighten them evenly and, at the same time, turn the motion inlet shaft in both directions of rotation in order to correctly embed the bearings and feel some resistance when rotating.



Loosen screws (1) and fasten them again so as to slightly lock cover (2).

Use a thickness gauge (4) to measure, at four equidistant points, the distance 'X' between cover (2) and front half case (3).

The thickness ${\bf S}$ of adjusting ring (4, Figure 93) is obtained as follows:

$$S = A - X + P$$

where:

-

A = thickness of the adjusting ring used for measuring;

X = average value of measurements made;

 \mathbf{P} = bearing preload:


new bearings 0.075 ÷ 0.125 mm


used bearings 0.00 ÷ 0.05 mm

After measuring the thickness of the adjusting ring, remove screws (1) and cover (2).

Choose an adjusting ring from among those supplied as spares, of the calculated thickness, then mount it in place of the one used for measuring.

Apply LOCTITE 5900 on cover (2) mating surface, then mount the cover on half case (3). Apply LOCTITE 641 on screw (1) threads, then fasten the screws with new safety washers and tighten them to the specified torque.





Mount the level check and oil filling cap, then tighten it to the specified torque.

SECTION 5

Propeller shafts


	Page
DESCRIPTION	3
PROPELLER SHAFT LAYOUT ON VEHICLES .	8
PROPELLER SHAFT SPECIFICATIONS AND DATA	9
DIAGNOSTICS	11
TIGHTENING TORQUES	11
SLIDING PROPELLER SHAFT REMOVAL- REFITTING	12
🔲 Removal	12
Refitting	12
FIXED PROPELLER SHAFT REMOVAL- REFITTING	12
CHECKING PROPELLER SHAFTS ON VEHICLE	12


DESCRIPTION


Motion transmission from engine-gearbox to rear axle occurs through a propeller shaft that is sliding in a single section or in two sections composed of a fixed front shaft and a sliding rear shaft.


Coupling between assemblies and shaft is implemented by universal joints.


The front end of the sliding propeller shaft is composed, in addition to the universal joint, of a moving grooved sleeve also, which allows the shaft to modify its length in order to dampen possible axial transmission displacements, due to rear axle oscillations.












PROPELLER SHAFT LAYOUT ON VEHICLES




PROPELLER SHAFT SPECIFICATIONS AND DATA

	PITCH	3105	3330			369	90		4185			4455		4	4815		5175				5670	
		L mm	LI	L mm		LI mm	L mm	LI mm	L	1	LI mm	n	L nm	LI mm	L mm		LI mm	L mm		_I nm	L mm	
MODEL	GEARBOX TYPE	min max		min n	nax	n	nin ma	x	min	max		min	max		min	max	min	ma	x		min max	
110/120 EL 17	2855.6	1725 to 1835	985	965 to 10	76	1330 9	90 to 1100) 330	1485 to	1595	1330	1750 -	to 1860	1630	1740 to	850	-			-	-	
110/120 EL 17	2870.9	1540 to 1650	-	765 to 8	375	1140 9	90 to 1100	1100 1140		1485 to 1595		1750 -	to 1860	1610	1650 to	760	-	-		-	-	
110/120 EL 21	2865.6	1580 to 1690	-	8 0 to 9	920	1180 9	90 to 1100) 80	1485 to	1485 to 1595 1180		1750 -	to 1860	1560	1750 to	860	-	-		-	-	
110/120 EL 21	2870.9	420 to 530	-	1650 to 17	760	1020 9	90 to 1100) 1020	1485 to	1595	1020	1750 -	to 1860	1390	1750 to	860	-	-			-	
		1			1													1				
	PITCH	3105		3690		4185		4455		4815		5175		175	5		670	6570				
		L mm	LI mm	L mm	LI mm	L mm	LI mm	L mm	LI	n	L nm	L2 mm	LI mm	L mm	L2 mm	LI mm	L mm	L3 mm	L2 mm	LI mm	L mm	
MODEL	GEARBOX TYPE	min max		min max		min ma	x	min ma	x	min	max			min max			min max				min ma	
120/130 E 18	2855.6	1690 to 1800	1300	965 to 1075	1300	1460 to 15	70 395	6 630 to 7	40 1740	1650	to 1760	1300	1035	4 0 to 520	1300	1310	1630 to 1740	1300	1110	0	1630 to 17	
120/130 E 18-21	2870.9	1490 to 1600	1110	965 to 1075	1110	1460 to 15	70 0) 725 to 8	35 1730) 1460	to 1570	-	1730	1830 to 1940	1110	1110	1830 to 1940	-	1270	1850	1830 to 19	
120/130 E 21	2865.6	1650 to 1760	1180	965 to 1075	1180	1460 to 15	70 1235	5 740 to 8	50 1610) 1740	to 1850	-	1860	1865 to 1975	1350	1030	1830 to 1940	-	1350	1880	1875 to 19	
120/130 E 24-28	2895.9	1410 to 1520	-	1990 to 2100	1030	1455 to 15	65 1030) 725 to 8	35 380) 1725	to 1835	-	1895	580 to 690	-	1895	2075 to 2185	-	1090	1895	1875 to 19	
120/130 E 24	FSO5206B	1540 to 1650	1155	965 to 1075	1155	1460 to 15	70 1155	5 1740 to 8	50 1500) 1740	to 1850	-	1740	1865 to 1975	-	-	1830 to 1940	-	-	-	1875 to 19	
150 E 21	2865.6	1635 to 1745	1190	1040 to 1150	1270	1445 to 15	55 1270) 7 5 to 8	25 1630) 1715	to 1825	-	1860	1830 to 1940	1350	1020	1830 to 1940	-	1350	1880	1865 to 19	
150 E 21	2870.9	1475 to 1585	-	2065 to 2175	1115	1445 to 15	55 1115	5 7 5 to 8	25 1470) 1715	to 1825	-	1700	1830 to 1940	1190	1020	1830 to 1940	-	1190	1880	1865 to 19	
150 E 24	FSO5206B	1500 to 1610	1085	1020 to 1130	1160	1425 to 15	35 60) 695 to 8	05 1510) 1695	to 1805	-	1740	1825 to 1935	1240	1020	1820 to 1930	-	1240	1880	1850 to 19	

	PITCH	3105
		L mm
MODEL	GEARBOX TYPE	min max
130 E 18 RS	2865.9	1635 to 1745
150 E 21 RS	2870.9	1475 to 1585

	РІТСН	38	30		4190	
		LI mm	L mm	L2 mm	LI mm	
MODEL	GEARBOX TYPE	min max	min max		min max	min
260 E 28 KE	2895.9	1975 to 2085	673 to 833	1095	1255 to 1365	673


	РІТСН		3690		4185		4590		4815		5175		50	670		62	210		65	570
		LI mm	L mm	L2 mm	LI mm	L mm	L2 mm	LI mm	L mm	L2 mm	LI mm	L mm								
MODEL	GEARBOX TYPE		min max			min max			min max			min max								
180 E 21	2865.6	1190	1030 to 1140	1270	1440 to 1550	1270	1845 to 1955	1630	1960 to 1800	1860	1825 to 1935	1270	1085	1825 to 1935	1350	1895	1475 to 1585	1350	1895	1845 to 1955
180 E 21	2870.9	-	2035 to 2145	1115	1425 to 1535	1115	1825 to 1935	1470	690 to 800	1700	1825 to 1935	1115	1085	1825 to 1935	1190	1895	480 to 590	1190	1895	1825 to 1935
180 E 24-28	2895.9	-	1950 to 2060	1030	1420 to 1530	1030	1825 to 1935	1380	695 to 805	1605	1830 to 1940	1030	1085	1820 to 1930	1090	1895	490 to 600	1090	1895	1850 to 1960
180 E 24	FSO5206B	1085	1020 to 1130	1160	1440 to 1550	1160	1845 to 1955	1510	1710 to 1820	1740	1850 to 1960	1240	1020	1825 to 1935	1240	1880	500 to 6 0	1240	1880	1850 to 1960




DIAGNOSTICS

Main propeller shaft anomalies:

I - Transmission noises and vibration






the following warnings: Self-locking nuts must always be replaced and tightened at the required torque.

Check whether arrows on the sliding part and on shaft are aligned.


FIXED PROPELLER SHAFT REMOVAL- REFITTING



33701

Removal/refitting of these propeller shafts is similar to the sliding one, apart from the presence of a rear support (2) on the fixed shaft, that must be detached from the chassis after having unscrewed the four securing bolts and detached the sliding propeller shaft (1) from the fixed one.

CHECKING PROPELLER SHAFTS ON VEHICLE



Propeller shafts are provided by the manufacturer as assemblies ready for being assembled.

They are statically and dynamically balanced.

The welded plates to propeller shafts are balancing plates. In case of lack of plates, it is necessary to balance the shaft again.

By operating on the propeller shaft and simultaneously, in reverse order, on the sliding sleeve, check that there is no excessive clearance among grooved parts.

By operating on sleeve forks, check that spiders are not worn; otherwise, replace them.

SECTIC	DN 6	
5250	Rear axles	
		Page
MERITO	R AXLE SP 145 E	3
MERITO	R AXLE MS08 - 125	*
MERITO	R AXLE MS10 - 144	*
MERITO	R AXLES MS10 - 164	*
MERITO	R AXLES MSI 3 - 165	*
	The rear axles marked with an asterisk will be vith in the next edition.	dealt

AXLES IN TANDEM Meritor SP 145 E

	Page
PD 145 E (R 2468) (INTERMEDIATE)	5
PR 140 E (R 0868) (REAR)	53

Axles in tandem (Intermediate) Meritor PD 145 E (R 2468)

	Page		
DESCRIPTION	7		
SPECIFICATIONS AND DATA	7		
TIGHTENING TORQUES			
TOOLS			
EXPERIMENTAL TOOLS	18		
INTERMEDIATE AXLE DISCONNECTION/ RECONNECTION (with Hendrickson suspensions)	21		
Disconnection	21		
Reconnection	21		
SERVICING INTERMEDIATE AXLE ASSEMBLY PD 145 E (R 2468)	23		
AIR BREATHER REMOVAL-REFITTING	23		
SERVICING WHEEL HUBS	23		
Checking wheel hub components	24		
ASSEMBLING WHEEL HUBS	25		
REMOVING DIFFERENTIAL GEAR - TRANSFER BOX (with rear axle on stand 99322215)	28		
REFITTING DIFFERENTIAL GEAR - TRANSFER BOX (with rear axle on stand 99322215)	28		
REPAIRING INTER-AXLE UNIT	29		
Dismantling inter-axle unit	29		
Checking inter-axle unit components	31		
Fitting inter-axle unit	31		
Adjusting drive input shaft bearing end float	33		
Adjusting differential lock and inter-axle control pin end-stop	34		
REPAIRING MAIN DIFFERENTIAL-DISMANTLING DIFFERENTIAL CASING	34		
Dismantling gear cage	38		
Checking differential components	38		
Assembling gear cage	39		

	Page
ASSEMBLING DIFFERENTIAL CASING	40
Calculating bevel pinion position in differential casing	40
COMPUTATIONAL EXAMPLES	41
Adjusting the cap gap	44
CORRECTING THE CROWN WHEEL AND PINION CONTACTS (AFTER ASSEMBLY)	46
REMOVING-SERVICING-REFITTING INTER-AXLE OUTPUT SHAFT	49

DESCRIPTION

The intermediate axle is a bearing axle type with a simple reduction; it consists of a box made in metal sheet, housing a reduction differential and a main differential. Drive transmission from the reduction to main differential is achieved through a helical gear pair. The reduction differential is made up by a drive input shaft keying: the front support, the oil pump, the driving gear housing the front crown wheel and side pinion assembly; the rear crown gear is housed on the axle box and keyed on the drive output shaft.

A sliding sleeve is mounted on the rear crown wheel to lock the differential; the sliding sleeve is driven by a pneumatic device through a fork.

Taper roller bearing axial clearance is adjusted by inserting shims between front and wheelwork support; the main differential is made up by a pair of bevel reduction gears with helical toothing (pinion – ring gear assembly) and a wheelwork box (side pinion – crown wheel assembly).

The adjustment of the bevel pinion assembly is made through adjusting rings placed between the two taper roller bearings. You can also adjust the bevel pinion position with reference to the ring bevel gear by changing the thickness of the pack of the rings, which are inserted between the taper bearing under the head and the bevel pinion support.

The wheelwork box is supported by two taper roller bearings and can be adjusted axially through two threaded ring nuts.

The axle is provided with a pneumatic control differential locking device.


The wheel hubs are supported by two tapered-roller bearings floating on a post and adjustable by means of a threaded nut.


SPECIFICATIONS AND DATA


SPECIFICATIONS	AND DATA	
	Axle type:	PD 145 E (R 2468)
	Bearing axle with simple reduction, with a pneumatic control differential locking device	
MAIN DIFFERE	NTIAL ASSEMBLY	
	Crown wheel and pinion assembly reduction ratio (pinion/ring gear teeth number)	/5.86 (7/41) /5.29 (7/37) /4.63 (8/37)
	Bevel pinion bearings	2 taper roller bearings
	Bevel pinion bearing rolling torque	
	New bearings Nm kgm Reused bearings Nm kgm	1.12 to 5.08 0.112 to 0.508 1.68 to 3.39 0.168 to 0.339
	Bevel pinion bearing pre-load adjustment	through shims
	Thickness of bevel pinion bearing pre-load adjusting rings	5.30-5.33-5.35-5.38-5.40-5.50-5.60 5.70-5.80-5.90-6.00-6.10-6.13-6.15-6.18-6.20
	Clearance between pinion and ring gear mm new gears reused gears recover working conditions	0.20 to 0.46
	Clearance adjustment between pinion and ring gear	Through ring nuts


Cap opening out mm	0.08 to 0.22
Differential box bearing rolling torque Nm kgm	1.7 to 3.9 0.17 to 0.39
Cap opening out adjustment	Through ring nuts
Rolling torque between side gear pinions and crown wheels Nm kgm	Max. 68 Max. 6.8
Bevel pinion positioning with reference to differential box	Through adjusting shims
Thickness of adjusting rings inserted between bearing ring and differential carrier	0.076 - 0.127 - 0.254
FERENTIAL ASSEMBLY	
Reduction differential bearings	2 taper roller bearings
Reduction differential bearing axial clearance mm	0.05 to 0.20
Reduction differential bearing axial clearance adjustment	Through adjusting shims
Thickness of reduction differential bearing adjusting shims mm	0.076 - 0.127 - 0.254
WHEEL HUBS	
Wheel hub bearings	Two taper roller bearings
Hub bearing axial clearance mm	0.00 to 0.05
Wheel hub bearing rolling torque Nm kgm	Max. 1.96 Max. 0.20
Wheel hub bearing axial clearance adjustment	Through nut
xle oil TUTELA W140/M-DA Hendrickson suspension Litres (kg)	16.2 (14.6)
	Differential box bearing rolling torque Nm kgm Cap opening out adjustment Rolling torque between side gear pinions and crown wheels Nm kgm Bevel pinion positioning with reference to differential box with reference to differential box Thickness of adjusting rings inserted between bearing ring and differential carrier and differential bearings Reduction differential bearing axial clearance mm Reduction differential bearing axial clearance adjustment mm Thickness of reduction differential bearing axial clearance mm wheel hub bearings Wheel hub bearing rolling torque Nm kgm Wheel hub bearing rolling torque Nm kgm Wheel hub bearing axial clearance adjustment Nm kgm Wheel hub bearing axial clearance adjustment Nm kgm Wheel hub bearing rolling torque Nm kgm Wheel hub bearing axial clearance adjustment Nm kgm Wheel hub bearing axial clearance adjustment Nm kgm Wheel hub bearing axial clearance adjustment Nm kgm


TIGHTENING TORQUES











TOOLS	
TOOL No.	DENOMINATION
99348001	Puller tool with clamping device
99355025	Wrench for differential gearcase bearing adjustment ring nuts
99355069	Wrench (75 mm) for differential bevel pinion nut (to be used with 99370317)
99355088	Wrench (60 mm) for differential bevel pinion nut (to be used with 99370317)
99355131	Wrench (55 mm) for the nut of the drive input flange of the transfer box (use with 99370317)
99355167	Wrench (114 mm) for wheel hub bearing adjustment nut


TOOLS	
TOOL No.	DENOMINATION
99360311	Oil filter wrench
99370005	Hand-grip for interchangeable drift punches
99370007	Hand-grip for interchangeable drift punches
99370317	Reaction lever and extension for flange lock
99370509	Hook to remove differential gearcase half-housing
99370616	Support to remove-fit back differential


TOOLS	
TOOL No.	DENOMINATION
99370617	Universal support to remove-fit back rear axles
99371047	Stand to hold differential half-housing when tightening crown wheel screws (to be used with 99322205 - 99322225)
99374093	Drift punch for installation of bearing outer races (91 ÷ 1 34) (use with 99370007)
99374094	Drift punch for installation of bearing outer races (134+215) (use with 99370007)
99374134	Installer, wheel hub inner seal
99374162	Installer, transfer case input shaft seal


TOOLS		
TOOL NO.		DESCRIPTION
99374163		Keying device for assembling the distributor motion output shaft sea
99381125		Pliers for removal of circlips on transfer box shaft
99389816		4 x torque multiplier, with square connection, 3/4" in, 1" out (maximum torque 2745 Nm)
99389819	Constant of the second	Torque wrench (0 - 10 Nm) with 1/4'' square fitting
99395026		Tool for measuring hub rolling drag torque (use with torque wrench)
99395027		Tool for determining thickness of differential bevel pinion adjust ment shims (use with 99395693)

EXPERIMENTAL TOOLS


This heading covers the technical working drawings of the experimental tools (S.P.), used when overhauling the rear axle described in this section, that can be made in your repair shop.







Suitably reverse the operations performed for disconnecting checking the electric connections.



I. Brake wear sensor connection - 2. Reaction triangle fastener - 3. Tie rod fixing bracket - 4. Tie rod fastener -5. Propeller shaft - 6. Electric connection - 7. Air piping - 8. Piping

74092


525010 SERVICING INTERMEDIATE AXLE ASSEMBLY PD 145 E (R 2468)



Removal/installation operations concerning the following units: axle shafts, brake shoes and drums, air breather, differential can be performed with the unit on the vehicle.

Before placing the axle assembly on the stand, loosen the bottom plug and drain the oil.

525013 AIR BREATHER REMOVAL-REFITTING




77221

Set the rear axle assembly on the stand 99322215, Check that the air breather (1) is not clogged; if it is, remove it, clean it carefully and fit it back on.




The identification data of the rear axle assembly PD 145 E (R 2468) are given on the plate (2).




77222

Lock the differential gear, operating as follows: unscrew the screw (7) and screw it down in the hole (8): screw down the screw fully to get the differential lock to go in.




Remove the screws fixing the drum (1) to the wheel hub (2) and screw them down in the holes (\rightarrow) to extract the drum (1).



Using the wrench 99355167(1) unscrew the lock nut (2) locking the bearing adjustment nut (4).


Extract the retaining ring nut (3), unscrew the bearing adjustment nut (4) and take out the bearing (5).




Disassemble the wheel hub (1). In case of difficulty, use the puller comprised of: arms 99341016 (2), yoke 99341003 (3) and block 99345055 (4), applied as shown in the figure.



When putting aside the wheel hub, take care not to damage the phonic wheel (1, Figure 12).



Only dismantle the phonic wheel (1) if it is to be replaced. Do so using a suitable lever.





If the phonic wheel (1, Figure 12) is not to be dismantled, do not use it as a support.

Use a general purpose bronze drift (1) to remove inner bearing cup (2).

Sealing ring (3) will also be expelled.

Proceed in the same way to remove the outer bearing cup.

Checking wheel hub components



Clean every single hub component thoroughly.

Examine axle drive shafts and make sure they are free from any distortion.



Check wheel mounting bolts: if their threads are distorted or damaged replace without hesitation on a power press.


Lubricate bearings and rock roller cages; rotation must be smooth without any sign of binding.

Check condition of wheel bearing adjuster nut and axle sleeve end threads: if necessary, change the nuts.

Check the oil slinger: if damaged, replace.

Discard old seals and fit new ones.

525030 ASSEMBLING WHEEL HUBS




Ensure the rest surface of screw heads is free from burrs, slags or nicks before fitting new screws (3).

The load to be applied to screw heads for driving them into their seats must not exceed 2300 Kg.

When driving operation is completed, screws should abut perfectly on the wheel hub face : maximum squareness tolerance 0,2 mm.

If the oil slinger (2) was removed in order to be replaced, coat oil slinger and hub mating face with sealing compound that can resist heat to temperatures of 40 to 250°C.




Refit phonic wheel (2), if necessary, by heating to a temperature of 150°C. Ensure phonic wheel is perfectly bedded onto hub seat after installation.

Check squareness of phonic wheel (2) as follows.

Position wheel hub (4) with taper roller bearings on base of column drill. Interpose a spacer between base and outer bearing race (5) so that wheel hub may turn.

Rest a plate (7) on the internal bearing roller ring (3).

Turn handle (8) to raise base so that drill chuck comes into contact with plate (7) and bearings (3 and 5) are slightly preloaded.



Fit taper roller bearing outer races in wheel hub using handle 99370007 (1) and drift (2): 99374094 for outer bearing race (3) and 99374094 for inner bearing race.


When fitting race (3) do not use phonic wheel (1) as a support base.


Press fit until bearings are 5 mm from abutting end and then complete operation by hand.



Turn wheel hub to settle bearings when pre-loading.


Position magnetic base dial gauge with flat base stylus as shown in figure and turn wheel hub. Check that maximum squareness error for phonic wheel (2) does not exceed 0,2 mm.





Lubricate the bearing seat on the sleeve and the wheel hub seal (1) with TUTELA W 140/M-DA oil.

Position the tapered roller bearing in the wheel hub (1) and, using the tool 99345103 (2) applied as in the figure, fit the wheel hub (1) onto the sleeve.




Tighten nut (${\sf I}$). Then adjust wheel hub bearing end play as follows.

Use wrench 99355167 (2) to tighten nut (1) to a torque of 98.1 Nm (10 kgm).


Tighten nut by turning hub simultaneously in both directions to settle bearings.

Loosen nut (1) to obtain an end play of $0.2 \div 0.3$ mm.




Fit the lock ring (2).

If the nut (1) for the locating dowel does not match any of the lock ring holes (2) (see \rightarrow), progressively undo the adjusting nut (1) until the lock ring can be inserted. (Consider also the end play specification obtained with the previous operation).





36305

Tighten nut (1) and torque it to 392.3 Nm (40 \pm 2 kgm) using wrench 99355167 (2).



Place a magnetic base dial gauge (1) on wheel hub (3); rest gauge stylus on sleeve (2) and check wheel hub end play. It should not be over 0.00 \div 0.05 mm.






Use retainer 99370317 (3) to stop flange (1) rotation. Unscrew drive flange (1) retaining nut using wrench 99355131 (2) and torque adaptor (4).

Remove screws (5) and disconnect axle housing output shaft mounting (6).

Loosen differential carrier (1) retaining screws. Screw in three screws to be used as extractors and separate differential carrier from axle housing by means of eyebolts and metal ropes.


Use mounting 99370616 for differential carrier removal with axle assembled on vehicle.

REFITTING DIFFERENTIAL GEAR – TRANSFER BOX (with rear axle on stand 99322215)




Coat the axle housing to differential mating face with sealant. Insert differential in axle housing. Tighten nuts (1) and screws with lock washers to the specified torque using a torque wrench (2).

Fit differential axle shafts as described in 525030 operation. Backout screw (3) to release the differential lock device; insert screw in its seat.




Turn the axle housing by 90°. Insert support (1) with drive output shaft (2) in the axle housing and tighten screw to the specified torque.




Stop flange (1) rotation by means of retainer 99370317 (4). With wrench 99355131 (2) and torque adaptor (3) tighten output shaft flange (1) retaining nut to the specified torque. Once assembly operations are completed, pour the specified quantity of TUTELA W140/M-DA oil into the axle housing. Then check efficiency of differential lock connection sending unit.

526060 REPAIRING INTER-AXLE UNIT Dismantling inter-axle unit




Detach the transfer box differential gear housing as described under the relevant heading.

Position the transfer box differential gear housing (1) on the rotary stand 99322205 (2) together with the mount 99322225 (3). Unscrew the screws (4) and remove the guard. Using tool 99360311 unscrew the oil filter (5).




Stop flange (1) rotation with tool 99370317 (2). Undo flange retaining nut using wrench 99355088 (3) and torque adaptor (4).




Remove nuts fixing mounting (1) to differential carrier and take it out together with input shaft, oil pump, gear and interaxle differential.

Remove shims (2).


Separate the differential housing as described in the relative chapter.




Remove cylinder (1) complete with inter-axle differential lock piston (2) and withdraw yoke (4) drive pin (3).




Remove the spring (1) and strip yoke (2), sleeve (3) and rear planetary gear (4).



Use a punch to expel cup (1) of rear planetary gear bearing (4, Figure 36).




Use extractor 99348001 (1) and reaction block (2) to dismantle cone (3) of rear planetary gear (4) roller bearing.




Tighten drive input shaft in a vice.

Remove snap ring (1) and take out differential gear assembly (2), gear (3) and thrust ring (4).




If the planet gear unit needs disassembling, make a mark (1), by means of a punch, on both half cases, in order to ensure correct match when re-assembling.

Unscrew screws (2), then separate the two half cases. Take off the spider unit, remove the four gears and pinion and the four spider thrust washers.



(3) by means of a suitable extractor.



Checking inter-axle unit components


Accurately clean each single component and check for wear in view of their possible re-use.



Make sure all screw, stud and ring nut threads are cleaned accurately so that clearance and torque specifications are not effected.


Always renew sealing rings, retaining rings and washers.

Fitting inter-axle unit




Tighten the drive input shaft (1) in a vice and install the oil pump (3).

Heat the bearing (2) to 100°C for 15 minutes and fit it on using a drift.




Using drift 99374093 (2) partially press fit cup (3) of bearing (2, Figure 43) in bearing cage (4). Complete installation manually using handle 99370007 (1).



Mount seal ring (3) with tool 99374162 on support (4). Install bearing cage (4) on oil pump (5) so that exhaust (\rightarrow) matches the valve seat (2).

Insert spring (1) in the seat for oil pressure relief valve and fit the plug.

Use a feeler gauge to check distance X between sealing ring (3) and mounting (4) at four equi-distant points. Distance X should be between $0.38 \div 0.76$ mm.




Mount the planet gear unit (if previously disassembled) by following the procedure below. Apply the specific lubricant used for the rear axle housing on all the other parts of the planet gear unit.

Mount the gears and pinion and the thrust washer on the spider.

Place the pinion unit and spider in one of half cases (1). Mount the remaining half case onto the half case with the spider unit. Make sure that the marks (2) available on each half case are aligned to one another.

Screw four of the cap screws (3) after applying LOCTITE. Screw the remaining cap screws (3) after applying LOCTITE on the thread, then tighten them to a torque of 60 \div 75 Nm.




Smear the thrust ring (4) with grease and arrange it under gear (3);

secure the gear on the drive input shaft (6),


then differential gear assembly (2) and fasten by means of snap ring (1).

Turn the input shaft (6) upside down and spline flange (5) onto it.


Fit washer (7) and screw in retaining nut (8) without fully tightening it.



Use drift 99374093 (2) and handle 99370007 (1) to fit bearing (2, Figure 51) cup (3) in the rear-axle differential carrier.



Heat bearing (2) to 100°C for 15 minutes and fit on rear side gear shaft (1).



Base - February 2003

36368


0

Fit new oil filter (5), fit guard (4) and secure it to differential carrier together with bearing cage (3) by screws (2). Check input shaft bearing (1) end play using a dial gauge. End


In case of a different reading, replace the shim pack with


play should be 0.05 to 0.20 mm.


another one of the appropriate thickness.




Using a punch, eject the ram (4) from the cylinder (3).









Take out the spring (1) and the fork (2) from inside the differential gear housing.




Remove split pin (3) and roll pin (1); dismantle caps (2) and bearing adjusting nuts (4).




Use a sling hook to extract the gear cage (1) complete with crown wheel and bearings.




Stop rotation of flange (1) by means of retainer 99370317 (2); with wrench 99355088 (3) and torque adaptor (4) loosen flange (1) retaining nut. Remove cover (5).




Remove nuts retaining bearing cage (1) to differential carrier. Pull out bearing cage complete with input shaft, oil pump, gear and inter-axle differential. Remove shims (2).




Remove the cylinder (1) together with the piston (2) of the differential locking-transfer box and extract the pin (3) governing the fork (4).



Remove drive shaft (3, Figure 57). Remove spring (1) and strip fork (2), sleeve (3) and rear planetary gear (4).




Block rotation of the bevel pinion with the tool S.P. 2373 (1); with wrench 99344069 (2) and the multiplier (3) remove the nut fastening the bearings to the bevel pinion and the washer beneath.




Apply on the housing a special extractor S.P. 2346, (5) and extract the pinion from the parts: spacer (1), gear (2), spacer (3) and bearing (4).


Then remove the above-mentioned parts from the housing.




Dismantle carrier bearing cups (1, 2, 3) using a drift.




Place tool 99348001 (2) under the taper roller bearing (1) and pull it off the bevel pinion (3) using a press.







Use hook (1) to raise the gear cage assembly and position on stand 99371047 (3).



Unscrew nuts (1) and remove them with screws. Drive out bevel crown wheel (2).




Use tool 99348001 (1) and reaction block 99345055 (2) to remove bearing (3) and bearing (4).



Mark the two casing halves (2 and 3) and the spider as indicated in the figure.

Unscrew screws (1) joining the casing halves. Lift the casing half (2).



Remove differential gear (2) with the associated thrust washer (1). Remove spider (6) with the four planetary gears (5) complete with thrust washers (3). Take the spider/planetary gear assembly apart. Remove the other differential gear with its thrust washer from the half cage (4).


Checking differential components


Thoroughly clean the individual parts making up the differential. Lubricate the bearings and spin the roller cages freely; these should rotate evenly without tight spots.

Check the seating surfaces of the bevel crown wheel and the bedding surface of the half cage so that the crown wheel adheres to it perfectly; distortion of these faces would cause vibration of the crown wheel attachment screws, compromising the satisfactory operation of the unit.




Thoroughly clean threads of screws, studs and ring nuts to prevent clearance or torque settings from being altered.






Heat bevel crown wheel (1) in a circulating air oven to a temperature of 100°C for about 15' and position it on its seating on the gear cage, ensuring that the holes for the bevel crown wheel/gear cage attachment screws are lined up.



Allow the bevel crown wheel to cool before positioning the screws. Use torque wrench (1) to tighten self locking nuts (2) to the specified torque.

ASSEMBLING DIFFERENTIAL CASING Calculating bevel pinion position in differential casing



If a new final drive set is installed, it will be necessary to know the meaning of the markings on pinion and crown wheel in order to position the pinion correctly:

- I. part number;
- tooth combination number. This number (example: 12/41) indicates that the pinion has 12 teeth and the crown wheel 41;
- 3. pinion/crown wheel pair set number.

All final drive sets are available as pairs: therefore pinion and crown wheel bear the same number which is stamped on head end for pinions and the outer face for crown wheels;

Never use a pinion and crown wheel set unless both components have the same number.

4. variation number needed to determine the thickness of the shim pack interposed between pinion bearing cage and differential carrier (in the example below, this number is identified as CP).

Every crown wheel is marked with a variation number which indicates the nominal assembly distance. Use this number to calculate the thickness of the shim pack that is interposed between pinion bearing cage and differential carrier.

The variation number (CP + 0, 1 or CP - 0, 1) is stamped on crown wheel outer face.

- 5. Pinion/crown wheel set manufacturing and inspection month and year.
- 6. Specified pinion/crown wheel set clearance.

Part number and tooth combination number are stamped on threaded end of all pinions. Number may alternatively be located on outer diameter of crown wheel. On any pinion/ crown wheel set, crown wheel will always bear an even stamped category number (e.g. 36786), whereas corresponding pinion will bear an odd number (e.g. 36787).

To determine the thickness of the shim pack to be interposed between bearing cage and differential carrier proceed as follows:

- 1. measure the thickness of the shim pack removed with the old final drive gear set. Use a micrometer or other suitable gauge and record the value found;
- read the CP marked on pinion to be replaced: if it is a plus (+) number or a minus (-) number respectively subtract or add it from the value obtained under I. above;

Take note of the result.



The value obtained in 2. will be used to calculate the thickness of the shim to be interposed between pinion bearing cage and differential carrier for correct new final drive assembly.

3. read the CP marked on the new pinion. Either add or subtract this value - depending on whether the sign is a plus or a minus - to or from the value noted under 2. above.


The result indicates the thickness which the new shim pack should have.

Refer to the following examples which cover all the possible calculation cases.


COMPUTATIONAL EXAMPLES

Case I:	mm
Original shim pack thickness	0.76
CP marked on pinion +2	+0.05
Resulting value	0.81
CP marked on new pinion +5	-0.12
Thickness for new shim pack	0.69
Case 2:	
Original shim pack thickness	0.76
CP marked on pinion -2	-0.05
Resulting value	-0.71
CP marked on new pinion +5	-0.12
Thickness for new shim pack	-0.59
Case 3:	
Original shim pack thickness	-0.76
CP marked on pinion + 2	+0.05
Resulting value	0.81
CP marked on new pinion -5	+0.12
Thickness for new shim pack	0.93
Case 4:	
Original shim pack thickness	-0.76
CP marked on pinion -2	-0.05
Resulting value	0.71
CP marked on new pinion -5	+0.12
Thickness for new shim pack	0.83

The difference between the value of the thickness of the new pack and that of the old one must be added to or subtracted from, depending on the case, the thickness of the adjustment ring (6, Figure 85).



Place the bevel pinion position adjustment rings (4) in the box and, using grip 99370007 (1) and drift 99374094 (2), mount the external ring (3) for the bevel pinion bearing. Fit remaining bearing cups using drift 99374093.




Measure the thickness of the adjustment ring (6) found on removal and note down the value (dimension A). Tighten the tool 99395027 (8) in a vice and place the following on it:

- the bearing (7) on the pinion side;
- the ring (6) previously measured.
- the gear (5);
- the spacer (4);
- the bearing (3).


Screw down the ring nut (2) and tighten it fully.

Position part (1) of tool 99395027 (8), equipped with a dial gauge, on the bearing (3) and reset the dial gauge on the end of the tool (8). Then remove:

- \Box the part (1);
- \Box the ring nut (2);
- the bearing (3);
- \Box the spacer (4);
- the gear (5);
- \Box the ring (6) the bearing (7) from the tool (8).



Insert the tool 99394027 (8, Figure 85) in the differential gear housing, comprehensive of the bearing (7, Figure 85), ring (6), gear (5), spacer (4), bearing (3). Screw down the ring nut (1) on the tool 99394027.



Reposition part (1) of tool 99395027, with the dial gauge previously reset on the bearing (3) and measure any difference (dimension B).

78313

The thickness **S** of the ring, or of the adjustment rings, is given by the following formula:

$$S = A - (\pm B) + C$$

where:

A = Thickness of the adjustment ring(s) fitted to reset the dial gauge;

 $\mathbf{B} =$ Value of the difference measured;

C = 0.2 mm coefficient that takes account of the expansion of the bearings due to the interference of assembly on the bevel pinion.

First example:

A = 13.12 mm **B** = + 0.13 mm **C** = 0.2 mm


S = |3.|2 - (+ 0.|3) + 0.2 = S = |3.|2 - 0.|3 + 0.2 = |3.|9 mm.

Second example:


A = 13.12 mm **B** = - 0.13 mm **C** = 0.2 mm

S = |3.|2 - (- 0.|3) + 0.2 = S = |3.|2 + 0.|3 + 0.2 = |3.45 mm.


Remove from the box the tool 99395027 (8, Figure 85) and take out the bearings, spacers and gear as shown in the figure.




Heat the bearing (2) to 100° C for 15 min. and, with a specific drift, fit it on the bevel pinion.




Insert the bevel pinion (3) in the box, simultaneously keying onto it the adjustment ring (1) of the thickness determined in the preceding measurements and the gear (2); screw the part 99345029 (4) onto the bevel pinion (3).






Position the caps taking care to make the reference marks coincide.


Insert the screws, together with the washers, and tighten them, using a torque wrench, to the prescribed torque. Then check that the external rings of the bearings slide, with a light pressure, in their respective seats without sticking. Again unscrew the fastening screws with the washers and remove the caps.



Using the hook (1), lift the gear housing (2) previously assembled and position it on the differential casing (3).



Position the caps (2), screw down the screws (1) with the washers and tighten them to the prescribed torque.



Lubricate taper roller bearings (1) and fit outer races. Screw in adjustment ring nuts (2).

Adjusting the cap gap


Adjusting and checking retraction of the caps can be done with two methods:

Ist METHOD

- 1. Use wrench 99355025 (3, Figure 98) to tighten the adjustment lock rings (4) of the bearings until eliminating the pinion-crown wheel clearance and end float. At the same time check that the crown wheel does not force on the pinion;
- using a suitable micrometer positioned diagonally and centrally in points (X-Y-arrows, Figure 97);

measure and note the distance of the caps;

Figure 97




3. further tighten the two adjustment lock rings (4, Figure 98) to obtain a retraction of the caps (2, Figure 98), measured on Axis X or on axis Y as described in point "2" of: 0.08 to 0.22 mm which corresponds to a preload on the bearings of 1.7 to 3.9 Nm (0.17 to 0.39 kgm).


2nd METHOD

A. Diagonally and centrally on the outer machined seats of both caps (2, Figure 98) position two dial gauges (1) with magnetic base as shown in Figure 98;

Figure 98




- B. proceed as described in point "I";
- after eliminating the end float further tighten the two adjustment lock rings (4) to obtain a retraction of the caps (2) of 0.08 to 0.22 mm, which corresponds to the sum of the readings on the dial gauges (1).



Adjust the axial clearance between the teeth of the pinion - crown wheel unit which must be 0.20 to 0.46 mm proceeding as follows:


- stop the bevel pinion from turning using tool 99370317;
- position the magnetic-based dial gauge (1) as illustrated;
- □ using wrench 99355025 (3) slacken the adjustment lock ring on the crown wheel side and tighten, to the same extent, the adjustment lock ring (2) of the opposite side. The purpose of this is to leave the previously-adjusted cap retraction unchanged;
- proceed as described until obtaining the specified clearance.

The clearance should be checked on 4 points the same distance apart.



Use a magnetic-based dial gauge (1) to check that the crown wheel (2) does not have any upper wobble above 0.20 mm. If it does, disassemble the differential unit and find the cause.


Refit and repeat the adjustment operations described previously.



To adjust the exact position of the pinion shims should be added under the pinion support to obtain the exact contact.

 $\ensuremath{\mathsf{Condition}}\xspace$ Condition C. Measure the clearance and restore it after adding shims.

Condition D. After adding shims, take the clearance towards minimum.




Contacts too much towards the crown wheel teeth top land

Conditions A-B. Indicates that the pinion is fastened to much towards the outside and therefore needs further adjustment. To adjust the exact position of the pinion, remove shims under the pinion support to obtain the exact contact.

Condition A. After removing the shims, take the clearance towards maximum.

 $\ensuremath{\mathsf{Condition}}\xspace \ensuremath{\mathsf{B}}\xspace.$ Measure the clearance and restore it after removing shims.



- 2. Top land
- 3. Pulling, convex side of tooth
- 4. Heel

PULLING. Central tending towards the top land on the tooth face and central on the tooth profile.


RELEASE. Central tending to the heel on the tooth face and central on the tooth profile.


Indicates that the pinion is fastened correctly.


The contact position can be further changed by changing the pinion-crown wheel clearance.

Condition E. Lower the clearance.

Condition F. Increase the clearance.









Fit on the spring pin (1) and the split pin (3) to lock the ring nuts (2-4).


If the spring pin or the split pin do not coincide with their respective seats on the ring nuts, slightly turn these so it is possible to insert the spring pin or the split pin,



Fit on the spring (1) and the fork (2) from inside the differential casing.



Position the fork (2) in the groove of the coupling (1) and fit this on the toothing (3) of the differential gear.




Mount the spindle (6). Lubricate the new seal (5) and fit it on the piston (4) and insert this into the cylinder (3). Apply sealant on the thread of the cylinder (3) and screw it down into the differential casing, tightening it to the prescribed torque.


Screw down the screw (2) so as to provisionally prevent the differential gear unlocking.

Remove the differential casing from the mounting and fit it back on the axle housing as described under the relevant heading.

Mount the differential locking - transfer box (Figure 53, page 33) and adjust it as described under the heading, "Adjusting differential locking-transfer box pin limit switch."



Position on the differential casing the adjustment rings (2) of the thickness determined under the heading "Adjusting drive input shaft bearing end float" and fit on the mount (1) comprehensive of the reduction gear transfer box.




Block rotation of the flange (1) using tool 99370317 (2); with wrench 99355088 (3) and multiplier (4) tighten the nut fastening the flange (1) to the prescribed torque.

Fit on the cover (5) with a new gasket.


Remove the differential casing – transfer box from the mounting 99322228 and fit it back on the axle housing as described under the relevant heading.

526082 REMOVING-SERVICING-REFITTING INTER-AXLE OUTPUT SHAFT




Stop rotation of flange (1) with retainer 99370317 (3). With wrench 99355131 (2) and torque adaptor (4) loosen shaft flange (1) retaining nut.


Removing retaining nuts (5) and separate shaft bearing cage (6) from axle housing.




Tighten the drive output shaft (3) in a vice; remove the nut securing flange (2) to drive output shaft (3) and dismantle flange (2) from shaft (3) using an extractor.



Remove sealing ring (1) from bearing cage (2) and take out snap ring (3) retaining bearing cup (4) and snap ring (5).





Tandem axles (Rear) Meritor PR 140 E (R 0868)

	Page
DESCRIPTION	55
SPECIFICATIONS AND DATA	55
TIGHTENING TORQUES	57
TOOLS	59
SERVICING REAR AXLE ASSEMBLY PR 140 E (R 0868)	64
AIR BREATHER REMOVAL/INSTALLATION	64
OVERHAULING WHEEL HUBS	64
REMOVING DIFFERENTIAL (with axle on stand 99322215)	64
REFITTING DIFFERENTIAL (with axle on stand 99322215)	64
REPAIRING DIFFERENTIAL	65
Removing differential lock	65
Dismantling differential casing	66
Dismantling gear cage	67
Dismantling bevel pinion support	67
Checking differential components	71
Assembling gear cage	71
Specimen calculations	73
Assembling differential casing	73
ADJUSTING THE CAP GAP	75
CORRECTING THE CROWN WHEEL AND PINION CONTACTS (AFTER ASSEMBLY)	78

DESCRIPTION

The axle is a bearing axle type with a simple reduction; it consists of a box made in stamped steel sheet and properly strengthened.

The differential consists of a reduction helical-toothed gear pair (pinion – ring gear assembly) and a wheelwork box (side pinion – crown wheel assembly).

The pinion is supported by two taper roller bearings and by one straight roller bearing.

The adjustment of the bevel pinion assembly is made through adjusting rings placed between the two taper roller bearings.

You can also adjust the bevel pinion position with reference to the ring bevel gear by changing the thickness of the pack of the rings, which are inserted between the differential box and the bevel pinion support.

The wheelwork box is supported by two taper roller bearings and can be adjusted axially through two threaded ring nuts. The axle is provided with a pneumatic control differential locking device.


The wheel hubs are supported by two taper roller bearings floating on the tube, which can be adjusted by means of a threaded nut.

SPECIFICATIONS AND DATA


Axle type:	PR 140 E (R 0868)
 Bearing axle with simple reduction.	
DIFFERENTIAL ASSEMBLY Crown wheel and pinion assembly reduction ratio (pinion/ring gear teeth number)	/5.86 (7/41) /5.29 (7/37) /4.63 (8/37)
Bevel pinion bearings	2 taper roller bearings and 1 straight roller bearing
Bevel pinion bearing rolling torque	
new bearings Nm kgm reused bearings Nm kgm	1.5 to 5.5 0.15 to 0.55 1.5 to 3.1 0.15 to 0.31
Bevel pinion bearing pre-load adjustment	through shims
Thickness of bevel pinion bearing pre-load adjusting rings mm	5. 9 - 5.22 - 5.30 - 5.32 - 5.52 - 5.55 - 5.45 - 5.60 - 8. 0 - 8.20 - 8.22 - 8.30 - 8.38 - 8.48 - 8.58
Clearance between pinion and ring gear mm	0.20 to 0.46
Clearance adjustment between pinion and ring gear	Through ring nuts

1		
	Cap opening out mm	0.08 to 0.22
	Differential box bearing rolling torque Nm kgm	1.7 to 3.9 0.17 to 0.39
	Cap opening out adjustment	Through ring nuts
	Rolling torque between side pinions and crown wheels Nm kgm	Max. 68 Max. 6.8
	Bevel pinion positioning with reference to differential box	Through adjusting shims
	Thickness of adjusting rings inserted between bevel pinion support and differential box	0.125 - 0.200 - 0.500
Ē	WHEEL HUBS	
	Wheel hub bearings	Two taper roller bearings
	Hub bearing axial clearance	0.00 to 0.05
	Wheel hub bearing rolling torque Nm kgm	Max. 1.96 Max. 0.20
	Wheel hub bearing axial clearance adjustment	Through nut
	Axle oil TUTELA W140/M-DA Hendrickson suspension Litres (kg)	12.2 (11)

	HTENING TORQUES		
	Figure I		
_			
Ľ			
			—5 —6 —7
			8 36395
	SECTION OF DIFFERENTIAL PR 140 E (R 0868)	/	
			36395
PART			36395 RQUE
PART	T	Nm	36395 RQUE (kgm)
I	T Nut to secure parts on bevel pinion	Nm 392.5± 42	RQUE (kgm) (139.2 ±14.2)
	Nut to secure parts on bevel pinion Transmitter locking nut	Nm 392.5± 42 40±5	36395 RQUE (kgm) (39.2 ± 4.2) (4 ± 0.5)
I	Nut to secure parts on bevel pinion Transmitter locking nut Differential locking device M6×1 (10.9)	Nm 392.5± 42 40±5 4±2	$\frac{RQUE}{(kgm)}$ (139.2 ± 14.2) (4 ± 0.5) (1.4 ± 0.2)
l 2	Nut to secure parts on bevel pinion Transmitter locking nut Differential locking device M6x1 (10.9) cover securing screw M6x1 (8.8)	Nm 1392.5±142 40±5 14±2 1±1	$\frac{RQUE}{(kgm)}$ (139.2 ±14.2) (4 ± 0.5) (1.4 ± 0.2) (1.1 ± 0.1)
l 2	Nut to secure parts on bevel pinion Transmitter locking nut Differential locking device M6x1 (10.9) cover securing screw M6x1 (8.8) Half box securing screw I st step: pre-tightening	Nm 1392.5±142 40±5 14±2 11±1 60±5	$RQUE = \frac{(kgm)}{(139.2 \pm 14.2)} \\ (4 \pm 0.5) \\ (1.4 \pm 0.2) \\ (1.1 \pm 0.1) \\ (6 \pm 0.5) \\ \end{cases}$
 2 3	Nut to secure parts on bevel pinion Transmitter locking nut Differential locking device M6x1 (10.9) cover securing screw M6x1 (8.8) Half box securing screw Ist step: pre-tightening 2 nd step: angle closing	Nm 1392.5±142 40±5 14±2 11±1 60±5	$\frac{RQUE}{(kgm)}$ (139.2 ±14.2) (4 ± 0.5) (1.4 ± 0.2) (1.1 ± 0.1)
 2 3 4	Nut to secure parts on bevel pinion Transmitter locking nut Differential locking device M6x1 (10.9) cover securing screw M6x1 (8.8) Half box securing screw Ist step: pre-tightening 2 nd step: angle closing Screw to secure bevel pinion	Nm 1392.5±142 40±5 14±2 11±1 60±5 85°	$\frac{(kgm)}{(139.2 \pm 14.2)}$ $\frac{(4 \pm 0.5)}{(1.4 \pm 0.2)}$ $\frac{(1.4 \pm 0.2)}{(1.1 \pm 0.1)}$ $\frac{(6 \pm 0.5)}{(6 \pm 95^{\circ})}$
l 2 3	Nut to secure parts on bevel pinion Transmitter locking nut Differential locking device M6x1 (10.9) cover securing screw M6x1 (8.8) Half box securing screw Ist step: pre-tightening 2 nd step: angle closing Screw to secure bevel pinion support to differential box	Nm 1392.5±142 40±5 14±2 11±1 60±5 85° 60±5	$\frac{36395}{(kgm)}$ (139.2 ± 14.2) (4 ± 0.5) (1.4 ± 0.2) (1.1 ± 0.1) (6 ± 0.5) $\div 95^{\circ}$ (6 ± 0.5)
 2 3 4	Nut to secure parts on bevel pinion Transmitter locking nut Differential locking device M6x1 (10.9) cover securing screw M6x1 (8.8) Half box securing screw Ist step: pre-tightening 2 nd step: angle closing Screw to secure bevel pinion support to differential box Ist step: pre-tightening 2 nd step: angle closing	Nm 1392.5±142 40±5 14±2 11±1 60±5 85° 60±5	$\frac{(kgm)}{(139.2 \pm 14.2)}$ $\frac{(4 \pm 0.5)}{(1.4 \pm 0.2)}$ $\frac{(1.4 \pm 0.2)}{(1.1 \pm 0.1)}$ $\frac{(6 \pm 0.5)}{(6 \pm 95^{\circ})}$
 2 3 4 5	Nut to secure parts on bevel pinion Transmitter locking nut Differential locking device M6x1 (10.9) cover securing screw M6x1 (8.8) Half box securing screw Ist step: pre-tightening 2 nd step: angle closing Screw to secure bevel pinion support to differential box Ist step: pre-tightening 2 nd step: angle closing Self-locking nut to secure ring bevel gear to half box	Nm 1392.5±142 40±5 14±2 11±1 60±5 85° 60±5	$\frac{36395}{(kgm)}$ (139.2 ± 14.2) (4 ± 0.5) (1.4 ± 0.2) (1.1 ± 0.1) (6 ± 0.5) $\div 95^{\circ}$ (6 ± 0.5)
 2 3 4	Nut to secure parts on bevel pinion Transmitter locking nut Differential locking device M6x1 (10.9) cover securing screw M6x1 (8.8) Half box securing screw Ist step: pre-tightening 2 nd step: angle closing Screw to secure bevel pinion support to differential box Ist step: pre-tightening 2 nd step: angle closing Self-locking nut to secure ring bevel gear to half box Ist step: pre-tightening 2 nd step: angle closing		$\frac{RQUE}{(kgm)}$ (139.2 ± 14.2) (4 ± 0.5) (1.4 ± 0.2) (1.1 ± 0.1) (6 ± 0.5) ÷ 95° (6 ± 0.5) ÷ 65°
 2 3 4 5	Nut to secure parts on bevel pinion Transmitter locking nut Differential locking device M6x1 (10.9) cover securing screw M6x1 (8.8) Half box securing screw Ist step: pre-tightening 2 nd step: angle closing Screw to secure bevel pinion support to differential box Ist step: pre-tightening 2 nd step: angle closing Self-locking nut to secure ring bevel gear to half box Ist step: pre-tightening 2 nd step: angle closing Self-locking nut to secure ring bevel gear to half box Ist step: pre-tightening 2 nd step: angle closing		$\frac{RQUE}{(kgm)}$ (139.2 ± 14.2) (4 ± 0.5) (1.4 ± 0.2) (1.1 ± 0.1) (6 ± 0.5) $\div 95^{\circ}$ (6 ± 0.5) $\div 65^{\circ}$ (10 ± 0.5)
 2 3 4 5	Nut to secure parts on bevel pinion Transmitter locking nut Differential locking device M6x1 (10.9) cover securing screw M6x1 (8.8) Half box securing screw Ist step: pre-tightening 2 nd step: angle closing Screw to secure bevel pinion support to differential box Ist step: pre-tightening 2 nd step: angle closing Self-locking nut to secure ring bevel gear to half box Ist step: pre-tightening 2 nd step: angle closing Self-locking nut to secure ring bevel gear to half box Ist step: pre-tightening 2 nd step: angle closing Screws and nuts to secure differential to axle box Ist step: pre-tightening 2 nd step: angle closing		$\frac{RQUE}{(kgm)}$ (139.2 ± 14.2) (4 ± 0.5) (1.4 ± 0.2) (1.1 ± 0.1) (6 ± 0.5) $\div 95^{\circ}$ (6 ± 0.5) $\div 65^{\circ}$ (10 ± 0.5) $\div 125^{\circ}$
 2 3 4 5 6	Nut to secure parts on bevel pinion Transmitter locking nut Differential locking device M6x1 (10.9) cover securing screw M6x1 (8.8) Half box securing screw Ist step: pre-tightening 2 nd step: angle closing Screw to secure bevel pinion support to differential box Ist step: pre-tightening 2 nd step: angle closing Self-locking nut to secure ring bevel gear to half box Ist step: pre-tightening 2 nd step: angle closing Screws and nuts to secure differential to axle box Ist step: pre-tightening 2 nd step: angle closing		$RQUE (kgm) (139.2 \pm 14.2) (4 \pm 0.5) (1.4 \pm 0.2) (1.1 \pm 0.1) (6 \pm 0.5) (6 \pm 0.5) (6 \pm 0.5) (10 \pm 0$
 2 3 4 5 6	Nut to secure parts on bevel pinion Transmitter locking nut Differential locking device M6x1 (10.9) cover securing screw M6x1 (8.8) Half box securing screw Ist step: pre-tightening 2 nd step: angle closing Screw to secure bevel pinion support to differential box Ist step: pre-tightening 2 nd step: angle closing Self-locking nut to secure ring bevel gear to half box Ist step: pre-tightening 2 nd step: angle closing Self-locking nut to secure ring bevel gear to half box Ist step: pre-tightening 2 nd step: angle closing Screws and nuts to secure differential to axle box Ist step: pre-tightening 2 nd step: angle closing		$RQUE (kgm) (139.2 \pm 14.2) (4 \pm 0.5) (1.4 \pm 0.2) (1.1 \pm 0.1) (6 \pm 0.5) \pm 95^{\circ} (6 \pm 0.5) \pm 65^{\circ} (10 \pm 0.5) \pm 125^{\circ} (10 \pm 0.5) \pm 1$




TOOLS	
TOOL No.	DESCRIPTION
99305121	Heater
99322205	Rotary stand for unit overhauling (capacity 1000 daN, torque 120 daN/m)
99322215	Stand for axle overhauling
99322225	Unit holder (to be mounted on stand 99322205)
99341003	Single-acting lift
99341012	Pair of brackets



TOOLS	
TOOL No.	DESCRIPTION
99355088	Wrench (60 mm) for differential bevel pinion nut (to be used with 99370317)
99355167	Wrench (114 mm) for wheel hub bearing adjustment nut
99370005	Tool to extract gaskets
99370007	Tool to extract gaskets
99370317	Reaction lever and extension for flange lock
99370509	Hook to remove differential gearcase half-housing

TOOLS	
TOOL No.	 DESCRIPTION
99370616	Support to remove-fit back differential
99370617	Universal support to remove-fit back rear axles
99371047	Stand to hold differential half-housing when tightening crown wheel screws (to be used with 99322205 - 99322225)
99374093	Drift punch for installation of bearing outer races (91÷134) (use with 99370007)
99374094	Drift punch for installation of bearing outer races (134÷215) (use with 99370007)
99374134	Guide to assemble wheel hub


	DESCRIPTION
	4 x torque multiplier, with square connection, 3/4" in, 1" out (maximum torque 2745 Nm)
Con of the second secon	Torque wrench (0 - 10 Nm) with 1/4" square fitting
	Tool for measuring hub rolling drag torque (use with torque wrench)
	Tool for determining thickness of differential bevel pinion adjust- ment shims (use with 99395603)
	Dial gauge (0+5 mm)



525030 OVERHAULING WHEEL HUBS

For the operations:


overhauling the wheel hubs (555030), follow the directions given for the Meritor rear axle PD 145 E.




threaded plug (2) and fit in its place screw (1) available on cylinder cover. Tighten screw fully in until the differential lock is activated.

Remove the drive shafts as described on page 23; unscrew the screws fixing the differential casing (1) and screw down three screws, that in this phase act as extractors, and extract it from the axle housing with two metal rope eyebolts.

REFITTING DIFFERENTIAL (with axle on stand 99322215)




Apply sealant to the rear axle housing contact surface.




Fit the differential into the axle casing; screw in nuts (2) and screws (3) complete with lock washers and tighten them to the specified torque using torque wrench (1).

Fit drive shafts into the differential as described in Figure 30, page 70; release the differential lock (if the axle has one) by unscrewing screw (1, Figure 5). Fit this screw in its seat on the cylinder cover and tighten plug (2, Figure 5), with washer, in the threaded hole previously occupied by the screw. Finally, fill the axle case with the specified amount of TUTELA W 140/M-DA oil and check the operation of the differential lock activation sending unit.


526210 REPAIRING DIFFERENTIAL Removing differential lock




99322005 (3) complete with support 99322228 (2). Only for axles with a differential locking device. Remove screw (4); screws (5) and cover (6) with copper washer, cylinder (7) with piston and sealing ring.





Use wrench 99355168 (2) to unscrew fork control shaft (1) and withdraw.






Use a punch to drive out the two roll pins (3) and separate fork (1) from sliding sleeve (2).






Using hook 99370509 (1), withdraw the gear cage complete with bevel crown wheel and bearing outer races (2).





Prevent flange (1) from rotating using holding tool 99370317 (3). Using wrench 99355088 (2) and adaptor (4), loosen the bevel pinion retaining nut.



Unscrew the screws securing the bevel pinion support to the differential casing.


Withdraw support (1) and bevel pinion from differential casing (3). Remove shims (2) adjusting the pinion position with respect to the crown wheel.







Mark the two casing halves (2 and 3) and the spider as indicated in the figure.

Unscrew screws (1) joining the casing halves. Lift the casing half (2).




Remove differential gear (2) with the associated thrust washer (1). Remove spider (6) with the four planetary gears (5) complete with thrust washers (3). Take the spider/planetary gear assembly apart. Remove the other differential gear with its thrust washer from the half cage (4).







Prevent the flange from rotating using tool 99370317 (2) and use a universal extractor or appropriate tool (1) to remove the transmission attachment flange from the bevel pinion.



Base - February 2003





Checking differential components

Thoroughly clean the individual parts making up the differential. Lubricate the bearings and spin the roller cages freely; these should rotate evenly without tight spots.

Check the seating surfaces of the bevel crown wheel and the bedding surface of the half cage so that the crown wheel adheres to it perfectly; distortion of these faces would cause vibration of the crown wheel attachment screws, compromising the satisfactory operation of the unit.



Thoroughly clean threads of screws, studs and ring nuts to prevent clearance or torque settings from being altered.


Check that there is no excessive wear in the splined portion for fitting the flange to the pinion; if there is, replace the pinion.


Check the planetary gears and associated thrust washers, the spider and differential gears and thrust washers. Replace all seals and gaskets, the locking pin for the adjustment ring nut and all lock washers.




If it should be necessary to replace the crown wheel or pinion, both must be replaced as the parts are supplied as matched pairs.

Assembling gear cage






Position half cage (2) on fixture 99371047. Position differential gear thrust washer (1) in the half cage (2) and then fit differential gear.



Fit spider (6) complete with planetary gears (5) and associated thrust washers (3) to half cage (4). Position second differential gear (2) with thrust washer (1).




36323

Lock the differential with the parts (1); fit on the half box (3). Check that the marks made at the time of removal coincide. Apply a few drops of "LOCTITE 270" on the thread of the screws (2).

Tighten the screws (2) to the prescribed torque.



It is always advisable to renew screws (2).



The tooth combination number (for example 5-37) indicates that the pinion has 5 teeth and the crown wheel 37, equal to a drive ratio of $7.4 \ I$.

Pinion/crown wheel assemblies are matched pairs.

D Both parts are, therefore, engraved with the same number. On pinions, this number is generally engraved on the end of the head while on crown wheels it is generally engraved on the outside diameter



Never use a pinion and a crown wheel which do not have the same number.

Every crown wheel has a variation number which indicates the nominal assembly distance. Use this variation number to calculate the thickness of the shims to be placed between the pinion support and the differential casing.

This variation number (for example C.P. + 0.1, or C.P. - 0.1 mm) is stamped on the outer part of the crown wheel.

To calculate the thickness of the shims to be placed between the pinion support and the differential casing, proceed as follows :

- measure the thickness of the shim pack used with the pinion/crown wheel assembly to be replaced. Use a micrometer or gauge and take note of the measurement recorded;
- 2. read the C.P. engraved on the crown wheel to be replaced. If this number represents a plus value (+), subtract it from the measurement recorded above at point 1.

If this number represents a minus value (-), add it to the measurement recorded at point 1 above.

Take note of this measurement.



The measurement obtained at point 2 will be used to calculate the shim pack to be placed between the pinion support and the differential casing, depending on the new pinion/crown wheel assembly.

7. Read the C.P. engraved on the new crown wheel. Add or subtract the value according to algebraic value (+ add, - subtract) from the measurement recorded at point 2.

The value obtained indicates the thickness of the new shim pack to be used.

Refer to the following examples which cover all possible calculation combinations.

Specimen calculations

Example I

Thickness of original stack	0.76 mm
C.P. engraved on crown wheel + 0.05	- 0.05
Measurement obtained	71 mm
C.P. engraved on the new crown wheel + 0.13	+ 0.13
New thickness of pack to be used	0.84 mm

Example 2

Thickness of original stack	0.76 mm
C.P. engraved on crown wheel - 0.05	+ 0.05
Measurement obtained	0.81 mm
C.P. engraved on the new crown wheel + (). 3 + 0. 3
New thickness of stack to be used	0.94 mm
Example 3	
Thickness of original stack	0.76 mm

	0.70 11111
C.P. engraved on crown wheel + 0.05	- 0.05
Measurement obtained	0.71 mm
C.P. engraved on the new crown wheel - 0.13	- 0. 3
New thickness of stack to be used	0.58 mm

Example 4

Thickness of original stack	0.76 mm
C.P. engraved on crown wheel - 0.05	+ 0.05
Measurement obtained	0.81 mm
C.P. engraved on the new crown wheel - 0.13	- 0. 3
New thickness of stack to be used	0.68 mm




The shims to be placed between the differential casing and the bevel pinion support are supplied as spare parts in thicknesses of 0.05 - 0.125 - 0.200 - 0.500 mm.

Every pinion and every crown wheel is marked with the month and year in which they were ground and inspected jointly to form a matched pair.


On the pinions, this information is given at the head end. On the crown wheels, this information is shown on the outside diameter.

All assemblies are engraved with a number which shows the nominal end play between the pinion and crown wheel obtained when machining was finished. This end play is shown on the outside diameter of the crown wheel.

Assembling differential casing



Fit the eight screws (2) complete with washers and tighten them, using torque wrench (1), to the specified torque.




ADJUSTING THE CAP GAP

Adjusting and checking retraction of the caps can be done with two methods:

Ist METHOD


- Use wrench 99355025 (3, Figure 47) to tighten the adjustment lock rings (4) of the bearings until eliminating the pinion-crown wheel clearance and end float. At the same time check that the crown wheel does not force on the pinion;
- using a suitable micrometer positioned diagonally and centrally in points (X-Y-arrows, Figure 46); measure and note the distance of the caps;




3. further tighten the two adjustment lock rings (4, Figure 47) to obtain a retraction of the caps (2, Figure 47), measured on Axis X or on axis Y as described in point "2" of: 0.080 to 0.22 mm which corresponds to a preload on the bearings of 1.7 to 3.9 Nm (0.17 to 0.39 kgm).

2nd METHOD

 A. Diagonally and centrally on the outer machined seats of both caps (2, Figure 47) position two dial gauges (1) with magnetic base as shown in Figure 47;




- B. proceed as described in point "I";
- C. after eliminating the end float further tighten the two adjustment lock rings (4, Figure 47) to obtain a retraction of the caps (2) of 0.080 to 0.22 mm, which corresponds to the sum of the readings on the dial gauges (1).





Adjust the axial clearance between the teeth of the pinion - crown wheel unit which must be 0.21 to 0.45 mm proceeding as follows:


- stop the bevel pinion from turning using tool 99370317;
- position the magnetic-based dial gauge (1) as illustrated;
- □ using wrench 99355025 (3) slacken the adjustment lock ring on the crown wheel side and tighten, to the same extent, the adjustment lock ring (2) of the opposite side. The purpose of this is to leave the previously-adjusted cap retraction unchanged;
- proceed as described until obtaining the specified clearance.


The clearance should be checked on 4 points the same distance apart.











SECTION 7

5206	Front Axles	
		Page
AXLE 5845		3
AXLE 5842	/5 - 5851/5	37
AXLE 587	1/5	67

52(06 Front axle 5845	
		Page
DES	CRIPTION	5
	Characteristic angles	8
SPE	CIFICATIONS AND DATA	10
DIA	GNOSTICS	12
TIG	HTENING TORQUES	15
TO	DLS	16
AXI	E DETACHMENT AND REATTACHMENT	20
	Front axle detachment	20
	Front axle reattachment	21
CH	ECKS ON THE VEHICLE	21
	Tie rods	21
	Articulated joints	21
	Check clearance of articulated joints	21
FRC	NT WHEEL SET UP	22
	Setting of clips and headlights	22
	Electronic compensation for rim maladjustment	23
	Wheel alignment	23
	Toe-in check	24
	Check of wheel inclination (Camber)	24
	Check upright angle of inclination (King Pin) and clearance angle (Caster)	24
	Check steering angles	25
OV	ERHAUL OF THE FRONT AXLE ASSY	26
	ACHMENT AND REATTACHMENT DF WHEEL HUBS	26
	Detachment	26
	Replacement of sealing ring	27
	Replacement of wheel stud bolts	28
	Wheel hub reattachment	28

Page


Check wheel hub end play	29
Rolling torque survey	29
Cross tie rod detachment and reattachment	30
Replacement of cross tie rod articulated pins	30
Cross tie rod lever detachment and reattachment	31
Longitudinal tie rod lever detachment and reattachment	31
Steering knuckle pin detachment and reattachment	31
Detachment	31
Steering knuckle pin bearing replacement	32
Reattachment	32
Check and adjustment of clearance between steering knuckle and axle	33
IECKS AND MEASUREMENTS OF THE AXLE UNIT	34
Check flatness of leaf spring surfaces compared to holes for steering knuckle pins	34
Check hole inclination for steering knuckle pins	35
	Rolling torque survey


DESCRIPTION


Front axle 5845 has a steel structure with a double "T" section having at the end steering knuckles.

The steering knuckles' connection is made through pins integral with the axle body and by means of four roller bearings set with interference in the holes of the steering knuckles' embossing. The wheel hubs are supported by two conical roller bearings, "set right" type, set on the steering knuckle shank. The bearing end

play is predetermined by the spacer placed between them.








Characteristic angles

In order to have a good roadholding, a low tyre wear and to enable driving wheels to recover an upright direction after steering, it is necessary to set the wheels according to certain assembly angles:

- u wheel angle of inclination
- upright angle of inclination
- clearance angle
- 🔲 toe-in

Such angles, when correctly calculated, enable the vehicle to maintain the right balance among the various forces involved in its movement, in different loading conditions, which tend to alter the wheel position on the ground.


Wheel angle of inclination



The wheel angle (α) of inclination is the one resulting from the axis passing through the wheel's centre line and the vertical to the ground, looking at the vehicle standing before it.


The inclination is positive (A) when the wheel's upper part moves outside. It is negative (B) when the wheel's upper part moves inside.

Upright angle of inclination



The upright angle (β) of inclination is the one resulting from the axis passing through the upright and the vertical to the ground, looking at the vehicle standing before it.

When the extension of the upright axis approaches the wheel when it is touching the ground (opposite direction compared to the wheel's inclination), the angle is positive. It is difficult, if not impossible, to have a negative upright angle of inclination. The wheel angle (α) of inclination and the upright angle (β) of inclination enable the wheel axis and the upright axis to get closer to the tyre's fulcrum on the ground as much as possible. As a result, it is possible to reduce the tyre wear and to get a low value of the steering torque.




The clearance angle (γ) is the one resulting from the upright axis and the vertical to the ground, looking at the vehicle from one side.

If the extension of the upright axis falls beyond the wheel's fulcrum on the ground in the vehicle's direction, as a rule the clearance angle is positive (A).

It is considered negative (B) if it falls behind the wheel's fulcrum on the ground.

It is null if it is absolutely perpendicular to the wheel's fulcrum on the ground.


Such an angle enables front wheels to keep an upright position when the vehicle is moving in an upright direction and to recover such a position after taking a curve as soon as the steering wheel is released by the driver.





Toe-in results from the difference between distance A and B (value expressed in mm) measured on the rims' horizontal axis, looking at the vehicle from above.


In this way it is possible to drive easily and to reduce the tyre wear.

Toe-in is positive if B is bigger than A.











Print 603.93.111

SPECIFICATIONS AND DATA

	Axle type	5845	
	STEERING KNUCKLE PINS		
	Inclination of steering knuckle pin housing	7°	
	Diameter of roller bearing housing on steering knuckle: - upper housing Ø I m - lower housing Ø 2 m		
	Outside diameter of roller bearings for steering knuckle: - upper bearings Ø3 m - lower bearings Ø4 m	47	
L S⊐	Upper bearings – steering knuckle m	0.012 ÷ 0.0028	
d P	Lower bearings - steering knuckle m	n 0.012 ÷ 0.0028	
	Inside diameter of roller bearings for steering knuckle: - upper bearings Ø 5 m - lower bearings Ø 6 m		
	Diameter of pin for steering knuckle - upper Ø 7 m - lower Ø 8 m		
	Upper bearings – pin m	n 0.025 ÷ 0.066	
	Lower bearings – pin m	n 0.025 ÷ 0.066	

			5845
XI	Clearance between axle and steering knuckle upper adjustment XI	mm	0.10 ÷ 0.35
X 2	Gap between axle and steering knuckle lower adjustment X2	mm	≥ 0.25
s	Adjusting plates XI, X2		
	0.25 mm S	mm	0.50 ÷ 1.75
	WHEEL HUBS		
	Wheel hub bearings		2 with taper rollers
	Hub bearing end play	mm	max 0.16
	Wheel hub clearance		not adjustable locking with lock nut torque
	Bearing preloading		daNm 0.30
	Oil for wheel hub bearings		Tutela W 140/M-DA
	WHEEL SET UP		
	Wheel inclination (vehicle with static load)		١°
	Wheel incidence (vehicle with static load)		3°
	Toe-in (vehicle with static load)	mm	0.5 ÷ 1.5
B	Steering angle Inside α Outside β		52° 36°





14 FRONT AXLE 5845		Euro
3 NOISE		
Good lubrication of wheel hub bearings.	- NO →	Top up oil in wheel hubs.
YES		
Efficient wheel hub bearings.	- NO ->	Replace worn bearings and adjust e
YES		
Regular coupling between steering knuckle pin and roller bearings.	- NO ->	Check and replace worn elements.
	_	

TIGHTENING TORQUES

Figure			
1 2 3 4 5 6			
PART	-	TOR	QUE
			<i></i>
		Nm	(kgm)
	t head cap screw to clamp upper cover	16 ± 2	(1.6 ± 0.2)
2 Selt	f-braking hexagonal head cap screw to clamp cross lever on steering knuckle	6 ± 2 5 5.5 ± 24.5	(1.6 ± 0.2) (52.5 ± 2.5)
2 Selt 3 Selt	If-braking hexagonal head cap screw to clamp cross lever on steering knuckle If-braking hexagonal head cap screw to clamp longitudinal lever on steering knuckle	16 ± 2 515.5 ± 24.5 515.5 ± 24.5	(1.6 ± 0.2) (52.5 ± 2.5) (52.5 ± 2.5)
 Seli Seli Seli Nu 	If-braking hexagonal head cap screw to clamp cross lever on steering knuckle If-braking hexagonal head cap screw to clamp longitudinal lever on steering knuckle It to clamp stop block for cross tie rod	16 ± 2 515.5 ± 24.5 515.5 ± 24.5 80 ± 10	(1.6 ± 0.2) (52.5 ± 2.5) (52.5 ± 2.5) (8.1 ± 1)
2 Sel: 3 Sel: 4 Nu 5 Cas	If-braking hexagonal head cap screw to clamp cross lever on steering knuckle If-braking hexagonal head cap screw to clamp longitudinal lever on steering knuckle at to clamp stop block for cross tie rod Istellated nut for steering knuckle pin	16 ± 2 515.5 ± 24.5 515.5 ± 24.5 80 ± 10 201 ± 20	(1.6 ± 0.2) (52.5 ± 2.5) (52.5 ± 2.5) (8.1 ± 1) (20.5 ± 2)
 Selit Selit Selit Nu Cast Flar 	If-braking hexagonal head cap screw to clamp cross lever on steering knuckle If-braking hexagonal head cap screw to clamp longitudinal lever on steering knuckle at to clamp stop block for cross tie rod istellated nut for steering knuckle pin nged hexagonal head cap screw to clamp lower thrust block cover on steering knuckle	16 ± 2 515.5 ± 24.5 515.5 ± 24.5 80 ± 10 201 ± 20 336 ± 17	(1.6 ± 0.2) (52.5 ± 2.5) (52.5 ± 2.5) (8.1 ± 1) (20.5 ± 2) (34.2 ± 1.7)
 Seli Seli Seli Nu Cas Flar Wh 	If-braking hexagonal head cap screw to clamp cross lever on steering knuckle If-braking hexagonal head cap screw to clamp longitudinal lever on steering knuckle at to clamp stop block for cross tie rod istellated nut for steering knuckle pin nged hexagonal head cap screw to clamp lower thrust block cover on steering knuckle heel lock nut	16 ± 2 515.5 ± 24.5 515.5 ± 24.5 80 ± 10 201 ± 20 336 ± 17 490 ± 50	(1.6 ± 0.2) (52.5 ± 2.5) (52.5 ± 2.5) (8.1 ± 1) (20.5 ± 2) (34.2 ± 1.7) (49.9 ± 5)
 Seli Seli Seli Nu Case Flar Flar Whether the selection of the selection	If-braking hexagonal head cap screw to clamp cross lever on steering knuckle If-braking hexagonal head cap screw to clamp longitudinal lever on steering knuckle at to clamp stop block for cross tie rod istellated nut for steering knuckle pin nged hexagonal head cap screw to clamp lower thrust block cover on steering knuckle heel lock nut onical threaded cap for wheel hub cover	16 ± 2 515.5 ± 24.5 80 ± 10 201 ± 20 336 ± 17 490 ± 50 57.5 ± 2.5	(1.6 ± 0.2) (52.5 ± 2.5) (52.5 ± 2.5) (8.1 ± 1) (20.5 ± 2) (34.2 ± 1.7) (49.9 ± 5) (5.9 ± 0.25)
 Self Self Self Nut Case Flar Flar Wh Co Wh 	If-braking hexagonal head cap screw to clamp cross lever on steering knuckle If-braking hexagonal head cap screw to clamp longitudinal lever on steering knuckle at to clamp stop block for cross tie rod istellated nut for steering knuckle pin nged hexagonal head cap screw to clamp lower thrust block cover on steering knuckle heel lock nut onical threaded cap for wheel hub cover heel hub cover	16 ± 2 515.5 ± 24.5 80 ± 10 201 ± 20 336 ± 17 490 ± 50 57.5 ± 2.5 106 ± 11	(1.6 ± 0.2) (52.5 ± 2.5) (52.5 ± 2.5) (8.1 ± 1) (20.5 ± 2) (34.2 ± 1.7) (49.9 ± 5) (5.9 ± 0.25) (10.8 ± 1.1)
2 Self 3 Self 4 Nu 5 Case 6 Flar 7 Wh 8 Co 9 Wh 10 Social	If-braking hexagonal head cap screw to clamp cross lever on steering knuckle If-braking hexagonal head cap screw to clamp longitudinal lever on steering knuckle at to clamp stop block for cross tie rod istellated nut for steering knuckle pin inged hexagonal head cap screw to clamp lower thrust block cover on steering knuckle heel lock nut ponical threaded cap for wheel hub cover theel hub cover cket head cap screw to clamp adjusting stop block on wheel bearings	16 ± 2 515.5 ± 24.5 80 ± 10 201 ± 20 336 ± 17 490 ± 50 57.5 ± 2.5 106 ± 11 27.5 ± 2.5	(1.6 ± 0.2) (52.5 ± 2.5) (52.5 ± 2.5) (8.1 ± 1) (20.5 ± 2) (34.2 ± 1.7) (49.9 ± 5) (5.9 ± 0.25) (10.8 ± 1.1) (2.8 ± 0.25)
2 Self 3 Self 4 Nut 5 Case 6 Flar 7 Wh 8 Coo 9 Wh 10 Soot 11 Me	If-braking hexagonal head cap screw to clamp cross lever on steering knuckle If-braking hexagonal head cap screw to clamp longitudinal lever on steering knuckle at to clamp stop block for cross tie rod istellated nut for steering knuckle pin nged hexagonal head cap screw to clamp lower thrust block cover on steering knuckle heel lock nut onical threaded cap for wheel hub cover heel hub cover cket head cap screw to clamp adjusting stop block on wheel bearings etal ring to clamp wheel bearings	16 ± 2 515.5 ± 24.5 80 ± 10 201 ± 20 336 ± 17 490 ± 50 57.5 ± 2.5 106 ± 11 27.5 ± 2.5 388.5 ± 18.5	(1.6 ± 0.2) (52.5 ± 2.5) (52.5 ± 2.5) (8.1 ± 1) (20.5 ± 2) (34.2 ± 1.7) (49.9 ± 5) (5.9 ± 0.25) (10.8 ± 1.1) (2.8 ± 0.25) (39.6 ± 1.8)
2 Self 3 Self 4 Nut 5 Case 6 Flar 7 WH 8 Coo 9 WH 10 Soci 11 Mei 12 Hei	If-braking hexagonal head cap screw to clamp cross lever on steering knuckle If-braking hexagonal head cap screw to clamp longitudinal lever on steering knuckle at to clamp stop block for cross tie rod istellated nut for steering knuckle pin nged hexagonal head cap screw to clamp lower thrust block cover on steering knuckle heel lock nut onical threaded cap for wheel hub cover heel hub cover cket head cap screw to clamp adjusting stop block on wheel bearings etal ring to clamp wheel bearings exagonal head cap screw to clamp brake disc on wheel hub	16 ± 2 515.5 ± 24.5 80 ± 10 201 ± 20 336 ± 17 490 ± 50 57.5 ± 2.5 106 ± 11 27.5 ± 2.5 388.5 ± 18.5 40 ± 4	(1.6 ± 0.2) (52.5 ± 2.5) (52.5 ± 2.5) (8.1 ± 1) (20.5 ± 2) (34.2 ± 1.7) (49.9 ± 5) (5.9 ± 0.25) (10.8 ± 1.1) (2.8 ± 0.25) (39.6 ± 1.8) (4.1 ± 0.4)
2 Self 3 Self 4 Nu 5 Case 6 Flar 7 Wh 8 Co 9 Wh 10 Soci 11 Me 12 Her 13 Self	If-braking hexagonal head cap screw to clamp cross lever on steering knuckle If-braking hexagonal head cap screw to clamp longitudinal lever on steering knuckle at to clamp stop block for cross tie rod istellated nut for steering knuckle pin nged hexagonal head cap screw to clamp lower thrust block cover on steering knuckle heel lock nut onical threaded cap for wheel hub cover heel hub cover cket head cap screw to clamp adjusting stop block on wheel bearings etal ring to clamp wheel bearings	16 ± 2 515.5 ± 24.5 80 ± 10 201 ± 20 336 ± 17 490 ± 50 57.5 ± 2.5 106 ± 11 27.5 ± 2.5 388.5 ± 18.5	(1.6 ± 0.2) (52.5 ± 2.5) (52.5 ± 2.5) (8.1 ± 1) (20.5 ± 2) (34.2 ± 1.7) (49.9 ± 5) (5.9 ± 0.25) (10.8 ± 1.1) (2.8 ± 0.25) (39.6 ± 1.8)

TOOLS

TOOLS	
TOOL No.	DESIGNATION
99305354	Portable optical equipment for check of wheel attitude
99306004	Mobile hydraulic truck
99321024	Hydraulic truck for wheel detachment and reattachment
99322215	Stand for axle overhaul
99341003	Simple effect puller
99341018	Pair of brackets with hole

TOOLS

TOOL No DESIGNATION 99347047 Tool for steering knuckle pin removal Extractor for track rod head pins 99347068 99355038 Wrench (65 mm) for front wheel hub caps (to be used with 99370317) Handle for interchangeable beaters 99370006 99370007 Handle for interchangeable beaters 99370317 Reaction lever with extension for flange holder

TOOLS		
TOOL No		DESCRIPTION
99370628	A CONTRACT OF A	Support for axle detachment and reattachment
99370712		Rail for wheel hub assembly
99374093		Beater for assembly of bearing outside tracks (91 – 134) (to be used with 99370007)
99374171		Locking ring for assembly of steering knuckle pin gaskets (to be used with 99370007)
99374400		Tool for steering knuckle pin setting
99374457		Locking ring for inside wheel hub gasket setting (to be used with 99370006)


TOOLS

TOOL No.		DESIGNATION
99374527		Beater for disassembly and reassembly of steering knuckle pi bearings (to be used with 99370007)
99389819	Constant of the second	Dynamometric wrench (0 – 10 Nm) with square connection 1/4
99395026		Tool for hub rolling torque check (to be used with dynamometri wrench)

520610 **AXLE DETACHMENT AND REATTACHMENT**

Front axle detachment

Figure 11



60383


Use extractor 99347068 (4) to remove the tie rod steering knuckle (6) of the lever (5).

Disconnect the air delivery pipe (1) from the membrane brake cylinders, the wire of the wheel revolution sensor (3) and the wire (2) of the worn braking washer signaller.

Place under the axle an hydraulic jack fitted with support 99370628.

Unscrew the nuts (8) and remove the brackets (7) connecting the axle spring bands and the supports (10) clamping the stabilizer bar (9), in order not to make it interfere with the following operation.

Lower the hydraulic jack and extract the axle underneath the vehicle.





ations.

Check and adjust front wheel set up. To lock nuts consider the couples contained in the appropriate table on page 13.

CHECKS ON THE VEHICLE

Tie rods

Check that screws and stop block lock nuts of tie rods are not worn and that they are clamped according to the prescribed toraue.

Tie rods must not be damaged or worn as well as the threaded part.


Articulated joints

Clean tie rod articulated joints, both cross and longitudinal. Such an operation must be made with dry towels or cotton wool. Do not use solvents.

Check that the articulated joint's several components are not corroded for more than I mm and, in particular, check the metal sheet cover next to the rolling.

Check the guard:

- it must be clamped to the joint's body and pin through circlips and it must not rotate;
- it must not be worn or damaged;
- press it manually and check if any grease comes out;
- check that the nut and the split pin are not worn.



38654

Place the vehicle on a lift-bridge or a pit and do not lift the wheels.

Use a gauge to measure the distance between the articulated joint's body and its edge making three measurements in the following conditions: dimension X;

straight wheels

turned wheels

- wheels turned on the left
 - dimension X₂;

(completely on the right)


Calculate clearance A according to the following formula: A = B - X

where B is the biggest value resulting from measurements XI and X2.


Such clearance must not be over 2 mm.

If an higher clearance or any other fault are detected during the checks, replace the involved element according to the procedure described in the related chapter.


dimension X1;




Setting of clips and headlights




Place the vehicle with the wheels in upright direction on a flat surface. Lift the vehicle's rear part and place the platforms under the wheels (3). Lower the vehicle, brake the rear wheels and set the hook (1) with the ruler (2).




Lift the vehicle's front part and place the swinging plates (1) under the wheels, clamping them with the appropriate locks (2).



Place on the wheel rim the self-centring clip (2) fitted with the right lock pins (1). Use the handle (3) to clamp the clip on wheel, checking that the wheel itself is well fixed.



Set the detecting system (3) on the clips (1) and clamp it with the screw (2). Repeat the same operations on the other wheel.



Connect detectors' plugs to the transformer and switch it on. Release the detector's lock screw and lift the lens cover. Push the button "off centre" (3) for at least two seconds, five

lines will be displayed on the digital (1) indicator. Slowly rotate the wheel by hand and project the light signal

on the corresponding ruler scale (5). Detect and write down the minimum and maximum excur-


sion of the light signal: e.g. 12 and 8. Calculate the excursion's average value: 12 + 8 = 20 : 2 = 10 and place the wheel according to the calculated average value,

marking the new position. Push again the button "off centre" (3) until the wheel inclination led (2) is switched on and on the digital indicator a fake value is displayed.


Repeat the same operations on the other wheel.

Be careful that the laser ray does not hit people's eyes: it would severely harm their sight.

Lower the vehicle so that the wheels, being in the marked position, touch completely the centre of the swinging plates and release the latter from the related bases by removing the pins (4).




Push the brake pedal and leave it in this position using the appropriate tool (1) set against the seat, thus keeping the vehicle braked during the whole measurement.




Balance detectors (3) by using the spirit level (1) and clamp them in this position by the screw (2).

Move the rulers (4) until they are hit by the light signal released by the detector and write the indicated values.



If the values are different, turn the wheels until the light signal indexes reach two equal values (A) and the exact average value resulting from the two previous detections. In such a way it is possible to obtain a perfect wheel alignment.

Toe-in check




Still having detectors perfectly balanced and the wheels completely aligned, use a lever (1) to move the lens cover. Move the lever (2) and point the light signal index to the ruler's graph scale (3) corresponding to the rim's diameter. Repeat the same operations with the opposite detector and read the toe-in values expressed in millimetres on the graph scales.

The algebraic sum of the two detected values must amount to: 0.5 \div 1.5 mm with static load.

848

Toe-in adjustment is performed by operating on the track rod so that toe-in for each wheel is from 0 to 0.5 mm.

Check of wheel inclination (Camber)




If the front wheels are aligned with the rear ones and the detectors are balanced, push the wheel inclination button (3) and the led (2) will be switched on. The digital indicator (1) will give the value of the angle of inclination which must be 1° .




The wheels' angle of inclination is a fixed value which cannot be adjusted.

Therefore, if a different value is detected, remove and dismantle the axle, make the appropriate investigations and possible replacements.


Check upright angle of inclination (King Pin) and clearance angle (Caster)




Still having the front wheels aligned with the rear ones, loose knurled knobs (2) and set to zero the graduated sector (3) on the swinging plate's index (1).



Turn the wheels inwards by 20° and push twice the upright inclination button (3), the led (2) will be switched on and nine horizontal lines will appear on the digital indicator (1).



Turn the wheels outwards by 20° and push again the upright inclination button (2), the digital indicator (1) will display the value of the upright angle of inclination (King Pin) which must be 7°.




Without moving the wheel, push the clearance angle button (3). The led will be switched on (1) and the digital indicator (2) will display the value of the clearance angle (Caster) which must be 3°.



The upright angle of inclination and the clearance angle are fixed values which cannot be adjusted. Therefore, if different values are detected, remove and dismantle the axle, make the appropriate investigations and possible replacements.


Check steering angles




With the wheels in upright direction, set to zero the graduated sectors (5) on the index (2) of the swinging plates (4). If the steering angles which must be detected are bigger than 30°, it is necessary to use as "0°" reference indexes the 20° sign (1) placed on the swinging plate and the corresponding one on the graduated sector.

Turn the inside wheel according to the prescribed value and check that the outside wheel's angle corresponds to the prescribed value, considering that to make the survey it is necessary to use as "0°" reference indexes the 20° sign (3) placed on the swinging plate and the corresponding one on the graduated sector.

Repeat the same operations and check steering of the opposite wheel.






Screw tool 99370712 (3) on the steering knuckle pin. Use a suitable rope (1) and a hydraulic hoist to support wheel hub (2) with axle 99341003 (6) and its respective brackets 99341018 and reaction block (7), all of them applied as shown in the figure, then take wheel hub (2) complete with tapered-roller bearing inner race (5) and spacer (4) out of the knuckle pin.

À

Do not lay down the wheel hub on the phonic wheel side, in order not to damage it.

Replacement of sealing ring



60874

Use general tools to remove the sealing ring (3) from the wheel hub (5). Moisten with oil the new sealing ring's inside outline.


Use locking ring 99374457 (2) and handle 99370006 (1) to place the sealing ring (3) on the wheel hub.

Replace the phonic wheel (if present).

Use general tools to remove the phonic wheel (4) from the wheel hub (5).

Before setting the phonic wheel (4), warm it up to 150°C. Once the assembly is completed, check that the "phonic" wheel (4) touches completely the wheel hub.


Check that the maximum orthogonality error of the phonic wheel (4) is not higher than 0.2 mm.



Remove the wheel hub as described in the related chapter. Take off the sealing ring and remove the bearing's inside ring from the wheel hub.

Use the appropriate beater to remove the bearing's outside rings (1 and 2) from the wheel hub.


Check that the bearing's outside ring housings on the wheel hub are not burred as a result of the pull out operation.



33001

Place the outside bearings's outside ring (3) and use beater 99374093 (2) and handle 99370007 (1) to make setting.

If present, do not use the phonic wheel as a supporting plane.




Place the stud bolts accurately putting on their heads a load not higher than 2300 kg.



Once the operation is completed, check the lack of clearance between the disc plane and the area under the stud bolt head and verify that the orthogonality error is not higher than 0.3 mm.


Wheel hub reattachment



Screw tool 99370712 (3) on the steering knuckle pin and lubricate its outside surface using oil TUTELA W 140/M-DA. Secure the wheel hub (2) with a rope (1) and support it with a lifter. Lock carefully the wheel hub (2) on the steering knuckle pin in order not to damage the sealing ring (3, Figure 35).


Mount spacer (4) and tapered-roller bearing inner race (5). Release tool 99370712 (3).

Force-fit washer (6) and screw down retaining ring (7).



Tighten ring (7, Figure 40) to the specified torque by means of wrench 99355038 (1).

burred.




Set the gauge to zero with a preload corresponding to 1.5 \div 2 mm.

Move the wheel hub in axial direction by means of a lever and detect the end play which must be 0.16 mm (maximum value).

If the detected value does not correspond to the prescribed one, replace the bearing unit and make a new survey.

Rolling torque survey




Apply tool (1) 99395026 on wheel hub stud bolts and use torque meter 99389819 (2) to check whether the wheel hub rolling torque is at the set value.




Deposit a sealing bead (Loctite type 574) exclusively on the hub cover ledge surface and protect the threaded part.

Tighten to torque the hub cover (3).




77203

Rotate the wheel hub until when hub cover (1) is positioned as shown in the figure. Restore the prescribed quantity of oil into the hub cover (1) through filling hole (2). Tighten the plug on the hub cover (1) to the set torque.




Reattach the brake callipers (1) to the flange (3) and lock the screws (2) according to the prescribed torque. Set braking gaskets following the procedure described in chapter "Wheel hub overhaul" Rear axle section.





Straighten and take off the split pin (1). Unlock the nut (2) and release it partially in order to prevent the tie rod (3) from falling when it is removed.



order.


To reattach reverse the detachment operation

Clamp the castellated lock nuts of the articulated pins according to the prescribed torque.



Check that the nut grooves match with the cross holes on the articulated pins. If it is not possible to introduce the split pins, gradually raise the nut tightening torque until the split pins are completely put in place (angle lower than 60°).

520636 **Replacement of cross tie rod** articulated pins




Block the screw (4), release the nut (3) and unscrew the articulated pin (2) from the cross tie rod (1).




Write down the number of turns needed to release every articulated pin in order to screw the new ones making the same number of turns.

Screw the articulated pin (2) in the tie rod (1). The nut (3) must be clamped according to the prescribed torque, after making toe-in adjustment as described in the "Wheel set up" chapter.



Loose the screws (2) and remove the lever (3) from the articulated pin (1). To make reattachment reverse the operation order and clamp the lock screws (2) according to the prescribed torque.


520632 Longitudinal tie rod lever detachment and reattachment




Loose the screws (1) and remove the lever (2) from the articulated pin (3). To make reattachment reverse the operation order and clamp the lock screws (1) according to the prescribed torque.


520611 Steering knuckle pin detachment and reattachment









Loose the screws (1) and remove the upper cover (2) together with the lubricator (3).



Release the screws (5) and remove the cover (3) together with the thrust block (2), the adjusting plate (1) and the lubricator (4).




Use tool 99347047 (1) and element (2) to unfasten the steering knuckle (4) articulated pin (3). Remove the tool, take off the pin (3) and remove the articulated joint (4) from the axle.




Steering knuckle bearing replacement (5) is made using for their disassembly and assembly beater's elements (1-2-3) 99374527 and handle 99370007 (4).

Use element (1) and handle (4) to disassemble the sealing ring (8) and the roller bearings (6-7) on the upper side.

Use element (3) and handle (4) to disassemble the sealing ring (9) and the roller bearings (10-11) on the lower side.




use element (1 and 2) and handle (4). Roller bearing assembly (6): use element (2) and handle (4). Roller bearing assembly (8): use elements (3 and 2) and handle (4). Roller bearing assembly (9): use element (2) and handle (4).



Use beater 99374171 (4) and handle 99370007 (3) to place sealing rings (2 and 5) in the steering knuckle (1).

Reattachment




Set on the axle (2) the steering knuckle (3) and place the articulated pin (1).


Set tool 99374400 (4) on the steering knuckle (3) and fasten it by using the same lower cover lock screws (5), clamping them with the right torque.

Place the pin (1) in the axle conical housing, screwing the pressure screw (6) with a torque having $10 \div 11$ daNm. Remove tool 99374400 (4) from the steering knuckle (3).


Before placing the pin (1), it is necessary to check that the conical housing on the axle and the pin surface are perfectly cleaned and dry, in order to avoid oil layers which could foster the pin rotation in its place during its introduction.



Check and adjustment of clearance between steering knuckle and axle



Keep the steering knuckle (3) raised and use a thickness gauge (1) to check clearance between the upper shim adjustment of the steering knuckle and the axle (2). This value must be between 0.10 and 0.35 mm.



Once the clearance between the upper shim adjustment of the steering knuckle (1) and the axle (3) has been checked, use a thickness gauge (2) to check that between the lower shim adjustment of the steering knuckle (1) and the axle's (3) one there is a gap not lower than 0.25 mm.




The possible clearance adjustment can be done replacing the adjusting shims (1, Figure 60) with spare ones having the right thickness.



As to the thickness of spare rings, see table "SPEC-IFICATIONS AND DATA".



Lubricate the whole lower and upper articulated joint with grease MR2, checking that the grease flows through the gasket baffle.




Place the brake callipers support (1) on the steering knuckle (3) and clamp lock screws (2) according to the prescribed torque.

Complete wheel hub assembly as described on page 27.


520618 CHECKS AND MEASUREMENTS OF THE AXLE UNIT

Check flatness of leaf spring surfaces compared to holes for steering knuckle pins.



Place two bars (1) fitted with cones (3) in the steering knuckle pin holes. Push the cones and clamp them placing the appropriate screws on the bars.

Introduce two centring dowels (2) in the leaf spring supporting plane (4).




Place on the planes (6) two bases (5) using goniometers and introduce them in the centring dowels.



Before placing the bases with the goniometers, check that the supporting planes are not painted or irregular.

Place the sliding bar (2) on the goniometer's bars (4), adjusting its length so that the shaped edges touch the bars (1).

Clamp the screws of the stop block (7) and the goniometer's lock screws (3) to the bars (4).



		Page
DES	SCRIPTION	3
	Characteristic angles	4
SPE	CIFICATIONS AND DATA	4
DIA	GNOSTICS	4
TIG	HTENING TORQUES	4
ТО	OLS	4
FRC	DNT WHEEL SET UP	5
	Setting of clips and headlights	5
	Electronic compensation for rim maladjustment	5
	Wheel alignment	5
	Toe-in check	5
	Check of wheel inclination (Camber)	5
	Check upright angle of inclination (King Pin) and clearance angle (Caster)	Ę
	Check steering angles	5
OV	ERHAUL OF THE FRONT AXLE ASSY	5
	Removal and refitting of wheel hubs	
	Sealing ring replacement	5
	Wheel hubs refitting	5
	End play adjustment of wheel hub bearings	5
	Rolling torque survey	5
REF	PLACEMENT OF WHEEL HUB BEARINGS	5
	PLACEMENT OF STUD BOLTS FOR WHEEL CLAMPING	e
CRO	DSS TIE ROD REMOVAL AND REFITTING	6
	PLACEMENT OF CROSS TIE ROD ARTICULATED JOINTS	6
	DSS TIE ROD LEVER REMOVAL AND REFITTING	6

	Page			
LONGITUDINAL TIE ROD LEVER REMOVAL AND REFITTING				
STEERING KNUCKLE PIN REMOVAL AND REFITTING				
Removal	61			
Refitting	62			
Check and adjustment of clearance between steering knuckle and axle	63			
ERING KNUCKLE PIN BEARING REPLACEMENT	64			
ECKS AND MEASUREMENTS OF THE AXLE UNIT	65			
Check flatness of leaf spring surfaces compared to holes for steering knuckle pins .	65			
Check hole inclination for steering knuckle pins	66			


DESCRIPTION

The front axle has a steel structure with a double "T" section having at the end steering knuckles.

The steering knuckles' connection is made through pins integral with the axle body and by means of four roller bearings set with interference in the holes of the steering knuckles' embossing.


The wheel hubs are supported by two conical roller bearings set on the steering knuckle shank and adjustable by a threaded ring.

Figure I



SECTION OF FRONT AXLE 5842/5 (F 5021) WHEEL SIDE

73841



Characteristic angles


In order to have a good roadholding, a low tyre wear and to enable driving wheels to recover an upright direction after steering, it is necessary to set the wheels according to certain assembly angles:

- u wheel angle of inclination
- upright angle of inclination
- clearance angle
- 🗋 toe-in

Such angles, when correctly calculated, enable the vehicle to maintain the right balance among the various forces involved in its movement, in different loading conditions, which tend to alter the wheel position on the ground.


Wheel angle of inclination

Figure 3



The wheel angle (α) of inclination is the one resulting from the axis passing through the wheel's centre line and the vertical to the ground, looking at the vehicle standing before it.

The inclination is positive (A) when the wheel's upper part moves outside. It is negative (B) when the wheel's upper part moves inside.




The upright angle (β) of inclination is the one resulting from the axis passing through the upright and the vertical to the ground, looking at the vehicle standing before it.

When the extension of the upright axis approaches the wheel when it is touching the ground (opposite direction compared to the wheel's inclination), the angle is positive. It is difficult, if not impossible, to have a negative upright angle of inclination.

The wheel angle (α) of inclination and the upright angle (β) of inclination enable the wheel axis and the upright axis to get closer to the tyre's fulcrum on the ground as much as possible.

As a result, it is possible to reduce the tyre wear and to get a low value of the steering torque.


Clearance angle



The clearance angle (γ) is the one resulting from the upright axis and the vertical to the ground, looking at the vehicle from one side.

If the extension of the upright axis falls beyond the wheel's fulcrum on the ground in the vehicle's direction, as a rule the clearance angle is positive (A). It is considered negative (B) if it falls behind the wheel's fulcrum on the ground. It is null if it is absolutely perpendicular to the wheel's fulcrum on the ground.


Such an angle enables front wheels to keep an upright position when the vehicle is moving in an upright direction and to recover such a position after taking a curve as soon as the steering wheel is released by the driver.




Toe-in results from the difference between distance A and B (value expressed in mm) measured on the rims' horizontal axis, looking at the vehicle from above.

In this way $\bar{\text{it}}$ is possible to drive easily and to reduce the tyre wear.

Toe-in is positive if B is bigger than A.



Toe-in is negative if B is lower than A.





Toe-in is zero if B corresponds to A.


SPECIFICATIONS AND DATA

	Axle type	5842/5 (F 502	I) 5851/5 (F 5521)
	STEERING KNUCKLE PINS		
α	Inclination of steering knuckle pin housing		7° ± 3'
	Diameter of roller bearing housing in steering knuckle: - upper housing Ø 1 - lower housing Ø 2	mm mm	41.972 to 41.988 51.967 to 51.986
Ø3	Outside diameter of roller bear- ings for steering knuckle: - upper bearings Ø 3 - lower bearings Ø 4	mm mm	42 52
	Upper bearings – steering knuckle	mm	0.012 to 0.028
¢	Lower bearings - steering knuckle	mm	0.014 to 0.033
	Inside diameter of roller bearings for steering knuckle: - upper bearings Ø 5 - lower bearings Ø 6	mm mm	35 43
Ø7 1 0 0 8	Diameter of pin for steering knuckle - upper Ø 7 - lower Ø 8	mm mm	34.984 to 35.000 42.984 to 43.000
	Upper bearings – pin	mm	0 to 0.016
	Lower bearings – pin	mm	0 to 0.016

		5842/5 (F 5021)	5821/5 (F 5521)
X1	Clearance between axle and steer- ing knuckle upper adjustment XI	mm	0.10 to 0.35
X2	Gap between axle and steering knuckle lower adjustment X2	mm	≥ 0.25
s	Adjusting plates XI, X2		
	0.25 mm S	mm	0.50 to 1.75
Ē	WHEEL HUBS		
	Wheel hub bearings	2 with	tapered rollers
	Hub bearing end play	mm	max 0.16
	Wheel hub clearance	by mean	s of a metal ring
	Bearing preloading	daN	Jm 0.30
	Oil for wheel hub bearings	Tutela	a W 140/MDA
	Quantity per hub		tres 0.23 kg 0.207
	WHEEL SET UP		
	Wheel inclination (vehicle with static load)		١°
	Wheel incidence (vehicle with static load)		l° 24"
	Toe-in (vehicle with static load)	mm	0.5 to 1.5
	Wheel inclination (vehicle with static load) Wheel incidence (vehicle with static load)	mm	' I°24''







TIGHTENING TORQUES


2			
3	5		
			738
			738
DT		TOR	
RT		TOR	
Self-braking hexagonal head	cap screw to clamp cross tie rod lever on steering knuckle		QUE
Self-braking hexagonal head Castellated nut for articulate	ed joint pin	Nm 515.5 ± 24.5 201 ± 20	QUE (kgm) (52.6 ± 2. (20.5 ± 2
Self-braking hexagonal head Castellated nut for articulate		Nm 515.5 ± 24.5	QUE (kgm) (52.6 ± 2. (20.5 ± 2
Self-braking hexagonal head Castellated nut for articulate Self-braking hexagonal head	ed joint pin	Nm 515.5 ± 24.5 201 ± 20	QUE (kgm) (52.6 ± 2 (20.5 ± 2 (52.6 ± 2
Self-braking hexagonal head Castellated nut for articulate Self-braking hexagonal head Flanged hexagonal head cap	ed joint pin cap screw to clamp longitudinal lever on steering knuckle	Nm 515.5 ± 24.5 201 ± 20 515.5 ± 24.5	QUE (kgm) (52.6 ± 2. (20.5 ± 2 (52.6 ± 2. (34.2 ± 1.
Self-braking hexagonal head Castellated nut for articulate Self-braking hexagonal head Flanged hexagonal head cap Hexagonal head cap screw	ed joint pin cap screw to clamp longitudinal lever on steering knuckle screw to clamp lower thrust block cover on steering knuckle	Nm 515.5 ± 24.5 201 ± 20 515.5 ± 24.5 336 ± 17	QUE (kgm) (52.6 ± 2. (20.5 ± 2) (52.6 ± 2. (34.2 ± 1. (4 ± 0.4)
Self-braking hexagonal head Castellated nut for articulate Self-braking hexagonal head Flanged hexagonal head cap Hexagonal head cap screw	ed joint pin cap screw to clamp longitudinal lever on steering knuckle screw to clamp lower thrust block cover on steering knuckle to clamp brake disc on wheel hub	Nm 515.5 ± 24.5 201 ± 20 515.5 ± 24.5 336 ± 17 40 ± 4	$QUE (kgm) (52.6 \pm 2.) (20.5 \pm 2.) (52.6 \pm 2.) (34.2 \pm 1.) (34.2 \pm 1.) (4 \pm 0.4) (2.8 \pm 0.2) (2.8 \pm 0$
Self-braking hexagonal head Castellated nut for articulate Self-braking hexagonal head Flanged hexagonal head cap Hexagonal head cap screw Socket head cap screw to fa Wheel hub cover	ed joint pin cap screw to clamp longitudinal lever on steering knuckle screw to clamp lower thrust block cover on steering knuckle to clamp brake disc on wheel hub asten wheel bearing adjusting clamp	Nm 515.5 ± 24.5 201 ± 20 515.5 ± 24.5 336 ± 17 40 ± 4 27.5 ± 2.5 133.5 ± 13.5	QUE (kgm) (52.6 ± 2. (20.5 ± 2 (52.6 ± 2. (34.2 ± 1. (4 ± 0.4) (2.8 ± 0.2 (13.6 ± 1.
Self-braking hexagonal head Castellated nut for articulate Self-braking hexagonal head Flanged hexagonal head cap Hexagonal head cap screw Socket head cap screw to fa Wheel hub cover Wheel bearings securing rin	ed joint pin cap screw to clamp longitudinal lever on steering knuckle screw to clamp lower thrust block cover on steering knuckle to clamp brake disc on wheel hub asten wheel bearing adjusting clamp g nut	Nm 515.5 ± 24.5 201 ± 20 515.5 ± 24.5 336 ± 17 40 ± 4 27.5 ± 2.5 133.5 ± 13.5 388.5 ± 18.5	QUE (52.6 ± 2. (20.5 ± 2) (52.6 ± 2. (34.2 ± 1. (4 ± 0.4) (2.8 ± 0.2) (13.6 ± 1. (39.7 ± 1.9)
Self-braking hexagonal head Castellated nut for articulate Self-braking hexagonal head cap Flanged hexagonal head cap Hexagonal head cap screw Socket head cap screw to fa Wheel hub cover Wheel bearings securing rin Tapered threaded plug for v	ed joint pin cap screw to clamp longitudinal lever on steering knuckle screw to clamp lower thrust block cover on steering knuckle to clamp brake disc on wheel hub asten wheel bearing adjusting clamp g nut wheel hub cover	Nm 515.5 ± 24.5 201 ± 20 515.5 ± 24.5 336 ± 17 40 ± 4 27.5 ± 2.5 133.5 ± 13.5 388.5 ± 18.5 27 ± 2	QUE (52.6 \pm 2 (20.5 \pm 2 (52.6 \pm 2 (34.2 \pm 1 (4 \pm 0.4) (2.8 \pm 0.2) (13.6 \pm 1 (39.7 \pm 1 (27.5 \pm 2
Self-braking hexagonal head Castellated nut for articulate Self-braking hexagonal head Flanged hexagonal head cap Hexagonal head cap screw Socket head cap screw to fa Wheel hub cover Wheel bearings securing rin Tapered threaded plug for v	ed joint pin cap screw to clamp longitudinal lever on steering knuckle screw to clamp lower thrust block cover on steering knuckle to clamp brake disc on wheel hub asten wheel bearing adjusting clamp g nut wheel hub cover Axle 5842/5 (vehicles 130)	Nm 515.5 ± 24.5 201 ± 20 515.5 ± 24.5 336 ± 17 40 ± 4 27.5 ± 2.5 133.5 ± 13.5 388.5 ± 18.5 27 ± 2 490 ± 50	QUE (kgm) (52.6 ± 2 (20.5 ± 2 (34.2 ± 1 (4 ± 0.4) (2.8 ± 0.2 (13.6 ± 1 (39.7 ± 1 (27.5 ± 2 (49.9 ± 5
Castellated nut for articulate Self-braking hexagonal head Flanged hexagonal head cap Hexagonal head cap screw Socket head cap screw to fa Wheel hub cover Wheel bearings securing rin Tapered threaded plug for v Wheel lock nuts	ed joint pin cap screw to clamp longitudinal lever on steering knuckle screw to clamp lower thrust block cover on steering knuckle to clamp brake disc on wheel hub asten wheel bearing adjusting clamp g nut wheel hub cover	Nm 515.5 ± 24.5 201 ± 20 515.5 ± 24.5 336 ± 17 40 ± 4 27.5 ± 2.5 133.5 ± 13.5 388.5 ± 18.5 27 ± 2	QUE (52.6 \pm 2 (20.5 \pm 2 (52.6 \pm 2 (34.2 \pm 1 (4 \pm 0.4) (2.8 \pm 0.2) (13.6 \pm 1 (39.7 \pm 1 (27.5 \pm 2


TOOLS	
TOOL No.	DESIGNATION
99305354	Portable optical equipment to check wheel attitude
99321024	Hydraulic truck for wheel detachment and reattachment
99322215	Stand for axle overhaul
99347047	Tool for steering knuckle pin removal
99347068	Extractor for track rod head pins
99354207	Wrench (94.5 mm) for wheel hub cups

TOOL No. DESIGNATION 99355038 Wrench (65 mm) for wheel hub bearing adjusting nut. (to be used with 99370317) 99370007 Handle for interchangeable beaters 99370317 Reaction lever with extension for flange holder 99370628 Support for axle detachment and reattachment 99370714 Rail for wheel hub assembly	TOOLS		
99370007 Handle for interchangeable beaters 99370317 Reaction lever with extension for flange holder 99370628 Support for axle detachment and reattachment	TOOL No.		DESIGNATION
99370317 Reaction lever with extension for flange holder 99370628 Support for axle detachment and reattachment	99355038		Wrench (65 mm) for wheel hub bearing adjusting nut (to be used with 99370317)
99370628 Support for axle detachment and reattachment	99370007		Handle for interchangeable beaters
Bail for wheel hub assembly	99370317		Reaction lever with extension for flange holder
99370714 Rail for wheel hub assembly	99370628	A A A A A A A A A A A A A A A A A A A	Support for axle detachment and reattachment
	99370714		Rail for wheel hub assembly
99374093 Beater for assembling external bearing race (91-134) use w 99370007	99374093		Beater for assembling external bearing race (91-134) use with 99370007


	DESIGNATION
	Locking ring for assembly of upper steering knuckle pin gasket (to be used with 99370007)
	Locking ring for assembly of lower steering knuckle pin gasket (to be used with 99370007)
	Locking ring for assembly of inside wheel hub gasket
	Tool for steering knuckle pin setting
	Beater for disassembly and reassembly of steering knuckle pir bearings (to be used with 99370007)
Constant of the second se	Dynamometric wrench (0 to 10 Nm) with square 1/4'' connec- tion

TOOLS TOOL No. DESIGNATION 6 Tool for hub rolling torque check (to be used with dynamometric 99395026 wrench)







Lift the vehicle's front part and place the swinging plates (1) under the wheels, clamping them with the appropriate locks



Place on the wheel rim the self-centring clip (2) fitted with the right lock pins (1). Use the handle (3) to clamp the clip on wheel, checking that the wheel itself is well fixed.



Set the detecting system (3) on the clips (1) and clamp it with the screw (2). Repeat the same operations on the other



Connect detectors' plugs to the transformer and switch it on. Release the detector's lock screw and lift the lens cover. Push the button "off centre" (3) for at least two seconds, five lines will be displayed on the digital (1) indicator.

Slowly rotate the wheel by hand and project the light signal on the corresponding ruler scale (5).

Detect and write down the minimum and maximum excursion of the light signal: e.g. 12 and 8.

Calculate the excursion's average value: 12 + 8 = 20 : 2 = 10and place the wheel according to the calculated average value, marking the new position.


Push again the button "off centre" (3) until the wheel inclination led (2) is switched on and on the digital indicator a fake value is displayed.

Repeat the same operations on the other wheel.




Be careful that the laser ray does not hit people's eyes: it would severely harm their sight.

Lower the vehicle so that the wheels, being in the marked position, touch completely the centre of the swinging plates and release the latter from the related bases by removing the pins (4).




Push the brake pedal and leave it in this position using the appropriate tool (1) set against the seat, thus keeping the vehicle braked during the whole measurement.




Balance detectors (3) by using the spirit level (1) and clamp them in this position by the screw (2).

Move the rulers (4) until they are hit by the light signal released by the detector and write the indicated values.



If the values are different, turn the wheels until the light signal indexes reach two equal values (A) and the exact average value resulting from the two previous detections. In such a way it is possible to obtain a perfect wheel alignment.






tectors are balanced, push the wheel inclination button (3) and the led (2) will be switched on. The digital indicator (1) will give the value of the angle of inclination which must be 1°.




The wheels' angle of inclination is a fixed value which cannot be adjusted.

Therefore, if a different value is detected, remove and dismantle the axle, make the appropriate investigations and possible replacements.


Check upright angle of inclination (King Pin) and clearance angle (Caster)




Still having the front wheels aligned with the rear ones, loose knurled knobs (2) and set to zero the graduated sector (3) on the swinging plate's index (1).



Turn the wheels inwards by 20° and push twice the upright inclination button (3), the led (2) will be switched on and nine horizontal lines will appear on the digital indicator (1).




Turn the wheels outwards by 20° and push again the upright inclination button (2), the digital indicator (1) will display the value of the upright angle of inclination (King Pin) which must be 7°.





The upright angle of inclination and the clearance angle are fixed values which cannot be adjusted. Therefore, if different values are detected, remove and dismantle the axle, make the appropriate investigations and possible replacements.

Check steering angles




With the wheels in upright direction, set to zero the graduated sectors (5) on the index (2) of the swinging plates (4).


If the steering angles which must be detected are bigger than 30°, it is necessary to use as "0°" reference indexes the 20° sign (1) placed on the swinging plate and the corresponding one on the graduated sector.


Turn the inside wheel according to the prescribed value and check that the outside wheel's angle corresponds to the prescribed value, considering that to make the survey it is necessary to use as "0" reference indexes the 20° sign (3) placed on the swinging plate and the corresponding one on the graduated sector.

Repeat the same operations and check steering of the opposite wheel.




Rotate wheel hub in order to set the screw plug (1) down; unscrew plug and drain oil into a special container. Take off the brake calipers.






Loosen screw (1), unscrew adjusting ring (2) by means of wrench 99355038 (4), take out washer (3), the tapered-roller bearing and the spacer, then take off the wheel hub in the proper way.



With generic tools, extract sealing ring (3). Moisten the edges with oil.

With keyer 99374233 (2) and handle (1), assemble the sealing ring into its own wheel hub seat.


Wheel hubs refitting



Screw on the steering knuckle pin the tool 99370714 (3) and lubricate its outside surface using oil TUTELA W 140/M-DA. Secure with a rope (1) the wheel hub (2) and support it with the lifter. Key the wheel hub (2) carefully on the steering knuckle pin in order not to damage the sealing ring. Mount spacer (4) and tapered-roller bearing (5). Release tool 99370714 (3).

Key the washer (6) and screw the check ring (7) with the requested torque.

End play adjustment of wheel hub bearings




Hit the wheel hub in axial direction with a mallet and rotate it in both directions in order to release the bearings' rolls. Set the magnetic base (1) fitted with a gauge (2) on the wheel hub.

Place the gauge pointer (3) perpendicular to the steering knuckle shank (4).

Set the gauge to zero with a preload corresponding to 1.52 $\,$ mm.


Move the wheel hub in axial direction by means of a lever and detect the end play which must be 0.16 mm (maximum value).

If the detected value does not correspond to the prescribed one, replace the bearing unit and make a new survey.



Once the requested end play has been reached, clamp the adjusting ring (2) check screw (1) with the requested torque.

Rolling torque survey



34541

Place tool (1) 99395026 on the wheel hub stud bolts and use dynamometer 99389819 (2) to check that the wheel hub rolling torque is 3.0 Nm.





Place some sealer (Loctite type 574) only on the surface touched by the hub cover, protecting the threaded part.



Screw the hub cover with the requested torque.

Reset hubs in the wheels and the prescribed (0.2 litres) quantity of oil (Tutela W 140/MDA).





Use general tools to pull out stud bolts (1) from the brake disc (2).

Check that the head supporting plane of the stud bolts is not burred.

Place the stud bolts accurately and put on their head a load not higher than:


2300 kg for axle 5842/5




2500 kg for axle 5851/5

Once the operation is completed, check that there is no clearance between the disc plan and the area below the stud bolt head. Check also that the orthogonality error is not higher than 0.3 mm.

520635 CROSS TIE ROD REMOVAL AND REFITTING



Straighten and take off the split pin (1). Unlock the nut (2) and release it partially in order to prevent the tie rod from falling when it is removed.



Use extractor (1) 99347068 to unlock the steering head (3) from the lever (2). Repeat the same operations on the opposite side, release the nuts completely and remove the cross tie rod.




To reattach reverse the detachment operation order.




Clamp the conical pin castellated lock nuts with the requested torque.



Check that the nut grooves match with the cross holes on the conical pins. If it is not possible to introduce the split pins, gradually raise the nut tightening torque until the split pins are completely put in place (angle lower than 60°).



520632 LONGITUDINAL TIE ROD LEVER REMOVAL AND REFITTING




34544

Release the screws (2) and remove the lever (1). To make reattachment reverse the operation order and clamp the screws with the requested torque.


520611 STEERING KNUCKLE PIN REMOVAL AND REFITTING






Release the screws (2) and remove the brake callipers support (1).

screws with the requested torque.





Set on the axle body the steering knuckle and put the pin in its place.

Set tool 99374400 (1) on the steering knuckle and fasten it by using the same lower cover lock screws, clamping them with the right torque.

Place the pin in the axle conical housing, screwing the pressure screw (2) to a torque having 7 to 8 daNm.


Remove tool 99374400 from the steering knuckle.

Â

Before placing the pin, it is necessary to check that the conical housing on the axle and the pin surface are perfectly cleaned and dry, in order to avoid oil layers which could foster the pin rotation in its place during its introduction.


Before making assembly, moisten the thrust block of the lower cover using grease Tutela MR2.

Figure 47



Place the lower cover (2) together with the thrust block (1) and the adjusting shims; fasten the lock screws (3) with the requested torque.


Repeat the same operations on the opposite steering knuckle.




Place the upper cover (2) together with the related seal; place the lubricator as shown in the figure, then introduce the safety ring (1) and check that the ring expansion is made in the correct way.

Check and adjustment of clearance between steering knuckle and axle

Figure 49



Keep the steering knuckle raised and use a thickness gauge (1) to check clearance between the upper shim adjustment of the steering knuckle and the axle. This value must be between $0.10 \div 0.15$ mm.



Once the clearance between the upper shim adjustment of the steering knuckle and the axle has been checked, use a thickness gauge (1) to check that between the lower shim adjustment of the steering knuckle and the axle's one there is a gap not lower than 0.25 mm.




The possible clearance adjustment can be done replacing the adjusting shims with spare ones having the right thickness.



As to the thickness of spare rings, see table "SPEC-IFICATIONS AND DATA".




Lubricate the whole lower and upper articulated joint with grease MR2, checking that the grease flows through the gasket baffle.




520618 CHECKS AND MEASUREMENTS OF THE AXLE UNIT





Place two bars (1) fitted with cones (3) in the steering knuckle pin holes. Push the cones and clamp them placing the appropriate screws on the bars.

Introduce two centring dowels (2) in the leaf spring supporting plane (4).




Place on the planes (6) two bases (5) using goniometers and introduce them in the centring dowels.




Before placing the bases with the goniometers, check that the supporting planes are not painted or irregular.

Place the sliding bar (2) on the goniometer's bars (4), adjusting its length so that the shaped edges touch the bars (1). Clamp the screw of the stop block (7) and the goniometer's lock screws (3) to the bars (4).



Check the angle of deformation on the goniometers' graduated sector shown by the arrows.

Goniometers' indexes will, of course, detect no angle movement when the flatness of leaf spring surfaces compared to the steering knuckle pin holes is correct. Remove the sliding bar and the goniometer's bases used to make the survey. Check hole inclination for steering knuckle



Check the angle of inclination value concerning the steering knuckle pin holes on the related graduated sectors (2), next

to the gauge (1). The angle of inclination concerning the steering knuckle pin holes must be $7^{\circ} \pm 0^{\circ}3'$.

5206	Front axle 5871/5
------	-------------------

	Page
Description	69
Characteristic angles	71
SPECIFICATIONS AND DATA	73
DIAGNOSTICS	75
TIGHTENING TORQUES	78
TOOLS	79
FRONT WHEEL SET UP	83
Setting of clips and headlights	83
Electronic compensation for rim maladjustment	84
U Wheel alignment	84
Toe-in check	85
Check of wheel inclination (Camber)	85
Check upright angle of inclination (King Pin) and clearance angle (Caster)	85
Check steering angles	86
OVERHAULING THE FRONT AXLE ASSEMBLY (MECHANICAL AND PNEUMATIC SUSPENSION)	87
OVERHAULING THE FRONT AXLE ASSEMBLY	87
Removing the wheel hubs	87
Replacing the wheel hub bearings	87
Replacing seal	88
Replacing wheel studs	88
Refitting wheel hubs	89
Adjusting wheel hub bearing end play	89
Checking the rolling torque	89
REMOVING AND REFITTING TRACK ROD	90
REPLACING TRACK ROD BALL JOINT	90

Page


	1 460
CHECKING BALL JOINT END PLAY FOR TRACK ROD AND DRAG LINK	90
Replacing ball joint	90
REMOVING AND REFITTING TRACK ROD ARMS	91
REMOVING AND REFITTING DRAG LINK ARM	91
REMOVING AND REFITTING THE KINGPIN	91
🔲 Removing	91
🔲 Refitting	92
Checking and adjusting play between stub axle and axle	92
STEERING KNUCKLE PIN BEARING REPLACEMENT	93
CHECKS AND MEASUREMENTS ON AXLE BODY	94
Checking surface flatness of leaf spring seating with respect to holes for kingpins.	94
Checking inclination of holes for kingpins	95

DESCRIPTION


Front axle 5871/5 has a steel structure with a double "T" section having at the end steering knuckles.

The steering knuckles' connection is made through pins integral with the axle body and by means of four roller bearings set with interference in the holes of the steering knuckles' embossing. The wheel hubs are supported by two conical roller bearings, "set right" type, set on the steering knuckle shank. The bearing end


play is predetermined by the spacer placed between them.



71175



32957




The inclination is positive (A) when the wheel's upper part moves outside. It is negative (B) when the wheel's upper part moves inside.

steering wheel is released by the driver.

В


32958




Toe-in results from the difference between distance A and B (value expressed in mm) measured on the rims' horizontal axis, looking at the vehicle from above.

In this way it is possible to drive easily and to reduce the tyre wear.

Toe-in is positive if B is bigger than A.



Toe-in is negative if B is lower than A.





Toe-in is zero if B corresponds to A.


SPECIFICATIONS AND DATA

	Axle type	5871/5
	STEERING KNUCKLE PINS	
	Inclination of steering knuckle pin housing	7°
	Diameter of roller bearing housing on steering knuckle: - upper housing Ø I mm - lower housing Ø 2 mm	
	Outside diameter of roller bearings for steering knuckle: - upper bearings Ø3 mm - lower bearings Ø4 mm	
Ś	Upper bearings – steering knuckle mm	0.014 ÷ 0.033
L S	Lower bearings - steering knuckle mm	0.014 ÷ 0.033
	Inside diameter of roller bearings for steering knuckle: - upper bearings Ø 5 mm - lower bearings Ø 6 mm	50
	Diameter of pin for steering knuckle - upper Ø 7 mm - lower Ø 8 mm	50.001 50
	Upper bearings – pin mm	0 ÷ 0.016
	Lower bearings – pin mm	0 ÷ 0.019


				5871/5
XI	Clearance between axle and steering knuckle upper adjustment	XI	mm	0.10 ÷ 0.35
X 2	Gap between axle and steering knuckle lower adjustment	X2	mm	≥ 0.25
s	Adjusting plates XI, X2			
	0.25 mm	S	mm	0.50 ÷ 1.75
	WHEEL HUBS			
	Wheel hub bearings			2 with taper rollers
	Hub bearing end play		mm	max 0.16
	Wheel hub clearance			not adjustable locking with lock nut torque
	Bearing preloading			daNm 0.50
	Oil for wheel hub bearings Amount per hub	Litres (kg)		Tutela W 140/M-DA 0.35 (0.32)
	WHEEL SET UP			
	Wheel inclination (vehicle with station	t load)		١٥
	Wheel incidence (vehicle with static	load)		۱°, 24''
	Toe-in (vehicle with static load)		mm	0 ÷ 1
β α β β β α β α β α β α β β β β β β β β β β β β β	Steering angle Inside $lpha$ Outside eta			52° 36°







TIGHTENING TORQUES



71195

-[15]

B

13

14


PART		TORQUE	
PAI		Nm	(kgm)
Ι	Oval headed screw for securing upper cover	10.8 ± 2	(± 0.2)
2	Self-braking hexagonal head screw for securing longitudinal levers on stub axle	1325 ± 75	(135 ± 7.5)
3	Self-braking hexagonal head screw for securing transverse tie rod lever on stub axle	1325 ± 75	(135 ± 7.5)
4	Clamp locking nut for transverse tie rod	80 ± 10	(8. ±)
5	Notched nut for ball head pin	201 ± 20	(20.5 ± 2)
6	Screw for securing lower cover on stub axle	7 ± 6	(.9 ± 0.6)
7	Wheel hub cover	33.5 ± 3.5	(13.6 ± 1.3)
8	Cylindrical headed screw with embedded hexagon for locking wheel bearings adjustment clamp	27.5 ± 2.5	(2.8 ± 0.2)
9	Wheel bearings securing ring nut	515.5 ± 24.5	(52.5 ± 2.5)
10	Bevel threaded plug for wheel hub cover	57.5 ± 2.5	(5.9 ± 0.25)
	Hexagonal head screw for securing brake disc to wheel hub	281.5 ± 13.5	(28.6 ± 1.3)
12	Wheel securing nut	627.5 ± 62.5	(63.9 ± 6.4)
13	Self-locking hexagonal head screw for securing brake shoes	615.5 ± 61.5	(62.7 ± 6.2)
4	Screw for securing brake shoes support	313.5 ± 15.5	(31.9 ± 1.5)
15	Steering stop screws	58.5 ± 5.2	(5.9 ± 0.5)


TOOLS TOOL No. DESIGNATION 99305354 Portable optical equipment to check wheel attitude Hydraulic truck for wheel detachment and reattachment 99321024 99322215 Stand for axle overhaul 99347047 Tool for steering knuckle pin removal 99347068 Extractor for track rod head pins Wrench (94.5 mm) for front wheel hub caps 99354207


TOOLS

TOOLS		
TOOL No.		DESIGNATION
99370006	Colleman D	Handle for interchangeable beaters
99370007		Handle for interchangeable beaters
99370317		Reaction lever with extension for flange holder
99370628	A Contraction of the second se	Support for axle detachment and reattachment
99370715		Rail for wheel hub assembly
99374093		Beater for assembly of bearing outside tracks (91 – 134) to be used with 99370007


DESIGNATION
Locking ring for assembly of inside wheel hub gasket (to be used with 99370006)
Locking ring for assembly of lower steering knuckle pin gasket (to be used with 99370007)
Tool for steering knuckle pin setting
Beater for disassembly and reassembly of steering knuckle pin bearings (to be used with 99370007)
Wrench (80 mm) for wheel hub bearing adjusting nut
Wrench for cross and longitudinal tie rod lock screws on steering knuckle









Lift the vehicle's front part and place the swinging plates (1) under the wheels, clamping them with the appropriate locks




Place on the wheel rim the self-centring clip (2) fitted with the right lock pins (1). Use the handle (3) to clamp the clip on wheel, checking that the wheel itself is well fixed.



Set the detecting system (3) on the clips (1) and clamp it with the screw (2). Repeat the same operations on the other




4 32979 Balance detectors (3) by using the spirit level (1) and clamp them in this position by the screw (2). Move the rulers (4) until they are hit by the light signal released by the detector and write the indicated values.




Base - February 2003

vehicle braked during the whole measurement.

13952






If the front wheels are aligned with the rear ones and the detectors are balanced, push the wheel inclination button (3) and the led (2) will be switched on. The digital indicator (1) will give the value of the angle of inclination which must be 1°.




The wheels' angle of inclination is a fixed value which cannot be adjusted.

Therefore, if a different value is detected, remove and dismantle the axle, make the appropriate investigations and possible replacements.


Check upright angle of inclination (King Pin) and clearance angle (Caster)




Still having the front wheels aligned with the rear ones, loose knurled knobs (2) and set to zero the graduated sector (3) on the swinging plate's index (1).



Turn the wheels inwards by 20° and push twice the upright inclination button (3), the led (2) will be switched on and nine horizontal lines will appear on the digital indicator (1).



Turn the wheels outwards by 20° and push again the upright inclination button (2), the digital indicator (1) will display the value of the upright angle of inclination (King Pin) which must be 7°.




Without moving the wheel, push the clearance angle button (3). The led will be switched on (1) and the digital indicator (2) will display the value of the clearance angle (Caster) which must be 2°30'.



The upright angle of inclination and the clearance angle are fixed values which cannot be adjusted. Therefore, if different values are detected, remove and dismantle the axle, make the appropriate investigations and possible replacements. EuroCargo Tector 12-26 t

Check steering angles



With the wheels in upright direction, set to zero the graduated sectors (5) on the index (2) of the swinging plates (4).

If the steering angles which must be detected are bigger than 30°, it is necessary to use as "0°" reference indexes the 20° sign (1) placed on the swinging plate and the corresponding one on the graduated sector.

Turn the inside wheel according to the prescribed value and check that the outside wheel's angle corresponds to the prescribed value, considering that to make the survey it is necessary to use as "0°" reference indexes the 20° sign (3) placed on the swinging plate and the corresponding one on the graduated sector.

Repeat the same operations and check steering of the opposite wheel.


520610 OVERHAULING THE FRONT AXLE ASSEMBLY (Mechanical and pneumatic suspension)

For front axle disconnection and reconnection, refer to the procedure described for 5842 and 5851 front axles.

520610 OVERHAULING THE FRONT AXLE ASSEMBLY


Using lifting gear, position and secure the axle assembly (1) on stand 99322215 (2) for overhaul.


520620 Removing the wheel hubs




Unscrew the plug (I) and drain the oil into a proper container.

Take down the brake calipers.






Loosen the screw (4), remove the adjusting nut (3) with wrench 99388001, pull out the washer (2), the outer bearing (1) and take down the wheel hub with the relactive spacer and inner bearing.




Using suitable tools remove the seal ring (2), inner bearing and phonic wheel (3) from the wheel hub. (1)

520621 Replacing the wheel hub bearings



Mak Whe rem

Make sure that the housings of the outer rings of the wheel hub bearings have not been dented by the removal operation.




Use drift 99374093 (2) to press-fit the outer race of the front hub bearing without pushing fully home. Repeat the operation on the opposite side for the rear bearing outer race.


Complete the operation of press-fitting the outer bearing races manually using drift 99374093 (2) with handle 99370007 (1).

Heat the phonic wheel (1) to a temperature of 150° (3, Figure 28) for 15 minutes, then fit it on the wheel hub (1) and let it cool down.

Replacing seal




Lubricate the inner bearing with SAE W 140M-DA oil and position it in its housing in the wheel hub. Using drift 99374232 (1) and handle 99370006 (2) fit in place the seal ring (3) on the wheel hub checking the assembly position (Figure 32).



ASSEMBLY POSITION OF THE SEAL RING (A) IN THE WHEEL HUB (B)

Cleaning the wheel hub cap. To prevent the polycarbonate transparent part from getting opaque, we advise you to wash it with cleaning products normally used for the body. Never use chlorotene solvents because they etch the polycarbonate.

Replacing wheel studs



Use ordinary tools to remove studs (1) from wheel hub. Check that the stud head mating surface is free of burrs. Press-fit studs carefully by applying a load of not more than 2500 kg to their heads.


Once the operation is complete, check there is no play between the disc surface and stud head undersides.

Refitting wheel hubs



Make sure that the surfaces of all components inside the hub are thoroughly clean and free from scale and burrs.

Install the wheel hub onto the stub axle. Fit the internal spacer onto the stub axle, then position the outer bearing and thrust washer.




Put stylus pointer (3) perpend. to the stub axle (4) spigot. Zero the gauge with a preload of 1.5 to 2 mm. Use a lever to move the wheel hub along the axis and measure the end play which should be 0.16 mm (max. value).



If the end play is not as required, replace the bearing assembly e repeat the adjusting operations.

Once the specified end play is obtained, lock the adjustment nut (4) retaining screw (5) to the specified torque.

Checking the rolling torque



77202

Apply tool (1) 99395026 on wheel hub stud bolts and use torque meter 99389819 (2) to check whether the wheel hub rolling torque is at the set value.




Deposit a sealing bead (Loctite type 574) exclusively on the hub cover ledge surface and protect the threaded part.




Tighten to torque the hub cover (3).

Figure 37



Rotate the wheel hub until when hub cover (1) is positioned as shown in the figure. Restore the prescribed quantity of oil into the hub cover (1) through filling hole (2). Tighten the plug on the hub cover (1) to the set torque.





Tighten the nuts securing the taper pins to the specified torque.



Check the position of the castellations on the nuts which line up with the transverse holes in the taper pins; if the cotter pins will not go in, progressively increase the torque of the nuts until correct insertion is achieved (angle less than 60°).

520636 REPLACING TRACK ROD BALL JOINT

Before replacing swivel head (Figures 40-41) check the axial clearance as described below.

CHECKING BALL JOINT END PLAY FOR TRACK ROD AND DRAG LINK

The vehicle should not be jacked up.

Use a gauge (1, Figure 40) to measure the distance "X" with the vehicle in straight on position.


Take the measurement again with the steering turned as far as possible, to the left (XI) and to the right (X2). Take a note of the values measured.

Calculate the axial clearance ''A'', noting the maximum value measured between X1 and X2.


Example:

 $A = \max(XI, X2)-X$

If the value rises above 2 mm replace the ball joint.



Replacing ball joint



Lock screws (4), loosen nut (3) and unscrew ball joint (2) from track rod (1).

Screw ball joint into rod and lock in position tightening locking nut to the specified torque.




To make it easier to refit the track rod and measure the wheel convergence, note down the number of turns needed to unscrew each ball joint so that the new ones can be screwed in by the same number of turns.


Refit the track rod.




Check and, if necessary, adjust front wheel toe-in as described on "Front wheel set up".




520611 REMOVING AND REFITTING THE KINGPIN



Unscrew screws (1) and remove support (2) from the brake calliper.




Using suitable pliers, remove the retainer circlip (1) and take out the cover (2) complete with grease nipple.




Unscrew screws (4) and remove lower cover (3), adjustment shims (2) and thrust bearing (1).

the specified torque.



(3). Remove the tool and withdraw the pin.






Fit stub axle (1) to axle (4) and insert the pin into its housing. Apply tool 99374405 (2) to the stub axle and secure by means of the lower cover retaining screws. Tighten to a suitable torque.

Press-fit the pin into the taper seating in the axle, tightening pressure screw (3) to a torque of 15 to 16 daNm. Remove tool 99374405 from the stub axle.




Before installing the pin, make sure that the taper seating in the axle and the surface of the pin are completely clean and dry to avoid oil films which would facilitate rotation of the pin in its seating during the installing operation.

Before assembling, lubricate the lower cover thrust bearing with Tutela MR2 grease.




Position lower cover (3) complete with thrust bearing (1) and adjustment shims (2). Tighten screws (4) to the specified torque.

Repeat the same operations for the opposite axle. Figure 50




Insert upper cover (2) complete with seal into its housing; position grease nipple as shown in the figure, then insert retainer circlip (1) making sure that the circlip expands correctly.

Checking and adjusting play between stub axle and axle




Lift the swivel axle to bring it into contact with the lower axle facing. Use feeler gauge (1) to check clearance between upper facing of swivel axle and axle. This should be between 0.10 and 0.35 mm.



520618 CHECKS AND MEASUREMENTS ON AXLE BODY

Checking surface flatness of leaf spring seating with respect to holes for kingpins.


Apply two rods (as shown in Figure 56, ref. 1) complete with cones (3) in the holes for knuckle pins; press the cones and lock them in position on the rods using relevant screws. Insert the two locating dowels (2) into the housings in the leaf spring seating surface.




Apply bases (5, Figure 57) to planes (6) using protractors and fit into centring dowels.



Before fitting the bases with protractors, make sure that the seating faces have no traces of paint or roughness.




Fit sliding bar (2) to protractor rods (4), adjusting the length so that the shaped ends come into contact with rods (1). Lock screw of clamp (7) and screws (3) securing the protractors to the rods (4).



Check the angle of distortion, if any, on the graduated sectors of the protractors shown by the arrows.

Obviously the protractor pointers do not record any angular deviation when the flatness of the leaf spring seating surfaces

is correct with respect to the holes for the kingpins. Remove the sliding bar and the bases with protractors used for the inspection.



SECTIO	N 8	
5004	Suspensions	
		Page
FRONT A SUSPEN	ND REAR MECHANICAL ISIONS	3
FRONT A	ND REAR PNEUMATIC	43

5004 Front and rear mechanical suspensions	
	Page
DESCRIPTION	5
FRONT LEAF SPRINGS	5
PARABOLIC LEAF SPRING SPECIFICATIONS AND DATA	7
FRONT SUSPENSION - MODELS 10EL120EL	7
FRONT SUSPENSION - MODELS 120E130E	8
FRONT SUSPENSION MODELS 120E120ED-130E130ED- 130E18RS-150E150ERS	9
FRONT SUSPENSION MODELS 180E260E	10
SEMI-ELLIPTICAL LEAF SPRING SPECIFICATION	IS
FRONT SUSPENSION - MODELS 120E130E	
FRONT SUSPENSION MODELS 120ED-130ED-150E	12
FRONT SUSPENSION - MODELS 180E	3
FRONT SHOCK ABSORBERS	14
Assembly diagrams	14
	15
REAR LEAF SPRINGS	17
PARABOLIC LEAF SPRING SPECIFICATIONS	19
REAR SUSPENSION MODELS 110EL120EL.	19
REAR SUSPENSION MODELS 120E130E	20
REAR SUSPENSION MODELS 120E130E130E18RS	21
REAR SUSPENSION MODELS 120E120ED-130E130ED- 150E150E18RS	22
REAR SUSPENSION - MODELS 180E	23
SEMI-ELLIPTICAL LEAF SPRING SPECIFICATION	IS 24
REAR SUSPENSION 120E130E	24
REAR SUSPENSION MODELS 120E130ED-150E	25
REAR SUSPENSION 180E	26

Page

	rage
HENDRICKSON REAR SUSPENSION Models 260E	27
Disconnection	
Reconnection	
REAR SHOCK ABSORBERS	
Assembly diagrams	
□ Shock absorber features and data	
Models 260E	31
DIAGNOSTICS	32
	36
FRONT MECHANICAL SUSPENSION REMOVAL-REFITTING	37
Removal	
Refitting	37
REAR MECHANICAL SUSPENSION REMOVAL-REFITTING	38
	38
Refitting	38
FRONT SHOCK ABSORBERS	
Removal	39
Refitting	39
REAR SHOCK ABSORBERS	39
	39
Refitting	39
FRONT SWAY BAR	39
	39
Refitting	39
REAR SWAY BAR	40
Removal	40
Refitting	40
REPAIRS	40
Leaf spring disassembly	40
Checks	40
BUSHING REPLACEMENT	
	41
Refitting	41
Leaf spring assembly	

DESCRIPTION

The suspension consists of leaf springs, two double-acting telescopic shock absorbers and a sway bar.

The leaf springs can be semi-elliptical or parabolic.

Semi-elliptical leaf springs are very stiff because all the leaves have the same thickness, from one end to the other. Furthermore, the leaves are arranged to create high internal friction, whereby limiting the leaf spring movements.


Parabolic leaf springs are made of leaves which are thicker in the middle and narrower at the ends. The distanced arrangement considerably reduces internal friction.


Low internal friction and the special leaf shape makes parabolic leaf springs softer, consequently ensuring greater riding comfort.

Double-acting telescopic shock absorbers counteract wheel movement upwards and downwards, ensuring excellent riding stability.

The sway bar keeps the wheel axle and chassis parallel, cancelling any load imbalance on the wheel on any one axle.

FRONT LEAF SPRINGS





PARABOLIC LEAF SPRING SPECIFICATIONS AND DATA FRONT SUSPENSION - Models 110EL..-120EL..

		mm
	Parabolic leaf springs	Nº 2
	Main leaf and second leaf length (measured at eye centre)	1714 ± 3
S ¥	Leaf thickness (measured in the middle)	26
s ¥	Thickness between leaves	3
	Width of leaves	70 ± 0.5
	NEW SPRING CHECK DATA: Static load deflection Static load flexibility	17 5.691 mm/kN
D A	Main leaf eye internal diameter (bushing housing)	55.5 + 0.1
	D = bushing external diameter	57.3 ^{-0.2} + 0.6
	d = bushing internal diameter	20.2 + 0.3 - 0

FRONT SUSPENSION - Models 120E..-130E..

		mm
	Parabolic leaf springs	Nº 2
	Main leaf and second leaf length (measured at eye centre)	1758 ± 3
S X	Leaf thickness (measured in the middle)	24
s ¥	Thickness between leaves	3
	Width of leaves	80 ± 0.5
	NEW SPRING CHECK DATA: Static load deflection Static load flexibility	6 6.96 mm/kN
D	Main leaf eye internal diameter (bushing housing)	55.5 + 0.1
D 777777 ¥ d	D = bushing external diameter	57.3 ^{+ 0.6} - 0.2
	d = bushing internal diameter	20.2 + 0.3 - 0

FRONT SUSPENSION - Models	120E120ED-130E130ED-130E18RS-15	UE15UERS
		mm
	Parabolic leaf springs	Nº 2
	Main leaf and second leaf length (measured at eye centre)	1758 ± 3
S ¥	Leaf thickness (measured in the middle)	21
s ¥	Thickness between leaves	3
	Width of leaves	80 ± 0.5
	NEW SPRING CHECK DATA: Static load deflection Static load flexibility	15 6,69 mm/kN
Þ Þ	Main leaf eye internal diameter (bushing housing)	55.5 + 0.1
	D = bushing external diameter	57.3 ^{+ 0.6} - 0.2
	d = bushing internal diameter	20.2 + 0.3

FRONT SUSPENSION - Models 120E..-120E..D-130E..-130E..D-130E18RS-150E..-150E..RS

FRONT SUSPENSION - Models 180E..-260E..

		mm
	Parabolic leaf springs	Nº 2
L	Main leaf and second leaf length (measured at eye centre)	1758 ± 3
S X	Leaf thickness I st leaf (measured in the middle) 2 nd - 3 rd - 4 th leaf (measured in the middle)	19 21
s ¥	Thickness between leaves	3
	Width of leaves	80 ± 0.5
	NEW SPRING CHECK DATA: Static load deflection Static load flexibility	2 5.53 mm/kN
D	Main leaf eye internal diameter (bushing housing)	55.5 + 0.1
	D = bushing external diameter	57.3 ^{+ 0.6} - 0.2
	d = bushing internal diameter	20.2 + 0.3

SEMI-ELLIPTICAL LEAF SPRING SPECIFICATIONS AND DATA FRONT SUSPENSION - Models 120E..-130E..


	1	mm
	Semi-elliptical leaf springs	N° 2
L	Main leaf and second leaf length (measured at eye centre)	1758 ± 3
S K	Leaf thickness (measured in the middle)	14
	Width of leaves	80 ± 0.5
	NEW SPRING CHECK DATA: Static load deflection Static load flexibility	12 6.31 mm /kN
P	Main leaf eye internal diameter (bushing housing)	55.5 ^{+0.1} -0
	D = bushing external diameter	57.3 ^{+0.6} -0.2
A	d = bushing internal diameter	20.2 ^{+0.3} -0


FRONT SUSPENSION - Models 120E..D-130E..D-150E..

		mm
	Semi-elliptical leaf springs	Nº 2
	Main leaf and second leaf length (measured at eye centre)	1758 ± 3
S ¥	Leaf thickness (measured in the middle)	13
	Width of leaves	80 ± 0.5
	NEW SPRING CHECK DATA: Static load deflection Static load flexibility	6.5 6.11 mm /kN
↓ ↓ ↓ ↓ ↓	Main leaf eye internal diameter (bushing housing)	55.5 + 0.1
D 272777 ¥ d	D = bushing external diameter	57.3 ^{+0.6} -0.2
A	d = bushing internal diameter	20.2 ^{+0.3} -0

FRONT SUSPENSION - Models 180E..


		mm
	Semi-elliptical leaf springs	Nº 2
	Main leaf and second leaf length (measured at eye centre)	1758 ± 3
S X	Leaf thickness (measured in the middle)	16.5
	Width of leaves	80 ± 0.5
	NEW SPRING CHECK DATA: Free spring pointer Flexibility	35 3.97 mm /kN
↓ ↓ ↓ ↓ ↓ ↓	Main leaf eye internal diameter (bushing housing)	55.5 ^{+0.1} -0
D 222777 ¥ d	D = bushing external diameter	57.3 ^{+0.6} -0.2
A	d = bushing internal diameter	20.2 ^{+0.3} -0






SHOCK ABSORBER	Length between eyebolts and extremity: Open (mm) Closed (mm) Stroke (mm)	MANNESMANN & SACHS 714 ± 3 414 ± 3 300
SHOCK ABSORBER		FICHTEL & SACHS
MODELS: 120ED/ 130ED/ 140E./ 150E150ERS	Length between eyebolts and extremity: Open (mm) Closed (mm) Stroke (mm) (with semi-elliptical springs)	725 ± 3 435 ± 3 290
SHOCK ABSORBER		FICHTEL & SACHS
MODELS: 140E./ 150E./150ERS	Length between eyebolts and extremity: Open (mm) Closed (mm) Stroke (mm) (with parabolic springs)	709 ± 3 409 ± 3 300
SHOCK ABSORBER		FICHTEL & SACHS
MODELS: 180E	Length between eyebolts and extremity: Open (mm) Closed (mm) Stroke (mm)	820 ± 3 470 ± 3 350

REAR LEAF SPRINGS





PARABOLIC LEAF SPRING SPECIFICATIONS AND DATA REAR SUSPENSION - Models 110EL..-120EL..

	1	mm
	Parabolic leaf springs	Nº 2
	Main leaf leaf length (measured at eye centre) Auxiliary spring length (measured between ends)	1670 ± 3 -
S X	Main leaf thickness (measured in the middle) Second leaf thickness (measured in the middle) Auxiliary leaf thickness (measured in the middle)	25 25 40
s ¥	Thickness between leaves	3
	Width of leaves	70 ± 0.5
	NEW SPRING CHECK DATA: Main leaf static load deflection Auxiliary leaf static load deflection Static load Main leaf static load flexibility Auxiliary leaf static load flexibility after operation	14.75 5 38.05 KN 5.77 mm/KN 1.90 mm/KN
Þ T	Main leaf eye internal diameter (bushing housing)	55.5 + 0.1
D 277777 ¥ d	D = bushing external diameter	57.3 ^{+0.6} _{-0.2}
A	d = bushing internal diameter	20.2 ^{+0.3} -0

REAR SUSPENSION - Models 120E..-130E..

		mm
	Parabolic leaf springs	Nº 2
L	Main leaf leaf length (measured at eye centre) Auxiliary spring length (measured between ends)	1680 ± 3 -
S K	Main leaf thickness (measured in the middle) Second leaf thickness (measured in the middle) Auxiliary leaf thickness (measured in the middle)	25 25 38
s ¥	Thickness between leaves	3
	Width of leaves	80 ± 0.5
	NEW SPRING CHECK DATA: Main leaf static load deflection Auxiliary leaf static load deflection Static load Main leaf static load flexibility Auxiliary leaf static load flexibility after operation	31 3.5 38.05 KN 6.55 mm/KN 2.12 mm/KN
↓ ↓ ↓ ↓	Main leaf eye internal diameter (bushing housing)	55.5 + 0.1
	D = bushing external diameter	57.3 ^{+0.6} _{-0.2}
	d = bushing internal diameter	20.2 ^{+0.3} -0

REAR SUSPENSION - Models 120E..-130E..- 130E18RS

		mm
	Parabolic leaf springs	Nº 2
L	Main leaf leaf length (measured at eye centre) Auxiliary spring length (measured between ends)	1680 ± 3
S ¥	Main leaf thickness (measured in the middle) Second leaf thickness (measured in the middle) Auxiliary leaf thickness (measured in the middle)	24 24 37
s ¥	Thickness between leaves	3
	Width of leaves	80 ± 0.5
	NEW SPRING CHECK DATA: Main leaf static load deflection Auxiliary leaf static load deflection Static load Main leaf static load flexibility Auxiliary leaf static load flexibility after operation	32 7.25 41.251 KN 5.658 mm/KN 2.105 mm/KN
P ZZZZ	Main leaf eye internal diameter (bushing housing)	55.5 + 0.1
	D = bushing external diameter	57.3 ^{+0.6} -0.2
*	d = bushing internal diameter	20.2 ^{+0.3} -0

REAR SUSPENSION -Models 120E..-120E..D-130E..-130E..D-150E..-150E18RS

		mm
	Parabolic leaf springs	Nº 2
L	Main leaf length (measured at eye centre)	1680 ± 3
S X	Main leaf thickness (measured in the middle) Auxiliary leaf thickness (measured in the middle)	23 38
s ¥	Thickness between leaves	3
	Width of leaves	80 ± 0.5
	NEW SPRING CHECK DATA: Main leaf static load deflection Auxiliary leaf static load deflection Main leaf static load flexibility Auxiliary leaf static load flexibility after operation	4 9.5 4.36 mm/KN 1.82 mm/KN
P A	Main leaf eye internal diameter (bushing housing)	55.5 + 0.1
D 222777 ¥ d	D = bushing external diameter	57.3 ^{+0.6} -0.2
*	d = bushing internal diameter	20.2 ^{+0.3} -0

REAR SUSPENSION - Models 180E..

		mm
	Parabolic leaf springs	Nº 2
	Main leaf length (measured at eye centre)	1680 ± 3
S ¥	Main leaf thickness (measured in the middle) Auxiliary leaf thickness (measured in the middle)	24 38
s X	Thickness between leaves	3
	Width of leaves	80 ± 0.5
	NEW SPRING CHECK DATA: Main leaf static load deflection Auxiliary leaf static load deflection Main leaf static load flexibility Auxiliary leaf static load flexibility after operation	4 6.5 3.87 mm/KN 1.73 mm/KN
→ D	Main leaf eye internal diameter (bushing housing)	55.5 + 0.1
D 222777 ¥ d	D = bushing external diameter	57.3 ^{+0.6} -0.2
	d = bushing internal diameter	20.2 ^{+0.3} -0

SEMI-ELLIPTICAL LEAF SPRING SPECIFICATIONS AND DATA REAR SUSPENSION 120E..-130E..

	1	mm
	Semi-elliptical leaf springs	Nº 2
	Main leaf length (measured at eye centre) Auxiliary leaf length	1680 ± 3 1254 ± 3
s ¥	Main leaf thickness (1 st -2 nd) Main leaf thickness (3 rd - 4 th - 5 th) Auxiliary leaf thickness (1 st → 11 th)	4 6 0
	Width of leaves	80 ± 0.5
	NEW SPRING CHECK DATA: Main leaf static load deflection Auxiliary leaf static load deflection Main leaf static load flexibility Auxiliary leaf static load flexibility after operation	42 51 5.17 mm/KN 1.67 mm/KN
D	Main leaf eye internal diameter (bushing housing)	55.5 + 0.1
	D = bushing external diameter d = bushing internal diameter	57.3 ^{+0.6} -0.2 20.2 ^{+0.3} 0

REAR SUSPENSION - Models 120E...D-130E...D-150E..


		mm
C	Semi-elliptical leaf springs	Nº 2
L	Main leaf length (measured at eye centre) Auxiliary leaf length (measured between ends)	680 ± 3
s ¥	Main leaf thickness ($ ^{st} \rightarrow 7^{th}$) Auxiliary leaf thickness ($ ^{st} \rightarrow ^{th}$)	254 ± 3 5 0
	width of leaves	80 ± 0.5
	NEW SPRING CHECK DATA: Main leaf static load deflection Auxiliary leaf static load deflection Main leaf static load flexibility Auxiliary leaf static load flexibility after operation	35 46 3.87 mm/KN 1.504 mm/KN
Þ A	Main leaf eye internal diameter (bushing housing)	55.5 ^{+0,1} 0
	D = bushing external diameter d = bushing internal diameter	57.3 ^{+0.6} -0.2 20.2 ^{+0.3} 0

REAR SUSPENSION 180E..

		mm
	Semi-elliptical leaf springs	Nº 2
	Main leaf length (measured at eye centre) Auxiliary leaf length (measured between ends)	1680 ± 3 1254 ± 3
s to the second se	Main leaf thickness ($1^{st} \rightarrow 7^{th}$) Auxiliary leaf thickness ($1^{st} \rightarrow 11^{th}$)	6 0
	Width of leaves	80 ± 0.5
	NEW SPRING CHECK DATA: Main leaf static load deflection Auxiliary leaf static load deflection Main leaf static load flexibility Auxiliary leaf static load flexibility after operation	27 44 3.193 mm/KN 1.39 mm/KN
D	Main leaf eye internal diameter (bushing housing)	55.5 + 0.1
	D = bushing external diameter d = bushing internal diameter	57.3 ^{+0,6} - 0,2 20.2 ^{+0,3} 0

HENDRICKSON REAR SUSPENSION Models 260E.

Disconnection





Place the vehicle on a flat surface.

- Lock front wheels.
- Lift the rear part of the chassis and remove the wheels of the intermediate and rear axle.
- Place a suitable lifting tool under the equalizer to be removed.
- Disconnect the limit stop belt (12) loosening the screws (2) and removing the brackets (1).
- Disconnect the shock absorbers (3) from the lower part loosening the fasteners (10).
- Disconnect the suspension rubber springs (11) loosening the screws (4).
- Remove the screws (5) and withdraw the relevant bushes (8).
- Lower the equalizer by means of the lifting jack and extract it from its seat.

Reconnection



To reconnect follow the disconnection procedure in the reverse order.

Note: Work properly with the lifter under the equalizer (6) to obtain the centering of the axle box-type melting with the silentblock (9) in order to ease the insertion of the relevant bushes (8). Eventually lock the corresponding fasteners to the following tightening torques:


6

7

8

fastener (.	5) to	630	Nm

fastener (10) to 94 Nm;
fastener (4) to 50 Nm.




I. Limit stop belt locking bracket - 2. Bracket fastening screws - 3. Shock absorber - 4. Rubber spring fastening screws -5. Silentblock fastening screws - 6. Equalizer - 7. Axle box-type melting -8. Silentblock bush - 9. Silentblock - 10. Shock absorber fastener - 11. Rubber spring - 12. Limit stop belt

74086

28 FRONT AND REAR MECHANICAL SUSPENSIONS


EuroCargo Tector 12-26 t


REAR SHOCK ABSORBERS





SPECIFICATIONS AND DATA


SHOCK ABSORBERS		MANNESMANN & SACHS	
MODELS: 110EL./120EL	Length between eyebolts Open (mm) Closed (mm) Stroke (mm)	669 ± 3 404 ± 3 265	
SHOCK ABSORBERS		FICHTEL & SACHS	WAY - ASSAUTO
MODELS: 120E 130E130ERS	Length between eyelet centres Open (mm) Closed (mm) Stroke (mm)	714 ± 3 414 ± 3 300	702 ± 3 417 ± 3 285
SHOCK ABSORBERS		FICHTEL & SACHS	
MODELS: 120ED/130ED 140E 150E150ERS	Length between eyebolts and extremity: Open (mm) Closed (mm) Stroke (mm)	714 ± 3 414 ± 3 300	
SHOCK ABSORBERS		FICHTEL & SACHS	
MODELS: 180E	Length between eyebolts and extremity: Open (mm) Closed (mm) Stroke (mm) (with parabolic leaf springs)	666 ± 3 396 ± 3 270	
SHOCK ABSORBERS		FICHTEL (& SACHS
MODELS: 180E	Length between eyebolts and extremity: Open (mm) Closed (mm) Stroke (mm)	716 416 30	± 3













TIGHTENING TORQUES

PART		TOR	QUE
		Nm	(kgm)
FRONT SUSPENSIONS			
Leaf spring bracket fastening nut	M16x1.5	238 ± 22.5	(24 ± 2.2)
Leaf spring bracket fastening nut	M18×1.5	278 ± 27	(28 ± 2.7)
Leaf spring bracket fastening nut	M20×1.5	464 ± 46	(47 ± 4.7)
Leaf spring to pad fastening nut		445 ± 45	(45 ± 4.6)
Leaf spring to front mount fastening nut		445 ± 45	(45 ± 4.6)
Shock absorber to chassis fastening nut	MI6	80 ± 8	(8 ± 0.8)
Shock absorber to axle fastening nut	MI6	80 ± 8	(8 ± 0.8)
Upper shock absorber fastening nut	MI4×I.5	64 ± 6	(6.4 ± 0.6)
Shock absorber to axle fastening nut	M20	2 ± 2	(2.3 ± .2)
Shock absorber fork fastening nut		275 ± 55	(28 ± 5.6)
Connecting rod to chassis support screw nut		223 ± 22	(23 ± 2.3)
Connecting rod to sway bar fastening pin nut		311 ± 30	(34 ± 3)
Sway bar support to chassis fastening screw		76.5 ± 7.5	(8 ± 0.8)
Collar to sway bar support fastening screw	MI2	±	$(\pm .)$
REAR SUSPENSION			
Spring bracket on axle fastening nut	M22×1.5	623 ± 62	(63.5 ± 6.3)
Leaf spring front fastening nut	M20	445 ± 45	(45 ± 4.5)
Leaf spring to pad fastening screw	M20	445 ± 45	(45 ± 4.5)
Rear mount to chassis fastening screw nut	M16	227 ± 23	(23 ± 2.3)
Sway bar to axle mount fastening screw nut	M20	3 ± 3	(32 ± 3)
Connecting rod to chassis support fastening screw nut	M20	3 ± 3	(32 ± 3)
Upper shock absorber fastening nut	MI4xI.5	64 ± 6	(6.4 ± 0.6)
Lower shock absorber fastening nut	M20	2 ± 2	(2.3 ± .2)
Shock absorber to chassis fastening nut	M16	80 ± 8	(8 ± 0.8)
Shock absorber to axle fastening nut	M16	80 ± 8	(8 ± 0.8)
Rebound to chassis fastening screw		77 ± 7	(7.9 ± 0.7)
Sway bar support to chassis fastening screw nut	MI2	63 ± 7	(6.4 ± 0.6)
Sway bar to connecting rod fastening nut	MIO	35.5 ± 3.5	(3.6 ± 0.3)





500450 REAR MECHANICAL SUSPENSION REMOVAL-REFITTING



Disconnect the battery cables before starting removal-refitting operations.

Removal



Arrange the vehicle on level ground, block the front wheels and proceed as follows:

- Loosen the rear wheel fastening nuts, lift back of the vehicle and position it on stands.
- Arrange hydraulic jack 99321024 under the wheels, remove the fastening nuts and remove the wheels.
- Loosen the nuts (3) and remove the fastening U-bolts (4).
- Loosen the nut and remove the front leaf spring (5) anchoring pin (6) to the chassis support (7).
- Loosen the nut and remove the rear pin (2) anchoring the leaf spring (5) to the chassis (1), lower the axle and remove the complete leaf spring.

Refitting




IVECO

Refit by reversing the removal sequence. Fasten screws and nuts at the specified torque.


Lock nuts must be replaced and fastened at the specified torque.

Check that:

U-bolt (4) threading is in good conditions. If required, reface the threading or replace the part.








Loosen the nuts (1 and 4), take the rebound (3) and remove the shock absorber (2).

Refitting



Refit by reversing the removal sequence. Fasten screws and nuts at the specified torque.

500940 REAR SHOCK ABSORBERS Removal




Loosen the nuts (1 and 3) and remove the shock absorber (2).



Refit by reversing the removal sequence. Fasten screws and nuts at the specified torque.

528930 FRONT SWAY BAR Removal



72830

Loosen the nuts (1 and 3) and remove the sway bar (4) with anchoring rod (2).

Refitting



Refit by reversing the removal sequence. Fasten screws and nuts at the specified torque.

528960 REAR SWAY BAR

Figure 23

Loosen the nut and remove the axle support fastening pin (3).

Remove the nut (1), remove the pin and remove the sway bar with reaction rod (2).

Refitting

Refit by reversing the removal sequence. Fasten screws and nuts at the specified torque.

REPAIRS

- Do not replace leaves if more than one leaf is broken.
- Do not replace leaves if there are less than three leaves in the faulty spring.
- Auxiliary leaf springs with main spring and auxiliary springs are an exception to the specification above. In other words, they can be replaced also if the total number of leaves in the auxiliary spring is less than three.
- □ Leaf springs consists on main leaves and supplementary leaves should be considered as leaf springs consisting of a main spring (main leaves) and auxiliary spring (supplementary leaves) reason for which the main leaves can be replaced if there are at least three while supplementary leaves can be replaced in any case.
- ☐ The remaining leaves of the faulty spring which are not replaced must not present superficial alterations to visual inspection nor alternations of shape which may compromise compliance with original construction principles.

Leaf spring disassembly



Arrange the leaf spring near the central pin in a vice on the specific work bench.

Remove the central union pin after removing the respective nut. Loosen the nuts fastening the side brackets and remove the brackets. This operation will free the individual leaves forming the leaf spring.

Checks



Carefully clean all parts with diesel fuel or solvent. Make sure that the bushings are well anchored in the spring and pad holes. Make sure that the internal surface is not ovalised and that the pins are neither worn nor misshapen. Replace if this is not so.

<image>

Position the leaf spring (1) under a press (4) and remove the bushing (2) from its housing with a ram (3).

Refitting



Refit by reversing the removal sequence.

Leaf spring assembly




 \square

 $\langle \bullet \bullet \rangle$

Make sure the surfaces in contact with the leaves are perfectly smooth and clean,

Arrange the leaves in the bundle next to each other, arrange the respective shims in between and align the central holes for fitting the union pin.



The brackets must be fastened to keep the leaves aligned, without restricting free movement.

After assembly, use a punch to rivet the central pin and the bracket pins to lock them safely.

50	04 Front and rear pneumatic suspensions	
		Page
PN	EUMATIC SUSPENSIONS	45
INT	RODUCTION	45
PN	EUMATIC SUSPENSION ASSEMBLIES	45
FRC	DNT PNEUMATIC SUSPENSION	45
LEA	AF SPRING SPECIFICATIONS AND DATA .	46
	DNT SUSPENSION - MODELS 120EFP/130EFP/150EFP	46
FRC	ONT SHOCK ABSORBERS	47
	Assembly diagrams	47
SPE	CIFICATIONS AND DATA	47
RE/	AR PNEUMATIC SUSPENSION	48
RE/	AR SHOCK ABSORBERS	51
	Assembly diagrams	51
SPE	CIFICATIONS AND DATA	52
	Electronically controlled rear pneumatic suspension diagram (NEWAY for Models 110ELP-120ELP)	53
	Cable-and-trunk diagram of pneumatic rear suspensions (For Models 120EP-130EP- 150EP-180EP)	54
	Electronically controlled FULL PNEUMATIC susp sion diagram (For Model 120EFP-130EFP-150EFP)	en- 55
	Rear pneumatic suspension vehicle wiring diagram	n 56
	Front and rear pneumatic suspension vehicle wirir diagram	ng 57
CH	ASSIS LIFTING/LOWERING AND LEVELLING	58
	Remote control	58
	MOTE CONTROL DESCRIPTION	59
	Lifting/lowering the chassis	59
	Chassis self-leveling	59
	Level "M1" - "M2"	59

VEHICLE MAIN COMPONENT ARRANGEMENT	60	REAR SWAY BAR
SPECIFICATIONS AND DATA	61	🗋 Removal
DIAGNOSTICS	62	Refitting
		REAR AIR SPRINGS
	64	🔲 Removal
TOOLS	65	Refitting
MAIN PNEUMATIC SYSTEM COMPONENTS	66	FRONT SHOCK ABSORBERS
Controlled-pressure valve	66	Removal
Low pressure indicator	66	Refitting
Check valve	66	FRONT AIR SPRINGS
Electro-pneumatic front axle distributor for		Removal
4 × 2 FP vehicles	66	Refitting
Operation	67	FRONT PNEUMATIC SUSPENSION
Front axle lifting	67	REMOVAL-REFITTING
Front axle lowering	67	Removal
Self-leveling	67	Refitting
Electro-pneumatic rear axle distributor		FRONT SWAY BAR
for 4 x 2 P/FP vehicles	68	🔲 Removal
Operation	68	Refitting
Rear axle lifting	68	REAR PNEUMATIC SUSPENSION
Rear axle lowering	68	REMOVAL-REFITTING
Self-leveling	68	Removal
Level sensor	69	Refitting
Air springs	69	REAR AIR SPRINGS
ECU	69	🗋 Removal
REAR PNEUMATIC SUSPENSIONS REMOVAL-		🗋 Refitting
REFITTING	70	REAR SHOCK ABSORBERS
🖸 Removal	70	Removal
Refitting	70	Refitting
REAR SHOCK ABSORBERS	71	REAR SWAY BAR
Removal	71	🗋 Removal
Refitting	71	Refitting

		Page
REA	AR SWAY BAR	71
	Removal	71
	Refitting	71
REA	AR AIR SPRINGS	71
	Removal	71
	Refitting	71
FRC	DNT SHOCK ABSORBERS	72
	Removal	72
	Refitting	72
FRC	DNT AIR SPRINGS	72
	Removal	72
	Refitting	72
	ONT PNEUMATIC SUSPENSION REMOVAL-REFITTING	73
	Removal	73
	Refitting	73
FRC	DNT SWAY BAR	73
	Removal	73
	Refitting	73
REA F	AR PNEUMATIC SUSPENSION REMOVAL-REFITTING	74
	Removal	74
	Refitting	74
REA	AR AIR SPRINGS	75
	Removal	75
	Refitting	75
REA	AR SHOCK ABSORBERS	75
	Removal	75
	Refitting	75
REA	AR SWAY BAR	76

Page

76 76

PNEUMATIC SUSPENSIONS INTRODUCTION

Pneumatic suspensions are very flexible and offer considerable vibration damping features, regardless of vehicle load. By effect of the system self-adjusting features, the "chassis-road surface" distance is kept constant. A specific button can be used to vary the "chassis-road surface" distance, and consequently the vehicle load surface, in pneumatic suspension systems.

In addition to the advantages of pneumatic suspensions, the ECAS system ensures:

considerable air consumption reduction;

prompt response to adjustments;

system simplicity;

high safety;

complete system diagnostics.

The ECAS (Electronically Controlled Air Suspension) system automatically controls the nominal vehicle pneumatic suspension level.

All operations depend on certain working conditions and respective safety of the connected systems.

The ECAS ECU automatically controls the level (distance from the road surface) of the chassis by means of the real values provided by sensors, comparing them to the nominal values stored in the memory.

In the event of distancing or trim changes, the ECU controls the electrical-pneumatic units to correct the real level with respect to the nominal values previously set or stored by the driver.

The system has a remote control for lifting/lowering and levelling the chassis. The system can be worked with the vehicle either stationary or moving.


In addition to lifting, lowering and levelling, the system can be used to store other chassis trim levels, which can be recalled when required.

PNEUMATIC SUSPENSION ASSEMBLIES



Models equipped with mixed suspension systems (front mechanical suspensions and rear pneumatic suspensions) fit the front suspension of the corresponding mechanical suspension models.


FRONT PNEUMATIC SUSPENSION





	S 120EFP/130EFP/150EFP	mm
	Parabolic leaf springs	Nº 2
L	Main leaf and second leaf length (measured at eye centre)	1739 ± 3
S X	Leaf thickness I st leaf (measured in the middle) 2 nd leaf (measured in the middle)	30 23
s ¥	Thickness between leaves	3
	Width of leaves	80 ± 0.5
	NEW SPRING CHECK DATA: Static load deflection Static load flexibility	54 9.818 mm/KN
Þ A	Main leaf eye internal diameter (bushing housing)	55.5 + 0.1
	D = bushing external diameter	57.3 ^{+0.6} -0.2
	d = bushing internal diameter	20.2 ^{+0.3} -0

FRONT SHOCK ABSORBERS Assembly diagrams Figure 2 -----6 Ó Ð 0 Ū TP. 72792 SHOCK ABSORBER ASSEMBLY DIAGRAM (Models 120E..FP/130E..FP/150E..FP) SPECIFICATIONS AND DATA SHOCK ABSORBERS FICHTEL & SACHS Length between the ends Open (mm) 588 ± 3 Closed (mm) 358 ± 3 Stroke (mm) 230 MODELS: 120E..FP/130E..FP 150E..FP


REAR PNEUMATIC SUSPENSION








REAR SHOCK ABSORBERS




SPECIFICATIONS AND DATA

SHOCK ABSORBERS		MANNESMANN - SACHS
	Length between eyebolts: Open (mm) Closed (mm) Stroke (mm)	669 ± 3 404 ± 3 265
MODELS: 110ELP/120ELP		
SHOCK ABSORBERS		MANNESMANN - SACHS
MODELS: 120EP/FP - 130EP/FP 150EP/FP 180EP	Length between eyebolts and extremity: Open (mm) Closed (mm) Stroke (mm)	674 ± 3 404 ± 3 270


Electronically controlled rear pneumatic suspension diagram (NEWAY for Models 110EL..P-120EL..P)




Cable-and-trunk diagram of pneumatic rear suspensions (For Models 120E..P-130E..P-150E..P-180E..P)




Electronically controlled FULL PNEUMATIC suspension diagram (For Model 120E..FP-130E..FP-150E..FP)



Rear pneumatic suspension vehicle wiring diagram



Front and rear pneumatic suspension vehicle wiring diagram



CHASSIS LIFTING/LOWERING AND LEVELLING **Remote control** Figure 13 ***A** В * I 2 2 8 7 3 6 5 4 3 Front axle selection * The traditional controls arranged next to the driver's seat are 1) replaced with a remote control on the left-hand side of the 2) Memory level "I' З́) driver's seat. Lift chassis This device is used to manage the various chassis trim 4) Lower chassis 5) STOP functions. The remote control can be extracted to make the selection Level chassis 6) Memory level "2" from the driver's seat or from the ground. 7) The remote control consists of a set of buttons and two 8) Rear axle selection warning lights: The remote control is connected to the system by means of A) Front axle selection green warning light a four-pole connector. B) Rear axle selection green warning light Pin I Power positive Pin 2

- Negative
- Communication line with ECU Pin 3
- Pin 4 Communication line with ECU

See "Operation" for remote control instructions. * full pneumatic vehicles only

78799

REMOTE CONTROL DESCRIPTION AND OPERATION

EUROCARGO TECTOR 12-26 t Lifting/lowering the chassis Figure 14 B Δ I 8 2 7 6 3 5 4 78800 This operation can only be activated at speeds slower than 20 km/h. The set trim will be kept constant over this speed. Proceed as follows to lift/lower the chassis: Press button (1) and/or (8) to select the required axle. The respective warning light "A" and/or "B" will come on Press button (3) or (4) to reach the required level. All solenoid valves will be de-energised and returned to home/hold condition when button (3) or (4) is released. During this operation, the yellow warning light on the instrument panel will light up signalling that trim has not been reached. This condition and the respective warning will be kept on, also if the ignition key is switched on and off. The maximum lift limit is regulated by level sensors according to the calibration set by the ECU. Button description refers to FP vehicle remote controls.

Chassis self-leveling

This operation can be carried out at any speed.

Proceed as follows to level the chassis:

Press button (1 or 8, Figure 14) to select an axle, the respective warning light "A" or "B" will come on.

Press button (6, Figure 14).

The yellow warning light on the instrument panel will go out when the operation is recalled to signal that the chassis has been levelled.

This condition and the respective warning will be kept on, also if the ignition key is switched on and off.

The ECU will automatically re-establish chassis level if the button is not pressed at speeds over 20 km/h.

Level "MI" - "M2"

The system can store two additional trim levels "MI" and M2" as needed.

These two positions can be recalled only at speeds lower than 20 km/h.

Proceed as follows to activate the levels:

- Press button (1 or 8, Figure 14) to select an axle, the respective warning light "A" or "B" will come on.
- Press button (3 or 4, Figure 14).

During this operation, the yellow warning light on the instrument panel will light up signalling that trim has not been reached.

Proceed as follows to store trim levels "MI" and M2":


- Press button (1, Figure 14) to select the front axle, the respective warning light "Á" will come on.
- Press button (3 or 4, Figure 14) to reach the required level.
- REPEAT THE OPERATIONS ON THE REAR AXLE.
- Hold button pressed button (5, Figure 14).
- Press button (2 or 7, Figure 14).
- Release button (2 or 7, Figure 14) and then button (5, Figure 14).





In an emergency, press button (5, Figure 14) to stop levelling operations.






SPECIFICATIONS AND DATA


DESCRIPTION	
imited return controlled pressure valve	
Type: MARELLI - WABCO 434 100 232 0 - KNORR DR 4248	0.5.1
Opening pressure	8.5 bar
Air reservoir	15 litres
ront suspension	
Rear suspension Level sensor	15 litres
Type: WABCO 441 050 012 0	
Power voltage	Pulse 8 ÷ 16V
Current intake	Max 90 mA
Lever working range	Max 100°
ectro-pneumatic distributor	
Type: WABCO 472 880 001 0 (for P models, on rear axle for FP models) WABCO 472 880 020 0 (on front axle for FP models)	
Working temperature range	
Working pressure range (input)	- 40 °C ÷ + 80 °C
Maximum dynamic pressure (output control)	5 ÷ 13 bar
Power voltage	20 bar
-	24 V
Check valve	
Type: WABCO WESTINGHOUSE 434 014 000 0	Max 20 bar
Working pressure range	- 40 °C ÷ + 80 °C
Working temperature range	- tu C ÷ t tu C
Tressure test point Type: RAUFOSS 6237776 - SIRT VMF 1615 - WABCO 463.703.114.0	
_ /.	- 40 °C ÷ + 80 °C
Working temperature range Iectronic control unit	
Type: WABCO	
Power voltage	18 ÷ 32 V
Working temperature range	- 40 ÷ 70 °C
1anometric switch for low air pressure	
Type: TDS F13016	
Working voltage	2/24 V
Permitted electric load	0.001 to 1 A
Maximum operating pressure	12 bar

DIAGNOSTICS

Main pneumatic suspension operating problems:

- I Low or irregular pneumatic system recharging
- 2 Irregular vehicle trim
- 3 Chassis out of trim warning light on at speeds faster than 20 km/h






TIGHTENING TORQUES


PART	TORQUE	
	Nm	(kgm)
Front pneumatic suspension (Models 120EFP/130EFP/150EFP)		
Rebound fastening screw nut	62.5 ± 6.5	(6.25 ± 0.65)
Spring brackets fastening screw nut	463.5 ± 46.5	(46.35 ± 4.65)
Spring to front mount fastening screw nut	336.5 ± 33.5	(33.65 ± 3.35
Spring to pad fastening screw nut	336.5 ± 33.5	(33.65 ± 3.35)
Rear pneumatic suspension (Models 110ELP/120ELP)		
Front support to chassis fastening screw	250 ÷ 306	(25 ÷ 30.6)
Suspension arm to front mount fastening screw nut	435 ÷ 530	(43.5 ÷ 53)
Suspension arm to axle box fastening screw nut	819 ÷ 1002	(81.9 ÷ 100.2)
Upper and lower shock absorber fastening screw nut	9 ÷ 46	(.9 ÷ 4.6)
* Axle box fastening U-bolt nut	425 ÷ 440	(42.5 ÷ 44)
Sway bar fastening nut	794 ÷ 971	(79.4 ÷ 97.1)
Panhard bar fastening screw nut	40 ÷ 54	(4 ÷ 5.4)
Air spring lower fastening nut	435 ÷ 530	(43.5 ÷ 53)
Other flanged head fasteners with waxed nut: M12x1,75 R80 M12x1,75 R100	56 ÷ 69 83 ÷ 101	(5.6 ÷ 6.9) (8.3 ÷ 10.1)
 U-bolts must be fastened diagonally in several times to ensure contact between maximum specified torque. 	adapter and axle befor	re reaching
Rear pneumatic suspension (Models: 120EP-FP/130EP-FP/150EP-FP)		
Reaction triangle to chassis fastening screw	352.5 ± 32.5	(35.25 ± 3.25)
Longitudinal arm bar fastening screw nut	418 ± 42	(41.8 ± 4.2)
Air spring support arm to air spring fastening screw nut	90 ± 10	(9 ± 1)
Air spring to chassis fastening screw nut	92 ± 9	(9.2 ± 0.9)
Nut for screw fastening the air-operated spring support arm to the rear axle.	545 ± 55	(54.5 ± 5.4)


PART	TORQUE	
	Nm	(kgm)
Rear pneumatic suspension (Models: 180EP)		
Axle to air spring support arm fastening screw nut	845 ± 170	(84.5 ± 17)
Reaction triangle to axle fastening screw	290 ± 30	(29 ± 3)
Reaction bar fastening screw nut	418 ± 42	(42.6 ± 4.3)
Support arm to air spring fastening screw nut	100 ± 10	(0 ±)
Air spring to chassis fastening screw nut	92 ± 9	(9.4 ± 0.9)
Sway bar to spring support arm fastening pin nut	373.5 ± 37.5	(38 ± 3.8)
Sway bar support to chassis fastening screw nut (M16)	226.5 ± 22.5	(23 ± 2.3)
Sway bar support to chassis fastening screw nut (M12)	92 ± 9	(9.4 ± 0.9)
Connecting rod to chassis support fastening pin nut	359 ± 36	(36.6 ± 3.7)
Upper shock absorber fastening pin nut	8 ± 2	(.8 ± .2)
Lower shock absorber fastening pin nut	187.5 ± 18.5	(18.7 ± 1.9)
Reaction triangle to chassis support fastening screw	418 ± 42	(42.6 ± 4.3)

TOOLS



MAIN PNEUMATIC SYSTEM COMPONENTS





Pneumatic connections

- 11 from air reservoir
- 21 from axle electro-pneumatic distributor
- 22 to air spring on right-hand side
- 23 to air spring on left-hand side

Electrical connections

- 6.1 Solenoid valve power positive
- 6.2 Negative
- 6.4 Free

<section-header>

78804

Front axle lifting

The ECU energises the solenoid valve supplying the distributors via the air duct (11) from the reservoir and energising the axle electro-pneumatic distributor solenoid valve "A" (Figure 24) to supply the first distributor, closes the relief to atmosphere (3, Figure 24) and opens the air intake (11, Figure 24) from the reservoir.

In this way, the air from duct (21, Figure 24) to duct (21) supplies the axle air springs via ducts (22 and 23).

Front axle lowering


In this case, the ECU energises the solenoid valve supplying the distributor, allowing the air to be relieved from the air springs from duct (21) to duct (21, Figure 24) and opens the air input (3, Figure 24), which is open because the axle electro-pneumatic solenoid valve "A" (Figure 24) is de-energised.

Self-leveling

The ECU, according to the position of the level sensors, controls the front axle electro-pneumatic distributor solenoid valve and the rear axle electro-pneumatic distributor solenoid valves accordingly for lifting or lowering in order to reach vehicle levelling or stored positions "MI" or "M2".

Electro-pneumatic rear axle distributor for 4 x 2 P/FP vehicles






This components consists of three control solenoid valves "A", "B", "C" and three pneumatic distributors.

Solenoid valve "A" manages the supply/discharge distributor.

Solenoid valve "B" manages the right-hand chassis trim distributor.

Solenoid valve "C" manages the left-hand chassis trim distributor.

The distributor is connected to the system by means of a four-pole connector.




Pneumatic connections

- 11 from air reservoir
- 21 to axle electro-pneumatic distributor
- 22 to air spring on right-hand side
- 23 to air spring on left-hand side

Electrical connections

- 6.1 Solenoid valve "A" power positive 6.2 Solenoid valve "B" power positive 6.3 Solenoid valve "C" power positive





Rear axle lifting

The ECU energises solenoid valve "A" supplying the first distributor that closes the relief to atmosphere (3) and opens the air intake (11) from the reservoir.

The ECU then energises solenoid valve "B" and "C" for supply the second and third distributor and to consequently supply the rear axle air springs via ducts (22 and 23).



4x2 P vehicles Duct (21) is capped. 4x2 FP vehicles

Duct (21) is connected to front axle electro-pneumatic distributor duct (14) for supplying the air springs.


Rear axle lowering

In this case, the ECU energises solenoid valves "B" and "C" supplying the second and third distributor, allowing the air to be relieved from the air springs from duct (3), which is open because the axle electro-pneumatic solenoid valve "A" is de-energised.

Self-leveling

The ECU, according to the position of the level sensors, controls solenoid valves "A", "B" and/or "C" accordingly for lifting or lowering in order to reach vehicle levelling or stored positions "MI" or "M2".

Level sensor




The level sensor consists of a coil fastened to the chassis and a piston.

The piston is moved by an eccentric gear and a lever connected to the axle when the height changes, whereby changing the inductance of the coil.


These variations are used by the ECU to intervene in the various phases of system work.

The sensor connection lever is fixed and cannot be adjusted.



Sensor nominal characteristic curve according to angular lever movement

5007 Air springs



This elastic element contains pressurised air and changes its extension, regardless of the applied load.

ECU

The ECU manages the various chassis positions according to the requests made by the driver by means of the remote control.


When the key switch is switched on, the electronic control unit performs a system check by powering, during ~ 2 seconds, the red warning light (pneumatic suspension low pressure) found on the dashboard. If an anomaly is found, the CLUSTER display will show the corresponding symbol, according to the type of anomaly: a yellow symbol on the left portion (anomalies and faults not critical), or a red symbol on the right portion (critical faults). The ECU must keep the levels required by the driver constant and, at the same time, reduce air consumption, by cyclically monitoring the level sensor signals, cutting in ONLY when the discrepancy between sensors is > 5 counts.


Correction will be made with a delay of:

D approximately I second when the vehicle is stationary D approximately 60 seconds when the vehicle is moving. The ECU will store a plausibility error if the level is not restored within a maximum time of 30 seconds.


This is ONLY valid providing that the vehicle has been moving for at least five minutes, because the system details checks to allow recharging the pneumatic system.

When braking, the ECU receives a signal from the brake light switch, interrupting automatic trim adjustments. The ECU is equipped with an extremely advanced self-diagnostic system which is capable of recognising and storing system failures (also intermittent), according to environmental conditions, during operation, for ensuring correct, reliable repairs, in addition to blink codes displayed by the red warning light for preliminary troubleshooting. Diagnostic, programming and error memory deletion operations, etc., can be carried out using the MODUS computerised diagnostic station. All system components, except for the steering system, are connected to the ECU, by means of a comb connector. The pin numbering and ECU type change according to the version.





screws and nuts at the specified torque.




Disconnect the air supply tubes (2).

Loosen the fastening screws (1), loosen the nut (4) and remove the air spring (3) from the vehicle.

Refitting



Refit by reversing the removal sequence. Fasten screws and nuts at the specified torque.




Loosen upper nut (1) and lower nut (5), take the pads (2) and (4) and remove the shock absorber (3) from the vehicle.

Refitting



Refit by reversing the removal sequence. Fasten screws and nuts at the specified torque.



72820

Disconnect the air supply tube (1).

Loosen the upper fastening screws (2) and the lower fastening screws (4). Remove the air springs from the vehicle.

Refitting



Refit by reversing the removal sequence. Fasten screws and nuts at the specified torque.

Figure 34

500710 FRONT PNEUMATIC SUSPENSION REMOVAL-REFITTING



Disconnect the battery cables before starting removal-refitting operations.

Removal



Arrange the vehicle on level ground, block the rear wheels with wedges and proceed as follows:

- Loosen the front wheel fastening nuts, lift the vehicle and position it on stands.
- Arrange hydraulic jack 99321024 under the wheels, remove the fastening nuts and remove the wheels.
- Loosen the nuts (6), taking the pad (10) and remove the shock absorber (14).
- On the lower side of the vehicle, loosen the nuts (4) and remove the U-bolt (3) taking the plate (11).
- Loosen the nut and remove the rear pin (13) anchoring the leaf spring (12) to the chassis mount.
- Loosen the nut and remove the front leaf spring (12) anchoring pin (1) to the chassis mount. Lower the axle and remove the complete leaf spring.
- Loosen the nut (9) and disconnect the tie-rod (8).
- Loosen the nut (7), remove the screw and disconnect the air spring from the leaf spring.

Refitting

ו⊞ן


 \bigcirc

VECC

Refit by reversing the removal sequence. Fasten screws and nuts at the specified torque.

Lock nuts must be replaced and fastened at the specified torque.

Check that:



528930 FRONT SWAY BAR Removal



On the lower side of the vehicle, loosen the front U-bolt (3) nuts (4) and remove from the housing.

- Loosen the nuts (2) fastening the sway bar connecting rod to the chassis mount.
- Remove the mounts from the axle and remove the sway bar (5) with connecting rod from the vehicle.

Refitting




VECO

Refit by reversing the removal sequence. Fasten screws and nuts at the specified torque.

Lock nuts must be replaced and fastened at the specified torque.

Check that:

U-bolt threading is in good conditions. If required, reface the threading or replace the part.



A = Part seen from the right-hand side of the vehicle.

6

500730 REAR PNEUMATIC SUSPENSION REMOVAL-REFITTING

(Models 120E..P-FP/130E..P-FP/150E..P-FP)

The following paragraph describes the procedure for model 130E..FP and is suitable also for the other models. Figure 35

Disconnect the battery cables before starting removal-refitting operations.

Removal



Arrange the vehicle on level ground, block the rear wheels with wedges and proceed as follows:

- Loosen the front wheel fastening nuts, lift the vehicle and position it on stands in the point shown by (\Rightarrow) .
- Arrange hydraulic jack 99321024 under the wheels, remove the fastening nuts and remove the wheels.
- Loosen nut (13) and remove the shock absorber (14).
- Remove the air spring (2) and (11) fastening nuts (4) and (9).
- Remove the sway bar (10) fastening bolts (8).
- Loosen the fastening nuts and disconnect the level valve tie-rid (12).
- Loosen the fastening nuts (6), taking the plates and remove the U-bolts (15).
- Loosen the reaction rod (3) fastening bolts (1) and (7).
- Remove the suspension arms from the vehicle (5).

Refitting





- Refit by reversing the removal sequence. Fasten screws and nuts at the specified torque.
- Lock nuts must be replaced and fastened at the specified torque.


Check that:




U-bolt (15) threading is in good conditions. If required, reface the threading or replace the part.







Refit by reversing the removal sequence. Fasten screws and nuts at the specified torque.



SECTION 9

5025 Wheels and Tires

	Page
DESCRIPTION	3
SPECIFICATIONS AND DATA	3
Tire pressure values	3
TOOLS	4
DIAGNOSTICS	4
STATIC WHEELS BALANCING	7
CORRECTION OF RESIDUAL STATIC UNBALANCE	8
TIRE PRESSURE	8
TIRE BEHAVIOUR DEPENDING ON PRESSURE	9

DESCRIPTION

The wheel rim shows the rigid wheel structure and is identified by the following dimensions:

- im diameter, measured at the circumferential groove base (that is on the surface on which the air chamber rests);
- circumferential wheel rim groove width (that is the distance between the surfaces on which the cover rests).
- The tire has the following tasks:
- absorbing the majority of impacts generated by road projections by exploiting air resiliency;

- developing on ground the motive force provided by the engine and necessary for moving the vehicle;
- ensuring the maximum adherence established by the tire-road contact with a satisfactory length;
- Supporting efforts generated by sudden brakings, by quick accelerations and by the centrifugal force thrust in a curve;
- guaranteeing vehicle stability and ensuring the directional vehicle power.

SPECIFICATIONS AND DATA


	WHEEL RIMS: Disc-type with drop center rim
MODELS 4x2	MEASURES
ML 110 EL	17.5" × 6.75"
ML 120 EL	17.5" × 6.75"
ML 120 E	19.5" × 8.25" - 19.5" × 6.75" - 19.5" × 7.50" - 22.5" × 6.75"
ML 130 E	19.5'' × 6.75'' - 19.5'' × 7.50'' - 22.5'' × 6.75''
ML 140 E	19.5" × 6.75" - 19.5" × 7.50" - 19.5" × 8.25" - 22.5" × 6.75" - 22.5" × 7.50"
ML 150 E	19.5" × 6.75" - 19.5" × 7.50" - 19.5" × 8.25" - 22.5" × 6.75" - 22.5" × 7.50"
ML 180 E	22.5'' × 8.25'' - 22.5'' × 9.00''
MODELS 6x4	MEASURES
260E28KE	22.5'' × 8.25''


Tire pressure values




For checking tire pressure, comply with values shown in the specific "Use and Maintenance" booklet.

TOOLS







(continues)



502511 STATIC WHEELS BALANCING





If the weight is in the area marked with letter A, this means	
that it is too light and therefore weight must be added	
according to what the instrument shows (1, Figure 2).	

☐ If the weight is in the lower area marked with letter C, this means that it is too heavy and then it must be decreased by what the measuring instrument marks.

When the weight is in the areas marked with letters B and D, do not remove or add any weight, but rather move it by 5 cm upwards along the arrows direction, see Figure 4.


502510 TIRE PRESSURE

The tire pressure values must be checked with cold tires. Strictly take care of the pressure correctness, because, if it is greater than the required one, it creates running stiffness and excessive wear of central tread surface, while if it is lower, the load is not distributed on the whole tread but is concentrated on the side parts, early consuming them, and damaging the internal tire structures.

A pressure unbalance between tires impairs the vehicle driving stability and impairs its running safety.

The anomalous tire wear can occur in different tread areas thereof.

adjustment.



It is advisable that the pair of tires assembled on an axle are replaced when on the tread, after the small blocks consumption, continuous bands appear extended to the whole tire width (displayed in the figures with dots). The tires further have wear indicators A and B placed next to indicator TWI for PIRELLI tire (B) and next to MICHELIN (A) symbol for those of this latter manufacturer: the replacement is mandatory in case these indicators are reached.


Print 603.93.111

SECTION 10 Steering 5014 Page DESCRIPTION 3 SPECIFICATIONS AND DATA 4 DIAGNOSTICS 4 9 TIGHTENING TORQUES 9 TOOLS ZF HYDRAULIC POWER STEERING (8095-8098) 10 Description 10 13 Hydraulic steering limiting HYDRAULIC POWER STEERING DISCONNECTION AND RECONNECTION (ZF 8095-8098) 14 14 15 Reconnection HYDRAULIC STEERING LIMITER ADJUSTMENT 16 TRW TAS 55 HYDRAULIC POWER STEERING 17 17 Rectilinear running neutral position 18 19 20 21 HYDRAULIC STEERING LIMITATION HYDRAULIC POWER STEERING DISCONNECTION AND RECONNECTION (TRW TAS 55) ... 22 Automatic adjustment setting of hydraulic steering limitation for TRW TAS 55 hydraulic power 22 steering 22 Hydraulic drops adjustment 23 AIR DRAIN FROM HYDRAULIC POWER STEERING CIRCUIT 24 24 Hydraulic power steering oil level restoration . MEASURE OF DRIVE CASE CLEARANCES DETECTED ON STEERING WHEEL 24 MAXIMUM PRESSURE CHECK IN HYDRAULIC POWER STEERING SYSTEM . 24

DESCRIPTION


The steering control system, that can be found on EuroCargo vehicles, is composed of an hydraulic power steering of the ball-circulation type controlled by a geared pump assembled together with the air compressor. Such pump has the feature of having its oil tank integrated with the body.


Hydraulic power steering system installation view





SPECIFICATIONS AND DATA


	Steering		Hydraulic	
	Hydraulic power steering (with ball circ tion with embedded pressure limiting valve)	ula- ZF 8095	ZF 8098	TRW/TAS 55
$\langle \langle \rangle \rangle$	Variable operating pressure	150 + 15	30 + 3	150 + 10
VM PP	Reduction ratio	19.6 : 1	22.2 to 26.2 : I	20.4 : 1
U	No. of revolutions/steering wheel	5.4	3.1	5.7
	Power steering pump with integrated ta and safety filter valve	nk	ZF FN4 Integral	1
	Min. number of revolutions Revs/mir		600	
	Max. number of revolutions Revs/mir		2700	
	Operating pressure bar		max. 180	
	Flow rate dm ³ /min		16	
	Maximum operating temperature		100 ° C	
PIAGNOSTICS	eering operating anomalies:			
lain hydraulic power st – Hard steering ir - Hard steering o – Hard steering v rotated; – When one stee wheel;	eering operating anomalies: n right and left steering; 5 nly in left or right steering; 6 when the steering wheel is quickly 7 rs, strong impacts occur on steering RD STEERING RIGHT AND	 Torsional stee Excessive stee Oil leakage; Insufficient circ 	ring wheel clearand	ns; ce;
 1ain hydraulic power st Hard steering ir Hard steering o Hard steering v rotated; When one stee wheel; 	right and left steering; 5 nly in left or right steering; 6 when the steering wheel is quickly 7 rs, strong impacts occur on steering	 Excessive stee Oil leakage; 	ring wheel clearand	ns; ce;
lain hydraulic power st – Hard steering ir - Hard steering o – Hard steering v rotated; – When one stee wheel; I	a right and left steering; nly in left or right steering; when the steering wheel is quickly rs, strong impacts occur on steering RD STEERING I RIGHT AND	 Excessive stee Oil leakage; Insufficient circ 	ring wheel clearand cuit pressure. Inning engine; top-u	up the oil till the
lain hydraulic power st – Hard steering ir - Hard steering o – Hard steering v rotated; – When one stee wheel; I	a right and left steering; nly in left or right steering; when the steering wheel is quickly rs, strong impacts occur on steering RD STEERING RIGHT AND FT STEERING	 Excessive stee Oil leakage; Insufficient circ 	ring wheel clearand cuit pressure. Inning engine; top-u	up the oil till the
lain hydraulic power st – Hard steering ir - Hard steering o – Hard steering v rotated; – When one stee wheel; I	a right and left steering; nly in left or right steering; when the steering wheel is quickly rs, strong impacts occur on steering ARD STEERING FFT STEERING I RIGHT AND FFT STEERING I NO ↓	 Excessive stee Oil leakage; Insufficient circ 	ring wheel clearand cuit pressure. unning engine; top-u urk and drain the sy e and pump shaft	up the oil till the /stem.
lain hydraulic power st – Hard steering ir - Hard steering o – Hard steering v rotated; – When one stee wheel; I HA I I I I I I I I I I I I I	a right and left steering; 5 nly in left or right steering; 6 when the steering wheel is quickly 7 8 rs, strong impacts occur on steering RD STEERING RIGHT AND FT STEERING - YES →	 Excessive stee Oil leakage; Insufficient circ Check level with ru upper level rod ma Check suction pipe	ring wheel clearand cuit pressure. unning engine; top-u urk and drain the sy e and pump shaft	up the oil till the /stem.











TIGHTENING TORQUES

PART				
	HYDRAULIC POWER STEERING	ZF 8095	ZF 8098	TRW/TAS 55
Screw for securing hydraulic power steer- ing to support	Nm (kgm)	520 ± 52 (53 ± 5.3)	560 ± 17 (57 ± 1.7)	700 ± 3.5 (71 ± 0.3)
Nut for securing lever on shaft	Nm (kgm)	520 ± 52 (53 ± 5.3)	550 ± 55 (56 ± 5.6)	700 ± 3.5 (71 ± 0.3)
Screw for securing the support to chassis	Nm (kgm)	655 ± 65 (67 ± 6.6)	655 ± 65 (67 ± 6.6)	-
Nut for securing hydraulic steering limiter adjustment screws on hydraulic power steering	Nm (kgm)	15 ± 5 (1.5 ± 0.5)	15 ± 5 (1.5 ± 0.5)	75 ± 7.5 (7.3 ± 0.7)
Nut for securing M22x1.5 steering wheel	Nm (kgm)	73 ± 7 (7.4 ± 0.7)	73 ± 7 (7.4 ± 0.7)	73 ± 7 (7.4 ± 0.7)

DENOMINATION

TOOLS

TOOL No.


PII Driving steering wheel extractor. 99347042 99347068 Extractor for steering tie-rods head pins. 99374393 Tool with manometers for checking hydraulic ZF hydraulic power steering pressure. 99374398 Graded sector and index for checking steering wheel clearance (use with 99374393).


ZF HYDRAULIC POWER STEERING (8095-8098) Description

The ZF hydraulic power steering with ball circulation control and a compact shape, is mainly composed of a case and an embedded power steering mechanical part, of a control valve and an operating cylinder. As can be seen in Figure 4 and Figure 5, the rotating movement given to the steering wheel is transmitted without friction from power steering shaft to piston through an infinite sequence of balls and then transformed into an axial piston movement. The toothing of piston driven into case meshes into toothed-sector shaft toothing and makes it rotatingly move. The steering control arm fixed onto this shaft transmits the torque to wheel steering tie-rods. This solely mechanical steering movement is servo-assisted by pressurised oil supplied by an engine-operated ZF pump.

The control valve is composed of rotating distributor, supported on rollers in the worm screw and equipped with six control grooves on perimeter and of worm screw end supported in the steering case and equipped with six control grooves as well.

The rotating distributor at the same time operates also as lower connection element of steering shaft and rotates with the worm screw till the steering wheel is rotated.





CONTROL VALVE IN NEUTRAL POSITION

A. Case – B. Piston – C. Rotating distribution/steering shaft – D. Control case/worm screw – E. Torsion bar – F. Toothed-sector shaft – G. Pressure limiting valve – H. Re-suction valve – Q. Oil tank – R. ZF blade pump – S. Flow-rate limiting valve.

This synchronous rotary motion is due to the fact that the worm screw and the rotating distributor (C) are connected through a torsion bar (E, Figure 4) that keeps the control valve in a neutral position (rectilinear running) till the steering wheel is rotated.

When a torque is transmitted from steering wheel or steering wheels to worm screw, the torsion bar is subjected to a distortion in its elastic area, so that between rotating distributor (C) and worm screw end, that operates as control case (D), a relative movement occurs. This causes a distributor control grooves displacement with respect to worm screw ends grooves, so that the control valve passes from neutral position to operating position. The pressurised oil by the control valve (G) can now cross the open control grooves and penetrate into one of the two operating cylinder chambers, thereby assisting the steering movement through the pressure on one of piston surfaces.

If the hydraulic steering servoassistance is lacking, it is always possible to steer, even if with a higher effort on the steering wheel. To avoid that with the whole hydraulic pressure it is possible to steer till the right and left limit stop and in some cases damage the driving tie-rods, the ZF-Servocom is equipped with hydraulic steering limiting (Figure 6).

A re-suction valve (H, Figure 4) is assembled into the drive case with which return circuit oil can be sucked when it is necessary to steer without hydraulic servoassistance.

Moreover, according to the driving system execution, a pump delivery pressure limiting valve is also assembled according to a pre-established maximum value.

In the operating drawings (Figure 4 and Figure 5) the control valve and oil flow are schematically shown. The valve (S) is shown in a transverse section, so that its operation and connection to cylinder chambers can be seen.

The pressurised oil coming from the pump flows into the central annular groove of the control case and reaches, through three radial holes, the arcuate control grooves of the rotary distributor.

The mutual position of these grooves and the worm screw end grooves allows, in a neutral valve position, the pressurised oil to pass through admission ports till it reaches the equally arcuate grooves in the control case. These latter ones are connected through radial holes with both operating cylinder chambers.

Therefore, in the control valve neutral position, the pressurised oil can penetrate into the two operating cylinder chambers and also into the three return circuit grooves of the rotary distributor and from there reflow into the oil tank.


If the steering wheel is rotated rightwards, the rightward-threading piston moves rightward (Figure 5). Since this piston movement must be hydraulically servoassisted, the pressurised oil must penetrate into the left cylinder chamber. The three control grooves of the rotating distributor are displaced clockwise, so that the admission ports (K) are further opened to let the pressurised oil flow. The admission ports (J) are closed and stop the pressurised oil flow towards the axial grooves (O) of the control case.


Through the admission ports (K), the pressurised oil penetrates into the axial grooves (N) of the control case and from there, after having crossed the worm screw balls circulation threading, comes into the left cylinder chamber. The hydraulic servoassistance is then turned on, while the admission ports (I) closure prevents oil from returning into the tank. The oil being present in the right cylinder chamber is made go out and flows, through the open return ports (M), towards the return grooves (P) of the rotating distributor and returns, through its central hole, to the oil tank.

If the steering wheel is rotated leftwards (not shown), the operating cylinder piston is displaced leftwards. The distributor control grooves rotate counterclockwise. The pressurised oil penetrates through admission ports (J) into axial grooves (O) and then into right cylinder chamber.

The oil being present in the left cylinder chamber reflows into the tank through the ball circulation threading, the return ports (L), the return grooves (P) and the central rotating distributor hole.

Figure 5







Two valves (T and U) are axially arranged in the piston (B, Figure 6) for steering limiting. They are equipped with small spring-loaded pistons, whose stems project from right and left front piston surfaces.

If the piston is rightwards or leftwards displaced along limit stop direction, the stems can reach the adjustment screws (X and Y) in the case and cover, and move. Both limiting valves remain closed till one of the stems touches the adjustment screw. If for example the piston is rightward displaced (Figure 7), the right steering limiting valve (T) is opened by screw (X) before the piston reaches the limit stop.


In such a way, the pressurised oil being present in the left operating cylinder chamber can penetrate into its right chamber, flowing around the displaced valve piston (U) and through the open right valve (T), and then reach the return circuit. If the piston is leftwards displaced, the valve (U) is opened after the pre-established stroke and the pressurised oil in the right cylinder chamber can flow into the return cylinder, thereby reducing the pressure into the circuit chamber.

When the steering limiting valve is open, hydraulic servoassistance is strongly reduced and the steering wheel can be rotated only with a higher effort till wheel or drive stop.






501430 HYDRAULIC STEERING LIMITER ADJUSTMENT



I. Pump – 2. Tank – 3. Delivery piping – 4. Suction piping – 5. Reflow piping – 6. Manometers

X = Hydraulic steering limiting adjustment screw for rotating steering control arm along "A" direction.

Y = Hydraulic steering limiting adjustment screw for rotating steering control arm along "B" direction.



With the pair of manometers 99374393 already connected on hydraulic power steering delivery piping fitting, abut the front wheels onto rotating plates.

Place a spacer (f, Figure 16) of the shown thickness, see table enclosed below, between wheel stop parts (7).

f SPACER THICKNESS, WITHOUT CODE Front mechanical suspension

	Left wheel	Right wheel
No-loaded vehicle	3 mm	6 mm
Full-loaded vehicle	3 mm	3 mm
Front	pneumatic suspe	ension
No-loaded or	3 mm	3 mm
full-loaded vehicle		

Always with front wheels on rotating plates, start the engine up and keep it at a speed \leq 1550 revs/min.

Steer till the wheel stops against the spacer; then, go on steering the steering wheel for a few seconds exceeding in such a way the steering valve reaction force till the fixed stop is reached.

In such position the manometer will have to point out an oil pressure equal to $35 \div 50$ bar.

In order to correct different values, the lock nut is unscrewed and the screw of the corresponding valve (X or Y, Figure 17) is screwed or unscrewed.


During such phase, it is necessary to let the steering wheel free in order to avoid undesired pressure increases.

Then close the lock nut at a torque of 30 ± 5 Nm (3 ± 0.5 kgm); to adjust the second wheel stop, proceed in a similar way.

When the hydraulic power steering moves to A (Figure 17), adjust valve (X), when it moves to B (Figure 17), adjust valve (Y).

When the shown pressure is greater than 50 bar, it is necessary to (clockwise) screw the corresponding steering limiting valve.

When the shown pressure is lower than 35 bar, it is necessary to (counterclockwise) unscrew the corresponding steering limiting valve. At the end of the adjustment, check again the pressure drops along the two steering directions.



TRW TAS 55 HYDRAULIC POWER STEERING

Description

The ball-circulation control hydraulic power steering is essentially composed of a case in which manual steering mechanism, an hydraulic cylinder controlled by a rotating distributor valve, and hydraulic steering and safety limiting valves are housed.

The rotary motion impressed to steering wheel is transmitted from inlet shaft (7) to worm screw (3), through the torsion bar (5).

The worm screw (3) in turn, being connected by means of a set of balls (9) to the rack piston (12), transforms the rotary motion into an axial motion of this latter one.


The piston rack toothing (12) meshes into the toothed-sector shaft toothing and impresses a rotary motion thereto. The steering control arm fixed on this shaft transmits the motion to the wheel steering tie-rods.

This only-mechanical steering movement is servoassisted by the pressurised oil supplied to an engine-actuated blade pump.


If when steering the wheels are subjected to violent impacts, the force created by the same ones is transmitted through outlet shaft (11) to rack piston (12) and from it to worm screw (3). The internal hydraulic power steering system makes the rotary distributor valve (6) send highly pressurised oil into the cylinder chamber where such pressure can fight and absorb the given impact force. In this way no recoils are generated on the steering wheel.

The hydraulic power steering is equipped with an automatic air drain valve.

Rectilinear running neutral position




(6) connecting inlet shaft (5) to worm screw (7); under rectilinear running conditions, the valve (4) keeps open the communication between incoming oil canalisation from blade pump (2) and oil tank discharge (3) one.



If when rotating the steering wheel the transmitted torque is lower that the steering wheels resisting torque, torsion bar (7) in its elastic area is subjected to a distortion, so that the rotary distributor (4) integral therewith rotates with respect to valve body (5), passing from neutral condition to operating condition. Consequently, by closing the discharge canalisation and opening the control one, the pressurised oil enters the cylinder chamber affected by steering, generating the axial displacement of the rack piston (9). This hydraulic servoassistance action is kept till the hydraulic steering limiting valve (8) intervenes or the action on the steering wheel ceases that generated the torsion bar (7) distortion.

In this case, the rotary distributor (4) will be placed again in its neutral condition.

If the hydraulic servoassistance lacks, it is always possible to steer even if with a greater effort on the steering wheel.



HYDRAULIC STEERING LIMITATION

Figure 22 B L 3 4 5)(6)(7)(8) 2 3 9 2 X 77848 I. Steering hydraulic limiting screw - A and B steering limiting valve - 2. Small piston - 3. Bush - 4. Valve body - 5. Spring -6. Thrust sleeve - 7. Spacer pin - 8. Rack piston - 9. Cover - X. Left cylinder chamber - Y. Right cylinder chamber. The two steering limiting valves **A** and **B** are housed in the rack Consequently, the pressurised oil present in the affected piston (8) end. chamber will pass through the valve A or B opening in the opposite chamber and from there it will be discharged into the They are composed of a valve body (4) inside which valve tank. intervention adjustment bush (3) is placed, with a forced coupling, such valve in turn operating as small piston (2) seat. Small pistons (2) are kept in their closing position on bushes The figure shows the left steering condition. (3) by counter-spring (5). Valves A and B are kept closed till small pistons (2) stems are taken in contact by the rack piston displacement: with adjustment screw (1) if the displacement is towards When the hydraulic limiting valve is open, the hydraulic the left; servoassistance is highly reduced, and consequently it will be necessary to exert a higher force on the steering wheel in


Base - February 2003

order to continue to steer till it stops.

541430 HYDRAULIC POWER STEERING **DISCONNECTION AND RECONNECTION (TRW TAS 55)** For disconnecting and reconnecting the TRW TAS 55 hydraulic power steering, comply with the procedure disclosed for ZF 8095 - ZF 8098 hydraulic power steering. Automatic adjustment setting of hydraulic steering limitation for TRW TAS 55 hydraulic power steering Figure 23 2 60924 In case of an hydraulic power steering detached from the vehicle, the outlet shaft rotation must not exceed 29° (equal to 1.3 revolutions of the inlet shaft (1)) with respect to center drive position marked by references (2). The adjustment is carried out after having assembled the hydraulic power steering on the vehicle, with unloaded vehicle

and lifted front wheels. Moreover both right steering and left

steering must be performed operating as follows.



Make sure that the gearbox is idle.

Start the engine up and keep it at a rotation speed that is \leq 1500 revs/min.

Rotate the steering wheel along a direction, applying thereto a 34 Nm torque till the stop screw (2) assembled on the stub axle (3) is taken in contact with front axle (1).

In this way bush (4, Figure 18) will go back with respect to valve body (5, Figure 18) of affected steering limiting valve. The position that bush (4, Figure 18) will get will make the hydraulic pressure discharged inside the affected chamber before screw (2, Figure 18) comes in contact with front axle (1), safeguarding hydraulic system components.

Repeat the same procedure steering to the opposite side.

Automatic adjustment check


The automatic adjustment check is carried out with full-loaded vehicle moving and at low speed, both in right and in left steerings, operating as follows.

Rotate the steering wheel along a direction till the absence of hydraulic interlock is detected.

From this condition verify that the steering wheel rotation to reach the steering stop (screw (2) in contact with front axle (3)) is included between 60° and 120°.

Repeat the same procedure by steering along the opposite direction.

When detecting different values, operate as described in the following chapter "Manual hydraulic drops adjustment".



501430 **AIR DRAIN FROM HYDRAULIC POWER STEERING CIRCUIT**

Carry out the air drain from hydraulic power steering circuit proceeding as follows:

- fill with required oil (TUTELA GI/A) the circuit tank;
- rotate the engine with the starter and top-up the oil continuously in order to avoid that the pump sucks air. Top-up the oil till its level does not go below the upper rod mark;
- start the engine up and rotate it at minimum speed checking that the oil level does not go below the upper rod sign;
- rotate the steering wheel many times from stop to stop so that air cannot go out of the hydraulic power steering cylinder till no air bubbles are noted incoming into the tank:
- accelerate the engine at its maximum, stop it and check that the oil level in the tank does not rise more than | + 3 cm.

Hydraulic power steering oil level restoration


The oil level check must be carried out with moving engine verifying that the level corresponds to the "MAX" indication included on the tank side.

Under off engine conditions, the level, due to the backup of oil contained in the upper tank part, will be able to exceed the "MAX" indication by two millimeters.

MEASURE OF DRIVE CASE 501430 **CLEARANCES DETECTED ON STEERING WHEEL**

Check that there are no mechanical clearances in the related connecting tie-rods.

Lock the left wheel under straight running position with suitable shims on coupling bar, lift the front axle.



Arrange on the windscreen, through a suction cup, a fixed index (2) and the millimeter sector (1) on the steering wheel. Arrange the pair of manometers 99374393 (3) from 0 to 10 and from 0 to 160 bar, mutually connected by means of a short-circuit valve.

Connect the piping of the pair of manometers on the hydraulic power steering oil delivery piping fitting. Possibly restore the oil level.

Start the engine up at its minimum speed and read on the manometer from 0 to 10 bar the pressure value at that time. Slowly rotate the steering wheel leftwards till the previously-read pressure value is increased by 1 bar, keep the steering wheel unmoving and mark on the millimeter scale 99374398 the reached value in mm.

Rotate the steering wheel rightwards till a I bar pressure increase is again obtained; read what the scale 99374398 is marking, sum the two left steering plus right steering values: the sum must not exceed 40 mm. Lower the front axle.

MAXIMUM PRESSURE CHECK IN HYDRAULIC POWER STEERING SYSTEM

With the pair of manometers 99374393 already previously connected and the wheel on drive side locked with suitable shims, start the engine up at its minimum speed, steer along one direction with an effort of $10 \div 20$ kg on the steering wheel and measure the pressure on the manometer from 0 to 160 bar.

Carry out the same operation by steering along the opposite direction; if the detected values are different from the required ones, search for their cause.



The maximum pressure value can be detected by the ZF or TRW plate applied onto the drive case.

SECTION 11

Pneumatic System – Brakes

		Page
S	APHIC SYMBOLS FOR HYDROPNEUMATIC SYSTEMS DIAGRAMS MISCELLANEOUS AND GENERATORS)	5
	APHIC SYMBOLS FOR HYDROPNEUMATIC SYSTEMS DIAGRAMS (VALVES)	6
S	APHIC SYMBOLS FOR HYDROPNEUMATIC YSTEMS DIAGRAMS TANKS AND ACCUMULATORS)	12
S	APHIC SYMBOLS FOR HYDROPNEUMATIC YSTEMS DIAGRAMS CONVERTERS, CYLINDERS AND CALIPERS)	13
S	APHIC SYMBOLS FOR HYDROPNEUMATIC SYSTEMS DIAGRAMS CYLINDERS AND CALIPERS)	14
S	APHIC SYMBOLS FOR HYDROPNEUMATIC YSTEMS DIAGRAMS COUPLING HALF-JOINTS AND HEADS) .	15
S	APHIC SYMBOLS FOR HYDROPNEUMATIC YSTEMS DIAGRAMS SIGNALING DEVICES AND SWITCHES)	17
	APHIC SYMBOLS FOR HYDROPNEUMATIC SYSTEMS DIAGRAMS (BRAKES)	18
PIPE	es and fittings	19
	In general	19
	Rigid pipings reflanging	19
	Rigid pipings bending	20
	Rigid pipings cutting	20
	Flexible pipings replacement with threaded fittings	21
	Flexible pipings replacement with quick connection fittings	22
BRA	AKING SYSTEM	24
	Principle diagram for single vehicles (Models 110 EL 120 EL.)	24
	Principle diagram for vehicles adapted for towing (Models 110 EL 120 EL.)	25
	Principle diagram for single vehicles (Models 120 E 130 E 150 E)	26

		Page
	Principle diagram for vehicles adapted for towing (Models 120 E 130 E 150 E.)	27
	Principle diagram for single vehicles (Model 180 E)	28
	Principle diagram for vehicles adapted for towin (Model 180 E.)	g 29
	Principle diagram for single vehicles (Model 260 E.)	30
	RANGEMENT ON A VEHICLE DF MAIN BRAKING SYSTEM COMPONENTS	31
DES	SCRIPTION	32
	Service braking	32
	Safety braking	32
	Engine brake	32
	Operation	32
	Parking braking	32
BR/	AKES	32
	Front brakes	32
	Rear brakes	32
DIA	GNOSTIC	33
TIG	HTENING TORQUES	44
ТО	OLS	46
	CIFICATIONS AND DATA - PNEUMATIC	53
SPE	CIFICATIONS AND DATA - BRAKES	58
CH (ECKS OF MAIN BRAKE SYSTEM COMPONENTS	60
MA	IN BRAKE SYSTEM COMPONENTS	63
СО	MPRESSOR	63
	Diagnostics	63
A.P.	U. (AIR PROCESSING UNIT)	64
	Operation	65
	Diagnostics	66
EN	GINE BRAKE SWITCH	67

	Page
ENGINE BRAKE SOLENOID VALVE	67
ENGINE BRAKE CONTROL	
OPERATING CYLINDER	67
MANUAL DISCHARGE VALVE	67
SAFETY VALVE (OPTIONAL)	68
DUPLEX DISTRIBUTOR	68
Unbraking	69
Diagnostics	69
PRESSURE RELIEF VALVE	70
Operation	70
Pressure limiting	70
Bench calibration	70
Diagnostics	70
RELAY VALVE	71
Diagnostics	71
CHECK VALVE	71
Operation	71
PARKING BRAKE CONTROL MANUAL DISTRIBUTOR (SINGLE VEHICLES)	72
Diagnostics	72
PARKING BRAKE CONTROL MANUAL DISTRIBUTOR	
(VEHICLES ADAPTED FOR TOWING)	73
Diagnostics	73
QUICK DISCHARGE VALVE	74
TRIPLE CONTROL SERVODISTRIBUTOR	74
Predominance adjustment	74
Diagnostics	74
COUPLING HEADS	75
Operation	75
PRESSURE PLUG VALVE	75

		Page
	MBRANE BRAKE CYLINDER FOR DISC BRAKES AND DRUM BRAKES)	75
CO	MBINED BRAKE CYLINDER	76
	Combined cylinder emergency unbraking device	76
	Repair interventions	76
	Diagnostics	76
ABS	S SYSTEM WITH EBL FUNCTION	77
	"ABS" Anti-Lock Brake System	77
	''EBL'' (Electronic Brake Limiter) anti-skid device	77
ELE	CTRONIC UNIT	77
	Operation	77
REV	OLUTIONS SENSORS	77
PHO	ONIC WHEELS	77
	Operation	77
ELE	CTRO-PNEUMATIC VALVE	78
	Operation	78
BR/	AKE REPAIRS MODELS ML 110 EL / 120 EL)	79
	Front Brakes (Brake calipers of the PAN 17 type)	79
	Rear Brakes (Brake calipers of the PAN 17 type)	79
	Description	79
	Brake locking system and brake operation	79
	Automatic braking gaskets wear recovering device	79
	Efficiency check for braking gaskets/brake disc wear recovering device	81
	Braking gaskets replacement	81
	Checks	81
	Brake calipers disconnection and reconnection	82
	Disconnection	82
	Reconnection	82

		Page
BR/	KE CALIPERS REVISION	82
	Disassembly	82
	Check of component parts	83
	Assembly	83
BRA	ake discs revision	86
	Brake discs turning and grinding	86
BRA	KE REPAIR	87
	Front brakes (KNORR brake caliper, SB6 type)	87
	Front and rear brakes (Brake caliper KNORR SN6-SN7 type)	88
	Operation	89
CH	ECKS	89
	Checking the automatic play recovery system efficiency	89
	Check of braking gaskets thickness	90
REA	AR BRAKES REVISION	92
	Braking gaskets replacement	92
	Brake calipers disconnection and reconnection	94
	Disconnection	94
	Reconnection	95
	Wheel hubs disconnection and reconnection .	95
	Disconnection	95
	Reconnection	95
BRA	AKE CALIPERS REVISION TYPE SB6	96
	Disassembly	96
	Cleaning and check of component parts	97
	Assembly	97
BRA	AKE CALIPER OVERHAUL TYPE SN6-SN7 .	99
	Disassembly	99
	Component part cleaning and check	100
	Assembly	100

	Page
REAR DISC BRAKES REVISION (12-18 t)	102
BRAKE DISCS REVISION	102
BRAKE DISCS TURNING AND GRINDING	102
REAR DRUM BRAKES - MODEL 260E28KE	103
Brake position with Hendrickson suspension .	103
REAR BRAKES REVISION (26 t)	104
Disassembly	104
Check of component parts	106
DRUM TURNING	107
BRAKING GASKETS REPLACEMENT	108
BRAKING GASKETS TURNING	108
Assembly	109

GRAPHIC SYMBOLS FOR HYDROPNEUMATIC SYSTEMS DIAGRAMS (MISCELLANEOUS AND GENERATORS)

DENOMINATION	SYMBOL	
HYDRAULIC FLOW	◄	
PNEUMATIC FLOW	\triangleleft	
ELECTRIC DUCT	4	
POSSIBLE ROTATION		
CROSSING OF CONNECTED DUCTS	•	
PRESSURE CONTROL TAP	¥	
QUICK CONNECTION FITTING	¥	
COCK		
COCK WITH DISCHARGE		
SILENCER		
COMPRESSOR	0-2	
ENERGY SAVING COMPRESSOR		
VACUUM PUMP	3	
HYDRAULIC PUMP	0-2	
MANUAL HYDRAULIC PUMP		Ţ

DENOMINATION	SYM	BOL
Condensate separator	\bigwedge	
FILTER	1 - 2	
DRIER	1 - 2	
DRIER	$21 \qquad 4 \qquad 1 \\ 22 \qquad 1 \qquad 1$	
DRIER WITH INTEGRATED REGULATOR		
AUTOMATIC CONDENSATE DRAIN VALVE	\diamond	
DRIVEN CONDENSATE DRAIN VALVE		
MANUAL CONDENSATE DRAIN VALVE	\diamond	
DRIVEN ANTIFREEZER		
AUTOMATIC ANTIFREEZER	I 2	
PRESSURE REGULATOR WITH INDEPENDENT CIRCUIT		
PRESSURE REGULATOR	1 - 21	
PRESSURE REGULATOR		
PRESSURE REGULATOR (GOVERNOR)	ı — 2	
PRESSURE LIMITING VALVE	1 - 2	S.

DENOMINATION	SYM	BOL
PROPORTIONAL REDUCTION VALVE	1 - 2	
ADAPTER VALVE	1 - 2	
4-CIRCUIT PROTECTION VALVE		
3-CIRCUIT PROTECTION VALVE		
2-CIRCUIT PROTECTION VALVE		
AIR INTAKE VALVE WITHOUT RETURN	I — 2	
AIR INTAKE VALVE WITH LIMITED RETURN	I — 2	
SAFETY VALVE		
CHECK VALVE		Œ
CHECK VALVE		
Double stop valve		
DOUBLE DIFFERENTIAL STOP VALVE	U M-< \$	
THROTTLING VALVE WITH QUICK RETURN		
THROTTLING VALVE		()A

32783 32784 32785

QUICK EXHAUST VALVE		A SEA A
	$[] \\ \forall$	
BRAKE CONTROL DISTRIBUTOR	11- A - 21 12- P - 22	
BRAKE CONTROL DISTRIBUTOR		
BRAKE CONTROL DISTRIBUTOR		
PARKING BRAKE CONTROL DISTRIBUTOR		
PARKING BRAKE CONTROL DISTRIBUTOR		
BRAKE DISTRIBUTOR		
CONTROL DISTRIBUTOR		
CONTROL DISTRIBUTOR		
DECELERATOR CONTROL DISTRIBUTOR	I3 - R - 23	
SERVODISTRIBUTOR		

DENOMINATION	SYM	BOL
SERVODISTRIBUTOR		
SERVODISTRIBUTOR FOR MONO-DUCT		
TRAILER TRIPLE BRAKE CONTROL VALVE	$41 - \frac{42}{1} - 43$	
TRAILER TRIPLE BRAKE CONTROL VALVE WITH EMBEDDED SERVOSWITCH	$41 - \frac{42}{1} - 43$ $11 - 1 - 22$ $12 - 1 - 22$	
BRAKE CORRECTOR		SP
DOUBLE BRAKE CORRECTOR		ME
BRAKE CORRECTOR WITH BY-PASS		
BRAKE CORRECTOR WITH INTEGRATED RELAY		
BRAKE CORRECTOR WITH INTEGRATED RELAY WITH PNEUMATIC CONTROL		



SYM	IBOL
1-2-2	
	F\$
	FÖ
	+ + + + + + + + + +

SYMBOL 42 41 21 - 22 3 E &
41 € _21 _22
_21 _22
A A
- 2
- 21 - 22
HZ2 HZI HR
-2

GRAPHIC SYMBOLS FOR HYDROPNELIMATIC SYSTEMS DIAGRAMS

DENOMINATION	SYMBOL	
Compressed Air Tank		
RAKE FLUID TANK		
AIR SPRING		\square
AIR SPRING		

GRAPHIC SYMBOLS FOR HYDROPNEUMATIC SYSTEMS DIAGRAMS (CONVERTERS, CYLINDERS AND CALIPERS)

DENOMINATION	SYM	BOL
VACUUM SERVOBRAKE		
VACUUM SERVOBRAKE		
DOUBLE CIRCUIT MASTER CYLINDER		
SIMPLE CIRCUIT MASTER CYLINDER	- -	Ţ Ţ ţŢ
PNEUMO-HYDRAULIC CONVERTER		
PNEUMO-HYDRAULIC CONVERTER		
HYDRAULIC BRAKE CYLINDER		
OPERATOR CYLINDER		
BRAKE CYLINDER	-	
SPRING CYLINDER		
COMBINED BRAKE CYLINDER		
FIXED DISC BRAKE CALIPER		

GRAPHIC SYMBOLS FOR HYDROPNEUMATIC SYSTEMS DIAGRAMS (CYLINDERS AND CALIPERS)

DENOMINATION	SYM	BOL
FLOATING DISC BRAKE CALIPER		
FLOATING DISC BRAKE CALIPER WITH PARKING		
MECHANICAL FLOATING DISC BRAKE CALIPER		
SERVOCLUTCH		
SERVOCLUTCH		

SYMBOL DENOMINATION Α "ISO" HALF-COUPLING Μ ISO VERSION Α "ISO" HALF-COUPLING Μ VERSION WITH ISO JOINTS Α "CUNA" HALF-COUPLING В ITALIAN VERSION "CUNA" HALF-COUPLING "NATO" HALF-COUPLING NATO VERSION

GRAPHIC SYMBOLS FOR HYDROPNEUMATIC SYSTEMS DIAGRAMS (COUPLING HALF-JOINTS AND HEADS)

SYMBOL DENOMINATION 5 HALF-COUPLING Z VERSION WITH MONO-DUCT Α Μ HALF-COUPLING VERSION WITH MONO-DUCT 12 HALF-COUPLING VERSION WITH MONO-DUCT -- --12 Α M HALF-COUPLING VERSION WITH MONO-DUCT

GRAPHIC SYMBOLS FOR HYDROPNEUMATIC SYSTEMS DIAGRAMS (COUPLING HALF-JOINTS AND HEADS)

GRAPHIC SYMBOLS FOR HYDROPNEUMATIC SYSTEMS DIAGRAMS (SIGNALING DEVICES AND SWITCHES)

DENOMINATION	SYMBOL	
MANOMETER	\bigcirc	
MANOMETER	\bigotimes	
PRESSURE TRANSMITTER		
LAMP	\otimes	
MECHANICAL CONTROL SWITCH		
PRESSURE SWITCH		
LOW PRESSURE SWITCH		ê
HOOTER		
SENSOR		- Comp

DENOMINATION	SYM	BOL
SIMPLEX HYDRAULIC BRAKE		
DUPLEX HYDRAULIC BRAKE		
DOUBLE-SERVO HYDRAULIC BRAKE		
DOUBLE-SERVO HYDRAULIC BRAKE WITH PARKING		
SIMPLEX WEDGE BRAKE		
DOUBLE-DUPLEX WEDGE BRAKE		


799512 PIPINGS AND FITTINGS

In general

Hydraulic system pipings for industrial vehicles are currently of two types:


- Flexible ones made of polyamide with single-layered or double-layered structure and in the following diameters (Ø 6-8-10-12-16 mm) equipped with spares in meters
- □ Rigid metal pipings in the following diameters (Ø 4.75-6.35-8-10-12 mm). Pipings from Ø 4.75 to Ø 10 mm are supplied as spares in straight 4-5-6 m crop ends, while those exceeding 10 mm are supplied as spares already cut, bent and reflanged.

Rigid pipings reflanging




RIGID PIPINGS REFLANGING REPRESENTATION


Reflanging type A



Arrange on a press 99386523 (3) small blocks (1) so that the punched numbers, showing the piping number to be worked, are facing the matrix die (2). The choice of the matrix die (2) depends on the diameter of the piping to be reflanged. Moreover, on every matrix die (2) the diameter of the piping is punched for which the same one can be used.




Burr piping (1), insert union (2) and place it between small blocks (3) abutting pin (5). Lock piping (1) with screw (4).




Take back pin (4) to its neutral position. Screw screw (1) till matrix die (2) comes to abut against small blocks (3) thereby shaping the piping (5) end.


Reflanging type B



Assemble matrix die (2) on press 99386523 (1). For the reflanging process comply with what has been stated above for reflanging type A.

Reflanging type C






- Carry out abutment ring reflanging upon assembly on the vehicle or work bench on a fitting.
- ☐ The exerted pressure and the final distance from front pressure ring edge to reinforcement bush edge must be those mentioned in the table below.

In case of a bad assembly, use the pipe after having extracted bush and abutment ring.

	Pipe mm	Distance between bush edge and ring mm (*)	Assembly pressure N/mm ²
Double-layered	6 × 1	to .5	0.040
	8 × 1	2 to 2.5	0.050
	10 x 1.5	2 to 2.5	0.050
Single-layered	12 × 1.6	2 to 2.5	0.060
	16 × 2.34	3 to 3.5	0.060

(*) See reference h, Figure 14.



 Reinforcement bush - 2. Pressure ring - 3. Nut - 4. Fitting -5. Pipe - h. Distance between bush edge and ring edge (see table).

Insert the thereby-prepared piping end into the fitting body till the reinforcement bush flange rests within the suitable seat:

□ For closing the nut on the fitting, initially screw it manually and then complete the tightening with a suitable box wrench inserted into the dynamometric wrench, to be calibrated according to the required tightening torque.

rake groove obtained in the flange;

Assembly of piping on vehicle is carried out by taking into account some important solutions:

Bendings must comply with minimum radiusses, in order to avoid throttlings;


Pipings diameter mm	Minimum bending radius mm
6 x	≈ 40
8 x I	≈ 50
10 × 1.5	≈ 60
2 x .6	≈ 75
16 × 2.34	≈ 100

Make sure that pipings are not in contact with sharp edges or with cutting metallic parts or with heat sources, but that are distant therefrom by a minimum safety distance of 15 mm.

- Moreover, when crossing chassis longitudinal members or metallic parts, check that passage holes are coated with rubber fairlead rings and that these latter ones are in good conditions;
- Avoid that the pipe slides along cutting edges that would risk to create nickings;
- Having to fix the piping onto already existing ducts, take into account the supplementary heat to which it can be subjected (hydraulic power steering duct): in such case, the piping must be protected with guards;
- At the end of the connection, verify that the piping, between keying and securing, is not stretched, but must be slightly loosened to recover higher temperature variations, particularly for short lengths;

Before assembling, accurately clean the pipings by blowing compressed air in order to guarantee system operation;

Figure 15




Protect the pipes in case of grinding or welding operations on the vehicle; for such purpose, an adhesive plate is applied in the cabin and shows the precautions to be observed with utmost care to avoid damages.

> For better safety and work comfortability, it is advisable to detach the pipings during such operations.

At the end of the assembly, check the perfect seal of all gaskets (unions, fittings, etc.).

Flexible pipings replacement with quick connection fittings


Rotating fittings:



pneumatic valve and lock it at the tightening torque shown in the table.


Swinging fittings:


Figure 17



Rotating and swinging fittings:

FITTING THREADING	TIGHTENIG TORQUE (Nm + 10%)
M 10 x 1.0 mm	22
M 12 x 1.5 mm	24
M 14 x 1.5 mm	28
M 16 x 1.5 mm	35
M 22 x 1.5 mm	40





SEALING RINGS
DIMENSIONS
10.1 × 1.6
I I.0 × 2.0
-
15.0 × 2.0
-



Every time a piping is detached from a quick connection fitting, it is necessary to replace the fitting itself. Quick connection fittings are supplied complete as spares.



Quick connection and threaded fittings, as well as flexible pipings used with quick connection fittings and flexible pipings used with threaded fittings, are not interchangeable.


16

27.1


24

BRAKING SYSTEM






Single-cylinder 225 cm³ (359 cm³ optional) compressor - 2. 0.26l silencer - 3. Air Processing Unit - 4. 15l front axle air tank - 6. Manual condensate exhaust valve - 7. Safety valve (optional) - 8. Engine brake control button - 9. Engine brake control solenoid valve - 10. Engine brake valve control cylinder - 11. Relay valve - 12. Phonic wheel - 13. Revolutions sensor - 14. Rear axle brake disc - 15. - Rear axle brake caliper - 16. Combined cylinder - 17. Parking relay valve - 18. Inserted parking brake signalling low pressure switch - 19. Rear axle ABS solenoid valve - 20. Manual parking control distributor - 21. Manual safety distributor (optional) - 22. Duplex distributor - 23. Front axle ABS solenoid valve - 24. Front axle brake disc - 25. Front axle brake caliper - 26. Front axle membrane cylinder - 27. Revolutions sensor - 28. Phonic wheel - 29. Quick discharge valve - 30. ABS electronic unit - 31. Parking brake luminous signaller - 32. STOP lights - 33. Front axle/rear axle manometer - 34. STOP lights relay control switch - 35. EDC inserted brake signalling switch - 36. Pneumatic control plug.



Principle diagram for vehicles adapted for towing (Models 110 EL. - 120 EL.)

19. Triple-control trailer servodistributor - 20. Rear axle brake disc - 21. - Rear axle brake caliper - 22. Combined cylinder - 23. Parking relay valve - 24. Inserted parking brake signalling low pressure switch - 25. Manual parking control distributor - 26. Manual safety distributor (optional) - 27. Unidirectional parking system valve - 28. Duplex distributor - 29. Front axle ABS solenoid valve - 30. Front axle brake disc - 31. Front axle brake caliper - 32. Front axle membrane cylinder - 33. Revolutions sensor - 34. Phonic wheel - 35. Quick discharge valve - 36. ABS electronic unit - 37. Parking brake luminous signaller - 38. STOP lights - 39. Front axle/rear axle manometer - 40. Trailer section low pressure luminous signaller (optional) - 41. STOP lights relay control switch - 42. EDC inserted brake signalling switch - 43. Trailer low pressure switch (optional) - 44. Pneumatic control plug.




Principle diagram for single vehicles (Models 120 E. - 130 E. - 150 E.)

84011

I. Single-cylinder 225 cm³ (359 cm³ optional) compressor - 2. 0.26l silencer - 3. Air Processing Unit - 4. 15l front axle air tank - 5. 151 Axle air reservoir - 6. Manual condensate exhaust valve - 7. Safety valve (optional) - 8. Engine brake control button - 9. Engine brake control solenoid valve - 10. Engine brake valve control cylinder - 11. Relay valve - 12. Rear axle phonic wheel - 13. Revolutions sensor - 14. Rear axle drum brake - 15. - Rear axle combined cylinder - 16. Parking relay valve - 17. Inserted parking brake signalling low pressure switch - 18. Rear axle ABS solenoid valve - 19. Manual parking control distributor - 20. Manual safety distributor (optional) - 21. Duplex distributor - 22. Front axle ABS solenoid valve -23. Front axle brake disc - 24. Front axle brake caliper - 25. Front axle membrane cylinder - 26. Revolutions sensor -

27. Phonic wheel - 28. Quick discharge valve (optional Proportional reduction valve) - 29. ABS electronic unit -30. Parking brake luminous signaller - 31. STOP lights - 32. Front axle/rear axle manometer - 33. STOP lights relay control


switch - 34. EDC inserted brake signalling switch - 35. Pneumatic control plug.



Principle diagram for vehicles adapted for towing (Models 120 E., - 130 E., - 150 E.,)

Single-cylinder 225 cm³ (359 cm³ optional) compressor - 2. 0.26l silencer - 3. Air Processing Unit - 4. 15l rear axle air tank - 5. 15l front axle air tank - 6. Manual condensate exhaust valve - 7. 15l trailer parking and reloading air tank Trailer system pressure reducer - 9. Engine brake control button - 10. Safety valve (optional) - 11. Engine brake control solenoid valve - 12. Engine brake valve control cylinder - 13. Trailer braking control pressure switch (optional) - 14. Relay valve - 15. Rear axle ABS solenoid valve - 16. Phonic wheel - 17. Revolutions sensor - 18. Trailer coupling half-joints - 19.


Triple-control trailer servodistributor - 20. Rear axle drum brake - 21. Rear axle combined brake cylinder -22. Parking relay valve - 23. Inserted parking brake signalling low pressure switch - 24. Manual parking control distributor -25. Manual safety distributor - 26. Unidirectional parking system valve - 27. Coaxial duplex distributor - 28. Front axle ABS solenoid valve - 29. Brake disc - 30. Front axle brake caliper - 31. Front axle membrane cylinder - 32. Revolutions sensor -33. Phonic wheel - 34. Quick discharge valve (optional Proportional reduction valve) - 35. ABS electronic unit - 36. Parking brake luminous signaller - 37. STOP lights - 38. Front axle/rear axle manometer - 39. Trailer section low pressure luminous signaller (optional) - 40. STOP lights relay control switch - 41. EDC inserted brake signalling switch - 42. Trailer low pressure switch (optional) - 43. Pneumatic control plug.



 Single-cylinder 359 cm³ compressor - 2. 0.26l silencer - 3. Air Processing Unit - 4. 20l rear axle air tank - 5. 20l front axle air tank - 6. Manual condensate exhaust valve - 7. Safety valve (optional) - 8. Engine brake control button - 9. Engine brake control solenoid valve - 10. Engine brake valve control cylinder - 11. Relay valve - 12. Rear axle phonic wheel -13. Revolutions sensor - 14. Rear axle brake disc - 15. Rear axle brake calliper - 16. - Rear axle combined cylinder -


17. Relay valve - 18. Inserted parking brake signalling low pressure switch - 19. Rear axle ABS solenoid valve - 20. Manual parking control distributor - 21. Manual safety distributor (optional) - 22. Duplex distributor - 23. Front axle ABS solenoid valve - 24. Front axle brake disc - 25. Front axle brake caliper - 26. Front axle membrane cylinder - 27. Revolutions sensor - 28. Front axle phonic wheel - 29. Quick discharge valve (optional Proportional reduction valve) - 30. ABS electronic unit - 31. Parking brake luminous signaller - 32. STOP lights - 33. Front axle manometer - 34. STOP lights relay

control switch - 35. EDC inserted brake signalling switch - 36. Pneumatic control plug.




Principle diagram for vehicles adapted for towing (Model 180 E..)

Single-cylinder 359 cm³ compressor - 2. 0.26l silencer - 3. Air Processing Unit - 4. 20l rear axle air tank - 5. 20l front axle air tank - 6. Manual condensate exhaust valve - 7. 15l trailer parking and reloading air tank - 8. Trailer system pressure reducer - 9. Engine brake control button - 10. Safety valve (optional) - 11. Engine brake control solenoid valve - 12. Engine brake valve control cylinder - 13. Trailer braking control pressure switch (optional) - 14. Relay valve - 15. Rear axle ABS solenoid valve - 16. Phonic wheel - 17. Revolutions sensor - 18. Trailer coupling half-joints - 19. Triple-control trailer servodistributor - 20. Rear axle disc brake - 21. Rear axle drum brake - 22. Rear axle combined brake cylinder - 23. Relay valve - 24. Inserted parking brake signalling low pressure switch - 25. Manual parking control distributor - 26. Manual safety distributor (optional) - 27. Unidirectional parking system valve - 28. Duplex distributor - 29. Front axle ABS solenoid valve - 30. Front axle brake disc - 31. Front axle brake caliper - 32. Front axle membrane cylinder - 33. Revolutions sensor - 34. Phonic wheel - 35. Quick discharge valve - 36. ABS electronic unit - 37. Parking brake luminous signaller - 38. STOP lights - 39. Front axle/rear axle manometer - 40. Trailer section low pressure luminous signaller (optional) - 41. STOP lights relay control switch - 42. EDC inserted brake signalling switch - 43. Trailer low pressure switch (optional) - 44. Pneumatic control plug.







 Phonic wheel - 2. Check valve - 3. Engine brake solenoid valve - 4. A.P.U. - 5. Relay valve - 6. Phonic wheel -7. Wheels revolution sensors - 8. Combined brake cylinder - 9. Triple-control servodistributor - 10. Coupling heads -11. Parking - trailer braking tank - 12. Hydraulic pressure control plug - 13. Wheels revolutions sensor - 14. Phonic wheel -15. Rear disc brake assembly - 16. Quick discharge valve - 17. Pressure relief valve - 18. Electro-pneumatic valve -19. Air tanks - 20. Pressure control plug - 21. Pressure relief valve - 22. Front disc brake assembly - 23. Membrane brake cylinder - 24. Wheels revolutions sensor - 25. Phonic wheel - 26. Engine brake operating cylinder - 27. Engine brake control button - 28. Duplex distributor - 29. ABS elecronic unit - 30. Single-cylinder compressor - 31. Parking brake distributor - 32. Trailer slowing-down control distributor (optional) - 33. Wheels revolutions sensor.

DESCRIPTION

Service braking

With pedal, of the electrically-controlled pneumatic type, operating on all wheels and on trailer or semitrailer.

It is composed of two independent sections, one for activating front axle braking elements, the other section for activating rear axle braking elements.

A third section, interlocked with the two distributor sections, is provided for braking the trailer. The duplex distributor with electric transmitter checks the two independent sections and the trailer control servodistributor in turn checks the above interlocked section. The pneumatic system sectioning enables, in case of failure of a section, the efficiency of the other ones.

Safety braking

The safety braking allows reducing vehicle running speed and stop it in a safety space, also when a braking system failure occurs.

It must be meant as partial service braking that, due to the double circuit, anyway operates on one of the two axles.

Engine brake

The "engine brake" system, being of the electric type, is managed by the EDC unit. The exhaust brake can be controlled in different ways, which can be selected by means of the special switch available on the dashboard or the pedal on the floor to be used with the different types/conditions of the road.

Actuation can be controlled directly through the pedal available on the floor.

When the selector is set to position I, the exhaust brake is linked to the accelerator pedal and is operated when the accelerator is released.

When the selector is set to position 2, engine brake/service brake are coupled, with operation starting from first pedal stroke length and keeping the position.

Every time the engine brake is inserted, the signalling panel warning light turns on.

The insertion of engine brake together with accelerator pedal disables all adjustment operations connected to Cruise Control.

Operation

Independently from the type of selection being set, the EDC electronic unit drives, through connector B pin 11, the engine brake solenoid valve.

This one, by switching its state from N.C. to N.O., allows the engine oil to flow to operating cylinder which, in turn, operating on the engine exhaust throttle valve, allows braking it.

Parking braking

It is composed of the pneumatic control of the manual distributor, of a spring cylinder that operates on rear wheel brakes by locking them.

This system, in case the supply is lacking, automatically brakes the vehicle.

BRAKES

Front brakes

Front brakes are of the disc type. Discs are keyed on wheel hubs and equipped with venting fins that allow lowering the high temperature that develops under the braking action. Braking gaskets are equipped with a wear signaller connected to a warning light placed on the dashboard, which signals gasket wear.

ABS device phonic wheels are keyed-in on wheel hubs.

Front axle 5845

type: WABCO (PERROT) PAN 17 - Ø 330x34

Front axle 5842/5 - 5851/5

☐ type: KNORR SB6 - Ø 377x45

Front axle 5871/5

type: KNORR SN7 - Ø 432x45

Rear brakes

Rear brakes are:

disc type on rear axle MS08-125, MS13-144, MS13-164 MS13-165

Drum brakes on tandem axle SP 145 E

In drum brakes, every braking assembly is composed of a body in which adjustment, control pins and wedge units are housed. Wedge units are actuated by cylinder stem in turn actuated by compressed air.

Wedge unit rollers along their stroke generate control pin expansion that, winning jaws return spring resistance, approach jaws to drum dampening the brakings. Adjustment and control pins are made integral with the brake body by two pins that are inserted in a side milling. When the braking action ceases, air pressure is lacking in the combined brake cylinder membrane section, and consequently the jaws return spring and wedge unit return spring actions take care of returning the wedge units into their starting position.

Braking gaskets are equipped with a wear signaller.

ABD device phonic wheels are an integral part of brake disc on H127E rear axle, while are keyed-in on wheel hubs in the other rear axles with drum brake.

Rear axle MS08-125

type: WABCO (PERROT) PAN 17 - Ø 330x34

Rear axle MS10-144; MS10-164


type: KNORR SN6 - Ø 377x45

Rear axle MSI 3-165


☐ type: KNORR SN7 - Ø 432x45


Rear axle SP145E

☐ type: Duoduplex - Ø 381×178





(continues)








(continues)




















TIGHTENING TORQUES

PART	TORQUE		
	Nm	(kgm)	
_			
Compressor	075 05	(2.2	
Head clamping screws	27.5 ± 2.5	(2.8 ± 0.25)	
Connecting rods caps clamping screws	3+3	(1.3+0.3)	
Front brakes (Front axle 5845)			
Ring nut for securing wheel hub bearings	388.5 ± 18.5	(39.6 ± 1.8)	
Cylindrical-head screw with embedded hexagon for bearings adjustment clamp	27.5 ± 2.5	(2.8 ± 0.2)	
Self-locking hexagonal-head screw for securing brake calipers	88 ± 8	(19 ± 1.8)	
Hexagonal-head screw for securing brake disc to wheel hub	40 ± 4	(4 ± 0.4)	
Wheel hub cover*	106 ± 11	$(0.8 \pm .)$	
Tapered threaded plug for wheel hub cover	55 ± 5	(5.5 ± 0.5)	
Brake cylinder securing nut	195 ± 15	(19.8 ± 1.5)	
Front brakes (Front axle 5842/5 - 5851/5) Ring nut for securing wheel hub bearings	388.5 ± 18.5	(39.6 ± 1.8)	
Cylindrical-head screw with embedded hexagon for bearings adjustment clamp	27.5 ± 2.5	(2.8 ± 0.2)	
Self-locking hexagonal-head screw for securing brake calipers	299.5	(30.6)	
Hexagonal-head screw for securing brake disc to wheel hub	40 ± 4	(4 ± 0.4)	
Wheel hub cover*	30 ± 0	(3 ±)	
Tapered threaded plug for wheel hub cover	55 ± 5	(5.5 ± 0.5)	
Brake cylinder securing nut	195 ± 15	(19.8 ± 1.5)	
Front brakes (Front axle 5871/5)			
Ring nut for securing wheel hub bearings	515.5 ± 24.5	(52.5 ± 2.5)	
Cylindrical-head screw with embedded hexagon for bearings adjustment clamp	27.5 ± 2.5	(2.8 ± 0.2)	
Self-locking hexagonal-head screw for securing brake calipers	615.5 ± 61.5	(62.5 ± 6.2)	
Hexagonal-head screw for securing brake disc to wheel hub	41 ± 4	(4 ± 0.4)	
Wheel hub cover*	30 ± 0	(3 ±)	
	55 ± 5	(5.5 ± 0.5)	
Tapered threaded plug for wheel hub cover	55 ± 5	(0.5 ± 0.5)	


* Apply a bead of LOCTITE 574 sealant on the cover abutting surface by means of the special measuring device. Protect the threaded portion.

PART	TORQUE		
	Nm	(kgm)	
Rear brakes (Rear axle MS08-125)			
Ring nut for securing wheel hub bearings	864.5 ± 86.5	(88.1 ± 8.8)	
Self-locking screw for securing brake calipers	187 ± 19	(19 ± 1.9)	
Screw for securing brake disc to wheel hub	40 ± 4	(4 ± 0.4)	
Brake cylinder securing nut	195 ± 15	(19.8 ± 1.5)	
Screw for securing half-shaft to wheel hub	150 ± 15	(15.2 ± 1.5)	
Wheel securing nut	490 ± 50	(49.9 ± 5)	
Manual unbraking screw	30 + 6	3 + 0.6	
Rear brakes (Rear axles MS10-144; MS10-164)		(10, 10)	
Brake caliper fastening screw	187 ± 19	$(9 \pm .9)$	
Screw fastening the brake disc to the wheel hub	40 ± 4	(4 ± 0.4)	
Screw fastening the axle shaft to the wheel hub	150 ± 15	(15 ± 1.5)	
Wheel hub bearing fastening ring	932 ± 98	(93 ± 9.8)	
Wheel fastening nut	490 ± 50	(49.5 ± 5)	
Rear brakes (Rear axles MS13-165)			
Screw fastening the brake disc to the wheel hub	281.5 ± 13.5	(28 ± 1.3)	
Brake caliper support fastening screw	289.5 ± 14.5	(29 ± 1.5)	
Wheel hub bearing fastening ring	932 ± 98	(93 ± 9.9)	
Screw fastening the axle shaft to the wheel hub	262 ± 35	(26 ± 3.5)	
Brake caliper fastening screw	738.5 ± 61.5	(74 ± 6)	
Rear brakes (Rear axles SP145E)			
Wheel hub adjusting nut securing ring	392.3 ± 20	(40 ± 2)	
Nut for brake support fastening screw	289.5 ± 14.5	(29 ± 1.5)	
Wheel fastening nut	600 ^{+ 50} / _{- 20}	$(60 + \frac{5}{2})$	
Screw fastening the axle shaft to the wheel hub	232.4 ± 24.5	(23.2 ± 2.4)	
5		· /	


TOOLS	
TOOL No.	DENOMINATION
99301001	Grinder and turning machine for brake drums and discs
99301005	Brake discs grinding assembly
99301006	Brake jaws turning device
99305087	Riveting press
99305117	Pneumatic circuits control instruments
99354207	Wrench (94.5 mm) for wheel hub covers (for front axles 5842/5 - 5851/5 - 5871/5)

TOOLS TOOL No. DENOMINATION 99355038 Wrench (65 mm) for wheel hub cover (for front axle 5845) and for wheel hub bearings adjustment nut (for front axles 5842/5 -5851/5) (use with 99370317) 99355167 Wrench (114 mm) for wheel hub bearings adjustment nut (for rear axles PR140E - PD145E) 99355177 Wrench (90 mm) for wheel hub bearings adjustment nut (for rear axle MS08-125) 99355180 Wrench (105 mm) for wheel hub bearings adjustment nut (for rear axle MS13-165) 99355182 Wrench (95 mm) for wheel hub bearings adjustment nut (for rear axle MS10-144; MS10-164) 99356001 Brake jaws adjustment wrench (for rear axle PR140E - PD145E)


TOOLS TOOL No. DENOMINATION 99363204 Gaskets removing tool 99370006 Handle for interchangeable beaters (for front axles 5845 - 5871/5) 99370317 Reaction lever with flanges check extension 99370700 Wheel hub assembling guide (for rear axle MS13-165) 99370711 Wheel hub assembling guide (for rear axle MS08-125) 99370712 Wheel hub assembling guide (for front axle 5845)



TOOLS



TOOLS TOOL No. DENOMINATION Tool for disassembling the brake caliper guide pin rubber bushing 99372245 (to be used with the screw of 99372237) 99373002 Coupler for mounting the wheel hub inner gasket (for rear axle PR140E - PD145E) 99374106 Keyer for assembling internal wheel hubs gasket (use with 99370005) (for rear axles PR140E - PD145E) 99374132 Keyer for assembling internal wheel hubs gasket (use with 99370006) (for front axle 5871/5) 99374233 Keyer for assembling internal wheel hubs gasket (for front axles 5842/5 - 5851/5) 99386523 Flanging machine for brake system pipings



SPECIFICATIONS AND DATA - PNEUMATIC SYSTEM

DE	NOMINATION	CHARACTERISTICS
Со	mpressor	
	Type: KNORR	Single-cylinder
_	Displacement	225 cm ³
	Type: KNORR	Single-cylinder
	Displacement	359 cm ^{3 (*)}
	(*) series-production on Full Pneumatic models - Optional on the other models	
A.P	P.U. (drier/4 ways)	
	Type: KNORR LA 8104/5/6/7	
Dri	ier	
	Disconnection pressure	.0 ± 0.2 bar
	Connection/disconnection pressure difference	0.7 + 0.6 bar
	Safety valve opening pressure	3.0 + 4.0 bar
	Heat resistance	max + 100° C
	Operating temperature	-40° C ÷ +80° C
	Supply voltage	24 V
	Power	100W 24V
1-w	vay protection valve	
	Opening pressure section 21-22	≥ 7.5 bar
	Opening pressure section 23-24	≤ 8.0 bar
	Closing pressure section 21-22	6.5 ± 0.25 bar
	Closing pressure section 23-24	≥ 6.5 bar
	P.U. (drier/4 ways) (for vehicles RS) Type: KNORR LA 8219/LA8220 - BOSCH 484460166/484460167	
Dri		
	Disconnection pressure	11.0 ± 0.2 bar
	Connection/disconnection pressure difference	0.7 + 0.7 bar
	Safety valve opening pressure	15.5 ± 2 bar
	Heat resistance	max + 80° C
	Operating temperature	-40° C ÷ +65° C
	Supply voltage	24 V
	Power	100W 24V
	ay protection valve	
_	Type: MARELLI VPS45A - WABCO 9347140190	
	Opening pressure section 21-22	≤ 7.5 bar
	Opening pressure section 23-24	$\ge 7.5^{+0.5}_{+0.2}$ bar
	Closing pressure section 21-22	6.5 ₋₀ bar

DENOMINATION	CHARACTERISTICS
Air tanks	
Front axle	151
Rear axle	15
Trailer + parking (for vehicles adapted for towing)	20
Front axle (for vehicles adapted for towing and Models 180E)	20
Rear axle (for vehicles adapted for towing and Models 180E)	20
Manual discharge valve	
Type: VOSS 520 899 750 0	
Maximum pressure	13 bar
Type: TECKNOMATIK - TP 1609.00.00	
Maximum pressure	13 bar
Safety valve	
Calibration for models with mechanical suspension (optional)	12 ± 1.2 bar
Calibration for models with pneumatic suspension (optional)	12 ± 1.2 bar
Duplex distributor	
Type: KNORR DX 65 A - DX 65 B	
Supply pressure	± 0.2 bar
Self-limiting pressure	7.6 ± 0.3 bar
 Type: BENDIX HVSI AC 156 B Supply pressure Output pressure Safety valve opening 	8 bar (max) 8.5 ⁺⁰ _{-0.4} bar 0 ± 0.5 bar
	10 ± 0.5 Dar
Type: WABCO 475 015 0310	
Supply pressure	bar
Output pressure	8.5 ⁺⁰ _{-0.4} bar
Safety valve opening	II bar (max)
Relay valve	
Type: KNORR AC 574 AXY	10 + 0.2 bar
Maximum operating pressure	-40° ÷ 40°C
Check valve	
	20 bar
Maximum operating pressure	
Maximum operating pressure Parking brake distributor (single vehicles) Type: KNORR BREMSE DFR0208A	
Parking brake distributor (single vehicles) Type: KNORR BREMSE DFR0208A	bar
Parking brake distributor (single vehicles) Type: KNORR BREMSE DFR0208A Supply pressure	bar 7.5 bar
Parking brake distributor (single vehicles) Type: KNORR BREMSE DFR0208A	

	NOMINATION	CHARACTERISTICS
Pa	rking brake distributor (vehicles adapted for towing)	
	Type: KNORR - BREMSE DPM 90 EY	
	Supply and operating pressure	8.5 bar
	Control lever excursion (discharging) with safety braking start (resistance point)	67°
	Parking braking	73°
	Control braking for supply check to trailer braking modulated servodistributor	86°
Pa	rking brake safety distributor (upon request)	
	Туре: WABCO 434 205 0300	
	Maximum operating pressure	bar
	Cylinder pressure (under which the supply is blocked)	$4^{+0}_{-0.6}$ bar
Qu	ick discharge valve	
	Type: BENDIX HVSI KX 1294/2 - WABCO 973 500 006 0	
_	Max. operating pressure	10 bar
Tr	ple-control servodistributor (for vehicles adapted for towing)	
	Type: KNORR - BREMSE AC 597 B	
	Operating pressure	8.5 bar
		0.2 bar
	Operating pressure	
	Operating pressure Predominance	0.2 bar
Ma	Operating pressure Predominance Distributor intervention differential pressure (ducts 41-42)	0.2 bar 2.5 ^{+ 0.5} _{- 0.3} bar
	Operating pressure Predominance Distributor intervention differential pressure (ducts 41-42) Maximum allowed pressure	0.2 bar 2.5 ^{+ 0.5} _{- 0.3} bar
	Operating pressure Predominance Distributor intervention differential pressure (ducts 41-42) Maximum allowed pressure	0.2 bar 2.5 ^{+ 0.5} _{- 0.3} bar
	Operating pressure Predominance Distributor intervention differential pressure (ducts 41-42) Maximum allowed pressure derate and automatic coupling heads Type: BOSCH - KNORR - WABCO - ISO Operating pressure	0.2 bar 2.5 ^{+ 0.5} bar 12 bar
	Operating pressure Predominance Distributor intervention differential pressure (ducts 41-42) Maximum allowed pressure derate and automatic coupling heads Type: BOSCH - KNORR - WABCO - ISO Operating pressure essure control plug valve	0.2 bar 2.5 ^{+ 0.5} bar 12 bar
	Operating pressure Predominance Distributor intervention differential pressure (ducts 41-42) Maximum allowed pressure oderate and automatic coupling heads Type: BOSCH - KNORR - WABCO - ISO Operating pressure essure control plug valve Type: RAUFOSS 623.7770 - FER.NA F103 087	0.2 bar 2.5 ^{+ 0.5} bar 12 bar 7.5 bar
	Operating pressure Predominance Distributor intervention differential pressure (ducts 41-42) Maximum allowed pressure derate and automatic coupling heads Type: BOSCH - KNORR - WABCO - ISO Operating pressure essure control plug valve	0.2 bar 2.5 ^{+ 0.5} bar 12 bar
Pro	Operating pressure Predominance Distributor intervention differential pressure (ducts 41-42) Maximum allowed pressure oderate and automatic coupling heads Type: BOSCH - KNORR - WABCO - ISO Operating pressure essure control plug valve Type: RAUFOSS 623.7770 - FER.NA F103 087	0.2 bar 2.5 ^{+ 0.5} bar 12 bar 7.5 bar
Pro	Operating pressure Predominance Distributor intervention differential pressure (ducts 41-42) Maximum allowed pressure Oderate and automatic coupling heads Type: BOSCH - KNORR - WABCO - ISO Operating pressure Essure control plug valve Type: RAUFOSS 623.7770 - FER.NA F103 087 Max. operating pressure	0.2 bar 2.5 ^{+ 0.5} bar 12 bar 7.5 bar

DENOMINATION	CHARACTERISTICS				
Membrane brake cylinder (for front axles - models 120 E 130 E)					
□ Type I4: KNORR IC 72563					
Max. operating pressure	10.7 bar				
U Type 16: KNORR IC 72565					
Max. operating pressure	10.7 bar				
U Type 18: KNORR IC 72231					
Max. operating pressure	10.7 bar				
U Type 20: KNORR IC 72233					
Max. operating pressure	10.7 bar				
Membrane brake cylinder (for front axles - models 150 E)					
U Type 20: KNORR IC 72233					
Max. operating pressure	10.7 bar				
U Type 22: KNORR IC 72235					
Max. operating pressure	10.7 bar				
Membrane brake cylinder (for front axles - models 180 E)					
U Type 24: KNORR IC 72237					
Max. operating pressure	10.7 bar				
Membrane brake cylinder (for front axles - models 260 E)					
U Type 24: KNORR IC 72237					
Max. operating pressure	10.7 bar				
Combined brake cylinder (for rear axles - models 110 EL 120 EL)					
Type 16/16: WABCO 925 424 839 0					
Max service brake operating pressure	10 bar				
Max. parking brake operating pressure	8.5 bar				
Spring load	6500 N				
Combined brake cylinder (for rear axles - models 120 E 130 E)					
Type 16/27: KNORR - BREMSE BS 8317/BS 8316					
Stroke	57 mm				

DEN	NOMINATION	CHARACTERISTICS				
Combined brake cylinder (for rear axles - models 150 E)						
о т	Гуре 16/24 HFL3: KNORR - BREMSE BS 8320/BS 8321					
S	itroke	57 mm				
ПТ	Гуре 18/24 HFL3: KNORR - BREMSE BS 9364/BS 9365					
	Stroke	57 mm				
Con	nbined brake cylinder (for rear axles - models 180 E)					
ПΙ	Гуре: 18/27: KNORR IC 68084					
	1ax service brake operating pressure	10.7 bar				
М	1ax. parking brake operating pressure	8.5 bar				
М	1inimum stroke	64 mm				
Con	nbined brake cylinder (for rear axles - models 260 E)					
	nbined brake cylinder (for rear axles - models 260 E) _{[ype:} 9/6000/180: BENDIX HVSE D7 5478					
ПТ						
Ц Т Men	Type: 9/6000/180: BENDIX HVSE D7 5478					
Т [] Меп	Гуре: 9/6000/180: BENDIX HVSE D7 5478	8.5 bar				
Men	Type: 9/6000/180: BENDIX HVSE D7 5478 nbrane brake cylinder (for rear axles - models 260 E) Type 9/187: BENDIX EF 90FY	8.5 bar				
Men D T B Elec	Type: 9/6000/180: BENDIX HVSE D7 5478 mbrane brake cylinder (for rear axles - models 260 E) Type 9/187: BENDIX EF 90FY Barrel length	8.5 bar				
Men D T B Elec	Type: 9/6000/180: BENDIX HVSE D7 5478 mbrane brake cylinder (for rear axles - models 260 E) Type 9/187: BENDIX EF 90FY Barrel length etronic unit for ABS/EBL system	8.5 bar 22 ÷ 26 ∨				
T Men T B Elec S	Type: 9/6000/180: BENDIX HVSE D7 5478 mbrane brake cylinder (for rear axles - models 260 E) Type 9/187: BENDIX EF 90FY Barrel length tronic unit for ABS/EBL system Type: KNORR ES 1082-II/35431 - WABCO O 486 14 110 - B 486 104 073 Supply voltage					
Men T B Elec T S ABS	Type: 9/6000/180: BENDIX HVSE D7 5478 mbrane brake cylinder (for rear axles - models 260 E) Type 9/187: BENDIX EF 90FY Barrel length tronic unit for ABS/EBL system Type: KNORR ES 1082-II/35431 - WABCO O 486 14 110 - B 486 104 073 Supply voltage S/EBL system wheel anti-locking modulator					
ABS T	Type: 9/6000/180: BENDIX HVSE D7 5478 mbrane brake cylinder (for rear axles - models 260 E) Type 9/187: BENDIX EF 90FY Barrel length tronic unit for ABS/EBL system Type: KNORR ES 1082-II/35431 - WABCO O 486 14 110 - B 486 104 073 Supply voltage					
Men T B Elec T S ABS	Type: 9/6000/180: BENDIX HVSE D7 5478 mbrane brake cylinder (for rear axles - models 260 E) Type 9/187: BENDIX EF 90FY Barrel length tronic unit for ABS/EBL system Type: KNORR ES 1082-II/35431 - WABCO O 486 14 110 - B 486 104 073 Supply voltage S/EBL system wheel anti-locking modulator Type: KNORR IC65307	22 ÷ 26 V				

SPECIFICATIONS AND DATA - BRAKES

	FRONT AND REAR BR CALIPERS AND DISCS	AKE	Front axle 5845 Rear axle MS08-125	Front axles 5851/5 - 5842/5 Rear axles MS10-144 MS10-164	Front axle 5871/5 Rear axle MS13-165	
			Floating caliper PAN 17	Floating caliper SB6 - SN6	Floating caliper KNORR SN7	
Ø	Brake calipers cylinders: - number - diameter Ø	mm		2	2 68	
S S	Braking gaskets thickness: - normal S - minimum allowed S	mm mm	19 2	21 2	21 2	
Ø	Brake discs diameter \emptyset	mm	330	377	432	
S	Brake discs thickness: - normal S mm - minimum allowed S	n mm	34 ÷ 33.85 28	45 41	45 41	
	WHEEL HUBS					
	Wheel hub bearings		UNIT BEARING	2, tapered-roller ty UNIT BEARING	pe (for front axles) 6 (for rear axles)	
	Front axle bearing rolling torq	ue:				
	Nm (kgi		-	3 (0.3)	5 (0.54)	
	Wheel hubs clearance		Not adjustable (securing ring nut torque tightening)			
	Oil for wheel hub bearings		Τι	utela SAE W 140/M D)A	
0	Amount for every hub L*	(Kg)	0.23 (0.2)	0.23 (0.2)	0.33 (0.3)	

			TANDEM AXLE (Meritor SP 145 E)		
	Rear drum brakes		PD 145 E (R2468)	PR 140 E (R0868	
				INTERMEDIATE	REAR
	Drum diameter: - Rated	Ø	mm	380.0 +	o 381.1
	- 1 st increase	Ø	mm		:o 383.1
	- 2nd increase	Ø	mm	384.9 t	:o 385.I
	Braking gaskets thickness				0
	- Rated - Ist increase	S S	mm mm		8
	- 1st increase 5 mm - 2nd increase 5 mm				20
	- Minimum allowed	S	mm		5.5
				(in the area where	e a wear is signalled)
Ø	Braking gaskets diameter				
	- Rated	Ø	mm		io 380
15°	- 1st increase - 2nd increase	Ø Ø	mm mm		:o 382 :o 384
	2	~			
2 200					
	Braking gaskets width				
and a		L	mm	177 to	5 178.6
G					
	Clearance between bra	king g	gaskets		
	and drum:	G	mm	0.45 t	:o 1.55
		U		0.151	.0 1.35
	Maximum tapering erro	or for	. drum		
E	diameter after turning				
▼ ã		Е	mm	0	04
	Rear wheel hubs				
	Wheel hub bearings			2 with tap	ered rollers
	Hub bearings and play			0 to 0	.05 mm
	Wheel hub and play			Adjustable the	ough a ring nut
	voneer nub and play				ough a ning nut
	Axle oil TUTELA W140				
Ŭ	with Hendrickson suspe		rs (kg)	16.2 (14.6)	12.2 (11)
			~ (**6/		

CHECKS OF MAIN BRAKE SYSTEM COMPONENTS

Since the vehicle system is homologated according to European Code standards, it is mandatory to periodically check the efficiency of system and related components with device 99305117.

These checks must be carried out with unmoving vehicle, using the compressed air into the tanks, recharged, with started-up engine, by the compressor.

\wedge	
<u> </u>	

Always lock the vehicle, before any intervention. Periodically check the manometers by comparing them with a sample manometer.


DEVICE	DENOMINATION	INTERVENTIONS
	Compressor	Check of fittings tightening and compressor securing; make sure that cooling fins are not dirty.
	A.P.U. (Air Processing Unit)	Check by actuating a drain valve or by loosening a screw plug (with integrated drain hole), whether the air drier correctly operates. In this case air must go out of the tank without traces of condensate water.
	Air tanks Humid Front axle Rear axle Trailer + parking	Check of corrosion-preventing seal and protection. Discharge the condensate from tanks by operating on the drain valve.
	Duplex distributor	Completely press the pedal; when the action ceases, the pedal must immediately go back into its rest position. Pressure limiting: 7.6 \pm 0.3 bar. Check that the pedal gasket is not worn, that brake control tie-rods are well tightened and lubricated, nor distorted. Check that lever housings are neither worn nor oxidised.
	Pressure relief valve	Check calibration pressure (see Characteristics and data table). Check its functionality.
	Relay valve	Check functionality and seal evaluating brake cylinders quick intervention.
	Engine brake control operating cylinder	Check functionality and seal.

(continues)

DEVICE	DENOMINATION	INTERVENTIONS
	Parking brake distributor	Actuate the parking brake distributor till it snaps; the manometer inserted on the control plug must mark the pressure discharge down to 0 bar in 1 sec.
All and a second	Parking brake distributor (with control position)	Simultaneously at the automatic coupling joint duct, the manometer must show a pressure of 7.5 bar.
	Quick discharge valve	Check functionality and seal. Actuate the parking brake distributor, verify that the compressed air is quickly discharged from the circuit.
		Fill-in the tank. Connect a manometer to the automatic coupling head, and one to the moderate coupling head.
	Trailer braking triple-control	At a pressure of 1 bar, sent by Duplex distributor, in the moderate coupling head a pressure from 0.8 to 1.5 bar must correspond. Carry out a total braking (unmoving vehicle).
	servodistributor	At the coupling head, the required braking pressure must be available or a pressure decreased by 0.5 bar. Insert the parking brake at the moderate coupling head, the pressure must remain unchanged or decreased by 0.5 bar.
	Coupling heads	Check that there are no dirt or damages in coupling guides. At the end of the coupling, actuate the brake pedal and check sea and stability between coupling heads by inserting air at 7.5 bar. Check that there is no air leakage from coupling gaskets.
	Hydraulic or pneumatic pressure control plugs	Make sure that protection plugs are inserted, check that they are completely screwed.
	Membrane cylinder	Check securing, integrity and seal. The drain hole must be downwards oriented and must not be clogged.
	Combined cylinder	Check securing, integrity and seal. The drain hole must be downwards oriented and must not be clogged.

DEVICE	DENOMINATION	INTERVENTIONS
	Disc brake caliper Brake disc Braking gaskets	Check braking gaskets wear status, brake disc scorings and wea pistons efficiency, dust-guarding casing wear conditions.
	Drum brakes	When ceasing the pressure on the pedal, the jaws must quickly an smoothly go back on all wheels to their rest position. Check clearance between jaws and drum. Check braking gaskets thickness.
	Pipings and fittings	Make sure that metal pipings are in a perfect condition, without dents nor cracks; polyamide pipings must not show fissures, cuts of nickings. Make further sure that they are far from body and chass cutting edges that could damage them. Check that all pipin anchoring brackets are well secured; their loosening in fact cause vibrations with following danger of breakages. Verify that rubber an cloth pipes have not come in contact with oil or mineral grease, that are rubber solvents. Strongly press the brake pedal and check that pipes do not show swellings, that signals leakages from internal pipe Check that there are no brake fluid leakages from various fitting otherwise it will be necessary to completely tighten them, with th warning not to generate, during their closure, anomalous pip torsions. In all mentioned cases, it is necessary to replace the relate parts when there is even a minimum doubt about their efficiency. Apart from their conditions, it is advisable to replace the hoses after many kilometers or after a long period of vehicle use: this to avoid a sudden breakage due to ageing and fatigue.
		This check is carried out on threaded fittings, inserting an air pressur not less than 5 bar into the system, laying rather dense soapy wate on joints and fittings with a soft brush and observing that there ar no leakages. An air loss is tolerated corresponding to a \emptyset 25 mr soap bubble in 5 seconds, or anyway a max pressure drop within 1 min of 2% of disconnection pressure = 0.22 + 0.02 bar.
	Pneumatic system seal in the partial braking range with 3 bar	For 3 min the pressure must be kept stabilised in the pneumati system. The check must be carried out with disconnected parkin brake.


MAIN BRAKE SYSTEM COMPONENTS



It produces the necessary compressed air for braking system and auxiliary services.

INCONVENIENCE	POSSIBLE REASON	REMEDY
Oil leakages from flange, ex ternal side	Incorrect tightening torque.	Lock the screws according to the required values.
	Not perfectly plane flange body sealing surfaces.	Check sealing surfaces, replace faulty parts or take the back on a plane.
	Broken gasket.	Replace gasket.
	Damaged shaft gasket.	Replace gasket.
Oil leakage from the head	Worn scraper ring (it is noted because all the sealing seat is shining).	Replace the whole piston
	Faulty scraper ring assembling.	It must be assembled with the writing TOP toward th compressor head
	Scraper ring and elastic bands all on the same vertical line.	Assemble piston rings at 120° one form the other
	Scored or ovalised cylinder.	Grind the cylinder and assemble a greater piston
Total lack of compression	Deteriorated compression or suction valve.	Replace the worn parts.
	Elastic bands all on the same vertical line.	Assemble the bands at 120° one to the other.
	Holed piston or breakage of piston-related members.	Replace the complete piston.
	Damaged gaskets.	Replace the gaskets.
Scarce efficiency	Worn elastic bands.	Replace the piston (completed with elastic bands)
	Air leakage between cylinder and head.	Replace the gasket and lock the screws at the require tightening torque.
	Excessive clearance between piston and cylinder.	Grind the cylinder and assemble an increased piston.
	Carbonised oil particles between suction and compression valves.	Clean the valves.
Mechanical noise	Excessive clearance between connecting rod foot and pin, between pin and piston hole, between shaft and connecting rod head, between shaft and bushings and between flanges and shaft.	Check affected couplings tolerance.
	Excessive clearance between piston and cylinder.	Grind the cylinder and assemble an increased piston.
	Excessive fouling between piston and cylinder head caused by burnt oil.	Clean fouled parts and replace the valves.
Water blow-by	Scored and irregular head gasket or coupling planes.	Replace the faulty parts.

A.P.U. (Air Processing Unit)



Operation

Figure 33

d

24

а

DOOD

22

21

f

NIIII

h

С

25

2

24

23

65

PNEUMATIC SYSTEM - BRAKES

Recharge phase:

The compressed air coming from the compressor through the supply fitting "11" is arranged on the safety valve "a" (calibrated at 13+4 bar) and through the suitable channel it reaches the drier filter.

Compressed air gives off, as it passes through the filter, its own moisture and feeds the timer "b" chamber through the calibrated hole. At the same time, it opens the unidirectional maintain valve "c", thus feeding the outlet 24 pressure intake, pressure regulator "d", pneumatic suspension circuit feed outlet 25 and, through outlet 21, the four-way protection valve. This valve will convey the air below the controlled-pressure valves of brake system outlets 21 and 22. When a pressure of \leq 7,5 bar is reached, the controlled-pressure valves will open, thus making it possible to feed the systems connected.

Simultaneously, through the two unidirectional valves "e", air can reach the controlled-pressure valve of the secondary sections.

The further pressure increase and reaching a pressure > 8 bar allow opening the controlled-pressure valves in the secondary sections and consequently supplying the outlets 23 and 24

(continues)

62629

When reaching the regulator calibration pressure of $10.3^{+0.2}$ bar, there occurs the opening thereof and the consequent opening of discharge valve "h" that generates a pressure drop inside the drier and the unidirectional keeping valve "c" closure and the activation of the drier filter regeneration step. The slow pressure drop of the timer supply chamber allows the pressure return from systems for a time of about 20 seconds. The compressed air returning from systems, when passing through the filter, will guarantee its regeneration and will discharge itself in the atmosphere through vent 3.

Failure phase of duct 21

In case there is a failure to main four-way protection valve circuit, the component will behave as follows:

The pressure drop that affects outlet 21 creates a general pressure drop in the whole component till the closure pressure is reached (6.5 bar) for the controlled-pressure valve in the faulty section.

This pressure decrease also goes to the regulator "d" that by moving itself goes back to its recharge condition.

The pressure drop in duct 21 creates the displacement and discharge opening of the safety valve "f" for the parking duct, that discharges the protection valve duct 23. With moving vehicle, the parking cylinders supply will be guaranteed either by the manual self-limited distributor (single vehicles) or by closing the unidirectional valve (vehicles adapted for towing) avoiding the vehicle self-braking.

Under this failure condition, the possible connected trailer will instead be automatically braked.


The system recharge, ensured by the regulator intervention, will take back the pressure at the opening levels of the controlled-pressure valve of the faulty section (about 7.5 bar), guaranteeing this pressure in all other component outlets.


The possible failure of all other sections will guarantee that the faulty valve opening pressure is kept for the healthy sections.



With any protection valve failure, the system supply is ensured at pressure levels that guarantee brake functionality but filter regeneration will not be ensured any more since this function is only activated when reaching the regulator triggering pressure.

POSSIBLE REASON	REMEDY
Clogged filtering cartridge.	Replace the cartridge
Air leakage from safety valve. Worn sealing gaskets.	Revise the device replacing the worn parts Revise the device replacing the worn parts
Insufficient piston seal.	Revise the device replacing the worn parts
Valve leakages in the four sections.	Revise the device replacing the worn parts.
Faulty non-return valve operation.	Revise the device replacing the worn parts, if necessar or replace the device.
	Clogged filtering cartridge. Air leakage from safety valve. Worn sealing gaskets. Insufficient piston seal. Valve leakages in the four sections.





The device is divided into two independent sections whose adjustment members are controlled in parallel by a push rod that operates on an equalizer.

It takes air from tanks and delivers it to braking elements.

It is self-limited, that is, it limits air delivery at a maximum established pressure and therefore there occurs a higher energy availability and a constant maximum braking pressure independently from pressure oscillations in tanks.


Pneumatic connections

- **II** From rear axle air tank
- From front axle air tank 12 -
- 21 -To rear axle
- To front axle 22 -
- 3 Discharge


Electric connections

- Positive for STOP lights/Body Controller
- Input positive
- EDC positive

Figure 40



The diagram shows the characteristic distributor curve and the self-limitation value at 7.6 \pm 0.3 bar.



Under rest conditions, the exhaust is open, since spring (5) pushes the pistons assembly (upper valve seat) (1 and 4) upwards.

Valves (6 and 8) are in contact against their respective sealing seats and intercept the passage of air between air inlet fittings **11** and **12** and outlets **21** and **22**.

The lower valve seat piston (7) is at rest (running) with discharge ${\bf 3}$ open.

By operating on the brake pedal, control push rod (2) and pistons assembly (1 and 4) are pushed downwards.

Piston push rod seat (4) initially closes the exhaust and afterwards opens upper valve (6). Compressed air, from fitting **11**, passes and supplies fitting **21**, rear axle and chamber **A**.

When in section **21** and chamber **A** a pressure value is reached of about $0.15 \div 0.3$ bar, value (8) is also opened due to the piston thrust effect.

Piston (7) abuts on valve (8), closes the exhaust and opens the passage between fitting 12 and fitting 22 that supplies the front vehicle section.

In case of failure in the control section **11-21**, the other one **12-22** intervenes only due to the mechanical thrust effect of upper pistons (1 and 4).

By completely operating on control push rod (2) (maximum stroke), the output pressure of the two sections **21** and **22** reaches 7.6 \pm 0.3 bar that is the pressure self-limiting value. In case of failure 0 (zero) bar in supply fitting **11**, by completely operating on control push rod (8) air must go out of fitting **22** till a pressure equal to or greater than 6.5 bar.

Such behaviour is guaranteed by the control push rod (2) mechanical thrust that abuts on piston (1); afterwards, piston (4) comes in contact with (7) and opens valve (8).

At a push rod (2) stroke of $0.5 \div 1.5$ mm, the stop lights contacts are closed and the engine brake contacts are opened in microswitches (3).


Unbraking


By releasing the brake pedal, the control push rod (2) and the piston assembly (1 and 4) return upwards together with piston (7).

By going on releasing the brake pedal, the valves remain into their respective entry seats and afterwards the exhaust seats of pistons (4 and 7) are detached from valves and air flows to the atmosphere through exhaust **3**.

At the end of the release, also microswitches (3) return to their running position.

INCONVENIENCE	POSSIBLE REASON	REMEDY
Air leakage from discharge hole	Outlet ducts leakage for sealing gaskets wear.	Revise the device replacing the faulty parts.
Distributor with irregular self-limitation	Self-limitation higher or lower than the re- quired one.	By operating on the suitable screw, calibrate the device.
Vibrations when braking	Springs wear.	Revise the device replacing the faulty parts.
	Air leakage caused by piston gaskets seal in the two sections.	Revise the device replacing the faulty parts.
Irregular stop lamp control switch operation	The electric circuit does not close.	Replace the switch.
control switch operation	The electric circuit does not open.	Replace the switch.






When air contained into chamber (A) reaches the calibration values, it wins the force of spring (2) and pushes pistons (1 and 3) downwards stopping the supply.

If in fitting **2** the pre-established pressure is accidentally exceeded, the piston element goes on running downwards and valve (2) is opened for the necessary time for discharging, through hole **3**, the excessive pressure.


Bench calibration

Assemble the device on the test bench, and connect fittings I and 2 through pipings to manometers and supply. Adjust through an adjustment screw at the pressure value of $7.5_{0}^{0.3}$ bar, and simultaneously check the perfect seal thereof.

INCONVENIENCE	POSSIBLE REASON	REMEDY
Fitting 2 pressure different from	Uncalibrated valve. Sealing rings leakage.	Calibrate the device. Revise the device replacing the damaged parts.
calibration pressure	Faulty piston and related seat.	Replace the device.



- I Supply
- 2 Delivery




The device, inserted in the tractor parking brake circuit, allows performing the vehicle safety and parking braking by discharging air contained in spring cylinders.

Diagnostics


INCONVENIENCE POSSIBLE REASON REMEDY Air leakage from Worn or faulty piston, discharge Carry out an accurate cleaning, making sure that the exhaust with valve, sealing rings. rubber parts and related seats are healthy. distributor lever in unbraking position Revise the device replacing the faulty parts. Air leakage from Faulty or deteriorated piston and Carry out an accurate cleaning and check of parts, revise exhaust with related sealing ring. the device replacing the faulty parts. distributor lever in safety or parking braking position Air leakage from Faulty or worn plate, gasket, sealing Carry out an accurate parts cleaning, check sealing distributor control rings. surfaces and gasket, make sure that rubber part and lever cover related seats are healthy. Revise the device replacing faulty or worn parts, possibly restore union plane surfaces. **Difficult distributor** Interferences inside the distributor. Carry out an accurate cleaning and check of all control lever component parts. rotation Revise the device replacing the faulty parts, when assembling moderately grease all sliding parts. If such failures or wears are detected that impair the operation, replace the complete device.

The device is connected as follows:

- I From four-way protection valve;
- 21 -To quick discharge valve upstream of spring cylinders.




Difficult control lever rotation



Function of the component is discharging the compressed air from front axle membrane brake cylinders to obtain a quick unbraking.

793332 TRIPLE CONTROL SERVODIS-TRIBUTOR

Figure 51




62373

The device, controlled by the two independent tractor circuits in duplex distributor and spring brake circuit, controls trailer braking; moreover, a predominance adjusting device is provided that is placed outside the lower part. The apparatus embeds a device that allows performing the trailer braking even in case of control duct failure.

Predominance adjustment

The apparatus is equipped with a predominance adjusting device.



The operations to be carried out for adjusting the servodistributor predominance are performed in the following order:


Unscrew screw (2) from silencer body.


Insert a socket-head screw in the hole through silencer body and operate on the hexagonal body (1) hole.

By CLOCKWISE rotating a predominance increase is obtained.

By COUNTERCLOCKWISE rotating, a predominance decrease is obtained.

INCONVENIENCE	POSSIBLE REASON	REMEDY
Air leakage from exhaust under rest conditions	Sealing gaskets leakage. Faulty discharge valve and seat.	Revise the device replacing the faulty parts. Revise the device replacing the faulty parts.
Output pressures different from the established ones	Sealing gaskets air leakage. Worn or faulty pistons and seats. Yielded springs	Revise the device replacing the faulty parts. Revise the device replacing the faulty parts. Revise the device replacing the faulty parts.





POSSIBLE REASON	REMEDY
Broken or holed membrane. Membrane lip breakage.	Replace the membrane.
1 0	Tighten the screw.
Deterioration of parts composing the spring section.	Revise the device replacing the worn parts and if necessary replace the complete cylinder.
Spring breakage.	Replace the complete cylinder.
	Broken or holed membrane. Membrane lip breakage. Check band locking screws loosening. Deterioration of parts composing the spring section.

ABS SYSTEM WITH EBL FUNCTION

"ABS" Anti-Lock Brake System

The system is able to avoid wheel locking, that could occur during the braking step, under any vehicle load condition and wheel-road bed friction coefficient condition, in order to guarantee better braking performances and a higher vehicle stability.

The system, controlled by an electronic unit, is activated at start-up and automatically operates for speeds greater than 5 km/h if, following a braking, one or more wheels tend to lock.

The ABS system is able to check the engine brake exclusion and the divider locking (if it exists).

These components are disconnected if the trend of one or more drive wheels to lock themselves is detected.

The reconnection automatically occurs when the ABS system action ceases.

"EBL" (Electronic Brake Limiter) anti-skid device


The "EBL" function checks the rear axle wheels "skid" by comparing it with the front axle wheels speed.

Depending on these values, the electronic control unit computes vehicle speed, deceleration and checks the presence of "skid" between rear axle wheels and front axle wheels.

The EBL function is activated (rear ABS modulators keep the imported pressure) when the driver applies an excessive braking force with respect to load conditions being present on the vehicle, in summary when skid thresholds on rear axle and vehicle deceleration thresholds are exceeded.

Data processed by the electronic control unit are wheel revolutions and braking pressure detected by the pressure sensor installed upstream of rear axle ABS modulators.

526711 ELECTRONIC UNIT



The electronic unit is the system brain. Its task is driving the system solenoid valves depending on signals measured by wheel revolutions sensors.


Operation

Every channel comprises four functional circuits: the first one is the input one, that receives analogue signals emitted by the sensor provided on the corresponding wheel, filters them from parasitic signals and converts them into digital information by means of cycle length measures. Then there is a main circuit, that consists in a microprocessor, that processes information received by the input circuit: it has a complex program that allows it to determine wheel acceleration and deceleration values, and to perform the logic combination of the various adjustment signals. If necessary it emits two control signals, that are sent to the corresponding electro-pneumatic valve through the third unit circuit, the control one, to adequately adjust the braking pressure.

The fourth and last circuit finally is the safety one, that takes care of verifying the efficiency of various system components. If an anomaly is detected, it takes care not only to inform the driver by turning on the suitable warning light on the dashboard, but also to automatically disconnect the whole ABS system leaving however the traditional braking system in efficiency.

526713 REVOLUTIONS SENSORS 526712 PHONIC WHEELS

Figure 61




35383

Task of revolutions sensors and phonic wheels is detecting revolutions of their respective wheels.

Operation

The phonic wheel is housed in the wheel hub and rotates at the same wheel speed. It generates alternate voltages by induction in the sensors, whose frequency is proportional to the rotation speed of the respective wheel. These voltage signals are transmitted to the unit to be adequately processed.

For every wheel a sensor and a phonic wheel are assembled. This arrangement allows driving during the adjustment an individual braking pressure for every wheel, optimising running stability and braking space.



71956

Task of the electropneumatic valve is modulating the air pressure on front brake circuit.


The device is connected as follows:

- I From duplex distributor
- 2 To front circuit pneumohydraulic converter
- 3 Exhaust.


Operation

The electro-pneumatic valve modulates air pressure in the brake circuit according to the signals received from the electronic control unit in the three phases:






The compressed air from the duplex distributor to duct I pushes membrane (1) outwards, thus allowing air to reach outlet **2** and, therefore, the brake cylinders; simultaneously, air is arranged behind the membrane (4) that closes the exhaust allowing to increase the pressure in the duct **2**.



The electronic unit detects the trend of wheel to be locked and intervenes sending a pulse to solenoid valves (2 and 3).

Solenoid valve (2) moves downwards while valve (3) moves upwards. Air contained behind the membrane (4) moves behind the membrane (1) that lock the supply. Membrane (4) moves outwards and allows air contained in duct **2** to be discharged to the atmosphere through duct **3** reducing pressure going out of the solenoid valve.



In this phase, the two solenoid values are displaced downwards allowing air to be arranged behind the membranes (I and 4) that, due to the greater operating surface, close both supply and exhaust, thereby keeping the previously-reached pressure value constant in duct $\mathbf{2}$ whichever the pressure exerted on the brake pedal.

BRAKE REPAIRS MODELS ML 110 EL.. / 120 EL..)

5274 Front Brakes (Brake calipers of the PAN 17 type)

5272 Rear Brakes (Brake calipers of the PAN 17 type)

Description

The PAN 17 (PERROT-AXIAL-NEW) brake mechanically operates by means of a membrane brake cylinder if assembled on front axle, or of a spring brake cylinder if assembled on rear axle; the above cylinders are flanged to brake caliper body.

The brake caliper is of the floating type. It axially slides on guide pins (3 and 28) assembled on support (2) and braking gaskets (7 and 9), also subjected to axial movements, are kept inside the brake support (2) by a check fork (21). In this way the braking force is transmitted to abutment surfaces inside the support (2).

The brake caliper (17) is transversally placed inside the brake caliper (1), and its rotary movement, during the locking phase, ensures an optimum operation for the brake and a small hystheresis.

This type of brake is equipped with braking gaskets (7-9) with large wear volume in order to extend their replacement times.

The braking gasket replacement operation is made easier and quicker by this very model of caliper characterised by a radial type of opening.

In order to compensate for sliders wear, the actuator mechanism is provided with an infinitely-varying automatic adjustment device, whose action changes according to the applied force. This provides a constant clearance, independently from the level of use or application of the brake and together with a sturdy and rigid caliper structure, it ensures minimum actuator cylinder strokes, contributing to increase emergency braking safety coefficients.

With the direct brake cylinder assembly on caliper a very compact assembly is obtained with following chance of optimally using the device, that is the widest steering angle possible.

Brake locking system and brake operation

The brake cylinder (not shown in Figure 66 page 80) is flanged to cover (24) of brake caliper and its shoe is inserted into lever (17). Lever (17) and brake shaft are embedded one into the other and the same are supported by ball bearings (18 and 19).

The brake cylinder shoe under the pressurised air action moves the thrust element (13), which, winning the spring reaction (27), pushes through plate (10), the braking gasket (9) against the internal brake disc (8) side. At the same time, the thereby-exerted braking force is divided on the external brake disc (8) side through the action that cover (24) of brake caliper (1) exerts on braking gasket (7). When the braking action ceases, springs (27) take the whole mechanism to its original position.


Automatic braking gaskets wear recovering device

The braking gaskets wear recovering device is housed inside the thrust element (13).

Every time the lever (17) is actuated by the brake cylinder, the pin (25), assembled on it, performs an excursion in the axial groove of the return sleeve (5). The width of such excursion corresponds to the operating clearance between braking gaskets (7-9) and brake disc (8). If due to wear, the distance between braking gaskets (7-9) and brake disc (8) increases, lever (17) will have to perform a greater rotation to transmit the braking force, and consequently pin (25) integral therewith, once having reached the groove end due to the lever (17) overstroke effect, will rotate the return sleeve (5). Such rotary movement will be unidirectionally transmitted to driven sleeve (6) by spring (14). In turn, the driven sleeve (6) transmits the rotary motion to the adjustment nut (12) through a tapered coupling functioning as torsion regulator. This coupling is kept by the force that spring (15), abutting on washer (23), exerts on driven sleeve (6). Screw (11) is screwed in adjustment nut (12). On the screw (11) end, a groove is obtained in which the thrust plate (10) pin is inserted.

This connection, during adjustment nut (12) rotation, makes screw (11) unscrewed so that this latter one, operating on thrust plate (10), makes the slider advance, compensating the thickness lost by wear and approaching friction gaskets (7-9) to disc (8). If under the above conditions, the brake lever (17) is further rotated, the actuation force between adjustment nut (12) and thrust element (13) or between nut (12) and screw (11) will exceed the moment that can be transmitted and applied to nut (12) due to driven sleeve (6) torque limiter. This latter one, then, sliding with respect to the adjustment nut (12), will not generate any mechanism adjustment. In this way the adjustment device will not be activated if the load exerted thereon will exceed the spring (15) calibration value, safeguarding the system from damages.


When the braking action ceases, internal components are taken again into their original position from reaction springs (27). Pin (25) oppositely rotates the return sleeve (5) and by means of the unidirectional connection, the motion will not be transmitted to other adjustment devices that will be excluded by the rotary motion.




14. Spring - 15. Spring - 16. Plug - 17. Brake lever - 18. Ball bearing - 19. Ball bearing - 20. Small springs - 21. Fork -

22. Screw - 23. Washer - 24. Brake caliper cover - 25. Pin - 26. Screw - 27. Spring - 28. Guide pin.

527420/527450 Efficiency check for braking gaskets/brake disc wear recovering device



Unscrew securing screws (1) and with hydraulic trolley $99321024\ (2)$ detach the wheels.



Remove protection plug (2) from brake caliper (1).

Through a wrench rotate adjustment screw (3) clockwise by 1/2 revolutions increasing clearance between braking gaskets and disc.

Slightly actuate the brakes (braking pressure about I bar) for about 5 times, simultaneously verifying that the wrench rotates counterclockwise with small rotations till the required clearance (0.7 mm) is restored between disc and braking gaskets.

Otherwise, if the wrench does not rotate, rotates only upon the first application or even rotates forward and backward, this means that the device is faulty. It is then necessary to replace the complete caliper.



The angular wrench movement is reduced during the check operation.

At the end of the check and/or possible replacement of brake caliper, attach again the wheels tightening the nuts in the required sequence and tightening torque.

527417 Braking gaskets replacement



The below-described operations are referred to rear brakes and must be deemed as valid also for front brakes.

Arrange the vehicle on a plane ground and lock its rear wheels; loosen nuts (1, Figure 67) securing the front wheels. With an hydraulic jack lift the vehicle from its front side and rest it on two support stands.

Unscrew securing nuts and with hydraulic trolley 99321024 (2, Figure 67) detach the wheels.



Verify the wear recovering device efficiency as described in the related chapter.

Disassemble braking gaskets as described in the chapter about Wheel hubs revision.



Replace all braking gaskets even if only one of them shows anomalies.

Remove dirt and rust around the braking disc edge with a scraper or an old screwdriver, resting on the caliper body, making disk (1) rotate.

End the work with abrasive cloth. Remove residuals by using a suction device or with canvasses and brush.

Do not use petrol or other petroleum derivatives that could create brake failures.

Use only denatured alcohol with methanol or isopropyl alcohol.

Accurately clean brake disc braking area surfaces.

Checks



Visually check dust-guarding casings conditions; if they show distortions or breakages, it is necessary to replace them; such operation implies the need of disassembling the brake caliper, so that it is advisable to detach the brake caliper body completed with carrier plate for the complete revision.

Verify that the caliper freely rotates on its guides.

If anomalies are detected on one brake caliper only, it is advisable to proceed with the complete revision of both brake calipers.

Remove dirt from brake caliper using a metal brush and avoiding to damage dust-guarding casings.


Clean braking gaskets sliding surfaces.

Check brake disc conditions as described in the related chapter.

Check wear sensors conditions, and when detecting anomalies in them, in cables or leads, replace the support bracket completed with the above-listed parts.


For the assembling, reverse the disassembling operations, complying for securing the components, with the required tightening torques.

527413 Brake calipers disconnection and reconnection



For disassembling the braking gaskets, comply with what is described in chapter about "Braking gaskets replacement".

If the brake caliper disconnection-reconnection operation is related to rear axle assembled on a vehicle it is necessary to withdraw the brake cylinder (2) by unscrewing the screw placed on its rear side. Disconnect supply piping from brake cylinder (2). Remove nuts (1) and detach brake cylinder (2) from brake caliper.



Unscrew screws (1 and 4) and detach brake caliper (2) from rear axle case flange (3).


Due to the type of brake caliper only and due to its weight, it is necessary to suitably support the brake caliper during disconnection and transport.

Reconnection




For the reconnection, reverse the operations performed for the disconnection and comply with the required tightening torques. At the end of reconnection operations, verify the wear recovering device efficiency as described in the related chapter.


527413 BRAKE CALIPERS REVISION



Take brake caliper (1) to bench and lock it in a vice. With a screwdriver remove small covers (2).




Withdraw guide pins (2 and 3) from brake caliper (1) and from protection casings (4).



Remove protection casings (2 and 3) from brake caliper (1). Remove casing (5) from adjustment screw (4) and remove this latter one from brake caliper (1).

Check of component parts



Lock screw (2) rotation inserting in this latter one's groove (\rightarrow) a screwdriver. From the opposite part to brake caliper (1), unscrew screw (3) to check its threading conditions.


When detecting anomalies, replace the complete brake caliper.

For washing the metal parts, use an hot water solution with Fiat LCD detergent.

By using a metal brush remove dirt from caliper body, then with a brush remove residuals and accurately clean guide pins and sliding bushes.


Proceed with an accurate blowing of the caliper body through a jet of compressed air.

With a canvas drenched with isopropyl alcohol or the like, accurately clean the sliding pins.




Check sliding pins and related bushes wear conditions on the brake caliper body, make sure that there are no wears or damages on sliding surfaces. Insert pins in bushes and verify their regular sliding, otherwise proceed with their replacement.

Measure bush (1) diameter in many points.



With a beater (2) assemble bushes (3, 4 and 5) on brake caliper (1) placing them into this latter one at the heights mentioned in the figure. Fill with grease the room between assembled bushes (3 and 4).



12. Plug* - 13. Plug* - 14. Screw* - 15. Bush - 16. Braking gaskets - 17. Small springs - 18. Connector support blade.


* The parts must be replaced upon every disassembly with new ones.

61998


3

4

61999




527411 BRAKE DISCS REVISION



Examine the brake discs; they must not show breakages, and their surface must not show cracks densities greater than the one shown in sector **A**;

- radial cracks shown in sector **B** must not have a width greater than 0.75 mm and a depth greater than 0.5 mm;
- irregularities shown in sector **C** must not have a depth greater than 1.5 mm;
- transverse fissures on the whole braking surface as shown in sector **D** are not allowed;
- the orthogonality error measured at 35 mm from the peripheral circumference must not be greater than 0.15 mm.




Examine the brake discs surfaces wear status.

When detecting different values from those included in characteristics and data table, perform brake discs turning and grinding operations, and if necessary replace them.

If it is necessary to replace them, it is advisable to replace both brake discs.


For disconnecting and reconnecting the brake disc (3), comply with procedures included in the chapter about "Wheel hubs revision".

Remove screws (1) and detach hub (2) from disc (3). Replace disc (3) and reassemble it following the reverse procedure to the previously-described one.



place tool-holder (3) axially with brake disc (1), then adjust tools depth;


proceed with brake disc (1) turning, operating on one or more removal passes, according to detected scoring.




Through lathe 99301001 proceed with grinding both brake disc working surfaces.



During grinding operations, gradually proceed with the advancement of sectored spring, till turning residuals are totally removed.



Front and rear brakes (Brake caliper KNORR SN6-SN7 type)



Operation (See previous figure)

Braking stage

During braking, the diaphragm cylinder rod presses down on the lever (30).

The force is transferred to the axle (15) by the bearing in an off - centered position (31)

Through the threaded sleeves (2) and pistons (3), the force is conveyed to the inner braking lining (28).

Once the play between brake linings (28) and brake disc (29) has been recovered, the force is conveyed to the outer brake lining (28), due to brake caliper displacement.

The brake linings (28) pressing on the brake disc (29) produce the braking power.

Releasing stage

As soon as the pressure on the brake is reduced, the pressure spring (17), the rear axle (15) along with threaded sleeves (2) and lever (32) go back to their original positions.

Automatic play recovery


The brake is equipped with automatic adjustment device, which keeps the operating play between brake linings and brake disc constant.

Every time the brake is operated, the adjustment device (21), which is integral with the lever (32), is automatically started. If worn brake linings and brake discs increase the operating play, the adjustment device (21) and drag link (13) turn the threaded sleeves (2) so to recover said increase in play.


The operating clearance should be between 0.6 and 1.1 mm; lower clearances might cause overheating problems.

CHECKS

Checking the automatic play recovery system efficiency



Remove the lock nuts and wheels, using hydraulic stand 99321024 (1).




Remove the plug (4) using the tab (3) and make sure the adapter is not lost.



Never turn the adjusting pinion (1) without fitting the adapter (2) first. If the adapter cut torque is overcome, the adapter gets broken.

Try again with a new adapter and if also in this case it gets broken, the caliper should be replaced because there is an inner damage.





Using a suitable wrench (1), rotate the adjustment pinion counterclockwise by 2-3 with the adapter (2, Figure 92) installed turns, thus increasing the play between brake linings and brake disc.

Operate the brakes for about 5-10 times and make sure the wrench (1) moves clockwise with small increments, up to complete recover of play between braking linings and brake disc.


Otherwise, i.e. if the wrench does not turn, turns just once or turns in both directions, this means the automatic play recovery system is faulty. Replace the caliper, following the procedure given subsequently, then fit back the wheels.

Check of braking gaskets thickness






REAR BRAKES REVISION 527417 Braking gaskets replacement





Arrange the vehicle on a plane ground and lock its rear wheels; loosen nuts (1) securing the front wheels.

With an hydraulic jack lift the vehicle from its front side and rest it on two support stands (2).



Unscrew securing nuts and with hydraulic trolley 99321024 (1) detach the wheels.






Remove and disconnect the electric connections (1) from the caliper body. Remove the split pin (2), pin (3) and plate (4) fastening the brake linings.

Do not fasten any lifting device on the plate (4).

Figure 101




Remove cap (3), act on adjusting unit (1) with the adapter fitted, by means of a wrench, in a counter-clockwise direction, so as to make pistons go back into the caliper body, then remove braking gaskets (5) by properly floating caliper body (4).




Never operate directly on the registration pinion (1) without having first of all fitted the adapter (2). If the cutting torque of the adapter is exceeded, this will break.

Test with a new adapter. If this also breaks, the caliper must be replaced because it is damaged.



Press (\rightarrow) the spring (1) and remove it; replace it with a new one if necessary.



Remove dirt and rust around the braking disc edge with a scraper or an old screwdriver (2), resting on the caliper body, making disk (1) rotate.

End the work with abrasive cloth. Remove residuals by using a suction device or with canvasses and brush.

Do not use petrol or other petroleum derivatives that could create brake failures.

Use only denatured alcohol with methanol or isopropyl alcohol.

Accurately clean brake disc braking area surfaces.



Visually check dust-guarding casings conditions; if they show distortions or breakages, it is necessary to replace them; such operation implies the need of disassembling the brake caliper, so that it is advisable to detach the brake caliper body completed with carrier plate for the complete revision.

Verify that the caliper freely rotates on its guides.

If anomalies are detected on one brake caliper only, it is advisable to proceed with the complete revision of both brake calipers.


Remove dirt from brake caliper using a metal brush and avoiding to damage dust-guarding casings.


Clean braking gaskets sliding surfaces.

Check brake disc conditions and make sure that it is not corroded, scored or grooved. Slight surface cracks are acceptable, but it is necessary to go on grinding the brake disc as described in the related chapter, otherwise if worn, replace the brake disc.

If there occurs the need of replacing, it is advisable to replace both brake discs.


Check springs and wear sensors conditions, if necessary replace them.





Assemble spring (1) proceeding in reverse with respect to disassembling.

Figure 105




Insert new gaskets in brake caliper (1) and check that they freely slide into their own seats.



If it is necessary to replace the pair of braking gaskets, always replace a complete series of them for every axle.


Figure 106

Using the wrench (1), act on the adaptator retriever pin to get a play not lower than 0.7 mm between brake lining and brake disk, which can be measured using the thickness gauge (2). Replace the cover (4) and lubricate it with white grease RENOLIT HLT2.



527413 Brake calipers disconnection and reconnection

Disconnection




49166

For disconnecting the braking gaskets, comply with what has been previously described in the paragraph about "Braking gaskets replacement". Remove clamps (2). Disconnect membrane cylinder supply piping (1).

Unscrew nuts (4) and remove membrane cylinder (3).

Figure 110



Remove screws (3) and detach brake caliper (1) completed with carrier plate (2).



Pay attention when disconnecting and transporting the caliper (1) since it is heavy and floating on the carrier plate (2).


Hold the caliper on its outer side only; never put your fingers between caliper (1) and support plate (2).

Reconnection




For reconnecting, reverse performed operations for disconnecting and comply with the required tightening torques.


520620 Wheel hubs disconnection and reconnection




Rotate wheel hub so that screw plug (1) is taken downwards; unscrew the cap and drain oil in a special container.



Suitably lock wheel hub rotation and with wrench 99354207 (1) unscrew oil cover (2), by draining residual oil in the special container provided.



Unscrew safety screw (3). With wrench 99388001 unscrew adjustment ring nut (2), withdraw washer (4), external bearing (1) and detach brake disc completed with wheel hub, spacer and internal bearing.



Visually check that gasket-holder ring (1) diameter is free from dents or accidental abrasions.

Replace internal wheel hubs gaskets and if necessary ring (1) complying with what is described in section about "Front axle".

Verify through adjustment ring nut that threading (2) is free from hardenings, otherwise take care of removing them with appropriate means.

Carry out the opposite braking assembly disassembling, keeping the components separate.

Reconnection




Make sure that surfaces of all parts inside the hub are accurately clean, free from slags and burrs.

Lubricate the bearings with SAE W 140/MDA oil.


Key-in wheel hub completed with brake disc on stub axle. Insert internal spacer on stub axle, then place external bearing and shoulder washer.

Screw and lock adjustment ring nut at the required torque.


Figure 115




Settle with some axial mallet blows on wheel hub, rotate it in both directions to free bearing rollers. Apply magnetic base (1) completed with comparator (2) to wheel hub. Arrange comparator (3) rod perpendicular to stub axle tang.




527413 BRAKE CALIPERS REVISION TYPE SB6 Disassembly




Take brake caliper to bench and lock it in a vice. Remove clamp (3) and protection cups (1 and 2).



Remove sliding pins (2 and 3) and disassemble carried plate (1) recovering washer (4).



on the hub cover (1) to the set torque.



Through wrench (4), operate on clearance recovering device in order to make small piston (1) go out of caliper body for a maximum of 30 mm (dimension A).

Remove dust-guarding casing from caliper body and through a suitable lever remove small pistons (1) together with protection casings (3).

> Dimension A must absolutely not be exceeded since threaded barrels (2) are synchronised. If threaded barrels (2) perform an overstroke, they lose their synchronism and the brake caliper must be replaced. Internal brake caliper parts must absolutely not be disassembled.

Therefore do not loosen or disassemble cover check screws.

Cleaning and check of component parts

For washing the metal parts, use an hot water solution with Fiat LCD detergent.

By using a metal brush, remove dirt from caliper body, then with a brush remove residuals and accurately clean guide pins and sliding bushes seats.

Through a synthetic brush with adequate sizes, remove grease residuals from sliding bushes seats.

Proceed with an accurate caliper body blowing through a compressed air jet.

With a canvas drenched with isopropyl alcohol or the like, accurately clean the sliding bushes.

Check wear conditions of sliding bushes and related seats on brake caliper body, make sure that there are no wears or damages on sliding surfaces.

Insert bushes in their seats, verify their regular sliding, otherwise proceed with their replacement, or restoration, if it is necessary, from seat on caliper body.




A regular braking very much depends on brake caliper sliding on guide pins.

Check wear conditions of braking gaskets check pins and related safety springs; if they show distortions or wears, replace the parts that are deteriorated.

It is advisable to replace all rubber and plastic parts and brass bush, even if visually they do not show distortions or deteriorations.


Assembly


Make sure that all brake caliper components are perfectly clean; remove possible abrasive residuals with a canvas without hairs, drenched with isopropyl alcohol or the like.




Through a suitable keyer, assemble small pistons (1) together with protection casings (2).

Through a wrench (3) operate on clearance recovering device in order to make small pistons (1) go back.





Through suitable toolings, carry out caulking in point (\rightarrow), next to caliper body groove to avoid brass bush (1) displacements. Verify that there are no burrs in bush seat, otherwise remove it. Butter the bush with white RENOLIT HLT2 grease.




Insert sliding bushes (2 and 8).

Assemble carrier bracket (1), inserting washer (9), securing it with sliding pins (3 and 7) at the required torque. Assemble: protection plug (4), protection casing (5) and

secure it through a clamp (6).

Before assembling brake caliper on vehicle, make sure that it freely slides operating on plate (1) along both directions.




Butter the bush with SYNTHESO GL EPI green grease with synthetical base.


Assemble protection casing (2) making sure that its sealing lip is inserted into the suitable seat.

7

79124



79125



Place the caliper on the bench and block it in a vice. Use the wrench (4) to operate the clearance recovery device so that the piston (1) comes out of the caliper body for a maximum of 30 mm (value A).

Take off the dust-guard from the caliper body and use tool 99372238 (5) to remove the thrust pressing devices (1) of the caliper together with the protection casings (3).



Value A must not be overcome because threaded hoses (2) are synchronised. If the threaded hoses (2) reach their over-travel, they loose synchronism and the brake caliper must be replaced. The brake caliper inner parts must never be removed.

For this reason you are recommended non to slacken or to remove the cover retaining screws..

Component part cleaning and check

To wash metal parts, use a solution of hot water with Fiat LCD detergent. Use a metal brush to remove dirt from the caliper body and then a little brush to remove the residuals and to clear accurately the guide pin and the sliding bush housings.

Use a synthetic brush with the right dimensions to remove the grease left on the sliding bush housings.

Clean the caliper body accurately with compressed air.

Use a piece of cloth soaked with isopropyl alcohol or similar to clean the sliding bushes accurately.

Check the wear conditions of the sliding bushes and their housings on the brake caliper body. Make sure they are not damaged or worn, especially the sliding surfaces. Fit the bushes in their housings and check they slide regularly.

Fit the bushes in their housings, check they slide correctly, otherwise replace or restore their housings on the caliper body, if needed.




Regular braking depends mainly on the brake caliper sliding on the guide pins.

Check the wear conditions of the brake lining retaining pins and the related safety pins. If they are worn or damaged, replace the worn parts.


It is advisable to replace all rubber and plastic parts and the brass bush even if they do not seem damaged or worn at sight.

Assembly


Make sure all the brake caliper components are perfectly clean. Possible abrasive residuals should be removed with a cloth soaked in isopropyl alcohol or similar.




Use tool 99372239 (4) (see figure A) to fit the protection casings (2). Use the same tool 99372239 (4) fitted on the other side (see figure B) to insert the pistons (1). Use a wrench (3) to act on play restorer, so as to make pistons (1) go back.



Use tool 99372244 (2) (to be used with the screw in tool 99372237) to assemble the rubber sleeve (1).





for front disc brakes.

next edition.

527411 **REAR DISC BRAKES REVISION** (12-18 t)

EUROCARGO TECTOR 12-26 t Figure 140 74 Overhaul the braking unit; disassemble and check the brake caliper by following the procedure described 3 Wheel hub disassembling will be described in the WW 35704 Through lathe 99301001 proceed with grinding both brake disc working surfaces. During grinding operations, gradually proceed with the advancement of sectored spring, till turning residuals are totally removed. **BRAKE DISCS TURNING** 527411 **AND GRINDING** Figure 141 24

Key-in on lathe 99301001 (2) shaft the brake disc (1)

key-in a series of spacers on the shaft that remove axial

place tool-holder (3) axially with brake disc (1), then

proceed with brake disc (1) turning, operating on one or

more removal passes, according to detected scoring.

assembly clearance, screw locking nut and apply lathe

completed with hub;

shaft support;

adjust tools depth;

I 2 3 38597 Examine the brake discs surfaces wear status. When detecting different values from those included in characteristics and data table, perform brake discs turning and grinding operations, and if necessary replace them. Remove screws (1) and detach hub (2) from disc (3). Replace disc (3) and reassemble it following the reverse


procedure to the previously-described one.

BRAKE DISCS REVISION

527411


Figure 139

35707





17239

17240



17241





Unscrew guiding pin (2) from small piston (1) and extract the piston from the brake body. With a screwdriver, undrive metal ring (4).

Unscrew guiding pin (3) of thrust pin (5) and extract this latter one from brake body.


Proceed with disassembling the wheel completed with hub, and the whole braking unit on the opposite side, keeping the component parts separated.



Examine the wear status of drums and braking joints: if they show scoring, braking surface damages, ovalities or eccentricity greater than 0.25 mm, they must be turned.

If braking gaskets show a thickness that is lower than the provided one, proceed with their replacement.


If the gasket braking surface shows traces of grease, it is necessary to discover the reason for grease or oil seepage into the braking unit, and then remove it.




Divide the automatic adjustment units.

Unscrew adjustment bushes (3) from adjustment pins (2), then withdraw sealing gaskets (1).


Verify the external helical toothing wear status of adjustment bushes, make sure of the regular sliding of bushes when screwing them on related adjustment pints.




Withdraw sealing gaskets (2) from thrust pins (1). Accurately clean all single parts composing the braking assemblies.



Check the wear status of adjustment pins (2) and thrust pins (1) sliding surfaces, further check chutes (3) surfaces on which jaws opening control rollers operate.




compression springs (2) and copper washers (1).



527231 DRUM TURNING


Measure drum diameter by using a sliding gauge without angling the arms, measure the diameter in many points to establish ovality and wear status.



Insert on lathe 99301001 shaft (3) the drum (1) completed with wheel centring it with suitable centring bushes.

Key-in on the shaft a series of spacers that remove axial assembly clearance, screw the locking nut and apply the lathe support.

Figure 164



17253

Carry out the turning operation by gradually operating till imperfections on drum braking surface are removed. Disassemble complete wheel from lathe, carry out an accurate blowing operation on brake drum.



The maximum diameter increase allowed in drums is 4 mm. This limit must absolutely not be exceeded since braking effect and drum resistance characteristics would otherwise be impaired.

Couple adequate braking gaskets for every single drum depending on the increase. Every vehicle axle must be equipped with gaskets of the same type.

527233 BRAKING GASKETS REPLACEMENT

Figure 165


Carry out worn braking gaskets detachment from jaws by using the compressed air press 99305087 (1).

Place complete jaws (4) on adjustable abutment plat (5). With chisel (2) inserted in press (1) operating head, shear rivets (3) heads.

Expel rivets from jaws.


Accurately clean the jaws by washing and blowing them.

Visually check that jaws do not show cracks; if they are detected, replace anomalous jaws.




Apply on mobile press support (4) the abutment pin (5). Proceed with nailing braking gaskets (3) on jaws (2) by using beater (1) inserted in press operating head.

> The correct execution of braking gaskets nailing is carried out starting from the center, and gradually extending it outside of braking sectors.



BRAKING GASKETS TURNING

Assemble jaws (1) on table (3) of lathe 99301006, and lock them with handles (2).





Reset tool (1) operating on handwheel (2) and proceed with turning.




527233

Brake jaws turning can also be carried out by using tool 99372228 on lathe 99301001.






By using keyer 99373002 (1), drive sealing gasket metal ring onto brake body (2).



Insert thrust pin (4) into brake body (1) so that the notch is facing the guide pin (2) hole.


Grease and screw guide pin (2) at the required torque.






By using keyer 99373002 (2) drive the metal ring (1) of sealing gasket on brake body.

Proceed as described for assembling the other jaws opening control units.




17268

Abundantly grease wedge control units (1) and insert them into their own seat into brake body (2) so that wedge unit rollers rest on related thrust pins sliding races.




Manually screw ring nut (2) on barrel (1) till its end of stroke. Apply non-hardenable sealing paste, LOCTITE 573 type, on first barrel threads.




Completely screw brake cylinders (2) into their own seat so that supply fittings are in their original position and exhaust hole is open and facing downwards.


Connect brake cylinders supply pipings (1).




Completely screw adjustment unit (2), then unscrew by one revolution in order to give an initial adjustment for automatic recovery; place them so that notches (1) allow inserting the jaws.



Assemble jaws (1) into their suitable seat so that the punched arrow (2) is oriented along the forward-running drum rotation direction. Hook jaws return springs (3 and 5) using tool 99372217 (4).




Operate on adjustment units (1 and 2) till a dimension (A) is obtained, measured with a gauge, that is by 2 mm lower than the one detected on the used drum.



Lubricate bearings seat on barrel (3) and wheel hub sealing ring with TUTELA W 140/MDA oil.


By using hydraulic trolley 99321024 (1), place complete wheel (2) so that internal hub diameter is perfectly centred on rear axle case barrel (3). Place tapered roller bearing (4) into wheel hub. Insert complete wheel till the end of its seat, taking care of aligning wheel hub with barrel (3) to avoid damaging sealing gaskets profiles.




Screw locking ring nut and tighten it through wrench 99355167 (1) and dynamometric wrench (2), tighten adjustment nut at a torque of 98 Nm (10 kgm); at the same time, rotate hub along the two directions.


Then loosen the nut down to a zero torque.

Further unscrew the nut till an axial clearance is obtained that is included between 0.20 and 0.30 mm, corresponding to an angular movement of about 1/6 of a revolution.




Assemble the safety ring (2): if the nut (1) stop dowel does not coincide with one of the safety ring (2) holes, change nut (1) position taking also into account the clearance obtained in the previous operation.







Place comparator (1) with magnetic base on hub (3). Abut rod onto barrel (2) and check that maximum axial hub clearance is 0.05 mm.




Butter with hermetic type ''B'' the contact surface (1) between half-shaft and wheel hub.



Assemble half-shaft (1), insert securing screws (2) and tighten them at the required torque.



Supply the brake cylinders operating on service brake. With wrench (1) 99356006, tighten combined brake cylinders securing ring nuts (2 and 3) at the required torque.



36765

Proceed with the assembly of opposite braking unit and restore rear axle oil level.

Restore operation of parking brake control cylinders (1), completely screwing screw (2) again.

Start the vehicle engine up for a sufficient time to carry out the system recharge.

Carry out repeated settling brakings of the braking and clearance recovery assembly between braking gaskets and drum with running vehicle.

CAB 3 General information 3 PROTECTIVE BODY TREATMENTS 4 Protective treatment 4 Protective treatment 4 Preparing the sheet metal (bonderizing) 5 Applying the protective paint (electrophoresis) 5 CHECKING THE GEOMETRY OF THE CHASSIS FRAME 5 GENERAL RULES FOR WORKING ON THE CHASSIS FRAME 5 Preparing the chassis frame for maintenance, checking and repair work authorized by IVECO 5 Spot welding 6 Welding instructions 6 Bodybuilder work on the structural members of the IVECO chassis frame 6 PRECAUTIONS 7 Welds on the chassis frame 8 CHASSIS FRAME 9 REPAIRS AND CHECKS 9 Measuring the side bend of the chassis frame 10 Measuring the torsion of the chassis frame 10 Measuring the torsion of the chassis frame 11 CHASSIS REFERENCE DIMENSIONS 12	SEC	CTION 12	
CAB 3 General information 3 PROTECTIVE BODY TREATMENTS 4 Protective treatment 4 Protective treatment 4 Preparing the sheet metal (bonderizing) 5 Applying the protective paint (electrophoresis) 5 CHECKING THE GEOMETRY OF THE CHASSIS FRAME 5 GENERAL RULES FOR WORKING ON THE CHASSIS FRAME 5 Preparing the chassis frame for maintenance, checking and repair work authorized by IVECO 5 Spot welding 6 Welding instructions 6 Bodybuilder work on the structural members of the IVECO chassis frame 6 PRECAUTIONS 7 Welds on the chassis frame 8 CHASSIS FRAME 9 REPAIRS AND CHECKS 9 Measuring the side bend of the chassis frame 10 Measuring the torsion of the chassis frame 10 Measuring the torsion of the chassis frame 11 CHASSIS REFERENCE DIMENSIONS 12			
General information 3 PROTECTIVE BODY TREATMENTS 4 Protective treatment 4 Preparing the sheet metal (bonderizing) 5 Applying the protective paint (electrophoresis) 5 CHECKING THE GEOMETRY OF THE CHASSIS FRAME 5 GENERAL RULES FOR WORKING ON THE CHASSIS FRAME 5 Preparing the chassis frame for maintenance, checking and repair work authorized by IVECO 5 Spot welding 6 Welding instructions 6 Bodybuilder work on the structural members of the IVECO chassis frame 6 PRECAUTIONS 7 Welds on the chassis frame 6 PREPAIRS AND CHECKS 9 Measuring the bend of the chassis frame 10 Measuring the bend of the chassis frame 10 Measuring the torsion of the chassis frame 11 CHASSIS REFERENCE DIMENSIONS 12			Page
PROTECTIVE BODY TREATMENTS 4 Protective treatment 4 Preparing the sheet metal (bonderizing) 5 Applying the protective paint (electrophoresis) 5 CHECKING THE GEOMETRY OF THE CHASSIS FRAME 5 GENERAL RULES FOR WORKING ON THE CHASSIS FRAME 5 Preparing the chassis frame for maintenance, checking and repair work authorized by IVECO 5 Spot welding 6 Welding instructions 6 Drilling the chassis frame 6 PRECAUTIONS 7 Welds on the chassis frame 9 REPAIRS AND CHECKS 9 Measuring the bend of the chassis frame 10 Measuring the torsion of the chassis frame 10 Measuring the torsion of the chassis frame 11 CHASSIS REFERENCE DIMENSIONS 12	CA	Β	3
Protective treatment 4 Preparing the sheet metal (bonderizing) 5 Applying the protective paint (electrophoresis) 5 CHECKING THE GEOMETRY OF THE CHASSIS FRAME 5 GENERAL RULES FOR WORKING ON THE CHASSIS FRAME 5 Preparing the chassis frame for maintenance, checking and repair work authorized by IVECO 5 Spot welding 6 Welding instructions 6 Drilling the chassis frame 6 Drilling the chassis frame 6 PRECAUTIONS 7 Welds on the chassis frame 8 CHASSIS FRAME 9 REPAIRS AND CHECKS 9 Measuring the bend of the chassis frame 10 Measuring the torsion of the chassis frame 10 Measuring the torsion of the chassis frame 11 CHASSIS REFERENCE DIMENSIONS 12		General information	3
Preparing the sheet metal (bonderizing) 5 Applying the protective paint (electrophoresis) 5 CHECKING THE GEOMETRY OF THE CHASSIS FRAME 5 GENERAL RULES FOR WORKING ON THE CHASSIS FRAME 5 Preparing the chassis frame for maintenance, checking and repair work authorized by IVECO 5 Spot welding 6 Welding instructions 6 Drilling the chassis frame 6 Drilling the chassis frame 6 PRECAUTIONS 7 Welds on the chassis frame 8 CHASSIS FRAME 9 REPAIRS AND CHECKS 9 Measuring the bend of the chassis frame 10 Measuring the torsion of the chassis frame 10 Measuring the torsion of the chassis frame 11 CHASSIS REFERENCE DIMENSIONS 12	PRC	DTECTIVE BODY TREATMENTS	4
Applying the protective paint (electrophoresis) 5 CHECKING THE GEOMETRY OF THE CHASSIS FRAME 5 GENERAL RULES FOR WORKING ON THE CHASSIS FRAME 5 Preparing the chassis frame for maintenance, checking and repair work authorized by IVECO 5 Spot welding 6 Welding instructions 6 Drilling the chassis frame 6 Drilling the chassis frame 6 PRECAUTIONS 7 Welds on the chassis frame 8 CHASSIS FRAME 9 REPAIRS AND CHECKS 9 Measuring the side bend of the chassis frame 10 Measuring the torsion of the chassis frame 10 Measuring the torsion of the chassis frame 11 CHASSIS REFERENCE DIMENSIONS 12		Protective treatment	4
CHECKING THE GEOMETRY OF THE CHASSIS FRAME 5 GENERAL RULES FOR WORKING ON THE CHASSIS FRAME 5 Preparing the chassis frame for maintenance, checking and repair work authorized by IVECO 5 Spot welding 6 Welding instructions 6 Bodybuilder work on the structural members of the IVECO chassis frame 6 Drilling the chassis frame 6 PRECAUTIONS 7 Welds on the chassis frame 8 CHASSIS FRAME 9 REPAIRS AND CHECKS 9 Measuring the bend of the chassis frame 10 Measuring the torsion of the chassis frame 10 Measuring the torsion of the chassis frame 11 CHASSIS REFERENCE DIMENSIONS 12		Preparing the sheet metal (bonderizing)	5
FRAME 5 GENERAL RULES FOR WORKING 5 ON THE CHASSIS FRAME 5 Preparing the chassis frame for maintenance, checking and repair work authorized by IVECO 5 Spot welding 6 Welding instructions 6 Bodybuilder work on the structural members of the NECO chassis frame 6 Drilling the chassis frame 6 PRECAUTIONS 7 Welds on the chassis frame 8 CHASSIS FRAME 9 REPAIRS AND CHECKS 9 Measuring the bend of the chassis frame 10 Measuring the bend of the chassis frame 10 Measuring the torsion of the chassis frame 10 Measuring the torsion of the chassis frame 11 CHASSIS REFERENCE DIMENSIONS 12		Applying the protective paint (electrophoresis)	5
ON THE CHASSIS FRAME 5 Preparing the chassis frame for maintenance, checking and repair work authorized by IVECO 5 Spot welding 6 Welding instructions 6 Bodybuilder work on the structural members of the IVECO chassis frame 6 Drilling the chassis frame 6 PRECAUTIONS 7 Welds on the chassis frame 8 CHASSIS FRAME 9 REPAIRS AND CHECKS 9 Measuring the bend of the chassis frame 10 Measuring the bend of the chassis frame 10 Measuring the torsion of the chassis frame 10 Measuring the torsion of the chassis frame 10 Heasuring the torsion of the chassis frame 11 CHASSIS REFERENCE DIMENSIONS 12			5
and repair work authorized by IVECO 5 Spot welding 6 Welding instructions 6 Bodybuilder work on the structural members of the IVECO chassis frame 6 Drilling the chassis frame 6 PRECAUTIONS 7 Welds on the chassis frame 7 Welds on the chassis frame 8 CHASSIS FRAME 9 REPAIRS AND CHECKS 9 Measuring the side bend of the chassis frame 10 Measuring the bend of the chassis frame 10 Measuring the bend of the chassis frame 10 Measuring the torsion of the chassis frame 10 Heasuring the torsion of the chassis frame 11 CHASSIS REFERENCE DIMENSIONS 12			5
 Welding instructions		Preparing the chassis frame for maintenance, check and repair work authorized by IVECO	ing 5
Bodybuilder work on the structural members of the NECO chassis frame 6 Drilling the chassis frame 6 PRECAUTIONS 7 Welds on the chassis frame 7 Welds on the chassis frame 8 CHASSIS FRAME 9 REPAIRS AND CHECKS 9 Measuring the side bend of the chassis frame 10 Measuring the torsion of the chassis frame 10 Heasuring the torsion of the chassis frame 11 CHASSIS REFERENCE DIMENSIONS 12		Spot welding	6
Image: WECO chassis frame 6 Image: Drilling the chassis frame 6 PRECAUTIONS 7 Image: Welds on the chassis frame 7 Image: Welds on the chassis frame 8 CHASSIS FRAME 9 REPAIRS AND CHECKS 9 Image: Measuring the side bend of the chassis frame 10 Image: Measuring the bend of the chassis frame 10 Image: Measuring the bend of the chassis frame 10 Image: Measuring the bend of the chassis frame 10 Image: Measuring the bend of the chassis frame 10 Image: Measuring the bend of the chassis frame 10 Image: Measuring the torsion of the chassis frame 10 Image: Measuring the torsion of the chassis frame 11 CHASSIS REFERENCE DIMENSIONS 12		Welding instructions	6
PRECAUTIONS 7 Welds on the chassis frame 8 CHASSIS FRAME 9 REPAIRS AND CHECKS 9 Measuring the side bend of the chassis frame 10 Measuring the bend of the chassis frame downwards or upwards 10 Measuring the bend of the chassis frame 10 Measuring the torsion of the chassis frame 10 Measuring the torsion of the chassis frame 10 Heasuring the torsion of the chassis frame 11 CHASSIS REFERENCE DIMENSIONS 12		Bodybuilder work on the structural members of the IVECO chassis frame	e 6
 Welds on the chassis frame		Drilling the chassis frame	6
CHASSIS FRAME 9 REPAIRS AND CHECKS 9 Measuring the side bend of the chassis frame 10 Measuring the bend of the chassis frame downwards or upwards 10 Measuring the movement of the chassis frame 10 Measuring the torsion of the chassis frame 10 Heasuring the torsion of the chassis frame 10 CHASSIS REFERENCE DIMENSIONS 12	PRE	CAUTIONS	7
REPAIRS AND CHECKS 9 Image: Measuring the side bend of the chassis frame 10 Image: Measuring the bend of the chassis frame downwards or upwards 10 Image: Measuring the movement of the chassis frame 10 Image: Measuring the torsion of the chassis frame 10 Image: Measuring the torsion of the chassis frame 10 Image: Measuring the torsion of the chassis frame 10 Image: Measuring the torsion of the chassis frame 11 CHASSIS REFERENCE DIMENSIONS 12		Welds on the chassis frame	8
 Measuring the side bend of the chassis frame . 10 Measuring the bend of the chassis frame downwards or upwards	CH.	ASSIS FRAME	9
 Measuring the bend of the chassis frame downwards or upwards	REP	PAIRS AND CHECKS	9
or upwards 10 Measuring the movement of the chassis frame 10 Measuring the torsion of the chassis frame 11 CHASSIS REFERENCE DIMENSIONS 12		Measuring the side bend of the chassis frame .	10
Measuring the torsion of the chassis frame II CHASSIS REFERENCE DIMENSIONS I2			ds 10
CHASSIS REFERENCE DIMENSIONS		Measuring the movement of the chassis frame	10
		Measuring the torsion of the chassis frame	11
	CH.	ASSIS REFERENCE DIMENSIONS	12
0.0000000000000000000000000000	CA	B GEOMETRY	19
SEAL APPLICATION DIAGRAM	SEA	AL APPLICATION DIAGRAM	20
CAB ANCHORING AND TIGHTENING TORQUES			23

		Page
FIX	TURE	26
REF	PAIRS	27
	Cab anchoring	27
	Replacing cab suspension front and rear shock absorbers	27
	Removing-refitting front mounts and cab stabilizer bar	27
ΗY	DRAULIC CAB LIFTING SYSTEM	28
	Replacing hydraulic cylinder for cab tilting	29
REF	PLACING WINDSCREEN WINDOW	29
	General	29
	Vibration knife	29
	Harmonic wire	30
	Removal (with harmonic wire)	30
	Preparing the windscreen opening	30
	Preparing the windscreen	31
	Refitting	31
	Replacing the winding window	33
	Replacing the window winder	34
	Replacing the fixed window	34
INS	TRUMENT PANEL	36
	Removal	36
	Refitting	36
MIE	DDLE INSTRUMENT PANEL	36
	Removal	36
	Refitting	37
INS	TRUMENT PANEL COVERING	37
	Removal	37
	Refitting	42
HE	ATING AND VENTILATION	42
	Removal	42
	Refitting	42

5501 CAB


General information

The cab is an advanced one, it can be tipped up hydraulically with a mechanical control. Tilting angle 57°.

Pressed and welded steel framework, parts made of electro-galvanized sheet steel.

Sound deadening on the underbody and anticorrosion protection in the boxed compartments. The cab suspension is mechanical.

Figure I



78688

PROTECTIVE BODY TREATMENTS

Protective treatment Figure 2 M R Double zinc plated sheets Single zinc plated sheets Elements in synthetic material 78692 The choice of materials comprising the body is geared to Fire plating: the molten zinc gets deposited on the sheet achieving an excellent quality standard so as to offer a product metal by the effect of the heat. With this process, which with lasting quality and performance. is mainly used for the structural elements of the body, thicknesses of up to 20 microns can be reached, against 7 The galvanizing is done according to different technological microns obtained with the galvanic process. processes: The wheel arches made of synthetic material also have an anti-corrosion function. Galvanic plating: the sheet metal is immersed or washed, depending on whether it is bi-galvanization or All the boxes are protected by using galvanized sheet steel that, galvanization, in a salt bath providing a high level of surface after painting, are sprayed on the inside with waxy oil to finishing. prevent internal oxidation.

Preparing the sheet metal (bonderizing)

After assembly, the body undergoes a range of treatments to cleanse it of grease, oxidation and to preserve it from corrosion.

The cycle comprises the following phases:

- Pre-degreasing: washing with an acid solution (deoxidine) to eliminate the oily substances on the metal.
- Degreasing: washing with a water-surfactant solution. This solution is sprayed at a temperature of approximately 60°C.
- Rinsing: this is done with industrial water to eliminate the alkaline residues.
- Activation: washing at ambient temperature with a titanium salt solution (exposing the crystals, "pickling").
- Phosphatizing: washing with zinc phosphates at a temperature of approximately 55°C. The electrolytic plating of these metals forms and multiplies the crystalline cores, creating a uniform and protective micro-crystalline layer on the body (decontamination).
- Passivating: washing with a chromium-based solution that provides an additional layer of protection and levelling of the crystals.
- Rinsing: using deionized water eliminates the residues of the previous solutions.
- Drying: in an oven at a temperature of approximately 110° C.

Applying the protective paint (electrophoresis) Electrophoresis treatment is performed by dipping the body in a bath of an electro-conductive solution to which particles of paint have been added in suspension.

CHECKING THE GEOMETRY OF THE CHASSIS FRAME

Before doing any work it is wise to make sure that the chassis frame is perfectly level, that is with no deformation or stress due to the weight of the various assemblies.

GENERAL RULES FOR WORKING ON THE CHASSIS FRAME

The criteria for performing the work permitted by IVECO on the chassis frames are subordinate to observance of the following instructions:

- □ Welding on the flanges of the structural members and on the structural members of the chassis frame is strictly prohibited.
- Drilling the flanges of the structural members is not permitted.
- The characteristics of the chassis frame must not be altered without IVECO approval.

Preparing the chassis frame for maintenance, checking and repair work authorized by IVECO

Parts fitted on the chassis frame that are removed before checking and repairing the chassis frame must be suitably stored and protected.

Likewise, the wirings and terminal installations must be well positioned on the chassis frame to prevent damage (from any welding, painting or rubbing on the ground).

Protect the entire installation of the chassis frame, placing suitable protection on it for workers and operators to tread on.

Should welding be required, keep to the instructions.

Arc welding with weld material

The weld must be good for the effects of penetration with no cracks or inclusions and with a non-porous appearance.

The thickness of the weld material must be in proportion to the thickness of the material to weld and must be no less than 2 mm even after any grinding.

When making the weld beads, they must be parallel to the direction of the stress; transverse beads must be avoided.

For elements that bend, the weld must be located along the neutral area, with a bead width in proportion to the thickness of the sheet metal. For elements with axial compression, the weld must be made at the end and with a concave bead.

Sudden changes in cross-section due to weld accumulation must be avoided.

Spot welding

This must be workmanlike. Take special care over the setting of the device so as to make spot welds that ensure a fully efficient join. Avoid positioning spots near the edge of the parts to weld.



The areas of the chassis frame involved in welding must be thoroughly cleaned and, after welding, protected with two-component epoxy rust-proofing or another similar product, and with another coat of single- or two-component paint.

The earth cable of the welding system must be connected on the chassis frame as close as possible to the welding zone, and never near a rotating part (transmission, wheel hubs, etc.) nor above or under an assembly with moving parts (compressor, bearings, etc.).

Welding instructions

Before welding, which must be done so as to minimize the tension and deformation that may be created, remove the paint and carefully deoxidize the surfaces involved.

Classification of corresponding steels in the EU:

French standards A 35 501	German standards DIN 17 100	British standards BS 4360	American standards A S T M
E 24.2	R-St. 37.2	40 B	A 283 gr. D
E 26.3	St. 42.3	43 C	A 284 gr. C
E 36.4	St. 52.3	50 D	-
Italian standards UNI - 7070	Swedish standards MNC - 810	Spanish standards UNE - 36 080	Belgian standards NBN 631
Fe 37.B	3. 2.00	A 360.B	AE 22B or AE24B
Fe 42.C	4. 3.00	A 410.C	AE 26 C
Fe 52.D	21.34.01	A 510.D	AE 36 D

Bodybuilder work on the structural members of the IVECO chassis frame

No modification (lengthening, shortening, drilling and/or welding on a significant scale) is authorized to the frameworks of the IVECO chassis frame or warranty for the chassis frame is forfeit. If, when specifically requested in writing, IVECO Engineering authorizes specific work to be performed, there are some rules of a general nature to follow in designing and performing these operations that are stated on the following pages.

Drilling the chassis frame

When it is necessary to fit auxiliary parts or assemblies on the chassis frame, the existing holes made when making the chassis frame must, as a rule, be used.

Drilling the flanges of the vehicle's structural members is strictly prohibited.


In special cases (fitting brackets, angle sections, etc.) where it is necessary to make fresh holes, these must be made on the vertical rib of the structural member and must be carefully deburred and bored.

The new holes must not be made in the areas of greatest stress (such as the spring mountings for example) and of changes to the cross-section of the structural member.

The diameter of the holes must be suited to the thickness of the sheet metal; in no case may it exceed 15 mm. The distance from the axis of the holes from the edges of the structural member must be no less than 40 mm. In any case, the axes of the holes must be at a distance of no less than 50 mm from each other or from the existing holes. The holes must be staggered as shown in the figure.


When moving the crosspiece or spring mountings, their drilling patterns must be maintained.

PRECAUTIONS



During the work of welding, drilling, grinding, cutting near brake system piping, especially if this is made of plastic, and electric cables, take the appropriate precautions to protect them, contemplating their removal if required. All the parts of the chassis frame subject to reconditioning will need to be protected against oxidation and corrosion.


This protection and painting will need to be done carefully on all the parts concerned, as per any relevant instructions, methods and precautions of the paint manufacturers.



Straighten the side bend of the chassis frame with wedge heating on the top and bottom waist of the part concerning the chassis frame.


The tip of the heating wedge has to lie in the direction of the required bend.

If the base of the two heating wedges is in the top plate of the structural member, then the plate also needs to be heated, but last.



The chassis frame is reconditioned by wedge heating the relevant part with a blowpipe.

During this operation the metal needs to turn cherry red, which corresponds to a temperature of 600 - 680 °C. The heated points must undergo no further heating. Let the treated parts cool slowly without using any water, compressed air or the like.




17361

Straighten the sag in the chassis frame downwards or upwards with wedge heating on the top plate of the structural member. In the case of downward bending, the base (a) of the heating wedge is at the bottom. In the case of upward bending, do the opposite.

The relevant bottom or top waist of the structural member has to be heated last in the area of the base of the heating wedge.

Welds on the chassis frame




Before starting work, disconnect the negative battery terminal and connect the earth of the welding machine straight onto the piece to weld. Plastic pipes will need to be protected or removed.

Welds will have to be made solely by skilled, trained personnel, with suitable equipment and in workmanlike fashion.

Remove the paint and deoxidize the parts to weld. At the point of breakage, on the inside of the structural member and along the full length of the relevant section, make a V bevel of 60°.



No cuts are permitted on the structural members at areas of changes in profile or at points with a high concentration of stresses; additionally, the line of separation must not concern the holes already in the structural member.




Here we give the operating instructions for proper welding:

- a) Heat all around the area to weld (except for QST E 420 material). Do the arc welding with several passes, using thoroughly dried basic electrodes, or MIG-MAG procedures with suitable weld material. Do not overload with current. The weld must have no edge cuts or dross.
- b) Start back welding as specified in point (a).
- c) Leave the structural members to cool slowly and evenly. It is not permissible to use jets of air or other means.
- d) Grind off the excess material.
- e) Apply angular steel strengthening, with the same specifications as the steel used in the chassis frame. The approximate minimum dimensions are given in the above illustrations. They are to be fixed solely on the vertical rib of the structural member and it is possible to use bead welding, dummy spots, screws or rivets. The cross section and length of the weld bead, the number and distribution of the dummy spots, screws or rivets must be suited to transmit the bending and cutting moments of the section. On completing the work, the part involved in welding must be effectively protected with rust proofing.

5001 CHASSIS FRAME REPAIRS AND CHECKS

Inspect the chassis frame, checking its alignment. If already at this stage you detect any deformation you then need to free the relevant part of the chassis frame to help make an exact measurement.

Before the test you need to check all the parts that, with their imperfections, affect the exact measurements (for example, tyre pressure, weak or broken leaf springs, etc.).



Check the rivets by striking their heads with a mallet and touching the opposite side with your fingers. Mark any loose rivets with paint to help identify them during the repair work.







Figure 10

Carefully check for any peeling or cracking all over the chassis frame, paying special attention to joints under great strain, such as: chassis frame cross members, brackets, mounts of leaf springs and chassis frame structural members. Mark any peeled or cracked points straight away.






A movement in the position of the axes can be checked by making a diagonal measurement. To do this, plumb the centre of the front mount of the front suspension and the centre of the front support of the rear leaf spring on the flat supporting surface, on both sides.



Firstly compare the distance of the points "a" and "b". Then make the diagonal measurement (distance "c" and "d") from point (1) in front to the right to point (2) behind to the left and the opposite.


Measuring the torsion of the chassis frame



- position the other side of the chassis frame, in a central position under the rear cross member, on the knee of an L-shaped iron (1);
- set a rule crosswise and put a spirit level (2) on this, checking the reading.

At each check point you will need to have the same reading or the chassis frame is out of shape.

CHASSIS REFERENCE DIMENSIONS



Ρ

Q

R

S

Т

U

787.5

1147.5


787.5

787.5

787.5


787.5

787.5



II = Rear axle axis


Dimension (mm)			Wheel ba	ase (mm)		
` ´	3105	3330	3690	4185	4455	4815
Α	1001.25	1001.25	1001.25	1001.25	1001.25	1001.25
В	720	720	720	720	720	720
С	1080	1080	1080	1080	1080	1080
D	1912.5	1912.5	2182.5	2182.5	2182.5	2182.5
E				2992.5	3262.5	3217.5
F	405	405	405	405	405	405
G	405	405	405	405	405	405
Н						1260
I	990		1440	1755	1890	2115
J	840	840	840	840	840	840
К	967.5	967.5	967.5	967.5	967.5	967.5
L			2272.5	2272.5	2272.5	2272.5
М						3127.5
Ν	832.5	832.5	832.5	832.5	832.5	832.5
0	202.5	202.5	202.5	202.5	202.5	202.5
Р	787.5	787.5	787.5	787.5	787.5	787.5
Q	1147.5					
R	1080	1080	1080	1080	1080	1080
S	3105	3330	3690	4185	4455	4815
Т	1313	1830	1830	2145	2280	2505
U	5498	6240	6600	7410	7815	8400




Front axle axis I =

Rear axle axis ||=

Dimension (mm)				Wheel t	oase (mm)			
, ,	3105	3690	4185	4455	4815	5175	5670	6570
Α	1091.25	1091.25	1091.25	1091.25	1091.25	1091,25	1091,25	1091,25
В	697,5	1080	1080	1080	1080	1080	1080	1080
С	1732.5	2182.5	2182.5	2182.5	2182.5	2182.5	2182.5	2182.5
D			2970	3082.5	3397.5	3082.5	3217.5	3217.5
E						3960	4252.5	4297.5
F								5152.5
G	405	405	405	405	405	405	405	405
Н	405	405	405	405	405	405	405	405
I							1282.5	1440
J			1170	1170	1170	1575	2092.5	2587.5
K	1215	1642.5	1957.5	2092.5	2362.5	2587.5	2902.5	3397.5
L	840	840	840	840	840	840	840	840
Μ	1170	1170	1170	1170	1170	1170	1170	1170
Ν		2272.5	2272.5	2272.5	2272.5	2272.5	2272.5	2272.5
0					3307.5	3307.5	3307.5	3307.5
Р								4207.5
Q	832.5	832.5	832.5	832.5	832.5	832.5	832.5	832.5
R	157.5	157.5	157.5	157.5	157.5	157.5	157.5	157.5
S	810	810	810	810	810	810	810	810
Т						1372.5	1485	1980
U	1147,5	1575	1890	2025	2295	2520	2835	3330
V	1170	1170	1170	1170	1170	1170	1170	1170
W	3105	3690	4185	4455	4815	5175	5670	6570
Х	1313	1740	2055	2190	2460	2685	3000	3495
Y	5588	6600	7410	7815	8445	9030	9840	11235




Models: 180 (mechanic suspensions)




W

Х

Y



Dimension (mm)				Wheel t	oase (mm)			
	3690	4185	4590	4815	5175	5670	6210	6570
Α	1091.25	1091.25	1091.25	1091.25	1091.25	1091.25	1091.25	1091.25
В	1080	1080	1080	1080	1080	1080	1080	1080
С	2182.5	2182.5	2182.5	2182.5	2182.5	2182.5	2182.5	2182.5
D		2970	3217,5	3397.5	3082.5	3217.5	3217.5	3217.5
E					3960	4252.5	4095	4095
F							4905	5062.5
G	405	405	405	405	405	405	405	405
Н	405	405	405	405	405	405	405	405
I				1170	1170	1462.5	1417.5	1417.5
J	1032,5	1170	1507,5	1710	1980	2092.5	2092.5	2632.5
K	840	840	840	840	840	840	840	840
L	1170	1170	1170	1170	1170	1170	1170	1170
М	2272.5	2272.5	2272.5	2272.5	2272.5	2272.5	2272.5	2272.5
Ν				3307.5	3307.5	3307.5	3307.5	3307.5
0							4185	4185
Р								4972.5
Q	697.5	697.5	697.5	697.5	697.5	697.5	697.5	697.5
R	157.5	157.5	157.5	157.5	157.5	157.5	157.5	157.5
S		906	906	906	906	906	906	906
Т								1507.5
U	902.5	1147.5	1504	1707	1977	2089	2089	2629
V	1170	1170	1170	1170	1170	1170	1170	1170
W	3690	4185	4590	4815	5175	5670	6210	6570
Х	1133	1313	1650	1853	2123	2235	2235	2775
Y	5993	6668	7410	7838	8468	9075	9615	10515








BODY - CHASSIS 19


CAB GEOMETRY

EuroCargo Tector 12-26 t












78693

DRIVER'S PASSENGER'S SEAT SEAT 440 - 455 440 - 465 1145 - 1160 1135 - 1160 LOWER BED LOWER BED
45 - 60 35 - 60
UPPER BED
CHASSIS INSIDE UPPER EDGE

SEAL APPLICATION DIAGRAM







о


0

B


A


78695

EuroCargo Tector 12-26 t




5542 CAB ANCHORINGCAB ANCHORING AND TIGHTENING TORQUES






TOOLS TOOL No. DENOMINATION 99370147 Cab mechanic suspension spring check tool 9937803 I Two-vacuum cup grip pair to lift windows



In order to disassemble front shock absorbers (Figure 35), just unscrew nuts (2) end take out screws (1). In order to disassemble rear shock absorbers, it is needed to unscrew fastenings and dodge aspiration duct (3), as well as take out screws (1).

To fit them, carry out the above steps in the appropriate reverse order.

554215 Removing-refitting front mounts and cab stabilizer bar



38600

Remove the bumper bar assembly.


Disconnect the shock absorber.

Support the cab with the specific prop.

Arrange the appropriate tool 99370147 (1) to compress the mount spring.

Unscrew the mount fixing screws.

Unscrew the screws fixing the top mount to the cab and the ones fixing the bracket (2) to the chassis frame. Then extract the mount together with the stabilizer bar.



The tool (2) compressing the spring of the mount (3) is removed and refitted with a press (1).


• Replace all worn or broken parts.


For refitting, carry out the steps performed for removal in reverse order.



When mounting the stabilizer bar, grease the grooves of the bar with TUTELA Z2 grease to prevent noise and wear.

HYDRAULIC CAB LIFTING SYSTEM





Unscrew the oil fittings (3); unscrew the nuts (1) for the connecting pins and extract the cylinder (2).

This operation has to be carried out with the cab lowered.

REPLACING WINDSCREEN WINDOW

General


New EuroCargo Tector windscreen windows observe the industrial standard which concerns fixed (glued) window fastening.

This is a great advantage, both in quality, because it assures perfect impermeableness and resistance to water, and in safety, because it makes structure more integral and lighter.

To detach the windscreen window, it can be operated with either a vibration cutter provided with a suitable cutting blade or harmonic wire.



Do not use lubricants while cutting. Blades must be always sharp.




A vibration cutter is made up of special shears and a suitable set of vibrating blades with a number of oscillations electrically adjustable.

It can be used to cut polyurethane sealants.

It is important that, while cutting, the blade goes on parallel both to the window and body, in order to prevent the blade from breaking.

In order to prevent the shears from overheating, it is useful to adjust both advance and number of oscillations depending on use conditions.


In detail (A) it is shown the scraper to be applied to vibration shears to level sealant residue.



Examples of some situations occurring on cutting glued windows by matching blade type needed.

Harmonic wire

For cutting the sealant bead with the harmonic wire, it is necessary to use a tool as illustrated in Figure 44.




I. Check tool - 2. Draw handle

Removal (with harmonic wire)

Before performing windscreen detaching operation, it is needed to remove, from the vehicle, those components which would hinder operations or could suffer damage while executing these operations.




Before starting the cutting procedure, it is needed to protect, though an adhesive tape, the painted area, in order to avoid possible damages.



Cut a wire section about 500 mm long and, using a check tool (3), put in a wire end (1) through sealant bead (2), starting from windscreen window lower centre (see Figure 45).

Fix the wire end to check tool (3), operating inside the vehicle, and the other end to the draw handle outside the vehicle.


The inside operator has to point the check tool at sealant bead (2), about 300 mm from where wire (1) runs through.



The other operator, who is outside the vehicle, has to pull the draw handle (1) while following the windscreen profile, and cut the sealant bead.

Repeat the operation for 300 mm sections throughout the profile, properly decreasing their length along the corners of the window, until a sealant bead complete cut is achieved, then remove the window using the vacuum cups.

Preparing the windscreen opening





By using a suitable blade, cut and level the windscreen opening sealant so as to leave 0.25 to 1 mm thickness in order not to scratch paint.

Remove sealant residue through compressed air, then degrease thoroughly with heptane and expendable paper.




The sealant film left on the windscreen opening will serve as a support for next gluing.






In case of recovery of the windscreen window, it is not needed to apply the adhesion promoter on sealant left.


Wait 15 minutes before going on with operations, so as to let the adhesion promoter solvent evaporate.



Put in windscreen window (4) upper seal (6). Position plugs against horizontal sinking (5) on the windscreen window opening. Position pads against vertical (3) and horizontal (2) sinking. Make a test assembling and perfectly center the windscreen window. Once windscreen window centering has been completed, mark windscreen and seat mutual position with adhesive tape strips (1). Cut the adhesive tape strips and remove the windscreen.




Cut the adhesive cartridge spout in such a way that extrusion shape is a triangle with 5×7 mm base and 12 mm height.



By dedicated vacuum cups (1), place the windscreen in its seat immediately after applying sealant, then settle its position.

Position a belt (2) by using vacuum cups (1) as shims, then tension it in such a way that an even pressure is applied throughout the windscreen to the purpose of assuring correct matching among window (4), adhesive (3) and windscreen opening (5).



Before re-attaching previously detached portions, check for lack of infiltration points.

Apply suds with a sponge along the outer perimeter and blow compressed air from inside in order to highlight possible infiltration.

When bubbles are in, degrease affected portion and fill it with the adhesive.

Possible sealant overflowed portions inside can be removed, once the sealant has hardened, by cutting them with a blade and detaching them with a pair of pliers.




Pay attention not to damage silk screen on the window with the blade.

Re-attach detached portions and clean the window.




Do not move or deliver the vehicle before one hour and thirty minutes expired at 23.5 °C and 50% RU (Relative Humidity) climatic conditions. When either temperature or humidity are lower, the dwell time has to be increased.




Print 603.93.111

Base – February 2003





Take the inside trim off the door as described above.




Unhook the clips (1), unscrew the screws (2), unhook the window from its lifting device (4) and extract the window winder (3).

To fit it, carry out the steps described for removal in reverse order.





Lift the shields (1), unscrew the screws and remove the rearview mirror (2). Take off the shield (3). Remove the inside door trim.



Extract the outside seal (1), apply the suction cup 99378031 (2).



Before starting to cut, you need to protect the paintwork with adhesive tape to prevent any damage.

Insert a suitable tool through the sealant by a corner (arrow) of the window.


Make the cut all along the perimeter. Remove the window with a suction cup handle (2).

Using a specific tool, level the bead of sealant remaining in the seat of the window in the door: clean with compressed air then fully degrease with heptane and disposable paper.




If refitting the window, it is necessary to remove the old sealant without damaging the screen- printed area of the window.


Position the window in its seat correctly, register its position and mark it with adhesive tape. Cut the tape and take out the window.





553710 **INSTRUMENT PANEL**


Removal

















79630 Operate from Body Control lower side and unscrew securing nut (1), and set aside electric components support panel (2) to access fastening underneath;

3

unscrew screws (3) securing instrument panel covering to support bracket.







SECTION 13

Service plan

Dage
3
3
3
3
3
4
4
7
7
8
9
12
12
12
13
13
14
14

SERVICING

Service plan

The checks, maintenance interventions and adjustments required at regular frequency on vehicle parts to ensure optimal working conditions are illustrated on the following pages.



The engine lubricant frequency in kilometres refers to a percentage of sulphur in fuel lower than 0.5%. **NOTE**: halve the oil replacement frequency if fuel with a percentage of sulphur higher than 0.5% is used.

Engine lubricant oil - ACEA E5 (URANIA LD5)



In the case lower class lubricant is used, for example ACEA E2 (Urania Turbo), halve the oil replacement frequency.

Change the engine lubricant oil in any case every 12 months in the event of very low distance, less than 800 hours/80,000 kilometres per year.

Change the transmission and axle oil at least once every two years in the event of very low yearly distances.

Carry out the general greasing procedure at least once a year in the event of very low yearly distances.

SERVICE FREQUENCY

Type of use	MI	M2	M3	M4	EPI	EP2	EP3	EP4	EP5
Long distance hauls: national or international, mainly motorway	80,000 km/ 3200 hours	160,000 km/ 6400 hours	240,000 km/ 9600 hours	480,000 km/ 19200 hours	40,000				
Short-to-medium distance hauls: regional or interregional	60,000 km/ 2400 hours	120,000 km/ 4800 hours		240,000 km/ 9600 hours	km	6 months	l year	2 years	3 years
Demanding use, mainly in city traffic: tippers, compactors, road cleaning services, distribution, off-road.	40,000 km/ I 600 hours/ I year	80,000 km/ 3200 hours/ 2 years		160,000 km/ 6400 hours/ 4 years	800 hours				

MI, M2, M3, M4: PLANNED SERVICE OPERATIONS

EP1, EP2, EP3, EP4, EP5: EXTRA PLAN OPERATIONS

EXTRA PLAN OPERATIONS

The Extra Plan (EP) operations are additional service interventions, which are complementary with respect to standard servicing, to be carried out at regular time or distance frequencies referred to options not fitted in all vehicles.

Extra plan operations (to be carried out possibly at the same time as a planned service operation)

EPI

EVERY 20,000 km or 800 hours - for urban or off-road use. EVERY 40,000 km - for long, medium or short distance hauls.

- Change automatic transmission filter and oil.
- Remove-refit and clean automatic transmission oil breather.

EP2

EVERY 6 MONTHS - particularly at the beginning of spring

• Clean radiator curtain.

EP3 EVERY YEAR

• Replace pneumatic system drier filter.

EVERY YEAR - before winter

- Check coolant density
- Replace supplementary heater fuel filter.

EVERY YEAR - before summer

• Check conditioner coolant conditions through the gauge.

EP4

EVERY TWO YEARS

- Replace air cleaner cartridge and clean container.
- Change engine coolant.

EP5


EVERY THREE YEARS

• Replace oil and bleed hydraulic clutch system.


		MI	M2	M3	M4
-	Cab tilting, opening and closing radiator cowling engine guard disjoining – re-joining	•	•	•	•
-	Handling operations	•	•	•	
-	Functional testing on road	٠	•	•	
-	Checking cooling system piping tightness	٠	•	•	
-	General chassis greasing	٠	•	•	•
	Replacing blow – by filters	٠	•	•	•
	Checking clutch hydraulic system fluid level	•	•	•	•
	Checking brake disks and shoe wear	٠	•	•	•
5	Check of brake shoe wear (26t)	٠	•	•	•
	Checking headlight aiming		•		•
	Checking steering articulated joint and steering column linkage		•		•
6	Replacing mechanical gearbox oil		•		•
9	Replacing axle hub oil		•		•
4	Replacing rear axle oil		•		•
7	Cleaning mechanical gearbox oil breather		•		•
3	Cleaning rear axle oil breather		•		•

EXTRA-PLAN OPERATIONS

		EPI	EP2	EP3	EP4	EP5
-	Replacing automatic gearbox filter and oil	٠				
-	Disjoining–re-joining and cleaning automatic gearbox oil breather	٠				
14	Cleaning radiator curtain		•			
2	Replacing pneumatic system dryer filter			•		
15	Checking engine coolant density			•		
8	Replacing cartridge and cleaning air filter container				•	
15	Replacing engine coolant				•	
12	Replacing oil and bleeding clutch hydraulic system					•



84414



77834

SCHEDULED MAINTENANCE OPERATIONS

		M2	M2	M3	M4
17	Replacing engine oil	•	•	•	•
19	Replacing engine oil filter	•	•	•	•
21	Checking conditions of different control belts	•	•	•	•
22	Replacing fuel filter		•		•
20	Replacing fuel pre-filter		•		•
16	Checking steering box and support fixing		•		•
21	Replacing belts of different controls			•	•
24	Checking valve backlash and possible adjustments			•	•
23	Check-up engine EDC system by means of MODUS or IT 2000			•	•


EXTRA-PLAN OPERATIONS

		EPI	EP2	EP3	EP4	EP5
18	Check conditioning system cooling fluid conditions by means of display.			•		
-	Replacing additional heater fuel filter			•		

MI SERVICE

- Handling operations
- Functional testing on road
- General chassis greasing
- Checking cooling system and hydraulic brake pipe seal

I - Replace the blow-by filters



Unscrew the 6 screws (1) and remove cover (2). Remove blow-by filters (3).

Before assembling the new filters clean their housing.


5 - Checking wear of brake shoes (26 t)

If you find too much wear, replace the worn components as described in the relevant section ''BRAKES''.

10 - Checking wear of discs, pads

If you find too much wear, replace the worn components as described in the relevant section ''BRAKES''.

12 - Check clutch hydraulic system fluid level



Check the level of the clutch fluid. Top it up if it is too low (see the fluids table in the GENERAL section).




The clutch fluid is poisonous and corrosive: if you accidentally come into contact with it, wash immediately with water and a neutral soap.


17 - Changing engine oil

Take out the oil level dipstick .

Remove the plug (1) from the oil sump and drain the engine oil off into a specific container.

Figure 5





Remove the oil vapour breather (1) and clean it thoroughly. Mount it, making sure it is in the right position and tighten it to the prescribed torque.




Remove the oil vapour breather (1) and clean it thoroughly. Mount it, making sure it is in the right position and tighten it to the prescribed torque.


4 - Changing rear axle oil

Figure 9


- With the axle warm, drain off the oil into a specific container by taking out the plug (2).
- Replenish with fresh oil through the hole closed by the plug (1) (see the FLUIDS section under the heading GENERAL INFORMATION).
- Clean the rear axle oil vapour breather.
- Tighten the plugs to the prescribed torque.



9 - Replace hub oil (axle 5842/5-5851/5-5871/5)




13 - Checking headlight adjustment



16 - Checking steering box fixing and mounting

20 - Changing fuel pre-filter




Unscrew the pre-filter (1) and replace it.

Before refitting the new cartridge, moisten the seal with diesel or engine oil.

Screw the cartridge on by hand until it is in contact with the mounting and then tighten by 3/4 of a turn to the required tightening torque.

When replacing the cartridge, it must not have been pre-filled. This is to prevent impurities getting into circulation that could damage the system components, injectors/pump.


22 - Changing fuel filter



Remove the fuel filter (1) with tool 99360314.

Before refitting the new cartridge, moisten the seal with diesel or engine oil.

Screw the new one on by hand, taking care to check that the rubber seal and the mating surface are clean and in a perfect state of repair. Screw the cartridge on by hand until it is in contact with the mounting and then tighten by 3/4 of a turn to the required tightening torque.



To remove and fit the belt (1) back on, you need to use an appropriate tool on the tightener (2) in the direction shown by the arrow.



The tighteners are automatic, so they are not to be adjusted after assembly.

23 - EDC system check-up using MODUS or IT2000


24 - Checking valve clearance and adjustment if necessary

To perform these operations correctly, proceed as described under "ENGINE" in the relevant section.

EXTRA-PLAN MAINTENANCE

EPI SERVICE

- Replace filter and automatic transmission oil
- Disconnect reconnect and clean automatic transmission oil breather



18 - Checking the state of the air-conditioning system refrigerant

Should gas be replaced, the quantity must be 1020 ± 20 g.

Replace additional heater fuel filter.

15 - Checking density of antifreeze in the engine coolant

<image><image>



Figure 21

The plug (1) must never be taken out for any reason whatsoever.

With the engine warm, the cooling system is in overpressure, therefore take care when taking off the cap (2).

Take off the cap (2) and draw off a sample of the coolant from the expansion tank (3) with the densimeter 99395858.

Depending on the temperature of the liquid, check the percentage of antifreeze in the liquid on the scale of the instrument. The percentage has to be higher than 40% and must not exceed 50%.

If necessary, restore the percentage of antifreeze, bearing in mind that the liquid needs to be replaced every 2 years.



77841

For vehicles fitted with an additional heater, the percentage of antifreeze must never exceed 50%.

Discharge the pressure of the compressed air system.

Unscrew the drier filter (1) and change it; tighten it to the prescribed torque, checking there is no air leakage when


pressure is restored.

EP4 SERVICE

8 - Changing the cartridge of the dry air filter and cleaning its container (even if no clogging signalled)

Once a year (servicing with frequency in hours)

Once every two years (servicing with frequency in km)



- Operate on fastening/s and remove cover (1).
- Take the cartridge out of the air filter.


Before fitting the new cartridge, clean its housing thoroughly.

15 - Replace engine coolant

Carry out the procedure described under the relevant heading in the "ENGINE" section.

EP5 SERVICE

12 - Replace oil bleed clutch hydraulic system



84410

Drain off the clutch control fluid and change it (see Fluids table in GENERAL section).



The clutch fluid is poisonous and corrosive: if you accidentally come into contact with it, wash immediately with water and a neutral soap.

Then proceed with air bleeding from the clutch control hydraulic circuit by suitably operating on the bleeding valve placed on the deaerator device operator cylinder 99306010.