



DAILY

REPAIR MANUAL

MECHANICAL

ELECTRIC/ELECTRONIC

IVECO



"This document provides data, characteristics, instructions and methodology to perform repair interventions on the vehicle and its components.

Anyway, this document is addressed to qualified and specialised personnel. Iveco commercial and assistance network personnel as well as all Iveco authorised points of assistance are specifically qualified and equipped to perform the repair interventions that are indicated in this document.

Before performing any intervention, check to have available the document relating to the vehicle model on which the intervention is being performed and also make sure that all accident prevention devices, such as, as a rough guide, goggles, helmet, gloves, shoes, as well as work tooling, lifting and transport tooling, etc., are available and efficient, and further make sure that the vehicle is put such a way that an intervention can be made in safety conditions.

Making interventions strictly observing the indications given here, as well as using specific tooling indicated, assures a correct repair intervention, execution timing observance and operators' safety.

Each repair intervention must be finalised to the recovery of functionality, efficiency and safety conditions that are provided by Iveco.

Each intervention, on the vehicle, that is finalised to a modification, alteration or else, which is not authorised by Iveco, involves the exclusion of any responsibility for Iveco, and, in particular, where the vehicle is covered by a guarantee, each such intervention involves an immediate lapse of the guarantee.

Responsibility for Iveco in repair intervention execution is excluded.

Iveco is available to provide all clarifications necessary to make interventions, as well as to provide indications in cases and situations not included in this document.

Data and information contained in this document could result not to be updated owing to modifications made by Iveco at any moment for technical or commercial reasons, or because of the need to adapt the vehicle to law requirements in different countries.

In the case of a difference between what contained here and what actually found on the vehicle, please contact Iveco network before making any intervention."

The data contained in this publication might fail to reflect the latest changes which the Manufacturer may introduce at any time, for technical or sales purposes, or to meet the requirements of local legislation.

Copy, even partial, of text and drawings is forbidden.

Publication Edited by:
IVECO S.p.A.
Customer Service
Lungo Stura Lazio, 15
10156 Torino (TO) - Italy

Print **603.93.281** - 1st Ed. 2004

Produced by:

The logo for SATIZmsx INTERNATIONAL. It features the word "SATIZ" in a bold, black, sans-serif font, followed by "msx" in a red, lowercase, sans-serif font. Below "msx" is the word "INTERNATIONAL" in a smaller, black, uppercase, sans-serif font. A red triangle points upwards from the top of the "S" in "SATIZ".

B.U. TECHNICAL PUBLISHING
Iveco Technical Publications
Lungo Stura Lazio, 15
10156 Torino (TO) - Italy

PRELIMINARY REMARKS

Manuals for repairs are split into Sections, each one of which is marked by a numeral; the contents of these sections are indicated in the general table of contents.

Each section is generally dedicated to a main Unit (e.g.: engine, gearbox, electric system, etc.).

Sections with mechanical contents include technical data, tightening torque collections, tool lists, connections – disconnections of units to/from the vehicle, overhauls at the bench and relating troubleshooting.

On the electric/electronic system section there are the descriptions of the electric network and vehicle electronic systems, electric schemes, components electric characteristics, components codes and troubleshooting relating to the central units specific of the electric system.

The manual uses proper symbols in its descriptions; the purpose of these symbols is to classify contained information. In particular, there have been defined a set of symbols to classify warnings and a set for assistance operations.

SYMBOLS - WARNINGS



Danger for persons

Missing or incomplete observance of these prescriptions can cause serious danger for persons' safety.



Danger of serious damage for the vehicle

Partial or complete non observance of these prescriptions can cause serious damages to the vehicle and sometimes guarantee lapse too.



General danger

It includes the dangers of above described signals.



































Environment protection

It indicates correct behaviour in order that vehicle use is environmentally friendly as much as possible.

NOTE It indicates an additional explanation for a piece of information.

SYMBOLS - ASSISTANCE OPERATIONS


| | |
|---|---|
|  | Removal Disconnection |
|  | Refitting Connection |
|  | Removal Disassembly |
|  | Fitting in place Assembly |
|  | Tighten to torque |
|  | Tighten to torque + angle value |
|  | Press or caulk |
|  | Regulation Adjustment |
|  | Visual inspection Fitting position check |
|  | Measurement Value to find Check |
|  | Equipment |
|  | Surface for machining Machine finish |
|  | Interference Strained assembly |
|  | Thickness Clearance |
|  | Lubrication Damp Grease |
|  | Sealant Adhesive |
|  | Air bleeding |
|  | Replacement Original spare parts |

| | |
|---|---|
|  | Intake |
|  | Exhaust |
|  | Operation |
| ϱ | Compression ratio |
|  | Tolerance Weight difference |
|  | Rolling torque |
|  | Rotation |
|  | Angle Angular value |
|  | Preload |
|  | Number of revolutions |
|  | Temperature |
|  | Pressure |
| > | Oversized Higher than.... Maximum, peak |
| < | Undersized Less than.... Minimum |
|  | Selection Classes Oversizing |
|  | Temperature < 0 °C Cold Winter |
|  | Temperature > 0 °C Hot Summer |

PRODUCT CODE

Each title or subtitle concerning operations being performed is preceded by a six-figure number named PRODUCT CODE. This number represents the **PRODUCT CODE** referred to by the repair operation contained in both REPAIR TIMES and TROUBLE CODE document.


As a quick reference there are shown below the guide lines to read this code (see Repair Timing, too).



The first and second figures identify the PRODUCT within motor vehicle.

Example :


| | | | |
|---------|----|---|-------------------|
| Product | 50 | = | Vehicle chassis; |
| Product | 52 | = | Axles; |
| Product | 53 | = | Transmission; |
| Product | 76 | = | Electric ssystem. |



The third and fourth figures identify the UNIT within the PRODUCT.

Example :

| | | | |
|---------|----|---|------------------|
| Product | 50 | = | Vehicle chassis; |
| Unit | 01 | = | Chassis; |
| Unit | 02 | = | Bumpers; |
| Unit | 03 | = | Alternator. |



The fifth and sixth figures exactly identify the SUB-ASSEMBLY and Component of a Unit within a PRODUCT.

Example :

| | | | |
|--------------|----|---|------------------------|
| Product | 50 | = | Vehicle chassis; |
| Unit | 01 | = | Chassis; |
| Sub-assembly | 40 | = | Chassis cross members; |
| Sub-assembly | 13 | = | Rotor. |

GENERAL WARNINGS



Warnings shown cannot be representative of all danger situations possibly occurring. Therefore, it is suggested to contact immediate superiors where a danger situation occurs which is not described.

Use both specific and general-purpose toolings according to the prescriptions contained in respective use and maintenance handbooks. Check use state and suitability of tools not subjected to regular check.

The manual handling of loads must be assessed in advance because it also depends, besides weight, on its size and on the path.

Handling by mechanical means must be with hoisters proper as for weight as well as for shape and volume. Hoisters, ropes and hooks used must contain clear indications on maximum carrying capacity acceptable. The use of said means is compulsorily permitted to authorised personnel only. Stay duly clear of the load, and, anyhow, never under it.

In disassembling operations, always observe provided prescriptions; prevent mechanical parts being taken out from accidentally striking workshop personnel.

Workshop jobs performed in pairs must always be performed in maximum safety; avoid operations which could be dangerous for the co-operator because of lack of visibility or of his/her not correct position.

Keep personnel not authorised to operations clear of working area.

Learn operation and safety knowledge necessary relating to the vehicle prior to each intervention on it. Scrupulously observe all safety warnings on the vehicle. Apply suitable signals for the vehicles being repaired. Once the repair intervention has been completed, before starting up the vehicle, perform all checks indicated on paragraph "Controls care of user" of Use and Maintenance handbook.

In lack of visibility in operating from the vehicle, charge a person on the ground with assistance. Do not leave unmanned a vehicle in motion during repair interventions.

Keep the vehicle stationary by proper chocks.

In the case of an intervention on a vehicle lifted from the ground, check the vehicle to be quite steady on special support stands and, in the case of lifting by means of a lift, check manual/automatic safeties to be activated.

When it is necessary to perform an intervention on methane-fed vehicles, observe the indications contained inside the document, as well as all specific safety regulations provided.

Only remove radiator cap when the engine is cold by cautiously unscrewing it in order to let system residual pressure out.

Inflammable fuel and all inflammable fluids and liquids must be handled with care, according to what contained on harmful materials 12-point cards. Refuelling must be performed outdoors with the engine off, avoiding lit cigarettes, free flames or sparks in order to prevent sudden fires/bursts. Adequately store inflammable, corrosive and polluting fluids and liquids according to what provided by regulations in force. Compulsorily avoid to use food containers to store harmful liquids. Avoid to drill or bore pressurised containers, and throw cloths impregnated with inflammable substances into suitable containers.

Worn out, damaged or consumable parts must be replaced by Iveco original spares.

During workshop activity, always keep the work place clean; timely clear or clean floors from accidental liquid or oil spots. Electric sockets and electric equipment necessary to perform repair interventions must meet safety rules.

For every intervention on vehicle hydraulic, pneumatic, conditioning and AIR - BAG systems, scrupulously observe indications specified in relating manual sections.

GENERAL WARNINGS



Put on, where required by the intervention, garments and protections provided in accident prevention rules; contact with moving parts can cause serious injuries. Use suitable, preferably tight-fitted garments, and avoid to use jewels, scarves, etc.

Do not leave the engine in motion at workshop locations not provided with a pipe to scavenge exhaust gas outside.

Avoid to breathe fumes coming from heating or from paint welding because they can cause damages to health; operate outdoors or in suitably ventilated areas. Put on proper inspirator if paint powder is present.

Avoid contact with hot water or steam coming from the engine, radiator and pipings because they could cause serious burns. Avoid direct contact with liquids and fluids present in vehicle systems; where an accidental contact has occurred, refer to 12-point cards for provisions to make.



Clean units or assemblies detached from the vehicle and carefully check their integrity before overhaul. Tidy up detached or disassembled parts with their securing elements (screws, nuts, etc.) into special containers.

Check for the integrity of the parts which prevent screws from being unscrewed: broken washers, dowels, clips, etc. Self-locking nuts with an insert made of nylon must always be replaced.

Avoid contact of rubber parts with diesel oil, petrol or other not compatible substances.

Before washing under pressure mechanical parts, protect electric connectors, and central units, if present.

Tightening screws and nuts must always be according to prescriptions; IVECO commercial and assistance network is available to give all clarifications necessary to perform repair interventions not provided in this document.

Before welding:

- Disconnect all electronic central units, take power cable off battery positive terminal (connect it to chassis bonding) and detach connectors.
- Remove paint by using proper solvents or paint removers and clean relevant surfaces with soap and water.
- Await about 15 minutes before welding.
- Equip with suitable fire resistant protections to protect hoses or other components where fluids or other materials flow which may catch fire easily on welding.

Should the vehicle be subjected to temperatures exceeding 80°C (dryer ovens), disassemble drive electronic central units.



The disposal of all liquids and fluids must be performed with full observance of specific rules in force.

GENERAL WARNINGS ON THE ELECTRIC SYSTEM



If an intervention has to be made on the electric/electronic system, disconnect batteries from the system; in this case, always disconnect, as a first one, the chassis bonding cable from batteries negative terminal.

Before connecting the batteries to the system, make sure that the system is well isolated.

Disconnect the external recharging apparatus from the public utility network before taking apparatus pins off battery terminals.

Do not cause sparks to be generated in checking if the circuit is energised.

Do not use a test lamp in checking circuit continuity, but only use proper control apparatuses.

Make sure that the electronic devices wiring harnesses (length, lead type, location, strapping, connection to screening braiding, bonding, etc.) comply with IVECO system and are carefully recovered after repair or maintenance interventions.

Measurements in drive electronic central units, plugged connections and electric connections to components can only be made on proper testing lines with special plugs and plug bushes. Never use improper means like wires, screwdrivers, clips and the like in order to avoid the danger of causing a short circuit, as well as of damaging plugged connections, which would later cause contact problems.



To start up the engine, do not use fast chargers. Start up must only be performed with either separate batteries or special truck.

A wrong polarisation of supply voltage in drive electronic central units (for instance, a wrong polarisation of batteries) can cause them to be destroyed.

Disconnect the batteries from the system during their recharging with an external apparatus.

On connecting, only screw up connector (temperature sensors, pressure sensors etc.) nuts at prescribed tightening torque.

Before disconnecting the junction connector from an electronic central unit, isolate the system.

Do not directly supply electronic central units servo components at nominal vehicle voltage.

Cables must be arranged such as to result to be parallel to reference plane, i.e. as close as possible to chassis/body structure.

Once the intervention on the electric system has been completed, recover connectors and wiring harnesses according to original arrangement.

Key memorisation procedures are influenced by electromagnetic jamming (mobile phones, etc.). Therefore, during key memorisation:

- 1 Pay attention that jamming sources are not present in the cab or near the keys.
- 2 Keys not inserted in the panel must be at least 1 meter away.

NOTE Connectors present must be seen from cable side. Connectors views contained in the manual are representative of cable side.


Bonding and screening

Negative leads connected to a system bonded point must be both as short and possible and "star"-connected to each other, trying then to have their centering tidily and properly made (Figure 1, re. M).

Further, following warnings are to be compulsorily observed for electronic components:


- Electronic central units must be connected to system bonding when they are provided with a metallic shell.
- Electronic central units negative cables must be connected both to a system bonding point such as the dashboard opening bonding (avoiding "serial" or "chain" connections), and to battery negative terminal.
- Analog bonding (sensors), although not connected to battery negative system/terminal bonding, must have optimal isolation. Consequently, particularly considered must be parasitic resistances in lugs: oxidising, clinching defects, etc.
- Screened circuits braiding must only electrically contact the end towards the central unit entered by the signal (Figure 2).
- If junction connectors are present, unscreened section **d**, near them, must be as short as possible (Figure 2).
- Cables must be arranged such as to result to be parallel to reference plane, i.e. as close as possible to chassis/body structure.

Figure 1



1. NEGATIVE CABLES "STAR" CONNECTION TO SYSTEM BONDING M

Figure 2



2. SCREENING THROUGH METALLIC BRAIDING OF A CABLE TO AN ELECTRONIC COMPONENT – C. CONNECTOR
d. DISTANCE → 0

88039

OPTIONAL ELECTRICAL AND MECHANICAL PARTS INSTALLATIONS

Accessories mounting, additions and modifications on the vehicle are to be performed complying with IVECO mounting instructions (specific document "Instructions for transformation and preparation" is available at Assistance Network workshops). It is reminded that, especially about the electric system, several electric sockets are provided for as series (or optional) sockets in order to simplify and normalise the electrical intervention that is care of preparation personnel.

For any exception to mounting instructions, IVECO's authorisation is necessary.

Lack of observance of above described prescriptions involves guarantee lapse.



It is absolutely forbidden to make modifications or connections to electric central units wiring harnesses; in particular, the data interconnection line between central units (CAN line) is to be considered inviolable.

CONVERSIONS BETWEEN THE MAIN UNITS OF MEASUREMENT OF THE INTERNATIONAL SYSTEM AND MOST USED DERIVED QUANTITIES

Power

| | | |
|-------------|---|-----------------|
| 1 kW | = | 1.36 metric HP |
| 1 kW | = | 1.34 HP |
| 1 metric HP | = | 0.736 kW |
| 1 metric HP | = | 0.986 HP |
| 1 HP | = | 0.746 kW |
| 1 Hp | = | 1.014 metric HP |

Torque

| | | |
|-------|---|------------|
| 1 Nm | = | 0.1019 kgm |
| 1 kgm | = | 9.81 Nm |

Revolutions per time unit

| | | |
|---------|---|------------------|
| 1 rad/s | = | 1 rpm × 0.1046 |
| 1 rpm | = | 1 rad/s × 9.5602 |

Pressure

| | | |
|----------------------|---|-------------------------|
| 1 bar | = | 1.02 kg/cm ² |
| 1 kg/cm ² | = | 0.981 bar |
| 1 bar | = | 10 ⁵ Pa |

(Nm and bar units are converted according to 10:1 and 1:1 for the sake of simplicity)

| | | |
|----------------------|---|-------|
| 1 kgm | = | 10 Nm |
| 1 kg/cm ² | = | 1 bar |

Temperature

| | | |
|------|---|--------------------|
| 0° C | = | 32° F |
| 1° C | = | (1 × 1.8 + 32) ° F |

DAILY

Print 603.93.281 – 1st edition
Base - May 2004

UPDATE DATA

| Section | Description | Page | Revision date |
|---------|---|--|--------------------|
| 1 | General | 4÷6, 8, 9, 12÷15, 19 | Revi February 2005 |
| 2 | Engine | 1, 107, 151, 288÷290, 294÷296, 299, 305, 308, 308/1÷308/4, 310÷317, 321÷323, 336, 443, 488/1÷488/60, 489÷492, 492/1÷492/20, 494, 495, 498, 499, 499/1, 499/2, 512÷515, 525, 526, 531, 543, 557, 564, 604÷610 | Revi February 2005 |
| 3 | Clutch | 1, 8, 8/1, 8/2, 24÷28 | Revi February 2005 |
| 4 | Transmission | 1, 7, 9÷42, 122/1÷122/32 | Revi February 2005 |
| 5 | Propeller shafts | 5÷8 | Revi February 2005 |
| 6 | Rear axles | 1, 9, 12÷14, 14/1÷14/2, 22÷28, 30, 35, 48, 51, 56, 59, 91÷118 | Revi February 2005 |
| 7 | Axle | 55 | Revi February 2005 |
| 8 | Suspensions | 86, 96 | Revi February 2005 |
| 10 | Steering gear | 24 | Revi February 2005 |
| 11 | Hydro-pneumatic system - brakes | 1, 2, 2/1, 2/2, 24, 25, 25/1, 25/2, 28, 29, 29/1, 29/2, 30, 31, 43÷45, 47, 48, 48/1, 48/2, 51, 51/1÷51/30, 52, 63÷68 | Revi February 2005 |
| 12 | Bodywork - Chassis frame - Cab air-conditioning | 1, 11, 27 | Revi February 2005 |
| 13 | Scheduled Maintenance | 5, 7, 11 | Revi February 2005 |
| 14 | Electric/electronic system | 2÷6, 37/1÷37/4, 132/1÷132/36, 177/1, 177/2, 293, 294, 405÷407 | Revi February 2005 |
| | | | |

INDEX OF SECTIONS

| | Section |
|---|-----------|
| General | I |
| Engines | 2 |
| Clutch | 3 |
| Transmission | 4 |
| Propeller shafts | 5 |
| Rear axles | 6 |
| Axle | 7 |
| Suspensions | 8 |
| Wheels and tyres | 9 |
| Steering gear | 10 |
| Hydro-pneumatic system - brakes | 11 |
| Bodywork - Chassis frame - Cab air-conditioning | 12 |
| Scheduled Maintenance | 13 |
| Electric/electronic system | 14 |

SECTION I

General

| | Page |
|---|------|
| IDENTIFICATION DATA | 3 |
| <input type="checkbox"/> Vehicle Identification Plate | 3 |
| COMPOSITION OF MODELS | 4 |
| ALPHANUMERICAL CODING FOR VEHICLE IDENTIFICATION | 7 |
| ALPHANUMERICAL CODING FOR BUS IDENTIFICATION | 16 |
| REPLENISHING FLUIDS | 19 |

IDENTIFICATION DATA

Vehicle Identification Plate


Plate legend

- a) Type-approval number marking, manufacturer's code and general vehicle data.
- b) Total tractor weight.
- c) Total weight of tractor + trailer (if applicable).
- d) Permissible weight limit on front axle.
- e) Permissible weight limit on middle axle (if applicable).
- f) Permissible weight limit on rear axle.
- g) Permissible weight limit on 4th axle (if applicable).
- h) Specific identification of type.
- i) Wheelbase in mm.
- l) Engine type.
- m) Engine power.
- n) No. of axles.
- o) Place of manufacture.


* Permissible grade of smoke

| | | | | | | | | | | | |
|------------------|---|------|-------------|-----------|-----------|-------------|-----------------|--|-----------|---------|--------------|
| IVECO SPA | | | | | | | | | | | |
| a) | _____ | | | | | | | | | | |
| b) | _____ Kg | | | | | | | | | | |
| c) | _____ Kg | | | | | | | | | | |
| d) | <u>1</u> - _____ Kg | | | | | | | | | | |
| e) | <u>2</u> - _____ Kg | | | | | | | | | | |
| f) | <u>3</u> - _____ Kg | | | | | | | | | | |
| g) | <u>4</u> - _____ Kg | | | | | | | | | | |
| h) | <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 75%;">Type</td> <td style="width: 25%;">N° of axles</td> </tr> <tr> <td style="width: 75%;">Wheelbase</td> <td style="width: 25%;">n)</td> </tr> <tr> <td style="width: 50%;">Engine type</td> <td style="width: 25%;">Engine power KW</td> </tr> <tr> <td style="width: 50%;"></td> <td style="width: 25%;">m)</td> </tr> <tr> <td style="width: 75%;">Made in</td> <td style="width: 25%;">IVECO</td> </tr> </table> | Type | N° of axles | Wheelbase | n) | Engine type | Engine power KW | | m) | Made in | IVECO |
| Type | N° of axles | | | | | | | | | | |
| Wheelbase | n) | | | | | | | | | | |
| Engine type | Engine power KW | | | | | | | | | | |
| | m) | | | | | | | | | | |
| Made in | IVECO | | | | | | | | | | |
| i) | _____ | | | | | | | | | | |
| l) | _____ | | | | | | | | | | |
| o) | _____ | | | | | | | | | | |

Admissible smoke value




Manufacturer's plate
To identify the vehicle according to E.E.C. directive (on the front cross member).




Chassis frame

Stamping (at the front on the right-hand structural member of the chassis frame).










Engine

Stamping (right-hand side on the crankcase)










COMPOSITION OF MODELS

| ASSEMBLIES | | MODELS | | | | | | | | | | | | | | | | | | | | | |
|---|--|--------|---------|---------|---------|--------|---------|---------|---------|---------|---------|---------|---------|--------|---------|---------|---------|---------|---------|---------|---------|---|--|
| | | 29 L 9 | 29 L 10 | 29 L 11 | 29 L 12 | 35 S 9 | 35 S 10 | 35 S 11 | 35 S 12 | 35 S 13 | 35 S 14 | 35 S 15 | 35 S 17 | 35 C 9 | 35 C 10 | 35 C 11 | 35 C 12 | 35 C 13 | 35 C 14 | 35 C 15 | 35 C 17 | | |
|  | 8140.63.4.. (85 CV PC/NA + EGR + OXICAT) | • | | | | • | | | | | | | | • | | | | | | | | | |
| | 8140.43R.43XX/44XX (90 CV ID/TCA*) | ⊗ | | | | ⊗ | | | | | | | | ⊗ | | | | | | | | | |
| | 8140.43B.43XX/44XX (105 CV ID/TCA*) | | | ○ | | | | ○ | | | | | | | | ○ | | | | | | | |
| | 8140.43C.40XX (105 CV ID/TCA + OXICAT) | | | ○ | | | | ○ | | | | | | | | ○ | | | | | | | |
| | 8140.43S.41XX (125 CV ID/TCA* E.G.R. + OXICAT) | | | | | | | | ■ | | | | | | | | | | | | | | |
| | 8140.43S.43XX/44XX (125 CV ID/TCA*) | | | | | | | | | ○ | | | | | | | | ○ | | | | | |
| | 8140.43N.43XX/44XX (150 CV ID/TCA*) | | | | | | | | | | | ○ | | | | | | | | | ○ | | |
| | FIAE0481A*A (96 CV) | | ○ | | | | ○ | | | | | | | | | ○ | | | | | | | |
| | FIAE0481B*A (116 CV) | | | | ○ | | | | | ○ | | | | | | | | ○ | | | | | |
| | FIAE0481B*B (116 CV + E.G.R. + OXICAT) | | | | | | | | | ■ | | | | | | | | | | | | | |
| | FIAE0481D*A (136 CV) | | | | | | | | | | | ○ | | | | | | | | | ○ | | |
| FICE0481A | | | | | | | | | | | | | | | | | | | | ○ | | | |
| FICE0481B | | | | | | | | | | | | | | | | | | | | | ○ | | |
|  | Single disk 9" 1/4 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | | | | | | ○ | ○ | ○ | | | | | | |
| | Single disk 10" 1/2 | | ○ | | ○ | | ○ | | ○ | ○ | ○ | | | | ○ | | ○ | ○ | ○ | ○ | | | |
| | Single disk 11 | | | | | | | | | | | ○ | ○ | | | | | | | ○ | ○ | ○ | |
|  | ZF 5S 200 | ○ | | ○ | | ○ | | ○ | | ○ | | | | ○ | ○ | | | | | | | | |
| | ZF 5S 270 | | ○ | | ○ | | ○ | | ○ | | | | | | ○ | | ○ | | | | | | |
| | ZF 5S 300 | | | | | | | | | | ○ | | | | | | | | | ○ | | | |
| | ZF 6S 300 | | | | | | | | | | ○ | | | | | | | | | ○ | | ○ | |
| | ZF 6AS 300 V.D. | | ○ | | ○ | | ○ | | ○ | | ○ | | | | ○ | | ○ | | | | ○ | ○ | |
| | ZF 6S 380 O.D. | | | | | | | | | | | | | | | | | | | ○ | | ○ | |
|  | FRONT AXLES: | | | | | | | | | | | | | | | | | | | | | | |
| | 5817 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | | | | | | | | | | |
| | 5818 | | | | | | | | □ | □ | □ | □ | ● | | ● | ● | ● | ● | ● | ● | ● | ● | |
| | 5819 | | | | | | | | | | | ◇ | | ◇ | ◇ | ◇ | ◇ | ◇ | ◇ | ◇ | ◇ | ◇ | |
| | 5823 | | | | | | | | | | | | | | | | | | | | | | |
|  | 450210 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | | | | | | | | | | |
| | 450310 | | | | | | | | | | | | ∇ | | ∇ | | | | | | ∇ | ∇ | |
| | 450311/1 | | | | | | | | | | | | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | 450511 | | | | | | | | | | | | | | | | | | | | | | |
| | 450517/2 | | | | | | | | | | | | | | | | | | | | | | |
| Rack-and-pinion | Powered steering | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
|  | FRONT MECHANICAL SUSPENSIONS: | | | | | | | | | | | | | | | | | | | | | | |
| | independent with transverse leaf spring (MK3) | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | independent with torsion bars | | | | | | | | | | | | | ● | ● | ● | ● | ● | ● | ● | ● | ● | |
| | REAR MECHANICAL SUSPENSIONS: | | | | | | | | | | | | | | | | | | | | | | |
| | Parabolic | | | | | | | | | | | | | ◇ | ◇ | ◇ | ◇ | ◇ | ◇ | ◇ | ◇ | ◇ | |
| | - single leaf | | | | | | | | | | | | | | | | | | | | | | |
| - reinforced | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | | | | | | | | | | | |
| Semi-elliptical | | | | | | | | | | | | | ● | ● | ● | ● | ● | ● | ● | ● | ● | | |
| Semi-elliptic with leaf spring | | | | | | | | | | | | | ◆ | ◆ | ◆ | ◆ | ◆ | ◆ | ◆ | ◆ | ◆ | | |
|  | REAR AIR SUSPENSIONS | □ | □ | □ | □ | □ | □ | □ | □ | □ | □ | □ | □ | ● | □ | ● | □ | ● | □ | ● | □ | | |

ID = Direct injection
 NA = Aspirated
 PC = Indirect injection (pre-combustion chamber)
 TCA = Turbocharged with intercooler
 OXICAT = Catalytic silencer
 O.D. = Over Drive
 V.D. = Van Direct
 (●) Optional extra (with max load of 1900 kg)
 ○ Standard
 □ Alternative
 * With Common Rail: 43XX, MS6.3 - 44XX, EDC 16 electronic injection system
 EGR = Anti-pollution device
 ■ Vehicle category M1
 ⊗ Non-EU markets
 ● Vehicles made until 9/01
 ⊗ Vehicles made since 9/01
 ● Vehicles with front suspension with transverse leaf spring
 ◇ Vehicles with front suspension with torsion bars

● Standard on chassis cabs and vans 40C
 Alternatively on Vans – Chassis Cowl and Cut Aways
 ◇ Standard on Vans (excluding 40C) – Chassis Cowl and Cut Aways – Alternatively on Chassis Cabs
 ● Except for 35 S chassis-cabs and chassis-cowls - Combi
 ◆ Chassis cabs only, as an alternative
 ● Not provided on 35C (with max. load of 1900 kg and tyres 135/75 R16) and 40 C Chassis cabs - 40 C Vans and Cut Aways
 S Single rear wheels
 ∇ Camper van version
 L Light with single rear wheels
 C Twin rear wheels
 BUS = Glazed vans – Glazed Vendor – Chassis Cowl – Cut Aways, bodied or adaptable to carry passengers








COMPOSITION OF MODELS







| MODELS | | ASSEMBLIES | | | | | | | | | | | | | | | | | |
|---|--|------------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---|--|
| | | 40 C 9 | 40 C 10 | 40 C 11 | 40 C 12 | 40 C 13 | 40 C 14 | 40 C 17 | 45 C 11 | 45 C 13 | 45 C 14 | 45 C 17 | 50 C 11 | 50 C 13 | 50 C 14 | 50 C 15 | 50 C 17 | | |
|  | 8140.63.4.. (85 CV PC/NA + EGR + OXICAT) | • | | | | | | | | | | | | | | | | | |
| | 8140.43R.43XX/44XX (90 CV ID/TCA*) | ☒ | | | | | | | | | | | | | | | | | |
| | 8140.43B.43XX/44XX (105 CV ID/TCA*) | | | ○ | | | | | ○ | | | | ○ | | | | | | |
| | 8140.43C.40XX (105 CV ID/TCA + OXICAT) | | | ◻ | | | | | ◻ | | | | ◻ | | | | | | |
| | 8140.43S.41XX (125 CV ID/TCA* E.G.R. + OXICAT) | | | | | | | | | | | | | | | | | | |
| | 8140.43S.43XX/44XX (125 CV ID/TCA*) | | | | | | ○ | | | ○ | | | | ○ | | | | | |
| | 8140.43N.43XX/44XX (150 CV ID/TCA*) | | | | | | | | | | | | | | | | ○ | | |
| | F1AE0481A*A (96 CV) | | ○ | | | | | | | | | | | | | | | | |
| | F1AE0481B*A (116 CV) | | | | ○ | | | | | | | | | | | | | | |
| | F1AE0481B*B (116 CV + E.G.R. + OXICAT) | | | | | | | | | | | | | | | | | | |
| F1AE0481D*A (136 CV) | | | | | | | | | | | | | | | | | | | |
| F1CE0481A | | | | | | | | ○ | | | | ○ | | | | ○ | | | |
| F1CE0481B | | | | | | | | | ○ | | | ○ | | | | | | ○ | |
|  | Single disk 9" 1/4 | ○ | ○ | ○ | ○ | | | | | | | | | | | | | | |
| | Single disk 10" 1/2 | | ○ | | ○ | ○ | | | ○ | ○ | | | ○ | ○ | | | | | |
| | Single disk 11 | | | | | | | ○ | ○ | | | ○ | ○ | | ○ | ○ | ○ | ○ | |
|  | ZF 5S 200 | ○ | | ○ | | | | | | | | | | | | | | | |
| | ZF 5S 270 | | ○ | | ○ | | | | | | | | | | | | | | |
| | ZF 5S 300 | | | | | | | | | | | | | | | | | | |
| | ZF 6S 300 | | | | | | | ○ | | ○ | ○ | | | ○ | ○ | | ○ | | |
| | ZF 6AS 300 V.D. | | ○ | | ○ | | | | | | | | | | | | | | |
| | ZF 6S 380 O.D. | | | | | | | ○ | ○ | | | ○ | ○ | | | | ○ | ○ | |
|  | FRONT AXLES: | | | | | | | | | | | | | | | | | | |
| | 5817 | | | | | | | | | | | | | | | | | | |
| | 5818 | | | | | | | | | | | | | | | | | | |
| | 5819 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | 5823 | | | | | | | | | | | | | | | | | | |
|  | 450210 | | | | | | | | | | | | | | | | | | |
| | 450310 | | | | | | | | | | | | | | | | | | |
| | 450311/1 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | | | | | | | | | | | |
| | 450511 | | | | | | | | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | 450517/2 | | | | | | | | | | | | | | | | | | |
| Rack-and-pinion | Power steering | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
|  | FRONT MECHANICAL SUSPENSIONS: | | | | | | | | | | | | | | | | | | |
| | independent with transverse leaf spring (MK3) | | | | | | | | | | | | | | | | | | |
| | independent with torsion bars | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | REAR MECHANICAL SUSPENSIONS: | | | | | | | | | | | | | | | | | | |
| | Parabolic | ◇ | ◇ | ◇ | ◇ | ◇ | ◇ | ◇ | ◇ | ◇ | ◇ | ◇ | ◇ | ◇ | ◇ | ◇ | ◇ | ◇ | |
| | - single leaf | | | | | | | | | | | | | | | | | | |
| | - reinforced | | | | | | | | | | | | | | | | | | |
| Semi-elliptical | ⊕ | ⊕ | ⊕ | ⊕ | ⊕ | ⊕ | ⊕ | ⊕ | ⊕ | ⊕ | ⊕ | ⊕ | ⊕ | ⊕ | ⊕ | ⊕ | ⊕ | | |
| Semi-elliptical with leaf spring | ◆ | ◆ | ◆ | ◆ | ◆ | ◆ | ◆ | ◆ | ◆ | ◆ | ◆ | ◆ | ◆ | ◆ | ◆ | ◆ | ◆ | | |
|  | REAR AIR SUSPENSIONS | ◐ | ◻ | ◐ | ◻ | ◐ | ◻ | ◻ | ◻ | ◻ | ◻ | ◻ | ◻ | ◻ | ◻ | ◻ | ◻ | | |

ID = Direct injection
 NA = Aspirated
 PC = Indirect injection (pre-combustion chamber)
 TCA = Turbocharged with intercooler
 OXICAT = Catalytic silencer
 O.D. = Over Drive
 V.D. = Van Direct
 (•) Optional extra (with max load of 1900 kg)
 ○ Standard
 ◻ Alternative
 * With Common Rail: 43XX, MS6.3 - 44XX, EDC 16 electronic injection system
 EGR = Anti-pollution device
 ■ Vehicle category M1
 ◻ Non-EU markets
 ◻ Vehicles made until 9/01
 ◻ Vehicles made since 9/01
 ◐ Vehicles with front suspension with transverse leaf spring
 ◐ Vehicles with front suspension with torsion bars

⊕ Standard on chassis cabs and vans 40C
 Alternatively on Vans – Chassis Cowl and Cut Aways
 ◇ Standard on Vans (excluding 40C) – Chassis Cowl and Cut Aways – Alternatively on Chassis Cabs
 • Except for 35 S chassis-cabs and chassis-cowls - Combi
 ◆ Chassis cabs only, as an alternative
 ◐ Not provided on 35C (with max. load of 1900 kg and tyres 135/75 R16) and 40 C Chassis cabs - 40 C Vans and Cut Aways
 S Single rear wheels
 ▽ Camper van version
 L = Light with single rear wheels
 C = Twin rear wheels
 BUS = Glazed vans – Glazed Vendor – Chassis Cowl – Cut Aways, bodied or adaptable to carry passengers

COMPOSITION OF MODELS

| MODELS | | ASSEMBLIES | | | | | | | | | |
|---|--|------------|---------|---------|---------|----------------|----------------|----------------|----------------|----------------|----------------|
| | | 60 C 15 | 60 C 17 | 65 C 15 | 65 C 17 | A35 S 13 (BUS) | A40 C 13 (BUS) | A40 C 15 (BUS) | A50 C 13 (BUS) | A50 C 15 (BUS) | A65 C 15 (BUS) |
|  | 8140.63.4.. (85 CV PC/NA + EGR + OXICAT) | | | | | | | | | | |
| | 8140.43R.43XX/44XX (90 CV ID/TCA*) | | | | | | | | | | |
| | 8140.43B.43XX/44XX (105 CV ID/TCA*) | | | | | | | | | | |
| | 8140.43C.40XX (105 CV ID/TCA + OXICAT) | | | | | | | | | | |
| | 8140.43S.41XX (125 CV ID/TCA* E.G.R. + OXICAT) | | | | | | | | | | |
| | 8140.43S.43XX/44XX (125 CV ID/TCA*) | | | | | o | o | | o | | |
| | 8140.43N.43XX/44XX (150 CV ID/TCA*) | o | | o | | | | o | | o | o |
| | FIAE048IA*A (96 CV) | | | | | | | | | | |
| | FIAE048IB*A (116 CV) | | | | | | | | | | |
| | FIAE048IB*B (116 CV + E.G.R. + OXICAT) | | | | | | | | | | |
| | FIAE048ID*A (136 CV) | | | | | | | | | | |
| | FICE048IA | | | | | | | | | | |
| FICE048IB | | o | | o | | | | | | | |
|  | Single disk 9" 1/4 | | | | | | | | | | |
| | Single disk 10" 1/2 | | | | | o | o | | o | | |
| | Single disk 11 | o | o | o | o | | | o | | o | |
|  | ZF 5S 200 | | | | | | | | | | |
| | ZF 5S 270 | | | | | | | | | | |
| | ZF 5S 300 | | | | | | | | | | |
| | ZF 6S 300 | o | | o | | o | o | o | o | o | |
| | ZF 6AS 300 V.D. | | | | | | | | | | |
| | ZF 6S 380 O.D. | | o | | o | | | | | | |
|  | FRONT AXLES: | | | | | | | | | | |
| | 5817 | | | | | o | | | | | |
| | 5818 | | | | | | | | | | |
| | 5819 | | | | | | o | o | o | o | |
| | 5823 | o | o | o | o | | | | | o | |
|  | 450210 | | | | | o | | | | | |
| | 450310 | | | | | | | | | | |
| | 450311/1 | | | | | | o | o | | | |
| | 450511 | | | | | | | | o | o | |
| | 450517/2 | o | o | o | o | | | | | o | |
| Rack-and-pinion | Power steering | o | o | o | o | o | o | o | o | o | |
|  | FRONT MECHANICAL SUSPENSIONS: | | | | | | | | | | |
| | independent with transverse leaf spring (MK3) | | | | | o | | | | | |
| | independent with torsion bars | o | o | o | o | o | o | o | o | o | |
| | REAR MECHANICAL SUSPENSIONS | Parabolic | ◇ | | ◇ | | | o | o | o | o |
| | - single leaf | | | | | o | | | | | |
| | - reinforced | | | | | | | | | | |
| Semi-elliptical | ⊞ | ⊞ | ⊞ | ⊞ | | | | | | | |
| Semi-elliptic with leaf spring | ◆ | ◆ | ◆ | ◆ | | | | | | | |
|  | REAR AIR SUSPENSIONS | □ | □ | □ | □ | □ | □ | □ | □ | □ | |

ID = Direct injection
 NA = Aspirated
 PC = Indirect injection (pre-combustion chamber)
 TCA = Turbocharged with intercooler
 OXICAT = Catalytic silencer
 O.D. = Over Drive
 V.D. = Van Direct
 (•) Optional extra (with max load of 1900 kg)
 o Standard
 □ Alternative
 * With Common Rail: 43XX, MS6.3 - 44XX, EDC 16 electronic injection system
 EGR = Anti-pollution device
 Vehicle category M1
 Non-EU markets
 Vehicles made until 9/01
 Vehicles made since 9/01
 Vehicles with front suspension with transverse leaf spring
 Vehicles with front suspension with torsion bars

⊞ Standard on chassis cabs and vans 40C
 Alternatively on Vans – Chassis Cows and Cut Aways
 ◇ Standard on Vans (excluding 40C) – Chassis Cows and Cut Aways – Alternatively on Chassis Cabs
 • Except for 35 S chassis-cabs and chassis-cows - Combi
 ◆ Chassis cabs only, as an alternative
 ● Not provided on 35C (with max. load of 1900 kg and tyres 135/75 R16) and 40 C Chassis cabs - 40 C Vans and Cut Aways
 S Single rear wheels
 V Camper van version
 L = Light with single rear wheels
 C = Twin rear wheels
 BUS = Glazed vans – Glazed Vendor – Chassis Cows – Cut Aways, bodied or adaptable to carry passengers

ALPHANUMERICAL CODING FOR VEHICLE IDENTIFICATION

CUSTOMIZED VEHICLE (V.P.)

MARKET VEHICLE (V.M.)

STANDARD VEHICLE (V.C.B.)

I 2 3 4 5 6 7 8 9 10 11 12 13 14

RANGE









I 2 3 4 5 6 7 8 9 10 11 12 13 14



LIGHT ROAD VEHICLES

PROGRAMMING FAMILY






I 2 3 4 5 6 7 8 9 10 11 12 13 14






| | | | | | |
|----------|---|--------|----------------|---|---------------------------------------|
| 1 |  | L 30 | { 29 L 35 S | } | CHASSIS CABS AND DERIVATIVES * |
| 2 |  | L 35 | { 35 C 40 C | | |
| 3 |  | L 50 | { 50 C 45 C | | |
| 4 |  | L 65 | { 60 C 65 C | | |
| 5 |  | L 30 A | { 29 L 35 S | } | VANS AND DERIVATIVES * |
| 6 |  | L 35 A | { 35 C 40 C | | |
| 7 |  | L 50 A | { 50 C 45 C | | |
| 8 |  | L 65A | { 60 C 65 C | | |

* With engines 8140

PROGRAMMING FAMILY

1 2 3 4 5 6 7 8 9 10 11 12 13 14

| | | | | | |
|----------|---|------|----------------|---|---------------------------------------|
| H |  | F 25 | { 29 L | } | CHASSIS CABS AND DERIVATIVES • |
| M |  | F 30 | { 35 S | | |
| E |  | F 35 | { 35 C 40 C | | |
| P |  | F 50 | { 50 C 45 C | | |
| Q |  | F 65 | { 60 C 65 C | | |

| | | | | | |
|----------|---|--------|----------------|---|-------------------------------|
| L |  | F 25 A | { 29 L | } | VANS AND DERIVATIVES • |
| N |  | F 30 A | { 35 C | | |
| G |  | F 35 A | { 35 C 40 C | | |
| R |  | F 50 A | { 50 C 45 C | | |
| S |  | F 65 A | { 60 C 65 C | | |

• With engines FIA - FIC

ENGINE

1 2 3 4 5 6 7 8 9 10 11 12 13 14


A  **8140.63.40XX PC/NA - 85 CV**


B  **8140.43 C.40XX ID/TCA - 105 CV**

E  **8140.43 S.41XX ID/TCA - 125 CV (MI)**

ENGINE

I **2** **3** **4** **5** **6** **7** **8** **9** **10** **11** **12** **13** **14**

F  **8140.43 B.43XX ID/TCA - 105 CV**

G  **8140.43 S.43XX ID/TCA - 125 CV**

H  **8140.43 N.43XX ID/TCA - 150 CV**

M  **8140.43 R.43XX ID/TCA - 90 CV**

J  **FIAE048IA ID/TCA - 96 CV**

K  **FIAE048IB ID/TCA - 116 CV**

L  **FIAE048IB ID/TCA - 116 CV (MI)**

P  **FICE048IA ID/TCA - 136 CV**

Q  **FICE048IB ID/TCA - 166 CV**


R  **FIAE048ID ID/TCA - 136 CV**

SUSPENSION



- A** Mechanical suspension: front with transverse leaf spring.
- B** Mechanical suspension: front with torsion bars.
- C** Mechanical front suspension with transverse leaf spring – rear air suspension.
- D** Mechanical front suspension with torsion bars – rear air suspension.

VERSION



**CHASSIS
CAB**

35 S.9 (•) - 29 L.9 - 35 S.11 (•)
 29 L.10 (•) - 29 L.11 - 29 L.12 (•)
 35 S.10 (•) - 35 S.12 (•) - 35 S.13 (•)
 35 S.15 (•) 35 S.17 (•) - 35 C.9 (•)
 35 C.10 (•) - 35 C.11 (•) - 35 C.12 (•)
 35 C.13 (•) - 35 C.14 (•) - 35 C.15 (•)
 35 C.17 (•) - 40 C.9 - 40 C.11 - 40 C.12
 45 C.11 - 45 C.13 - 45 C.14 (•) - 45 C.17 (•)
 50 C.11 (•) - 50 C.13 (•) - 50 C.14 (•)
 50 C.15 (•) - 50 C.17 (•) - 60 C.15 (•)
 60 C.17 (•) - 65 C.15 (•) - 65 C.17 (•)



**CHASSIS
CAB
6 + 1**

29 L.9 D - 29 L.10 D (•) - 29 L.11 D
 29 L.12 D (•) - 35 S.9 D (•) - 35 S.10 D (•)
 35 S.11 D (•) - 35 S.12 D (•) - 35 S.13 D (•)
 35 S.15 D (•) - 35 S.17 D (•) - 35 C.9 D (•)
 35 C.10 D (•) - 35 C.11 D (•) - 35 C.12 (•)
 35 C.13 D (•) - 35 C.14 D (•) - 35 C.15 D (•)
 35 C.17 D (•) - 40 C.12 D - 40 C.13 D
 45 C.11 D - 45 C.13 D - 45 C.14 D (•)
 45 C.17 D (•) - 50 C.11 D (•) - 50 C.13 D (•)
 50 C.14 D (•) - 50 C.15 D (•) - 50 C.17 D (•)
 60 C.15 D - 60 C.17 D - 65 C.15 D (•)
 65 C.17 D (•)



**CHASSIS
COWL**

29 L.9 CC - 29 L.10 CC (•) - 29 L.11 CC
 29 L.12 CC (•) - 35 S.9 CC (•) - 35 S.10 CC (•)
 35 S.11 CC (•) - 35 S.12 CC (•) - 35 S.13 CC (•)
 35 S.15 CC (•) - 35 S.17 CC (•) - 35 C.9 CC (•)
 35 C.10 CC (•) - 35 C.11 CC (•) - 35 C.12 CC (•)
 35 C.13 CC (•) - 35 C.14 CC (•) - 35 C.15 CC (•)
 35 C.17 CC (•) - 40 C.9 CC - 40 C.10 CC
 40 C.11 CC - 40 C.12 CC - 40 C.13 CC
 40 C.14 CC (•) - 40 C.17 CC (•) - 45 C.11 CC
 45 C.13 CC - 45 C.14 CC (•) - 45 C.17 CC (•)
 50 C.11 CC (•) - 50 C.13 CC (•) - 50 C.14 CC (•)
 50 C.15 CC (•) - 50 C.17 CC (•) - 60 C.15 CC
 60 C.17 CC (•) - 65 C.15 CC (•) - 65 C.17 CC (•)

(•) present version /P too (rear air suspensions)

VERSION

1

2

3

4

5

6

7

8

9

10

11

12

13

14


**CHASSIS
COWL SHORT**

29 L.9 CCS - 29 L.10 CCR (•) - 29 L.11 CCS
 29 L.12 CCR (•) - 35 S.9. CCS (•)
 35 S.10 CCS (•) - 35 S.10CCR (•)
 35 S.11 CCS (•) - 35 S.12 CCR (•)
 35 S.12 CCS (•) - 35 S.13 CCS (•)
 35 S.15 CCS (•) 35 S.17 CCR (•)
 35 C.9 CCS (•) - 35 C.10 CCR
 35 C.10 CCS (•) - 35 C.11 CCS (•)
 35 C.12 CCR - 35 C.12 CCS (•)
 35 C.13 CCS (•) - 35 C.14 CCR (•)
 35 C.15 CCS (•) - 35 C.17 CCR (•)
 40 C.9 CCS - 40 C.10 CCR - 40 C.11 CCS
 40 C.12 CCR - 40 C.13 CCS - 40 C.14 CCR (•)
 40 C.17 CCR (•) - 45 C.11 CCS
 45 C.13 CCS - 45 C.14 CCR (•)
 45 C.17 CCR (•) - 50 C.11 CCS (•)
 50 C.13 CCS (•) - 50 C.14 CCS (•)
 50 C.15 CCS (•) - 50 C.17 CCS (•)
 60 C.15 CCS - 60 C.17 CCS (•)
 65 C.15 CCS (•) - 65 C.17 CCS (•)


CUT-AWAY

35 C.9 CA (•) - 35 C.10 CA (•)
 35 C.11 CA (•) - 35 C.12 CA (•)
 35 C.13 CA (•) - 35 C.15 CA (•)
 40 C.9 CA - 40 C.10 CA - 40 C.11 CA
 40 C.12 CA - 45 C.11 CA - 45 C.13 CA
 45 C.17 CA (•) - 50 C.11 CA (•)
 50 C.13 CA (•) - 50 C.15 CA (•) - 50 C.17 CA (•)
 60 C.15 CA - 60 C.17 CA (•) - 65 C.15 CA (•)
 65 C.17 CA (•)


VAN

29 L.9 V - 29 L.10 V (•) - 29 L.11 V
 29 L.12 V (•) - 35 S.9 V (•) - 35 S.10 V (•)
 35 S.11 V (•) - 35 S.12 V (•) - 35 S.13 V (•)
 35 S.15 V (•) - 35 S.17 V (•) - 35 C.9 V (•)
 35 C.10 V (•) - 35 C.11 V (•) - 35 C.12 V (•)
 35 C.13 V (•) - 35 C.14 V (•) - 35 C.15 V (•)
 35 C.17 V (•) - 40 C.9 V - 40 C.10 V
 40 C.11 V - 40 C.12 V - 40 C.13 V
 40 C.14 V (•) - 40 C.17 V (•) - 45 C.11 V
 45 C.13 V - 45 C.14 V (•) - 45 C.17 V (•)
 50 C.11 V (•) - 50 C.13 V (•) - 50 C.15 V (•)
 60 C.15 V - 65 C.15 V (•)


**SEMI-GLAZED
VAN**

29 L.10 SV (•) - 29 L.12 SV (•) - 30 S.9 SV
 30 S.11 SV - 35 S.9 SV (•) - 35 S.10 SV (•)
 35 S.11 SV (•) - 35 S.12 SV (•) - 35 S.13 SV (•)
 35 S.15 SV (•) - 35 S.17 SV (•) - 35 C.9 SV (•)
 35 C.10 SV (•) - 35 C.11 SV (•) - 35 C.12 SV (•)
 35 C.13 SV (•) - 35 C.14 SV (•) - 35 C.15 SV (•)
 35 C.17 SV (•) - 40 C.9 SV - 40 C.10 SV
 40 C.11 SV - 40 C.12 SV - 40 C.13 SV
 40 C.14 SV (•) - 40 C.17 SV (•) - 45 C.11 SV
 45 C.13 SV - 45 C.14 SV (•) - 45 C.17 SV (•)
 50 C.11 SV (•) - 50 C.13 SV (•) 50 C.15 SV (•)
 50 C.17 SV (•) - 65 C.15SV (•)

(•) present version /P too (rear air suspensions)

VERSION

- 1
- 2
- 3
- 4
- 5
- 6
- 7
- 8
- 9
- 10
- 11
- 12
- 13
- 14

U **VENDOR VERSION CITY VAN**

29 L.9 C.V. - 29 L. 10 C.V. (•) - 29 L.12 C.V. (•)
 29 S.11 C.V. - 35 S.9 C.V. (•) - 35 S.10 C.V. (•)
 35 S.11 C.V. (•) - 35 S.12 C.V. (•)
 35 S.13 C.V. (•) - 35 S.15 C.V. (•)
 35 C.9 C.V. (•) - 35 C.10 C.V. (•)
 35 C.11 C.V. (•) - 35 C.12 C.V. (•)
 35 C.13 C.V. (•) - 35 C.15 C.V. (•)
 40 C.10 C.V. - 40 C.12 C.V. - 45 C.14 CV (•)
 45 C.17 CV (•) - 50 C.11 C.V. (•)
 50 C.13 C.V. (•) - 50 C.14 C.V. (•)
 50 C.15 C.V. (•) - 50 C.17 C.V. (•)

5 **COMBI**

29 L.12 C (•) - 35 S.9 C (•) - 35 S.11 C (•)
 35 S.12 C (•) - 35 S.13 C (•)

8 **CAMPER**

35 S.14 (•) - 35 C.14 - 35 S.17 (•) - 35 C.17

9 **CHASSIS-COWL SHORT VERSION FOR CAMPER VAN**

35 S.14 CCRC (•) - 35 C.14 CCRC -
 35 S.17 CCRC (•) - 35 C.17 CCRC

(•) present version /P too (rear air suspensions)

WHEELBASE

- 1
- 2
- 3
- 4
- 5
- 6
- 7
- 8
- 9
- 10
- 11
- 12
- 13
- 14

1 **3000 mm (L30 - L30A - L35A - L50A - F25 - F30 - F25A - F30A - F35A - F50A)**

1 **3000 L mm (F35) •**

2 **3000 L mm (L35 - L50 - L30A - L35A - L50A - F25A - F30A - F35A - F50A)**

3 **3300 mm (L30A - L35A - L50A - L65A - F65 - F25A - F30A - F35A - F50A)**












3 **3450 mm (L30 - L35 - L50 - L65) ***

4 **3450 mm (F25 - F30 - F35 - F50 - F65) •**

* With engines 8140
 • With engines FIA - FIC

WHEELBASE









| | | |
|----------|---|---|
| 4 |  | 3750 mm (L30 - L35 - L50 - L65) * |
| 4 |  | 3950 mm (L30A - L35A - L50A - L65A) * |
| 5 |  | 4100 mm (L35) * |
| 5 |  | 3750 mm (F30 - F35 - F50 - F65) • |
| 6 |  | 3950 mm (F30 - F35 - F25A - F30A - F35A - F50A - F65A) • |
| 6 |  | 4750 mm (L50 - L65) • |
| 7 |  | 4100 mm (F35) • |
| 7 |  | 4350 mm (L50 - L65) * |
| 8 |  | 3950 mm (L30 - L35) * |
| 8 |  | 4350 mm (F50 - F65) • |
| 9 |  | 4750 mm (F50 - F65) • |

- * With engines 8140
- With engines F1A - F1C

GEARBOX











| | | | |
|----------|---|----------------|----------------------------|
| A |  | 5 SPEED | (5 S 200 - 5 S 270) |
| B |  | 6 SPEED | (6 S 300) |
| C |  | 5 SPEED | (5 S 300) |
| D |  | 6 SPEED | (6 AS 300 V.D.) |
| E |  | 6 SPEED | (6 S 380 O.D.) |
| F |  | 6 SPEED | (6 AS 380 O.D.) |

A Automated
 O.D. Over Drive
 V.D. Van Direct

DRIVE - INTERNAL HEIGHT OF LOADING BAY

| | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|

| | | |
|--|--|-----------------|
| <p>LEFT-HAND DRIVE (L30 - L35 - L50 - L65)* (F25 - F30 - F35 - F40 - F65) •</p> |  | <p>I</p> |
| <p>LEFT-HAND DRIVE AND INTERNAL HEIGHT OF LOADING BAY H₁ = 1545 mm (L30A - L35A - L50A - L65A) * (F25A - F30A - F35A - F50A - F65A) •</p> |  | <p>I</p> |
| <p>LEFT-HAND DRIVE AND INTERNAL HEIGHT OF LOADING BAY H₂ = 1900 mm (L30A - L35A - L50A - L65A) * (F25A - F30A - F35A - F50A - F65A) •</p> |  | <p>2</p> |
| <p>LEFT-HAND DRIVE AND INTERNAL HEIGHT OF LOADING BAY H₃ = 2100 mm (L30A - L35A - L50A - L65A)* (F30A - F35A - F50A - F65A) •</p> |  | <p>3</p> |
| <p>RIGHT-HAND DRIVE (L30 - L35 - L50 - L65) * (F25 - F30 - F35 - F50A - F65A) •</p> |  | <p>A</p> |
| <p>RIGHT-HAND DRIVE AND INTERNAL HEIGHT OF LOADING BAY H₁ = 1545 mm (L30A - L35A - L50A - L65A) * (F25A - F30A - F35A - F50A - F65A) •</p> |  | <p>A</p> |
| <p>RIGHT-HAND DRIVE AND INTERNAL HEIGHT OF LOADING BAY H₂ = 1900 mm (L30A - L35A - L50A - L65A) * (F25A - F30A - F35A - F50A - F65A) •</p> |  | <p>B</p> |
| <p>RIGHT-HAND DRIVE AND INTERNAL HEIGHT OF LOADING BAY H₃ = 2100 mm (L30A - L35A - L50A - L65A) * (F30A - F35A - F50A - F65A) •</p> |  | <p>C</p> |

- * With engines 8140
- With engines F1A - F1C

MANDATORY MARKET OPTIONAL EXTRAS

| | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|

OPTIONAL EXTRAS REQUIRED BY THE CUSTOMER

| | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|

ALPHANUMERICAL CODING FOR BUS IDENTIFICATION

CUSTOMIZED VEHICLE (V.P.)

MARKET VEHICLE (V.M.)

STANDARD VEHICLE (V.C.B.)

1 2 3 4 5 6 7 8 9 10 11 12 13 14

RANGE

1 2 3 4 5 6 7 8 9 10 11 12 13 14



LIGHT ROAD VEHICLES

PROGRAMMING FAMILY

1 2 3 4 5 6 7 8 9 10 11 12 13 14

A **LBU1 35 S**

B **LBU2 40 C**

C **LBU2 50 C**

ENGINE

1 2 3 4 5 6 7 8 9 10 11 12 13 14

G **8140.43 S.43XX ID/TCA - 125 CV**

H **8140.43 N.43XX ID/TCA - 150 CV**

SUSPENSION

- 1
- 2
- 3
- 4
- 5
- 6
- 7
- 8
- 9
- 10
- 11
- 12
- 13
- 14

- A** Mechanical suspension: front with transverse leaf spring.
- B** Mechanical suspension: front with torsion bars.
- C** Mechanical front suspension with transverse leaf spring
– rear air suspension.
- D** Mechanical front suspension with torsion bars
– rear air suspension.




VERSION

- 1
- 2
- 3
- 4
- 5
- 6
- 7
- 8
- 9
- 10
- 11
- 12
- 13
- 14

- V **GLAZED VENDOR** LBU2
- F **GLAZED VAN** LBU1
LBU2
- 2 **MINIBUS** LBU2
- 3 **HIRE** LBU2
- I **PRIMARY SCHOOLS** LBU2
- M **MIDDLE SCHOOLS** LBU2

GEARBOX – WHEELBASE




| | | | |
|----------|---|-----------------------------|----------------------------|
| A |  | 5 SPEED 3000 L mm | LBUI |
| B |  | 6 SPEED 3000 L mm | LBUI LBU2 |
| C |  | 6 SPEED 3950 mm | LBU2 |

DRIVE – INTERNAL HEIGHT OF LOADING BAY




















LEFT-HAND DRIVE AND INTERNAL HEIGHT OF LOADING BAY $H_1 = 1900$ mm (LBUI - LBU2)



RIGHT-HAND DRIVE AND INTERNAL HEIGHT OF LOADING BAY $H_2 = 1900$ mm (LBUI - LBU2)



REPLENISHING FLUIDS


| IVECO RECOMMENDED LUBRICANTS | | PARTS TO BE REPLENISHED | Quantity | | | |
|--|---|---|-----------------------------------|------|------|--|
| | | | Litres | kg | | |
|  | Urania Daily Urania LD 5 |  Engine 8140 | Sump + filter capacity | 6.3 | 6.7 | |
| | | | Sump capacity | 5.2 | 4.6 | |
| | | | Total dry engine capacity | 6.9 | 6.1 | |
| | |  Engine FIA | Sump capacity: | | | |
| | | | - max level | 5.2 | 4.6 | |
| | | | - min level | 3.5 | 3.1 | |
|  Engine FIC | Quantity of oil in circulation in the cartridge filter and heat exchanger | 1.4 | 1.23 | | | |
| | Total dry engine capacity | 5.7 | 5.02 | | | |
| | Sump capacity: | | | | | |
| | | - max level | 4.3 | 3.78 | | |
| | | - min level | 3 | 2.65 | | |
|  | Max. gradient negotiable by vehicle uphill/downhill with oil at minimum level 30% | | | | | |
| |  |  | Gearbox | | | |
| | | | ZF 5S 200 - ZF 5S 270 - ZF 5S 300 | 2 | 1.8 | |
| | | | ZF 6S 300 - ZF 6 AS 300 V.D. | 2.7 | 2.43 | |
| | | ZF 6S 380 O.D. | 2.2 | - | | |
|  | Tutela W140/M-DA (SAE 85W140) |  | Front axle: | | | |
| | | | 5817 | - | - | |
| | | | 5818 | - | - | |
| | | | 5819 | - | - | |
| | | | 5823 | - | - | |
|  | Tutela W140/M-DA (SAE 85W140) |  | Rear axles: | | | |
| | | | 450210 | 1.8 | 1.5 | |
| | | | 450310 | 1.85 | 1.6 | |
| | | | 450311/1 | 1.9 | 1.65 | |
| | | | 450511 | 1.9 | 1.65 | |
| | | 450517/2 | 3 | 2.7 | | |
|  | Tutela GI/A |  | Power steering | 1.4 | 1.3 | |
|  | Tutela TRUCK DOT SPECIAL |  | Brake circuit | 1.11 | 1 | |
|  | Arexons DPI | | Windscreen washer | 5 | 4.5 | |
|  | Paraflu ¹¹ * | | Cooling system | 9 | - | |

* = Protective anti-freeze (concentration 50%, freezing point -35°C)

| International lubricant description | FL Group products |
|---|---|
| Engine oil meets specifications: ACEA B5 with synthetic base SAE 5W30 ACEA E3/E5 with mineral base | Urania Daily Urania LD5 |
| Differential and wheel hub oil meets specifications: API GL-5 with mineral base SAE 85W140 API GL-5 with mineral base SAE 80W90 | Tutela W 140/M - DA Tutela W 90/M - DA (1) |
| Mechanical gearbox oil containing non-EP anti-wear additives Meets specification API GL 4 SAE 75W80 | Tutela Truck Gearlite |
| Hydrostatic transmission and power steering oil Meets specifications: ATF-DEXRON II D | Tutela GI/A |
| General-purpose grease lithium soap based grease N.L.G.I. fluidity no. 2 | Tutela MR 2 |
| Specific grease for wheel hubs and bearings lithium soap based grease N.L.G.I. fluidity no. 3 | Tutela MR 3 |
| Hydraulic brake and clutch control fluid In conformity with N.H.T.S.A. standards No. 116, ISO 4925 Standard SAE J 1703, IVECO STANDARD 18-1820 | Tutela TRUCK DOT SPECIAL |
| Windscreen washer liquid Mixture of spirits, water and surfactants CUNA NC 956-11 | Tutela Professional SC 35 |
| Concentrated protective radiator fluid ethylene glycol based containing corrosion inhibitors, in conformity with Iveco Standard 18-1830 | Paraflu ¹¹ (2) |

(1) Specific for cold climates.

(2) 100% Paraflu to be diluted with water to 50%



SECTION 2**5401 Engines**

| | Page |
|--|------|
| ENGINES 8140.XXX | 3 |
| ENGINES WITH ELECTRONIC HIGH-PRESSURE INJECTION SYSTEM | 25 |
| <input type="checkbox"/> 8140.43R. 43XX/44XX | |
| <input type="checkbox"/> 8140.43B. 43XX/44XX | |
| <input type="checkbox"/> 8140.43S. 41XX | |
| <input type="checkbox"/> 8140.43S. 43XX/44XX | |
| <input type="checkbox"/> 8140.43N. 43XX/44XX | |
| <hr/> | |
| ENGINES WITH ROTARY MECHANICAL INJECTION PUMP | 209 |
| <input type="checkbox"/> 8140.43C. 43XX | 221 |
| <input type="checkbox"/> 8140.63C. 40XX | 249 |
| <hr/> | |
| FIA ENGINE | 287 |
| <hr/> | |
| FIC ENGINE | 489 |
| <hr/> | |

5401 Engines 8140.XXX

| | Page |
|---|------|
| MAIN SERVICING OPERATIONS TO BE PERFORMED ON VEHICLE ENGINE | 5 |
| ENGINE REMOVAL-REFITTING | 7 |
| <input type="checkbox"/> Removal (Engine 8140.43B/R/S) | 7 |
| <input type="checkbox"/> Removal (Engine 8140.43C - 8140.63) | 12 |
| <input type="checkbox"/> Refitting | 13 |
| <input type="checkbox"/> Checks and tests | 13 |
| <input type="checkbox"/> Bleending the fuel system | 14 |
| <input type="checkbox"/> Power steering system air bleed | 14 |
| OXICAT - OXYDIZER CATALYST (VEHICLES WITH 8140.43C - 8140.63 ENGINES) | 14 |
| <input type="checkbox"/> Description | 14 |
| <input type="checkbox"/> Cylinder head removal and refitting | 15 |
| <input type="checkbox"/> Removal | 15 |
| <input type="checkbox"/> Refitting | 16 |
| REPLACING BELTS | 17 |
| <input type="checkbox"/> Replacing air-conditioning compressor drive belt 7 | |
| <input type="checkbox"/> Disassembly | 17 |
| <input type="checkbox"/> Assembly and adjusting belt tension | 17 |
| <input type="checkbox"/> Replacing water pump - alternator drive belt .. | 17 |
| <input type="checkbox"/> Disassembly | 17 |
| <input type="checkbox"/> Assembly and adjusting belt tension | 17 |
| <input type="checkbox"/> Changing the timing system driving belt | 17 |
| <input type="checkbox"/> Disassembly | 17 |
| <input type="checkbox"/> Removal | 18 |
| <input type="checkbox"/> Refitting | 19 |
| REPLACING WATER PUMP | 20 |

| | Page |
|--|------|
| <input type="checkbox"/> Disassembly | 20 |
| <input type="checkbox"/> Assembly | 20 |
| REPLACING INJECTORS (ENGINE 8140.63 - 8140.43C) | 21 |
| <input type="checkbox"/> Disassembly | 21 |
| <input type="checkbox"/> Assembly | 21 |
| REPLACING INJECTION PUMP | 21 |
| <input type="checkbox"/> Disassembly | 21 |
| <input type="checkbox"/> Assembly and injection pump adjustment | 22 |
| ENGINE FLYWHEEL REMOVAL-REFITTING ... | 23 |
| <input type="checkbox"/> Removal | 23 |
| <input type="checkbox"/> Refitting | 23 |
| <input type="checkbox"/> Removal | 23 |
| <input type="checkbox"/> Refitting | 23 |

MAIN SERVICING OPERATIONS TO BE PERFORMED ON VEHICLE ENGINE



On vehicles equipped with 8140.43B/R/S (Common Rail) engines, follow the indications specified below before performing engine servicing operations that involve fuel system:

- before every engine servicing operation, perform engine/vehicle diagnosis by proper IVECO testers and print out obtained results.
- the replacement of central unit MS6.3 or EDC 16 must be authorised by the **Help Desk**;
- following components in feed system cannot be overhauled but have to be replaced: flow limiting devices, if present, pressure relief valve, if present, fuel pressure sensor, hydraulic accumulator, complete CPI high pressure feed pump, pressure control valve, electric injectors;
- Every Common Rail system part is packed by supplier into oil paper sheets and then stored into cardboard boxes. These parts shall be protected against dampness and shall be unpacked just before their use.
- Take utmost care to part cleanliness during filter and prefilter handling and fitting (even in case of simple replacement) to prevent foreign matters and dirt infiltration. To this purpose, hydraulic part and sensor protective plugs shall be removed just before refitting into place.
- Assembly direction shall be observed for all electric connections.
- Every threaded connection shall be tightened to the specified torque.
- Every quick coupling connector (on this engine find them on high pressure pump and diesel fuel draining duct) shall be fitted properly. Operate on the tabs set at connector base to remove them.

Electroinjector:

injector body connections/unions/nuts shall never be manipulated. Nozzle body and electromagnet shall never be disassembled, since this operation is not required and is forbidden.

When servicing operations on high pressure pipe are required, the hexagon on injector side shall be held with proper wrench.

Before servicing pipes, check whether injector is fitted into seat on cylinder head.

When removing/refitting injector draining duct, do not remove retaining spring from its seat on injector: when pushing the spring towards the engine and exerting a vertical force on connector, recycling is released. When refitting, put recycle connector into its seat and exert a vertical force by pressing the retaining spring towards engine. Fitting shall be friendly.

Rev. sensor (camshaft/flywheel):

during positioning, air gap between sensor and phonic wheel shall be falling within 0.8 and 1.5 mm and detection surface and wheel surface shall be parallel.

CPI high pressure pump:

no intervention is allowed on third pumping element cutoff device.

When servicing operations on high pressure pipe are required, the hexagon on pump side shall be held with proper wrench.

Before servicing high pressure pipe, check whether pump is properly fitted into its seat.

High pressure pipes

When removed, high pressure pipes shall not be reused but replaced.

Fixing connection tightening or loosening shall be performed with injectors, rail and high pressure pump perfectly secured and holding the hexagon on component side if there is enough space.

Rail and accessories

Pressure control device and pressure relief valve can be refitted 5 consecutive times, then they shall be replaced. Before refitting they shall be smeared with an oil film.

Overpressure valve shall be lubricated before refitting and its seal shall always be replaced.

For engine 8140.43S only - Since engine No. 3089322, a rail with the same configuration but without flow limiters and pressure relief valve has been mounted. The same prescriptions specified for the previous one shall be complied with.

540110 ENGINE REMOVAL-REFITTING**Removal (Engine 8140.43B/R/S)**

Set the vehicle over the pit or on the lift.

Lift up the bonnet (1), unscrew the screws securing it and take it off. Remove the prop (2).

Disconnect the negative cable (3) and the positive cable (5) from the battery (4) and detach this from the engine bay.

Unhook the cable (17) from the bonnet opening control devices.

Disconnect the electrical connections (8) of the front headlamps.

Unscrew the nuts (6) and screws (7), then remove the front cross member (16) with the light clusters.

Unscrew the screws (10, 12 and 14) and remove the bottom side guards (11 and 13).


Unscrew the eight nuts (9) and remove the bumper (15).

Underneath the vehicle (see Figure 4):

Unscrew the screws (8) and nuts (10), then remove the bottom side guards (11).

Unscrew the screws (⇒) and remove the central guard (12).

Figure 1



Take the cap (1) off the expansion tank (3).

Unscrew the coolant plug (10), under the radiator (11), and drain the cooling system.

Disconnect the heat exchanger pipes (7 and 8) from the intake manifold and from the turbocharger.

NOTE Close the turbocharger air outlet appropriately to prevent foreign bodies accidentally getting inside and damaging it.

Disconnect the coolant pipes (12, 13 and 16) from the radiator (11).

NOTE Vehicles with an air-conditioner in the cab should have the electrical connection (9) disconnected from the drier filter.

Disconnect the electrical connection (16) of the fan switch.

Unscrew the air filter bracket fasteners (17) to help extract the air intake pipe (18) from the duct (15) on the radiator assembly.

Unscrew the four screws (6) and remove the heat-exchanger radiator assembly (11).

NOTE For vehicles with an air-conditioner in the cab:

- Put the radiator, with condenser and drier filter, back into the engine bay, taking care not to put the air-conditioning system pipes under tension.


Disconnect the coolant pipes (2-19-20-21-22) from the relative pipes on the engine.

Disconnect the electrical connection (4).

Unscrew the nuts (5) and remove the expansion tank (3).

NOTE This figure refers to a vehicle provided with additional heater **A**.

Figure 2



Disconnect the electrical connections of the engine cable:

- (4), from the fascia wiring;
- (6), from the chassis frame cable;
- (7), from the electronic control unit;
- (8), of the earthing cable on the engine;
- (14), from the low engine oil level indicator;
- (25) from turbosupercharger actuator control solenoid valve (engine 8140.43N only);
- (13), from the diesel filter.

Disconnect the electrical connection (1) from the thermostart glow plug.

Disconnect the electrical connection (2) from the thermostart solenoid valve.

NOTE The remaining electrical connections of the engine cable should be disconnected from the relative electric components after removing the engine (see Figure 5).

Unscrew the screws (3) to free the engine cable from the body.

Disconnect the fuel pipe (11) from the high-pressure pump.

Disconnect the fuel recovery pipes (9 and 10).

Disconnect the pipe (12) from the vacuum pump.

Place a container under the power steering pump to recover the oil from the system. Then disconnect the oil inlet and outlet pipes (15 and 16).

Disconnect oil vapour piping (23) from flow control valve (for EGR versions only).

Disconnect air intake duct (22) from turbosupercharger.

Disconnect pressure pipe (24) from turbosupercharger actuator control solenoid valve (engine 8140.43N only).


NOTE Close the turbocharger air outlet appropriately to prevent foreign bodies accidentally getting inside and damaging it.

Attach the rocker arm 99360550 (5) to the lifting hooks on the engine. Hook it onto the hoist and put the engine slightly under traction.

NOTE Vehicles with air-conditioning in the cab should have the compressor (20) disconnected as follows:

- loosen the nut (17);
- unscrew the tightener screw (18);
- remove the drive belt (21);
- take out the screws (19) and put the compressor (20) back into the engine bay without disconnecting it from the system pipes.

Figure 3



Remove the sealing from the ring nut (1), unscrew it and disconnect the speedometer control cable.

Disconnect the electrical connection (4) from the reversing light switch.

Unscrew the screws (3) securing the propeller shaft (2) to the gearbox. Fasten the propeller shaft to the chassis frame appropriately.

Unscrew the screws (6) and the screw (5). Remove the crosspiece (7) supporting the gearbox complete with plug.

Disconnect the exhaust pipe (9) from the turbocharger outlet pipe.

Disconnect the screws (16 and 18) securing the brackets (15 and 17) and disconnect the "bowdens" (14 and 19) from the gearbox.

Unscrew the screws (20), move the clutch control cylinder (21), with its bracket, and fasten it to the chassis frame appropriately.

Remove the nuts (13) for the screws securing the engine brackets to the structural members and take out the screws.

Lift the engine assembly and take it out of the engine bay.

NOTE The engine should be taken out of the engine bay extremely carefully so as not to damage the top pipe of the power steering and the heatproof-soundproof covering of the engine bay.

Figure 4





Figure 5




50956

Disconnect the electrical connections (\Rightarrow) of the engine cable from the relative electric components.

Detach the gearbox from the engine as follows:

- stand the engine on a workbench so it is sufficiently stable;
- disconnect the starter motor and the bottom guard (1, Figure 6) from the gearbox;
- set the stand 99370620 on a hydraulic lift and apply it to the gearbox;
- take out the screws securing the gearbox to the engine;
- disconnect gearbox from engine.


Figure 6



62853

In case of difficulty, take the inspection cover off the front cover of the gearbox.

Using special pliers, open out the split ring retaining the thrust-bearing sleeve to the clutch plate and at the same time disconnect the gearbox from the engine.

Removal (Engine 8140.43C - 8140.63)**Figure 7**

51194

This differs from engine removal for the 8140.43S as there is no engine cable or electric components connected to it and in the following.

Disconnect the electric cables:

- (1), from the thermostart solenoid valve;
- (2), thermostart glow plug;
- (3), insufficient engine oil pressure indicator;
- (4), coolant temperature indicator;
- (5), temperature switch for K.S.B. and thermostart;
- (6), alternator;
- (7), temperature switch;
- (8), electric fan;
- (11), starter motor;
- (15) electric stop;
- (16), K.S.B.;
- (17), engine speed sensor.

Disconnect the throttle cable (9) from the injection pump and from the bracket.

Disconnect the fuel pipes (10 and 14) from the injection pump.

8140.63 (aspirated) engine only:

- (18), vacuum pipe from EGR valve;
- (19), EGR potentiometer electric cable;
- Disconnect the glow plug electrical connection from the control unit in the engine bay, above the battery.

NOTE The engine should be taken out of the engine bay extremely carefully so as not to damage the top pipe of the power steering and the heatproof-soundproof covering of the engine bay.



Refitting

To refit the power unit, reverse removal operations and observe the following indications:

- before refitting gearbox to engine, remove thrust bearing from diaphragm spring by opening circlip.
Fit thrust bearing on input shaft cover sleeve and connect it to clutch disengagement lever. Smear input shaft with Molikote molybdenum disulphate grease.
Engage a speed to rotate main shaft by rotating propeller shaft flange. Push down the gearbox to properly engage thrust bearing into diaphragm spring;
- take the utmost care when refitting the power unit into engine compartment;
- check the conditions of the coolant pipes or sleeves and of the air conveyors. Replace them if they show any sign of deterioration;
- check the flexible mountings of the assemblies: engine and gearbox. Replace them if they show any sign of deterioration;
- check that the exhaust pipe members have not deteriorated and are not about to deteriorate. If this is so, replace them along with the flexible parts for securing them;
- tighten the screws or nuts to the required torque;
- meticulously check the state of the vacuum pipe. It must show no sign of cracking, cutting, scoring or of being crushed. Replace it if there is any doubt at all about its soundness. When mounting it, make sure the pipe does not come into contact with sharp metal parts or corners or with any particularly hot parts. In addition, after assembly, the pipe must have no bends or constrictions, its radius of curvature should be broad and it must be secured to the vacuum pump fitting with a suitable clamp;
- make sure that the quick-coupling fittings of the fuel pipes are carefully cleaned and that, after their connection to the relevant unions of the high-pressure pump or of the fuel filter mounting, they are fully inserted and do not get disconnected.
- fill the cooling system with coolant.
- bleed the fuel supply system as described in the relative paragraph (only for engines 8140.63.4... - 8140.43C.4...);
- fill the power steering circuit and bleed the air as described in the relevant paragraph;
- check the level of oil in the engine and gearbox;
- adjust the tension of the drive belt of the compressor for the air-conditioner as described in "Replacing Belts" (if present).




When positioning the engine in the engine bay, take special care not to damage the top pipe of the power steering and the soundproof-heatproof cladding of the engine bay.

Once positioned, meticulously check that the top pipe of the power steering is sound.

Before using it again, check that the power steering oil and coolant contain no impurities. If they do, filter with suitable mesh filters. For any topping up, refer to the REPLENISHING FLUIDS table in the "GENERAL" section.

Figure 8



FUEL PIPES

1. High-pressure pump fuel pipe fast coupling - 2. Fuel supply pipe fast coupling 3. Fuel return pipe fast coupling - 4. Fuel filter mount.

If the fuel pipes (1-2-3) get disconnected from the mount (4), it is necessary, when refitting, to make sure their couplings are thoroughly clean. This is to prevent getting a bad seal and fuel leaking out as a result.

Checks and tests



Start up engine, leave running at a speed slightly in excess of idle speed and wait for coolant to heat sufficiently to open thermostat. Then check the following:



- no coolant leaks from coolant hose and cab interior heating hose connection sleeves. Tighten hose clips, if necessary;
- no oil leaks from between cover and cylinder head, oil sump and crankcase, oil filter and housing, heat exchanger and crankcase or from lubrication circuit lines;
- no fuel leaks from injection pump and injector lines. Tighten fittings if necessary;
- check that the indicator lights on the instrument panel and relating to the devices disconnected when the engine was removed are working properly.



542011 Bleeding the fuel system (see Figure 7) 8140.43C - 8140.63 engines only

Loosen bleed screw (12), operate priming pump lever (13) until complete bleeding of all the air in the system, tighten bleed screw.

NOTE If the engine stops for lack of fuel, resulting in air being introduced into the system (and if the bleeding process described above is no sufficient), it is necessary to loosen the unions of at least two injectors, rotate the engine and start it. When the air has been bled off, close the unions again.



501430 Power steering system air bleed

Check the level of oil in the tank and top it up if necessary. Lift the vehicle at the front, start up the engine and let it idle for some time. Check there is no oil leakage from the hydraulic circuit and check the level in the tank. Slowly turn the flywheel in both directions of steering so that the air in the hydraulic system comes out. Check the level of oil in the tank again and top up if necessary.

507130 OXICAT - OXYDIZER CATALYST (Vehicles with 8140.43C - 8140.63 engines)

Description

The oxidizing catalyst (1) is a post-treatment device for exhaust gases. It is used to oxidize CO, HC transforming them into carbon dioxide (CO₂) and steam (H₂O).

This catalyst also treats saturated and aromatic hydrocarbons forming part of the particulate, such as the carbon in the form of soot, metals, water and sulphur compounds that are exhausted.

The cylindrical-shaped catalyst consists of a ceramic honeycomb monolith whose cells are platinum-impregnated, a catalyzing substance of oxidation reactions. Its total volumetric capacity is equal to 600 cm³ with a density of 400 cells per square inch.


The exhaust gases passing through the cells heat the catalyst, converting the pollutants into inert compounds.

The chemical oxidation reaction of CO, HC and of the particulate is efficient with temperatures ranging between 200°C +350°C.

With temperatures higher than 350°C it starts oxidizing the sulphur contained in the diesel oil, generating sulphur dioxide (SO₂) and sulphur trioxide (SO₃), which are the cause of acid rain.

Correct catalyst sizing enables limiting the temperature, obtaining the greatest percentage of conversion of polluting emissions, while reducing the freezing of sulphur compounds.


Figure 9



455182

540610 Cylinder head removal and refitting

Figure 10



Removal

Remove the timing belt as described under the relevant heading (operation 541257).

Disconnect the electrical connections from the:

- cooling temperature indicator (11);
- "KSB" temperature switch (8140.63/43C engines only) and/or thermostart;
- air temperature and pressure sensor (4) (8140.43B/R/S engine only);
- expansion tank level indicator (14);
- disconnect the coolant pipes (2, 3 and 5);
- remove the expansion tank (15);
- remove the coolant pipes (10) from the water pump and from the heat exchanger pipe (9);
- take out the screw (1) and the nut securing the bracket fixing the pipes (10 and 16) to the inlet manifold;
- extract the oil vapour recirculation valve (6) from the duct (8) (8140.63 engine only);
- remove the exhaust pipes (7) from the turbocharger (8140.43C - 8140.43B/R/S engines only);
- remove the turbocharger (8140.43B/R/S/43 C engines only) from the inlet manifold;

- remove the pipe (19) from the rear cover of the cylinder head;
- take out the screw securing the engine electric cable bracket;
- take out the screw (20) securing the pipes (17) to the cylinder head;
- take out the screw (18) securing the oil vapour condenser;
- remove the top (23) and side (22) soundproofing;
- disconnect the electrical connections: (29) from the electro-injectors (26) (8140.43B/R/S engines only);
- (13) from the engine speed sensor (8140.43B/R/S and 8140.63 engines only);
- from the glow plugs (8140.63 engine only);
- from the fuel pressure sensor (25) (8140.43B/R/S engines only);
- remove the tappet cover.

8140.43B/R/S engines only

Disconnect fuel recovery pipe (28) from connection (24). Press clamps (32) and lift connections (31) at the same time, disconnect connections and pipes (28) from electroinjectors (26).

Disconnect the fuel pipes (28) from the electro-injectors (26) and from the hydraulic accumulator. Take out the screws securing the electro-injector brackets (20). Remove the electro-injectors (26) from the cylinder head.

62063

Disconnect the pipe (33) from the high-pressure pump and from the hydraulic accumulator.

8140.43B/R/S engine excluded

Disconnect the fuel pipes from the injection pump and from the injectors.

Disconnect the fuel recovery pipes from the injectors.

Disconnect the LDA pipe from the inlet manifold (8140.43 C engine only).

Take out the screws (27) and remove the cylinder head with its gasket.

Refitting

Refitting requires carrying out the operations for removal in reverse order, while taking the following precautions:

Check that the piston of cylinder No. 1 is at TDC.

Check that the mating surfaces of the cylinder head and crankcase are clean.

Keep the cylinder head gasket clean.

Position the cylinder head gasket, of the thickness determined in the "checking piston protrusion" paragraph, with the lettering "HIGH" facing the cylinder head.

NOTE It is essential to keep the gasket sealed in its package until just before assembly.


Before reusing the cylinder head fixing screws, measure their thread diameter to check it is no less than 11.5 mm at any point. If this is not so, replace them.

Turn the camshaft so that the valves of cylinder No. 1 are shut.

Mount the cylinder head. Insert the screws and tighten them, in three successive stages, following the order and method shown in the following figure.

NOTE The angle closure is done with tool 99395216.

Figure 11




6448

Tightening order diagram for cylinder heads fastening screws:

- 1st step: pre-tightening with torque wrench to torque of 60 ± 5 Nm;
- 2nd step: return to torque of 60 ± 5 Nm;
- 3rd step: closing with $180^\circ \pm 10^\circ$ angle.

Figure 12



62063

Clean spaces between rear cover (4) and cylinder head (3) from sealant residues and refill with IVECO 1905685 sealant.


Fit seal (2) on tappet cover (1). Smear tappet cover corners (\Rightarrow) with Silastic 732 RTV (approx. 10g). Refit tappet cover on cylinder head and tighten fixing nuts (5) to the specified torque.

Check the speed sensor is mounted as described under the relevant heading (8140.63 - 8140.43 S engines only).

When fitting the fuel pipes, don't use the metal clamp with the flexible plug and fixing screw. Replace them with new parts (8140.63 - 8140.43C engines only).

REPLACING BELTS

Figure 13



543910 Replacing air-conditioning compressor drive belt



Disassembly

Set the vehicle on a lift or over a pit.
From underneath the vehicle, detach the central soundproofing guard.

Loosen the screws (4 and 6) fixing the tensioner (5) and the nut (8).

Remove the belt (10) driving the compressor.



Assembly and adjusting belt tension



Mount the drive belt (10), taking care to position its ribs properly in the respective races of the pulleys.
Turn the screw (7) to lightly tension the belt (10).



Turn the crankshaft by one turn. Using the appropriate instrument, check that in section **B**, compressor/crankshaft, the frequency is 160 ± 10 Hz, corresponding to a load of 500 ± 50 N.

If this is not so, turn the screw (7) appropriately. Lock the screws (4 and 6) at the required tightening torque.

Unscrew the screw (7) by two turns and lock the nut (8) at the required torque.

Mount the radiator assembly and the remaining parts as described for refitting the engine assembly.

543411 Replacing water pump - alternator drive belt



Disassembly

Disassemble the compressor drive belt, if there is one, as described under the relevant heading.

Cancel the action of the automatic tightener (2) with the screw (3) and remove the water pump - alternator drive belt (1).



Assembly and adjusting belt tension



Mount the drive belt (1) taking care to position its ribs correctly in the respective races of the pulleys.

Turn the screw (3) to release the automatic tightener (2).

Turn the crankshaft by one turn to settle the belt.

With suitable equipment, measure the tension of the belt (1) in the section **A**, crankshaft / water pump / alternator, that should be 140 ± 5 Hz.

Mount the compressor drive belt, if there is one, and adjust the tension as described under the relevant heading.

543411 Changing the timing system driving belt




Disassembly

Following the procedures described for removing the engine, take out the radiator assembly without disconnecting the air-conditioning system pipes from the condenser and from the drier filter and put it suitably aside in the engine bay.

NOTE For this operation it is not necessary to remove the bumpers, it is sufficient to remove the air duct from the radiator and, for vehicles with engine 8140.63, to remove the screws securing the intake filter air inlet to the radiator.

50958

Figure 14



86142



Removal

Remove the air-conditioner compressor drive belt (7) (if there is one) and the water pump / alternator drive belt (6) as described under the relevant headings.

Remove the transverse air duct (3) without disconnecting the fuel pipe from the solenoid valve and the electric cables. Put it appropriately to one side in the engine bay (8140.63 engine excluded).

Take out the screw (11) securing the pulley and remove this from the crankshaft.

Remove the top (2) and side (1) soundproofing covers, if present.

Remove the top timing cover (4).

Arrange the engine so that cylinder piston 1 is at firing stroke TDC as follows.

Insert tool 99360608 (19) in hole (⇒) of transmission cover (20) from underneath the vehicle.

Turn the crankshaft slowly in the direction of rotation until the following conditions occur:

1) hole (15) of the crankshaft timing gear is facing downwards;

2) references **A** and **B** on the tappet cover and on the camshaft pulley coincide;

3) tool 99360608 (19) is inserted in the engine flywheel groove (18).


NOTE For engines 8140.43C - 814063 only (engines with rotary injection pump), in these conditions, stop the injection pump pulley (9) from turning by inserting another 99360608 tool through hole (8) and that of the auxiliary unit.

Remove the nut (16) securing the belt-tightening roller (17). Remove the bottom timing cover (10). Insert a special wrench (12) between the pin (14) and the push rod (13) so as to cancel its pressure on the belt-tightening roller (15). Remove the timing belt (5).



When removing the cogged belt after travelling ≥ 30000 km, replace it no matter what its state of efficiency.

Figure 15



50960

NOTE Replace the front crankshaft cover in the event of leakage as shown in the respective section (operation 540440).



Refitting

Mount the cogged belt (1).
Mount the bottom cover (4) and tighten the fixing screws to the required torque.
Remove the wrench (3) so that the push rod (2), acting on the belt tightener (7), tensions the cogged belt (1).
8140.43C - 8140.63 engines only.
Remove the tool 99360608 (5).

Check timing as follows.
Turn the crankshaft slowly in the direction of rotation by two turns and check that the conditions illustrated in removal procedure 1-2-3 are fulfilled when the timing belt is taut.

NOTE For 8140.43C - 8140.63 engines, in these conditions, check injection pump pulley timing by inserting tool 99360608 (5) through the pulley hole (6) and that of the auxiliary unit.

Tighten the nuts securing the tightener roller (7) at the torque of 37 ± 45 Nm.


Use tool 99395849 to check timing belt tension (1) which must be as follows in point **C**:

- engines 8140.43R/B/S/N: 90 - 115 Hz;
- engines 8140.43C - 8140.63: 88 - 112 Hz.

Then complete refitting by carrying out the operations described for removal in reverse order.

543210 REPLACING WATER PUMP

Figure 16



Disassembly

Disassemble the compressor drive belt (if there is one) and the water pump drive belt as described under the relevant headings. Remove the air manifold (20) without disconnecting the electric cables and the fuel pipe from the solenoid valve - thermostat glow plug in the engine bay.

Remove the side (18) (if present) and top (19) soundproofing covers from the cylinder head.

Remove the timing belt cover (17).

Remove the automatic tightener (14). Loosen the screw (15) for the nut securing the alternator to the mounting.

Take out the screw (12) securing the alternator to the water pump (1).

Insert a special wrench (16) between the pin (13) and the push rod (11) so as to cancel its pressure on the tightener roller (25). Take out the screws securing the piping (8) to the water pump (1).

Disconnect the electromagnetic pulley electrical connection (10).

Stop electromagnetic pulley (5) rotation using the proper tool. Unscrew clockwise (7) hub retaining nut (9) and remove the hub.

Remove the wrench (4) and the washer (3) from the water pump shaft (1) and take out the pulley (5). Remove the nuts and extract the electromagnetic coupling (2).

Shift the piston ring (22) downwards and insert the pipe (23) into the thermostat box so as to remove it from the water pump (1).

Take out the screws (24) and remove the water pump (1) from the crankcase.

Assembly

For assembly, carry out the operations for disassembly in reverse order, taking the following precautions:

- replace the seal rings of the pipe (23);
- clean the thread of the screws (24) and apply IVECO 1905683 sealant on their first 15 mm.

NOTE The hub locking nut (9) has a left-hand thread. The nut (7) must be replaced whenever disassembled.


Phase 1, tightening with torque wrench to a torque of 40 Nm.
Phase 2, closing with an angle of $110^\circ \pm 10^\circ$.

NOTE The nut (7) retaining the hub (9) has a left-hand thread.

NOTE The angle closure is performed with tool 99395216.

775010 REPLACING INJECTORS (ENGINE 8140.63 - 8140.43C)

Figure 17

**Disassembly**

Remove the air manifold (10) from the inlet manifold without disconnecting the electric cables and the fuel pipe. Put the air manifold (10) appropriately to one side in the engine bay. Take out the side soundproofing cover (if any) and the top cover (11). Remove the injectors (17 or 13), the fuel recovery pipe (16) and the fuel pipes (15). For engine 8140.43C, take out the screws (18) securing the injector brackets and remove the injectors from the cylinder head. For engine 8140.63, unscrew the injectors (13).

**Assembly**

For assembly, carry out the operations described for disassembly in reverse order, taking the following precautions:

- tighten the injectors of engine 8140.63 at a torque of 60 Nm (6 kgm);
- bleed the fuel air as described under the relevant heading.

771010 REPLACING INJECTION PUMP**Disassembly**

Remove the transverse air manifold (10) without disconnecting the fuel pipe and electric cables from the thermostart components. Put the transverse air manifold (10) appropriately to one side in the engine bay.

Remove the top (11) and side (if any) soundproofing covers. Remove the timing cover (6). Turn the crankshaft so as to align the camshaft pulley mark **A** with the tappet cover mark **B**, making it possible to insert tool 99360608 into the hole (5) in the pulley and into the hole in the auxiliary member assembly. If this is not possible, turn the crankshaft by one turn.

Remove the pipe bracket for the oil dipstick (7) from the auxiliary member assembly.

Disconnect the following from the injection pump:

- Electric cables:
 - (9), KSB device.
 - (14), electrostop.
 - (12), EGR potentiometer (if present);

50963

- fuel pipes (3 - 7, Figure 17);
- pipes delivering fuel to the injectors (15, Figure 17);
- vacuum pipe (8, Figure 17)
- bowden throttle control cable (1, Figure 17);

Disconnect the injection pump.

NOTE Having to refit the same injection pump that has been removed. Mark its assembly position on its mounting.

Connect the electric cable to the bulb (1, Figure 18) of the KSB device and power it with the voltage of the vehicle. This deactivates the KSB device.


From underneath the vehicle:

- remove the soundproofing guards of the engine/gear-box;
- disconnect the oil dipstick pipe (7, Figure 17);
- take out a nut securing the injection pump.

From the engine bay, take out the nuts securing the injection pump and remove the pump.


Assembly and injection pump adjustment

Figure 18



Take out the plug located on the pump closure screw and screw down tool 99395100 (2), with the rod in contact with the top of the timing piston. Preload the dial gauge 99395603 (3) by approx. 3 mm.


Figure 19



NOTE Having to replace the coupling (1), take the new part with the spare part number corresponding to the angle stamped on it.

Check the timing is correct.

Key the injection pump onto the auxiliary member assembly, making the groove (2), obtained in the pump drive shaft, with the protrusion (1) of the coupling. Screw down the nuts securing the pump without fully locking them.



NOTE The KSB device is deactivated when the timing advance control lever is no longer pulled.

Remove the tool 99360608 from the injection pump control pulley.

Turn the engine in the opposite direction to that of rotation until the injection pump timing piston reaches TDC, indicated by the dial gauge (3). Zero the dial gauge (3). Insert tool 99360608 (5) into the hole (⇒) of the gearbox cover (6). Slowly turn the crankshaft in its direction of rotation to insert tool 99360608 (5) into the slot in the engine flywheel (4). In the above condition, marks **A** and **B** (Figure 17) must coincide and the injection pump piston must have made the required travel. If this is not so, turn the pump body in its slot to obtain the required value shown by the dial gauge. Fully lock the nuts securing the pump to the auxiliary member assembly.

NOTE The injection pump fixing nut, crankcase side, is tightened with wrench 99352114.

Remove tool 99360608 (5).

Cut off supply to the KSB device.

Remove tool 99395100 (2, Figure 18) and screw the plug back onto the closing screw.

Finish mounting the parts removed, following the reverse order to disassembly.

540850 ENGINE FLYWHEEL REMOVAL-REFITTING



Removal

This operation includes:

- propeller shafts removal-refitting (see relevant section 505620)
- gearbox removal-refitting (see relevant section 530210)
- clutch removal-refitting (operation 505210).

For engines 8140.43C-8140.43 B/R/S proceed as follows:

Remove cylinder I injector (6) as specified in engine overhaul.

Fit tool 99395098 (2) with dial gauge 99395603 (1) into injector seat and secure it to cylinder head by clip (5) and screw (4).


Rotate the output shaft until reading piston (3) TDC position on dial gauge (1).

Apply gauge 99395214 (10) to engine block.

Operate on engine flywheel (13) to fit tool 99395214 (10) pin (11) into engine flywheel (13) milling.

Lock pin (11) by screw (12).

Figure 20



Remove the flywheel fastening screws, lift pin (11) from engine flywheel (13) milling and remove it.

NOTE Should rear cover leaks be found, replace the cover as described in the relevant chapter (operation 540460).



Refitting

Check on dial gauge (1) whether piston (3) is at TDC, otherwise operate on the output shaft to position it in said condition.

Position engine flywheel (13) on output shaft to fit tool pin (11) into flywheel milling and secure the fastening screws. Tighten flywheel fastening screws to the required torque. Refit injector as specified in engine overhaul.

For engines 8140.63:



Removal

Set cylinder I piston to TDC at compression stage (valves closed).

Fit tool 99395100 (8) including the dial gauge 99395603 (9) on injection pump (7) (after removing the plug); preload and set the dial gauge to zero.

Apply gauge 99395214 (10) to engine block and proceed as described for engines 8140.43C-8140.43 B/R/S.



Refitting

Check for no rotation of the output shaft on dial gauge (9). Otherwise reset it to dial gauge zero position.

Refit engine flywheel as described for engines 8140.43C-8140.43 B/R/S.

62851

5401 Engines with electronic high-pressure injection system

- 8140.43R.43XX/44XX
- 8140.43B.43XX/44XX
- 8140.43S.41XX
- 8140.43S.43XX/44XX
- 8140.43N.43XX/44XX

| | Page |
|--|------|
| EMISSIONS VALUES | 29 |
| <input type="checkbox"/> Engine 8140.43R.43XX/44XX | 29 |
| <input type="checkbox"/> Engine 8140.43B.43XX/44XX | 30 |
| <input type="checkbox"/> Engine 8140.43S.41 | 31 |
| <input type="checkbox"/> Engine 8140.43S.43XX/44XX | 32 |
| <input type="checkbox"/> Engine 8140.43N.43XX/44XX | 33 |
| GENERAL SPECIFICATIONS | 38 |
| ASSEMBLY DATA - CLEARANCES | 41 |
| TIGHTENING TORQUES | 46 |
| TOOLS | 49 |
| OVERHAULING ENGINE | 57 |
| DISASSEMBLING THE ENGINE AT THE BENCH | 57 |
| REPAIR OPERATIONS | 63 |
| CYLINDER BLOCK | 63 |
| <input type="checkbox"/> Checks and measurements | 63 |
| <input type="checkbox"/> Checking head mating surface on cylinder block | 64 |
| <input type="checkbox"/> Spare cylinder barrel assembling | 64 |
| CRANKSHAFT | 66 |
| <input type="checkbox"/> Measuring main journals and connecting rods . | 66 |
| <input type="checkbox"/> Checking crankshaft | 68 |
| <input type="checkbox"/> Replacing gearbox input shaft centering ring | 69 |
| <input type="checkbox"/> Replacing timing control gear | 69 |
| ENGINE ASSEMBLY | 69 |

| | Page | | Page |
|---|------|---|------|
| <input type="checkbox"/> Assembling main bearings | 69 | <input type="checkbox"/> Disassembling camshaft | 81 |
| <input type="checkbox"/> Measuring main journals assembly clearances . . | 70 | <input type="checkbox"/> Checks | 81 |
| <input type="checkbox"/> Checking crankshaft end float | 71 | <input type="checkbox"/> Checking cam lift and journal alignment | 82 |
| <input type="checkbox"/> Checking alignment pulley crankshaft | 71 | VALVE TAPPET | 82 |
| <input type="checkbox"/> Rear crankshaft cover | 71 | <input type="checkbox"/> Disassembling valves | 82 |
| <input type="checkbox"/> Front crankshaft cover | 71 | <input type="checkbox"/> Checking cylinder head seal | 83 |
| ENGINE FLYWHEEL | 72 | <input type="checkbox"/> Checking cylinder head mating surface | 83 |
| <input type="checkbox"/> Replacing bearing supporting gearbox input shaft | 72 | VALVES | 83 |
| <input type="checkbox"/> Replacing engine flywheel ring gear | 72 | <input type="checkbox"/> Removing deposits, refacing and checking valves | 83 |
| CONNECTING ROD - PISTON ASSEMBLY | 72 | <input type="checkbox"/> Checking clearance between valve stem and valve guide and centring valves | 84 |
| <input type="checkbox"/> Pistons | 74 | VALVE GUIDES | 84 |
| <input type="checkbox"/> Measuring the pistons diameter | 74 | <input type="checkbox"/> Replacing valve guides | 84 |
| <input type="checkbox"/> Piston gudgeon pins | 74 | <input type="checkbox"/> Reaming valve guides | 84 |
| <input type="checkbox"/> Conditions for correct pin-piston coupling | 74 | VALVE SEATS | 84 |
| <input type="checkbox"/> Piston rings | 75 | <input type="checkbox"/> Regrinding and replacing valve seats | 84 |
| <input type="checkbox"/> Connecting rods | 76 | VALVE SPRINGS | 86 |
| <input type="checkbox"/> Bushes | 76 | ASSEMBLING CYLINDER HEADS | 86 |
| <input type="checkbox"/> Checking connecting rod for distortion | 76 | <input type="checkbox"/> Assembling valves | 86 |
| <input type="checkbox"/> Checking torsion | 77 | <input type="checkbox"/> Assembling tappets | 87 |
| <input type="checkbox"/> Checking bending | 77 | <input type="checkbox"/> Assembling camshaft | 87 |
| <input type="checkbox"/> Assembling connecting rod - piston assembly . . | 77 | <input type="checkbox"/> Adjusting tappet clearance | 87 |
| <input type="checkbox"/> Coupling connecting rod - pistons | 77 | <input type="checkbox"/> Refitting cylinder head | 89 |
| <input type="checkbox"/> Checking for connecting rod - piston distortion | 78 | AUXILIARY MEMBER ASSEMBLY | 90 |
| <input type="checkbox"/> Assembling piston rings | 78 | <input type="checkbox"/> Disassembling auxiliary member assembly | 90 |
| <input type="checkbox"/> Assembling connecting rod - piston assemblies in cylinder barrels | 78 | <input type="checkbox"/> Oil pressure control valve | 91 |
| <input type="checkbox"/> Measuring connecting rod assembly clearance . . | 79 | OIL PUMP | 91 |
| <input type="checkbox"/> Checking piston protrusion | 79 | <input type="checkbox"/> Assembling auxiliary member assembly | 92 |
| <input type="checkbox"/> Flywheel adjustment | 80 | <input type="checkbox"/> 6-element heat exchanger | 94 |
| CYLINDER HEADS | 81 | | |


| | Page | | Page |
|---|------|---|------|
| LUBRICATION | 95 | | |
| <input type="checkbox"/> General | 95 | <input type="checkbox"/> Operation at low engine rpm | 108 |
| <input type="checkbox"/> Oil vapour recycling system | 95 | <input type="checkbox"/> Operation at high engine rpm | 108 |
| COOLING | 97 | <input type="checkbox"/> Proportional solenoid valve controlling turbocharger actuator | 109 |
| <input type="checkbox"/> Description | 97 | <input type="checkbox"/> Actuator | 109 |
| <input type="checkbox"/> Operation | 97 | REPAIRS | 110 |
| <input type="checkbox"/> Electromagnetic pulley | 98 | <input type="checkbox"/> Checking the actuator | 110 |
| <input type="checkbox"/> Water pump | 98 | FUEL SUPPLY | 111 |
| <input type="checkbox"/> Thermostat | 98 | HIGH-PRESSURE ELECTRONIC INJECTION SYSTEM (COMMON RAIL MS 6.3 OR EDC.16) | 111 |
| TIMING AND AUXILIARY MEMBER CONTROL | 99 | <input type="checkbox"/> General | 111 |
| <input type="checkbox"/> Setting the timing system | 99 | SYSTEM OPERATION | 113 |
| <input type="checkbox"/> Checking and aligning electromagnetic coupling pulleys | 101 | <input type="checkbox"/> Self-diagnosis - BLINK CODE | 113 |
| <input type="checkbox"/> Checking alternator pulley alignment | 102 | <input type="checkbox"/> Immobilizer recognition | 113 |
| <input type="checkbox"/> Checking compressor pulley alignment | 102 | <input type="checkbox"/> Checking fuel temperature | 113 |
| <input type="checkbox"/> Adjusting compressor - air-conditioner drive belt tension | 102 | <input type="checkbox"/> Checking engine coolant temperature | 113 |
| <input type="checkbox"/> Adjusting alternator - water pump drive belt tension | 102 | <input type="checkbox"/> Checking quantity of fuel injected | 113 |
| <input type="checkbox"/> Timing system speed sensor | 105 | <input type="checkbox"/> Checking idling adjustment | 113 |
| <input type="checkbox"/> Engine speed sensor | 105 | <input type="checkbox"/> Fuel cut-off in release phase | 113 |
| SUPERCHARGING | 106 | <input type="checkbox"/> Checking cylinder balancing on idling | 113 |
| <input type="checkbox"/> Description | 106 | <input type="checkbox"/> Checking regulator engine rotation (anti-sawing) | 113 |
| <input type="checkbox"/> Turbocharger | 106 | <input type="checkbox"/> Checking smokiness at exhaust on acceleration | 113 |
| REPAIRS | 107 | <input type="checkbox"/> Checking exhaust gas recirculation (E.G.R. if present) | 113 |
| PRESSURE RELIEF VALVE | 107 | <input type="checkbox"/> Checking top speed limit | 113 |
| <input type="checkbox"/> Checking and adjusting the pressure relief valve | 107 | <input type="checkbox"/> Checking rotation regularity during acceleration | 113 |
| <input type="checkbox"/> Changing the pressure relief valve | 107 | | |
| <input type="checkbox"/> GARRET GT 2256 T variable geometry turbosupercharger | 108 | | |
| <input type="checkbox"/> General | 108 | | |

Page

| | | |
|--------------------------|---|-----|
| <input type="checkbox"/> | Checking thermostart | 113 |
| <input type="checkbox"/> | Checking activation of air-conditioning system | 113 |
| <input type="checkbox"/> | Checking fuel pump | 113 |
| <input type="checkbox"/> | Checking diesel warming | 114 |
| <input type="checkbox"/> | Checking cylinder position | 114 |
| <input type="checkbox"/> | Checking pilot and main injection timing | 114 |
| <input type="checkbox"/> | Checking injection pressure closed cycle | 114 |
| <input type="checkbox"/> | Fuel supply | 114 |
| <input type="checkbox"/> | Correcting flow rate according to water temperature | 114 |
| <input type="checkbox"/> | Correcting flow rate to avoid noise, smoke or overloading | 114 |
| <input type="checkbox"/> | De-rating | 114 |
| <input type="checkbox"/> | Adjusting turbine speed (for variable geometry turbocharger - when present) | 114 |
| <input type="checkbox"/> | Injection timing electronic test | 114 |
| <input type="checkbox"/> | Speed governor | 114 |
| <input type="checkbox"/> | Engine starting | 114 |
| <input type="checkbox"/> | Cold starting | 115 |
| <input type="checkbox"/> | Warm starting | 115 |
| <input type="checkbox"/> | Run up | 115 |
| <input type="checkbox"/> | After run | 115 |
| <input type="checkbox"/> | Cut-off | 115 |
| <input type="checkbox"/> | Cylinder balancing | 115 |
| <input type="checkbox"/> | Synchronization search | 115 |
| <input type="checkbox"/> | Operation | 116 |
| | HYDRAULIC SYSTEM | 117 |
| <input type="checkbox"/> | Fuel pump | 117 |
| <input type="checkbox"/> | Specifications | 117 |
| <input type="checkbox"/> | Fuel filter | 118 |
| <input type="checkbox"/> | Tightening torques | 118 |

Page

| | | |
|--------------------------|---|-----|
| <input type="checkbox"/> | Fuel pipes | 118 |
| <input type="checkbox"/> | High-pressure pump | 119 |
| <input type="checkbox"/> | 3rd pumping element exclusion device | 120 |
| <input type="checkbox"/> | Pressure regulator | 120 |
| <input type="checkbox"/> | Hydraulic accumulator (rail) | 121 |
| <input type="checkbox"/> | Flow limiters | 121 |
| <input type="checkbox"/> | Pressure relief valve | 123 |
| <input type="checkbox"/> | Fuel recirculation and supply system | 123 |
| | ELECTRO-INJECTORS | 125 |
| <input type="checkbox"/> | Operation | 125 |
| | ELECTRIC/ELECTRONIC COMPONENTS | 126 |
| <input type="checkbox"/> | Electronic control unit MS6.3 | 126 |
| | SENSORS | 126 |
| <input type="checkbox"/> | Engine speed sensor | 126 |
| <input type="checkbox"/> | Camshaft timing sensor | 126 |
| <input type="checkbox"/> | Air temperature and pressure sensor | 126 |
| <input type="checkbox"/> | Fuel temperature sensor | 126 |
| <input type="checkbox"/> | Fuel pressure sensor | 127 |
| <input type="checkbox"/> | Atmospheric pressure sensor | 127 |
| <input type="checkbox"/> | Engine coolant temperature sensor | 127 |
| <input type="checkbox"/> | Throttle pedal position sensor | 127 |
| <input type="checkbox"/> | Clutch pedal position sensor | 127 |
| <input type="checkbox"/> | Brake pedal position sensor | 127 |
| <input type="checkbox"/> | Vehicle speed sensor | 127 |
| | ACTUATORS | 127 |
| <input type="checkbox"/> | PWM (Pulse Width Modulation) controls | 127 |
| | EXHAUST GAS RECIRCULATION SYSTEM E.G.R. (vehicles with homologation MI) | 128 |
| | GUIDE TO TROUBLESHOOTING | 129 |

EMISSIONS VALUES**Engine 8140.43R.43XX/44XX****Figure 21**

74943

Gas emissions

Engine 8140.43R.43XX/44XX conforms to the Euro3 standards on gas emissions (measured on engine bench to OICA mode 13 cycle), with the following limits fixed by EEC regulation 1999/96:

- CO (carbon monoxide) < 2.1 g/kWh
- NO_x (nitrogen oxide) < 5.0 g/kWh
- HC (hydrocarbons) < 0.66 g/kWh
- Particulate < 0.13 g/kWh

Test fuel: CEC RFT 73 - T - 90 - S ≤ 0.05 %.

Smokiness


Engine 8140.43R.43XX/44XX conforms to the smoke limits required by EEC regulations 72/306 and R24-03 with the following exhaust smoke values:

- Maximum power (Bosch BSU opacimeter degrees) 1.5
- Maximum torque (Bosch BSU opacimeter degrees) 2.5
- Full load at 1000 rpm (Bosch BSU opacimeter degrees) 3.5

Noise emissions

Maximum mean noise level, L_{pa}, of the standard engines measured according to ISO Std. 3745 (microphones at 1 m from the engine surfaces):

- | | | |
|------------|------------|---------|
| Idling | (800 rpm) | dB A 76 |
| Full power | (3600 rpm) | dB A 99 |

Engine 8140.43B.43XX/44XX**Figure 22**

74939

Gas emissions

Engine 8140.43B.43XX/44XX conforms to the Euro3 standards on gas emissions (measured on engine bench to OICA mode I3 cycle), with the following limits fixed by EEC regulation 1999/96:

- CO (carbon monoxide) < 2.1 g/kWh
- NO_x (nitrogen oxide) < 5.0 g/kWh
- HC (hydrocarbons) < 0.66 g/kWh
- Particulate < 0.13 g/kWh

Test fuel: CEC RFT 73 - T - 90 - S ≤ 0.05 %.

Smokiness


Engine 8140.43B.43XX/44XX conforms to the smoke limits required by EEC regulations 72/306 and R24-03 with the following exhaust smoke values:

- Maximum power (Bosch BSU opacimeter degrees) 1.5
- Maximum torque (Bosch BSU opacimeter degrees) 2.5
- Full load at 1000 rpm (Bosch BSU opacimeter degrees) 3.5

Noise emissions

Maximum mean noise level, L_{pa}, of the standard engines measured according to ISO Std. 3745 (microphones at 1 m from the engine surfaces):

- | | | | |
|------------|------------|------|----|
| Idling | (800 rpm) | dB A | 76 |
| Full power | (3600 rpm) | dB A | 99 |

Engine 8140.43S.41..**Figure 23**

74939

Gas emissions

Engine 8140.43S.41.. with E.G.R. conforms to the Standard on gas emissions ECE 96/69 step 2 (measured on roller bench according to ECE-EUDC 20 mode I cycle), with the following limits:

- CO (carbon monoxide) < 1.5 g/kWh
- HC+NO_x (unburnt hydrocarbons + nitrogen oxide) < 1.6 g/km
- Particulate < 0.2 g/kWh

Test fuel: CEC RFT 73 - T - 90 - S v 0.05 %.

Test conditions: coast-down assigned 12.7 kW at 80 km/h.

Reference weight of vehicle 2270 kg

Vehicle equipped with EGR system and oxidizing catalyst:

- Degussa 1.5 l - 300 cpsi - V50 - 2g - Pt
- Kemira 1.5 l - 300 cpsi - 7007 - 1g - Pt

Smokiness


Engine 8140.43S.41.. with E.G.R. conforms to the smoke limits required by EEC regulations 72/306 and R24-03 with the following exhaust smoke values:

- Maximum power (Bosch BSU opacimeter degrees) 1.5
- Maximum torque (Bosch BSU opacimeter degrees) 2.5
- Full load at 1000 rpm (Bosch BSU opacimeter degrees) 3.5

Noise emissions

Maximum mean noise level, L_{pa}, of the standard engines measured according to ISO Std. 3745 (microphones at 1 m from the engine surfaces):

- Idling (800 rpm) dB A 76
- Full power (3600 rpm) dB A 99

Engine 8140.43S.43XX/44XX**Figure 24**

74939

Gas emissions

Engine 8140.43S.43XX/44XX conforms to the Euro3 standards on gas emissions (measured on engine bench to OICA mode 13 cycle), with the following limits fixed by EEC regulation 1999/96:

- CO (carbon monoxide) < 2.1 g/kWh
- NO_x (nitrogen oxide) < 5.0 g/kWh
- HC (hydrocarbons) < 0.66 g/kWh
- Particulate < 0.13 g/kWh

Test fuel: CEC RFT 73 - T - 90 - S ≤ 0.05 %.

Smokiness


Engine 8140.43S.43XX/44XX conforms with the limits of smokiness required by EEC standards 72/306: 1.37 lm with the following exhaust smokiness values:

- Maximum power (Bosch BSU opacimeter degrees) 1.5
- Maximum torque (Bosch BSU opacimeter degrees) 2.5
- Full load at 1000 rpm (Bosch BSU opacimeter degrees) 3.5

Noise emissions

Maximum mean noise level, L_{pa}, of the standard engines measured according to ISO Std. 3745 (microphones at 1 m from the engine surfaces):

- | | | | |
|------------|------------|------|----|
| Idling | (800 rpm) | dB A | 76 |
| Full power | (3600 rpm) | dB A | 99 |

Engine 8140.43N.43XX/44XX**Figure 25**

74940

Gas emissions

Engine 8140.43N.43XX/44XX conforms to the Euro3 standards on gas emissions (measured on engine bench to OICA mode 13 cycle), with the following limits fixed by EEC regulation 1999/96:

- CO (carbon monoxide) < 2.1 g/kWh
- NO_x (nitrogen oxide) < 5.0 g/kWh
- HC (hydrocarbons) < 0.66 g/kWh
- Particulate < 0.13 g/kWh

Test fuel: CEC RFT 73 - T - 90 - S ≤ 0.05 %.

Smokiness

Engine 8140.43N.43XX/44XX conforms with the limits of smokiness required by EEC standards 72/306: 1.37 lm with the following exhaust smokiness values:


- Maximum power (Bosch BSU opacimeter degrees) 1.5
- Maximum torque (Bosch BSU opacimeter degrees) 2.5
- Full load at 1000 rpm (Bosch BSU opacimeter degrees) 3.5

Noise emissions

Maximum mean noise level, L_{pa}, of the standard engines measured according to ISO Std. 3745 (microphones at 1 m from the engine surfaces):

- | | | |
|------------|------------|---------|
| Idling | (800 rpm) | dB A 76 |
| Full power | (3600 rpm) | dB A 99 |


Figure 26



74942

LONGITUDINAL SECTION OF THE ENGINE WITH INTEGRATED CYLINDER LINERS


Figure 27



74941

CROSS SECTION OF THE ENGINE WITH INTEGRATED CYLINDER LINERS


Figure 28



51158

LONGITUDINAL SECTION OF THE ENGINE WITH INSERTED CYLINDER LINERS















Figure 29



62866









CROSS SECTION OF THE ENGINE WITH INSERTED CYLINDER LINERS








GENERAL SPECIFICATIONS

|  | Type | | 8140.43R.43XX 8140.43R.44XX ID/TCA | 8140.43B.43XX 8140.43B.44XX ID/TCA | 8140.43S.41XX 8140.43S.43XX 8140.43S.44XX ID/TCA | 8140.43N.43XX 8140.43N.44XX ID/TCA |
|---|---|-----------------|--|--|---|--|
|  | Cycle | | Diesel 4 strokes | | | |
| | Feedin | | Supercharged with aftercooler | | | |
| | Injection | | Direct | | | |
|  | No. of cylinders | | 4 on-line | | | |
|  | Diameter | mm | 94.4 | | | |
|  | Stroke | mm | 100 | | | |
|  | Total displacement | cm ³ | 2800 | | | |
|  | Compression ratio | | 18:1 | | | |
|  | Max. power | kW (HP) | 64.7 ÷ 67.3 (88.0 ÷ 91.6) | 75.3 ÷ 80.7 (102.4 ÷ 1098) | 88.8 ÷ 95.2 (120.8 ÷ 129.5) | 103.5 ÷ 110.5 (140.7 ÷ 150.3) |
|  | | rpm | 3600 | 3600 | 3600 | 3600 |
|  | Max. torque | Nm (kgm) | 201.6 ÷ 218.4 (20.6 ÷ 22.3) | 237.5 ÷ 262.5 (24.2 ÷ 26.7) | 275.5 ÷ 304.7 (28.1 ÷ 31.1) | 304 ÷ 338 (31 ÷ 34.2) |
|  | | rpm | 1800 | 1800 | 1800 | 1800 |
|  | Engine idling speed, no load | rpm | 800 ± 25 | | | |
|  | Maximum engine speed, no load | rpm | 4200 ± 50 | | | |
|  | Pressure at T.D.C. | *bar | 20 ÷ 26 | | | |
| | Minimum permissible pressure at T.D.C. | *bar | 16 | | | |

















(*) The pressure value is recorded by turning the engine over with the electric starter motor, with oil temperature at 40°- 50°C and the injection pump in the stop condition.












ID = Direct injection
PC = Indirect injection (pre-chamber)
TCA = Supercharging with intercooler

















|  Type | 8140.43R.43XX 8140.43R.44XX ID/TCA | 8140.43B.43XX 8140.43B.44XX ID/TCA | 8140.43S.41XX 8140.43S.43XX 8140.43S.44XX ID/TCA | 8140.43N.43XX 8140.43N.44XX ID/TCA |
|---|---|--|---|--|
|  <p>VALVE TIMING</p> <p>opens before T.D.C. A closes after B.D.C. B</p> <p>opens before B.D.C. D closes after T.D.C. C</p> | | | | |
| <p>For timing check</p>  <p>Running</p> <p>X mm } X mm }</p> <p>X mm } X mm }</p> | <p>0.5 ± 0.05</p> <p>0.5 ± 0.05</p> <p>0.5 ± 0.05</p> <p>0.5 ± 0.05</p> | | | |
|  <p>FUEL SUPPLY</p> | Electronic high-pressure fuel supply system type BOSCH MS6.3 or EDC 16, comprising a high-pressure pump, electro-injectors, hydraulic accumulator (rail), EDC control unit, pressure and temperature sensors. | | | |
|  <p>Pump arrangement With piston n. 1 at T.D.C.</p> <p>Start of delivery mm</p> | <p>-</p> <p>-</p> | | | |
|  <p>Injector nozzle type</p> | BOSCH DSLA I 36 P 804 | | | |
|  <p>Injection order</p> | 1 - 3 - 4 - 2 | | | |
|  <p>Injection pressure bar</p> | 1350 | | | |



















|  | | Type | 8140.43R.43XX 8140.43R.44XX ID/TCA | 8140.43B.43XX 8140.43B.44XX ID/TCA | 8140.43S.41XX 8140.43S.43XX 8140.43S.44XX ID/TCA | 8140.43N.43XX 8140.43N.44XX ID/TCA | |
|---|--|--|---|--|---|--|---|
|  | | SUPERCHARGING Turbocharger type marked with colour | With intercooler KKK K03-2076-CCA 6.68 | | | - | - |
| Turbocharger shaft radial clearance | | | pink | blue | - | - | |
| Turbocharger shaft axial clearance | | | - | - | - | - | |
| Minimum opening stroke of pressure relief valve | | mm | - | - | - | - | |
| Maximum opening stroke of pressure relief valve | | mm | 3.5 ± 0.2 | 2.2 | - | - | |
| Pressure corresponding to the minimum stroke | | bar | - | - | - | - | |
| Pressure corresponding to the maximum stroke | | bar | 1.3 ± 0.002 | | - | - | |
|  | | Turbocharger type marked with colour | MITSUBISHI TD04 | | | - | - |
| Turbocharger shaft radial clearance | | | pink | blue | - | - | |
| Turbocharger shaft axial clearance | | | 0.396 ÷ 0.602 | | - | - | |
| Minimum opening stroke of pressure relief valve | | mm | 0.034 ÷ 0.106 | | - | - | |
| Pressure corresponding to the minimum stroke | | bar | 0.820 ± 0.020 | 0.920 ± 0.020 | - | - | |
| Maximum opening stroke of pressure relief valve | | mm | 5 | | - | - | |
| Pressure corresponding to the maximum stroke | | bar | 1.000 ± 0.030 | | 1.100 ± 0.030 | - | |
|  | | Turbocharger type | GARRET GT 20 | | | GARRET GT 2256 T with variable geometry | - |
| Minimum opening stroke of pressure relief valve | | mm | - | 1 | - | - | |
| Pressure corresponding to the minimum stroke | | bar | - | 1,20 ÷ 1,27 | - | - | |
| Maximum opening stroke of pressure relief valve | | mm | - | 4 | - | - | |
| Pressure corresponding to the maximum stroke | | bar | - | 1,28 ± 1,42 | - | - | |
| Turbocharger shaft radial clearance | | | - | | | 0.086 ÷ 0.117 | |
| Turbocharger shaft axial clearance | | | - | | | 0.030 ÷ 0.083 | |
| Actuator setting: | | | | | | | |
| - low pressure 0 mmHg | | valve fully open | - | | | | |
| - low pressure 150 mmHg | | valve stroke | - | | | 2.3 ÷ 3.7 | |
| - low pressure 400 mmHg | | valve stroke | - | | | 9.7 ÷ 10.7 | |
| - valve fully shut | | valve stroke | - | | | 11 ÷ 12.4 | |
|   | | LUBRICATION | Forced feed by gear pump, relief valve, dual action oil filter | | | | |
| Oil pressure, engine hot at idling speed | | bar | ≥ 0.8 | ≥ 0.8 | 0.8 | ≥ 0.8 | |
| Oil pressure, engine hot at maximum speed | | bar | ≥ 3.5 | ≥ 3.5 | 3.5 | ≥ 3.5 | |
| COOLING | | | With a centrifuge pump, driven by the crankshaft via a poly-V belt, thermostat, fan with electro-magnetic clutch, radiator, "Intercooler" heat exchanger. | | | | |
| Thermostat: starts to open: fully open: | | | 82° C ± 2° C 110° C | | | | |
|  Urania Daily Urania LD 5 | | OIL REPLENISHMENT | | | | | |
| Total capacity at 1st filling | | liters | 6.9 | | | | |
| | | kg | 6.1 | | | | |
| Quantity at periodical replacements: | | | | | | | |
| - engine sump | | liters | 5.2 | | | | |
| | | kg | 4.6 | | | | |
| - engine sump + filter | | liters | 6.3 | | | | |
| | | kg | 5.7 | | | | |















ASSEMBLY DATA - CLEARANCES

|  | Type | 8140.43R.43XX 8140.43R.44XX ID/TCA | 8140.43B.43XX 8140.43B.44XX ID/TCA | 8140.43S.41XX 8140.43S.43XX 8140.43S.44XX ID/TCA | 8140.43N.43XX 8140.43N.44XX ID/TCA |
|--|--|--|--|--|--|
| CYLINDER BLOCK AND CRANK MECHANISM COMPONENTS | | | | | |
|  | Bores for cylinder liners $\varnothing 1$ | | | | 97.39 ÷ 97.45 * |
|  | Cylinder liners: outside diameter $\varnothing 2$ length L | | | ** 97.47 ÷ 97.50 167.00 ÷ 167.30 | |
|  | Cylinder liners - crankcase bores (negative allowance) | | | | 0.02 ÷ 0.11 |
|  |  Outside diameter $\varnothing 2$ | | | | 0.2 |
|  | Cylinder barrels: (protrusion from engine block bottom) inside diameter $\varnothing 3$ | | | ** 0.005 max 94.402 ÷ 94.432 | |
|  | Pistons: supplied as spare parts type: measuring dimension X outside diameter $\varnothing 1$ pin bore $\varnothing 2$ | | | MONDIAL PISTON 10 94.306 ÷ 94.320 32.003 ÷ 32.009 | |
|  | Piston - cylinder sleeve | | | | 0.082 ÷ 0.126 |
|  | Pistons: supplied as spare parts type: measuring dimension X outside diameter $\varnothing 1$ pin bore $\varnothing 2$ | | | KS 10 94.306 ÷ 94.320 32.003 ÷ 32.009 | |
|  | Piston - cylinder sleeve | | | | 0.082 ÷ 0.126 |
|  |  Piston diameter $\varnothing 1$ | | | | 0.4 |
|  | Pistons protrusion X | | | | > 0.40 ÷ ≤ 0.80 |
|  | Gudgeon pin $\varnothing 3$ | | | | 31.990 ÷ 31.996 |
|  | Gudgeon pin - pin housing | | | | 0.003 ÷ 0.015 |
| * Diameter to obtain at the time of servicing to fit the cylinder liners supplied as spares. | | | | | |
| ** Supplied as spares. | | | | | |

|  | Type | 8140.43R.43XX 8140.43R.44XX ID/TCA | 8140.43B.43XX 8140.43B.44XX ID/TCA | 8140.43S.41XX 8140.43S.43XX 8140.43S.44XX ID/TCA | 8140.43N.43XX 8140.43N.44XX ID/TCA |
|---|--|--|--|---|--|
| CYLINDER BLOCK AND CRANK MECHANISM COMPONENTS | | | | | |
| mm | | | | | |
|  | Piston type X1* Piston ring grooves X2 X3 * measured on \varnothing of 91.4 mm | MONDIAL PISTON - KS 2.200 ÷ 2.230 2.050 ÷ 2.070 2.540 ÷ 2.560 | | | |
|  | Piston rings S 1* S 2 S 3 * measured on \varnothing of 91.4 mm | 2.068 ÷ 2.097 1.970 ÷ 1.995 2.470 ÷ 2.490 | | | |
|  | Piston rings - grooves 1 2 3 | 0.103 ÷ 0.162 0.55 ÷ 0.100 0.05 ÷ 0.09 | | | |
|  | Piston rings | 0.4 | | | |
|  | Piston ring end gap in cylinder liners X1 X2 X3 X1 X2 X3 | 0.20 ÷ 0.35 0.30 ÷ 0.50 0.30 ÷ 0.55 | | | |
|  | Small end bush housing \varnothing 1 Big end bearing housing * \varnothing 2 * spare connecting rod supplied | 35.460 ÷ 35.490 60.341 ÷ 60.348 | | | |
|  | Small end bush diameter outside \varnothing 4 inside \varnothing 3 Big end bearing shell supplied as spare parts S | 35.570 ÷ 35.595 32.010 ÷ 32.020 1.875 ÷ 1.884 | | | |
|  | Small end bush - housing | 0.08 ÷ 0.135 | | | |
|  | Piston pin - bush | 0.014 ÷ 0.03 | | | |
|  | Piston rings | 0.254 ÷ 0.508 | | | |

|  | Type | 8140.43R.43XX 8140.43R.44XX ID/TCA | 8140.43B.43XX 8140.43B.44XX ID/TCA | 8140.43S.41XX 8140.43S.43XX 8140.43S.44XX ID/TCA | 8140.43N.43XX 8140.43N.44XX ID/TCA |
|--|---|--|--|---|--|
| CYLINDER BLOCK AND CRANK MECHANISM COMPONENTS mm | | | | | |
|  | Measuring dimension X | X | 125 | | |
|  | Max. connecting rod axis misalignment tolerance = | = | 0.07 | | |
|  | Main journals n° 1 - 2 - 3 - 4 n° 5 | Ø 1 | 80.182 ÷ 80.208 86.182 ÷ 86.208 | | |
|  | Crankpins | Ø 2 | 56.515 ÷ 56.538 | | |
|  | Main bearing shells | S1* | 2.165 ÷ 2.174 | | |
|  | Big end bearing shells | S2* | 1.875 ÷ 1.884 | | |
| * supplied as spare parts | | | | | |
|  | Main bearings n° 1 - 2 - 3 - 4 n° 5 | Ø 3 | 84.588 ÷ 84.614 90.588 ÷ 90.614 | | |
|  | Bearing shells - main journals | | 0.032 ÷ 0.102 | | |
|  | Bearing shells - big ends | | 0.035 ÷ 0.083 | | |
|  | Main bearing shells | | 0.254 ÷ 0.508 | | |
|  | Big end bearing shells | | 0.254 ÷ 0.508 | | |
|  | Main journal, thrust bearing | X 1 | 31.000 ÷ 31.100 | | |
|  | Main bearing housing, thrust bearing | X 2 | 26.500 ÷ 26.550 | | |
|  | Thrust washer halves | X 3 | 30.900 ÷ 30.950 | | |
|  | Crankshaft end float | | 0.060 ÷ 0.310 | | |

|  Type | 8140.43R.43XX 8140.43R.44XX ID/TCA | 8140.43B.43XX 8140.43B.44XX ID/TCA | 8140.43S.41XX 8140.43S.43XX 8140.43S.44XX ID/TCA | 8140.43N.43XX 8140.43N.44XX ID/TCA |
|---|--|--|---|--|
| CYLINDER HEADS - VALVE GEAR mm | | | | |
|  Valve guide housings in the cylinder heads $\varnothing 1$ | 12.950 ÷ 12.985 | | | |
|  Valve guide $\varnothing 2$ $\varnothing 3$ | 8.023 ÷ 8.038 13.012 ÷ 13.025 | | | |
|  Valve guides and housings in the cylinder heads | 0.027 ÷ 0.075 | | | |
|  Valve guide | 0.05 - 0.10 - 0.2 | | | |
|  Valves:  $\varnothing 4$ α  $\varnothing 4$ α | 7.985 ÷ 8.000 60° 15' ± 7' 30" 7.985 ÷ 8.000 45° 30' ± 7' 30" | | | |
|  Valve stem and its guide | 0.023 ÷ 0.053 | | | |
|  Housing in head for valve seat  $\varnothing 1$  $\varnothing 1$ | 42.125 ÷ 42.175 37.380 ÷ 37.415 | | | |
|  Outside diameter of valve seat; angle of valve seat in cylinder head:  $\varnothing 2$ α  $\varnothing 2$ α | 44.245 ÷ 44.260 60° ± 5' 37.495 ÷ 37.510 45° ± 5' | | | |
|  Recessing of valve X | 1.2 ÷ 1.5 1 ÷ 1.3 | | | |
|  Between valve seat and head | 0.070 ÷ 0.135 0.080 ÷ 0.130 | | | |
|  Valve seats | - | | | |

|  | Type | 8140.43R.43XX 8140.43R.44XX ID/TCA | 8140.43B.43XX 8140.43B.44XX ID/TCA | 8140.43S.41XX 8140.43S.43XX 8140.43S.44XX ID/TCA | 8140.43N.43XX 8140.43N.44XX ID/TCA |
|---|---|--|--|---|--|
| CYLINDER HEADS - VALVE GEAR mm | | | | | |
|  | Valve outside spring height: free height H under a load of: kg 43.8 ± 2.5 H1 kg 77.4 ± 4 H2 | 52 38.5 28.5 | | | |
|  | Valve inside spring height: free height H under a load of: kg 16.4 ± 1 H1 kg 30 ± 1.5 H2 | 45.5 33.5 23.5 | | | |
|  | Injector protrusion X | 3.7 ÷ 4.3 | | | |
|  | Camshaft bearing housing normal ∅ oversized ∅ | 33.985 ÷ 34.015 34.185 ÷ 34.215 | | | |
|  | Camshaft bearing journals normal ∅ oversized ∅ | 33.934 ÷ 33.950 34.134 ÷ 34.150 | | | |
|  | Between seats and supporting pins | 0.035 ÷ 0.081 | | | |
|  | Tappets housing on cylinder heads ∅ normal | 44.000 ÷ 44.025 | | | |
|  | Tappet ∅ normal | 43.950 ÷ 43.970 | | | |
|  | Between tappets and seats | 0.030 ÷ 0.075 | | | |
|  | Cap | 3.25 to 4.45 mm with a progression of 0.05 | | | |
|  | Cam lift:  H  H | 9.5 10.5 | | | |

TIGHTENING TORQUES

| PART | TORQUE | |
|--|------------|---------|
| | Nm | kgm |
| Flanged screw, cylinder head | | |
| Phase 1: pretightening | 60 ± 5 | 6 ± 0.5 |
| Phase 2: pretightening | 60 ± 5 | 6 ± 0.5 |
| Phase 3: angle | 180° ± 10° | |
| Flanged screw, lower to upper cylinder block | | |
| Preliminary torque | 50 ± 5 | 5 ± 0.5 |
| Angle | 90° ± 5° | |
| Connecting rod caps fastening screw | | |
| Preliminary torque | 50 ± 5 | 5 ± 0.5 |
| Angle | 63° ± 2° | |
| Flywheel attachment bolts | | |
| Preliminary torque | 30 + 3 | 3 + 0.3 |
| Angle | 90° ± 2° | |
| Self-locking nut for fastening the electromagnetic joint to the water pump | | |
| Preliminary torque | 40 | 4 |
| Angle | 110° ± 10° | |
| Blanking plug, engine oil main pipe M18 | 40 | 4 |
| Water circuit M16x1.5 conic cap | 25 | 2,5 |
| Oil pan/engine block fastening screw | 18 | 1.8 |
| Accessory equipments support oil duct sealing plug | 25 | 2.5 |
| Flanged screw, auxiliary units mounting M12 | 60 | 6 |
| Accessory equipments support fastening screw M8 | 25 | 2.5 |
| Accessory equipments support front cover fastening screw | 25 | 2.3 |
| Accessory equipments support rear cover fastening screw | 18 | 1.8 |
| Auxiliary members assembly upper cover securing screw | 25 | 2,5 |
| Hexagon socket-head screw, crankshaft oil seal rear cover (Rotostat) | 25 | 2.5 |
| Hexagon socket-head screw, crankshaft oil seal front cover (Rotostat) | 7.5 | 0.75 |
| Camshaft front cover fastening nut | 7.5 | 0.75 |
| Water pump pipe/inlet manifold fastening nut | 25 | 2.5 |
| Cylinder heads rear cover fastening screws and nut | 25 | 2.5 |
| Nut, engine lifting brackets | 18 | 1.8 |
| Inlet and outlet manifold fastening nut | 25 | 2.5 |
| Inlet manifold/crank fastening screw | 18 | 1.8 |
| Crankshaft driving pulley fastening screw | 200 | 20 |
| Camshaft caps fastening nut | 18 | 1.8 |
| Camshaft driving gear fastening screw | 25 | 2.5 |
| Injection pump driving gear fastening screw | 100 | 10 |
| EGR valve/inlet and outlet manifolds fastening nut | 18 | 1.8 |
| Nut fixing toothed bushing to the high-pressure pump | 79 | 7.9 |
| Coupling fixing heat exchanger and for oil filter cartridge * | 75 | 7.5 |
| Oil filter fixing | 25 | 2.5 |
| Screw fixing oil suction strainer | 25 | 2.5 |
| Oil pressure valve spring cap | 65 | 6.5 |
| Union for piston cooling nozzle | 40 | 4 |
| Flanged screw fixing water pump casing to crankcase | 50 | 5 |
| Oil level sensor fixing on crankcase | 25 | 2.5 |

* The thread must first be spread with IVECO I905683 sealant

| PART | TORQUE | |
|--|--------|------|
| | Nm | kgm |
| Nut, magnet to water pump | 7.5 | 0.75 |
| Screw, cylinder head water thermostat pipe union | 18 | 1.8 |
| Screw, driven pulley to water pump hub | 25 | 2.5 |
| Screw, alternator mounting to crankcase | 50 | 5 |
| Screw, alternator to mounting | 75 | 7.5 |
| Nut to secure alternator to support | 65 | 6.5 |
| Nut, turbocharger to exhaust manifold | 25 | 2.5 |
| Screw, thermostat water outlet pipe | 18 | 1.8 |
| Nut, power steering pump | 35 | 3.5 |
| M6 screw, vacuum pump | 12 | 1.2 |
| M8 flanged screw, vacuum pump | 18 | 1.8 |
| Plug, auxiliary units front cover | 35 | 3.5 |
| Self-locking nut, tappets cover | 10 | 1 |
| Nut fixing top tensioner bearing mount | 30 | 3 |
| Nut fixing bottom tensioner mount | 25 | 5 |
| Nut fixing bottom tensioner bearing | 40 | 4 |
| Screw to secure the piping of oil exiting turbocharger | 10 | 1 |
| Union, turbocharger oil delivery pipe | 38 | 3.8 |
| Flanged screw, oil drain mounting to lower crankcase | 40 | 4 |
| Oil pipe fitting, to crankcase main duct | 45 | 4.5 |
| Fastening, oil pressure sender and switch to pipe fitting | 40 | 4 |
| Flanged screw, gas exhaust pipe to turbocharger | 25 | 2.5 |
| Nut, thermostarter plug | 35 | 3.5 |
| Fastening, thermostarter connection to plug | 22 | 2,2 |
| Fastening, solenoid valve union | 20 | 2 |
| Screws, heat exchanger pipes to upper crankcase | 40 | 4 |
| Water transmitter fixing M16x1.5 (conical) | 30 | 3 |
| Crankcase water drain pipe union | 35 | 3.5 |
| Nut, water inlet line to pump | 25 | 2.5 |
| Screw, cover to thermostat box | 18 | 1.8 |
| Thermometric transmitter fixing - M8x1.25 | 10 | 1 |
| Thermometric transmitter fixing - M12x1.5 | 30 | 3 |
| Thermometric transmitter fixing - M14x1.5 | 25 | 2.5 |
| M10x1.25 50 c.s. hex screw to secure injector bracket | 40 | 4 |
| M12x1.5 fitting for diesel outlet from high-pressure pump | 22 | 2.2 |
| M12x1.5 fitting for diesel inlet on hydraulic accumulator (rail) | 22 | 2.2 |
| M14x1.5 fitting for diesel outlet from hydraulic accumulator (rail) | 22 | 2.2 |
| M12x1.5 fitting for diesel inlet on electro-injector | 22 | 2.2 |
| 5-way fixing coupling M16x1.5 on overpressure valve (rail), if applicable | 27 | 2.7 |
| Screw to secure 4-way pipe fitting on hydraulic accumulator (rail) | 25 | 2,5 |
| M16 x1.5 pipe fitting to secure fuel recovery piping to hydraulic accumulator (rail) | 27 | 2,7 |
| M8 nut securing hydraulic accumulator (rail) on cylinder head | 25 | 2.5 |
| M8 nut securing bottom soundproof cover on hydraulic accumulator (rail) | 18 | 1.8 |
| M8 nut securing high-pressure pump on spacer | 25 | 2.5 |
| Fuel pressure sensor fixing on hydraulic accumulator (rail) | 35 | 3.5 |
| Flow limiter fixing on hydraulic accumulator, if applicable | 45 | 4.5 |
| Pressure relief valve fixing on hydraulic accumulator (rail) | 45 | 4.5 |

* Coat thread with IVECO I905683 sealing compound before assembly







| PART | TORQUE | |
|---|----------|------------|
| | Nm | kgm |
| Engine auxiliary units | | |
| Screw, fan distance piece to electromagnetic pulley | 13 ± 1 | 1.3 ± 0.1 |
| Screw, fan to distance piece | 6 ± 0,6 | 0.6 |
| Screw, starter motor | 41 ± 4 | 4.1 ± 0.4 |
| Screw to secure flywheel r.p.m. sensor | 10 | 1 |
| Screw to secure timing detector sensor | 7.5 | 0.7 |
| Securing conic pipe fitting M16x1.5 for water delivery from cylinder head to cab heater | 18 | 1.8 |
| Flanged screw M10x1.25 to secure the piping of water entering heat exchanger | 40 | 4 |
| Flanged screw M12x1.25 to secure the piping of water entering heat exchanger | 50 | 5 |
| Flanged screw M8x1.25 to secure the piping of water entering heat exchanger | 18 | 1.8 |
| Screw or nut to secure exhaust manifold bracket | 40 | 4 |
| Cap M10x1.25 of breather pipe on thermostat body | 10 | 1 |
| Socket conic threaded cap M16x1.5 * | 25 | 2.5 |
| M12x1.5 cap | 30 | 3 |
| Screw to secure compressor support | 65 | 6.5 |
| Engine assembly suspension | | |
| M12 screw fixing bracket for flexible plug to engine | 90 ÷ 74 | 9 ÷ 7.4 |
| M10 screw fixing bracket for flexible plug to frame | 58 ÷ 47 | 5.8 ÷ 4.7 |
| M12 screw fixing bracket for flexible plug to frame | 101 ÷ 83 | 10.1 ÷ 8.3 |
| M12 self-locking nut fixing flexible plug to brackets | 49 | 4.9 |
| Screw securing rear bracket supporting gearbox | 35 | 3.5 |
| Nut securing flexible plug to rear bracket supporting gearbox | 49 | 4.9 |
| Screw securing flexible plug to cross member | 20 | 2 |
| M12 screw securing cross member to frame | 101 ÷ 83 | 10.1 ÷ 8.3 |







* Apply LOCTITE 506 on thread

TOOLS







| TOOL NO. | DESCRIPTION |
|-----------------|---|
| 99305019 | Box with full set of tools for regrinding valve seats |
| 99305047 | Appliance to check spring loads |
| 99317915 | Set of three box wrenches (14-17-19 mm) |
| 99322205 | Telescopic rotary stand to overhaul units (700 daN bearing capacity, 120 daN/m torque) |
| 99340035 | Extractor for electromagnetic pulley |
| 99340205 | Extractor for electromagnetic pulley |

TOOLS







| TOOL NO. | DESCRIPTION |
|---|---|
| 99342138 | Puller for injection pump coupling joint |
|  | |
| 99348004 | Universal extractor for interiors from 5 to 70 mm |
|  | |
| 99350114 | Wrench for camshaft rotation when adjusting valve clearance (bench operation) |
|  | |
| 99355040 | Bushing (17 mm) to remove engine oil level sensor from crankcase |
|  | |
| 99360091 | Tool to remove cartridge filters |
|  | |
| 99360183 | Pliers for mounting rings on engine pistons |
|  | |

| TOOLS | |
|-----------------|---|
| TOOL NO. | DESCRIPTION |
| 99360268 |  <p>Tool for removing and refitting engine valves</p> |
| 99360288 |  <p>Punch for removing valve guides</p> |
| 99360291 |  <p>Punch for refitting valve guides (use with 99360288)</p> |
| 99360292 |  <p>Keying device for mounting gasket on valve guide</p> |
| 99360306 |  <p>Tool to retain engine flywheel</p> |
| 99360309 |  <p>Tool retaining tappets to replace plate when adjusting valve clearance</p> |

TOOLS

| TOOL NO. | DESCRIPTION | |
|-----------------|---|--|
| 99360363 |  | Mounting for securing injection pump control assembly and auxiliary assemblies when overhauling at the bench |
| 99360508 |  | Rings for lifting cylinder blocks |
| 99360550 |  | Arm for removing and refitting engine |
| 99360605 |  | Band to insert standard and oversized pistons into the cylinders |
| 99360607 |  | Parts to check oil pump drive shaft driving |
| 99360608 |  | Tool for setting the timing gears |







TOOLS

| TOOL NO. | DESCRIPTION |
|---|--|
| 99361004 | Mounting to support cylinder head when adjusting tappets |
|  | |
| 99361029 | Brackets securing engine to rotary stand 99322205 |
|  | |
| 99365014 | Adjustable mounting |
|  | |
| 99365147 | Injection pump coupling joint check wrench |
|  | |
| 99365160 | Wrench (17 mm) to remove injector pipes |
|  | |
| 99367121 | Vacuum and pressure hand pump |
|  | |

TOOLS

| TOOL NO. | DESCRIPTION |
|-----------------|--|
| 99370006 | Interchangeable grip for punches |
| 99370415 | Dial gauge base to check piston balancing and pre-chamber plug protrusion |
| 99374336 | Keying device to mount gasket on camshaft front cover and on auxiliary member assembly (use with 99370006) |
| 99387001 | Pliers to recover valve clearance plates |
| 99389829 | Torque wrench 9x12 (5-60 Nm) |
| 99389833 | Torque wrench |


TOOLS

| TOOL NO. | DESCRIPTION |
|---|--|
| 99390310 | Valve guide smoothers |
|  | |
| 99394038 | Milling cutter to regrind injector seat (8140.63 engine excluded) |
|  | |
| 99395098 | Tool for checking piston TDC (to be used with 99395603) |
|  | |
| 99395214 | Gauge to position engine flywheel |
|  | |
| 99395216 | Pair of meters for angular tightening with square 1/2" and 3/4" connection |
|  | |
| 99395220 | Universal goniometer/inclinometer |
|  | |


TOOLS

TOOL NO.


DESCRIPTION

99395363


Complete square to check for connecting rod distortion

99395603


Dial gauge (0 ÷ 5 mm)

99395604

Dial gauge (0 ÷ 10 mm)

99395687


Bore meter (50 ÷ 178 mm)

99395849

Belt tension tester (10.0 to 600 Hz frequency)

OVERHAULING ENGINE 540110 DISASSEMBLING THE ENGINE AT THE BENCH

Figure 30



62854

If the engine cable was not removed, disconnect its electrical connections from: thermostat temperature sensor, revs. sensor, engine rpm sensor, pressure regulator, 3rd pumping element cut-out device, rail pressure sensor, intake manifold air pressure/temperature sensor.


Remove the side cover, disconnect electrical connections from injectors and disconnect the engine cable.

Remove pipe (2) from hose (1).

To be able to fit the brackets 99361029 onto the crankcase to secure the engine to the stand for overhauling, on the left-hand side of the engine it is necessary to:

- disconnect the pipe (3) from the heat exchanger (4);
- disconnect the pipe (7) from the side cover (5);
- take out the screws (6 and 9) and remove the pipe (10) complete with pipes (3 and 7);
- disconnect the pipe (11) from the crankcase fitting;
- disconnect the pipe (2) from the fillpipe (1);
- remove the oil vapour condenser (8) complete with pipes (2 and 11).

Figure 31



52162

On the right-hand side:


- disconnect the pipe (2) from the crankcase, taking out the fixing screw (6) and the fitting complete with oil pressure transmitter (8);
- take out the threaded plug (7);
- take out the screw (10) and disconnect the fitting (9) from under the crankcase;
- take out the nuts (1) and remove the exhaust manifold (3) from the cylinder head complete with turbocharger (4) and oil pipes (2 and 5).



Block the turbocharger air/exhaust gas inlets and outlet to prevent foreign bodies getting inside.

Fit the brackets 99361029 to the crankcase and use these to secure the engine to the rotary stand 99322205. Drain the oil from the engine by removing the plug from the oil sump. Remove the fan from the electromagnetic coupling.


Figure 32



62855

Remove pipe (10) connection (8) from connection (9). Remove screws (5) and pipe (10) clamps fastening nut (11). Remove nuts (4) and disconnect duct (6) including solenoid valve (2), glow plug (3) and pipe (10) from intake manifold (1), remove soundproof cover (7).


Figure 33



62856

Press clips (5) in the direction shown by the arrow and disconnect fuel recovery pipe connection (3) from injectors (4). Disconnect pipe (2) from high pressure pump (1). Hold the pressure relief valve (7) and remove hose (9) with connection (8) including pipe (3), plug (6) and pipe (2).

Figure 34



62857

Disconnect the fuel pipes (2) from the electro-injectors (1) and from the hydraulic accumulator (rail) (7) as follows. Keeping the hexagon (4) of the electro-injector (1) stationary with a wrench, undo the coupling (3) using the wrench 99365160.


Keeping the hexagon (6) of the flow limiting valve stationary, if applicable, unscrew the coupling (5) and disconnect the fuel pipe (2).

Take out the screws (8) fixing the brackets (9) retaining the electro-injectors (1).

Disconnect the electro-injectors (1) from the cylinder head.

NOTE For engine 8140.43S only.
Since engine No. 3089322, a rail with the same configuration but without flow limiters and pressure relief valve has been mounted. The same prescriptions specified for the previous one shall be complied with.

Figure 35




62858

Disconnect the pipe (6) from the high-pressure pump (3) and from the hydraulic accumulator (rail) (7).

NOTE Stop high pressure pump hexagon (4) by means of the proper wrench when loosening connection (5).

Remove nuts (2) and then remove protection (1).


Figure 36



52168

Disconnect: rail (3), high pressure pump (4), oil dipstick pipe (2) and oil filler (1).

Figure 37



52163


Remove the screw (2) fastening the pipe (4 and 1) bracket (3) to the intake manifold (5).

Remove the pipe (4) from the cylinder head.

Remove the nuts (7) fastening the pipe (1) to the water pump (6).

Remove the screw (9) fastening the pipe (8) to the bedplate.


Figure 38



62859

Disconnect the pipe (4) from the heat exchanger (3). Take out the screw (1 and 5) and disconnect the pipe (2) complete with pipes (1 and 8, Figure 33) from the crankcase base.


Figure 39



52169

Remove the intake manifold (1), tappet cover (4) complete with speed sensor (2). Recover the brackets (5) and the timing cover (3).


Figure 40



50658

Using the right wrench on the automatic tightener (2), slacken the tension of the belt (1) and remove it.


Figure 41



50659

Using tool 99360306 (3), applied as shown in the figure, stop crankshaft rotation and loosen the screws (1) securing the flywheel (2). Take out the screws (5), remove the mounting (6) complete with speed sensor (4).


Figure 42



50660

Take out the screw securing the pulley (1) to the crankshaft. disconnect the pulley (1) from the crankshaft and the spacer, if any.


Figure 43



50661

Loosen gear fixing screws (1 and 7). Fit proper wrench (5) between push rod (3) and belt tightener cylinder (4). Remove nut (2). Remove lower cover (6) and timing belt (8).


Figure 44



Remove the fixed tightener mounting (5) and the guard beneath (6).

Remove the thermostat box (1) complete with switches (2 and 3) and pipe (4).


Figure 45



Unscrew the screws (1) securing the cylinder head (2) and remove it with its gasket.

NOTE Check the protrusion of the pistons as described in the relevant paragraph to check the possibility of facing the crankcase if it has deformed.


Figure 46



With a suitable plate (1) applied as shown in the figure, block rotation of the electromagnetic pulley (2), unscrew the nut (3) securing the hub (4) clockwise and remove the hub.

NOTE The hub nut (3) has a left-hand thread.

Figure 47



Remove the key (1) and washer (3) from the water pump shaft (2).

Extract the pulley (9) from the water pump shaft (2).

Take out the nuts (7) and extract the electromagnetic coupling (8).


Remove the mounting (5) complete with alternator (4) from the crankcase and from the water pump (2).

Remove the water pump (2).

Remove the adjustable tightener (6).

Remove the crankshaft front cover (10).


Figure 48



50666

Remove screws (2) and disconnect auxiliary component unit (1) including hydraulic power steering pump (3), vacuum device (4), oil filter (6) and heat exchanger (5).


Figure 49



50667

Turn the engine 180° and take out the oil sump (1).
Take out the engine oil suction rose (2).

Figure 50




41090

Take out the tool 99360306 for blocking flywheel rotation.
Turn the engine 90° and loosen the screws (3) of the connecting rod caps (1) with the appropriate wrench (2).

NOTE To be able to remove the connecting rod cap (1, Figure 50) of the piston No. 4, take it to TDC.

Figure 51




18830

Take out the screws fixing the connect rod caps, remove them and extract the pistons (1) from the top of the crankcase.

NOTE Keep the half bearings in their respective housings because, if utilized, they must be fitted in the same position they were in when dismantled.


Figure 52



41091


Using the wrench (3), take out the screws (2) securing the engine flywheel (1) and remove it from the crankshaft.

Figure 53




Remove the crankshaft rear cover (1) from the crankcase, complete with oil seal.

Figure 54



Unscrew lower/upper crankcase fastening screws (1) using wrench (2).


Figure 55



Remove lower crankcase (1) with its gasket.


NOTE At removal, take note of the assembling position of lower and upper crankshaft half bearings since if reused they shall be refitted in the same position.

Figure 56



Remove crankshaft (1) using a hoist and a suitable rope.

Figure 57



Recover main half bearings (2).


Straighten safety plate bends and remove oil spray nozzles (1).

REPAIR OPERATIONS

CYLINDER BLOCK

Checks and measurements

Figure 58



Once engine is dismantled, clean cylinder-crankcase group accurately.

For handling cylinder group use rings 99365508.

Make sure crankcase has no cracks.

Check working plug conditions. If rusted or not perfectly tightening, replace them.


Check cylinder liner surfaces: they should not show any traces of binding, scoring, ovalization or excessive taper.

The inside diameter of the cylinder liners, in order to ascertain the extent of their ovalization, taper and wear, is checked with the bore gauge 99395687 (1) fitted with the dial gauge and reset on the ring gauge (2) of the diameter of the cylinder liner.

NOTE If ring gauge is not available use a micrometer to set to zero.

With reaming gauge 99395687 (1), equipped with centesimal comparator set to zero as previously described, check cylinder liner inside diameter, to verify the degree of ovalization, taper and wear.


Figure 59



Measurements shall be taken for each cylinder, at three different heights on the barrel and on two perpendicular surfaces: the first one parallel to engine longitudinal axis (A) and the other one perpendicular (B); max. wear is generally found on this latter surface and in correspondence with the first measurement.

Bore/recondition and plateau finish by honing cylinder barrels if ovalization, excessive taper or any sign of wear are found. Cylinder barrel reboring shall be performed according to the diameter of spare pistons oversized by 0.4 mm of rated value and prescribed assembling clearance. Should cylinder barrel be bored to higher diameter, oversize shall be performed by fitting a spare cylinder barrel and proceeding as described in the relevant chapter.

Figure 60



A - B = Main bearing longitudinal axis

* Surface roughness parameters

Rl = 4 ÷ 10 μm

Rz = 3 ÷ 8 μm

Ra = 0.3 ÷ 0.6 μm

Wl < 2 μm

Admitted surface pores with machined cylinder

ZONE B1 = max. stress area between piston ring/barrel: two non-continuous pores, max. 0.5 x 0.5 admitted



100%


ZONE B2 = area interested by piston ring sliding: two non-contiguous pores, max 1x0.8 admitted



100%

Checking head mating surface on cylinder block

Figure 61



Make sure mating surface, on cylinder block, does not show any deformations.


This check can be done, after removing setscrews (1), with a soot-coated surface plate or with a gauged rule (2) and thickness gauge (3).

Once deformation areas are detected, flatten supporting surface with a grinder.

NOTE Crankcase flattening can be performed only after being sure that, once the work is completed, piston protrusion from cylinder liner will not be greater than specified value.

Spare cylinder barrel assembling


Figure 62



B = Main bearing longitudinal axis

Implement cylinder barrel seats into engine block by boring the latter at the values shown in the above figure, so as to obtain the average diameter measured according the methods described in the following

Figure 63



* Engine block surface

** Spot-faced surface Ø 111


When levelling is over, reset cylinder barrel spot-facing and bevelling as shown in the figure.

Check main bearing housings as follows:

- Fit lower crankcase on upper crankcase, without bearings and gaskets;
- tighten fastening screws to specified torque;
- with a suitable inside diameter comparator, make sure the seat diameter is equal to specified value.

If a greater value is found, replace crankcase.

Figure 64



61690

Measurements shall be performed for every four barrel seats at three different heights and on two perpendicular surfaces: the first one parallel to engine longitudinal axis (A) and the other one perpendicular (B) as shown in the diagram.

Average diameter $D_{I,med}$ shall be calculated according to the following formula:

$$D_{I,med} = \frac{A_1(10) + A_1(50) + A_1(142) + B_1(10) + B_1(50) + B_1(142)}{6}$$


It shall be $97.500_{+0.11}^{-0.05}$, the difference between max diameter D_{max} and min. diameter D_{min} shall be: $D_{max} - D_{min} = \leq 0.03$ mm

NOTE Value between brackets corresponds to the measurement point from upper block edge.

After implementing the proper seats, barrel fitting into cylinder unit shall be performed by hydraulic press and plate as follows:

- Check whether cylinder barrel outside diameter is equal to the prescribed value.
Avoid using oil or grease when driving barrels;
- set barrel into block and check whether at 80 mm driving the load is ≥ 1300 daN;
- proceed with driving and check whether load is ≥ 5000 daN when driving is over;

Figure 65



62069


* engine block surface - ** spot-faced surface $\varnothing 111$ mm

- to prevent breakage, check whether barrel edge is perfectly resting on block:
cylinder barrel shall not protrude by 0.005 above block bottom.

Otherwise, replace the cylinder barrel.

After driving in the cylinder liners, machine them to the tolerance and roughness indicated in the "Checks and measurements" section.

Figure 66




20767

| | |
|---|-----------------|
| X = D m | 97.390 ÷ 97.450 |
| Y = barrel outside \varnothing | 97.470 ÷ 97.500 |
| Z = barrel inside \varnothing | 92.700 ÷ 92.900 |
| * | 94.402 ÷ 94.432 |
| * Dimension to be obtained after driving the liner into the crankcase at the end of the work. | |

5408 CRANKSHAFT


540810 Measuring main journals and connecting rods

Figure 67




If any traces of seizing, scoring or excessive ovality are detected on main journals and crank pins it is necessary to re-grind journals (2), measure crank pins with micrometer (1) in order to determine to which diameter pins must be reduced.

NOTE It is advisable to record measured values on a table. See Figure 68.

 Undersize classes are of: 0.254 - 0.508 mm.

NOTE Main journals and crank pins must be all ground to the same undersize. The performed undersize, on main journal and crank pins, must be identified by a special printing applied on the side of crank arm n.1. For undersized crank pins: letter M For undersized main journals: letter B For undersized crank pins and main journals: letter MB


Figure 68



44035

TABLE ON WHICH MEASURED VALUES OF MAIN JOURNALS AND CRANK PINS OF CRANKSHAFT MUST BE RECORDED

Figure 69



44034

MAIN DATA ON MAIN JOURNALS AND ON CRANKS PINS

NOTE Since when reducing by 0.254 or 0.508 mm crank pin or main journal diameters, the rolled section of their side grooves can be damaged, grooves shall be turned according to data shown in the figure and rolling shall be performed according to the following specifications.

Rolling force:


- 1st main journal 925 ± 25 daN
- 2nd - 3rd - 4th - 5th main journal 1850 ± 50 daN
- 1st - 4th crank pin 1850 ± 50 daN
- 2nd- 3rd crank pin 2040 ± 50 daN

- rolling turns: 3 approaching, 12 actual, 3 output turns
- rolling speed: 56 rev/min
- crank pin groove depth reduction after rolling: $0.15 \div 0.30$ * mm
- main journal groove depth reduction after rolling: $0.15 \div 0.35$ * mm

* measured with 2.5 mm diameter gauged pins

Checking crankshaft

Figure 70




45065

CRANKSHAFT MAIN TOLERANCES

| TOLERANCES | CHARACTERISTIC SUBJECT TO TOLERANCE | GRAPHIC SYMBOL |
|----------------|-------------------------------------|----------------|
| OF SHAPE | Circularity | ○ |
| | Taper | <i>b</i> |
| OF ORIENTATION | Parallelism | // |
| | Perpendicularity | ⊥ |
| OF POSITION | Concentricity | ◎ |
| OF OSCILLATION | Circular oscillation | ↗ |
| | Total oscillation | ↗↘ |

| CLASS OF IMPORTANCE ATTRIBUTED TO PRODUCT CHARACTERISTICS | GRAPHIC SYMBOL |
|---|----------------|
| CRITICAL | ◎ |
| IMPORTANT | ⊕ |
| SECONDARY | ⊖ |

Figure 71



45066

NOTE The checks of tolerances indicated in the figures must be carried out after grinding crankshaft pins, if necessary.

SYMMETRY OF MAIN JOURNALS AND CRANK PINS


1. Crank pins
2. Main Journals
3. Normal position.

Once grinding is completed, observe the following notices:

- Round the burr edges of main journals and crank pins lubricating holes;
- remove oil duct sealing plugs, reface seats with a suitable miller to remove any calking, clean ducts accurately, fit plugs using a suitable tool (1, Figure 72) and calk them on the relevant seats;
- make sure the plugs do not show any leakage under an inner pressure of 1.5 bars.

Replacing gearbox input shaft centering ring

Figure 72




61886

Use puller 99348004 to remove drive shaft (3) gearbox input shaft centering ring (2).
Use a generic tool for refitting.

Replacing timing control gear

Figure 73



61712

Should timing gear tothing be damaged or worn, proceed with removal as follows:

- mill gear (1) in the two points indicated by the arrows, heat the gear to a temperature not exceeding 350 °C, then take out the gear by extractor 99348001 (2) and block (3).

To fit the new gear on the drive shaft, the gear shall be heated so that ≥ 200 °C temperature difference is present between the two parts and gear keyhole shall coincide with shaft spline.


After fitting, under 900 N load, gear must not be withdrawn from shaft.

NOTE Max. gear heating temperature is 350°C.

ENGINE ASSEMBLY

When fitting the engine, replace always: safety spring rings, sealing rings and gaskets.


Figure 74



18569

By means of ring 99360508 (1) lift engine block (2) and secure it on rotating stand 99322205 with clamps 99361029 (3).

Figure 75




18919

Rotate engine block, fit oil spray nozzles (2) with the respective safety plates and tighten screws with a torque wrench (1) to specified torque.
Bend safety plates on screws.

Assembling main bearings

Figure 76



18920

NOTE Having not found the need to replace small end bearings, refit them in the same order and position they were before being dismantled.


Small end bearings (1) are supplied as spare parts, with an undersized inside diameter of 0.254 - 0.508 mm.

NOTE Do not perform any adaptation on bearings.

Put the main bearing shells (1) with the lubrication hole into their respective seats.

540811 Measuring main journals assembly clearances

Figure 77




Fit crankshaft (1).

Check the clearance between crankshaft main journals and respective bearings, proceeding as follows:


- clean carefully the journals;
- apply a calibrated wire on main journals.

Figure 78




- Set rubber sealing gaskets (1) and small end bearings (2) on lower crankcase.

Figure 79




- Fit the lower crankcase on the upper crankcase, verifying that reference marks (1) correspond, since the parts component crank- case are not interchangeable.

Figure 80



- Screw and tighten screws (2) according to the following two stages:
- 1st stage: by torque wrench, to 50 ± 5 Nm;
- 2nd stage: $90^\circ \pm 5^\circ$ angle tightening according to the following diagram.


Figure 81



A. Valve gear side - B. Flywheel side

Tightening order diagram of lower/upper crankcase fastening screws.

Figure 82




- Dismantle lower crankcase.

The clearance between small end bearings is calculated by comparing the width the calibrated wire has reached, in the point of greater deflection, with the scale graduation indicated on the envelope containing the calibrated wire. The numbers indicated on the scale indicate the coupling clearance, in millimetres, that must be of 0.032 ± 0.102 mm. If a clearance different than that specified is found, replace half bearings and repeat the check; once the prescribed clearance is obtained, lubricate small end bearings and fit lower crankcase definitively, tightening fastening screws as described previously.

Checking crankshaft end float

Figure 83




End float check is carried out by placing a magnetic-base dial gauge (1) on crankshaft (2), as shown in the figure; the normal assembly clearance is of 0.060-0.310 mm.

If a greater clearance is found replace rear small end thrust bearings and repeat float check between crankshaft pins and small end bearings.

Checking alignment pulley crankshaft

Figure 84



Push the crankshaft (1) towards the flywheel side so as to keep the crankshaft end in contact with the thrust bearing. In these conditions, measure the distance **X** between the crankcase (3) and the end of the gear (2). If the distance **X** is 53.82 ± 54.55 , it is necessary to place a spacer n 98428488 (5) (thickness 0.5 ± 0.05 mm) between the gear (2) and the pulley (4 or 6). If the distance **X** is 54.56 ± 55.12 , don't apply the spacer.

Mount the pulley (4), (engine without air-conditioner compressor) or (6), (engine with air-conditioner compressor).


Measure the distance **Y** or **Y'** between the end of the pulley (4 or 6) and the crankcase at the two extreme positions of crankshaft end float.

$$Y = 89.67 \pm 91.03 \text{ mm}$$

$$Y' = 107.17 \pm 108.53 \text{ mm}$$

540460 Rear crankshaft cover

Figure 85



NOTE The rear (3) and front (1, Figure 86) covers of the crankshaft have the "ROTOSTAT" type gasket integrated.

The covers are supplied as spare parts together with the chock (2). The chock (2) must not be removed from the gasket until this has been fitted on the crankshaft.


In addition, the thickness of the cover is not the same as that of the first assembly.

This is to prevent its lip from getting onto the shank of the crankshaft in exactly the same position where it could be worn.

Trim any gasket excess in the points indicated by the arrows. Lubricate crankshaft (1) shank. Fit rear gasket (3) and tighten screws to specified torque. Remove chock (2).


540440 Front crankshaft cover

Figure 86



Cut the exceeding seal in the point shown by arrows. Lubricate drive shaft shank. Fit front cover (1) and tighten fixing screws (3) to the specified torque. Remove chock (2).

NOTE The remaining fixing screws should be mounted after positioning the belt guard.

540850 ENGINE FLYWHEEL**Figure 87**

Make sure there are no blisters, cuts or damage of any kind anywhere on the surface of the flywheel (1) shown by the arrow, otherwise replace flywheel.

Check clutch disk bearing surface. If it shows any scoring it is necessary to lathe-shape it.


NOTE Flywheel rated thickness is 53 mm.

540852 Replacing bearing supporting gearbox input shaft

Gearbox input shaft supporting bearing (3) dismantling and refitting is carried out by means of a common punch.


540853 Replacing engine flywheel ring gear

Check the state of the teeth of the ring gear (2). If any teeth are broken or excessively worn, remove it from the flywheel (1) with a general-purpose punch and fit the new one, after heating it to a temperature of 150°C for 15 + 20 min. The bevel, made on the internal diameter of the ring, must be facing towards the flywheel.

Figure 88


Fit engine flywheel (1) without tightening fixing screws (2). For final screw (2) tightening see chapter "Flywheel setting".

NOTE Before reusing flywheel fastening screws verify with a micrometer that threading diameter of the screws is not less than 10.8 mm in any point, otherwise replace them.


5408 CONNECTING ROD - PISTON ASSEMBLY**Figure 89****CONNECTING ROD - PISTON ASSEMBLY**

1. Piston - 2. Pin - 3. Split ring - 4. Sealing ring - 5. Oil scraper ring - 6. Slotted oil scraper ring with spiral spring - 7. Connecting rod body - 8. Half bearings - 9. Connecting rod cap - 10. Cap fastening screws.

Check pistons: they must not show any trace of seizing, scoring, cracks or excessive wear, otherwise replace them.


Figure 90

Remove split rings (1) from piston (2) with pliers 99360183 (3).

Figure 91

Remove piston (1) from connecting rod by removing split ring (2) and extracting pin (3).

Figure 92




74944

MAIN DATA FOR KS PISTON, PINS AND PISTON RINGS - ENGINES 8140.43B/R

*Measured on the diameter of 91.4 mm.

Figure 93




74945

MAIN DATA FOR MONDIAL PISTON, PINS AND PISTON RINGS - ENGINES 8140.43B/R

*Measured on the diameter of 91.4 mm.

Figure 94



74946


MAIN DATA ON KS - MONDIAL PISTONS, PINS AND SPRING RINGS - ENGINES 8140.43N/S

*Measured on the diameter of 91.4 mm.

540840 Pistons

Measuring the pistons diameter

Figure 95




41101

Measure piston diameter (1), with a micrometer (2), to determine assembly clearance; measured diameter value must be equal to that indicated in the table of page 43.

NOTE Spare pistons have standard diameter with 0.4 mm oversize and include rings, pin and safety rings.

Figure 96




41102

The clearance between piston and cylinder liner can be also checked by means of a thickness gauge (1), as shown in this figure.

540841 Piston gudgeon pins

Figure 97




18857

Measurements of piston gudgeon pin diameter (1) with a micrometer (2).

Conditions for correct pin-piston coupling

Figure 98




41103

Lubricate pin (1) and the relevant seat on piston (2) hubs with engine oil; piston must allow to be inserted with a slight finger pressure and it should not come out by gravity.

540842 Piston rings


Figure 99



74947

The piston rings (1st slot) and oil scraper rings (2nd slot) have TOP etched on them: this should be facing upwards when they are fitted on the piston.


Figure 100



16552

Check piston ring (2) thickness with a micrometer (1).


Figure 101



74948

Checking the clearance between the V-ring (2) 1st slot and the associated slot on the piston with a feeler gauge (1) as follows. Insert the piston into the cylinder barrel so that the ring (2) comes approximately half way out of it.

Figure 102




41104

DIAGRAM FOR MEASURING THE CLEARANCE BETWEEN THE FIRST PISTON SLOT AND THE PISTON RING

1. 1st piston slot - 2. Piston ring - 3. Cylinder barrel

Using a feeler gauge (1, Figure 101) check the clearance (X) between the ring (2) and the slot (1); this clearance must be of the prescribed value.


Figure 103



41105

Check the clearance between the seal rings (2) of the 2nd and 3rd slot and the associated seats on the piston (3) with the feeler gauge (1).

Figure 104




18858

Checking, with a thickness gauge (1), the opening between piston ring ends (2), introduced in cylinder liner.

540830 Connecting rods

Figure 105



MAIN DATA FOR CONNECTING ROD, BUSHING, PISTON PIN AND HALF BEARINGS

* Internal diameter to be obtained after driving into the connecting rod small end and regrinding with reamer.

** Cannot be measured in free state.

- \varnothing of the connected rod supplied as a spare

NOTE Connecting rods are marked as follows:

- body and cap with a number identifying the coupling;
- Connecting rod cap with a letter: Q or X identifying the diameter class for connecting rod head mounted in production;
- connecting rod cap with a number identifying the load class for the connecting rod mounted in production;
- it could also be marked with the corresponding cylinder number.

In case of replacement, the new connecting rod shall be marked with the same numbers and letters as the old one.

Numbering shall be performed on the opposite side to half bearing retaining slots.

Spare connecting rods are supplied with 60.341 \div 60.348 head diameter marked with letter Q and load class identified with number 33.

Material removal is not admitted.

540834 Bushes

Make sure that bushing, in connecting rod small end, is not loose and free from any scoring and traces of seizure, otherwise replace it.


Dismantling and refitting are performed with a suitable punch.

When driving, check accurately that oil flow holes, on bushing and connecting rod small end, coincide.

With reamer reface bushing so as to obtain 32.010 \div 32.020 mm diameter.

Checking connecting rod for distortion

Figure 106




61696

Use tool 99395363 (5) to check connecting rod (1) axes parallelism and proceed as follows:

- fit connecting rod (1) on tool 99395363 (5) chuck and lock it by screw (4);
- set chuck (3) on V-prisms and rest connecting rod (1) on stop bar (2).

Checking torsion

Figure 107




Check connecting rod (5) torsion by comparing the two piston pin (3) points (A and B) on connecting rod axis horizontal surface.

Position dial gauge (2) support (1) so that dial gauge is precharged by approx. 0.5 mm on piston pin (3) on point A and set dial gauge (2) to zero. Move chuck (4) with connecting rod (5) and compare the difference, if any, on the opposite side (B) of piston pin (3): the difference between A and B shall not exceed 0.08 mm.

Checking bending

Figure 108




Check connecting rod (5) bending by comparing two piston pin (3) points C and D on vertical connecting rod axis. Set dial gauge (2) vertical support (1) on piston pin (3) point C. Move connecting rod forward and backward searching the highest piston pin position and set dial gauge (2) to zero when finding this condition.

Move chuck and connecting rod (5) and repeat the above operation on piston pin (3) point D. The difference between points C and D shall not exceed 0.08 mm.


**Assembling connecting rod - piston assembly
Coupling connecting rod - pistons**

Figure 109




Etched on the top of the piston are, at reference (1): the type of engine, selection of the class and supplier*; at reference (2): the direction for fitting the piston in the cylinder barrel; (3), mark on testing adhesion of 1st slot insert; at reference (4): adhesive label with the numerical code for optical reading of the type of engine and class selection.

Figure 110



Fit piston (1) to connecting rod (2) so as piston assembly reference and connecting rod numbers (3) can be seen as shown in the figure.


Figure 111



Set piston (1) on connecting rod, fit pin (3) and secure it with piston rings (2).

Checking for connecting rod - piston distortion

Figure 112




61697

After assembling connecting rod-piston assembly, use tool 99395363 (8) to check squaring as follows:

- fit connecting rod (7) and piston (3) on tool 99395363 (8) chuck (4) and lock it by screw (5);
- set connecting rod (7) on bar (6);
- position dial gauge (2) support (1) so that dial gauge is set on piston point A, with 0.5 mm preload and set dial gauge (2) to zero;
- move chuck (4) so that dial gauge (2) is set on piston (3) point B and check for any deviation.

Assembling piston rings

Figure 113




41097

Fit piston rings (1) on piston (2), using pliers 99360183 (3).

NOTE The piston rings for the 1st and 2nd slot must be fitted with the word "TOP" facing upwards.

Assembling connecting rod - piston assemblies in cylinder barrels

Figure 114




18863

Lubricated pistons correctly, including piston rings and cylinder liner interiors.

By means of ring clamp 99360605 (2) fit connecting rod-piston assemblies (1) into cylinder liners, checking that:

- the number of each connecting rod corresponds to cap fitting number.

Figure 115



45071

DIAGRAM FOR CONNECTING ROD-PISTON ASSEMBLY FITTING INTO CYLINDER


1. Piston - 2. Accessory components group - 3. Number printing area - A. Indirect injection engine piston (prechamber) - *Piston crown cavity - B. Direct injection engine piston

- piston ring openings are 120° offset one another;
- all pistons are of same weight;
- the symbol printed on the piston crown is directed towards flywheel, or the recess on the piston skirt corresponds to the position of oil spray nozzles.

NOTE Having not found any need to replace main bearings, it is required to refit them in the same order and position they were when dismantled.

540831 Measuring connecting rod assembly clearance


Figure 116



To measure clearance carry out the following operations:

- clean carefully the parts and remove any oil traces;
- place a cut down size of calibrated wire (3) on crankshaft pins (4).

Figure 117



- Fit connecting rod caps (2) with relevant half bearings.

NOTE The fitting of connecting rod cap of cylinder n. 4 is practicable only when piston is at T.D.C.

- Tighten screws, previously lubricated with UTDM oil, with torque wrench (1) to torque of 50 Nm + angle of $63^\circ \pm 3^\circ$;

NOTE For angular closing use tool 99395216.


- Remove cap (2) and determine existing clearance, by comparing calibrated wire width (3, Figure 116) with graduation of scale indicated on envelope (2, Figure 116) containing such a wire. If a clearance other than the one specified is found, replace half bearings and repeat check. Once prescribed clearance is obtained, lubricate connecting rod half bearings and fit them definitively by tightening connecting rod caps fastening screws as described.

NOTE Connecting rod caps fastening screws must be replaced with new ones, when fitted definitively.

Check manually that connecting rods slide axially on crankshaft pins.

Checking piston protrusion

Figure 118



Once connecting rods-pistons assemblies fitting is completed, check for piston (1) protrusion at T.D.C. with respect to upper crankcase surface, with thickness gauge (3) and calibrated rule (2).

In connection with measured protrusion, choose cylinder head replacement gasket, according to the following table.

| Piston average protrusion | Cylinder head gasket thickness* | |
|---------------------------|---------------------------------|--------|
| | Free | Fitted |
| 0.61 ÷ 0.80 | 1.48 ÷ 1.62 | ~ 1.40 |
| 0.40 ÷ 0.60 | 1.23 ÷ 1.35 | ~ 1.20 |


NOTE * Thickness of cylinder head gasket is calculated on the basis of maximum piston protrusion from the crankcase measured on all four pistons.

The difference between minimum and maximum protrusion of the four pistons should be equal to or less than 0.200 mm.

The cylinder head gasket included in the engine overhauling spare parts kit is supplied in its maximum size. Obviously, it can also be obtained in other sizes, as required.

540850 Flywheel adjustment

Figure 119



Make sure flywheel fastening screws (4) are slack. Apply gauge 99395214 (3) to engine crankcase. Rotate crankshaft so as to set piston (1) to T.D.C. Rotate crankshaft in direction opposite to that of rotation of $\sim 90^\circ$ ($89^\circ 25'$).

With the special dial gauge (2), determine exact balance point of pistons of cylinders 1 and 2, operating as follows: set to zero dial gauge (2) on piston of cylinder n.1; move dial gauge so set to zero, on piston of cylinder n. 2 and record deviation.

If no deviation is found, it means that pistons of cylinders 1 and 2 are perfectly balanced. In the opposite case, share out halved value of measured deviation, by rotating crankshaft conveniently.

Example:

- If deviation is in default, i.e.: 0.2 mm before zero setting point, it is required to rotate crankshaft in opposite direction to that of rotation, so that deviation is halved, that is, 0.1 mm.
- If deviation is in excess, i.e. 0.2 mm after zero setting point, it is required to rotate crankshaft in its direction of rotation of $\sim 1/4$ of turn, to recover crank mechanism clearances, then invert rotation direction until deviation is halved, that is, 0.1 mm.


Once balance of pistons is so determined, without moving crankshaft, direct flywheel in such a way that pin of tool 99395214 (3) is inserted into flywheel milling (\rightarrow).

Slightly tighten screws (4).

Remove tool 99395214.

Then tighten flywheel fastening screws (4) according to procedures described in the following figure.

Figure 120




Apply tool 99360306 (3).

Tighten flywheel (1) fastening screws (2) in two stages:

- 1st stage: tightening with torque wrench to torque 30 ± 3 Nm;
- 2nd stage: closing with $90^\circ \pm 2^\circ$ angle.

NOTE The angle closing is performed with tool 99395216 (4).


Figure 121



Rotate the engine, fit oil suction strainer (1), place sealing ring (2) and fit oil sump.

560610 CYLINDER HEADS
541210 Disassembling camshaft

Figure 122




Set tool 99361004 on adjustable support 99365014 and secure cylinder head on said support.
 Remove cover (3), unscrew camshaft (2) caps (1) fastening nuts, remove caps and shaft.

NOTE To avoid bending the camshaft too much, loosen the nuts fixing the caps (1) gradually and evenly.

Checks

The surfaces of the shaft support pins and of the cams must be ultra-smooth. If they show signs of seizure and scoring, replace the shaft.

Figure 124




Measure camshaft pins (2) diameter with a micrometer (1), and with an inside micrometer gauge the diameter of the hole defined by the union of caps to the relevant supports on cylinder head, that should be 0.035 ± 0.081 mm. If not so, replace concerned parts.

If it is necessary to replace the basin plugs on the ends of the camshaft, use a suitable punch for removal - refitting.

NOTE Before mounting the plugs, apply sealant on their sealing surfaces.

Figure 123



MAIN DATA ON CAMSHAFT, RELEVANT SUPPORTS AND CAPS ON CYLINDER HEAD


* Normal diameter - ** 0.2 mm oversize diameter

541211 Checking cam lift and journal alignment

Set shaft on centres and check, with a centesimal dial gauge placed on central support, that alignment error is no greater than 0.04 mm, otherwise replace shaft. Also check cams lift: it should be 10.5 mm for those of outlet and 9.5 mm for those of inlet; if different values are found replace the shaft.

541224 VALVE TAPPET


Figure 125



25227

MAIN DATA ON VALVE TAPPET AND RELEVANT SEAT ON CYLINDER HEAD

Figure 126




18877

Extract valve tappet (1) complete with adjusting caps, placing them in a container according to the order they were when removed.

Lateral surface of valve tappet must be very smooth and dent free.

Small dents can be eliminated with a very fine abrasive stone.

Figure 127




18891

Check valve tappet (1) diameter, with a micrometer (2) and with an inside micrometer gauge the diameter of relevant seats on cylinder head; they must be equal to those indicated in Figure 125. The normal fitting clearance between the maximum diameter of valve tappet and that of seats is $0.030 \div 0.075$ mm.

The replacement of valve tappet, because of an excessive clearance in the seats, requires to fit oversized valve tappet after boring the seats by means of a suitable reamer.

540662 Disassembling valves

Figure 128




41113

Valve dismantling is performed with tool 99360268 (1) by exerting a pressure on cap (3) so that, pressing springs (4 and 5) it is allowed to remove lock cones (2). Then remove: upper cap (3), springs (4 and 5) and lower cap (6).

Repeat operation on all valves.

Overtum cylinder head and remove valves (7).

Figure 129




50674

Using suitable pliers (1), remove the seal rings (2) from the valve guides.

Checking cylinder head seal

Figure I30



18542

Check for hydraulic leak by means of suitable equipment (1-2-3-4).

Supply water, through pump, heated at ~ 90°C and at 2 ÷ 3 bar pressure.


Should plug leaks be found, replace them using a proper beater for removal/refitting.

NOTE Before mounting the plugs, apply water-reacting sealant on their sealing surfaces.

If there is any leakage from the cylinder head, it must be replaced.

Checking cylinder head mating surface

Figure I31




18879

The check of mating surface of the head (1) to cylinder group is performed by means of a rule (2) and a thickness gauge (3). If a deformation is found, measure cylinder head thickness, whose rated value is 150 ± 0.1 mm.

When checking, if the amount of material to be removed for flattening cylinder head is greater than 0.4 mm, replace cylinder head.

540662 VALVES

Figure I32




41115

MAIN DATA ON INTAKE AND EXHAUST VALVES AND VALVE GUIDES

Removing deposits, refacing and checking valves

Figure I33




18625

Remove any carbonic deposits on valves, using the special metal brush.

Check that valves do not show any trace of seizure, crack or burning. Regrind seats on valves, if necessary, with grinder 99301014, removing an amount of material, as little as possible.

Figure I34




18882

With a micrometer (2) measure valve stem (1): it must be 7.985 ÷ 8.00 mm.

Checking clearance between valve stem and valve guide and centring valves

Figure 135




41842

These checks are carried out with a magnetic-base dial gauge (1) set as shown. Assembly clearance is 0.023 ± 0.053 mm. On emptying valve (2) check that centring error is not greater than 0.03 mm.

540667 VALVE GUIDES
Replacing valve guides


Figure 136



18883

Remove valve guide with punch 99360288 (1).


Figure 137



18885

Heat cylinder head to $80^\circ \pm 100^\circ\text{C}$ and with punch 99360288 (1) equipped with part 99360291 (2) fit new valve guide (3) previously cooled in liquid nitrogen.

Figure 138




41116

Valve guide fitting.

Reaming valve guides

Figure 139




18886

Once valve guides are driven, sleek them with smoothing tool 99390310 (1).

540661 VALVE SEATS
Regrinding and replacing valve seats

Figure 140




18887

Check valve seats (2). If any slight scoring or burning is found regrind them with tool HUNGER 99360419 (1) according to inclination values specified in Figure 141.


If it is required to replace them, using the same tool and taking care not to damage the cylinder head, remove as much material as possible from valve seats, until it is possible to extract them from the cylinder head with a punch.

Figure I41



18889


Figure I42



18888

Heat cylinder head to $80^\circ + 100^\circ\text{C}$ and, by means of a suitable punch (1), fit in it the new valve seats (2), previously cooled in liquid nitrogen.
With tool HUNGER 99360419, regrind valve seats according to inclination values specified in Figure I41.


Figure I43



50675

Clean injector seats from any deposit, using cutter 99394038 (1).


Figure I44



18890

Fit valves and injectors.
Check valve sealing and respective seats with tools (1-2).

Figure I45




18880

With dial gauge (1) check that, from cylinder head surface, the hollow of valves and injector (2) protrusion have the prescribed value.

540665 VALVE SPRINGS


Figure 146



62386

Prior to reassembly, test valve spring flexibility by means of tool 99305047. Compare load and elastic deformation data with those applying to new springs shown in the following figure.

Figure 147




50676

MAIN DATA FOR ADJUSTING CONTROL VALVES SPRING EXHAUST

| EXTERNAL SPRING | | INTERNAL SPRING | |
|---------------------|---------------------------|-------------------------|---------------------|
| Height | Under a load of | | Height |
| mm | kg | | mm |
| H 52 | Free | | H 45.5 |
| H ₁ 38.5 | P ₁ 43.8 ± 2.5 | P ₁ 16.4 ± 1 | H ₁ 33.5 |
| H ₂ 28.5 | P ₁ 77.4 ± 4 | P ₁ 30 ± 1.5 | H ₂ 23.5 |

ASSEMBLING CYLINDER HEADS

Figure 148




62071

Should rear cover (1) be removed from cylinder head (3), fit a new gasket (2) at refitting and tighten fixing nuts to the specified torque.

Assembling valves


Figure 149



41122

Lubricate stem of valves and insert them in the relevant valve guides. With tool 99360292 (1) fit sealing ring (2) on intake and exhaust valve guides (3).

Figure 150




41113

Place on cylinder heads: lower cap (6), springs (4 and 5) and upper cap (3); with tool 99360268 (1) press springs (4 and 5) and secure parts to the valve by means of lock cones (2).

Assembling tappets

Figure 151




18877

Lubricate tappet seats and fit tappets (1) complete with adjusting cap, in the same sequence they were before dismantling.

Assembling camshaft

Figure 152




41123

Lubricate supports on camshaft (1) cylinder heads and fit camshaft.

Fit caps (2) on relevant supports, making sure that the numbers indicated on caps are turned to the same side as those indicated on cylinder heads.

Figure 153




41124

Screw nuts (1), that fasten caps (2) to cylinder heads, gradually and uniformly until bringing caps in contact with cylinder heads.

Then tighten nuts (1) to prescribed torque.

Figure 154



45081

Fit the seal ring (3) together with the chock into the front cover (4) using the keying device 99374336 (2) and the grip 99370006 (1).

Lubricate the shank of the camshaft.


Spread IVECO 1905685 sealant on the mating surface of the front cover (4) and fit it onto the cylinder head. Tighten the fixing nuts to the prescribed torque.

Remove the chock.

NOTE The seal ring (3) is supplied as a spare together with the choke; this must not be removed from the seal ring until the front cover (4) has been fitted on the cylinder head.

Adjusting tappet clearance

Figure 155




6423

VALVE GEAR DIAGRAM

Adjustment of valve tappet clearance must be carried out accurately so as not to alter the required valve gear diagram, as would occur if the clearance were greater or lesser than prescribed.

In fact, an excessive clearance causes noise or delays opening and advances valve closing, while an insufficient clearance causes the opposite effect; while if the clearance is quite null the valves always remain a little open with very harmful consequences as far as the life of the valves and seats is concerned.


Figure 156



For adjusting valve tappet clearance proceed as follows:

- insert key 99350114 (2) on valve gear control fastening screws and rotate camshaft until setting valves to closing position;
- check, with a thickness gauge (1), that clearance between valve tappets and intake/exhaust cams is 0.5 ± 0.05 mm.


Figure 157



If it is necessary to replace the adjusting caps, to obtain the required operating clearance, proceed as follows:


- rotate valve tappets so as milling on edge are directed towards intake and exhaust ducts;
- insert tool 99360309 (1), between intake and exhaust valve tappets, and use it as a lever until valve tappets are fully compressed;

Figure 158



- with gun (3), address a compressed air jet in milling (2) so as to lift adjusting cap (1) to be replaced;
- remove adjusting cap with pliers 99380701.

Figure 159



The thickness value of adjusting caps (1) is printed on one of their two surfaces. Should this value be illegible, measure it with a micrometer (2).


On fitting adjusting cap, printed value must be oriented towards valve tappets.

NOTE Valve tappet clearance adjusting caps are supplied as spare parts with the following thickness: 3,25 - 3,30 - 3,35 - 3,40 - 3,45 - 3,50 - 3,55 - 3,60 - 3,65 - 3,70 - 3,72 - 3,75 - 3,77 - 3,80 - 3,82 - 3,85 - 3,87 - 3,90 - 3,92 - 3,95 - 3,97 - 4,00 - 4,05 - 4,10 - 4,15 - 4,20 - 4,25 - 4,30 - 4,35 - 4,40 - 4,45 mm.

NOTE Having to adjust valve tappet clearance with cylinder heads installed on engine, before compressing valve tappet with tool 99360309 (1, Figure 157), rotate engine with special tool, so as to set intake valve cam of the cylinder involved in valve tappet adjusting, turned approximately upward; in these conditions piston will be 10-13 mm from T.D.C., thus avoiding piston crawling with valves.

Refitting cylinder head

Figure 160



61889

Set cylinder piston 1 to TDC and keep it in this position by locking engine flywheel (4) rotation and applying tool 99392214 (3) to block.

This condition is required to set timing.

Check that joining surface of cylinder heads and that on crankcase are clean.


Do not soil cylinder head gasket.

Place cylinder head gasket (2), according to thickness specified in paragraph "Checking piston protrusion", with inscription "ALTO" [top] (1) oriented towards head.

Arrow indicates the point where fitted gasket thickness is specified.

NOTE It is absolutely necessary to keep gasket sealed in its packing and to remove it from envelope only a short time before fitting it.

Figure 161



41144


Turn camshaft (2) to close cylinder 1 valves. Refit cylinder head (3).

NOTE Before reusing cylinder head fixing screws, check by micrometer whether screw thread diameter, measured at any point, is higher than 11.5 mm, otherwise replace screws.

Screw and tighten screws in three consecutive stages according to the sequence and procedure shown in the following figure.

NOTE Angle closing is carried out by means of tool 99395216 (1).

Figure 162




6448

Tightening order diagram for cylinder heads fastening screws:

- 1st step: pre-tightening with torque wrench to torque of 60 ± 5 Nm;
- 2nd step: return to torque of 60 ± 5 Nm;
- 3rd step: closing with $180^\circ \pm 10^\circ$ angle.

Figure 163



62072

Fill spaces **A** between rear cover (6) and cylinder head (5) with Silastic 732 RTV sealant.

Fit seal (2) on tappet cover (1). Smear tappet cover corners (\Rightarrow) with SILASTIC 732 RTV (approx. 10g). Refit tappet cover (1) on cylinder head and tighten fixing nuts (7) to the specified torque.


Fit pipe and electric cable locking clamps (8) and tighten fixing nuts (5) to the specified torque.

Fit sensor (4) and support on tappet cover and check air gap as described in the relevant chapter.

Fit intake manifold (3).

543050 AUXILIARY MEMBER ASSEMBLY

Figure 164



50677


Auxiliary components are collected into one support (1) fixed to engine upper block side and operated by the timing belt which controls the camshaft.

On the mounting there are oil ducts, for lubricating the various components.

The following components are fitted on said support: injection pump, oil pump and control valve, servo brake vacuum pump and power steering pump, double-action oil filter and heat exchanger.

Disassembling auxiliary member assembly


Figure 165



50677

Fit accessory equipments group with screws on support 99360363 (3) previously clamped in a vice. Unscrew oil filter (2) with tool 99360091 (1).


Figure 166



50678

With a socket head wrench (2) unscrew fittings (3) fastening heat exchanger (1) to the accessory equipments group (5) and mounting (4).


Figure 167



26244

Remove vacuum pump (1) complete with drive joint (2) and gasket. Remove oil pump rear cover (3) complete with oil pressure control valve.

Figure 168




50679

Remove the power steering pump (5). Take out the screws (3) and extract the oil pump control gear (4). Take out the screws (1) and remove the top cover (2).

543075 Oil pressure control valve

Figure 169




41812

Unscrew plug (5), remove spring (4) and control valve consisting of piston (3) and barrel (2) from the cover (1). Check that: piston (3) slides freely into barrel (2) and does not show any traces of scoring and that spring (4) is not broken or yielded.

Pressure adjusting calibration to oil temperature of 100°C:

- minimum rpm: 0.8 bars
- maximum rpm: 3.8 bars

Figure 170




74971

MAIN DATA FOR ADJUSTING OIL PRESSURE CONTROL VALVE SPRING

543010 OIL PUMP


Figure 171



18908

With a rule (2) and a thickness gauge (1) check clearance between upper surface of gears (3) and cover supporting surface that must be 0.065 ± 0.131 mm; otherwise replace worn parts.


Figure 172



26245

Remove oil pump driven gear (1).


Figure 173



26246

Remove screws and front cover (1).


Figure 174



26247

Remove oil pump driving gear (1).


Figure 175



Remove driven gear (1) only if an excessive wear of said gear or of entire driving gear (3) is detected; this operation must be carried out under a hydraulic press (2).

Assembling auxiliary member assembly


Figure 176



For assembling accessory equipments group, invert operations described for dismantling it observing the instructions described and illustrated here below.

Fitting operation of driven gear (2) on driving shaft (3) is to be performed with a hydraulic press (1), by heating gear and cooling shaft, so as a temperature difference of ~ 270°C between the two parts is found. Once fitting is completed, check that a space of 88 - 0.2 mm exist between outer surfaces of gears.


Figure 177



Check the torque resisting rotation between the driven gear and the oil pump driving shaft, proceeding as follows:


- apply tool 99360607 (2) to block rotation of gear (5);
- trace two reference marks (3) on shaft (4) and on gear (5);
- operate on the driving shaft with a torque wrench (1) calibrated at 64 Nm and tool 99360607;
- make sure the reference marks are perfectly aligned; replace the parts if they are not.

Figure 178




Fit the shaft (1) with the oil pump driven gear.

Figure 179



Fit the shaft (1) with the drive gear.


Figure 180



74949

Using the keying device 99374336 (2) and the grip 99370006 (1), fit the gasket (3) onto the front cover (4).


Figure 181



52378

Fit the front cover (2) with the gasket (1) on the auxiliary member support box and tighten the relative screws (3) to the required torque.

Figure 182




51700

Clean and degrease the mating surfaces of the cover (1) and the box supporting the auxiliary parts.

Spread IVECO 1905685 sealant on the sealing surface of the rear cover (1), indicated by the darker area, evenly and without any breaks.

Figure 183




50847

Fit the rear cover (2) and tighten the screws (3) and the fixing nuts to the required torque.

NOTE The rear cover (2) must be fitted within 10 minutes of applying the sealant.

Fit the vacuum pump (1).

Figure 184



50679


Fit the top cover (2) with the relative gasket and tighten the screws (1) to the required torque.

Fit the gear (4) and tighten the screws (3) to the required torque.

Fit the power steering pump (5).

543110 6-element heat exchanger

Figure 185




50681

On supplying heat exchanger (1) with air at 1 bar pressure, verify that no leaks exist from oil flow side (2) and also from water flow side.

Test conditions:

| | |
|---|----------------|
| Oil type | SAE 30 |
| Oil temperature at heat exchanger inlet | 115°C |
| Oil delivery | 30 litres/min |
| Water temperature at heat exchanger inlet | 85°C |
| Water delivery | 20 litres/min |
| PERFORMANCE | |
| Exchanged heat quantity | 4.0 kW |
| Oil pressure drop | 0.85 bar |
| Built-in safety valve (2) | |
| Opening pressure | 0.82+1.03 bars |

Figure 186




50682

Carefully clean support (2), heat exchanger (4) and fitting (5) and particularly their oil ways.

Always replace seal rings (1 and 3).

Figure 187




50823

Position the mounting (3) on the auxiliary member assembly (5) so that the hole (→) coincides with the centring pin (4). Position the heat exchanger (2) on the mounting (3) and constrain it to the auxiliary member assembly (5) with the fitting (1). Tighten the fitting (1) to the required torque.

NOTE Before mounting the fitting (1), spread IVECO sealant 1905683 onto its thread.

Figure 188




50677

Lubricate sealing rings with engine oil and place them on oil filter (2).

Screw oil filter on fittings (1, Figure 187) and tighten it with tool 99360091 (1) to 25 Nm torque.

Figure 189



Mount the auxiliary element assembly (2) fitting the gasket in between. Tighten the fixing screws with a torque wrench (3) to the prescribed torque.

NOTE As spares, the screws (1) are supplied with the thread pre-treated with LOCTITE 506 sealant. If they are reused, clean the thread thoroughly and apply IVECO 1905683 sealant at the section shown in the figure.

5050 LUBRICATION

General

Engine lubrication is forced circulation type and its is performed by the following components:

- gear oil pump built in accessory equipments group, a pressure control valve built in rear cover of accessory equipments group;
- a Modine type heat exchanger with built-in safety valve;
- a double-action oil filter with built-in safety valve.

Operation (see Figure 191)

Engine oil is sucked from sump by oil pump (8) through suction strainer (9) and sent under pressure to heat exchanger (4) where it is cooled.


Oil passes through oil filter (5) and conveyed to lubricate concerned components through ducts or pipes.

Once lubrication cycle is achieved, oil returns to sump by gravity. Oil filter can be cut out by built-in safety valve, in case it is clogged. Also heat exchanger, in case of clogging, is cut out by a safety valve.

NOTE To remove-check and refit the parts forming the oil pump and oil pressure adjustment valve, see "AUXILIARY MEMBER ASSEMBLY".

540480 Oil vapour recycling system

Figure 190




OIL VAPOUR RECYCLING SYSTEM DIAGRAM

Oil vapours formed into oil sump during engine running, pass through oil filler (1), are ducted into pipe (2) and then collected into condenser (4) where condensed vapours are drained into oil sump through pipe (5) and put into circulation again.

Exceeding vapours, if any, are discharged into atmosphere through pipe (3).

Figure 191




LUBRICATING SYSTEM DIAGRAM

1. Oil delivery pipe to camshaft - 2. Main oil delivery pipe - 3. Accessory equipments group with built-in oil pump seat - 4. "Modine" type water-oil heat exchanger - A. Oil delivery to engine - B. Oil suction from sump - 5. Double-action oil filter with built-in safety valve for clogged filter cut out - 6. Vacuum pump - 7. Oil pressure control valve - 8. Pump gears - 9. Oil suction strainer - 10. Oil spray nozzle for piston crown cooling - 11. Oil drainage pipe from turbocharger to crankcase - 12. Oil delivery pipe to turbocharger.

62183

5432 COOLING

Figure I92



52172

Description

The engine's cooling system is the closed-circuit, forced circulation type and comprises the following parts:

- an expansion tank whose plug has two valves incorporated in it: an outlet (2) and an inlet (1) that govern the pressure in the system;
- a coolant level sensor at the base of the expansion tank;
- an engine cooling module to dissipate the heat taken from the engine by the coolant with the heat exchanger for the intercooler;
- a heat exchanger to cool the lubricating oil;
- a centrifugal-type water pump built into the crankcase onto which the electric fan is keyed;
- an electric fan comprising an electromagnetic coupling on whose shaft turns an idle hub fitted with a mobile metal plate and on which is mounted the fan.

Coolant temperature for:

- turning on the fan: $94^{\circ}\text{C} \pm 2^{\circ}\text{C}$;
- turning off the fan: $80^{\circ}\text{C} \pm 2^{\circ}\text{C}$;
- a 3-way thermostat governing coolant circulation.

Operation

The water pump driven by the crankshaft via a poly-V belt sends the coolant into the crankcase and with a greater head into the cylinder head.

When the coolant temperature reaches and exceeds the working temperature it causes the thermostat to open and from here the coolant is sent to the radiator and cooled by the fan.

The pressure inside the system due to the change in temperature is governed by the outlet (2) and inlet valves built into the expansion tank filler cap (detail A).

The outlet valve (2) has a twofold function:


- to keep the system slightly under pressure so as to raise the boiling point of the coolant;
- to discharge into the atmosphere the excess pressure generated in case of high temperature of the coolant.

The function of the inlet valve (1) is to permit transferring the coolant from the expansion tank to the radiator when, inside the system, a low pressure is produced due to the decrease in volume of coolant as a result of its temperature lowering.

Outlet valve opening $1 \pm 0.1 \text{ kg/cm}^2$.
Inlet valve opening $0.005 \div 0.02 \text{ kg/cm}^2$.

543212 Electromagnetic pulley

Figure 193



50685

ELECTROMAGNETIC PULLEY SECTION


Specifications

- * Torque that can be entered at 1000 rpm and at 20°C 23 Nm
- * Torque that can be transmitted at 20°C with the clutch run in 43 Nm
- Voltage 12 Volt
- Consumption 24 W

When cooling fluid temperature reaches the value of $94^{\circ} \pm 2^{\circ}\text{C}$, thermometric switch allows electromagnet (1) to be supplied and that, becoming magnetized, it attracts movable plate (2) thus causing hub (4) to become integral with electromagnetic joint (3).

543210 Water pump

Figure 194




50686

WATER PUMP LONGITUDINAL SECTION

- 1. Pump body - 2. Bearing locking screw - 3. Pump driving shaft complete with bearing - 4. Sealing ring - 5. Impeller

A = 0.56 ± 1.08 mm; assembly clearance between impeller and sealing gasket for water pump body.

Figure 195




41128

Use a thickness gauge (3) to check that the distance between impeller (1) and sealing ring (2) is 0.56 ± 1.08 mm. Also check that there are no cracks in pump body. If there are, replace the whole water pump.

543250 Thermostat


Figure 196



50687

By-pass type thermostat (1) is inserted into the support (2) fixed to cylinder heads and it does not need any adjustment. If there are any doubts about its serviceability, replace it. The thermometric switch/transmitter and water temperature sensor are fitted on the thermostat body.


Figure 197



50822


- A. Stroke start $82^{\circ} \pm 2^{\circ}\text{C}$.
- B. Stroke at $97^{\circ} \geq 7$ mm
- Stroke at $110^{\circ} \leq 10.5$ mm
- The stroke of 7 mm within less than 60"
- Water blow-by with thermostat and valve closed ≤ 2 l/h

Figure 198



Fit new seal rings (2) and split rings (3) on the connecting pipe (4) and insert this into the thermostat box (1).

Figure 199




Insert the pipe (2) with the thermostat box (1) into the water pump (3) and fit the parts assembled in this manner onto the crankcase and onto the cylinder head.

NOTE As spares, the screws (4) are supplied with the thread pre-treated with LOCTITE 506 sealant. If they are reused, clean the thread thoroughly and apply IVECO 1905683 sealant on the first 15 mm.


TIMING AND AUXILIARY MEMBER CONTROL

Figure 200



Insert the reaction pin (2) into its seat in the water pump (1). Fit the guard (3) and the fixed tightener (4).

Figure 201




Fit the mobile tightener mounting without locking the nut (5) fixing the roller (4).

Insert, between barrel (1) and push rod (2), a special wrench (3) so as to annul push rod pressure on belt tightener roller (4).


Setting the timing system

Figure 202



Check whether cylinder I piston is at TDC. This condition takes place when tool 99395214 (1) pin (2) is fitted into engine flywheel (3) slit (⇒) and control gear hole (5) and timing gear (4) are facing downward.


Figure 203



45074

- Make coincide notch (1) engraved on camshaft driving toothed pulley, with that (2) engraved on valve tappets cover.


Figure 204



86143

- Fit toothed belt (1);
- fit lower cover (4) and tighten fastening screws and nuts to prescribed torque;
- remove tool (3) so as pushing rod (2), acting on belt tightener (5), makes toothed belt taut (1);

Figure 205




61900

- remove engine flywheel (3) slit (⇒) from tool 99395214 (1) pin (2);

- Turn the crankshaft slowly in the direction of rotation by two turns and check that hole (5) in gear (4) is facing downwards and that the pin (2) of the tool (1) is inserted in the slot (a) through the flywheel (3) when the timing belt is taut; the notches (1 and 2, Figure 203) must be aligned.

Figure 206




86144

- apply a torque of 28 ± 30 Nm to the crankshaft (3) to tension the belt (1) slightly;

Use tool 99395849 to check timing belt tension (1) which must be 90 ± 15 Hz in point A.


Figure 207



50711

Fit upper cover (1).


Figure 208



41808

Key the pulley (1) with the spacer, if any, found on disassembly or determined as described in "Checking crankshaft pulley alignment"; block engine flywheel rotation with tool 99360306 and tighten the setscrew with a torque wrench to the required torque.

Figure 209




62075

Fit the electromagnetic coupling (2) onto the water pump shaft (3) and tighten the nuts (1) to the required torque.

Checking and aligning electromagnetic coupling pulleys

Fit the puller key (5), puller (4) and measure the distance Y about 88.9 to 90.1 mm.

Figure 210



50696


Fit the hub (1), washer (2) and retaining nut (3). Block rotation of the hub (1) and tighten the nut (3) in two stages.

NOTE The hub (2) locking nut is left-handed. This nut (3) must be replaced at every dismantling.

1st step: tightening with torque wrench at 40 Nm torque;
2nd step: closing with $110^\circ \pm 10^\circ$ angle.

NOTE Angle closing is performed with tool 99395216.


Figure 211



41824

By means of thickness gauge (1) check the air gap that should be of 0.25 ± 0.45 mm.

Figure 212



62076

Fit the mounting (2 or 6) complete with alternator (1) back onto the crankcase base:


- mounting (2), for engines with air-conditioner compressor;
- mounting (6), for engines without air-conditioner compressor.

Tighten the screw (3) to a torque of $80 \div 90$ Nm
Tighten the screw (4) to a torque of $40 \div 50$ Nm.

Checking alternator pulley alignment

Check that the distance **X** between the crankcase and the end of the pulley (5) is $88.7 \div 90.1$ mm.

Figure 213



62077


Refit compressor (2) and tighten fixing screws (1) to 25 Nm torque.

Checking compressor pulley alignment

Check whether distance **y** between block and pulley end (3) is $106.96 \div 108.56$ mm.

544012 Adjusting alternator - water pump drive belt tension

Figure 214



50698

Cancel the action of the automatic tightener (2) with the screw (3).

Fit the drive belt (1) taking care to position its ribs correctly in the respective races of the pulleys.

Release the automatic tightener (2). Turn the crankshaft by 1 turn to settle the belt.

Using appliance 99395849, measure the tension of the belt (1) in section **A** water pump - alternator that must be 140 ± 5 Hz.

544035 Adjusting compressor - air-conditioner drive belt tension (see Figure 214)

Fit compressor (6) and tighten fixing screws (8) to 25 Nm torque.

Fit belt tighteners (5) without tightening screws (4 and 7).

Fit control belt (9) taking care to position its ribs into pulley grooves.


Operate on screw (11) to tension belt (9) and rotate drive shaft by one turn. Use tool 99395849 to check whether frequency in compressor-drive shaft section **B** is equal to 160 ± 10 Hz which corresponds to 500 ± 50 Nm.

Otherwise operate on screw (11).

Tighten screws (4 and 7) to 25 Nm torque.

Unscrew two turns screw (11) and lock nut (10) to 25 Nm torque.

Figure 215




74951

NOTE If the pump mount (5) had been removed, when fitting it on you need to insert a new gasket and position the mount (5) so that the hole A faces downwards.

Refit high pressure pump (4), oil dipstick pipe (3), oil filler (1) and rail (2).

NOTE Should high pressure pump (4) joint be replaced, use tool 99365143 to lock joint rotation when moving fixing nut and tool 99342138 to remove the joint from high pressure pump shaft. After fitting the new joint, tighten the fixing nut to the specified torque.

Figure 216



62078


Connect the pipe (5) to the high-pressure pump (6) and to the hydraulic accumulator (1).

NOTE Pipe fittings (4) of piping (5) must be tightened at prescribed torque by using a suitable wrench and dynamometric wrench 99389833. Connection (4) shall be tightened by keeping high pressure pump hexagon (3) stopped at the same time. Pipes (5) shall always be replaced after removing.

NOTE For engine 8140.435 only.

Since engine No. 3089322, a rail with the same configuration but without flow limiters and pressure relief valve has been mounted. The same prescriptions specified for the previous one shall be complied with.


Figure 217



50699

Fit the electro-injectors (1), position the brackets (3) on them and tighten the fixing screws (2) to the required torque.

Figure 218




62079

Connect the pipes (2) to the electro-injectors (1) and to the hydraulic accumulator (4).

NOTE Pipe fittings (3) of pipings (2) must be tightened at prescribed torque by using wrench 99317915 (5) and dynamometric wrench 99389833 (7). The couplings (3) must be tightened with a specific wrench keeping the hexagon (6) of the electro-injectors (1) and, if applicable, the hexagon (8) of the flow limiting valves stationary. The pipes (2) have to be changed with new ones with each removal.


Figure 219



74952

Fit protection (1) on rail (6) and tighten nuts (2) to the required torque. Hold valve (7) and connect fuel drain connection (8) to it with hose (5). Connect pipe (4) to high pressure pump (3).


Figure 220



62860

Press clips (2) in the direction shown by the arrow and connect pipe connection (1) to injectors (3). Fit rubber plug (4) into protection (5) and connect pipe (6) to connection (7).


Figure 221



62859

Connect to the heat exchanger (3) the pipe (4) including pipe (1) and fasten the latter to the bedplate by means of screws (1 and 5).


Figure 222



52163

Secure the pipe (8) to the crankcase base with the screw (9). With the nuts (7), secure the pipe (1) to the water pump (6). Connect the pipe (4) to the fitting of the cylinder head. Using the bracket (3), constrain the pipes (1 - 4) to the intake manifold (5), tightening the screw (2) to the required torque.

Figure 223




62855

Refit the soundproof cover (7). Refit air duct (6) including: solenoid valve (2), glow plug (3) and pipe (1) to intake manifold (1) and tighten nuts (4) to the required torque. Use connection (8) to connect pipe (10) to connection (9) and secure pipe (10) clamps with screws (5) and nut (11).

Connect the electrical connections of the engine cable, if any, to injectors (and refit the side cover), to air pressure and temperature sensor, to rail pressure sensor, to 3rd pumping element cut-out device, to engine rpm sensor, to revs. sensor and to thermostat box temperature sensor.

Reconnect the cooling fan to the electromagnetic joint. Apply lifting rig 99360549 to engine lifting hooks and hitch the lifting rig to the hoist, then remove engine from the rotary stand. Remove brackets 99361029.

Figure 224




62861

Complete engine assembly. Place new gaskets (1) on the cylinder head and fit the exhaust manifold (3) complete with turbocharger (4) and oil pipes (2 - 5).

NOTE Before fitting the turbocharger onto the engine, it is necessary to fill the central body with engine lubricating oil.

Secure the fitting (8) to the crankcase base with the screw (9). Secure the pipe (2) to the crankcase with the screw and with the fitting (7) complete with the oil pressure transmitter. Screw down the threaded plug (6).

Figure 225




50651

Fit the oil vapour condenser (8) complete with pipes (2 - 11). Connect the pipe (2) to the fillpipe (1). Connect the pipe (11) to the crankcase fitting. Connect the pipe (5) to the side cover (7). Connect the pipe (3) to the heat exchanger (4). Secure the pipe (10), with the screw (9), to the crankcase and, with the screw (6), to the cylinder head. Fill the engine with the required amount and grade of lubricating oil.

764264 Timing system speed sensor 764266 Engine speed sensor

Figure 226



50723

Check the sensor gap. It must be:

- 0.8 ÷ 1.5 mm, between the camshaft pulley (1) and the sensor (2).


If you find a different value, loosen the nut (3) and act on the mounting (4).

- 0.8 ÷ 1.5 mm, between the engine flywheel (5) and the sensor (6).

If you find different values, loosen the screws (7) and act on the mounting (8).

SUPERCHARGING

Figure 227



52174

TURBOCHARGING DIAGRAM FOR ENGINES 8140.43.B/R/S

Description

The turbocharging system comprises an air filter, turbocharger and the intercooler.

The air filter is the dry type comprising a filtering cartridge that can be periodically replaced.

The function of the turbocharger is to use the energy of the engine's exhaust gas to send pressurized air to the cylinders.

The intercooler comprises a radiator fitted onto the engine coolant radiator and its function is to lower the temperature of the air leaving the turbocharger to send it to the cylinders.

542410 Turbocharger type KKK K03-2076-CCA 6.68 MITSUBISHI TD 04 GARRETT GT 20

The turbocharger fitted on the engines 8140.43.B/R/S is the type with the pressure relief valve.

It is basically composed of:

- a central body housing a shaft supported by bushings at whose opposite ends are fitted the turbine rotor and the compressor rotor;
- a turbine body and a compressor body fitted on the end of the central body;
- an overpressure relief valve fitted on the turbine body. Its function is to choke the exhaust gas outlet, sending a portion of it straight into the exhaust pipe when the turbocharging pressure downstream from the compressor reaches the setting.


REPAIRS

NOTE On finding irregular operation of the engine due to the turbocharging system, before checking the turbocharger, it is wise to check the efficiency of the seals and the fastening of the coupling sleeves, checking moreover there are no blockages in the intake sleeves, air filter or radiators. If the turbocharger damage is due to a lack of lubrication, check that the oilways are neither burst nor clogged, in which case change them or remove the trouble.

542419 PRESSURE RELIEF VALVE Checking and adjusting the pressure relief valve

The following descriptions and illustrations refer to checking a KKK-type turbocharger that, by analogy, unless otherwise stated, hold for the MITSUBISHI and GARRETT type too.

Figure 228




33129

Cover the inlets and outlets of the air, exhaust gas and lubricating oil.

Thoroughly clean the outside of the turbocharger using anticorrosive and antioxidant fluid.

Disconnect the pipe (2) from the union of the pressure relief valve (1) and fit onto it the pipe of appliance 99367121 (1, Figure 229).

Figure 229



75821


Rest the tip of the dial gauge (1) with a magnetic base on the end of the tie rod (2) and reset it.

Using appliance 99367121 (5), introduce compressed air into the valve body (6) at the prescribed pressure and check this value stays constant throughout the check; if it does not, change the valve.

In the above conditions, the tie rod must have made the prescribed travel.

If you find a different value for the KKK type, take off the clip and turn the nuts (3 and 4) appropriately.

Figure 230



88617

For the MITSUBISHI type, loosen the nut (3) and turn the tie rod (4) appropriately.

For GARRETT type, unloosen nut (10) and properly turn ring nut (9).


Changing the pressure relief valve

For turbocharger MITSUBISHI, take off fastener (2) securing the tie rod to lever (1), and take valve (5) off the turbocharger by taking off securing screws (6).

For turbocharger GARRETT, take off fastener (7) securing the tie rod to lever (8), and take valve (12) off the turbocharger by taking off securing nuts (11).

Fit the new valve by carrying out the operations for removal in reverse order and adjust the travel of the tie rod as described under the relevant heading.

Figure 231



45078

For the KKK turbocharger, proceed as follows:

Take off the clip (1), remove the nut (2). Detach the bracket (3) supporting the relief valve (4) from the turbocharger.

Fit the new valve by carrying out the operations for removal in reverse order and adjust it as follows:

Screw the nut (6) onto the stem (5) of the valve down to the bottom of the thread; mount the lever (7) on the valve stem. Using appliance 99367121 (5, Figure 229) introduce compressed air into the valve (4) at the prescribed pressure; in this condition, screw down the nut (2) until the butterfly valve governed by the lever (7) goes onto the stop in its seat. Unscrew the nut (6) to bring it into contact with the lever (7) and at the same time lock the nuts (2 and 6).

Adjust the pressure relief valve as described under the relevant heading.

Afterwards, paint the nuts (2 and 6) with safety paint and fit the clip onto them and connect the pipe (2, Figure 228) to the valve (4), securing it with a new clamp.

542410 GARRET GT 2256 T variable geometry turbosupercharger (engine 8140.43N)

General

The variable geometry turbosupercharger consists of the following:

- centrifugal supercharger (1);
- turbine (2);
- set of mobile blades (3);
- mobile blade control pneumatic actuator (4), vacuum controlled by proportional solenoid valve controlled by EDC MS6.3 ECU.


Variable geometry enables:

- to increase the speed of the exhaust gases running into the turbine at low engine rpm;
- to decrease the speed of the exhaust gases running into the turbine at high engine rpm.

To obtain the max. engine volumetric efficiency also at low rpm (with on-load engine).

Operation at low engine rpm

Figure 232



62870


1. TURBINE - 2. MOBILE BLADES - 3. PNEUMATIC ACTUATOR - 4. REVOLVING RING

When engine is running at low speed, the exhaust gases show weak kinetic energy; under these conditions a traditional turbine shall rotate slowly, thus providing a limited booster pressure.

In the variable geometry turbine (1), the mobile blades (2) are set to max. closed position and the small through-sections between the blades increase the inlet gas speed. Higher inlet speeds involve higher tip speeds of the turbine and therefore of the turbosupercharger.

Engine speed increase results in a gradual increase of exhaust gas kinetic energy, and also in turbine (1) speed and booster pressure increase.


Figure 233



82871

Operation at high engine rpm

Figure 234




62872

The ECU, through the actuator control solenoid valve, modulates the vacuum acting on the diaphragm, so actuator (3) controls through the tie rod, the gradual opening of the mobile blades (2) until reaching the max. open position. Blade through-sections results larger thus producing a speed decrease in exhaust gas flow through the turbine (1) with speeds equal to or lower than those of the low rpm condition. Turbine (1) speed is therefore adjusted to a proper value enabling suitable engine operation at high speeds.

Proportional solenoid valve controlling turbocharger actuator

Figure 235




62876

The solenoid valve modulates the low pressure controlling the turbocharger actuator, taken from the air circuit of the servo brake, according to the information exchanged between the electronic control unit and the sensors: engine speed, throttle pedal position and pressure/temperature fitted on the intake manifold.

As a result, the actuator varies the opening of the blades of the turbocharger that adjust the flow of exhaust gases.

Actuator

Figure 237




62875

SECTION ON THE ACTUATOR

The actuator diaphragm, connected to the control rod, is governed by the low pressure on the top of the actuator.

The low pressure modulated by the proportional solenoid valve varies the movement of the diaphragm and, as a result, of the rod governing the turbine's mobile blades.

Figure 236




62869

TURBOCHARGING FUNCTIONAL DIAGRAM

- 1. Variable geometry turbocharger - 2. Pneumatic actuator - 3. Proportional solenoid valve - 4. Air filter - 5. MS6.3 control unit - 6. Servo brake - 7. Vacuum device - 8. High-pressure pump.

REPAIRS**Checking the actuator**

Figure 238



62873

Cover air, exhaust gas and lubricant inlets and outlets.

Clean the turbosupercharger outside accurately using anticorrosive and antioxidant fluid and check the actuator (6).

Clamp the turbosupercharger in a vice.

Apply vacuumer 99367121 (1) pipe to actuator (6) hose.

Apply the magnetic base gauge (2) to exhaust gas inlet flange in the turbine.

Set gauge (2) feeler pin on tie rod (3) end and set gauge (2) to zero.

Operate the vacuum pump and check whether the tie rod (3) stroke values correspond to the vacuum values shown in the following table:

| | |
|----------------------|-------------------------------|
| - vacuum 0 mm Hg | Fully open valve |
| - vacuum 150 mm Hg | Valve stroke 2.3 ÷ 2.7 mm |
| - vacuum 400 mm Hg | Valve stroke 9.7 ÷ 10.7 mm |
| - fully closed valve | Valve stroke 11 ÷ 12.4 mm |

If a different value is found, replace the turbocharger.

NOTE During the check the vacuum value shall not fall, otherwise the actuator shall be replaced.

NOTE NOT ALLOWED ARE:

- any replacement or regulation of the actuator, since the calibration of such component is made in an optimal way for each turbocharger and is guaranteed for the turbocharger;
- any operation on nut (5) and ring nut (4), since such operation does not change engine supply characteristics but may impair engine reliability and duration.

Ring nut (4) is sealed with antitempering yellow paint.

In case of engines under guarantee, each above specified intervention and/or alteration to paint applied on ring nut (4) causes the lapse of the guarantee.

FUEL SUPPLY HIGH-PRESSURE ELECTRONIC INJECTION SYSTEM (COMMON RAIL MS 6.3 OR EDC.16)

General

Common Rail MS6.3 is a high-pressure electronic injection system for fast diesel engines with direct injection. Its main features comprise:

- high injection pressures available (1350 bar);
- these pressures can be modulated between 150 bar up to the maximum operating pressure of 1350 bar, irrespective of the speed of rotation and engine load;
- capacity to operate at very high speeds (up to 6000 rpm);
- injection control precision (injection duration and advance);
- lower consumption;
- lower emissions.

The main functions of the system are basically as follows:

- checking fuel temperature;
- checking engine coolant temperature;
- checking amount of fuel injected;
- checking idling speed;
- cutting off fuel in release phase;
- checking cylinder balancing when idling;
- checking anti-sawing;
- checking smokiness at exhaust on acceleration;
- checking exhaust gas recirculation (E.G.R. if present);
- checking top speed limit;
- checking thermostart;
- checking activation of air-conditioning system (if any);
- checking auxiliary fuel pump;
- checking position of cylinders;
- checking main and pilot injection advance;
- checking closed cycle of injection pressure;
- checking turbocharging pressure;
- self-diagnosis;
- connection with immobilizer unit.


The system makes pre-injection (pilot injection) possible before T.D.C. with the advantage of decreasing the derivative of the pressure in the combustion chamber, lowering the noise level of combustion, which is typical of direct injection engines.

The control unit checks the amount of fuel injected, adjusting the line pressure and injection times.

The information the control unit processes to regulate the amount of fuel to be injected comprises:

- engine speed;
- coolant temperature;
- turbocharging pressure;
- air temperature;
- intake air quantity;
- battery voltage;
- diesel pressure;
- position of accelerator pedal.

Figure 239



HIGH-PRESSURE ELECTRONIC INJECTION SYSTEM COMPONENTS LAYOUT

1. Engine speed sensor - 2. Air temperature pressure sensor - 3. Thermostart glow plug - 4. Thermostart solenoid valve - 5. Timing phase sensor - 6. Electro-injectors - 7. Hydraulic accumulator (rail) - 8. Coolant temperature sensors - 9. Electromagnetic fan (Baruffaldi) - 10. Hydraulic accumulator (rail) fuel pressure sensor - 11. Compressor (if present) - 12. E.G.R. valve modulator (if present) - 13. High-pressure pump - 14. 3rd pumping element exclusion device - 15. Pressure regulator - 16. Fuel filter - 17. Heater - 18. Fuel temperature sensor - 19. Electric supply pump - 20. Fuel pre-filter - 21. Fuel tank - 22. Battery - 23. Control unit with atmospheric pressure sensor - 24. Fuel outlet assembly with calibrated hole - 25. Hydraulic accumulator (rail) pressure relief device - 26. Accelerator pedal sensor - 27. Clutch pedal sensor - 28. Brake pedal sensor - 29. Engine rev counter - 30. Tachograph - 31. Thermostart warning light.

SYSTEM OPERATION

Self-diagnosis - BLINK CODE

The control unit self-diagnosis system checks the signals from the sensors, comparing them with the admitted limits (see relative heading):

Immobilizer recognition

When the control unit receives the signal of the key on "MAR" it enables starting.

Checking fuel temperature

The control unit, with fuel temperature exceeding 75°C detected by fuel filter sensor, controls the pressure regulator to reduce line pressure (injection not modified). If temperature exceeds 90°C, power is reduced to 60%.

Checking engine coolant temperature

The control unit with the coolant temperature over:

- 98°C, operates the electromagnetic fan (Baruffaldi);
- 105°C, switches on the coolant temperature warning light.

Checking quantity of fuel injected

According to the signals from the sensors and the mapped values, the control unit:

- operates the pressure regulator;
- varies the "pilot" injection time to 2200 rpm;
- varies the "main" injection time.

Checking idling adjustment

The control unit processes the signals from the various sensors and regulates the amount of fuel injected:

- it operates the pressure regulator;
- it varies the injection times of the electro-injectors.

Within certain thresholds the speed takes account of the battery voltage.

Fuel cut-off in release phase

In the phase of releasing the accelerator pedal the control unit actuates the following logic elements:

- it cuts off supply to the electro-injectors;
- it partially reactivates supply to the electro-injectors before reaching idling speed;
- it operates the fuel pressure regulator.

Checking cylinder balancing on idling

According to the signals received from the sensors, the control unit controls the regularity of the torque at idling speed:

- it varies the amount of fuel injected into the single electro-injectors (injection time).

Checking regulator engine rotation (anti-sawing)

It ensures regular engine rotation at a constant rate while increasing revs.

The control unit processes the signals received from the sensors and determines the amount of fuel to be injected via:

- the pressure regulator;
- the electro-injector opening time.

Checking smokiness at exhaust on acceleration

With heavy acceleration, on the basis of the signals received from the debimeter and engine speed, the control unit determines the optimum amount of fuel to inject:

- it operates the pressure regulator;
- it varies the electro-injector injection time.

Checking exhaust gas recirculation (E.G.R. if present)

Depending on the engine load and the signal from the accelerator pedal sensor, the control unit limits the amount of air taken in, actuating partial suction of the exhaust gases.

Checking top speed limit

Depending on the number of revs, the control unit actuates two action strategies:

- at 4250 rpm, the control unit reduces fuel flow by reducing electroinjectors opening time, when 5000 rpm are exceeded it deactivates electroinjectors.

Checking rotation regularity during acceleration

Acceleration regularity is guaranteed under whatever condition by pressure regulator and electroinjectors opening time control.

Checking thermostart

In the phase of:

- starting
- after-starting

the control unit times operation of the thermostart control unit according to engine temperature.

Checking activation of air-conditioning system

The control unit operates the air-conditioning compressor:

- switching it on/off when the relative switch is pressed;
- momentarily turning it off (approximately 6 sec.) in the case of heavy acceleration or demand for full power, or if the engine coolant reaches a temperature of approx. 105°C.

Checking fuel pump

Irrespective of the speed, the control unit:

- supplies the auxiliary fuel pump with the key on MAR;
- cuts off auxiliary pump supply if the engine is not started up within a few seconds.

Checking diesel warming

It times operation of diesel warming in relation to ambient temperature.

Checking cylinder position

During each turn of the engine, the control unit recognizes which cylinder is in the power stroke and operates the injection sequence for the appropriate cylinder.

Checking pilot and main injection timing

According to the signals from the various sensors, including the absolute pressure sensor built into the control unit, the control unit determines the optimum point of injection according to internal mapping.

Checking injection pressure closed cycle

Depending on the engine load, determined by processing the signals from the various sensors, the control unit operates the regulator to obtain optimum line pressure.

Fuel supply

The fuel supply is calculated in relation to:

- accelerator pedal position
- engine speed
- quantity of air introduced.

The outcome may be corrected in relation to:

- the water temperature.

Or to avoid:

- noise
- smoke
- overloading
- overheating
- turbine over-revving.

The delivery can be modified in the case of:

- action of external devices (ABS), ABD, EDB
- serious trouble decreasing the load or stopping the engine.

After determining the mass of air introduced by measuring its volume and temperature, the control unit calculates the corresponding mass of fuel to inject into the relevant cylinder (mg per delivery) also taking into account the temperature of the diesel.

The mass of fuel calculated in this way is first converted into volume (mm³ per delivery) and then into degrees of throw, or duration of injection.

Correcting flow rate according to water temperature

A cold engine meets with greater resistance during operation: friction is high, the oil is still very viscous, the various clearances are not yet optimized.

In addition, the injected fuel tends to condense on the metal surfaces that are still cold.

The fuel supply for a cold engine is therefore greater than for a warm one.

Correcting flow rate to avoid noise, smoke or overloading

The behaviour that could lead to this kind of trouble is well known.

The designer has therefore included special instructions in the control unit to avoid it.

De-rating

In the event of the engine overheating, injection is modified, decreasing the delivery to a varying degree, in proportion to the temperature reached by the coolant.

Adjusting turbine speed (for variable geometry turbocharger - when present)

Turbine speed is adjusted by varying its geometry and is controlled by ECU through an electric signal which powers the pilot solenoid valve of the pneumatic actuator. ECU, according to signals received from engine rpm sensor, intake manifold pressure/temperature sensor and throttle sensor, processes the feedback signal to properly modulate turbine actuator pilot solenoid valve opening.

Injection timing electronic test

The advance (start of delivery, expressed in degrees) may be different from one injection to the next, also differentiated from one cylinder to another. It is calculated, similarly to the delivery, in relation to the engine load (accelerator position, engine speed and air introduced).

The advance is appropriately corrected:

- in phases of acceleration;
- according to the water temperature.

and also to obtain:

- lower emissions, noise and overloading;
- better vehicle acceleration.

An extremely high advance is set on starting, depending on the water temperature.

Feedback from the start of delivery is supplied by the change in impedance of the injector solenoid valve.

Speed governor

The electronic speed governor has both features of governors:

- idling and top speed
- all speeds

It is stable in ranges where conventional, mechanical governors are imprecise.

Engine starting

During the first few turns of the engine, the stroke and cylinder no. 1 recognition signals (flywheel sensor and camshaft sensor) are synchronized.

The accelerator pedal signal is ignored on starting. Starting delivery is set only according to water temperature, by a special map.

When the control unit detects such speed and acceleration of the flywheel as to be able to consider the engine started up and no longer driven by the starter motor, it re-enables the accelerator pedal.

Cold starting

If even just one of the three temperature sensors (water, air or diesel) records a temperature lower than 10°C, pre-post heating is activated.

When the key makes contact the pre-heating indicator light comes on and stays on for a length of time that varies in relation to the temperature (while the heater at the intake manifold inlet warms the air), then flashes. It is now possible to start up the engine.

When the motor is running this indicator light goes out, while the heater continues to be powered for a certain length of time (variable) for post-heating.

If, with the indicator light flashing, the engine is not started up within 20 ÷ 25 seconds (inattention time), the operation is cancelled so as not to run down the batteries pointlessly.

The pre-heating curve is also variable in relation to the battery voltage.

Warm starting

If the reference temperatures all exceed 10°C, when the key makes contact the indicator light comes on for approximately 2 sec., for a short test, and then goes out. It is now possible to start up the engine.

Run up

When the key makes contact, the control unit transfers the information stored in memory when the engine was last stopped into the main memory (see After run) and makes a diagnosis of the system.

After run

Whenever the engine is switched off with the key, the control unit stays powered for a few seconds by the main relay.

This makes it possible for the microprocessor to transfer some data from the main memory (of the volatile type) to a non-volatile memory, which can be cancelled and written over (EEPROM), so as to make it available at the next start up (see Run Up).

These data basically consist of:

- various settings (engine idling adjustment, etc.);
- settings of some components;
- fault memory.

The process lasts a few seconds, typically from 2 to 7 (depending on the amount of data to save), after which the ECU sends a command to the main relay and makes it disconnect from the battery.

NOTE It is extremely important for this procedure not to be broken off, for example by switching off the engine with the battery cut-out, or by disconnecting the battery cut-out before 10 seconds have passed since switching off the engine.
If this happens, the functioning of the system is ensured, but repeated interruptions may damage the control unit.

Cut-off

This function cuts off fuel delivery when the vehicle is decelerating (accelerator pedal released).

Cylinder balancing

Individual cylinder balancing contributes to increasing comfort and handling.

This function permits individual, customized control over the delivery of fuel and the start of delivery for each cylinder, even differently from one cylinder to another, to compensate for the hydraulic tolerances of the injector.

The differences in flow (delivery specifications) between the various injectors cannot be evaluated directly by the control unit. This information is supplied by Modus reading the bar code of each injector at the time of assembly.

Synchronization search

If there is no signal from the camshaft sensor, the control unit is anyhow able to recognize the cylinders into which the fuel is to be injected.

If this occurs when the engine is already running, the combustion sequence has already been acquired, so the control unit continues with the sequence on which it has already been synchronized.

If this occurs when the machine is at a standstill, the control unit energizes a single solenoid valve. Within at most 2 turns of the crankshaft, injection will take place in that cylinder, so the control unit just needs to get synchronized on the order of combustion and to start up the engine.

Operation

A piston pump supplies diesel at a regulated pressure equal to that of injection (up to 1350 bar).

A 2-way solenoid valve taps an adequate amount of fuel from the pump delivery in order to regulate the pressure on the desired value.

The diesel under pressure is accumulated in a hydraulic accumulator (rail) that performs the function of capacity to limit the pressure ripples.

A pressure sensor is fitted on the hydraulic accumulator (rail) with the job of sending a signal (feedback) to the pressure adjustment circuit.


The electro-injectors are supplied by the rail and their operation is determined by the excitation of a fast electromagnetic actuator built into the body of each electro-injector that, by opening a gap, causes a difference in pressure, making it possible for the needle to open.

An electronic control unit, in which the control and power units for operating the electro-injectors are integrated, is enabled to control the entire injection system.

Some sensors, connected to the control unit, make it possible to determine the status of the engine and injection system, as well as the demand for power from the driver, at any moment.

This system is completed by the possibility of operating an EGR actuator and an actuator for a turbocharger equipped with a waste-gate or a turbocharger with variable geometry (if present on the engine).

Figure 240



50701

FUNCTIONAL DIAGRAM

- 1. 3rd pumping element exclusion device - 2. Engine speed sensor on engine flywheel - 3. High-pressure pump - 4. Pressure regulator - 5. Other actuators (thermostart, heated filter, fan control, AC control) - 6. Electronic control unit with atmospheric pressure sensor built in - 7. Other sensors (accelerator, brake, clutch, vehicle speed, water temperature, air temperature) - 8. From the manifold (rail) pressure sensor - 9. Fuel tank - 10. Pre-filter - 11. Motor pump - 12. Fuel filter - 13. Filter overpressure valve - 14. Exhaust assembly with calibrated hole - 15. Pressure relief device of hydraulic accumulator (rail) - 16. Air flow rate meter - 17. Hydraulic accumulator (rail) - 18. Electro-injectors - 19. Stroke sensor on camshaft pulley.

- A** To thermostart
- Electric circuit
- Fuel at low pressure
- · — · — Fuel at high pressure

HYDRAULIC SYSTEM

The hydraulic system is composed of:

- tank;
- pre-filter;
- electric supply pump;
- fuel filter;
- high pressure supply pump;
- pressure regulator;
- manifold (rail);
- electro-injectors;
- supply pipes and fuel recirculation.

773010 Fuel pump

This rotary positive displacement pump with integrated by-pass is mounted on the suction pipe, on the left-hand side of the chassis frame.

The fuel pump is the roller-type with positive displacement, a brush motor with energizing by permanent magnets.

The impeller turns, driven by the motor, creating volumes that shift from the inlet port to the delivery port.


These volumes are defined by the rollers that stick to the outer ring when the motor turns.

The pump has two valves, a check valve to prevent the fuel circuit from emptying (with the pump stationary) and an overpressure valve that recirculates the delivery with the inlet when pressures over 5 bar are produced.

Specifications


| | |
|--------------------------|---------------|
| Delivery pressure: | 2,5 bar |
| Flow rate: | > 155 l/h |
| Power supply: | 13.5 V - < 5A |
| Coil resistance at 20°C: | 28.5 Ohm |

Figure 241



50707

CROSS-SECTION OF FUEL PUMP

542011 Fuel filter**Figure 242**

88613

1. Clogging signalling sensor - 2. Temperature sensor connector - 3. Heater support - 4. Water in signalling sensor - 5. Overpressure valve - 6. Heater connector - 7. Bending insert - 8. Fuel filter - 9. Water separator - 10. Connector - 11. Connector - 12. Purging screw.

The fuel filter is composed of a cartridge (8) equipped with a water separator (9).

The water accumulation capacity (A) of the filter is approx. 100 cm³.

The water indicator (4) is mounted on the bottom end. Unscrewing the indicator (4) drains off any water.

Heater support (3) has an integrated temperature sensor. On heater support (3) there are screwed up sensor (1) to signal filter clogging and overpressure valve (5).

When the temperature of the diesel is less than 6°C, an electric heating element warms it up to at most 15°C before sending it to the pressure pump.

When diesel oil temperature is under 6°C, a resistor heats the oil up 15°C maximum before delivering it to high pressure pump.

Overpressure valve characteristic

opening pressure $1.8 \begin{matrix} +0.2 \\ -0.3 \end{matrix}$ bar


Clogging indicator characteristics

differential working pressure $0.8 \begin{matrix} +0.05 \\ -0.1 \end{matrix}$ bar

Tightening torques

| | |
|--|------------|
| 1. Tightening clogging signalling sensor | 20±2 Nm |
| 4. Water indicator | 0.8±1.2 Nm |
| 5. Tightening overpressure valve | 25±2 Nm |
| 7. Threaded insert * | 30±2 Nm |
| 8. Fuel filter tightening | 18±2 Nm |
| 10. Connector | 30±2 Nm |
| 11. Connector | 30±2 Nm |
| 12. Bleed screw | 12 Nm |

* Before assembly, apply thread-stop LOCTITE on the thread.

Fuel pipes**Figure 243**

75585

1. High-pressure pump supply pipe quick-coupling fitting – 2. Supply pipe quick-coupling fitting – 3. Fuel return pipe quick-coupling fitting – 4. Fuel filter mounting.

If disconnecting the fuel pipes (1-2-3) from the mounting (4), it is necessary, when refitting, to make sure their fittings are perfectly clean. This is to avoid an imperfect seal and fuel getting out.

775010 High-pressure pump

This is the "radialjet" type with three radial pistons (total displacement 0.7 c.c.). It is operated by the timing belt without any need for timing.

Each pumping assembly is composed of:

- a piston (5) operated by a cam (2) integral with the shaft of the pump (6);
- an inlet plate valve (3);
- a delivery ball valve (4).

The high-pressure pump must be supplied by the motor pump at a pressure of at least 0.5 bar.

The maximum delivery pressure reaches 1350 bar.

The delivery pressure is controlled by a pressure adjustment solenoid valve mounted on the pump.


The high-pressure pump is lubricated and cooled by the diesel through appropriate channelling.

In addition, the pump is equipped with a 3rd pumping element exclusion device.

Specifications:

| | |
|-----------------------------|---|
| Type | with radial pumping elements |
| Number of pumping elements: | 3 |
| Total displacement: | 0.7 cm ³ |
| Volumetric efficiency: | > 80% at 1000 bar from 500 to 3000 rpm pump |
| Operating range: | up to 1350 bar |
| Input power: | 3.2 kW at 1000 bar and 3000 rpm pump |
| Top speed: | 3000 giri/min |
| Supply: | Diesel at a pressure of 0.5 bar, with a minimum flow rate of 0.5 l/min more than the flow rate absorbed by the high pressure. |

Figure 244



1. 3rd pumping element exclusion solenoid valve - 2. Push rod - 3. Inlet plate valve - 4. Cylinder - 5. Pumping element - 6. Pump shaft - 7. Inlet - low pressure (from diesel filter) - 8. Delivery ball valve - 9. Delivery - high pressure (rail) - 10. Delivery - low pressure (recirculation) - 11. Three-lobe cam


50702

3rd pumping element exclusion device

The 3rd pumping element exclusion device is composed of a solenoid valve (1, Figure 244) that by means of the push rod (2, Figure 244) keeps the inlet valve (3, Figure 244) open during the delivery phase of the 3rd pumping element (5, Figure 244). It is activated by the electronic control unit when the engine, running above 4200 rpm, does not increase the power. The fuel thus discharged (approx. 1/3 of the delivery), before being put into the recirculation circuit, increases the efficiency of the high-pressure pump.

771034 Pressure regulator

Figure 245



1. Valve - 2. Ball shutter - 3. Pin - 4. Body - 5. Coil -
6. Pre-loading spring - 7. Anchor

It is mounted on the high-pressure pump and operated by the electronic control unit. It regulates the supply pressure of the fuel for the electro-injectors.

The pressure regulator is mainly composed of:

- a ball shutter (2)
- a pin (3) controlling the valve (1)
- a pre-loading spring (6)
- a coil (5).


With the solenoid de-energized, the delivery pressure depends on the pre-load of the spring.

Pressure modulation is obtained by supplying the solenoid coil in PWM (Pulse Width Modulation) and closing the regulation loop by feedback from the pressure sensor, the PWM signal has a carrier of 1000 Hz and the duty cycle can be varied via software from 1% to 95%.

Replacing pressure regulator.


Accurately clean high pressure pump and operate as follows.

Figure 246



Take off screws (2) and unthread pressure regulator (3) from high pressure pump (1).


Figure 247



Accurately clean the seat (⇒) of pressure regulator and the connection surface (⇒) of the regulator.


NOTE For cleaning, do not use tools which could damage the surfaces and pay attention that impurities are not introduced into channels.

Figure 248



Mount new seal rings (2 and 3) on pressure regulator (1) and lubricate the rings with vaseline.


Figure 249



Mount pressure regulator (2) on high pressure pump (1).

NOTE Mounting operation must be performed keeping the regulator perpendicular to connection plane without angling it, in order not to damage seal rings (2 and 3, Figure 248).

Figure 250




Screw up screws (1) and tighten them at 6 ± 7 Nm ($0,6 \pm 0,7$ kgm) torque.

NOTE Where pressure regulator is replaced on the engine mounted on the vehicle, it is needed, after replacement, to check that there are no fuel leaks after an engine working period.

774510 Hydraulic accumulator (rail)

NOTE For engine 8140.43S only.
Since engine No. 3089322, a rail with the same configuration but without flow limiters and pressure relief valve has been mounted. Component description given in the following pages stands valid for engines up to this serial No.

Figure 251



The hydraulic accumulator is mounted on the cylinder head on the opposite side to the intake. With its volume of approximately 29 cm^3 dampens the pressure ripples of the fuel due to:


- the operation of the high-pressure pump
- the opening of the electro-injectors.

The flow limiters (2) are mounted on the top of the hydraulic accumulator (1).

The fuel pressure sensor (4) and pressure relief valve (5) are mounted on the bottom.

774512 Flow limiters


Figure 252



These ensure engine operation protecting the vehicle against the risk of fire in the event of fuel leakage: internal (electro-injector jet jammed open) or external (pipe fittings, loose or damaged electro-injectors under high pressure). Under regular conditions, piston (1) is kept in open position by spring (2) and fuel pressure that, due to section difference between piston (1) internal and external surface operates highly on the latter one. When there is high pressure loss at limiter outlets, inlet pressure prevails and overcoming spring (2) reaction moves piston (1), closing fuel outlet U.

774511 Pressure relief valve

Figure 253




52177

When the pressure of the fuel exceeds the setting of the pressure relief valve (1550 bar) it overcomes the reaction of the spring (2) and, by shifting the plunger (1), discharges the fuel into the low pressure - recovery circuit.

Figure 254

**542025
542026 Fuel recirculation and supply system**

The supply system is divided into a low-pressure circuit and a high-pressure circuit.
 The low-pressure circuit comprises: pre-filter pipes, motor pump, fuel filter, fuel outlets, recirculation pipes, thermostart solenoid valve and thermostart glow plug.
 The excess fuel of the high-pressure pump is partly used for lubricating and cooling the pump and with the excess fuel from the electro-injectors supplies the thermostart.
 The excess fuel from the hydraulic components flow into the outlets.
 The union fixing the outlet coupling and the pressure relief valve of the hydraulic accumulator contains a calibrated hole whose purpose is to keep an overpressure of 0.5 bar in the starter heater circuit.
 The system does not require air bleeding.
 The low pressure supply pipes, except for the recirculation pipes, are fast coupling ones.




FUEL SUPPLY AND RECIRCULATION SYSTEM DIAGRAM

- 1. Thermostart glow plug - 2. Thermostart solenoid valve - 3. Electro-injector - 4. Hydraulic accumulator (rail) - 5. 3rd pumping element exclusion solenoid valve - 6. High-pressure pump - 7. Fuel filter - 8. Motor pump - 9. Pre-filter - 10. Tank - 11. Pressure control valve - 12. Fitting - 13. Pressure relief valve - 14. Flow limiters.

61982

775010 ELECTRO-INJECTORS

Figure 255



50704

1. Pressure rod - 2. Pin - 3. Nozzle - 4. Coil -
 5. Pilot valve - 6. Ball shutter - 7. Control area -
 8. Pressure chamber - 9. Control pipe - 10. Low-pressure
 fuel return - 11. Control pipe - 12. Supply pipe -
 13. Electrical connection - 14. High-pressure fuel inlet fitting
 - 15. Spring

Electric injectors feed at high pressure (up to 1350 bar) and recirculate at atmospheric pressure; recirculation is necessary for diesel oil used for pilot valve operation.

The temperature of the diesel put back into circulation by the electro-injector can get very high (approximately 120°C).

The head of the electro-injector has a fitting for the electrical connector.

They are mounted on the cylinder head and operated by the injection control unit.

The electro-injector can be divided into two parts:

- actuator/jet composed of pressure rod (1), pin (2) and nozzle (3)
- control solenoid valve composed of coil (4) and pilot valve (5).

Operation

Electro-injector operation can be broken down into three phases:

- "rest position"

Coil (4) is de-energised, and shutter (6) is in closing position and prevents fuel from being introduced into the cylinder, $F_c > F_a$ (F_c : caused by fuel pressure acting on control area (7) of rod (1); F_a : caused by line pressure acting on pressure chamber (8)).

- "start of injection"

The coil (4) is energized and causes the shutter (6) to rise. The fuel of the control volume (9) flows off towards the return manifold (10) causing a drop in pressure in the control area (7).

At the same time, line pressure through feed duct (12) applies a force $F_a > F_c$ in pressure chamber (8) lifting peg (2), with fuel being consequently introduced into cylinders.

- "end of injection"

The coil (4) is de-energized and makes the shutter (6) return to its closed position. This recreates such a balance in the forces as to make the pin (2) return to its closed position and consequently end injection.

Injector level

The injector level is the set of characteristics of the amount of fuel injected in relation to the duration of the electrical signal at different pressures of injection. Accurate knowledge of these characteristics is of fundamental importance in determining the necessary electrical signal to inject the desired quantity of fuel.

Experimental measurements

The injector level can be measured:

- on the injector test bench;
- on the engine on the bench.

In both cases an injection pressure is established and the injectors are actuated (in the case of the test bench it is also possible to measure one injector at a time) with an electrical signal of fixed frequency (NG) and duration (ET).

On the injector test bench, the injected quantity is measured by directly accumulating, for a set time, the fuel in graduated burettes, then dividing the accumulated quantity by the number of injections.

On the engine on the bench, the injected quantity (QCARB) is measured indirectly by the consumption of fuel, generally measured with a gravimeter and expressed in kg/h. The measurement should be made for a sufficiently long time so as to average out errors.

However, it is necessary that throughout the measurement the speed of the engine and the injection pressure remain constant. In addition, all recirculation (pump, pressure regulator, injectors) must be put back into the circuit downstream from the meter so the measurement is not changed.

The quantity injected by each injector in each cycle is therefore:

$$Q_c = C_n \cdot \frac{1}{60} \cdot \frac{1}{eNG} \cdot \frac{1}{8} \cdot 10^6$$

where Q_c injected quantity in $\text{mm}^3/\text{cycle}/\text{cylinder}$
 C_n hourly consumption in kg/h
 NG speed in rpm
 δ fuel density in kg/dm^3
 ($\delta_{\text{diesel oil}} = 0.835 \text{ kg}/\text{dm}^3$).

while

$$\text{with } e = \frac{N_c}{N_t} \cdot 2$$

N_c number of cylinders
 N_t number of strokes (2 or 4)


It may immediately be seen how in the case of the test bench the delivery is measured for each single injector, whereas with the engine on the bench the delivery is averaged over the number of injectors. In this last case, it is therefore not known whether there are differences between the injectors. It is therefore useful to measure the temperature of the exhaust gas of each cylinder, a fairly reliable index of the torque delivered by each single cylinder and therefore of the amount of fuel introduced with each cycle. On the basis of these measurements it is possible to tell whether the injectors have a similar behaviour to one another.

To do this it is necessary to have thermocouples or thermometers to be placed in contact with each exhaust manifold outlet, in the area close to the cylinder head fixing flange.

ELECTRIC/ELECTRONIC COMPONENTS

766161 Electronic control unit MS6.3 or EDC 16

Figure 256



The control unit is a "flash EPROM" and so it can be reprogrammed from outside without changing the hardware. The injection control unit has the absolute pressure sensor built in to further improve the control of the injection system. The control unit is mounted on the left-hand side of the engine bay and is connected to the vehicle's wiring harness by two connectors:

MS6.3:

- 43-pin connector **A** for the components on the engine
- 43-pin connector **B** for the components on the vehicle

EDC.16:

- 60-pin connector **A** for the components on the engine
- 94-pin connector **K** for the components on the vehicle

In addition to handling the operation of the system described under the relevant heading, the electronic control unit is interfaced with the other electronic systems on the vehicles such as ABS - ABD - EBD cruise control, speed limiting device, immobilizer (IVECO CODE).

SENSORS

Engine speed sensor

This is an inductive sensor and is positioned on the flywheel. It generates signals obtained from lines of magnetic flux that cross through holes in the flywheel. There are 58 holes.

The electronic control unit uses this signal to measure the speed of rotation of the engine, its angular position and to operate the electronic rev counter.

If this signal fails the rev counter will not work.

Camshaft timing sensor

It is either an inductive type sensor for MS6.3 central unit or a Hall effect type sensor for EDC.16 central unit, and it is positioned on timing system shaft pulley.

The signal generated by this sensor is used by the electronic control unit as a redundant signal to measure the different engine speeds.

772655 Air temperature and pressure sensor

Positioned on the intake manifold, it measures the pressure of the turbocharging air introduced into the intake manifold.

This value, together with that of the air temperature sensor, makes it possible for the electronic control unit to calculate the exact quantity of air introduced into the cylinders so as to operate the injectors adjusting the fuel delivery, limiting harmful emissions, improving consumption and performance. The sensor contains an electronic temperature correction circuit to optimize the pressure measurement in relation to the temperature of the intake air.

772656 Fuel temperature sensor

Integrated in the fuel filter, it measures the fuel temperature and transmits it to the electronic control unit.

When the fuel temperature is too high (ambient temperature, engine at full load and tank in reserve), correct lubrication of the high-pressure pump is no longer assured. On the basis of the values received, the control unit determines the density and volume of the fuel, correcting the delivery limiting engine performance.

774511 Fuel pressure sensor

This is mounted in the middle of the hydraulic accumulator (rail) and it has the task of providing feedback for the injection control unit to:

- adjust injection pressure
- adjust the duration of injection.

766161 Atmospheric pressure sensor

This is integrated in the electronic control unit. It provides a criterion of correction for the measurement of the air flow rate and to calculate the reference air flow rate to check the EGR.

764254 Engine coolant temperature sensor

This provides the control unit with an index of the thermal status of the engine in order to determine corrections for the fuel delivery, injection pressure, EGR injection advance when starting cold (if mounted) and Warm-Up.

505910 Throttle pedal position sensor

The accelerator pedal position sensor provides the control unit with a voltage value in proportion to the angle of operation of the pedal determining fuel delivery.

772641 Clutch pedal position sensor

Mounted on the pedal board, it provides the control unit with a positive signal when the clutch is engaged (pedal released). Every time the clutch is disengaged to change gear, the control unit fails to receive this signal and deactivates the Cruise Control function.

772642 Brake pedal position sensor

There are two of these sensors mounted on the pedal board. With the brake pedal released, they provide the control unit with a positive signal that is used to detect brake operation so as to deactivate the Cruise Control function and stop delivery of fuel.

In addition, a sensor switches on the brake lights.

764261 Vehicle speed sensor

This sensor, mounted on the gearbox by the drive output shaft, transmits the vehicle speed signal, through the electronic tachograph, to the control unit.

ACTUATORS

The injection system comprises three classes of actuators interlocked with the electronic control unit:

- electro-injectors (see relevant heading);
- regulators (see relevant headings) requiring PWM control (Pulse Width Modulation):
 - for pressure
 - EGR (if mounted)
 - turbocharger with variable geometry (if mounted);
- actuators with continuous ON/OFF signal to:
 - engage electromagnetic coupling for radiator cooling fan;
 - turn on/off air-conditioner compressor (if mounted);
 - Cruise Control;
 - thermostart control;
 - fuel filter heating;
 - electric supply pump.

NOTE All the power controls are made with relays located in the cab.

PWM (Pulse Width Modulation) controls

A PWM control has an active and an inactive state that alternate within a constant set length of time. During the active state the actuator control circuit is closed, which is thus powered with the control voltage; whereas, during the inactive state the circuit is open.

The duration of the two states may be varied with the condition that the sum of the two times is equal to the length of the modulation delivery.

The duration of the active state determines the duty-cycle, which is normally expressed as a percentage of the total time. Therefore, if the duration of the two active and passive states are the same, the duty-cycle is equal to 50%.

For reasons of diagnostics, the duty-cycle is limited between 1% and 99%; the control resolution is equal to 0.005% (1/20000 of the time).

The time length has been chosen taking account of the dynamic actuator response specifications.

Too low a carrier frequency could cause oscillations in the actuator, while too high a frequency would decrease control resolution.

The E.G.R. and variable geometry turbocharger (if mounted) are controlled through a vacuum modulating valve.

**EXHAUST GAS RECIRCULATION SYSTEM
E.G.R.
(vehicles with homologation MI)**

The EGR system is similar to the one made on the 8140.63 engine and covered under the specific heading.

It differs from the version on 8140.63 engines in the control performed by the EDC control unit and in the different settings of the modulating solenoid valve and of the pneumatic one of the EGR.

GUIDE TO TROUBLESHOOTING

INTRODUCTION

Good diagnostic is mainly obtained when using Iveco electronic diagnostic tools (Modus/IWT).

When a vehicle enters the workshop, information given by the driver shall be taken in duly consideration but the first thing to do is to connect Modus/IWT and to perform an accurate and thorough diagnostic analysis:

- failure memory reading;
- parameter reading;
- engine test;
- etc.

Print out results, specially if Help Desk assistance is required.

In this case, take into account that Help Desk can reject assistance requests based only on blink code.

The blink code, when present, is a tool which can be useful in some cases (vehicle stopped along the road, Modus/IWT missing) but must not replace the diagnosis with Iveco tools, as it only provides rough indications.

Another factor that favours failure solving is experience.

To remove in part the lacking of experience of repair operators on this new electronic system, (since there is no previous system to be used for reference), the following pages contain a GUIDE TO TROUBLESHOOTING drawn up by Training together with the experts that have designed and developed Common Rail MS6.3 or EDC 16.

Take into account that "Troubleshooting" cannot replace Modus/IWT, but it is a further aid, a sort of condensed experience derived from the in-depth knowledge of the system.

"Troubleshooting" is divided into two separate sections:

- the first one, organised according to Blink Codes or DTC-FMI, concerns failures that can be directly detected by MS6.3 EDC 16. These failures are mainly electric - electronic;
- the second one, organised according to symptoms, describes failures that cannot be directly detected by the ECU. These failures are mainly mechanical - hydraulic.

"Troubleshooting" does not replace diagnostic through Iveco electronic diagnostic tools but is an integration to it.

Ist Section
BLINK CODE
with MS6.3 central unit

Blink code

With the key turned off, press the diagnosis button.

- Two sets of flashes of the EDC warning light with a short pause in between indicate the code number of the first error stored in memory.
- Press the button again to pass on to the next error.
- After reaching the last error, the first one is repeated.
- The list of errors contains all the errors stored in memory and not only the active ones.
- The order of presentation of the errors respects the chronological order in which they appeared.

This table gives the error codes:

To delete the list of errors from the control unit memory, follow this procedure:

- with the key turned off, press the diagnosis button;
- keeping the button pressed, turn the key on;
- keep the button pressed for 5 seconds;
- let go of the button;
- turn the key off.

| Blink-Code | Warning light | Failure | Reduction level (*) |
|-----------------|---------------|--------------------------------|---------------------|
| VEHICLE | | | |
| 1.1 | On | Vehicle speed | |
| 1.2 | | (not used) | |
| 1.3 | Off | Cruise Control push buttons | |
| 1.4 | Blinking | Accelerator pedal | * |
| 1.5 | Off | Clutch switch plausibility | |
| 1.6 | On | Brake switch plausibility | |
| 1.7 | Off | Brake/accelerator plausibility | Idling |
| 1.8 | Off | Diagnostic warning light | |
| 1.9 | Off | Air conditioner | |
| ENGINE 1 | | | |
| 2.1 | Blinking | Water temperature sensor | * |
| 2.2 | Off | Air temperature sensor | |
| 2.3 | On | Diesel fuel temperature sensor | |
| 2.4 | Blinking | Booster pressure sensor | * |
| 2.5 | Off | Atmospheric pressure sensor | |
| 2.7 | Blinking | Fuel electric pump | |
| 2.8 | Off | Fuel heater | |
| 2.9 | On | Fan | |
| ENGINE 2 | | | |
| 3.1 | Blinking | Cylinder 1 balancing | |
| 3.2 | Blinking | Cylinder 2 balancing | |
| 3.3 | Blinking | Cylinder 3 balancing | |
| 3.4 | Blinking | Cylinder 4 balancing | |
| 3.5 | Off | Battery voltage | |
| 3.6 | Off | Glow plug warning light | |
| 3.7 | Off | Glow plug relay | |
| 3.8 | Off | Glow plug relay | |
| 3.9 | Off | Glow plug control | |
| VGT | | | |
| 4.4 | Blinking | VGT control | |
| 4.5 | On | VGT solenoid valve | |

| Blink-Code | Warning light | Failure | Reduction level (*) |
|----------------------|---------------|--|--------------------------------|
| INJECTORS | | | |
| 5.1 | Blinking | Cylinder 1 injector solenoid valve | |
| 5.2 | Blinking | Cylinder 2 injector solenoid valve | |
| 5.3 | Blinking | Cylinder 3 injector solenoid valve | |
| 5.4 | Blinking | Cylinder 4 injector solenoid valve | |
| 5.7 | On | Block 1 (cylinders 1-4) | |
| 5.8 | On | Block 2 (cylinders 2-3) | |
| ENGINE RPM | | | |
| 6.1 | Blinking | Flywheel sensor | * |
| 6.2 | Blinking | Timing sensor | * |
| 6.4 | Blinking | Runaway speed rate | |
| FUEL PRESSURE | | | |
| 8.1 | Blinking | Fuel pressure control | * or engine switching off |
| 8.2 | Blinking | Fuel pressure sensor | * |
| 8.3 | Blinking | Pressure limiter | |
| 8.4 | On | 3rd pumping element cut-out solenoid valve | |
| 8.5 | On | EGR control | |
| 8.6 | On | EGR solenoid valve | |
| 8.7 | On | Flow meter | |
| 8.8 | Off | Air temperature sensor (flow meter) | |
| ECU | | | |
| 9.1 | Blinking | ECU error (Gate array) | * Engine switching off |
| 9.2 | On | ECU error (Eeprom) | |
| 9.3 | Blinking | Immobilizer - EDC communication | |
| 9.4 | On | Main relay | |
| 9.5 | Off | After run stopped repeatedly | |
| 9.6 | Blinking | Engine not switched off by key | |
| 9.7 | Blinking | Sensor power | * I or engine switching off |
| 9.8 | Blinking | ECU error (Checksum) | Impossible to start |
| 9.9 | Blinking | ECU error (Operating system) | Engine switching off |

* Cases in which there is a reduction in power.

| BLINK CODE | EDC WARNING LIGHT | POSSIBLE CAUSE | POSSIBLE FAILURES | RECOMMENDED TESTS OR OPERATIONS | REMARKS |
|------------|-------------------|--|--|--|---|
| I.1 | On | Vehicle speed sensor - not plausible or absent signal | Speed indication on speedometer may be failing. Light defect with high speeds. | Road test with IWT-IT2000 Read parameters Check wiring, connections and involved components | If the speed value read on IWT-IT2000 is fixed although the vehicle speed is varying, there is a communication fault between sensor and ECU. Should signal be missing, Cruise Control can be activated also at low speeds (operation according to PTO parameters) since the ECU does not detect that the speed threshold discriminating between PTO and Cruise Control modes have been exceeded. |
| I.1 | On | Vehicle speed signal (section between speedometer and ECU) shorted to positive or to ground | Faulty CRUISE CONTROL/PTO Light defect with high speeds. | Road test with IWT-IT2000 Check plausibility between speedometer indication and speed read by IWT-IT2000 Check wiring, connections between speedometer and ECU and involved components | If the speed value read on IWT-IT2000 is fixed although the vehicle speed is varying, there is a communication fault between speedometer and ECU. |
| I.3 | Off | Non-plausibility of CRUISE CONTROL/PTO push buttons | Faulty CRUISE CONTROL/PTO | Read parameters with IWT-IT2000 to detect the faulty push button Check wiring between steering column stalk and ECU, connections and control push button | |
| I.4 | Blinking | Accelerator pedal potentiometer shorted to positive or to ground, or excessive accelerator pedal voltage or potentiometer failure. | Power reduction. 1500 rpm accelerated idling | Read parameters with IWT-IT2000. Check wiring, connections and components | Should it be impossible to accelerate using the pedal, drive using the Cruise Control push button after disconnecting the speed sensor. |

| BLINK CODE | EDC WARNING LIGHT | POSSIBLE CAUSE | POSSIBLE FAILURES | RECOMMENDED TESTS OR OPERATIONS | REMARKS |
|------------|-------------------|--|---|---|--|
| 1.5 | Off | Clutch switch: not plausible or absent signal | Faulty CRUISE CONTROL/PTO Or, when depressing the clutch pedal with CRUISE CONTROL/PTO on, engine comes up to peak rpm Light defect at gear shifting. | Depress completely the pedal clutch and read state parameters on IWT-IT2000. If failure persists, check wiring, connections and proper switch assembling | If check is OK, failure could be due to poor clutch activation (it is possible to shift gears without activating the switch) If the clutch signal is absent, Engine test cannot be performed. |
| 1.6 | On | Brake switches: not plausible signals between primary and secondary | Possible stop light malfunctioning. Faulty CRUISE CONTROL/PTO | State parameters Wiring, connections, switches | Check proper pedal switch assembling (they must activate at the same time) |
| 1.7 | Off | Brake/accelerator pedal plausibility: brake and accelerator activated at the same time | Engine speed comes down to idling | Read parameters on Modus IWT-IT2000, check whether accelerator pedal potentiometer signal sets to zero when releasing, otherwise it is possible that the driver has depressed brake and accelerator at the same time. | If the brake is activated with the accelerator depressed, engine runs idle until releasing the brake to enable vehicle stop even if the accelerator pedal is locked in intermediate position. It is however possible to accelerate although the brake pedal is depressed without activating safety strategies. |
| 1.8 | Off | EDC lamp shorted or with open circuit | The EDC indicator light fails to come on when turning the key ON, or it always stays on even with the key turned OFF | Check component wiring connections | The functionality of the indicator light is of vital importance for the system's operation and integrity. Sensitize the user to verify that the indicator light works properly with every ignition (if there are no faults in memory, it has to turn on for 2 sec. and then go out). |

| BLINK CODE | EDC WARNING LIGHT | POSSIBLE CAUSE | POSSIBLE FAILURES | RECOMMENDED TESTS OR OPERATIONS | REMARKS |
|------------|-------------------|---|---|---|--|
| 1.9 | Off | Air-conditioning compressor control contactor coil shorted to conditioning earth or circuit open. | In case of open circuit at 8a pin, also 2.7, 2.8 and 2.9 are recorded Faulty conditioner compressor | Measurable relay parameters Check wiring, connections and relay | |
| 2.1 | Blinking | Circuit open, shorted to earth or shorted to positive of water temperature sensor, the fuel temperature is used instead | Difficult starting cold Engine cooling fan always on Power reduction (and noise since pre-injection is not effected) | Reading parameters on Modus IWT-IT2000 Checking wiring and connector of water temp. sensor, sensor replacement | The fan comes on with fuel temperature = 20 °C If the water and diesel temp. are the same, the substitution value is active. |
| 2.1 | Blinking | See 2 ^s Section: "The engine fails to start" | See 2 ^s Section: "The engine fails to start" | See 2 ^s Section: "The engine fails to start" | See 2 ^s Section: "The engine fails to start" |
| 2.2 | Off | Intake manifold air temperature sensor short to positive or to ground, or circuit open. | Light performance reduction at cold, light smoke when accelerating with warm engine, 3.9 indication at the same time and smoke at starting. Smoke at starting and when accelerating at high speed with warm engine | Read parameters on Modus IWT-IT2000. Check wiring and component. | 40°C air temperature fixed substitution value is set; glow plug control as a function of air temperature not operating. Flame start is however performed if water or fuel temperature sensors indicate < 0 °C and is deactivated when reaching 0° C |
| 2.3 | On | Fuel temperature sensor short to positive or to ground, or circuit open. | If the electric failure depends on pin 30 see also 2.1 Difficult cold starting. | Read parameters on Modus IWT-IT2000. Check wiring, connections and component. | Water temperature is adopted as substitution value. Should also this signal be missing, 40 °C fixed value is adopted. |

| BLINK CODE | EDC WARNING LIGHT | POSSIBLE CAUSE | POSSIBLE FAILURES | RECOMMENDED TESTS OR OPERATIONS | REMARKS |
|------------|-------------------|--|--|--|---|
| 2.4 | Blinking | Air turbocharging pressure sensor on intake manifold shorted to earth, circuit open or shorted to positive or supplied by current exceeding the minimum or maximum limit | Puff of smoke on acceleration VGT: reduced power Smoke on acceleration | Reading parameters on Modus IWT-IT2000. Checking wiring and component | |
| 2.5 | Off | ECU built-in atmospheric pressure sensor short to ground or to positive or circuit open. | Black smoke on vehicles with EGR (not excluded in height) | Read parameters on Modus IWT-IT2000. Contact Help Desk and comply with its instructions to replace the ECU, if required | The pressure value being used as substitution value is the last valid value recorded by ECU |
| 2.7 | Blinking | Fuel motor pump contactor shorted to positive | Batteries discharge Early deterioration of the motor pump The fuel motor pump is always active even with the engine turned off | Active diagnosis with Modus-IWT-IT2000 Check the wiring, connections and component | It is possible to hear the noise of the pump turning continuously, even with the key off. |
| 2.7 | Blinking | Coil of contactor for fuel motor pump shorted to earth or with open circuit | The engine cuts out or fails to start | Active diagnosis with Modus-IWT-IT2000 Check the wiring, connections and component | |

| BLINK CODE | EDC WARNING LIGHT | POSSIBLE CAUSE | POSSIBLE FAILURES | RECOMMENDED TESTS OR OPERATIONS | REMARKS |
|------------|-------------------|---|--|---|--|
| 2.7 | Blinking | Fuel motor pump contactor shorted to positive | Early deterioration of the motor pump Battery discharges | Active diagnosis on status parameters with Modus-IWT-IT2000 Status parameters Check wiring, connections and component | It is possible to hear the noise of the pump turning continuously, even with the key off |
| 2.8 | Off | Fuel filter heater contactor shorted to positive – the heater is always on even with fuel temperature > 5°C | Battery discharges | Active diagnosis with Modus-IWT-IT2000 Check the wiring, connections and component | |
| 2.9 | On | Fan electromagnet shorted to positive | Increased fuel consumption | Active diagnosis with Modus-IWT-IT2000 Check the wiring, connections and component | The fan is always on (with engine running) |
| 2.9 | On | Contactor coil shorted to earth or circuit open | Overheating of the engine and consequent possible limitation on power Engine cooling fan doesn't work | Active diagnosis with Modus-IWT-IT2000 Check the wiring, connections and component | |
| 2.9 | On | Fan contactor coil shorted to positive | Increased fuel consumption Engine cooling fan always on even with engine cold | Active diagnosis with Modus-IWT-IT2000 Check the wiring, connections and component | |

| BLINK CODE | EDC WARNING LIGHT | POSSIBLE CAUSE | POSSIBLE FAILURES | RECOMMENDED TESTS OR OPERATIONS | REMARKS |
|--|--------------------------|--|---|--|--|
| 3.1 or 3.2 or 3.3 or 3.4 | Blinking | Injector unbalanced | Possible irregular rotation and smokiness. EDC indicator light blinking from idling to approximately 1300 rpm | Engine test with Modus-IWT-IT2000 Replacement of defective injector, if any | The control unit must modify the signal to the relevant injector (Cylinder Balancing) too far past the normally expected value |
| 3.1 or 3.2 or 3.3 or 3.4 | Blinking | If not linked to 5.1 - 5.2 - 5.3 - 5.4, flow-limiter intervention due to pressure loss downstream the rail towards the involved cylinder | Engine running with 3 cylinders | Check for leaks outside injector pipes or inside the injector | Do not switch off the engine since it will re-start only after having removed the failure |
| 3.5 | Off | Battery voltage too low | Accelerated idling up to 1300 rpm with released pedal | Battery test with IWT-IT2000 Perform suitable checks on voltage regulator and batteries | |
| 3.5 | Off | Battery voltage too low | Engine switching off or not starting | Battery test. Check battery, terminals, wiring, alternator and voltage regulator | Engine off if battery voltage < 6,5V |
| 3.6 | Off | Starter heater indicator lamp shorted to positive or with open circuit | Indicator light always off. Cold starting difficult | Active diagnosis with Modus-IWT-IT2000 Check the wiring and component | The driver doesn't wait for pre-heating, even at low ambient temperatures, as there is no indication from the indicator light |
| 3.6 | Off | Starter heater indicator lamp shorted to earth | Starter heater indicator light always on | Active diagnosis with Modus-IWT-IT2000 Check the wiring, connections and component | Pre-heating works, but with cold starting there is no indication on when to start the engine because the lamp stays on. |

| BLINK CODE | EDC WARNING LIGHT | POSSIBLE CAUSE | POSSIBLE FAILURES | RECOMMENDED TESTS OR OPERATIONS | REMARKS |
|------------|-------------------|---|--|---|---|
| 3.7 | Off | Starter heater glow plug contactor shorted to earth | Possible destruction of the starter heater due to overheating because it is always supplied Battery discharges | Active diagnosis with Modus-IWT-IT2000 Check the wiring, connections and component | |
| 3.8 | Off | Starter heater solenoid valve contactor coil shorted to earth | 3.9, the battery can quickly discharge. Cold starting difficult Smoke on starting | Active diagnosis with Modus-IWT-IT2000 Check the wiring, connections and component | The solenoid valve is always activated, the fuel passes continuously through the glow plug in the intake manifold |
| 3.8 | Off | Starter heater solenoid valve contactor coil shorted to positive or with open circuit | If shorted to positive 3.9, smoke 1.5 - 1.6 - 1.3 - 2.1 - 2.2 - 2.3 - 3.6 if the electric trouble is correlated to the common earth of the components involved Cold starting difficult | Active diagnosis of the contactor Check the wiring and component | |
| 3.9 | Off | Glow plug solenoid short to ground | Smoke, noise, fuel smell and faulty engine performance Fuel consumption increase | Active diagnostic Check wiring, connections and component. | Solenoid valve always open, with key to ON fuel flows continuously into intake manifold |

| BLINK CODE | EDC WARNING LIGHT | POSSIBLE CAUSE | POSSIBLE FAILURES | RECOMMENDED TESTS OR OPERATIONS | REMARKS |
|--|-------------------|--|---|---|--|
| 4.4 | Blinking | Booster pressure too high, too low or too different from the provided value (for mechanical locking) | 4.5 Possible consumption increase due to exhaust back pressure Early turbine wear Power reduction Smoke when accelerating (due to air excess or lack) | VGT test Read parameters on Modus IWT-IT2000. Check VGT mechanism movement Check VGT actuator Check wiring Check VGT pneumatic control circuit | Mechanism locked partially/completely closed or open Or VGT solenoid valve short to positive or to ground |
| 4.5 VGT only | On | VGT actuator short to positive or to ground or circuit open | 4.4 and power reduction (and noise since pre-injection is not performed) Smoke when accelerating (due to air excess or lack) | VGT test Check wiring, connections and component. | If wiring to pin 8a short to positive or open, the following are also faulty: - fan control - VGT control - 3 rd pumping element cut-out - pressure regulator - EGR - conditioner compressor - fuel motor pump |
| 5.1 5.2 5.3 5.4 | Blinking | Corresponding cylinder injector shorted to positive | 3.1- 3.2 -3.3 -3.4 The engine runs on 2 cylinders | Engine test Wiring - connections – electrical part of relevant injector | The engine turns only with pairs of cylinders (2 and 3 or 1 and 4) After turning off and back on again the engine turns with 3 |
| 5.1 or 5.2 or 5.3 or 5.4 | Blinking | Injector electrical part short to ground or circuit open | 3.1 - 3.2 - 3.3 - 3.4 Engine running with 3 cylinders | Engine test. Check wiring, connections and component. | |

| BLINK CODE | EDC WARNING LIGHT | POSSIBLE CAUSE | POSSIBLE FAILURES | RECOMMENDED TESTS OR OPERATIONS | REMARKS |
|------------------|-------------------|---|---|--|---|
| 5.7 or 5.8 | Blinking | Power stage of cylinders 1 and 4 or 2 and 3 (in control unit) defective | 3.1 - 3.2 - 3.3 - 3.4 The engine runs on 2 cylinders | Delete fault memory and try again If the error remains, call the Help Desk and follow their instructions to replace the control unit, if necessary. | It might happen if the outer casing of the control unit has been shorted with battery + (accidentally with a spanner, etc.) |
| 6.1 | Blinking | Flywheel sensor: signal missing or not plausible | Difficult starting with warm engine, starting impossible with cold engine Power reduction (and noise since pre-injection is not performed) | Read parameters on Modus IWT-IT2000. Check wiring, connections and sensor assembling | Should flywheel signal be missing, camshaft sensor signal is adopted |
| 6.2 | Blinking | Camshaft sensor: signal missing or not plausible | Difficult starting with warm engine, starting impossible with cold engine Power reduction | Check wiring, connections and sensor assembling | Should camshaft signal be not good, flywheel sensor timing signal is adopted |
| 6.4 | Off | The engine has over-revved, probably driven, or: crankshaft sensor signal (in this case, signalling error 6.1) | If the over-revving occurred when driven, no reaction perceptible by the driver (other than the indicator light blinking) | Data saved, verify the duration and frequency of the over-revving Delete the fault memory | Sensitize the driver about the correct use of the vehicle |

| BLINK CODE | EDC WARNING LIGHT | POSSIBLE CAUSE | POSSIBLE FAILURES | RECOMMENDED TESTS OR OPERATIONS | REMARKS |
|------------|-------------------|--|--|--|--|
| 8.1 | Blinking | Excessive current to regulator - injectors with blow-by at end of lifetime, leaks from pressure relief valve, regulator locked open, 3rd pumping element cut-out always powered, high pressure pump breakage, rail breakage or pipe breakage between injection pump and rail | Engine off if actual pressure is lower than a certain value with respect to target pressure. Power reduction Noise increase since pre-injection is not performed | Visually inspect absence of fuel leaks from high pressure pipes and rail. Check pressure relief valve tightness. Check wiring and regulator coil resistance. If also 8.4 is displayed or injector and pressure relief valve malfunctioning can be excluded. Check 3rd pumping element cut-out wiring and connections and replace high pressure pump if required. | If ECU detects a pressure value significantly lower than the calculated value, engine is switched off NOTE: injectors must not show blow-by with < 200.000 km covered WARNING! If failure memory is deleted, engine will not start but failure is no longer indicated For this reason, before deleting the fault memory it is advisable to print out its content. |
| 8.1 | Blinking | Pressure regulator locked closed | 8.3 - 8.4 Power reduction Noise increase since pre-injection is not performed | If 8.3 blink code is not displayed, replace rail pressure sensor; otherwise check regulator resistance. Replace pump and regulator if required. If also 8.3 + 8.4 are displayed, contact Help Desk and comply with its instructions to replace the ECU, if required | |
| 8.2 | Blinking | Rail pressure sensor short to positive or to ground or circuit open | Power reduction Noise increase since pre-injection is not performed | Read parameters on Modus IWT-IT2000. Check wiring, and replace sensor | |
| 8.3 | Blinking | Pressure regulator short to ground or to positive or circuit open | 8.1 and 8.4 could be present Engine switching off or not starting | Check wiring, connections and regulator. Replace high pressure pump if 8.1 - 8.3 are displayed. Replace ECU if 8.3 - 8.4 are displayed, if required. | Restarting impossible |

| BLINK CODE | EDC WARNING LIGHT | POSSIBLE CAUSE | POSSIBLE FAILURES | RECOMMENDED TESTS OR OPERATIONS | REMARKS |
|------------|-------------------|--|--|--|---|
| 8.4 | Off | 3 rd pumping element cut-out solenoid valve control short to ground or circuit open | 8.1 Error in ECU memory | Active diagnostic with Engine test to check pump operation Check wiring, connections and component | 3 rd pumping element not cut-out when expected, pump can therefore be poor lubricated when motoring over (long downhill with warm engine and exhaust brake on over peak rpm). CAUTION NEVER RUN DOWNHILL WITH ENGINE OFF AND GEAR ENGAGED. |
| 8.5 | On | EGR monitoring: incorrect implementation of the EGR percentage calculated by the control unit | EGR is turned off Emissions not in conformity with legislation Smoke at high speed - reduced performance | Check that the EGR pneumatic valve is not jammed shut or open (or intentionally tampered with) Check that the pipe between the solenoid valve and the EGR pneumatic valve is not crushed, punctured or detached Check wiring - connectors and solenoid valve | In case of any defect with the wiring of pin 8A, the errors related to all the devices connected to this pin will be stored in memory |
| 8.6 | On | EGR solenoid valve short-circuited or with open circuit | EGR fails to work or works constantly Emissions not in conformity with legislation Smoke at high speed - reduced performance | Check the EGR solenoid valve works properly (diagnosis active with the diagnostic tool) Using a multimeter, check the integrity of the solenoid valve | In case of any defect with the wiring of the EDC connector pin 8A, the errors related to all the devices connected to this pin will be stored in memory |

| BLINK CODE | EDC WARNING LIGHT | POSSIBLE CAUSE | POSSIBLE FAILURES | RECOMMENDED TESTS OR OPERATIONS | REMARKS |
|------------|-------------------|--|---|---|---------|
| 8.7 | Blinking | Debimeter or air flow-rate meter (EGR version only) shorted to +Batt., shorted to earth or with open circuit, on the supply or measuring circuit Airflow signal not plausible | EGR not working Power reduction Increase in noise since pre-injection is not effected | Measurable parameters Check wiring and replace flow-meter, if required Check air circuit (loss due to too low air mass, waste-gate valve operation for too high air mass found max. power and high speed), replace flow-meter | |
| 8.8 | Off | Intake air pressure sensor for EGR shorted or with open circuit | No reaction perceivable by the driver | Check the sensor and associated wiring work properly | |

| BLINK CODE | EDC WARNING LIGHT | POSSIBLE CAUSE | POSSIBLE FAILURES | RECOMMENDED TESTS OR OPERATIONS | REMARKS |
|------------|-------------------|--|--|---|--|
| 9.1 | Blinking | ECU internal failure First switching off after replacing with new ECU not performed through key (+15), but by disconnecting the battery positive with engine on | Engine switching off or not starting. In certain cases it could not switch off and going to power reduction level | If failure persists, contact Help Desk and comply with its instructions to replace the ECU, if required | In this case ECU cannot perform switching off diagnostic and it is impossible to restart. If ECU was already being initialised, an improper engine switching off procedure (or current cut-off from alternator with engine running) results in storing of many system failures, under ambient conditions of low battery voltage and engine speed below idling. No failure could be stored, it depends on ECU damages |
| 9.1 | Blinking | ECU internal failure | Engine could switch off without being possible to restart it Power reduction (and noise increase since pre-injection is not performed) | If failure persists, contact Help Desk and comply with its instructions to replace the ECU, if required | This can take place when ECU power is cut out not by the key No failure could be stored, it depends on ECU damages |
| 9.2 | On | Control unit EEPROM fault | The data are not saved on switching off the engine. The fault memory is lost, it is possible to read solely the current faults and not the intermittent ones The curb idle speed that may have been set with the Cruise Control is not saved | Delete fault memory If the error remains, call the Help Desk and follow their instructions to replace the control unit, if necessary | |
| 9.3 | Blinking | Communication problems with Immobilizer in short or circuit open to CAN line | Engine switching off or not starting. | Check wiring, connections and component Perform Immobilizer diagnostic | |

| BLINK CODE | EDC WARNING LIGHT | POSSIBLE CAUSE | POSSIBLE FAILURES | RECOMMENDED TESTS OR OPERATIONS | REMARKS |
|-------------------|--------------------------|--|--|---|--|
| 9.4 | On | Main contactor fails to disconnect | 3.5 battery discharges | Status parameters Check wiring, connections and component | The control unit stays supplied and the EDC indicator light on even with the key off |
| 9.5 | Off | After Run interrupted several times | Fault memory and other operational data are not correctly stored in EE-PROM | Check the control unit supply wiring to find any intermittent false contacts If the wiring is in order, change the main contact | Investigate any incorrect use of the vehicle |
| 9.6 | Blinking | Failure of the internal test procedure that takes place in the control unit each time the engine stops | The engine fails to stop in the preset time when the +15 key is turned OFF | Delete the fault memory: if the error remains, in normal conditions of switching off the engine, call the Help Desk to replace the control unit, if necessary | |
| 9.7 | Blinking | ECU internal failure in sensor power circuit | 1.4 - 2.4 - 8.2 and 8.7 can be displayed at the same time Power reduction (and noise increase since pre-injection is not performed) | If failure persists, contact Help Desk and comply with its instructions to replace the ECU, if required | |

| BLINK CODE | EDC WARNING LIGHT | POSSIBLE CAUSE | POSSIBLE FAILURES | RECOMMENDED TESTS OR OPERATIONS | REMARKS |
|-------------------|--------------------------|---|--|---|---|
| 9.8 | Blinking | ECU software internal failure due to the attempt of tampering with ECU data-set | Engine switching off or not starting. | If failure persists, contact Help Desk and comply with its instructions to replace the ECU, if required | In certain cases engine could not be restarted now and then |
| 9.9 | Blinking | ECU software internal failure or attempt to tamper with ECU data-set | Possible short injection cut-off, indication of other failures with ambient parameters not consistent Impossible to restart engine Light defect at gear shifting | If failure persists, contact Help Desk and comply with its instructions to replace the ECU, if required | |

Ist Section
DTC-FMI error codes
with EDC central unit
software version P 315 S48

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|---|----------------------------|--|--|---|------------------------|----------------------|-----------------------|---------|
| 01 | 01 | VEHICLE - AIR-CONDITIO NER COMPRESSOR RELAY (DTC I) | EXCEEDED UPPER LIMIT | A/C compressor always on. | Short-circuit to positive. | Check wiring and connections. Replace relay if required. | | | | |
| 01 | 02 | VEHICLE - AIR-CONDITIO NER COMPRESSOR RELAY (DTC I) | BELOW LOWER LIMIT | Check correct operation of warning light using "Active diagnostic" procedure. | Short-circuit to ground. | Check wiring and connections. Replace relay if required. | | | | |
| 01 | 04 | VEHICLE - AIR-CONDITIO NER COMPRESSOR RELAY (DTC I) | NO SIGNAL | A/C compressor not working. | Open circuit, relay disconnected. | Check wiring and connections. Replace relay if required. | | | | |
| 01 | 08 | VEHICLE - AIR-CONDITIO NER COMPRESSOR RELAY | SIGNAL NOT PLAUSIBLE | A/C compressor not working. | Open circuit, relay disconnected. | Check wiring and connections. Replace relay if required. | | | | |
| 02 | 04 | VEHICLE - AIR-CONDITIO NER COMPRESSOR RELAY | NO SIGNAL | A/C compressor not working. | No CAN line signal. | Check wiring and connections. Replace relay if required. | | | | |
| 02 | 08 | VEHICLE - AIR-CONDITIO NER COMPRESSOR RELAY | SIGNAL NOT PLAUSIBLE | A/C compressor not working. | Non plausible CAN line signal. | Check wiring and connections. Replace relay if required. | | | | |
| 03 | 01 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | EXCEEDED UPPER LIMIT | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|--|---|---|------------------------|----------------------|-----------------------|---|
| 03 | 02 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | BELOW LOWER LIMIT | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 03 | 04 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | NO SIGNAL | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 03 | 08 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | SIGNAL NOT PLAUSIBLE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 05 | 01 | EGR INCORRECT DEBIMETER SIGNAL | EXCEEDED UPPER LIMIT | Possible poor performance in acceleration. | Flow meter short-circuit or open circuit. | Check integrity of flow meter and wiring between flow meter connector and EDC connector. | | | | Power reduction and deactivated EGR function. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|-----------------------------------|------------------------|---|---|---|------------------------|----------------------|-----------------------|--|
| 05 | 02 | EGR INCORRECT DEBIMETER SIGNAL | - BELOW LOWER LIMIT | Possible poor performance in acceleration. | Flow meter short-circuit or open circuit. | Check integrity of flow meter and wiring between flow meter connector and EDC connector. | | | | Power reduction and deactivated EGR function. |
| 07 | 01 | EGR DEBIMETER SIGNAL OUT OF LIMIT | - EXCEEDED UPPER LIMIT | Possible poor performance in acceleration. | Flow meter short-circuit or open circuit. | Check integrity of flow meter and wiring between flow meter connector and EDC connector. | | | | Power reduction and deactivated EGR function. |
| 07 | 02 | EGR DEBIMETER SIGNAL OUT OF LIMIT | - BELOW LOWER LIMIT | Possible poor performance in acceleration. | Flow meter short-circuit or open circuit. | Check integrity of flow meter and wiring between flow meter connector and EDC connector. | | | | Power reduction and deactivated EGR function. |
| 08 | 01 | VEHICLE ACCELERATOR PEDAL I | - EXCEEDED UPPER LIMIT | Incorrect accelerator pedal operation, engine idling at 1500 rpm. | Short-circuit to positive, voltage exceeding 4700 mV. | In "Measurable parameters" environment, check that the "accelerator pedal position" parameter changes proportionally to the position of the pedal from 0% to 100%. Check wiring and connections. Replace accelerator pedal if required. | | | | Make sure that accelerator pedal travel is not hindered. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|-------------------------------|----------------------|---|---|---|------------------------|----------------------|-----------------------|--|
| 08 | 02 | VEHICLE ACCELERATOR PEDAL 1 - | BELOW LOWER LIMIT | Incorrect accelerator pedal operation, engine idling at 1500 rpm. | Short-circuit to ground. | In "Measurable parameters" environment, check that the "accelerator pedal position" parameter changes proportionally to the position of the pedal from 0% to 100%. Check wiring and connections. Replace accelerator pedal if required. | | | | Make sure that accelerator pedal travel is not hindered. |
| 08 | 08 | VEHICLE ACCELERATOR PEDAL 1 - | SIGNAL NOT PLAUSIBLE | Incorrect accelerator pedal operation, engine idling at 1500 rpm. | Accelerator pedal potentiometer 1 and accelerator pedal potentiometer 2 values not plausible. | In "Measurable parameters" environment, check that the "accelerator pedal position" parameter changes proportionally to the position of the pedal from 0% to 100%. Check wiring and connections. Replace accelerator pedal if required. | | | | Make sure that accelerator pedal travel is not hindered. |
| 09 | 01 | VEHICLE ACCELERATOR PEDAL 2 - | EXCEEDED UPPER LIMIT | Incorrect accelerator pedal operation, engine idling at 1500 rpm. | Short-circuit to positive, voltage exceeding 4700 mV. | In "Measurable parameters" environment, check that the "accelerator pedal position" parameter changes proportionally to the position of the pedal from 0% to 100%. Check wiring and connections. Replace accelerator pedal if required. | | | | Make sure that accelerator pedal travel is not hindered. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|---|---|---|------------------------|----------------------|-----------------------|--|
| 09 | 02 | VEHICLE ACCELERATOR PEDAL 2 - | BELOW LOWER LIMIT | Incorrect accelerator pedal operation, engine idling at 1500 rpm. | Short-circuit to ground. | In "Measurable parameters" environment, check that the "accelerator pedal position" parameter changes proportionally to the position of the pedal from 0% to 100%. Check wiring and connections. Replace accelerator pedal if required. | | | | Make sure that accelerator pedal travel is not hindered. |
| 09 | 08 | VEHICLE ACCELERATOR PEDAL 2 - | SIGNAL NOT PLAUSIBLE | Incorrect accelerator pedal operation, engine idling at 1500 rpm. | Accelerator pedal potentiometer 1 and accelerator pedal potentiometer 2 values not plausible. | In "Measurable parameters" environment, check that the "accelerator pedal position" parameter changes proportionally to the position of the pedal from 0% to 100%. Check wiring and connections. Replace accelerator pedal if required. | | | | Make sure that accelerator pedal travel is not hindered. |
| 0A | 01 | ENGINE 1 - ATMOSPHERIC PRESSURE SENSOR | EXCEEDED UPPER LIMIT | Possible smokiness at high altitude. Problematic cranking at high altitude. | Faulty environmental pressure sensor in ECU. | Replace ECU. | | | | |
| 0A | 02 | ENGINE 1 - ATMOSPHERIC PRESSURE SENSOR | BELOW LOWER LIMIT | Possible smokiness at high altitude. Problematic cranking at high altitude. | Faulty environmental pressure sensor in ECU. | Replace ECU. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|--|---|--|------------------------|----------------------|-----------------------|--|
| 0B | 08 | VEHICLE ACCELERATOR PEDAL/BRAKE PEDALSUSPECT | SIGNAL NOT PLAUSIBLE | Power reduction: engine rpm drop to idling speed. | Press brake and accelerator at the same time. | Check wiring and connections. Replace sensor if required. | | | | If the brake is actuated while the accelerator is pressed, the motor runs on slow idling until the brake is released, so that the vehicle can be stopped even if the pedal of the accelerator remains stuck on the intermediate position. Instead you can accelerate while the pedal is pressed without the interference of safety measures. |
| 0C | 01 | EGR - AIR MASS SUPPLY TOO LOW | EXCEEDED UPPER LIMIT | EGR off. Emissions not compliant with law. Derated performance and smoke at high engine rpm. | EGR monitoring: incorrect EGR percentage actuation calculated by ECU. | Check, if the EGR pneumatic valve is not locked in Open or Closed-Position 2) Check, that the solenoid valve and the EGR pneumatic valve is not squashed or holed or detached 3) Check the EGR solenoid valve-functionality 4) Check the solenoid valve-integrity by means of a multimeter 5) Check the wiring harness between the solenoid valve and the EDC connector. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--------------------------------|----------------------|--|---|--|------------------------|----------------------|-----------------------|---|
| 0D | 02 | EGR - AIR MASS SUPPLY TOO HIGH | BELOW LOWER LIMIT | EGR off. Emissions not compliant with law. Derated performance and smoke at high engine rpm. | EGR monitoring: incorrect EGR percentage actuation calculated by ECU. | Check, if the EGR pneumatic valve is not locked in Open or Closed-Position 2) Check, that the solenoid valve and the EGR pneumatic valve is not squashed or holed or detached 3) Check the EGR solenoid valve-functionality 4) Check the solenoid valve-integrity by means of a multimeter 5) Check the wiring harness between the solenoid valve and the EDC connector. | | | | |
| 11 | 01 | ENGINE BOOST PRESSURE SENSOR | EXCEEDED UPPER LIMIT | Positive power reduction and smoke in exhaust. | | Check wiring and connections. Possibly replace sensor. Check in "measurable parameter" environment that atmospheric pressure sensor and turbo charger air pressure sensor values are similar when engine is off. | | | | Possible smoke in exhaust during acceleration. Replace if required. |
| 11 | 02 | ENGINE BOOST PRESSURE SENSOR | BELOW LOWER LIMIT | Positive power reduction and smoke in exhaust. | | Check wiring and connections. Replace sensor if required. | | | | Possible smoke in exhaust during acceleration. Replace if required. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------------------------------|----------------------|--|--|---|------------------------|----------------------|-----------------------|---|
| 11 | 08 | ENGINE 1 - BOOST PRESSURE SENSOR | SIGNAL NOT PLAUSIBLE | Positive power reduction and smoke in exhaust. | Faulty sensor. | Check wiring and connections. Replace sensor if required. | | | | |
| 12 | 01 | ENGINE 2 - BATTERY VOLTAGE | EXCEEDED UPPER LIMIT | Problematic cranking. | Flat battery, interrupted wiring. | Check battery state with diagnostic tool (measurable parameters). Check wiring and connections. | | | | Replace alternator, regulator or battery. |
| 12 | 02 | ENGINE 2 - BATTERY VOLTAGE | BELOW LOWER LIMIT | Engine does not start. Possible power reduction. | Faulty battery, faulty alternator, faulty ECU. | Check with diagnostic tool. | | | | Replace battery, alternator or ECU if required. |
| 13 | 08 | VEHICLE - BRAKE PEDAL SIGNAL ERROR | SIGNAL NOT PLAUSIBLE | Brake signal plausibility, possibly no brake lights, Cruise Control / PTO not working. | The two switch states are different. | Check wiring and connections. Replace sensor if required. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|---------------------------------------|----------------------|--|------------------------------------|--|--|--|--|---------|
| 14 | 01 | ENGINE 1 - COOLANT TEMPERATURE SENSOR | EXCEEDED UPPER LIMIT | Problematic cold cranking. Possible power reduction. | Faulty sensor, interrupted wiring. | Check wiring and connections. Replace sensor if required. | 1- Measure type: Resistance (KOhm) Measure point 1: Sensor Pin: 1 Measure point 2: Sensor Pin: 2 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A58 Measure point 2: Sensor Pin: 1 3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A41 Measure point 2: Sensor Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Min. value: 0,11 KOhm; Max. value: 48,3 KOhm; Typical Value: 2,5 KOhm; 2- Typical Value: 0,1 Ohm; 3- Typical Value: 0,1 Ohm; | |
| 14 | 02 | ENGINE 1 - COOLANT TEMPERATURE SENSOR | BELOW LOWER LIMIT | Problematic cold cranking. Possible power reduction. | Faulty sensor, interrupted wiring. | Check wiring and connections. Replace sensor if required. | 1- Measure type: Resistance (KOhm) Measure point 1: Sensor Pin: 1 Measure point 2: Sensor Pin: 2 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A58 Measure point 2: Sensor Pin: 1 3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A41 Measure point 2: Sensor Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Min. value: 0,11 KOhm; Max. value: 48,3 KOhm; Typical Value: 2,5 KOhm; 2- Typical Value: 0,1 Ohm; 3- Typical Value: 0,1 Ohm; | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|--|------------------------------------|--|--|--|---|---------|
| 14 | 08 | ENGINE 1 - COOLANT TEMPERATURE SENSOR | SIGNAL NOT PLAUSIBLE | Problematic cold cranking. Possible power reduction. | Faulty sensor, interrupted wiring. | Check wiring and connections. Replace sensor if required. | 1- Measure type: Resistance (KOhm) Measure point 1: Sensor Pin: 1 Measure point 2: Sensor Pin: 2 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A58 Measure point 2: Sensor Pin: 1 3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A41 Measure point 2: Sensor Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Min. value: 0,11 KOhm; Max. value: 48,3 KOhm; Typical Value: 2,5 KOhm; 2- Typical Value: 0,1 Ohm; 3- Typical Value: 0,1 Ohm; | |
| 15 | 01 | ENGINE 1 - COOLANT TEMPERATURE SENSOR (TEST) | EXCEEDED UPPER LIMIT | | Faulty coolant temperature sensor. | Replace sensor. | 1- Measure type: Resistance (KOhm) Measure point 1: Sensor Pin: 1 Measure point 2: Sensor Pin: 2 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A58 Measure point 2: Sensor Pin: 1 3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A41 Measure point 2: Sensor Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Min. value: 0,11 KOhm; Max. value: 48,3 KOhm; Typical Value: 2,5 KOhm; 2- Typical Value: 0,1 Ohm; 3- Typical Value: 0,1 Ohm; | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|---|---|--|------------------------|----------------------|-----------------------|--|
| 1E | 08 | VEHICLE CLUTCH SIGNAL SUSPECT | SIGNAL NOT PLAUSIBLE | Clutch switch: signal either not plausible or not present. Cruise Control / PTO not working or engine revs up to maximum speed when clutch pedal is pressed and Cruise control / PTO is on. | Gear shift detected without pressing brake pedal. | Check wiring and connections. Replace sensor if required. | | | | The anomaly caused by incomplete clutch operation if everything is OK. |
| 20 | 01 | EGR - EGR POWER SHORT TO BATT. | EXCEEDED UPPER LIMIT | | EGR solenoid valve short-circuit to battery. | 1) Check integrity of solenoid valve with multimeter. 2) Check wiring between solenoid valve and EDC connector. | | | | EGR either not working or always working. Emissions not compliant with law. No reaction perceivable by driver. |
| 21 | 02 | EGR - SHORT CIRCUIT TO GROUND ON EGR VALVE | BELOW LOWER LIMIT | | Solenoid valve short-circuit to ground. | 1) Check integrity of solenoid valve with multimeter. 2) Check wiring between solenoid valve and EDC connector. | | | | EGR either not working or always working. Emissions not compliant with law. No reaction perceivable by driver. |
| 22 | 04 | EGR - OPEN CIRCUIT ON EGR VALVE | NO SIGNAL | | EGR solenoid valve short-circuit or open circuit. | 1) Check integrity of solenoid valve with multimeter. 2) Check wiring between solenoid valve and EDC connector. | | | | EGR either not working or always working. Emissions not compliant with law. No reaction perceivable by driver. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|----------------------------------|----------------------|--|---|--|------------------------|----------------------|-----------------------|--|
| 22 | 08 | EGR - OPEN CIRCUIT ON EGR VALVE | SIGNAL NOT PLAUSIBLE | | EGR solenoid valve short-circuit or open circuit. | 1) Check integrity of solenoid valve with multimeter. 2) Check wiring between solenoid valve and EDC connector. | | | | EGR either not working or always working. Emissions not compliant with law. No reaction perceivable by driver. |
| 24 | 01 | ENGINE SPEED - CAMSHAFT SENSOR | EXCEEDED UPPER LIMIT | Possible problematic cold cranking. | No signal, open circuit. | Check wiring and connections. | | | | Flywheel sensor timing signal adopted if camshaft signal is not correct. |
| 24 | 02 | ENGINE SPEED - CAMSHAFT SENSOR | BELOW LOWER LIMIT | Possible problematic cold cranking. | No signal, open circuit, faulty sensor. | Check correct assembly of sensor and phonic wheel, check engine timing. | | | | Flywheel sensor timing signal adopted if camshaft signal is not correct. |
| 25 | 01 | ENGINE SPEED - CRANKSHAFT SENSOR | EXCEEDED UPPER LIMIT | Problematic cold cranking, power reduction (possible noise due to missed pre-injection). | Faulty sensor. | Check wiring and connections. | | | | Camshaft sensor speed adopted if signal is not present. |
| 25 | 02 | ENGINE SPEED - CRANKSHAFT SENSOR | BELOW LOWER LIMIT | Problematic cold cranking, power reduction (possible noise due to missed pre-injection). | Faulty sensor. | Check wiring and connections. | | | | Camshaft sensor speed adopted if signal is not present. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|---|----------------------|---------------------------|---|--|---|--|--|-----------------------|
| 26 | 01 | ENGINE SPEED - FAULT BETWEEN FLYWHEEL SENSOR AND CAMSHAFT | EXCEEDED UPPER LIMIT | Possible power reduction. | Incorrect camshaft phonic wheel assembly. | Check wiring, connections and sensor, check that phonic wheel is fitted correctly. | | | | Longer cranking time. |
| 28 | 01 | ENGINE I - FUEL TEMPERATURE SENSOR | EXCEEDED UPPER LIMIT | Possible power reduction. | Short-circuit to positive, excessively low temperature is detected. | Check wiring and connections. Replace sensor if required. | 1- Measure type: Resistance (Ohm) Measure point 1: Sensor Pin: 1 Measure point 2: Sensor Pin: 2 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A52 Measure point 2: Sensor Pin: 1 3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A51 Measure point 2: Sensor Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Typical Value: 1 Ohm; 2- Typical Value: 0,1 Ohm; 3- Typical Value: 0,1 Ohm; | |
| 28 | 02 | ENGINE I - FUEL TEMPERATURE SENSOR | BELOW LOWER LIMIT | Possible power reduction. | Short-circuit to ground, excessively high temperature is detected. | Check wiring and connections. Replace sensor if required. | 1- Measure type: Resistance (Ohm) Measure point 1: Sensor Pin: 1 Measure point 2: Sensor Pin: 2 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A52 Measure point 2: Sensor Pin: 1 3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A51 Measure point 2: Sensor Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Typical Value: 1 Ohm; 2- Typical Value: 0,1 Ohm; 3- Typical Value: 0,1 Ohm; | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|---|---|---|------------------------|----------------------|-----------------------|--|
| 29 | 01 | ENGINE I - FAN RELAY | EXCEEDED UPPER LIMIT | Fan relay not working. | Fan relay short-circuit to positive. | Check wiring and connections. Replace relay if required. | | | | Possible increased fuel consumption. Possible engine overheating and power reduction. |
| 29 | 02 | ENGINE I - FAN RELAY | BELOW LOWER LIMIT | Fan relay not working. | Fan relay short-circuit to ground. | Check wiring and connections. Replace relay if required. | | | | Possible increased fuel consumption. Possible engine overheating and power reduction. |
| 29 | 04 | ENGINE I - FAN RELAY | NO SIGNAL | Fan relay not working. | | Check wiring and connections. Replace relay if required. | | | | Possible increased fuel consumption. Possible engine overheating and power reduction. |
| 29 | 08 | ENGINE I - FAN RELAY | SIGNAL NOT PLAUSIBLE | Fan relay not working. | | Check wiring and connections. Replace relay if required. | | | | Possible increased fuel consumption. Possible engine overheating and power reduction. |
| 2A | 01 | ENGINE I - PRE-HEATING RELAY FUEL FILTER | EXCEEDED UPPER LIMIT | Fuel filter pre-heater relay not working. | Filter heater relay short-circuit to positive - Heater always on also at fuel temperature > 5° C. | Check wiring and connections. Replace relay if required. | | | | Battery goes flat. |
| 2A | 02 | ENGINE I - PRE-HEATING RELAY FUEL FILTER | BELOW LOWER LIMIT | Fuel filter pre-heater relay not working. | Filter heater relay short-circuit to ground. | Check wiring and connections. Replace relay if required. | | | | Battery goes flat. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|---|----------------------------|---|---|---|------------------------|----------------------|-----------------------|---|
| 2A | 04 | ENGINE 1 - PRE-HEATING RELAY FUEL FILTER | NO SIGNAL | Fuel filter pre-heater relay not working. | | Check wiring and connections. Replace relay if required. | | | | Battery goes flat. |
| 2A | 08 | ENGINE 1 - PRE-HEATING RELAY FUEL FILTER | SIGNAL NOT PLAUSIBLE | Fuel filter pre-heater relay not working. | | Check wiring and connections. Replace relay if required. | | | | Battery goes flat. |
| 2F | 01 | ENGINE 2 - GLOW PLUG RELAY | EXCEEDED UPPER LIMIT | Possible problematic cold cranking. | Short-circuit to positive, glow plugs always on also with ECU off, possible battery deployment. | Check wiring and connections. Replace relay if required. | | | | |
| 2F | 02 | ENGINE 2 - GLOW PLUG RELAY | BELOW LOWER LIMIT | | Short-circuit to ground, glow plugs always on. | Check wiring and connections. Replace relay if required. | | | | |
| 2F | 04 | ENGINE 2 - GLOW PLUG RELAY | NO SIGNAL | Possible problematic cold cranking. | Faulty wiring. | Check wiring and connections. Replace relay if required. | | | | Faulty diagnostic light. |
| 2F | 08 | ENGINE 2 - GLOW PLUG RELAY | SIGNAL NOT PLAUSIBLE | Possible problematic cold cranking. | Faulty relay, wiring interrupted. | Check wiring and connections. Replace relay if required. | | | | Possible increased fuel consumption. Possible engine overheating and power reduction. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|----------------------------|----------------------|--|----------------------------|--|------------------------|----------------------|-----------------------|--|
| 30 | 01 | ENGINE 2 - COLD START LAMP | EXCEEDED UPPER LIMIT | Warning light always off. Problematic cold cranking. Pre-heater warning light always on. | Short-circuit to positive. | Check wiring and connections. Replace sensor if required. | | | | The driver does not wait preheating even when the room temperatures are low, because no warning light signal is enabled. Preheating works, but with cold start-up no indication is available that tells you when to start the motor because the light is always turned on. |
| 30 | 02 | ENGINE 2 - COLD START LAMP | BELOW LOWER LIMIT | Warning light always off. Problematic cold cranking. Pre-heater warning light always on. | Short-circuit to ground. | Check wiring and connections. Replace sensor if required. | | | | The driver does not wait preheating even when the room temperatures are low, because no warning light signal is enabled. Preheating works, but with cold start-up no indication is available that tells you when to start the motor because the light is always turned on. |
| 30 | 04 | ENGINE 2 - COLD START LAMP | NO SIGNAL | Warning light always off. Problematic cold cranking. Pre-heater warning light always on. | | Check wiring and connections. Replace sensor if required. | | | | Warning light off during pre-heating. Replace bulb if required. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|---|----------------------------|---|------------------------|----------------------|-----------------------|--|
| 30 | 08 | ENGINE 2 - COLD START LAMP | SIGNAL NOT PLAUSIBLE | Warning light always off. Problematic cold cranking. Pre-heater warning light always on. | | Check wiring and connections. Replace sensor if required. | | | | Warning light off during pre-heating. Replace bulb if required. |
| 31 | 01 | ENGINE 2 - CONTROL SYSTEM PRE-POSTHEATING | EXCEEDED UPPER LIMIT | Possible problematic cold cranking. | Short-circuit to positive. | Check wiring and connections. Check electrical system between relay and glow plugs. | | | | Relay unit always on also with ECU off, possible battery deployment. |
| 32 | 01 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | EXCEEDED UPPER LIMIT | | Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 33 | 01 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | EXCEEDED UPPER LIMIT | The engine switching off-data are not memorized. The failures memory is lost, only the present failures and not the intermittent ones can be read, the idling speed, which can be eventually set by the Cruise Control commands, remains not memorized. | Faulty ECU EEPROM. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|-------------------|---|--------------------|---|------------------------|----------------------|-----------------------|---------|
| 33 | 02 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | BELOW LOWER LIMIT | The engine switching off-data are not memorized. The failures memory is lost, only the present failures and not the intermittent ones can be read, the idling speed, which can be eventually set by the Cruise Control commands, remains not memorized. | Faulty ECU EEPROM. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 33 | 04 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | NO SIGNAL | The engine switching off-data are not memorized. The failures memory is lost, only the present failures and not the intermittent ones can be read, the idling speed, which can be eventually set by the Cruise Control commands, remains not memorized. | Faulty ECU EEPROM. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|---|---|---|------------------------|----------------------|-----------------------|---------|
| 33 | 08 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | SIGNAL NOT PLAUSIBLE | The engine switching off-data are not memorized. The failures memory is lost, only the present failures and not the intermittent ones can be read, the idling speed, which can be eventually set by the Cruise Control commands, remains not memorized. | Faulty ECU EEPROM. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 34 | 08 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | SIGNAL NOT PLAUSIBLE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 35 | 08 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | SIGNAL NOT PLAUSIBLE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|--|---|---|---|---------------------------------------|--------------------------|--|
| 36 | 08 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | SIGNAL NOT PLAUSIBLE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 37 | 01 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | EXCEEDED UPPER LIMIT | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 38 | 02 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | BELOW LOWER LIMIT | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 39 | 01 | ENGINE 1 - AIR TEMPERATURE SENSOR | EXCEEDED UPPER LIMIT | Problematic cranking, smoke, problematic acceleration. | | Check wiring and connections. Replace sensor if required. | Measure type: Resistance (KOhm) Measure point 1: Sensor Pin: 1 Measure point 2: Sensor Pin: 2 | Connector Not connected; Key +15 OFF; | Typical Value: 2,5 KOhm; | Air temperature sensor and built-in pressure sensor. The sensor is fitted on flow meter in engines with EGR. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|---------------------------------------|----------------------|--|--|---|--|---------------------------------------|----------------------------|--|
| 39 | 02 | ENGINE 1 - AIR TEMPERATURE SENSOR | BELOW LOWER LIMIT | Problematic cranking, smoke, problematic acceleration. | Short-circuit to ground, excessively high temperature is detected. | Check wiring and connections. Replace sensor if required. | Measure type: Resistance (KOhm) Measure point 1: Sensor Pin: 1 Measure point 2: Sensor Pin: 2 | Connector Not connected; Key +15 OFF; | Typical Value: 2,5 KOhm; | Air temperature sensor and built-in pressure sensor. The sensor is fitted on flow meter in engines with EGR. |
| 3A | 02 | ELECTRONIC CONTROL UNIT - IMMOBILISER | BELOW LOWER LIMIT | The engine fails to start | Communication with Immobilizer ECU problems on CAN Line. | Check integrity of CAN Line, run Immobilizer ECU diagnostics and wait for indications provided. | Measure type: Resistance (Ohm) Measure point 1: Diagnostic socket. Pin: 21 Measure point 2: Diagnostic socket. Pin: 22 | Connector Connected; Key +15 OFF; | Typical Value: 60 Ohm Ohm; | |
| 3C | 01 | INJECTOR BENCH 1 - | EXCEEDED UPPER LIMIT | Engine not working properly, possible power reduction. | Injector wiring short-circuit. | Check wiring and connections. Replace injector if required. | | | | Only two cylinders running. |
| 3C | 02 | INJECTOR BENCH 1 - | BELOW LOWER LIMIT | Engine not working properly, possible power reduction. | Short-circuit to ground. | Check wiring and connections. | | | | Only two cylinders running. |
| 3C | 08 | INJECTOR BENCH 1 - | SIGNAL NOT PLAUSIBLE | Engine not working properly, possible power reduction. | Injector electrical system failure. | Check wiring and connections. Replace injector if required. | | | | Only two cylinders running. |
| 3D | 04 | INJECTOR BENCH 1 - | NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring disconnected. | Check wiring and connections. Replace injector if required. | | | | Only two cylinders running. |
| 3E | 01 | INJECTOR BENCH 2 - | EXCEEDED UPPER LIMIT | Engine not working properly, possible power reduction. | Injector wiring short-circuit. | Check wiring and connections. Replace injector if required. | | | | Only two cylinders running. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--------------------------|-----------------|----------------------|--|-------------------------------------|--|----------------------|-----------------------|-----------------------------|
| 3E | 02 | INJECTOR BENCH 2 | - | BELOW LOWER LIMIT | Engine not working properly, possible power reduction. | Short-circuit to ground. | Check wiring and connections. | | | Only two cylinders running. |
| 3E | 08 | INJECTOR BENCH 2 | - | SIGNAL NOT PLAUSIBLE | Engine not working properly, possible power reduction. | Injector electrical system failure. | Check wiring and connections. Replace injector if required. | | | Only two cylinders running. |
| 3F | 04 | INJECTOR BENCH 2 | - | NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring disconnected. | Check wiring and connections. Replace injector if required. | | | Only two cylinders running. |
| 40 | 01 | INJECTOR INJECTOR SUPPLY | - A | EXCEEDED UPPER LIMIT | Engine off. | Internal ECU problem. | Clear failure memory. If the error persists, ensure that the failure does not concern the injectors and call the Help Desk for instructions on how to replace the ECU. | | | |
| 40 | 02 | INJECTOR INJECTOR SUPPLY | - A | BELOW LOWER LIMIT | Engine off. | Internal ECU problem. | Clear failure memory. If the error persists, ensure that the failure does not concern the injectors and call the Help Desk for instructions on how to replace the ECU. | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--------------------------------|--------------------------------------|-----------------|--------------------------|--|------------------------|----------------------|-----------------------|---------|
| 40 | 04 | INJECTOR INJECTOR SUPPLY | - A NO SIGNAL | Engine off. | Internal ECU problem. | Clear failure memory. If the error persists, ensure that the failure does not concern the injectors and call the Help Desk for instructions on how to replace the ECU. | | | | |
| 40 | 08 | INJECTOR INJECTOR SUPPLY | - A SIGNAL NOT PLAUSIBLE | Engine off. | Internal ECU problem. | Clear failure memory. If the error persists, ensure that the failure does not concern the injectors and call the Help Desk for instructions on how to replace the ECU. | | | | |
| 41 | 01 | INJECTOR INJECTOR SUPPLY | - B EXCEEDED UPPER LIMIT | Engine off. | Internal ECU problem. | Clear failure memory. If the error persists, ensure that the failure does not concern the injectors and call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--------------------------------|--------------------------------------|--|-------------------------------|--|------------------------|----------------------|-----------------------|-------------------------------------|
| 41 | 02 | INJECTOR INJECTOR SUPPLY | - B BELOW LOWER LIMIT | Engine off. | Internal ECU problem. | Clear failure memory. If the error persists, ensure that the failure does not concern the injectors and call the Help Desk for instructions on how to replace the ECU. | | | | |
| 41 | 04 | INJECTOR INJECTOR SUPPLY | - B NO SIGNAL | Engine off. | Internal ECU problem. | Clear failure memory. If the error persists, ensure that the failure does not concern the injectors and call the Help Desk for instructions on how to replace the ECU. | | | | |
| 41 | 08 | INJECTOR INJECTOR SUPPLY | - B SIGNAL NOT PLAUSIBLE | Engine off. | Internal ECU problem. | Clear failure memory. If the error persists, ensure that the failure does not concern the injectors and call the Help Desk for instructions on how to replace the ECU. | | | | |
| 42 | 01 | INJECTOR INJECTOR I | - EXCEEDED UPPER LIMIT | Engine not working properly, possible power reduction. | Short-circuit to positive. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------------------|------------------------------|--|-----------------------------------|--|--|--|--|-----------------------------------|
| 42 | 01 | INJECTOR INJECTOR 1 | - EXCEEDED UPPER LIMIT | | | | 1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A47 Measure point 2: Injector Pin: 2 2- Measure type: Resistance (Ohm) Measure point 1: Injector Pin: 1 Measure point 2: Injector Pin: 2 3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A16 Measure point 2: Injector Pin: 1 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Typical Value: 0.1 Ohm; 2- Min. value: 0.5 Ohm; Max. value: 0.9 Ohm; Typical Value: 0.7 Ohm; 3- Typical Value: 0,1 Ohm; | |
| 42 | 04 | INJECTOR INJECTOR 1 | - NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring short-circuit. | Check wiring and connections. Replace injector if required. | | | | Only two cylinders running. |
| 42 | 04 | INJECTOR INJECTOR 1 | - NO SIGNAL | | | | 1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A47 Measure point 2: Injector Pin: 2 2- Measure type: Resistance (Ohm) Measure point 1: Injector Pin: 1 Measure point 2: Injector Pin: 2 3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A16 Measure point 2: Injector Pin: 1 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Typical Value: 0.1 Ohm; 2- Min. value: 0.5 Ohm; Max. value: 0.9 Ohm; Typical Value: 0.7 Ohm; 3- Typical Value: 0,1 Ohm; | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|---------------------|------------------------|--|--------------------------------|---|--|---|---|-------------------------------|
| 42 | 08 | INJECTOR INJECTOR 1 | - SIGNAL NOT PLAUSIBLE | Engine not working properly, possible power reduction. | Injector not working properly. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |
| 42 | 08 | INJECTOR INJECTOR 1 | - SIGNAL NOT PLAUSIBLE | | | | <p>1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A47 Measure point 2: Injector Pin: 2</p> <p>2- Measure type: Resistance (Ohm) Measure point 1: Injector Pin: 1 Measure point 2: Injector Pin: 2</p> <p>3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A16 Measure point 2: Injector Pin: 1</p> | <p>1- Connector Not connected; Key +15 OFF;</p> <p>2- Connector Not connected; Key +15 OFF;</p> <p>3- Connector Not connected; Key +15 OFF;</p> | <p>1- Typical Value: 0.1 Ohm;</p> <p>2- Min. value: 0.5 Ohm; Max. value: 0.9 Ohm; Typical Value: 0.7 Ohm;</p> <p>3- Typical Value: 0,1 Ohm;</p> | |
| 43 | 04 | INJECTOR INJECTOR 1 | - NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring open circuit. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |
| 44 | 01 | INJECTOR INJECTOR 2 | - EXCEEDED UPPER LIMIT | Engine not working properly, possible power reduction. | Short-circuit to positive. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------------------|------------------------------|--|-----------------------------------|--|--|--|--|-----------------------------------|
| 44 | 01 | INJECTOR INJECTOR 2 | - EXCEEDED UPPER LIMIT | | | | 1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A17 Measure point 2: Injector Pin: 1 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A13 Measure point 2: Injector Pin: 2 3- Measure type: Resistance (Ohm) Measure point 1: Injector Pin: 1 Measure point 2: Injector Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Typical Value: 0,1 Ohm; 2- Typical Value: 0,1 Ohm; 3- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm; | |
| 44 | 04 | INJECTOR INJECTOR 2 | - NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring short-circuit. | Check wiring and connections. Replace injector if required. | | | | Only two cylinders running. |
| 44 | 04 | INJECTOR INJECTOR 2 | - NO SIGNAL | | | | 1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A17 Measure point 2: Injector Pin: 1 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A13 Measure point 2: Injector Pin: 2 3- Measure type: Resistance (Ohm) Measure point 1: Injector Pin: 1 Measure point 2: Injector Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Typical Value: 0,1 Ohm; 2- Typical Value: 0,1 Ohm; 3- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm; | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|---------------------|------------------------|--|--------------------------------|---|---|--|--|-------------------------------|
| 44 | 08 | INJECTOR INJECTOR 2 | - SIGNAL NOT PLAUSIBLE | Engine not working properly, possible power reduction. | Injector not working properly. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |
| 44 | 08 | INJECTOR INJECTOR 2 | - SIGNAL NOT PLAUSIBLE | | | | 1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A17 Measure point 2: Injector Pin: 1 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A13 Measure point 2: Injector Pin: 2 3- Measure type: Resistance (Ohm) Measure point 1: Injector Pin: 1 Measure point 2: Injector Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Typical Value: 0,1 Ohm; 2- Typical Value: 0,1 Ohm; 3- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm; | |
| 45 | 04 | INJECTOR INJECTOR 2 | - NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring open circuit. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |
| 46 | 01 | INJECTOR INJECTOR 3 | - EXCEEDED UPPER LIMIT | Engine not working properly, possible power reduction. | Short-circuit to positive. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |
| 46 | 04 | INJECTOR INJECTOR 3 | - NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring short-circuit. | Check wiring and connections. Replace injector if required. | | | | Only two cylinders running. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|---------------------|------------------------|--|--------------------------------|---|--|--|--|-------------------------------|
| 46 | 08 | INJECTOR INJECTOR 3 | - SIGNAL NOT PLAUSIBLE | Engine not working properly, possible power reduction. | Injector not working properly. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |
| 47 | 04 | INJECTOR INJECTOR 3 | - NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring open circuit. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |
| 47 | 04 | INJECTOR INJECTOR 3 | - NO SIGNAL | | | | 1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A31 Measure point 2: Injector Pin: 2 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A1 Measure point 2: Injector Pin: 1 3- Measure type: Resistance (Ohm) Measure point 1: Injector Pin: 1 Measure point 2: Injector Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Typical Value: 0,1 Ohm; 2- Typical Value: 0,1 Ohm; 3- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm; | |
| 48 | 01 | INJECTOR INJECTOR 4 | - EXCEEDED UPPER LIMIT | Engine not working properly, possible power reduction. | Short-circuit to positive. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |
| 48 | 04 | INJECTOR INJECTOR 4 | - NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring short-circuit. | Check wiring and connections. Replace injector if required. | | | | Only two cylinders running. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------------------------------|------------------------|--|---|--|---|---|---|--|
| 48 | 08 | INJECTOR INJECTOR 4 | - SIGNAL NOT PLAUSIBLE | Engine not working properly, possible power reduction. | Injector not working properly. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |
| 49 | 04 | INJECTOR INJECTOR 4 | - NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring open circuit. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |
| 49 | 04 | INJECTOR INJECTOR 4 | - NO SIGNAL | | | | <p>1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A46 Measure point 2: Injector Pin: 2</p> <p>2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A1 Measure point 2: Injector Pin: 1</p> <p>3- Measure type: Resistance (Ohm) Measure point 1: Injector Pin: 1 Measure point 2: Injector Pin: 2</p> | <p>1- Connector Not connected; Key +15 OFF;</p> <p>2- Connector Not connected; Key +15 OFF;</p> <p>3- Connector Not connected; Key +15 OFF;</p> | <p>1- Typical Value: 0,1 Ohm;</p> <p>2- Typical Value: 0,1 Ohm;</p> <p>3- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm;</p> | |
| 4E | 08 | VEHICLE CRUISE CONTROL SWITCH UNIT | - SIGNAL NOT PLAUSIBLE | Cruise control / PTO not working. | Press SET+ / SET- and RESUME/ OFF at the same time. | Check correct operation of the switch by reading state parameters. | | | | Replace wiring and connections if state does not change when Cruise Control buttons are pressed. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|---|----------------------|--|--|--|------------------------|----------------------|-----------------------|---------|
| 50 | 01 | ELECTRONIC CONTROL UNIT - MAIN RELAY DEFECT | EXCEEDED UPPER LIMIT | Engine does not start, ECU not powered or ECU always powered and EDC off also at key-on. | Main relay interrupted or short-circuit. | Check wiring and connections. Replace relay if required. | | | | |
| 50 | 02 | ELECTRONIC CONTROL UNIT - MAIN RELAY DEFECT | BELOW LOWER LIMIT | Engine does not start, ECU not powered or ECU always powered and EDC off also at key-on. | Main relay interrupted or short-circuit. | Check wiring and connections. Replace relay if required. | | | | |
| 51 | 01 | VEHICLE - MULTIPOSITION SELECTOR / PTO | EXCEEDED UPPER LIMIT | Incorrect PTO operation. | Voltage exceeding max. threshold, short-circuit to positive. | Check wiring and connections. Replace sensor if required. | | | | |
| 51 | 02 | VEHICLE - MULTIPOSITION SELECTOR / PTO | BELOW LOWER LIMIT | Incorrect PTO operation. | Voltage under min. threshold, short-circuit to ground. | Check wiring and connections. Replace sensor if required. | | | | |
| 51 | 08 | VEHICLE - MULTIPOSITION SELECTOR / PTO | SIGNAL NOT PLAUSIBLE | Incorrect PTO operation. | Faulty device. | Check wiring and connections. Replace sensor if required. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|-----------------|---|---|--|---------------------------------------|---|-------------|
| 52 | 04 | FUEL PRESSURE - PRESSURE MPROP REGULATOR ERROR | NO SIGNAL | Engine off. | Faulty MPROP. | Check wiring and connections. | Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A49 Measure point 2: ECU Pin: A19 | Connector Not connected; Key +15 OFF; | Min. value: 3.2 Ohm; Max. value: 3.6 Ohm; Typical Value: 3.4 Ohm; | High noise. |
| 52 | 08 | FUEL PRESSURE - PRESSURE MPROP REGULATOR ERROR | SIGNAL NOT PLAUSIBLE | | | Check wiring and connections. Replace ECU if required. | Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A49 Measure point 2: ECU Pin: A19 | Connector Not connected; Key +15 OFF; | Min. value: 3.2 Ohm; Max. value: 3.6 Ohm; Typical Value: 3.4 Ohm; | |
| 53 | 01 | FUEL PRESSURE - PRESSURE MPROP REGULATOR ERROR (SHORT CIRCUIT TO POSITIVE) | EXCEEDED UPPER LIMIT | | Short-circuit to battery, faulty MPROP. | Check wiring and connections. Replace MPROP if required. | | | | |
| 54 | 01 | FUEL PRESSURE - PRESSURE MPROP REGULATOR ERROR (SHORT CIRCUIT TO NEGATIVE) | EXCEEDED UPPER LIMIT | | Short-circuit to ground. Faulty MPROP. | Check wiring and connections. Replace MPROP if required. | | | | |
| 56 | 08 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | SIGNAL NOT PLAUSIBLE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|-----------------|---|---|------------------------|----------------------|-----------------------|---------|
| 5A | 01 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | EXCEEDED UPPER LIMIT | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 5A | 02 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | BELOW LOWER LIMIT | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 5B | 01 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | EXCEEDED UPPER LIMIT | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|---|--|---|------------------------|----------------------|-----------------------|----------------------|
| 5E | 01 | ENGINE I - FUEL PUMP RELAY | EXCEEDED UPPER LIMIT | Fuel pump on always when engine is off. | Faulty relay, short-circuit to positive in wiring. | Turn key-on: pump must run for approximately 10 seconds (it should hum). Check pump relay if pump remains on. Check wiring if all checks are OK. | | | | |
| 5E | 02 | ENGINE I - FUEL PUMP RELAY | BELOW LOWER LIMIT | Fuel pump not working. | Faulty relay, short-circuit to ground in wiring. | Turn key-on: pump must run for approximately 10 seconds (it should hum). Check the pump relay, protection fuse and wiring if this does not occur. | | | | |
| 5E | 04 | ENGINE I - FUEL PUMP RELAY | NO SIGNAL | Fuel pump not working. | Faulty relay, wiring interrupted. | Check wiring and connections. Replace relay if required. | | | | |
| 5E | 08 | ENGINE I - FUEL PUMP RELAY | SIGNAL NOT PLAUSIBLE | Fuel pump not working. | Faulty relay, wiring interrupted. | Check wiring and connections. Replace relay if required. | | | | |
| 5F | 01 | FUEL PRESSURE - RAIL PRESSURE SENSOR OR SIGNAL ERROR | EXCEEDED UPPER LIMIT | | Short-circuit to positive. Faulty sensor. Rail pressure not regular. | Check wiring and connections. Replace sensor if required. | | | | Check DTC 103 error. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|-----------------|--|---|------------------------|----------------------|-----------------------|---|
| 5F | 02 | FUEL PRESSURE - RAIL PRESSURE SENSOR OR SIGNAL ERROR | BELOW LOWER LIMIT | | Short-circuit to ground, faulty sensor. | Check wiring and connections. Replace sensor if required. | | | | |
| 60 | 01 | FUEL PRESSURE - RAIL PRESSURE SENSOR OFFSET | EXCEEDED UPPER LIMIT | | Faulty rail pressure sensor. | Replace sensor. | | | | |
| 60 | 02 | FUEL PRESSURE - RAIL PRESSURE SENSOR OFFSET | BELOW LOWER LIMIT | | Faulty rail pressure sensor. | Replace sensor. | | | | |
| 62 | 01 | FUEL PRESSURE - FAULT ON THE FUEL DRUCK CONTROL OF THE RAIL (POSITIVE DEVIATION) | EXCEEDED UPPER LIMIT | | High pressure circuit fuel leakage. | Check fuel feed system. | | | | Fuel management and pressure failure in rail. |
| 62 | 01 | FUEL PRESSURE - FAULT ON THE FUEL DRUCK CONTROL OF THE RAIL (POSITIVE DEVIATION) | EXCEEDED UPPER LIMIT | | Injector jammed in fuel passage open position. | Check hydraulic and mechanical efficiency of injectors. | | | | Fuel management and pressure failure in rail. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|-----------------|--------------------------------------|---|------------------------|----------------------|-----------------------|---|
| 62 | 01 | FUEL PRESSURE - FAULT ON THE FUEL DRUCK CONTROL OF THE RAIL (POSITIVE DEVIATION) | EXCEEDED UPPER LIMIT | | MPROP adjuster open movement jammed. | Check efficiency of MPROP adjuster. | | | | Fuel management and pressure failure in rail. |
| 62 | 01 | FUEL PRESSURE - FAULT ON THE FUEL DRUCK CONTROL OF THE RAIL (POSITIVE DEVIATION) | EXCEEDED UPPER LIMIT | | Faulty high pressure pump. | Check efficiency of high pressure pump. | | | | Fuel management and pressure failure in rail. |
| 63 | 01 | FUEL PRESSURE - FAULT ON THE FUEL DRUCK CONTROL OF THE RAIL (NEGATIVE DEVIATION) | EXCEEDED UPPER LIMIT | | MPROP adjuster open movement jammed. | Check efficiency of MPROP adjuster. | | | | Fuel management and pressure failure in rail. |
| 64 | 01 | FUEL PRESSURE - RAIL PRESSURE ERROR: TOO LOW | EXCEEDED UPPER LIMIT | | High pressure circuit fuel leakage. | Check high pressure system. Replace high pressure pump if required. | | | | Fuel management and pressure failure in rail. |
| 65 | 01 | FUEL PRESSURE - RAIL PRESSURE ERROR: TOO HIGH | EXCEEDED UPPER LIMIT | | MPROP regulator jammed. | Check MPROP regulator, replace if required. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|---|----------------------|--|---|---|------------------------|----------------------|-----------------------|--------------------------------|
| 66 | 01 | FUEL PRESSURE - ERROR ON THE RAIL PRESSURE (EXCESSIVE DUTY CYCLE) | EXCEEDED UPPER LIMIT | Negative vehicle reaction with smoke in exhaust during acceleration. | High pressure circuit fuel leakage. | Check fuel feed system, replace high pressure pump if required. Faulty fuel feed system (fuel pump and filter jammed). | | | | |
| 67 | 01 | FUEL PRESSURE - ERROR ON THE RAIL PRESSURE (EXCESSIVE) | EXCEEDED UPPER LIMIT | Engine off. | MPROP regulator jammed. | Check MPROP regulator, replace if required. | | | | Replace pressure relief valve. |
| 68 | 02 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | BELOW LOWER LIMIT | | | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 68 | 04 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | NO SIGNAL | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|---|----------------------|---|---|---|------------------------|----------------------|-----------------------|---|
| 68 | 08 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | SIGNAL NOT PLAUSIBLE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 69 | 01 | ELECTRONIC CONTROL UNIT - SENSOR POWER SUPPLY | EXCEEDED UPPER LIMIT | Anomalous engine operation due to incorrectly powered sensors. Reduced power. | Sensor power circuit fault in ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | Possible fault indications of various sensors powered by ECU. |
| 69 | 02 | ELECTRONIC CONTROL UNIT - SENSOR POWER SUPPLY | BELOW LOWER LIMIT | Anomalous engine operation due to incorrectly powered sensors. Reduced power. | Sensor power circuit fault in ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | Possible fault indications of various sensors powered by ECU. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|---|----------------------|---|------------------------------------|---|------------------------|----------------------|-----------------------|---|
| 6A | 01 | ELECTRONIC CONTROL UNIT - SENSOR POWER SUPPLY | EXCEEDED UPPER LIMIT | Anomalous engine operation due to incorrectly powered sensors. Reduced power. | Sensor power circuit fault in ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | Possible fault indications of various sensors powered by ECU. |
| 6A | 02 | ELECTRONIC CONTROL UNIT - SENSOR POWER SUPPLY | BELOW LOWER LIMIT | Anomalous engine operation due to incorrectly powered sensors. Reduced power. | Sensor power circuit fault in ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | Possible fault indications of various sensors powered by ECU. |
| 6B | 01 | ELECTRONIC CONTROL UNIT - SENSOR POWER SUPPLY | EXCEEDED UPPER LIMIT | Anomalous engine operation due to incorrectly powered sensors. Reduced power. | Sensor power circuit fault in ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | Possible fault indications of various sensors powered by ECU. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|---|----------------------|---|------------------------------------|---|------------------------|----------------------|-----------------------|--|
| 6B | 02 | ELECTRONIC CONTROL UNIT - SENSOR POWER SUPPLY | BELOW LOWER LIMIT | Anomalous engine operation due to incorrectly powered sensors. Reduced power. | Sensor power circuit fault in ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | Possible fault indications of various sensors powered by ECU. |
| 6C | 01 | VEHICLE - EDC LAMP | EXCEEDED UPPER LIMIT | Warning light not working. | Short-circuit to positive. | Check correct operation of warning light using "Active diagnostic" procedure. | | | | Warning light should come on for approximately 5 seconds at key-on. Check wiring and connections if this does not occur. |
| 6C | 02 | VEHICLE - EDC LAMP | BELOW LOWER LIMIT | Warning light not working. | Short-circuit to ground. | Check correct operation of warning light using "Active diagnostic" procedure. | | | | Warning light should come on for approximately 5 seconds at key-on. Check wiring and connections if this does not occur. |
| 6C | 04 | VEHICLE - EDC LAMP | NO SIGNAL | Warning light not working. | Open circuit, bulb disconnected. | Check correct operation of warning light using "Active diagnostic" procedure. | | | | Warning light should come on for approximately 5 seconds at key-on. Check wiring and connections if this does not occur. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|-----------------------------|---|---|------------------------|----------------------|-----------------------|--|
| 6C | 08 | VEHICLE - EDC LAMP | SIGNAL NOT PLAUSIBLE | Warning light not working. | Wiring problems. | Check wiring and connections. Replace sensor if required. | | | | Warning light should come on for approximately 5 seconds at key-on. Check wiring and connections if this does not occur. |
| 6D | 08 | ENGINE 2 - INTERNAL ECU FAULT (PLAUSIBILITY ERROR +15) | SIGNAL NOT PLAUSIBLE | | | Check wiring and connections. | | | | Key I5 off during initialisation. |
| 6E | 08 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | SIGNAL NOT PLAUSIBLE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 75 | 01 | VEHICLE - VEHICLE SPEED SENSOR / SIGNAL | EXCEEDED UPPER LIMIT | Speed of 170 km/h exceeded. | | Check correct calibration of speedometer. | | | | Encourage driver to use the vehicle correctly. |
| 75 | 04 | VEHICLE - VEHICLE SPEED SENSOR / SIGNAL | NO SIGNAL | | Interrupted wiring between vehicle speed sensor and instrument panel. | Check wiring and connections between vehicle speed sensor and instrument panel. | | | | |
| 75 | 04 | VEHICLE - VEHICLE SPEED SENSOR / SIGNAL | NO SIGNAL | | Wiring interrupted between instrument panel and EDC ECU. | Check wiring and connections between instrument panel and EDC ECU. | | | | Intervention required if instrument panel indicates vehicle speed. |


| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|------------------------|---|---|---|------------------------|----------------------|-----------------------|---------|
| 75 | 04 | VEHICLE SPEED SENSOR / SIGNAL | - NO SIGNAL | | Vehicle speed sensor disconnected or failed. | Check correct assembly and efficiency of vehicle speed sensor. | | | | |
| 75 | 08 | VEHICLE SPEED SENSOR / SIGNAL | - SIGNAL NOT PLAUSIBLE | | Vehicle speed sensor disconnected or failed. | Check correct assembly and efficiency of vehicle speed sensor. | | | | |
| 75 | 08 | VEHICLE SPEED SENSOR / SIGNAL | - SIGNAL NOT PLAUSIBLE | Vehicle speed on instrument panel does not increase sensibly. | Wrong speedometer setting. | Check correct calibration of speedometer. | | | | |
| 77 | 01 | VEHICLE SPEED SENSOR / SIGNAL | - EXCEEDED UPPER LIMIT | Wrong vehicle speed indication. | Wrong speedometer setting. | Check correct calibration of speedometer. | | | | |
| 77 | 02 | VEHICLE SPEED SENSOR / SIGNAL | - BELOW LOWER LIMIT | Wrong vehicle speed indication. | Wrong speedometer setting. | Check correct calibration of speedometer. | | | | |
| 77 | 08 | VEHICLE SPEED SENSOR / SIGNAL | - SIGNAL NOT PLAUSIBLE | Wrong vehicle speed indication. | Wrong speedometer setting. | Check correct calibration of speedometer. | | | | |
| 79 | 08 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | SIGNAL NOT PLAUSIBLE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |

2nd Section


SYMPTOMS

Main engine operating trouble:


- 1 – The engine fails to start or cuts out;
- 2 – The engine overheats;
- 3 – The engine lacks power;
- 4 – The engine produces black or dark grey smoke;
- 5 – The engine produces grey (tending to white) smoke;
- 6 – The engine produces blue smoke;
- 7 – The engine produces white or black smoke;
- 8 – The engine knocks abnormally;
- 9 – The engine stops;
- 10 – Fuel consumption too high;
- 11 – Oil pressure low or too high.




(continues)




(continues)




(continues)




2 THE ENGINE OVERHEATS





(continues)







(continues)











(continues)






Engines with rotary mechanical injection pump

| | Page |
|---|------|
| TROUBLESHOOTING | 211 |
| <input type="checkbox"/> Engine 8140.43C.43XX | 221 |
| <input type="checkbox"/> Engine 8140.63.40XX | 249 |


TROUBLESHOOTING

Main engine operating faults with mechanical injection pump:


- | | |
|--|--|
| <ul style="list-style-type: none"> 1 - engine will not start; 2 - engine overheats; 3 - engine lacks power; 4 - engine emits black or dark grey smoke; 5 - engine emits grey (whitish) smoke; | <ul style="list-style-type: none"> 6 - engine emits blue smoke; 7 - abnormal knocking from the engine; 8 - engine stops; 9 - engine exceeds maximum rpm; 10 - oil pressure too high or too low; 11 - excessive fuel consumption. |
|--|--|




(continued)




(continued)







(continued)




(continued)




(continued)




(continued)



(continued)




(continued)



5401 Engine 8140.43C.43XX

| | Page |
|---|------|
| <input type="checkbox"/> Gas emissions | 223 |
| <input type="checkbox"/> Smokiness | 223 |
| <input type="checkbox"/> Noise emissions | 223 |
| GENERAL SPECIFICATIONS | 226 |
| ASSEMBLY DATA - CLEARANCES | 229 |
| TIGHTENING TORQUE | 234 |
| TOOLS | 235 |
| ENGINE OVERHAUL | 236 |
| <input type="checkbox"/> Dismantling engine on bench | 236 |
| CYLINDER HEAD | 237 |
| <input type="checkbox"/> Engine assembling at the bench | 237 |
| <input type="checkbox"/> Setting the timing system | 237 |
| <input type="checkbox"/> Injection pump assembling and timing | 237 |
| COOLING | 239 |
| FEEDING | 241 |

Figure 1



52184

Gas emissions

Engine 8140.43C conforms with the Euro2 standards on gas emissions (measurement on engine bench according to R 49 cycle), with the following limits fixed by EEC 91/542 standards:

- | | |
|------------------------|--------------|
| – CO (carbon monoxide) | < 4.0 g/kWh |
| – NOx (nitrogen oxide) | < 7.0 g/kWh |
| – HC (hydrocarbons) | < 1.10 g/kWh |
| – Particulate | < 0.15 g/kWh |

Test fuel: CEC RFT 73 - T - 90 - S \leq 0.05 %.

Smokiness

Engine 8140.43C conforms with the limits of smokiness required by EEC standards 72/306 and R 24-03 with the following exhaust smokiness values:


- | | |
|--|-----|
| Maximum power (Bosch BSU opacimeter degrees) | 2.0 |
| Maximum torque (Bosch BSU opacimeter degrees) | 2.5 |
| Full load at 1000 rpm (Bosch BSU opacimeter degrees) | 3.5 |

Noise emissions

Maximum mean noise level, Lpa, of the standard engines measured according to ISO Std. 3745 (microphones at 1 m from the engine surfaces):

- | | | |
|------------|------------|---------|
| Idling | (800 rpm) | dB A 79 |
| Full power | (3600 rpm) | dB A 99 |


Figure 2



52178

8140.43C.4... ENGINE LONGITUDINAL SECTION















Figure 3



8140.43C.4... ENGINE CROSS SECTION









52179

GENERAL SPECIFICATIONS







| | | | |
|---|---|--------------------------------|---------------|
|  | Type | 8140.43C.4.. ID/TCA | |
|  | Cycle | Diesel 4 strokes | |
| | Feeding | Supercharged | |
| | Injection | Direct | |
|  | No. of cylinders | 4 on-line | |
|  | Diameter | mm | 94.4 |
|  | Stroke | mm | 100 |
|  | Total displacement cm ³ | | 2800 |
|  | Compression ratio | 18.5 | |
|  | Max. power | kW | 73.8 ÷ 78.6 |
| | | (HP) | 100.4 ÷ 106.9 |
|  | | rpm | 3600 |
|  | Max. torque | Nm | 245.8 ÷ 268.6 |
| | | (kgm) | 25.1 ÷ 27.4 |
|  | | rpm | 1800 |
|  | Engine idling speed, no load | rpm | 800 ± 25 |
|  | Maximum engine speed, no load | rpm | 4200 ± 50 |
|  | Pressure at T.D.C. *bar | 20 ÷ 26 | |
| | Minimum permissible pressure at T.D.C. *bar | 16 | |

(*) The pressure value is recorded by turning the engine over with the electric starter motor, with oil temperature at 40°- 50°C and the injection pump in the stop condition.















ID = Direct injection
 PC = Indirect injection (pre-chamber)
 TCA = Supercharging with intercooler

|  | Type | 8140.43C.4. ID/TCA |
|---|---|--|
|  | <p>VALVE TIMING</p> <p>opens before T.D.C. A</p> <p>closes after B.D.C. B</p> <p>opens before B.D.C. D</p> <p>closes after T.D.C. C</p> | <p>8°</p> <p>37°</p> <p>48°</p> <p>8°</p> |
|  | <p>For timing check</p> <p>X mm</p> <p>X mm</p> <p>Running</p> <p>X mm</p> <p>X mm</p> | <p>0.5 ± 0.05</p> <p>0.5 ± 0.05</p> <p>0.5 ± 0.05</p> <p>0.5 ± 0.05</p> |
|  | <p>FUEL SUPPLY</p> <p>Bosch type injection pump</p> <ul style="list-style-type: none"> - with immobilizer - without immobilizer <p>Speed governor</p> <p>Cold start</p> | <p>rotating distributor</p> <p>VER 824</p> <p>VER 824-1</p> <p>all speeds</p> <p>K.S.B. electrical, mechanical</p> |
|  | <p>Pump arrangement</p> <p>With piston n. 1 at T.D.C.</p> <p>Start of delivery mm</p> | <p>1.10 ± 0.05</p> |
|  | <p>BOSCH injector nozzle type</p> | <p>SACLESS</p> <p>DSLA 134 P 604</p> |
|  | <p>Injection order</p> <ul style="list-style-type: none"> - injection pump - engine | <p>A - B - C - D</p> <p>1 - 3 - 4 - 2</p> |
|  | <p>Injection pressure bar</p> | <p>240 + 12 *</p> |

* When checking, for any values of less than 200 bars, calibrate the injectors at 230 + 8 bar.












|  | Type | 8140.43C.4.. ID/TCA |
|---|--|---|
|  | SUPERCHARGING Turbocharger type marked with colour Turbocharger shaft radial clearance Turbocharger shaft axial clearance Minimum opening stroke of pressure relief valve mm Maximum opening stroke of pressure relief valve mm Pressure corresponding to the minimum stroke bar Pressure corresponding to the maximum stroke bar | With intercooler KKK K03-2076-CCA 6.68 pink - - - 3.5 ± 0.2 - 1.3 ± 0.002 |
|  | Turbocharger type marked with colour Turbocharger shaft radial clearance Turbocharger shaft axial clearance Minimum opening stroke of pressure relief valve mm Maximum opening stroke of pressure relief valve mm Pressure corresponding to the minimum stroke bar Pressure corresponding to the maximum stroke bar | MITSUBISHI TD04 pink $0.396 \div 0.602$ $0.034 \div 0.106$ 1 5 1.11 ± 0.0026 1.35 ± 0.0039 |
|   | LUBRICATION Oil pressure, engine hot at idling speed bar at maximum speed bar | Forced feed by gear pump, relief valve, dual action oil filter ≥ 0.8 ≥ 3.5 |
| COOLING | Thermostat: starts to open: fully open: | With a centrifuge pump, driven by the crankshaft via a poly-V belt, thermostat, fan with electro-magnetic clutch, radiator, heat exchanger. "Intercooler" $82^{\circ} \text{C} \pm 2^{\circ} \text{C}$ 110°C |
|  | OIL REPLENISHMENT Total capacity at 1st filling liters kg Quantity at periodical replacements: - engine sump liters kg - engine sump liters kg | 6.9 6.1 5.2 4.6 6.3 5.7 |













ASSEMBLY DATA - CLEARANCES



















|  Type | 8140.43C.4.. ID/TCA | |
|--|------------------------|--|
| CYLINDER BLOCK AND CRANK MECHANISM COMPONENTS | | |
|  Bores for cylinder liners $\varnothing 1$ | $\varnothing 1$ | 97.39 ÷ 97.45* |
|  Cylinder liners: outside diameter $\varnothing 2$ length L | | ** 97.47 ÷ 97.50 167.00 ÷ 167.30 |
|  Cylinder liners - crankcase bores (negative allowance) | | 0.02 ÷ 0.11 |
|  Outside diameter $\varnothing 2$ | | 0.2 |
|  Cylinder barrels: (protrusion from engine block bottom) inside diameter $\varnothing 3$ | | ** 0.005 max 94.402 ÷ 94.432 |
|  Pistons: supplied as spare parts type: measuring dimension X outside diameter $\varnothing 1$ pin bore $\varnothing 2$ | | MONDIAL PISTON 10 94.306 ÷ 94.320 32.003 ÷ 32.009 |
|  Piston - cylinder sleeve | | 0.082 ÷ 0.126 |
|  Pistons: supplied as spare parts type: measuring dimension X outside diameter $\varnothing 1$ pin bore $\varnothing 2$ | | KS 10 94.306 ÷ 94.320 32.003 ÷ 32.009 |
|  Piston - cylinder sleeve | | 0.082 ÷ 0.126 |
|  Piston diameter $\varnothing 1$ | | 0.4 |
|  Pistons protrusion X | X | > 0.40 ÷ ≤ 0.80 |
|  Gudgeon pin $\varnothing 3$ | $\varnothing 3$ | 31.990 ÷ 31.996 |
|  Gudgeon pin - pin housing | | 0.003 ÷ 0.015 |













* Diameter to be obtained at servicing when fitting spare cylinder barrels.

** Supplied as spare parts.

|  Type | 8140.43C.4.. ID/TCA | |
|---|--|--|
| CYLINDER BLOCK AND CRANK MECHANISM COMPONENTS | | |
|  Piston type Piston ring grooves * measured on \varnothing of 91.4 mm | X1* X 2 X3 | MONDIAL PISTON - KS 2.200 ÷ 2.230 2.050 ÷ 2.070 2.540 ÷ 2.560 |
|  Piston rings * measured on \varnothing of 91.4 mm | S 1* S 2 S 3 | 2.068 ÷ 2.097 1.970 ÷ 1.995 2.470 ÷ 2.490 |
|  Piston rings - grooves | 1 2 3 | 0.103 ÷ 0.162 0.55 ÷ 0.100 0.05 ÷ 0.09 |
|  Piston rings | | 0.4 |
|  Piston ring end gap in cylinder liners | X1 X2 X3 X1 X2 X3 | 0.20 ÷ 0.35 0.30 ÷ 0.50 0.30 ÷ 0.55 |
|  Small end bush housing Big end bearing housing * * spare connecting rod supplied | \varnothing 1 \varnothing 1 \varnothing 2 \varnothing 2 | 35.460 ÷ 35.490 60.341 ÷ 60.348 |
|  Small end bush diameter outside inside Big end bearing shell supplied as spare parts | \varnothing 4 \varnothing 4 \varnothing 3 \varnothing 3 S S | 35.570 ÷ 35.595 32.010 ÷ 32.020 1.875 ÷ 1.884 |
|  Small end bush - housing | | 0.08 ÷ 0.135 |
|  Piston pin - bush | | 0.014 ÷ 0.03 |
|  Piston rings | | 0.254 ÷ 0.508 |

|  | Type | 8140.43C.4. ID/TCA |
|---|--|---|
| CYLINDER BLOCK AND CRANK MECHANISM COMPONENTS | | |
|  | Measuring dimension X | 125 |
|  | Max. connecting rod axis misalignment tolerance = | 0.07 |
|  | Main journals $\varnothing 1$ n° 1 - 2 - 3 - 4 n° 5 Crankpins $\varnothing 2$ Main bearing shells S1* Big end bearing shells S2* * supplied as spare parts | 80.182 ÷ 80.208 86.182 ÷ 86.208 56.515 ÷ 56.538 2.165 ÷ 2.174 1.875 ÷ 1.884 |
|  | Main bearings $\varnothing 3$ n° 1 - 2 - 3 - 4 n° 5 | 84.588 ÷ 84.614 90.588 ÷ 90.614 |
|  | Bearing shells - main journals | 0.032 ÷ 0.102 |
|  | Bearing shells - big ends | 0.035 ÷ 0.083 |
|  | Main bearing shells Big end bearing shells | 0.254 ÷ 0.508 0.254 ÷ 0.508 |
|  | Main journal, thrust bearing X 1 | 31.000 ÷ 31.100 |
|  | Main bearing housing, thrust bearing X 2 | 26.500 ÷ 26.550 |
|  | Thrust washer halves X 3 | 30.900 ÷ 30.950 |
|  | Crankshaft end float | 0.060 ÷ 0.310 |

|  Type | 8140.43C.4.. ID/TCA |
|---|--|
| CYLINDER HEADS - VALVE GEAR | |
|  Valve guide housings in the cylinder heads $\varnothing 1$ | 12.950 ÷ 12.985 |
|  Valve guide $\varnothing 2$ $\varnothing 3$ | 8.023 ÷ 8.038 13.012 ÷ 13.025 |
|  Valve guides and housings in the cylinder heads | 0.027 ÷ 0.075 |
|  Valve guide | 0.05 - 0.10 - 0.2 |
|  Valves:  $\varnothing 4$ α  $\varnothing 4$ α | 7.985 ÷ 8.000 60° 15' ± 7' 30" 7.985 ÷ 8.000 45° 30' ± 7' 30" |
|  Valve stem and its guide | 0.023 ÷ 0.053 |
|  Housing in head for valve seat  $\varnothing 1$  $\varnothing 1$ | 42.125 ÷ 42.175 37.380 ÷ 37.415 |
|  Outside diameter of valve seat; angle of valve seat in cylinder head:  $\varnothing 2$ α  $\varnothing 2$ α | 42.245 ÷ 42.260 60° ± 5' 37.495 ÷ 37.510 45° ± 5' |
|  Recessing of valve X | 1.2 ÷ 1.5 1 ÷ 1.3 |
|  Between valve seat and head | 0.070 ÷ 0.135 0.080 ÷ 0.130 |
|  Valve seats | - |

|  Type | 8140.43C.4.. ID/TCA |
|---|---|
| CYLINDER HEADS - VALVE GEAR | |
|  Valve outside spring height: free height H under a load of: kg 43.8 ± 2.5 H1 kg 77.4 ± 4 H2 | 52 38.5 28.5 |
|  Valve inside spring height: free height H under a load of: kg 16.4 ± 1 H1 kg 30 ± 1.5 H2 | 45.5 33.5 23.5 |
|  Injector protrusion X | 2.23 ÷ 2.69 |
|  Camshaft bearing housing normal ∅ oversized ∅ | 33.985 ÷ 34.015 34.185 ÷ 34.215 |
|  Camshaft bearing journals normal ∅ oversized ∅ | 33.934 ÷ 33.950 34.134 ÷ 34.150 |
|  Between seats and supporting pins | 0.035 ÷ 0.081 |
|  Tappets housing on cylinder heads ∅ normal | 44.000 ÷ 44.025 |
|  Tappet ∅ normal | 43.950 ÷ 43.970 |
|  Between tappets and seats | 0.030 ÷ 0.075 |
|  Cap | 3.25 to 4.45 mm with a progression of 0.05 |
|  Cam lift: H H H | 9.5 10.5 |





TIGHTENING TORQUE

NOTE This differs from the analogous section for 8140.43R/B/S/N engines in the following tightening torques.

| PART | TORQUE | |
|--|--------|-----|
| | Nm | kgm |
| Nut M14 x 1.5 fixing toothed bushing to the injection pump | 83 | 8.3 |
| Nut or screw fixing injection pump | 25 | 2.5 |
| Fastening L.D.A. coupling to the intake manifold and to the injection pump | 10 | 1 |
| Screw fixing injector bracket | 40 | 4 |
| Screw fixing top cover of auxiliary element assembly | 18 | 1.8 |
| Fastening diesel inlet and outlet coupling on injection pump | 25 | 2.5 |
| Fastening diesel pipe fittings to the injection pump and injectors | 33 | 3.3 |
| Fastening "OUT" coupling on injection pump | 25 | 2.5 |
| Fixing diesel recovery pipes from the injectors | 7 | 0.7 |

TOOLS

NOTE This differs from the analogous section for 8140.43R/B/S/N engines in the exclusion of tools 99317915 - 99389829 - 99389833 - 99395603 and the addition of the following tools.


| TOOL NO. | DESCRIPTION | |
|----------|---|--|
| 99352114 |  | Wrench (13 mm) for nut on crankcase side fixing injection pump (8140.43C engines only) |
| 99360486 |  | Fitting to check compression in cylinders (use with 99395682) |
| 99395100 |  | Dial gauge holding tool for injection pump setting |
| 99395682 |  | Device for checking diesel engine cylinder compression |

ENGINE OVERHAUL

NOTE This differs from the overhaul of the 8140.43B/R/S/N engines in the following.

540110 Dismantling engine on bench

Figure 4




Take out the fitting (4) and disconnect the pipe (3) from the L.D.A. device (5).

Disconnect the pipe (2) from the fuel recirculation fitting (6).

Remove the air duct (1) complete with pipes (2, 3), thermostart glow plug (7) and thermostart solenoid valve (8) from the intake manifold.


Remove the soundproofing cover (9).

Figure 5



Disconnect the fuel pipes (1) from the injectors (3) and from the injection pump (2).

Figure 6




Remove connections (5) and disconnect fuel recovery pipes (6) from injectors (4).

Remove connection (8) and disconnect three-way connection (3) from injection pump including pipes (6-7) and spring plugs.

Remove injector (4) bracket (1) fixing screws (2).
Remove injectors from cylinder head.

Figure 7




Mark the assembly position of the injection pump (1) on the auxiliary member assembly (2).

Remove the fixing nuts and disconnect the injection pump (1) from the auxiliary member assembly (2).

NOTE To remove the bottom fixing nut on the crankcase side, use wrench 993521 I4 (3).

560610 CYLINDER HEAD

Figure 8




18880

Use dial gauge (1) to check whether valve sunk and injector (2) protrusion from cylinder head surface are falling within the required value.

**Engine assembling at the bench
Setting the timing system**


Figure 9



61900

Check whether cylinder I piston is at TDC. This condition takes place when tool 99395214 (1) pin (2) is fitted into engine flywheel (3) slit (⇒) and control gear hole (5) and timing gear (4) are facing downward.


Figure 10



45074

Make coincide notch (1) engraved on camshaft driving toothed pulley, with that (2) engraved on valve tappets cover.


Figure 11



41820

Rotate accessory equipments driving toothed pulley (1) so as to align pulley hole (1) with that of support and lock rotation by inserting tool 99360608 (2).


Figure 12



45079

- Fit toothed belt (1);
- fit lower cover (4) and tighten fastening screws and nuts to prescribed torque;
- remove tool (3) so as pushing rod (2), acting on belt tightener (5), makes toothed belt taut (1);


Figure 13



61900

- remove engine flywheel (3) slit (\Rightarrow) from tool 99395214 (1) pin (2);
- turn the crankshaft slowly in the direction of rotation by two turns and check that hole (5) in gear (4) is facing downwards and that the pin (2) of the tool (1) is inserted in the slot (\rightarrow) through the flywheel (3) when the timing belt is taut; the notches (1 and 2, Figure 10) must be aligned.

Figure 14




86144

- lock the tightener (2), tightening the fixing nut at a torque of 37 ± 45 Nm;

Use tool 99395849 to check timing belt tension (1) which must be 88 ± 112 Hz in point **A**.

Injection pump assembling and timing

Figure 15




62081

NOTE Should joint (2) be replaced, use tool 99365143 to lock joint (2) rotation when moving nut (4) and tool 99342138 to remove the joint from injection pump shaft.

Connect injection pump on accessory equipments group proceeding as follows:

- check for the exact timing of valve gear;
- Fit injection pump (2, Figure 16) on auxiliary component unit (3, Figure 16). The spline (1) obtained inside pump control shaft shall coincide with joint projection (3). Position the injection pump on auxiliary component unit so that marks performed at removal coincide.
- Screw pump fastening nuts (1, Figure 16) without tightening them;

Figure 16




52221

- Remove the plug, situated on pump closing screw, and screw tool 99395100 (5) with the rod in contact with distributor piston crown;
- prevaricate dial gauge 99395603 (5) of ~ 3 mm;
- feed the thermal bulb (4) of K.S.B. device with a 12 V voltage, throughout timing duration; in this way K.S.B. device is cut-out.

NOTE K.S.B. device is cut-out when advance changer lever is no more engaged.


- Reverse engine rotation until dial gauge (5, Figure 16) indicates that pump piston is at BDC.
- Set dial gauge to zero.

Figure 17



- Turn the engine flywheel (3) in its direction of rotation so that, when the hole (5) of the gear (4) driving the timing system goes into its lowest position, the pin (2) of tool 99395214 (1) goes into the milled slot (⇒) of the engine flywheel (3).
In these conditions it is necessary to measure the stroke of the timing system piston on the dial gauge (5, Figure 16). If you find the stroke has a different value to the prescribed one, turn the pump casing in its slot to get the prescribed value indicated by the dial gauge.

Figure 18



62082


- Tighten the nuts fixing injection pump (1) to auxiliary component unit (2) to the specified torque.

NOTE To tighten injection pump fastening nut, engine crankcase side, use key 99352114 (4).

- cut-out feed to K.S.B. device (3);
- remove tool 99395100 with dial gauge (5, Figure 16) and screw again plug on locking screw;
- remove tool 99395214 (1, Figure 17).

NOTE When refitting fuel pipes, do not reuse metallic clamp with spring plug and fixing screw, but replace them with new parts.

Figure 19



NOTE The injection pump is supplied as a spare part with the start of delivery already set and with the spacer (1).

The screw (3) locks the shaft (2) of the injection pump to keep the above-mentioned setting until the pump is fitted onto the engine.

After assembly, loosen the screw (3), to make it possible to insert the spacer (1) between the screw and the casing of the injection pump, then lock the screw (3), the spacer (1) is used to ensure the shaft of the injection pump turns.

After tightening the screw (3), twist the end of the spacer (1) so as to cause it to break off and then be removed.

After fitting the injection pump, check its timing as described under the relevant heading.

5432 COOLING

Coolant temperature:

- turning on the fan: $92 \pm 2^\circ\text{C}$;
- turning off the fan: $87 \pm 2^\circ\text{C}$.

Feeding

| | Page |
|--|------|
| INJECTION PUMP TEST VALUES | 243 |
| COLD INJECTION ADVANCE AUTOMATIC DEVICE (KSB) [KALT START BETRIEBSEINRICHTUNG] . . . | 247 |
| <input type="checkbox"/> Description | 247 |
| <input type="checkbox"/> Operation | 247 |

NOTE The test and adjustment values indicated in the text and summary tables are given as a general indication.

INJECTION PUMP TEST VALUES

| | | | |
|---|----------------------------------|--|----------------------------------|
| IVECO ENGINEERING | | No. 500347285 | Edit. I |
| INJECTION ROTARY PUMP TEST VALUES | | | |
| Injection pump: VE4/12F1800R824 Speed governor: All speeds | | IVECO PART N.: 500329477 BOSCH PART N.: 0460 424 177 | |
| Engine : 8140.43C.4000 | | For: IVECO | |
| Timing: | | | |
| <ul style="list-style-type: none"> - Injection pump static advance (Output reference "A") 1.0 ± 0.5 degrees before X after T.D.C. with I.P. pumping in phase of delivery at 1 mm from B.D.C. - Or with piston at T.D.C. and injection pump pumping in phase of delivery at 1.10 ± 0.04 mm from B.D.C. - Engine idling speed without load: 800 ± 25 rpm | | | |
| TEST BENCH WITH STATIC AND DYNAMIC CHARACTERISTICS CONFORMING TO STANDARDS ISO 4008/1 -/2 | | | |
| <ul style="list-style-type: none"> - Rotation direction: Right X Left - Pipes: $\varnothing 6 \times \varnothing 2 \times 450$ mm - Injectors: 1688 901 027 - Calibrated hole pad: = $\varnothing 0.5$ mm - Injector setting : 250 ± 3 bar - Backflow chock: $\varnothing 0.75$ mm | | <ul style="list-style-type: none"> - Supply pressure: 0.35 ± 0.05 bar - Burette evacuation time: - Test fluid conforming to standard: ISO 4113 - Temperature Influx Defluxion X - Thermometer : 55 ± 1 °C - Electronic : ± 4 °C | |
| "INJECTION PUMP ADJUSTMENT VALUES" "THE NUMBERS GIVEN IN BRACKETS SHOULD BE USED ONLY AS CONTROL VALUES" | | | |
| 1 - START OF DELIVERY | | 5 - DELIVERY AT FULL LOAD WITHOUT OVERCHARGING | |
| Pre-lift (from B.D.C.) | mm: 0 ± 0.02 | Speed | rpm: 550 |
| 2 - ADVANCE CHANGER TRAVEL | | Delivery per 1000 shots | cm ³ : 28.5 ± 0.5 |
| Speed | rpm: 900 | Max difference | cm ³ : |
| Overcharging pressure | hPa: 1200 | 6 - IDLE SPEED ADJUSTMENT | |
| Adjustment values | mm: 1.2 ± 0.1 | Speed | rpm: 350 |
| 3 - TRANSFER PUMP PRESSURE | | Delivery per 1000 shots | cm ³ : 7.0 ± 2.0 |
| Speed | rpm: 900 | Max difference | cm ³ : 6.0 (6.5) |
| Overcharging pressure | hPa: 1200 | 7 - ADJUSTING THE RESIDUAL DELIVERY | |
| Adjustment values | bar: 5.9 ± 0.3 | Speed | rpm: |
| 4 - DELIVERY AT FULL LOAD WITH OVERCHARGING | | Delivery per 1000 shots | cm ³ : |
| Speed | rpm: 1100 | 8 - MAXIMUM SPEED ADJUSTMENT | |
| Overcharging pressure | hPa: 1200 | Speed | rpm: 2000 |
| Delivery per 1000 shots | cm ³ : 57.5 ± 0.5 | Overcharging pressure | hPa: 1200 |
| Max difference | cm ³ : 4.0 (4.5) | Delivery per 1000 shots | cm ³ : 43.0 ± 0.5 |

Date: 17-11-1998

Sheet 1/4

| IVECO ENGINEERING | | No. 500347285 | | Edit. 1 | |
|--|-------------------|---------------|--|-------------------|------------|
| INJECTION ROTARY PUMP TEST VALUES | | | | | |
| 9 - START | | | 14 - DELIVERY RUN AND ADJUSTMENT | | |
| Speed | rpm: | 100 | .1 Speed | rpm: | 500 (*) |
| Delivery per 1000 shots | cm ³ : | 75.0 ± 20 | Overcharging pressure | hPa: | 500 |
| Minimum delivery | cm ³ : | 55.0 | Delivery per 1000 shots | cm ³ : | 48.5 ± 0.5 |
| 10 - "LFB" SETTING | | | .1. Delivery difference per 1000 shots | | |
| Speed | rpm: | | cm ³ : | (± 3.5) | |
| Overcharging pressure | hPa: | | .2 Speed | | |
| .1. Delivery difference per 1000 shots | cm ³ : | | Overcharging pressure | hPa: | 2230 |
| .2. Transfer pump pressure difference | bar: | | Delivery per 1000 shots | cm ³ : | 1200 |
| 11 - INJECTION ADVANCE RUN | | | cm ³ : | | |
| Overcharging pressure | hPa: | 1200 | (± 2.0) | | |
| .1 Speed | rpm: | 900 | .3 Speed | | |
| Advance travel | mm: | 1.2 ± 0.1 | Overcharging pressure | hPa: | 2100 |
| | mm: | (± 0.7) | Delivery per 1000 shots | cm ³ : | 1200 |
| .2 Speed | rpm: | 1500 | cm ³ : | 21.0 ± 6.0 | |
| Advance travel | mm: | 3.6 ± 0.6 | cm ³ : | | |
| | mm: | (± 0.7) | (± 8.0) | | |
| .3 Speed | rpm: | | .4 Speed | | |
| Advance travel | mm: | | Overcharging pressure | hPa: | 2000 |
| | mm: | | Delivery per 1000 shots | cm ³ : | 1200 |
| .4 Speed | rpm: | | cm ³ : | 43.0 ± 0.5 | |
| Advance travel | mm: | | cm ³ : | | |
| | mm: | | (± 4.5) | | |
| 12 - TRANSFER PRESSURE RUN | | | .5 Speed | | |
| Overcharging pressure | hPa: | 1200 | Overcharging pressure | hPa: | 1800 |
| .1 Speed | rpm: | 900 | Delivery per 1000 shots | cm ³ : | 1200 |
| Transfer pump pressure | bar: | 5.9 ± 0.3 | cm ³ : | 5.8 ± 2.5 | |
| .2 Speed | rpm: | 1800 | cm ³ : | | |
| Transfer pump pressure | bar: | 8.3 ± 0.5 | (± 3.5) | | |
| .3 Speed | rpm: | 600 | .6 Speed | | |
| Transfer pump pressure | bar: | 4.9 ± 0.5 | Overcharging pressure | hPa: | 1100 |
| .4 Speed | rpm: | | Delivery per 1000 shots | cm ³ : | 1200 |
| Transfer pump pressure | bar: | | cm ³ : | 57.5 ± 0.5 | |
| | bar: | | cm ³ : | | |
| 13 - BACKFLOW VOLUME ON VALVE | | | (± 3.5) | | |
| .1 Speed | rpm: | 600 | .7 Speed | | |
| Overcharging pressure | hPa: | 1200 | Overcharging pressure | hPa: | 600 |
| Backflow volume c.c./10s: | | 113 ÷ 146 | Delivery per 1000 shots | cm ³ : | 1200 |
| | c.c./10s: | (107 ÷ 152) | cm ³ : | 60.5 ± 4.0 | |
| .2 Speed | rpm: | 1800 | cm ³ : | | |
| Overcharging pressure | hPa: | 1200 | (± 6.0) | | |
| Backflow volume c.c./10s: | | 143 ÷ 187 | .8 Speed | | |
| | c.c./10s: | (138 ÷ 193) | Overcharging pressure | hPa: | 550 |
| | | | Delivery per 1000 shots | cm ³ : | 0 |
| | | | cm ³ : | 28.5 ± 0.5 | |
| | | | cm ³ : | | |
| | | | (± 3.5) | | |
| | | | .9 Speed | | |
| | | | Overcharging pressure | hPa: | |
| | | | Delivery per 1000 shots | cm ³ : | |
| | | | cm ³ : | | |
| | | | .10 Speed | | |
| | | | Overcharging pressure | hPa: | |
| | | | Delivery per 1000 shots | cm ³ : | |
| | | | cm ³ : | | |

IVECO ENGINEERING

No. 500347285

Edit. I

INJECTION ROTARY PUMP TEST VALUES

15 - DELIVERY NULL (STOP)

| | | | |
|-------------------------|-------------------|-----------|--|
| 1 Mechanical: | | | |
| Speed | rpm: | 425 | |
| Delivery per 1000 shots | cm ³ : | 1.5 ± 1.5 | |
| Voltage | volt: | 12 | |
| 2 Electrical: | | | |
| Speed | rpm: | 350 | |
| Delivery per 1000 shots | cm ³ : | 1.5 ± 1.5 | |
| Voltage | volt: | 0 | |

16 - DELIVERY AT IDLING SPEED

| | | | |
|-------------------------|-------------------|----------------------|--|
| 1 Speed | rpm: | 350 | |
| Delivery per 1000 shots | cm ³ : | 7.0 ± 2.0 (± 4.0) | |
| 2 Speed | rpm: | | |
| Delivery per 1000 shots | cm ³ : | | |
| 3 Speed | rpm: | | |
| Delivery per 1000 shots | cm ³ : | | |
| 4 Speed | rpm: | | |
| Delivery per 1000 shots | cm ³ : | | |
| Residual delivery check | | | |
| 5 Speed | rpm: | | |
| Delivery per 1000 shots | cm ³ : | | |

17 - "LFB" CHECK

| | | |
|--------------------------------------|-------------------|--|
| Speed | rpm: | |
| Overcharging pressure | hPa: | |
| 1 Delivery difference per 1000 shots | cm ³ : | |
| Advance travel diff. | mm: | |
| 2 Delivery per 1000 shots | cm ³ : | |
| Advance travel diff. | mm: | |

18 - AUTOMATIC START EXTRA DELIVERY

| | | |
|-------------------------|-------------------|-------------|
| 1 Speed | rpm: | 100 |
| Delivery per 1000 shots | cm ³ : | 75.0 ± 20.0 |
| | cm ³ : | min. 55 |
| 2 Speed | rpm: | 370 |
| Delivery per 1000 shots | cm ³ : | 55.0 ± 20.0 |
| | cm ³ : | max 75 |
| 3 Speed | rpm: | |
| Delivery per 1000 shots | cm ³ : | |
| | cm ³ : | |

19 - POTENTIOMETER CALIBRATION AND CHECKING

| | | |
|------------------------------|-------------------|--|
| Supply | volt: | |
| Setting | | |
| Speed | rpm: | |
| Delivery per 1000 shots | cm ³ : | |
| Potentiometer output voltage | volt: | |
| Checking: | | |
| Speed | rpm: | |
| Delivery per 1000 shots | cm ³ : | |
| Potentiometer output voltage | volt: | |

20 - EGR MICROSWITCH CALIBRATION

| | | |
|-------------------------|-------------------|--|
| Speed | rpm: | |
| Overcharging pressure | hPa: | |
| Delivery per 1000 shots | cm ³ : | |

21 - GLOW PLUG MICROSWITCH ADJUSTMENT

Contact closed at:
control lever travel
of injection pump
of injection

22 - CUT-OUT ELECTROMAGNET

| | | |
|---------------------------|-------|----|
| Operating minimum voltage | volt: | 10 |
| Rated voltage | volt: | 12 |

23 - ASSEMBLING AND ADJUSTING DIMENSIONS

| | | |
|---------------|-----|------------|
| Denomination: | | |
| K | mm: | 3.6 |
| MS | mm: | 0.9 |
| Ya | mm: | 34.0 ± 1.0 |
| Yb | mm: | 47.0 ± 3.0 |



| | | |
|--------------------------|-----|-----------|
| Devices | | |
| LDA STROKE | mm: | 5.2 + 0.2 |
| KSB LEVER | : | |
| KSB ADVANCE | mm: | 5.71 |
| KSB ADVANCE A.P. DEGREES | : | 2.0 |

| | | |
|---|---------------------------------|--------------------|
| IVECO ENGINEERING | No.500347285 | Edit. I |
| INJECTION ROTARY PUMP TEST VALUES | | |
| <p>REMARKS:</p> <ol style="list-style-type: none"> 1) References for which no letters or numbers are given are reserved for other injection pump designs. 2) For a correct adjustment of injection pumps on the electric bench, conform to the manual IVECO Technical Publications and Training No. XXXXXXXXXXXX 3) Measurements taken on injection pumps equipped with "KSB" must be performed with the same at rest. 4) (*) LDA adjusting point: act on spring pre-loading ring. 5) After every variation of LDA pressure, act on the control lever. 6) For adjusting the starting point (ARF valve) add a 12.0 mm spacer to the third delivery stop. | | |
| NOTES: BOSCH SHEET ED. 3 DTD. 10.07.98 | C . I . D . I-114734-006-085 | DATE 17-11-1998 |

Sheet 4/4

COLD INJECTION ADVANCE AUTOMATIC DEVICE (KSB) [KALT START BETRIEBSEINRICHTUNG]

Figure 20



1. Wax thermal bulb - 2. Control lever - 3. Flexible connecting cable - 4. Eccentric pin - 5. Roll-carrier ring - 6. Advance changer piston - a. Lever position (2) in cold start condition - b. Lever position (2) in normal operating condition.

Description

Rotary injection pumps, with mechanical speed governor, that are fitted on the engines dealt with in this publication, are equipped with a cold injection advance automatic device (KSB). This tool has the purpose of setting the injection advance, below a given temperature, to a greater value than that static one of pump fitting to the engine, and to reset it by degrees to the value of this latter, as temperature rises.

Operation

KSB cold injection advance automatic device is a mechanical type electric drive tool that mainly consists of a wax thermal bulb (1) that acts on the advance changer control lever (2), through a pushing rod and a connecting cable (3).

When starting a cold engine, the thermal bulb (1) pushing rod, that operates on the connecting cable (3), is placed at back position; consequently the lever (2) is kept in position "a".

In this condition the eccentric pin (4) (which is operated by the lever (2)), changes the position of roll carrier ring (5) with respect to its normal position and, in its turn, it causes piston (6) to move, thus producing an increase of advance with respect to the value of fitting static advance.

At engine start the resistance existing in the thermal bulb (1) is supplied by alternator D⁺.

The heat generated by the flow of current, heats the wax that expands and causes pushing rod to come out, resetting the lever (2) to position "b" by degrees.

In this way the extra advance is cancelled, since the parts of advance changer come back to their normal operating position.

The full cut-out of KSB device is achieved after about 3-4 minutes of operation.

NOTE The check and adjustment, if required, of KSB tool is carried out with the injection pump placed on a test bench.

Coolant temperature values for KSB heat bulb connection

Engine 8140.43C:

- connection at 45°C ± 2°C
- disconnection at 30°C ± 2°C

Engines 8140.63 - 8140.43S

- at altitudes < 1000m:
 - connection at 25°C ± 3°C
 - disconnection at 20°C ± 3°C
- at altitudes > 1000m:
 - connection at 55°C ± 4°C
 - disconnection at 50°C ± 4°C


5401 Engine 8140.63.40XX

| | Page |
|---|------|
| EMISSIONS VALUES | 251 |
| <input type="checkbox"/> Gas emissions | 251 |
| <input type="checkbox"/> Smokiness | 251 |
| <input type="checkbox"/> Noise emissions | 251 |
| GENERAL SPECIFICATIONS | 252 |
| ASSEMBLY DATA - CLEARANCES | 255 |
| TIGHTENING TORQUES | 261 |
| TOOLS | 262 |
| 8140.63 ENGINE OVERHAUL | 265 |
| <input type="checkbox"/> Disassemblt engine on bench | 265 |
| PISTONS - PINS - SNAP RINGS | 268 |
| <input type="checkbox"/> Assembling connecting rod-piston assembly . . . | 269 |
| <input type="checkbox"/> Fitting connecting rods-pistons | 269 |
| CYLINDER HEADS | 269 |
| CAMSHAFT | 269 |
| <input type="checkbox"/> Checking cam lift and journal alignment | 269 |
| <input type="checkbox"/> Checking cylinder head mating surface | 270 |
| PRECOMBUSTION CHAMBERS | 271 |
| <input type="checkbox"/> Disassembly | 271 |
| <input type="checkbox"/> Assembly | 271 |
| GLOW PLUGS | 272 |
| <input type="checkbox"/> Disassembly | 272 |
| <input type="checkbox"/> Checking glow plugs continuity | 272 |
| <input type="checkbox"/> Assembly | 272 |
| LUBRICATION | 272 |
| <input type="checkbox"/> Heat exchanger | 272 |
| <input type="checkbox"/> Oil vapour full recirculation system (Blow-by) . | 273 |

| | Page |
|--|------|
| COOLING SYSTEM | 274 |
| <input type="checkbox"/> Thermostat | 274 |
| EXHAUST GAS RECIRCULATION SYSTEM E.G.R. | 275 |
| <input type="checkbox"/> General Information | 275 |
| <input type="checkbox"/> Operation | 275 |
| <input type="checkbox"/> Modulating solenoid valve | 277 |
| <input type="checkbox"/> Potentiometer on injection pump lever | 277 |
| <input type="checkbox"/> Engine rpm sensor | 277 |
| <input type="checkbox"/> Engine coolant temperature sensor | 278 |
| <input type="checkbox"/> Absolute pressure sensor | 278 |
| <input type="checkbox"/> Vacuum sensor | 278 |
| <input type="checkbox"/> Electronic control unit | 278 |
| OPERATION LOGICS | 279 |
| <input type="checkbox"/> Air conditioner interface operation logic | 279 |
| <input type="checkbox"/> Pre-Post Heating Operating Logic | 279 |
| <input type="checkbox"/> Engine Cooling Fan Operating Logic | 279 |
| <input type="checkbox"/> KSB Operating Logic | 279 |
| FEEDING | 281 |

EMISSIONS VALUES

Figure 21



52182

Gas emissions

Engine 8140.63 conforms with the ECE 96/69 standard (measurement with vehicle on roller test bench according to ECE + EUDC cycle), with the following limits:

- CO (carbon monoxide) < 1.36 g/km
- HC+NO_x (hydrocarbons + nitrogen oxide) < 1.20 g/km
- Particulate < 0.14 g/km

Test conditions: assigned coast-down 12.7 kW at 80 km/h. Reference weight of vehicle 2270 kg, vehicle equipped with EGR system and oxidation catalyst:

- Degussa 1.5 l-300 cpsl-V50-2g Pt
- Kemira 1.5 l-300 cpsl-7007-1g Pt

Test fuel: CEC RFT 73 - T - 90 - S ≤ 0.05 %.

Smokiness

Engine 8140.63 conforms with the limits of smokiness required by EEC standards 72/306 and R 24-03 with the following exhaust smokiness values:















- Maximum power (Bosch BSU opacimeter degrees) 2.0
- Maximum torque (Bosch BSU opacimeter degrees) 3.5
- Full load at 1000 rpm (Bosch BSU opacimeter degrees) 3.5

Noise emissions

Maximum mean noise level, L_{pa}, of the standard engines measured according to ISO Std. 3745 (microphones at 1 m from the engine surfaces):

- Idling (800 rpm) dB A 79
- Full power (3800 rpm) dB A 99

GENERAL SPECIFICATIONS





| | | | |
|---|---|---|------------------------------------|
|  | Type | | 8140.63.4.. PC/NA |
|  | Cycle | | Diesel 4 strokes |
| | Feeding | | Aspirated |
| | Injection | | Indirect |
|  | No. of cylinders | | 4 on-line |
|  | Diameter | mm | 94.4 |
|  | Stroke | mm | 100 |
|  | Total displacement cm ³ | | 2800 |
|  | Compression ratio | | 21.7 ± 0.5 |
|  | Max. power | kW (HP) | 58 ÷ 62 (78.9 ÷ 84.3) |
| | |  rpm | 3800 |
|  | Max. torque | Nm (kgm) | 179 18.2 |
| | |  rpm | 2000 |
|  | Engine idling speed, no load | rpm | 800 ± 25 |
|  | Maximum engine speed, no load | rpm | 4400 ± 25 |
|  | Pressure at T.D.C. | *bar | 20 ÷ 26 |
| | Minimum permissible pressure at T.D.C. | *bar | 16 |

(*) The pressure value is recorded by turning the engine over with the electric starter motor, with oil temperature at 40°- 50°C and the injection pump in the stop condition.















ID = Direct injection
 NA = Aspirated
 PC = Indirect injection (pre-chamber)
 TCA = Supercharging with intercooler













| | | |
|--|---|---|
| | <p>Type</p> | <p>8140.63.4.. PC/NA</p> |
| | <p>VALVE TIMING</p> <p>opens before T.D.C. A</p> <p>closes after B.D.C. B</p> <p>opens before B.D.C. D</p> <p>closes after T.D.C. C</p> | <p>8°</p> <p>48°</p> <p>48°</p> <p>8°</p> |
| | <p>For timing check</p> <p>Running</p> <p>X mm</p> <p>X mm</p> <p>X mm</p> <p>X mm</p> | <p>0.5 ± 0.05</p> <p>0.5 ± 0.05</p> <p>0.5 ± 0.05</p> <p>0.5 ± 0.05</p> |
| | <p>FUEL SUPPLY</p> <p>Bosch type injection pump</p> <p>Speed governor</p> <p>Cold start</p> | <p>rotating distributor</p> <p>VER 808 - 2 (with immobilizer)</p> <p>min. and max.</p> <p>K.S.B. electrical, mechanical</p> |
| | <p>Pump arrangement</p> <p>With piston n. 1 at T.D.C.</p> <p>Start of delivery mm</p> | <p>0.94 ± 0.05</p> |
| | <p>BOSCH injector nozzle type</p> | <p>KGM DNO</p> <p>SACLESS</p> |
| | <p>Injection order</p> <p>- injection pump</p> <p>- engine</p> | <p>A - B - C - D</p> <p>1 - 3 - 4 - 2</p> |
| | <p>Injection pressure bar</p> | <p>130 + 8</p> |

* When checking, for any values of less than 200 bars, calibrate the injectors at 230 + 8 bar.


















|  | Type | 8140.63.4.. PC/NA |
|---|--|---|
|  | LUBRICATION | Forced feed by gear pump, relief valve, dual action oil filter |
|  | Oil pressure, engine hot at idling speed bar at maximum speed bar | ≥ 0.8 ≥ 3.5 |
| COOLING | Thermostat: starts to open: fully open: | With a centrifuge pump, driven by the crankshaft via a poly-V belt, thermostat for adjustment, fan with electro-magnetic clutch, radiator. 79° C ± 2° C 110° C |
|  | OIL REPLENISHMENT Total capacity at 1st filling liters kg | 6.9 6.1 |
| Urania Daily Urania Turbo Urania LD 5 | Quantity at periodical replacements: - engine sump liters kg | 5.2 4.6 |
| | - engine sump liters kg | 6.3 5.7 |













ASSEMBLY DATA - CLEARANCES

|  | Type | 8140.63.4.. PC/NA | |
|--|--|---|--|
| CYLINDER BLOCK AND CRANK MECHANISM COMPONENTS | | | |
|  | Bores for cylinder liners $\varnothing 1$ | $\varnothing 1$ | 97.39 ÷ 97.45* |
|  | Cylinder liners: outside diameter $\varnothing 2$ length L | $\varnothing 2$ L | ** 97.47 ÷ 97.50 167.00 ÷ 167.30 |
|  | Cylinder liners - crankcase bores (negative allowance) | | 0.02 ÷ 0.11 |
|  | Outside diameter $\varnothing 2$ | | 0.2 |
|  | Cylinder barrels: (protrusion from engine block bottom) inside diameter $\varnothing 3$ | $\varnothing 3$ $\varnothing 3$ | 0.005 max 94.402 ÷ 94.432 |
|  | Pistons: supplied as spare parts type: measuring dimension X outside diameter $\varnothing 1$ pin bore $\varnothing 2$ | X $\varnothing 1$ $\varnothing 2$ | MONDIAL PISTON 13 94.306 ÷ 94.320 32.000 ÷ 32.005 |
|  | Piston - cylinder sleeve | | 0.082 ÷ 0.126 |
|  | Pistons: supplied as spare parts type: measuring dimension X outside diameter $\varnothing 1$ pin bore $\varnothing 2$ | X $\varnothing 1$ $\varnothing 2$ | AE GOETZE 13 94.306 ÷ 94.320 32.000 ÷ 32.005 |
|  | Piston - cylinder sleeve | | 0.082 ÷ 0.126 |
|  | Piston diameter $\varnothing 1$ | $\varnothing 1$ | 0.4 |
|  | Pistons protrusion X | X | 0.75 ÷ 1.15 |
|  | Gudgeon pin $\varnothing 3$ | $\varnothing 3$ | 31.990 ÷ 31.996 |
|  | Gudgeon pin - pin housing | | 0.004 ÷ 0.015 |
| * Diameter to be obtained at servicing when fitting spare cylinder barrels. ** Supplied as spare parts. | | | |

| | | | |
|---|---|---|---|
|  | Type | 8140.63.4.. PC/NA | |
|  | Piston type | MONDIAL PISTON/AE GOETZE | |
| | Piston ring grooves | X1* X2 X3 | 2.685 ÷ 2.715 2.050 ÷ 2.070 2.540 ÷ 2.560 |
| | * measured on \varnothing of 91.4 mm | | |
|  | Piston rings | S 1* S 2 S 3 | 2.568 ÷ 2.597 1.970 ÷ 1.995 2.470 ÷ 2.490 |
| | * measured on \varnothing of 91.4 mm | | |
|  | Piston rings - grooves | 1 2 3 | 0.088 ÷ 0.147 0.55 ÷ 0.100 0.05 ÷ 0.09 |
|  | Piston rings | | 0.4 |
|  | Piston ring end gap in cylinder liners | X1 X2 X3 X1 X2 X3 | 0.20 ÷ 0.35 0.30 ÷ 0.50 0.30 ÷ 0.55 |
|  | Small end bush housing | \varnothing 1 | 35.460 ÷ 35.490 |
| | Big end bearing housing * | \varnothing 2 | 60.341 ÷ 60.348 |
| | * spare connecting rod supplied | | |
|  | Small end bush diameter | outside \varnothing 4 inside \varnothing 3 | 35.570 ÷ 35.595 32.010 ÷ 32.020 |
|  | Big end bearing shell supplied as spare parts | S | 1.875 ÷ 1.884 |
|  | Small end bush - housing | | 0.08 ÷ 0.135 |
|  | Piston pin - bush | | 0.014 ÷ 0.03 |
|  | Piston rings | | 0.254 ÷ 0.508 |

| | | |
|---|--|---|
| | <p>Type</p> | <p>8140.63.4.. PC/NA</p> |
| <p>CYLINDER HEADS - VALVE GEAR</p> | | |
| | <p>Valve guide housings in the cylinder heads</p> | <p>12.950 ÷ 12.985</p> |
| | <p>Valve guide</p> | <p>8.023 ÷ 8.038 13.012 ÷ 13.025</p> |
| | <p>Valve guides and housings in the cylinder heads</p> | <p>0.027 ÷ 0.075</p> |
| | <p>Valve guide</p> | <p>0.05 - 0.10 - 0.2</p> |
| | <p>Valves:</p> | <p>7.985 ÷ 8.000 60° 15' ± 7' 30"</p> <p>7.985 ÷ 8.000 45° 30' ± 7' 30"</p> |
| | <p>Valve stem and its guide</p> | <p>0.023 ÷ 0.053</p> |
| | <p>Housing in head for valve seat</p> | <p>44.025 ÷ 44.075 37.380 ÷ 37.415</p> |
| | <p>Outside diameter of valve seat; angle of valve seat in cylinder head:</p> | <p>44.145 ÷ 44.160 60° ± 5'</p> <p>37.495 ÷ 37.510 45° ± 5'</p> |
| | <p>Recessing of valve X</p> | <p>1.15 ÷ 1.45 1.0 ÷ 1.3</p> |

|  | Type | 8140.63.4.. PC/NA | |
|---|---|---|------------------------------------|
| CYLINDER BLOCK AND CRANK MECHANISM COMPONENTS | | | |
|  | Measuring dimension | X | 125 |
|  | Max. connecting rod axis misalignment tolerance | = | 0.07 |
|  | Main journals n° 1 - 2 - 3 - 4 n° 5 | Ø 1 | 80.182 ÷ 80.208 86.182 ÷ 86.208 |
|  | Crankpins Main bearing shells | Ø 2 | 56.515 ÷ 56.538 |
|  | Big end bearing shells | S1* | 2.165 ÷ 2.174 |
|  | * supplied as spare parts | S2* | 1.875 ÷ 1.884 |
|  | Main bearings n° 1 - 2 - 3 - 4 n° 5 | Ø 3 | 84.588 ÷ 84.614 90.588 ÷ 90.614 |
|  | Bearing shells - main journals | | 0.032 ÷ 0.102 |
|  | Bearing shells - big ends | | 0.035 ÷ 0.083 |
|  | Main bearing shells |  | 0.254 ÷ 0.508 |
|  | Big end bearing shells | < | 0.254 ÷ 0.508 |
|  | Main journal, thrust bearing | X 1 | 31.000 ÷ 31.100 |
|  | Main bearing housing, thrust bearing | X 2 | 26.500 ÷ 26.550 |
|  | Thrust washer halves | X 3 | 30.900 ÷ 30.950 |
|  | Crankshaft end float | | 0.060 ÷ 0.310 |

| | | |
|---|--|--|
|  | <p>Type</p> | <p>8140.63.4.. PC/NA</p> |
| <p>CYLINDER HEADS - VALVE GEAR</p> | | |
|  | <p>Between valve seat and head</p> | <p>0.070 ÷ 0.145</p> |
|  | | <p>0.080 ÷ 0.130</p> |
|  |  | <p>Valve seats</p> |
|  | <p>Valve outside spring height: free height H under a load of: kg 43.8 ± 2.5 H1 kg 77.4 ± 4 H2</p> | <p>52 38.5 28.5</p> |
|  | <p>Valve inside spring height: free height H under a load of: kg 16.4 ± 1 H1 kg 30 ± 1.5 H2</p> | <p>45.5 33.5 23.5</p> |
|  | <p>Height of precombustion chamber plug base seat X Precombustion chamber plug seat Ø</p> | <p>5.348 ÷ 5.373 5.373 ÷ 5.398 5.398 ÷ 5.423 32.490 ÷ 32.540</p> |
|  | <p>Precombustion chamber plug Ø S A Green B - C Yellow</p> | <p>32.550 ÷ 32.570 5.373 ÷ 5.397 5.398 ÷ 5.422 5.423 ÷ 5.447</p> |
|  | <p>Precombustion chamber plug - Cylinder heads</p> | <p>0.010 ÷ 0.080</p> |
|  | <p>Precombustion chamber position from cylinders heads level surface X</p> | <p>-0.000 ÷ +0.049</p> |
|  | <p>Injector protrusion X</p> | <p>-</p> |

| | | |
|------------------------------------|--|---|
| | Type | 8140.63.4. PC/NA |
| CYLINDER HEADS - VALVE GEAR | | |
| | Camshaft bearing housing normal \emptyset oversized \emptyset | 33.985 ÷ 34.015 34.185 ÷ 34.215 |
| | Camshaft bearing journals normal \emptyset oversized \emptyset | 33.934 ÷ 33.950 34.134 ÷ 34.150 |
| | Between seats and supporting pins | 0.035 ÷ 0.081 |
| | Tappets housing on cylinder heads \emptyset normal | 44.000 ÷ 44.025 |
| | Tappet \emptyset normal | 43.950 ÷ 43.970 |
| | Between tappets and seats | 0.030 ÷ 0.075 |
| | Cap | 3.25 to 4.45 mm with a progression of 0.05 |
| | Cam lift: | 10.5 |
| | H H | 10.5 |

TIGHTENING TORQUES

NOTE This differs from the analogous section for the 8140.43C engine in the following tightening torques.


| PART | TORQUE | |
|--|---------|------------|
| | Nm | kgm |
| Nut M12x1.5 fixing toothed bushing to the injection pump | 55 | 5.5 |
| Fixing incandescent glow plugs | 25 | 2.5 |
| Nut fixing electric cable to the glow plug | 1.5 ÷ 2 | 0.15 ÷ 0.2 |
| Injector fastening | 60 | 6 |

TOOLS

NOTE This differs from the analogous section for the 8140.43C engine in the exclusion of tools 99360486 - 99367121 - 99394038 - 99395098 and the addition of the following tools.


TOOL NO.

DESCRIPTION

99360498

Cylinder compression test coupling
(use with 99395682)


Figure 22



52180

8140.63.4... ENGINE LONGITUDINAL SECTION

Figure 23



8140.63.4... ENGINE TRANSVERSE SECTION


52181

8140.63 ENGINE OVERHAUL

NOTE This differs from overhauling engine 8140.43.C in the following.

Disassembly engine on bench

Figure 24




To be able to apply the brackets 99361029 to the crankcase for securing the engine to the stand for overhauling, it is necessary:

on the left-hand side of the engine:

- to disconnect the pipe (3) from the heat exchanger (4);
- to disconnect the pipe (7) from the side cover (6);
- to take out the screws (5 and 9) and remove the pipe (10) complete with pipes (3 and 7);
- to disconnect the pipe (11) from the crankcase fitting;
- to disconnect the pipe (2) from the fillpipe (1);
- to remove the oil vapour condenser (8) complete with pipes (2 - 10 - 11).

Figure 25




On the right-hand side, take the plug out of the crankcase to be able to screw down the screw (3) fixing the bracket 99361029 (1) and to mount this bracket.

Mount the other bracket on the left-hand side of the crankcase and secure them to the rotary stand 99322230 (2).


Take the plug out of the oil sump (4) and drain off the lubricating oil.

Figure 26




Take out the screw (3) fixing the bracket (4) securing the pipes (1 and 2) to the intake manifold (5). Disconnect the pipe (2) from the cylinder head. Take out the nuts (6) securing the pipe (1) to the water pump (7).

Figure 27




Disconnect the pipe (4) from the heat exchanger (3). Take out the screws (1 and 5) and remove the pipe (2) from the crankcase complete with pipes (4) and pipes (1, Figure 26).

Figure 28



Take out the nuts (5) for the screws (4) and disconnect the EGR valve (3) from the sleeve (6). Remove the intake manifold (1) and exhaust manifold (2) from the cylinder head.


Figure 29



Lift the clips (1) and remove the side soundproofing guard (2).

Take out the nuts (3) and remove the top soundproofing guard (4).


Figure 30



Remove the fuel pipes (1) from the injection pump (3) and from the injectors (2).

Remove the fuel recovery pipes (4) from the injectors (2).

Figure 31




Take out the nuts (4) and disconnect the electric cable (5) from the glow plugs (6).

Unscrew and remove the injectors (1).

Take out the screws (2) and remove the guard (3).

Figure 32




Remove the tappet cover (6) with its relative gasket.

Take out the screw (2) and remove the fillpipe (1) from the auxiliary member assembly (5).

Take out the screw (3) and extract the oil dipstick pipe (4) from the crankcase base.

Figure 33




Mark (⇒) the position of assembly of the injection pump (3) on the auxiliary member assembly (1).

Take out the fixing nuts (2) and remove the injection pump (3) from the auxiliary member assembly (1).


NOTE To remove the lower fixing nut on the crankcase side, use wrench 99352114 (4).

Figure 34




Using the right wrench on the tightener (2), slacken the tension of the belt (1) and remove it.

Figure 35




Using tool 99360306 (3) applied as illustrated in the figure, block crankshaft rotation and loosen the screws fixing (1) the flywheel (2).

Figure 36




Remove the screw fixing the pulley (1) to the crankshaft. Remove the pulley (1) from the crankshaft and the spacer, if any.

Figure 37



Loosen the screws fixing the gears (1 - 7). Insert a special wrench between (5) the push rod (3) and the cylinder (4) of the tightener. Take out the nut (2). Remove the bottom cover (6). Remove the cogged belt (8).


Figure 38



Remove the fixed tightener mounting (2) and the guard (3) beneath. Remove the screws fixing the thermostat box (1). Block rotation of the electromagnetic pulley. Unscrew the nut (6) securing the hub (4) clockwise. Remove the hub (4) and the washer (5).

NOTE The hub fastening nut (6) has a left-hand thread.


Figure 39



52217

Remove the key (1) and washer (3) from the water pump shaft (2).
 Remove the pulley (10) from the water pump shaft (2).
 Take out the nuts (8) and extract the electromagnetic coupling (9).
 Remove the mounting (5) complete with alternator (4) from the crankcase and from the water pump (2), complete with thermostat box (7).
 Remove the adjustable tightener (6).
 Remove the front cover (11) of the crankshaft.

Figure 40




52218

Remove the screws (2) fixing the cylinder head (1) and remove this with the gasket from the crankcase.

NOTE Check piston protrusion as described in the relevant paragraph to verify the possibility of crankcase flattening in case it is deformed.

Figure 41

PISTONS - PINS - SNAP RINGS




62083

MAIN DATA OF MONDIAL PISTONS FEDERAL MOGUL, PINS AND RINGS OF THE 8140.63... ENGINE

* This dimension is measured on the diameter of 91.4 mm.

Assembling connecting rod-piston assembly
Fitting connecting rods-pistons

Figure 42




45069

On the crown of the piston, reference (1) indicates the type of engine (7), class selection (A) and supplier (X)*; reference (2) has an adhesive label (on the piston supplied as a spare) with the code number for optical reading of the type of engine and class selection; reference (3); piston crown cavity.

- * X = Federal MOGUL
- Y = MONDIAL PISTON

Figure 43



62385


Fit piston (1) to connecting rod (2) so as piston assembly reference and connecting rod numbers (3) can be seen as shown in the figure.

560610 CYLINDER HEADS

541210 CAMSHAFT

541211 Checking cam lift and journal alignment


Figure 44



61795

Set shaft on centres and check, with a centesimal dial gauge placed on central support, that alignment error is no greater than 0.04 mm, otherwise replace shaft. Also check cams (1) lift: it should be 10.5 mm; if different values are found replace the shaft.


Figure 45



62084


DIAGRAM OPENING-CLOSING VALVE

Figure 46



49074

Figure 49




49076

SECTION F-F

1. Glow plug - 2. Injector seat - 3. Combustion prechamber plug

Figure 47




49075

MAIN DATA - VALVE SEATS

Checking cylinder head mating surface

Figure 48



18879


The check of mating surface of the head (1) to cylinder group is performed by means of a rule (2) and a thickness gauge (3). If a deformation is found, measure cylinder head thickness, whose rated value is 150 ± 0.1 mm.

When checking, if the amount of material to be removed for flattening cylinder head is greater than 0.4 mm, replace cylinder head.

If the amount of material to be removed is within 0.2 mm there is no need to dismantle combustion prechamber plugs, otherwise proceed as stated in the following figure.

PRECOMBUSTION CHAMBERS Disassembly

Figure 50




52219

Number the pre-combustion chambers (3) in order to refit them in the same order of disassembly and remove them from the cylinder head (1) taking special care with a suitable punch (2).

Assembly

Figure 51




41802

Precombustion chambers (1) are subdivided into classes according to base thickness X and selected as follows:

| Class | X mm |
|-------|---------------|
| A | 4.500 ÷ 4.520 |
| B | 4.520 ÷ 4.540 |
| C | 4.540 ÷ 4.560 |

Should it be required to replace one or more precombustion chambers (1) (being not necessary to regrind respective seats on cylinder heads), measure thickness X of their base to fit the new part of same class and in the same order found upon dismantling.

Figure 52




41803

After cylinder heads regrinding, with material removal of more than 0.2 mm thickness, measure with dial gauge (1) the depth Y of pre-combustion chamber seats.

According to the class of the pre-combustion chambers, shown in the previous figure, restore depth Y of respective seats, to the corresponding classes listed here below:

| Class | depth Y mm |
|-------|---------------|
| A | 4.480 ÷ 4.505 |
| B | 4.505 ÷ 4.530 |
| C | 4.530 ÷ 4.555 |

Figure 53




52189

Precombustion chamber (1) plugs driving is carried out with tool 99360356 (2), making their centring balls (←) coincide with the milling (→) of relevant seat on cylinder heads.

GLOW PLUGS Disassembly

Figure 54




52220

Remove glow plugs (1) from cylinder heads.

Checking glow plugs continuity

Figure 55



41807


Check the efficiency of each single glow plug (2) by connecting the two tester terminals (1) to glow plug terminals and verify its continuity, otherwise replace glow plug.

Assembly

Fit incandescence plugs to the cylinder head and tighten them to a torque of $15 \pm 1 \text{ Nm}$ ($1.5 \pm 0,1 \text{ kgm}$).

NOTE Re-check continuity after fitting glow plugs, since deforming effect, due to assembly pressure, may cause the interruption of said continuity

Figure 56




52222

Screw the injectors (1) into the cylinder head and, with the right wrench, tighten them to the required torque. Fit the glow plugs (2) and electric cable (4), and tighten the fixing nuts (3) to the required torque.

LUBRICATION

543110 Heat exchanger

Figure 57



50681

10-element heat exchanger


On supplying heat exchanger (1) with air at 1 bar pressure, verify that no leaks exist from oil flow side (2) and also from water flow side.

Test conditions:

| | |
|---|------------------------------|
| Oil type | SAE 30 |
| Oil temperature at heat exchanger inlet | 115°C |
| Oil delivery | 30 litres/minute |
| Water temperature at heat exchanger inlet | 85°C |
| Water delivery | 20 litres/minute |
| PERFORMANCE | |
| Exchanged heat quantity | 5.0 kW |
| Oil pressure drop | 0.85 bar |
| Built-in safety valve (2) | |
| Opening pressure | $0.82 \pm 1.03 \text{ bars}$ |

540480 Oil vapour full recirculation system (Blow-by)

Figure 58



52614

OIL VAPOUR FULL RÉCIRCULATION SYSTEM DIAGRAM (8140.63 engine)
 1. Suction conveyer - 2. Flow relief valve - 3. Delivery pipe - 4. Oil vapour outlet pipe -
 5. Oil vapour condenser - 6. Oil drainage pipe - 7. Crankcase

The vapours that develop in the sump during engine operation, are collected in a condenser (5).


A portion of such vapours condense and, through pipe (6), return in the sump, while the remaining portion, through pipe (3) is sucked by engine and burnt.

The flow of vapours sucked by engine, is controlled by a relief valve (2).

This valve, applied on pipe (3) in proximity to suction conveyer (1), limits the flow of vapours, by choking flowing section according to the vacuum existing in suction pipe. In this way most of the vapours will return in the sump.

5432 COOLING SYSTEM
543250 Thermostat

Figure 59



A. Stroke start $79^{\circ}\text{C} \pm 2^{\circ}\text{C}$.

B. Stroke at $94^{\circ}\text{C} \geq 7\text{ mm}$
 Stroke at $110^{\circ}\text{C} \leq 10.5\text{ mm}$
 7 mm stroke in $< 60''$

Water blow-by with thermostat closed and valve closed
 $\leq 2\text{ l/h}$

7 mm stroke shall take place in $\leq 60\text{ seconds}$

Coolant temperature for:

- turning on the fan: $94^{\circ} \pm 2^{\circ}\text{C}$;
- turning off the fan: $80^{\circ} \pm 2^{\circ}\text{C}$.

EXHAUST GAS RECIRCULATION SYSTEM E.G.R.

General Information

The system recirculates a portion (max. 30%) of the exhaust gas from the exhaust manifold to the intake manifold of the engine according to characteristics that are permanently stored in the system's electronic control unit.

Recirculation of gas at the intake is only permissible at low loads where the air/fuel ratio is definitely high.

Exhaust gas recirculation is applied solely to permit the engine/vehicle to observe the gas emission limits of nitrogen oxide (NO_x).

Exhaust gas recirculation permits a reduction of as much as 40% of the quantity of nitrogen oxides emitted by the engine against virtually negligible increases in hydrocarbons and particulate.

This is due to an effect of the combustion reaction slowing down due to there being inert gases instead of oxygen, with an according decrease in the maximum temperature of the gas cycle on which the formation of nitrogen oxides closely depends.

Besides the difference in combustion, there is an additional effect of the reduction in the flow rate of gases leaving the vehicle exhaust from which the flow of recirculated gas is taken away.

Operation (see Figure 60)


The electronic control unit (7) processes the information from the atmospheric pressure sensor (2), water temperature sensor (3), engine speed sensor (4), potentiometer on the injection pump control lever (5) and, as programmed in its memory, it uses a PWM signal to control the modulating solenoid valve (7).

This command sets circuits (a) and (b) in communication inside the solenoid valve, modulating a variable vacuum in circuit (b) according to the strength of the command issued by the control unit.

This lower pressure acts on the diaphragm of the EGR pneumatic valve (10) calling up and lifting the shutter that normally closes the passage of exhaust gas toward the intake.


In this way, communication is opened between the exhaust and intake manifolds and the percentage of exhaust gas calculated by the control unit flows into the intake manifold.

Figure 60



75994

- 1. Bitron electronic control unit - 2. Atmospheric pressure sensor - 3. Water temperature sensor - 4. Engine speed sensor
- 5. Potentiometer on injection pump control lever - 6. Vacuum chamber - 6. Air filter - 7. Modulating solenoid valve -
- 8. Servo brake - 9. Vacuum - 10. EGR pneumatic valve - 11. Vacuum tank.



A closed-circuit feedback check is assured by the vacuum sensor inside the control unit that measures the modulated vacuum in the circuit (b). If different from the set value (within certain parameters), the control signal to the solenoid valve is appropriately modified to achieve the calculated vacuum.


In the engine phases that do not require gas recirculation (starting, cold engine, idling, load required, high levels), the control signal of the control unit (1) to the modulating solenoid valve (7) is cancelled. The solenoid valve closes the connection between the implementing circuit (b) and the vacuum circuit (a) while restoring atmospheric pressure in the circuit (b) with the air coming out of the filter (6) of the modulating solenoid valve (7).

The quantity of recirculated gas is adjusted by a poppet valve controlled pneumatically by low pressure taken, via a fitting with a calibrated cross-section, from the pipe connecting the vacuum device to the servo brake.

The governing modulated vacuum from the solenoid valve (7) will reach the pipe (B) and, overcoming the force of the spring, will lift the diaphragm connected to the shutter that will move upwards and permit exhaust gas recirculation towards the intake manifold.

System components EGR pneumatic valve

Figure 61




1. PIPE - 2. DIAPHRAGM - 3. SHUTTER

The quantity of recirculated gas is adjusted by a poppet valve controlled pneumatically by low pressure taken, via a fitting with a calibrated cross-section, from the pipe connecting the vacuum device to the servo brake.

The governing modulated vacuum from the solenoid valve will reach the pipe (1) and, overcoming the force of the spring, will lift the diaphragm (2) connected to the shutter (3) that will move upwards and permit exhaust gas recirculation towards the intake manifold.

Modulating solenoid valve

Figure 62



This is a proportional solenoid valve connected on one side to servobrake vacuum circuit (typical ratings 600 mm Hg) and on other it makes it possible to modulate a vacuum variable between 30 and 3,000 mm Hg depending on the command signal generated by electronic control unit.

It is connected to the control unit on pin 19.

It is supplied with a $0 \div 12$ V signal at a fixed frequency of 140 Hz (duty-cycle). Duty cycle means the ratio between the time the signal is "ON" and the total period of the cycle (1/140 Hz). The vacuum modulated by the solenoid valve depends only on the duty cycle.


Supplying the solenoid (1), the core (2) attracts the mobile plate (3) towards it which obstructs the passage of atmospheric pressure (A) to the chamber (B).

Vacuum is created in chamber (B) the mobile, equipment (4) rises allowing connection between the vacuum source (F) and the outgoing vacuum (E).

When the solenoid valve is not supplied, there will only be atmospheric pressure at the outlet as the mobile pressure (3) falls, atmospheric pressure reaches chamber (B), mobile equipment (4) moves down, valve (5) blocks the inlet of the vacuum source (F) and atmospheric pressure (C) and control pressure (B) communicate with the outlet vacuum (E) through hole (D).

Potentiometer on injection pump lever

Figure 63



Potentiometer (1) is set on injection pump control lever. Since control unit cannot read exactly the load acting on engine instantaneously, it reads injection pump lever position that is an indication of fuel introduction and therefore of load.


It is supplied with a voltage of 5 V.

It is connected to the control unit on pins 3 - 9 - 11.

It supplies the control unit a signal between $0 \div 5$ V depending on the angle of rotation of the injection pump lever.

Engine rpm sensor

Figure 64



This is an inductive sensor (1) located on the engine flywheel.

It generates signals obtained by the magnetic flux lines which close through the four holes machined on the flywheel.


The electronic control unit uses this signal to detect the different engine speeds.

This signal is also sent to the instrument cluster on pin B2 to drive the electronic rev counter.

It is connected to the control unit on pins 8 - 17.

Engine coolant temperature sensor

Figure 65




This is an NTC sensor located in a boss of the thermostat body.

It detects the temperature of the water in the head and makes it possible to reduce E.G.R. below a temperature of 40 °C until shutting it off completely because when the engine is cold it would cause high smoke and difficulty in starting.

It is connected to the control unit on pins 2 - 11.

Absolute pressure sensor

Figure 66



Atmospheric pressure sensor (1), is set on engine compartment right side and detects atmospheric pressure value, thus enabling to reduce E.G.R. above 1,500 m altitude, since the oxygen reduction connected to air density reduction improves smokes in presence of E.G.R.


It is supplied at 5 V.

It is connected to the control unit on pins 9 - 10 - 11.

It supplies the control unit a signal of between 0 ÷ 5V depending on the environment pressure.

Vacuum sensor

Figure 67



62191

Modulated vacuum sensor (2) is set inside control unit and corrects any error and/or miscalibration of the different components to guarantee the proper vacuum value required by the system.

It also makes it possible to detect any malfunctioning of the E.G.R. system due to blowby or pneumatic failure of the modulating solenoid valve.

Electronic control unit

Control unit (1) is set on engine compartment right side and is connected to wiring by 25-pin connector.

It incorporates the vacuum sensor.

In addition to the E.G.R. it is capable of controlling the before-after heating function, the engine cooling fan electromagnetic joint, the KSB device and, where applicable, it is connected to the climate control unit.


E.G.R. operating logic.

Depending on the position of the injection pump lever, engine rpm, coolant fluid temperature and environment pressure, the control unit decided the re-circulation percentage to be activated and drives the modulating solenoid valve.

Through the vacuum sensor (2) it reads the "actual" vacuum modulated by the modulating solenoid valve, compares it with the theoretical one, and if the two values differ within determinate parameters, it makes the necessary corrections to control the modulating solenoid valve until reaching the required "actual" vacuum rating, otherwise, it does not take account of it and controls the solenoid valve without the reference signal.

OPERATION LOGICS

Figure 68



CONNECTIONS OF GLOW PLUG CONTROL RELAY

Air conditioner interface operation logic

EGR control unit controls air conditioning system compressor (load) relay connections and disconnection and obviously compressor activation or deactivation, at starting and according to engine coolant temperature, i.e. engine rpm and acceleration.

NOTE: With load ON, compressor is OFF
With load OFF, compressor is ON


Starting: at starting, EGR control unit activates compressor relay (NC). This load will be disconnected 6 ± 1 sec. after exceeding 700 ± 25 engine rpm, thus enabling if required, to activate compressor. Although engine rpm returns to lower values than threshold ones, load will no longer be connected until next engine starting.

Engine coolant temperature: load is activated at approx. 107°C and deactivated at approx. 101°C . Resistance values for EGR engine coolant temperature sensor are approx. 160Ω at 107°C and approx. 195Ω at 101°C .

Engine rpm: load is disconnected at ≥ 4000 rpm and connected at ≤ 4100 rpm.

Acceleration: load disconnects for approx. 100 m/sec. at > 2500 i.e. engine rpm.

Figure 69



BEFORE-AFTER WARMING DEVICE OPERATING GRAPH
A. WARMING ON AND WARNING LIGHT ON - B. WARMING TIME ON WITH WARNING LIGHT ON - C. DISTRACTION TIME - D. AFTER WARMING TIME - E. AFTER WARMING OFF AND WARNING LIGHT OFF

Pre-Post Heating Operating Logic

The control unit monitors pre-post heating as a function of the engine compartment temperature measured by a sensor located inside the control unit itself.

It activates the remote control switch controlling the plugs (this switch is positioned on the right side of the engine compartment) for a variable time as a function of the above temperature.

Engine Cooling Fan Operating Logic

The control unit can connect/disconnect the electromagnetic coupling of the fan depending on the cooling fluid temperature.

It connects it when $\sim 94^{\circ}\text{C}$ are reached and disconnects it at $\sim 76^{\circ}\text{C}$. (The temperature sensor resistance at these values is equal to $\sim 245\Omega$ at 94°C and $\sim 420\Omega$ at 76°C).

KSB Operating Logic

At approximately 1000 m, the EGR electronic control unit turns on, by activating the relevant remote control switch, the KSB advance variator when the engine cooling fluid temperature is equal to $\sim 25^{\circ}\text{C}$ and turns it off at $\sim 20^{\circ}\text{C}$.

The relevant resistance values of the engine cooling fluid temperature sensor are: $3\text{k}\Omega \pm 100\Omega$ at 25°C and $3.8\text{k}\Omega \pm 100\Omega$ at 20°C .

Instead, at an altitude of approximately 1100 m, the variator is activated at $\sim 55^{\circ}\text{C}$ and disconnected at $\sim 50^{\circ}\text{C}$. In this case the resistance values of the sensor are, respectively, $900 \pm 20\Omega$ and $1.08\text{k}\Omega \pm 20\Omega$.

Feeding

| | Page |
|--------------------------------------|------|
| INJECTION PUMP TEST VALUES | 283 |

NOTE The test and adjustment values indicated in the text and summary tables are given as a general indication.

INJECTION PUMP TEST VALUES

| | | | |
|--|--------------------|--|----------------------------------|
| IVECO ENGINEERING | | No. 500338906 | Edit. I |
| INJECTION ROTARY PUMP TEST VALUES | | | |
| Injection pump: VE4/9F1900R808-1 Speed governor: MIN/MAX | | IVECO PART N.: 500329480 BOSCH PART N.:0460 494 470 | |
| Engine : 8140.63.4000 | | For: IVECO | |
| Timing: | | | |
| - Injection pump static advance (Output reference "A") $1.0^\circ \pm 0.5^\circ$ degrees before after X T.D.C. with I.P. pumping in phase of delivery at 1 mm from B.D.C. | | | |
| - Or with piston at T.D.C. and injection pump pumping in phase of delivery at 0.94 ± 0.05 mm from B.D.C. | | | |
| - Engine idling speed without load: 800 ± 25 rpm | | | |
| TEST BENCH WITH STATIC AND DYNAMIC CHARACTERISTICS CONFORMING TO STANDARDS ISO 4008/1 -/2 | | | |
| - Rotation direction: Right Left | | X | |
| - Pipes: $\varnothing 6 \times \varnothing 2 \times 450$ mm | | - Supply pressure: 0.35 ± 0.05 bar | |
| - Injectors: 1688 901 022 | | - Burette evacuation time: KMM | |
| - Calibrated hole pad: - | | - Test fluid conforming to standard: ISO 4113 | |
| - Injector setting : 130 + 3 bar | | - Temperature Influx Defluxion X | |
| - Backflow chock: $\varnothing 0.55$ mm | | - Thermometer : 45 ± 1 °C | |
| | | - Electronic : ± 4 °C | |
| "INJECTION PUMP ADJUSTMENT VALUES" "THE NUMBERS GIVEN IN BRACKETS SHOULD BE USED ONLY AS CONTROL VALUES" | | | |
| 1 - START OF DELIVERY | | 5 - DELIVERY AT FULL LOAD WITHOUT OVERCHARGING | |
| Pre-lift (from B.D.C.) | mm: 0 ± 0.02 | Speed | rpm: 1250 |
| 2 - ADVANCE CHANGER TRAVEL | | Delivery per 1000 shots | cm ³ : 53.0 ± 0.5 |
| Speed | rpm: 1250 | Max difference | cm ³ : 3.0 (3.0) |
| Overcharging pressure | hPa: | 6 - IDLE SPEED ADJUSTMENT | |
| Adjustment values | mm: 2.8 ± 0.1 | Speed | rpm: 375 |
| 3 - TRANSFER PUMP PRESSURE | | Delivery per 1000 shots | cm ³ : 13.0 ± 2.0 |
| Speed | rpm: 1250 | Max difference | cm ³ : 3.0 (3.50) |
| Overcharging pressure | hPa: | 7 - ADJUSTING THE RESIDUAL DELIVERY | |
| Adjustment values | bar: 6.2 ± 0.2 | Speed | rpm: |
| 4 - DELIVERY AT FULL LOAD WITH OVERCHARGING | | Delivery per 1000 shots | cm ³ : |
| Speed | rpm: | 8 - MAXIMUM SPEED ADJUSTMENT | |
| Overcharging pressure | hPa: | Speed | rpm: 2050 |
| Delivery per 1000 shots | cm ³ : | Overcharging pressure | hPa: |
| Max difference | cm ³ : | Delivery per 1000 shots | cm ³ : 43.0 ± 1.0 |

| IVECO ENGINEERING | | No. 500338906 | | Edit. 1 | |
|-----------------------------------|-------------------|----------------|----------------------------------|-------------------|------------|
| INJECTION ROTARY PUMP TEST VALUES | | | | | |
| 9 - START | | | 14 - DELIVERY RUN AND ADJUSTMENT | | |
| Speed | rpm: | 100 | .1 Speed | rpm: | (*) |
| Delivery per 1000 shots | cm ³ : | 80.0 ± 15 | Overcharging pressure | hPa: | - |
| Minimum delivery | cm ³ : | 65.0 | Delivery per 1000 shots | cm ³ : | - |
| 10 - "LFB" SETTING | | | .2 Speed | | |
| Speed | rpm: | 1250 | Overcharging pressure | hPa: | 2380 |
| Overcharging pressure | hPa: | - | Delivery per 1000 shots | cm ³ : | 1.5 ± 1.5 |
| 1. Delivery difference | cm ³ : | < 12 ± 1.0 | | cm ³ : | (± 1.5) |
| per 1000 shots | | | .3 Speed | | |
| 2. Transfer pump pressure | bar: | 0.2 ± 0.1 | Overcharging pressure | hPa: | 2150 |
| difference | | | Delivery per 1000 shots | cm ³ : | 23.0 ± 5.0 |
| 11 - INJECTION ADVANCE RUN | | | cm ³ : | | |
| Overcharging pressure | hPa: | - | | cm ³ : | (± 6.0) |
| .1 Speed | rpm: | 1250 | .4 Speed | | |
| Advance travel | mm: | 2.8 ± 0.1 | Overcharging pressure | hPa: | 2050 |
| | mm: | (± 0.5) | Delivery per 1000 shots | cm ³ : | 43.0 ± 1.0 |
| .2 Speed | rpm: | 1700 | | cm ³ : | (± 6.0) |
| Advance travel | mm: | 5.5 ± 0.4 | .5 Speed | | |
| | mm: | (± 0.6) | Overcharging pressure | hPa: | 1900 |
| .3 Speed | rpm: | - | Delivery per 1000 shots | cm ³ : | 50.0 ± 2.0 |
| Advance travel | mm: | - | | cm ³ : | (± 2.5) |
| | mm: | - | .6 Speed | | |
| .4 Speed | rpm: | - | Overcharging pressure | hPa: | 1250 |
| Advance travel | mm: | - | Delivery per 1000 shots | cm ³ : | 53.0 ± 0.5 |
| | mm: | - | | cm ³ : | (± 2.0) |
| 12 - TRANSFER PRESSURE RUN | | | .7 Speed | | |
| Overcharging pressure | hPa: | - | Overcharging pressure | hPa: | 600 |
| .1 Speed | rpm: | 1250 | Delivery per 1000 shots | cm ³ : | 52.0 ± 2.5 |
| Transfer pump pressure | bar: | 6.2 ± 0.2 | | cm ³ : | (± 3.0) |
| .2 Speed | rpm: | 1900 | .8 Speed | | |
| Transfer pump pressure | bar: | 8.5 ± 0.5 | Overcharging pressure | hPa: | - |
| .3 Speed | rpm: | - | Delivery per 1000 shots | cm ³ : | - |
| Transfer pump pressure | bar: | - | | cm ³ : | - |
| .4 Speed | rpm: | - | .9 Speed | | |
| Transfer pump pressure | bar: | - | Overcharging pressure | hPa: | - |
| | | | Delivery per 1000 shots | cm ³ : | - |
| 13 - BACKFLOW VOLUME ON VALVE | | | cm ³ : | | |
| | cm ³ : | - | .10 Speed | | |
| .1 Speed | rpm: | 600 | Overcharging pressure | hPa: | - |
| Overcharging pressure | hPa: | - | Delivery per 1000 shots | cm ³ : | - |
| Backflow volume | c.c./10s: | 41.4 ÷ 74.52 | | cm ³ : | - |
| | c.c./10s: | (41.4 ÷ 74.52) | | | |
| .2 Speed | rpm: | 1900 | | | |
| Overcharging pressure | hPa: | - | | | |
| Backflow volume | c.c./10s: | 60.7 ÷ 104.8 | | | |
| | c.c./10s: | (60.7 ÷ 104.8) | | | |

IVECO ENGINEERING

No. 500338906

Edit. I

INJECTION ROTARY PUMP TEST VALUES

15 - DELIVERY NULL (STOP)

| | | | |
|-------------------------|-------------------|-----------|-----|
| .1 Mechanical: | | | |
| Speed | rpm: | | 460 |
| Delivery per 1000 shots | cm ³ : | 1.5 ± 1.5 | |
| Voltage | volt: | | 0 |
| .2 Electrical: | | | |
| Speed | rpm: | | 375 |
| Delivery per 1000 shots | cm ³ : | 1.5 ± 1.5 | |
| Voltage | volt: | | 0 |

16 - DELIVERY AT IDLING SPEED

| | | | |
|-------------------------|-------------------|------------|---------|
| .1 Speed | | | |
| Speed | rpm: | | 375 |
| Delivery per 1000 shots | cm ³ : | 13.0 ± 1.0 | (± 5.0) |
| .2 Speed | | | |
| Speed | rpm: | | 300 |
| Delivery per 1000 shots | cm ³ : | 28.0 ± 6.0 | (± 6.0) |
| .3 Speed | | | |
| Speed | rpm: | | 460 |
| Delivery per 1000 shots | cm ³ : | 1.5 ± 1.5 | |
| .4 Speed | | | |
| Speed | rpm: | | |
| Delivery per 1000 shots | cm ³ : | | |
| Residual delivery check | | | |
| .5 Speed | | | |
| Speed | rpm | | |
| Delivery per 1000 shots | cm ³ | | |

17 - "LFB" CHECK

| | | | |
|----------------------------|-------------------|------------|------|
| Speed | rpm: | | 1250 |
| Overcharging pressure | hPa: | | |
| .1 Delivery difference | | | |
| per 1000 shots | cm ³ : | 17.0 ± 3.0 | |
| Advance travel diff. | mm: | 1.0 ± 0.1 | |
| .2 Delivery per 1000 shots | | | |
| Advance travel diff. | mm: | 5.0 ± 1.0 | |

18 - AUTOMATIC START EXTRA DELIVERY

| | | | |
|-------------------------|-------------------|-----------|-----|
| .1 Speed | | | |
| Speed | rpm: | | 100 |
| Delivery per 1000 shots | cm ³ : | 80.0 ± 15 | |
| | cm ³ : | 65 min. | |
| .2 Speed | | | |
| Speed | rpm: | | 400 |
| Delivery per 1000 shots | cm ³ : | 65.0 ± 8 | |
| | cm ³ : | 73 max. | |
| .3 Speed | | | |
| Speed | rpm: | | |
| Delivery per 1000 shots | cm ³ : | | |
| | cm ³ : | | |

19 - POTENTIOMETER CALIBRATION AND CHECKING

| | | | |
|------------------------------|-------------------|------------|------|
| Supply | volt: | | 5.0 |
| Setting | | | |
| Speed | rpm: | | 1000 |
| Delivery per 1000 shots | cm ³ | 33.8 ± 0.5 | |
| Potentiometer output voltage | volt: | 3.25 ± 0.1 | |
| Checking: | | | |
| Speed | rpm: | | |
| Delivery per 1000 shots | cm ³ : | | |
| Potentiometer output voltage | volt: | | |

20 - EGR MICROSWITCH CALIBRATION

| | | | |
|-------------------------|-------------------|--|--|
| Speed | rpm: | | |
| Overcharging pressure | hPa: | | |
| Delivery per 1000 shots | cm ³ : | | |

21 - GLOW PLUG MICROSWITCH ADJUSTMENT

Contact closed at:
of injection pump
control lever travel

22 - CUT-OUT ELECTROMAGNET

| | | | |
|---------------------------|-------|--|----|
| Operating minimum voltage | volt: | | 10 |
| Rated voltage | volt: | | 12 |

23 - ASSEMBLING AND ADJUSTING DIMENSIONS

| | | | |
|--------------------------|------|------------|-----|
| Denomination: | | | |
| K | mm: | | 3.7 |
| KF | mm: | | |
| MS | mm: | | 1.6 |
| SVS max. | mm: | | |
| MSI | mm: | | |
| Ya | mm: | 38.9 ± 1.0 | |
| Yb | mm: | 44.5 ± 3.0 | |
| TLA-E | mm: | | |
| Devices | | | |
| HBA STROKE | mm: | | |
| LDA STROKE | mm: | | |
| KSB LEVER | : | | |
| KSB SPEED R.P.M | : | | |
| KSB TRANSFER | bar: | | |
| KSB SPEED R.P.M | : | | |
| KSB ADVANCE | mm: | | 2.8 |
| KSB ADVANCE A.P. DEGREES | : | | 3.5 |
| KSB VOLT EL. VALVE | : | | |

| | | |
|--|---------------|------------------|
| IVECO ENGINEERING | No. 500338906 | Edit. I |
| INJECTION ROTARY PUMP TEST VALUES | | |
| <p>REMARKS:</p> <ol style="list-style-type: none"> 1) references for which no letters or numbers are given are reserved for other injection pump designs; 2) for a correct adjustment of injection pumps on the electric bench, conform to the manual IVECO Technical Publications and Training No. XXXXXXXXXXXX; 3) measurements taken on injection pumps equipped with "KSB" must be performed with the same at rest; 4) (*) LDA adjusting point: act on spring pre-loading ring; 5) after every variation of LDA pressure, act on the control lever; 6) for adjusting the starting point (ARF valve) add a 12.0 mm spacer to the third delivery stop. 6b) "MODIFICATION POINT 6" FOR POTENTIOMETER SETTING POINT, PLACE A 12mm SHIM BETWEEN THE THROTTLE LEVER AND THE THIRD STOP. | | |
| NOTES: BOSCH SHEET ED. 5 DTD. 24.06.98 | C . I . D . | DATE 26-06-98 |

Sheet 4/4

FIA engine

| | Page |
|---|------|
| MAIN OPERATIONS ON ENGINE MOUNTED ON VEHICLE | 291 |
| ENGINE REMOVAL-REFITTING | 293 |
| <input type="checkbox"/> Removal | 293 |
| <input type="checkbox"/> Refitting | 297 |
| <input type="checkbox"/> Checks and tests | 297 |
| <input type="checkbox"/> Power steering system air bleed | 297 |
| REPLACING BELTS | 298 |
| <input type="checkbox"/> Replacing air-conditioning compressor drive belt (version with belt tensioner) | 298 |
| <input type="checkbox"/> Disassembly | 298 |
| <input type="checkbox"/> Assembly and adjusting belt tension | 298 |
| <input type="checkbox"/> Replacing air-conditioning compressor drive belt (version with elastic belt) | 298 |
| <input type="checkbox"/> Disassembly | 298 |
| <input type="checkbox"/> Assembly | 298 |
| <input type="checkbox"/> Power steering pump-alternator belt replacement | 298 |
| <input type="checkbox"/> Disassembly | 298 |
| <input type="checkbox"/> Assembly | 298 |
| <input type="checkbox"/> Replacing timing drive belt | 299 |
| <input type="checkbox"/> Disassembly | 299 |
| <input type="checkbox"/> Assembly | 300 |
| REPLACING ELECTRO-INJECTORS | 301 |
| <input type="checkbox"/> Disassembly | 301 |
| <input type="checkbox"/> Assembly | 301 |
| CYLINDER HEAD REMOVAL AND REFITTING | 302 |
| <input type="checkbox"/> Removal | 302 |
| <input type="checkbox"/> Refitting | 304 |
| REPLACING HIGH-PRESSURE PUMP CP3 | 305 |
| <input type="checkbox"/> Removal | 305 |
| <input type="checkbox"/> Refitting | 305 |
| REPLACING WATER PUMP | 305 |
| <input type="checkbox"/> Removal | 305 |

| | Page |
|---|-------|
| <input type="checkbox"/> Refitting | 305 |
| EMISSIONS | 306 |
| ENGINE IDENTIFICATION CODE | 308 |
| CHARACTERISTIC CURVES | 308/1 |
| GENERAL SPECIFICATIONS | 310 |
| ASSEMBLY DATA – CLEARANCES | 313 |
| TOOLS | 318 |
| EXPERIMENTAL TOOLS | 323 |
| TIGHTENING TORQUE | 334 |
| OVERHAULING ENGINE FIA | 339 |
| DISASSEMBLING THE ENGINE AT THE BENCH | 339 |
| REPAIRS | 348 |
| CYLINDER BLOCK | 348 |
| <input type="checkbox"/> Checks and measurements | 348 |
| <input type="checkbox"/> Checking head mating surface on cylinder block | 349 |
| CRANKSHAFT | 349 |
| <input type="checkbox"/> Measuring main journals and crank pins | 349 |
| <input type="checkbox"/> Checking crankshaft | 350 |
| <input type="checkbox"/> Replacing timing control gear | 352 |
| ENGINE ASSEMBLY | 352 |
| <input type="checkbox"/> Assembling main bearings | 352 |
| <input type="checkbox"/> Measuring main journal assembly clearance ... | 352 |
| <input type="checkbox"/> Checking crankshaft end float | 353 |
| <input type="checkbox"/> Assembling rear seal | 354 |
| <input type="checkbox"/> Replacing bearing supporting gearbox input shaft | 355 |
| ENGINE FLYWHEEL | 355 |
| CONNECTING ROD – PISTON ASSEMBLY ... | 355 |
| <input type="checkbox"/> Pistons | 356 |
| <input type="checkbox"/> Measuring piston diameter | 356 |
| <input type="checkbox"/> Piston pins | 357 |
| <input type="checkbox"/> Conditions for correct pin-piston coupling ... | 357 |
| <input type="checkbox"/> Piston rings | 357 |
| <input type="checkbox"/> Connecting rods | 358 |
| <input type="checkbox"/> Bushes | 359 |

| | Page |
|--|------|
| <input type="checkbox"/> Checking connecting rods | 359 |
| <input type="checkbox"/> Checking torsion | 359 |
| <input type="checkbox"/> Checking bending | 359 |
| <input type="checkbox"/> Assembling connecting rod-piston assembly ... | 359 |
| <input type="checkbox"/> Checking for connecting rod – piston distortion | 360 |
| <input type="checkbox"/> Assembling piston rings | 360 |
| <input type="checkbox"/> Assembling connecting rod – piston assemblies in cylinder barrels | 360 |
| <input type="checkbox"/> Measuring crankpin assembly clearance | 361 |
| <input type="checkbox"/> Checking piston protrusion | 361 |
| CYLINDER HEAD | 362 |
| <input type="checkbox"/> Disassembly | 362 |
| <input type="checkbox"/> Removing valves | 362 |
| <input type="checkbox"/> Checking cylinder head seal | 363 |
| <input type="checkbox"/> Checking cylinder head mating surface | 363 |
| VALVES | 363 |
| <input type="checkbox"/> Removing deposits, refacing and checking valves | 363 |
| <input type="checkbox"/> Checking clearance between valve stem and valve guide and centring valves | 364 |
| VALVE GUIDES | 364 |
| <input type="checkbox"/> Replacing valve guides | 364 |
| <input type="checkbox"/> Boring valve guides | 364 |
| VALVE SEATS | 365 |
| <input type="checkbox"/> Regrinding - replacing valve seats | 365 |
| VALVE SPRINGS | 366 |
| ROCKER ARMS – TAPPETS | 366 |
| <input type="checkbox"/> Checks | 367 |
| ASSEMBLING CYLINDER HEADS | 367 |
| <input type="checkbox"/> Overhead | 368 |
| <input type="checkbox"/> Overhead removal | 368 |
| TIMING SYSTEM | 369 |
| <input type="checkbox"/> Description | 369 |
| <input type="checkbox"/> Camshaft | 370 |
| <input type="checkbox"/> Checks | 370 |
| <input type="checkbox"/> Checking cam lift and pin alignment | 370 |

| | Page | | Page |
|---|------|---|------|
| <input type="checkbox"/> Assembling overhead | 371 | <input type="checkbox"/> Operating principles | 393 |
| <input type="checkbox"/> Assembling front seal ring | 372 | <input type="checkbox"/> Air flow meter | 394 |
| <input type="checkbox"/> Refitting cylinder head | 375 | FUEL SUPPLY | 395 |
| <input type="checkbox"/> Adjusting air-conditioner – compressor drive belt tension | 378 | HIGH-PRESSURE ELECTRONIC INJECTION SYSTEM (MS 6.3 - EDC 16) | 395 |
| <input type="checkbox"/> Timing speed sensor | 382 | <input type="checkbox"/> General | 395 |
| <input type="checkbox"/> Engine speed sensor | 382 | SYSTEM OPERATION | 397 |
| LUBRICATION | 383 | <input type="checkbox"/> Self-diagnosis – BLINK CODE | 397 |
| <input type="checkbox"/> General | 383 | <input type="checkbox"/> Immobilizer recognition | 397 |
| OIL VACUUM PUMP ASSEMBLY (GPOD) | 385 | <input type="checkbox"/> Checking fuel temperature | 397 |
| <input type="checkbox"/> Oil pump | 385 | <input type="checkbox"/> Checking engine coolant temperature | 397 |
| <input type="checkbox"/> Characteristic data | 385 | <input type="checkbox"/> Checking quantity of fuel injected | 397 |
| <input type="checkbox"/> Vacuum pump | 385 | <input type="checkbox"/> Checking idling adjustment | 397 |
| <input type="checkbox"/> Oil pressure control valve | 386 | <input type="checkbox"/> Fuel cut-off in release phase | 397 |
| <input type="checkbox"/> Oil filter | 386 | <input type="checkbox"/> Checking cylinder balancing on idling | 397 |
| <input type="checkbox"/> Modine heat exchanger | 386 | <input type="checkbox"/> Checking regular engine rotation (anti-sawing) | 397 |
| <input type="checkbox"/> Oil vapour recirculation system | 387 | <input type="checkbox"/> Checking smokiness at exhaust on acceleration | 397 |
| <input type="checkbox"/> Description | 387 | <input type="checkbox"/> Checking exhaust gas recirculation (E.G.R. if present) | 397 |
| COOLING | 388 | <input type="checkbox"/> Checking top speed limit | 397 |
| <input type="checkbox"/> Description | 388 | <input type="checkbox"/> Checking regular rotation on acceleration | 397 |
| <input type="checkbox"/> Operation | 388 | <input type="checkbox"/> Checking glow plug control unit | 397 |
| <input type="checkbox"/> Electromagnetic pulley | 389 | <input type="checkbox"/> Checking activation of air-conditioning system | 397 |
| <input type="checkbox"/> Water pump | 389 | <input type="checkbox"/> Checking fuel pump | 397 |
| <input type="checkbox"/> Thermostat | 389 | <input type="checkbox"/> Checking diesel warming | 398 |
| TURBOCHARGING | 390 | <input type="checkbox"/> Checking cylinder position | 398 |
| <input type="checkbox"/> Description | 390 | <input type="checkbox"/> Checking pilot and main injection timing | 398 |
| <input type="checkbox"/> Turbocharger | 391 | <input type="checkbox"/> Checking injection pressure closed cycle | 398 |
| REPAIRS | 392 | <input type="checkbox"/> Fuel supply | 398 |
| <input type="checkbox"/> Pressure relief valve | 392 | <input type="checkbox"/> Correcting flow rate according to water temperature | 398 |
| <input type="checkbox"/> Checking and adjusting pressure relief valve | 392 | <input type="checkbox"/> Correcting flow rate to avoid noise, smoke or overloading | 398 |
| <input type="checkbox"/> Replacing pressure relief valve | 392 | | |
| EXHAUST GAS RECIRCULATION (EGR) SYSTEM | 393 | | |
| <input type="checkbox"/> EGR system operation | 393 | | |

| | Page | | Page |
|---|------|---|------|
| <input type="checkbox"/> De-rating | 398 | <input type="checkbox"/> Engine speed sensor | 415 |
| <input type="checkbox"/> Injection timing electronic test | 398 | <input type="checkbox"/> Camshaft timing sensor | 415 |
| <input type="checkbox"/> Speed governor | 398 | <input type="checkbox"/> Air temperature and pressure sensor | 415 |
| <input type="checkbox"/> Engine starting | 398 | <input type="checkbox"/> Fuel temperature sensor | 415 |
| <input type="checkbox"/> Cold starting | 399 | <input type="checkbox"/> Fuel pressure sensor | 415 |
| <input type="checkbox"/> Warm starting | 399 | <input type="checkbox"/> Atmospheric pressure sensor | 415 |
| <input type="checkbox"/> Run up | 399 | <input type="checkbox"/> Engine coolant temperature sensor | 416 |
| <input type="checkbox"/> After run | 399 | <input type="checkbox"/> Throttle pedal position sensor | 416 |
| <input type="checkbox"/> Cut-off | 399 | <input type="checkbox"/> Clutch pedal position sensor | 416 |
| <input type="checkbox"/> Cylinder balancing | 399 | <input type="checkbox"/> Brake pedal position sensor | 416 |
| <input type="checkbox"/> Synchronization search | 399 | <input type="checkbox"/> Vehicle speed sensor | 416 |
| OPERATION | 401 | ACTUATORS | 416 |
| HYDRAULIC SYSTEM | 403 | <input type="checkbox"/> PWM (Pulse Width Modulation) controls | 416 |
| <input type="checkbox"/> Fuel pump | 403 | GUIDE TO TROUBLESHOOTING | 417 |
| <input type="checkbox"/> Specifications | 403 | | |
| <input type="checkbox"/> Fuel filter | 404 | | |
| <input type="checkbox"/> Tightening torques | 404 | | |
| <input type="checkbox"/> Fuel pipes | 404 | | |
| <input type="checkbox"/> High-pressure pump | 405 | | |
| <input type="checkbox"/> High-pressure pump internal structure | 407 | | |
| <input type="checkbox"/> Working principle | 408 | | |
| <input type="checkbox"/> Pressure control valve | 411 | | |
| <input type="checkbox"/> Replacing pressure regulator | 411 | | |
| MECHANICAL SUPPLY PUMP | 412 | | |
| <input type="checkbox"/> Hydraulic accumulator (rail) | 413 | | |
| <input type="checkbox"/> Overpressure valve (for forged hydraulic accumulator) | 413 | | |
| ELECTRO-INJECTORS | 413 | | |
| <input type="checkbox"/> Operation | 414 | | |
| ELECTRIC/ELECTRONIC COMPONENTS | 414 | | |
| <input type="checkbox"/> Electronic control unit MS6.3 or EDC 16 | 414 | | |
| <input type="checkbox"/> Glow plug electronic control unit | 415 | | |
| <input type="checkbox"/> Glow plugs | 415 | | |
| SENSORS | 415 | | |

MAIN OPERATIONS ON ENGINE MOUNTED ON VEHICLE



Keep to the following instructions before doing any work on the engine involving components of the fuel supply system.

- Before doing any work on the engine, perform the engine/vehicle fault diagnosis with specific IVECO diagnosis equipment and print out the results.
- Replacement of the MS6.3 or EDC 16 control unit must be authorized by the **Help Desk**.
- Following components in feed system cannot be overhauled but have to be replaced: pressure relief valve, if present, fuel pressure sensor, hydraulic accumulator, complete CPI high pressure feed pump, pressure control valve, electric injectors.
- All the parts of the Common Rail system are packaged by the supplier in sheets of oiled paper and are stored in cardboard boxes. They must therefore be protected against moisture and unpacked just prior to assembly.
- The greatest care must be taken over the cleanliness of parts, making sure that when handling or assembling (starting with straightforward filter and pre-filter replacement) no dirt or foreign bodies can get inside. For this reason, the plugs protecting the hydraulic parts and sensors must be removed just prior to positioning in their seats.
- Take care over the direction of assembly for all electrical connections.
- All threaded connections must be tightened to the prescribed torque.
- All the quick-coupling connectors (on the engine they are found on the high-pressure pump and on the diesel drain manifold) must be fully inserted. To drive them out, press on the tabs at the base of the connectors.

Electro-injector

None of the couplings/unions/nuts on the injector body may be handled. It is neither necessary nor permitted to dismantle the nozzle body or the electromagnet.

If working on the high-pressure pipe, the hexagon on the injector side must be kept stationary with a wrench.

Before working on pipes, make sure the injector is stationary in its seat on the cylinder head.

When assembling/disassembling the injector drain, the retaining spring must not be removed from its seat in the injector: pushing the spring towards the engine and applying a vertical force on the connector frees the recirculation. When assembling, rest the recirculation connector in its seat and apply a vertical force while keeping the retaining spring pressed in the direction of the engine. Fitting in has to be easy.

CP3 High-pressure pump

If working on the high-pressure pipe, the hexagon on the pump side must be kept stationary with a wrench.

Before working on the high-pressure pipe, make sure the pump is secured in its seat.

High-pressure pipes

Each high-pressure pipe must be replaced after disassembly operations.

The couplings must be tightened or loosened with the injectors, hydraulic accumulator (rail) and high-pressure pump well secured and taking care to keep the hexagon on the component side stationary, space permitting.


Hydraulic accumulator (rail) and accessories

Pressure sensor, as well as pressure relief valve (if present) can be successively mounted 5 times. Thereafter, they need to be replaced. They must be lubricated with a thin layer of oil before being mounted.

Pressure relief valve, if present, must also be lubricated before being mounted and its gasket must compulsorily be replaced.

Toothed timing drive belt

If the engine has run for a period equivalent to over 25,000 km, the toothed timing drive belt must be replaced with a fresh one, no matter what its state of wear, whenever it gets removed or any work is done on its automatic tightener.



72446

540110 ENGINE REMOVAL-REFITTING**Removal**

Set the vehicle over the pit or on the lift.

Lift up the bonnet (2), unscrew the screws (1) securing it and take it off. Remove the prop (3).

Disconnect the negative cable (4) and the positive cable (6) from the battery (5) and detach this from the engine bay.

Unhook the cable (11) from the bonnet opening control devices.

Disconnect the electrical connections (12) of the front headlamps.


Unscrew the nuts (7) and screws (8), then remove the front cross member (10) with the light clusters.

Unscrew the screws (10, 12 and 14) and remove the bottom side guards (11 and 13).

Underneath the vehicle (see Figure 4):

- Unscrew the screws (⇒) and remove the central guard (12).

Figure 1



- Take the cap (2) off the expansion tank (4).
- Unscrew the coolant plug (16), under the radiator (17), and drain the cooling system.
- Disconnect the pipe (25) from the coalescence filter (26) and from the air intake pipe (14).
- Disconnect the pipes (12) and (13) from the heat exchanger, intake manifold and turbocharger.

NOTE Close the turbocharger air outlet appropriately to prevent foreign bodies accidentally getting inside and damaging it.

- Disconnect the coolant pipes (9 and 10).

NOTE Vehicles with an air-conditioner in the cab should have the electrical connection (15) disconnected from the drier filter.


- Unscrew the air filter bracket fasteners (20) to help extract the air intake pipe (21) from the duct (18) on the radiator assembly.
- Disconnect the pipe (22) from the duct (19) and (23) from the engine.
- Disconnect the tube (3) from the expansion tank (4).
- Unscrew the screws (11) to remove the radiator assembly (17) together with the heat exchanger.

NOTE In case of vehicles equipped with cabin internal conditioner, proceed as follows:

- vehicles equipped with drying filter separated from the condenser:
put the radiator (complete with the condenser and drying filter) back in the engine compartment, taking care not to subject the conditioning system pipes to tension;
- vehicles equipped with drying filter built into the condenser:
blow gas off the air-conditioning system, as described in the relevant chapter in the "Bodywork and chassis" section, then disconnect the pipes from the condenser and seal both the pipes and their respective fittings on the condenser to prevent moisture and impurities from penetrating into the system.

- Disconnect the coolant pipes (8) and (24) from the rigid three-way pipe (27), freeing them from any clamps (7).
- Disconnect the heater delivery pipe (1).
- Unscrew the fasteners (6) to remove the expansion tank (4), disconnecting the level sensor's electrical connection.
- Take the soundproofing cover (5) off the cylinder head after removing the oil filler cap.

Figure 2



Place a container under the power steering pump to recover the oil from the system. Then disconnect the oil inlet and outlet pipes (16 and 17).

- Disconnect the pipes (7) recovering diesel from the high-pressure-pump.
- Disconnect the pipe (8) delivering diesel to the high-pressure-pump.
- Disconnect the vacuum pipe (23) from the vacuum pump.
- Disconnect the air intake duct (19).

NOTE Close the turbocharger air outlet appropriately to prevent foreign bodies accidentally getting inside.

- Free the wiring harness of the engine (15) from the clamps (←) on the timing cover, disconnect the connections of the alternator (21) and from the sensors on the thermostat (22), from the electromagnetic coupling of the fan hub (20) and move the wiring to one side so it will not interfere with the disassembly of the engine.
- Disconnect the wiring (2) from the water temperature and timing sensors, from the injectors, intake air temperature sensor and rail pressure sensor. Move the wiring to one side.
- Disconnect the high-pressure pump electrical connection (10).
- Disconnect the engine speed sensor (9).
- Disconnect the engine earth cable (6).
- Disconnect the positive cable from the starter motor (5).


The remaining electrical connections of the engine cable are disconnected from the associated electrical components after removing the engine.

- Disconnect the oil fillpipe by undoing the fastenings (1).
- Undoing the fastenings (18), remove the fan from the electromagnetic coupling (20).
- Attach tool 99360544 (4) to the brackets on the engine to extract it from the engine bay and put it slightly under traction.

NOTE In case of vehicles equipped with conditioner, proceed as follows:

- as regards the vehicles equipped with drying filter separated from the condenser, remove compressor (11) by proceeding as follows:
 - loosen the belt stretcher by acting on screw (13), then remove belt (14);
 - act on fasteners (12) to remove compressor (11), then put the latter back into the compartment without disconnecting the pipes of the system;
- as regards the vehicles equipped with drying filter built into the condenser, disconnect the pipes from the compressor, then seal the pipes and their respective fittings on the compressor to prevent moisture and impurities from penetrating into the system.

Figure 3



- Disconnect the screws (16 and 20) securing the brackets (17 and 19) and disconnect the "bowdens" (18 and 21) from the gearbox.
- Unscrew the fixing screws (22), move the clutch control cylinder (23), with its bracket, and fasten it to the chassis frame appropriately.
- Remove the sealing from the ring nut (1), unscrew it and disconnect the speedometer control cable.
- Disconnect the electrical connection (4) from the reversing light switch.

NOTE As regards automatic transmission, disconnect gearbox-chassis cable connector (27) from the control unit.


- Disconnect the exhaust pipe (9) from the turbocharger outlet pipe.
- Put a jack under the gearbox to support it.
- Disconnect the bracket supporting the gearbox on the rear crosspiece by undoing the four screws (5).
- Unscrew the fixing screws (6) and remove the crosspiece (7) supporting the gearbox complete with the gearbox/support bracket.
- Remove nuts (14) securing elastic supports (13) to the chassis.
- Remove bolts (3) securing drive shaft (2) to the gearbox; remove, if necessary, screws (24) securing elastic support (25) to the chassis, then properly secure the drive shaft to the chassis.
- Take the jack out from under the gearbox.
- Lift the engine assembly and take it out of the engine bay.

NOTE The power unit must be removed from the engine compartment with the greatest care, to avoid damaging the remaining parts on the vehicle, in particular the steering box oil pipes.

If it is necessary to detach the gearbox from the engine, take out the fixing screws and remove the starter motor.

Take out the fixing screws and detach the gearbox from the engine.

NOTE As far as automatic transmission is concerned, strictly adhere to the operations described in the relevant chapter in the "Gearbox" section.





Refitting

To refit the engine assembly, carry out the operations described for removal in reverse order, following these instructions:

- Before refitting the gearbox to the engine, it is necessary to remove the pressure plate bearing from the diaphragm spring by opening out the retaining circlip. Fit the pressure plate bearing on the sleeve of the drive input shaft cover, connecting it to the clutch release lever. Spread the gearbox input shaft with Molikote molybdenum disulphide grease. Engage a gear to let the main shaft turn, rotating the propeller shaft connecting flange. Push the gearbox fully in so that the pressure plate bearing couples with the diaphragm spring correctly.
- Pay special attention to the operations needed to install the engine assembly in the engine bay.
- Check the conditions of the coolant pipes or sleeves and of the air ducts. Replace them if they show any sign of deterioration.
- Check the flexible mountings of the assemblies: engine and gearbox. Replace them if they show any sign of deterioration.
- Check that the exhaust pipe members have not deteriorated and are not about to deteriorate. If this is so, replace them along with the flexible parts for securing them.
- Tighten the screws or nuts to the required torque.
- Meticulously check the state of the vacuum pipe. It must show no sign of cracking, cutting, scoring or of being crushed. Replace it if there is any doubt at all about its soundness. When mounting it, make sure the pipe does not come into contact with sharp metal parts or corners or with any particularly hot parts. In addition, after assembly, the pipe must have no bends or constrictions, its radius of curvature should be broad and it must be secured to the vacuum pump fitting with a suitable clamp.
- Make sure the quick-coupling fittings of the fuel pipes are thoroughly clean and, after connection to the relevant high-pressure pump unions or fuel filter mount, are fully inserted and do not come loose.
- Fill the cooling system with coolant.
- Fill the hydraulic power steering circuit and bleed the air as described under the relevant heading.
- Check the level of oil in the engine and gearbox.
- Adjust the tension of the drive belt of the compressor for the air-conditioner as described in "Replacing Belts" (if present).

NOTE When positioning the engine in the engine bay, take special care not to damage the top pipe of the power steering and the soundproof-heatproof cladding of the engine bay. Once positioned, meticulously check that the top pipe of the power steering is sound. Before using it again, check that the power steering oil and coolant contain no impurities. If they do, filter with suitable mesh filters. For any topping up, refer to the REPLENISHING FLUIDS table in the "GENERAL" section.

Checks and tests



Start up the engine, leave it running just a little faster than idling speed and wait for the coolant temperature to reach the value for opening the thermostat, then check that:



- No water leaks from the connecting sleeves of the engine cooling and cab heating circuit pipes; tighten the collars if necessary.
- No oil leaks from between the cover and cylinder head, oil sump and crankcase, oil filter and its seat, heat exchanger and crankcase or from between the various pipes of the lubricating circuit.
- No fuel leaks from injection pump and injector lines. Tighten fittings if necessary.
- Check the indicator and warning lights on the instrument panel and the devices disconnected on removing the engine all work properly.



501430 Power steering system air bleed

Check the level of oil in the tank and top it up if necessary. Lift the vehicle at the front, start up the engine and let it idle for some time.

Check there is no oil leakage from the hydraulic circuit and check the level in the tank.

Slowly turn the steering wheel in both directions of steering so that the air in the hydraulic system comes out.


Check the level of oil in the tank again and top up if necessary.

REPLACING BELTS

543910 Replacing air-conditioning compressor drive belt (version with belt tensioner)

Disassembly


Figure 5



Set the vehicle on a lift or over a pit. From underneath the vehicle, detach the middle soundproofing guard. Loosen the screw (2) fixing the tightener (1) and remove the belt (4) driving the air-conditioner compressor (3).

Assembly and adjusting belt tension

Figure 6



Mount the drive belt, taking care to position its ribs properly in the respective races of the pulleys.

With the tool SP.2341 (2) inserted in the holes of the tightener (1) and a torque wrench (3), turn the tightener (1) with a torque of 8.2-10 Nm; in this condition, tighten the screw (4) to a torque of 25 Nm.

Turn the engine in its direction of rotation to have the belt (5) make two full turns.


Using tool 99395849, measure the tension of the belt (5) in the section **A**, which must be 204 ± 10 Hz, corresponding to a load of 1010 ± 10 N on the tightener.

Fit the middle soundproofing guard back on.

543910 Replacing air-conditioning compressor drive belt (version with elastic belt)

Disassembly

Figure 7



Take elastic belt (3) off pulleys (1 and 4).

Assembly

Fit the flexible belt (3) equipped with tool 99360191 (2) on the pulley (4) and apply the tool on the pulley (1).


Fit the drive ring (5) on the flexible belt (3) and fasten the ring on the compressor support.

Turn the drive shaft clockwise until the belt fits perfectly on the pulley (1).

543910 Power steering pump-alternator belt replacement

Disassembly

Figure 8



Disassemble the compressor drive belt, if there is one, as described under the relevant heading.

Slacken off the tension of the belt (1) using a specific wrench on the automatic tightener (2) and remove the belt.

Assembly

Mount the drive belt (1) taking care to position its ribs correctly in the respective races of the pulleys. Release the automatic tightener (2). Turn the crankshaft by one turn to settle the belt.

Mount the compressor drive belt, if there is one, and adjust the tension as described under the relevant heading.

Fit the middle soundproofing guard back on.

541257 Replacing timing drive belt**Disassembly**

Following the procedures described for removing the engine, take out the radiator assembly without disconnecting the air-conditioning system pipes from the condenser or from the drier filter and put it appropriately aside in the engine bay.

Remove the air-conditioner compressor drive belt (22) (if there is one) and the water pump / alternator drive belt as described under the relevant headings.

Remove the fan (25) from the electromagnetic coupling (6). Disconnect the electrical connection (24) from the electromagnetic coupling (6).

Take out the fixing screws (2) and (3) and remove the mounting together with the electromagnetic coupling (6).

Take out the screws and remove the fixed tightener (5) and the automatic tightener (4).

Remove screws (26), then disassemble pulley (27).

Remove the wiring from the timing cover (23) and dismantle this.

Take off the cap (13) and remove the soundproofing cover (14).

Disassemble valve gear cover (23).

Disconnect the pipes (15) from the pipe (16).

Take out the fixing screws (8) and remove the expansion tank (7); disconnect the electrical connection for the level indicator from the expansion tank and put the tank (8) aside appropriately.

Take out the screws (10) and remove the bracket (11) fixing the soundproofing cover (14).

Remove the plugs (9) from the overhead and the plug (20) from the oil pump – vacuum pump assembly mounting.

Turn the crankshaft clockwise so as to be able to insert the pins 99360614 (12) through the holes in the plugs (9) into the relevant holes of the camshafts and pin 99360615 (19) through the hole in the plug (20) into the crankshaft.

Loosen the screw (17) securing the automatic tightener (18) and remove the timing belt (21).

Figure 9




Figure 10



Assembly

Insert tool 99360608 (8) into the hole of the toothed pulley (7) and into the corresponding hole of the overhead to prevent changing the assembly position of the toothed pulley (7) in the following operations.

Loosen the screw (9) fixing the toothed pulley (7) and, using tool 99340028, drive the pulley (7) out of the camshaft.

Turn the automatic tightener (1) clockwise, positioning it as shown in frame **A**.

Turn the timing belt (10) as shown in the figure observing the precautions below.

Do not bend the timing belt. Arrows indicating the direction of assembly of the timing belt on the engine are shown on the back of the belt. The arrows must correspond to the direction of rotation of the belt and the notches must coincide with those on the pulley (7) and the gear (12).

If required to fit the timing belt (10) on the pulley (7), remove tool 99360608 (8) and turn the pulley (7) clockwise by no more than half a pulley tooth.

On completing assembly, adjust the toothed pulley (7) to put the section **X** of the belt under tension and tighten the screw (9) to a torque of 90 Nm.

Keeping the screw (2) stationary and using a suitable wrench on the hexagon of the plate (3) of the tightener, turn it anticlockwise to cover the reference hole (5) located on the fixed portion of the tightener (see frame **B**).

In the above conditions, tighten the fixing screw (2) to a torque of 36 ± 4 Nm.

Remove the tools 99360614 (6) and 99360615 (11) for the timing.

Turn the engine in its direction of rotation by 8 turns to be able to put the tools (6) and (11) back in to do the timing.

In these conditions, the notches of the timing belt (10) must coincide with those of the pulley (7) and the gear (12).


NOTE Do not turn the engine in the opposite direction; if, on turning the engine, you pass the point for inserting the tools (6) and (11), turn the engine clockwise by another two turns.

See frame C: holding the tightener plate (3) stationary with the wrench inserted in its hexagon, loosen the fixing screw (2). Keeping the fixing screw (2) stationary, turn the plate (3) clockwise until its reference mark **Λ** (4) coincides with the reference hole (5) of the fixed portion of the tightener.

In the above conditions, tighten the screw (2) to a torque of 30 ± 4 Nm.

Then complete assembly by carrying out the steps described for disassembly in reverse order.


After assembly, the belt (10) tension measured using tool 99395849 must be as follows in the following points: X, 212 ± 12 Hz - X₁, 178 ± 10 Hz.



x = direction of movement of the tightener
y = direction of rotation of the wrench

775010 REPLACING ELECTRO-INJECTORS

Figure 11



75564

Disassembly

Partly drain the coolant off from the radiator. Remove the plug (13, Figure 9) and detach the soundproofing cover (14, Figure 9).

Disconnect the pipes (15, Figure 9) from the pipe (16, Figure 9).

Take out the fixing screws (8, Figure 9) and remove the expansion tank (7, Figure 9). Disconnect the level indicator electrical connection from the expansion tank.

Disconnect the pipe (17, Figure 12) from the coalescence filter (2, Figure 12).

Disconnect the electrical connections (1) from the electro-injectors (10) and (2) from the fuel pressure sensor (8).

Press the springs (3) in the direction shown by the arrow and disconnect the fittings of the pipe (4) to recover fuel from the electro-injectors (10).

Disconnect the fuel pipes (7) from the electro-injectors (10) and from the hydraulic accumulator (9).

Take out the screws (6) and the brackets (5) fixing the electro-injectors (10) to the cylinder head.

Using tool 99342153 (11) extract the electro-injectors (10) from the overhead.

Assembly

Thoroughly clean the seat of the electro-injectors, taking care no foreign bodies get into the cylinder barrels.

Fit a fresh gasket (12) onto the electro-injector (10) and fit this in the overhead.


Complete assembly by carrying out the operations described for disassembly in reverse order, taking the following precautions:

- With each disassembly, the fuel pipes must be replaced with fresh ones.
- Tighten the nuts, screws and fittings to the prescribed torque.
- To tighten the fittings of the fuel pipes, use the wrench in the 99317915 series and the torque wrench 99389829.
- After assembly, replenish the coolant as described under the relevant heading.

Check assembly of the timing sensor as described under the relevant heading.

540610 CYLINDER HEAD REMOVAL AND REFITTING

Figure 12



75567

**Removal**

Remove the timing belt as described under the relevant heading (operation 541257).

Disconnect the coolant pipes (12) and (13) from the pipe (11).

Take out the fixing screws and remove the expansion tank (16), disconnecting the level sensor electrical connection from this.

Remove the pipe (18) for the oil dipstick from the intake manifold.

Disconnect the pipes (1) and (17) from the coalescence filter (2) and detach this from the overhead.


Disconnect the pipe (3) from the fitting.

Remove the electro-injectors (4) as described in "Replacing electro-injectors" (operation 775010).

Disconnect the electrical connections from: timing sensor (5) and remove this from the overhead, water temperature sensors (6) and (7), air pressure and temperature sensor (10), and glow plugs (15).

Detach the fuel pipe (9) from the hydraulic accumulator (8), from the high-pressure pump and from the intake manifold. Disconnect the fuel return pipe (14) from the pressure relief valve of the hydraulic accumulator (8).

Figure 13



75568

Loosen the clamp and disconnect the sleeve (11) from the air duct (10).

Loosen the collar (2), take out the screw (13) fixing the bracket (12) and detach the air duct (10).

Disconnect the oil vapour recirculation pipe (8) from the air intake sleeve (9) and disconnect this from the turbocharger (5).

Disconnect the oil pipe (1) from the cylinder head and from the turbocharger (5).

Loosen the clamp (7) and disconnect the oil pipe (6) from the crankcase union.

Take out the screws and disconnect the exhaust pipe (4) from the turbocharger (5).

Take off the nuts (3) and remove the turbocharger (5) with its gasket from the exhaust manifold.

NOTE Close the turbocharger air outlet/inlet appropriately to prevent foreign bodies accidentally getting inside and damaging it.

Take out the screws and remove the overhead together with the pins 99360614.

NOTE The pins 99360614 applied so as not to alter the timing after removing the timing belt must be removed from the overhead only if this is to be removed.

Take off the overhead gasket.

Take out the tappets and carefully put them aside.

Using the bushing 99355041, take out the glow plugs.

Take out the screws fixing the cylinder head and detach this from the crankcase.

Remove the cylinder head gasket.



Refitting

Refitting requires carrying out the operations for removal in reverse order, while taking the following precautions:
Check that the timing tools:

- 99360614 (6, Figure 10) and 99360608 (8, Figure 10) are inserted in the overhead;
- 99360615 (11, Figure 10) is inserted in the crankcase as described in "Replacing timing belt."

Check that the mating surfaces of the cylinder head and crankcase are clean.

Keep the cylinder head gasket clean.


Position the cylinder head gasket with the lettering "TOP" facing the cylinder head.

NOTE It is essential to keep the gasket sealed in its package until just before assembly.

Mount the cylinder head. Insert the screws and tighten them, in three successive stages, following the order and method shown in the following figure.

NOTE The angle closure is done with tool 99395216.

Figure 14



75494

Diagram of the tightening sequence for the cylinder head fixing screws:

- 1st phase: pre-tightening with torque wrench
 - screws 1-2-3-4-5-6 to a torque of 100 ± 5 Nm;
 - screws 7-8-9-10 to a torque of 50 ± 2.5 Nm.
- 2nd phase: angle closing
 - screws 1-2-3-4-5-6 $90^\circ \pm 5^\circ$;
 - screws 7-8-9-10 $60^\circ \pm 3^\circ$.
- 3rd phase: angle closing
 - screws 1-2-3-4-5-6 $90^\circ \pm 5^\circ$;
 - screws 7-8-9-10 $60^\circ \pm 3^\circ$.

A = flywheel side.

- Tighten the screws and nuts to the prescribed torque.
- The seals and gaskets must not be reused, but replaced with new ones.

NOTE If the engine has run for a period equivalent to = 25,000 km, the toothed timing drive belt must be replaced with a fresh one, no matter what its state of wear.

To tighten the glow plugs, use the bushing 99355041 and torque wrench 99389819.

771010 REPLACING HIGH-PRESSURE PUMP CP3




Removal

Remove the timing drive belt, as described in the relevant chapter (operation 541257).

Disconnect the following items:


- electric connection from the pressure sensor;
- fuel pipes from the high-pressure pump.

Figure 15




Lock rotation of the high-pressure pump gear (1) by applying tool SP. 2263 (2) as illustrated in the figure. Remove the nut (3) and take out the tool (2).

Figure 16



Using tool 99340035 (2) applied as shown in the figure, extract the gear (1) from the shaft of the high-pressure pump (3).

Figure 17



Take out the screws (1) and remove the high-pressure pump (2) from the water pump mounting (3).



Refitting

Re-attachment is carried out by reversing the order of detachment operations. In particular, take care of the following: replace the seal rings, gaskets and high-pressure pipe with new parts; tighten the nuts, screws and fittings to the specified torque values.

NOTE If the engine has run for a period equivalent to = 25,000 km, the toothed timing drive belt must be replaced with a fresh one, no matter what its state of wear.


543210 REPLACING WATER PUMP



Removal

Remove the high-pressure pump as described under the relevant heading.

Figure 18



Take out the screw (2) and remove the fixed tightener (1). Take out the screws (3) and remove the water pump mounting (4).




Refitting

Fit two new seals on the water pump and fit it back on the crankcase, carrying out the operations described for removal in reverse order and tightening the screws or nuts to the prescribed torque.

EMISSIONS**Engine FIAE048IA*A (96 HP) – Engine FIAE048IB*A (116 HP)**

Figure 19



75570

Gas emissions

The engines conform to the Euro3 standards on gas emissions (measurement on engine bench according to OICA cycle), with the following limits fixed by the ESC and ELR 1999/96-2001/27 standards:

ESC:

- CO (carbon monoxide) < 2.1 g/kWh
- NO_x (nitrogen oxide) < 5.0 g/kWh
- HC (unburnt hydrocarbons) < 0.66 g/kWh
- Particulate < 0.13 g/kWh

ELR: 0.8 l/m (opacity)

Test fuel: CEC RF03A084 – S ≤ 0.03%

Smokiness

The engines conform to the limits of smokiness required by EEC standards 72/306, updated 97/20 EC: 1.49 l/m with the following exhaust smoke values:

- Maximum power (Bosch BSU opacimeter degrees) 1.5
- Maximum torque (Bosch BSU opacimeter degrees) 1.5


Noise emissions

Maximum mean noise level, L_{pa}, of the standard engines measured according to ISO Std. 3745 (microphones at 1 m from the engine surfaces):

- Idling (800 rpm) 76 dBA
- Full power (3800 rpm) 96 dBA.

Engine FIAE048IB*B (116 HP with EGR)

Figure 20



75571

Gas emissions

The engine conforms to the Euro3 standards on gas emissions (measurement on engine bench according to OICA cycle), with the following limits fixed by the ESC and ELR 1999/96-2001/27 standards:

ESC:

- CO (carbon monoxide) < 0.95 g/kWh
- NO_x (nitrogen oxide) < 0.78 g/kWh
- HC + NO_x (unburnt hydrocarbons) < 0.86 g/kWh
- Particulate < 0.1 g/kWh

ELR: 0.8 l/m (opacity)

Test fuel: CEC RF03A084 – S ≤ 0.03%

Smokiness

The engine conforms to the limits of smokiness required by EEC standards 72/306, updated 97/20 EC: 1.49 l/m with the following exhaust smoke values:


| | |
|--|-----|
| Maximum power (Bosch BSU opacimeter degrees) | 1.5 |
| Maximum torque (Bosch BSU opacimeter degrees) | 2.5 |
| Full load at 1000 rpm (Bosch BSU opacimeter degrees) | 3.5 |

Noise emissions

Maximum mean noise level, L_{pa}, of the standard engines measured according to ISO Std. 3745 (microphones at 1 m from the engine surfaces):


| | | |
|------------|------------|---------|
| Idling | (800 rpm) | 76 dBA |
| Full power | (3800 rpm) | 96 dBA. |

ENGINE IDENTIFICATION CODE



CHARACTERISTIC CURVES

Figure 20/1



102408

CHARACTERISTIC CURVES OF ENGINE FIAE 0481A

Max OUTPUT 71 kW

96 HP


at 3000 ÷ 3700 rpm

Max TORQUE 240 Nm

24.4 kgm

at 1800 ÷ 2800 rpm

Figure 20/2



102409

CHARACTERISTIC CURVES OF ENGINE FIAE 0481B

Max OUTPUT 85 kW

116 HP


at 3000 ÷ 3900 rpm

Max TORQUE 270 Nm

27.5 kgm

at 1800 ÷ 2800 rpm

Figure 20/3



102410

CHARACTERISTIC CURVES OF ENGINE FIAE 0481M

Max OUTPUT 100 kW

136 HP


at 3600 ÷ 3900 rpm

Max TORQUE 320 Nm

32.6 kgm


at 1700 ÷ 2900 rpm

Figure 21



75243

Figure 22














75244









| | EXAMPLE |
|--|------------------|
| A = IVECO trademark | IVECO |
| B = IVECO name of engine variant ** | F1AE0481A * A001 |
| C = Engine serial number | 1359862 |
| D = 1 st digit, main journal no. 1 (engine front) | 12345 |
| E = Main bearing selection diameters | 1234 |
| F = Barrel selection diameters | |
| G = 1 st digit, cylinder no. 1 (engine front) | |






(**) Data obtainable from "XZ" engine ordering number information

GENERAL SPECIFICATIONS














|  | Type | | FIAE048I A | FIAE048I B | FIAE048I M |
|---|--|-----------------|-------------------------------|--------------|--------------|
|  | Cycle | | Diesel 4 strokes | | |
| | Supply | | Turbocharged with intercooler | | |
| | Injection | | Direct | | |
|  | Number of cylinders | | 4 in line | | |
|  | Bore | mm | 88 | | |
|  | Stroke | mm | 94 | | |
|  | Total displacement | cm ³ | 2300 | | |
| Q | Compression ratio | | 18 | | |
|  | Maximum power | kW (HP) | 71 (96) | 85 (116) | 100 (136) |
| | | rpm | 3000 ÷ 3700 | 3000 ÷ 3900 | 3600 ÷ 3900 |
|  | Maximum torque | kW (HP) | 240 (244) | 270 (275) | 320 (326) |
| | | rpm | 1800 ÷ 2800 | 1800 ÷ 2800 | 1700 ÷ 2900 |
|  | Slow running of engine with no load | rpm | 800 | | |
|  | Fast idling speed of engine with no load | rpm | 4600 | | |
|  | Pressure at T.D.C. | *bar | 20 ÷ 26 | | |
| | Minimum permissible pressure at T.D.C. | *bar | 16 | | |














(*) The pressure is measured by setting the engine turning with the aid of just the starter motor, with an oil temperature of 40 – 50°C.












|  | Type | FIAE048I A | FIAE048I B | FIAE048I M |
|---|--|--|---|------------|
|  | <p>TIMING SYSTEM</p> <p>Start before T.D.C. A</p> <p>end after B.D.C. B</p> <p>Start before T.D.C. D</p> <p>end after B.D.C. C</p> | | <p>14°</p> <p>27°</p> <p>54°</p> <p>10°</p> | |
|  | <p>For timing check</p> <p>Operation</p> <p>X mm</p> <p>X mm</p> | | <p>-</p> <p>-</p> <p>-</p> <p>-</p> | |
|  | SUPPLY | <p>High pressure electronic fuel feed system BOSCH MS6.3 to chassis number (...) and BOSCH EDC16 from chassis number (...).</p> <p>Composed of CP3 high-pressure pump, electro-injectors, hydraulic accumulator (rail), EDC control unit, pressure and temperature sensors</p> | | |
|  | <p>Pump setting With piston no.1 at T.D.C.</p> <p>Start of delivery mm</p> | <p>-</p> <p>-</p> | | |
|  | Electro-injectors type | BOSCH | | |
|  | Injection sequence | 1- 3 - 4 - 2 | | |
|  | Injection pressure bar | 1600 | | |























|  | Type | FIAE0481 A | FIAE0481 B | FIAE0481 M |
|--|--|---|------------|--|
|  Turbocharger shaft radial play Turbocharger shaft end float Maximum stroke of pressure relief valve opening mm Pressure corresponding to maximum stroke: bar | TURBOCHARGING Turbocharger type | With intercooler KKK K03-2072-EDC 5.68 - - 3.5 ±0.5 1.5 ±0.002 | | KKK 2.2 ± 0.5 1.4 ± 0.05 |
|   | LUBRICATION Oil pressure with engine hot (100°C ±5°C): at idling speed bar at top speed bar | forced by gear pump, pressure relief valve, oil filter with integral cartridge with total filtering ≥0.6 4 | | |
| | COOLING Water pump control: Thermostat: start of opening: | by centrifugal pump, thermostat for adjustment, coolant temperature, fan with electromagnetic coupling, radiator, heat exchanger by belt N. I. 82 ±2°C | | |
|  Urania Daily Urania LD 5 | FLUIDS Capacity: engine sump at minimum level liters kg engine sump at maximum level litres kg quantity in circulation in cartridge filter and heat exchanger litres kg quantity of oil for first filling liters kg | 3 2.65 4.3 3.78 1.4 1.23 5.7 5.02 | | |











ASSEMBLY DATA – CLEARANCES

|  | Type | FIAE0481 A | FIAE0481 B | FIAE0481 M |
|---|---|--|--|-----------------|
| CYLINDER ASSEMBLY AND CRANK MEMBERS | | | | |
| mm | | | | |
|  | Cylinder liners: Ø 1 | | | 88.002 ÷ 88.022 |
|  | Cylinder liners: outside diameter Ø length L | - - - | - - - | - - - |
|  | Cylinder liners – crankcase seats (interference) | - | - | - |
|  | Outside diameter Ø 2 | - | - | - |
|  | Cylinder liners: (protrusion from bottom of crankcase) inside diameter  Ø 3 | - - | - - | - - |
|  | Pistons: supplied as spares type measurement X outside diameter Ø 1 seat for pin Ø 2 | FEDERAL MOGUL 46 87.801 ÷ 87.815 | MAHLE MONDIAL 45.5 87.832 ÷ 87.846 | 31.003 ÷ 31.009 |
|  | Piston – cylinder liners | 0.187 ÷ 0.221 | 0.156 ÷ 0.190 | |
|  | Piston diameter Ø 1 | | 0.4 | |
|  | Piston protrusion from crankcase X | | 0.3 ÷ 0.6 | |
|  | Piston gudgeon pin Ø 3 | | 30.990 ÷ 30.996 | |
|  | Piston gudgeon pin – pin seat | | 0.07 ÷ 0.019 | |

|  | Type | FIAE048I A | FIAE048I B | FIAE048I M |
|---|---|------------------------|-----------------|------------|
| CYLINDER ASSEMBLY AND CRANK MEMBERS | | mm | | |
|  | Type of piston | FEDERAL MOGUL | MAHLE MONDIAL | |
| | X1* | 2.197 | 2.200 ÷ 2.230 | |
| | Piston ring slots X2 | 2.040 ÷ 2.060 | 2.050 ÷ 2.070 | |
| | X3 | 2.520 ÷ 2.540 | 2.540 ÷ 2.560 | |
| | * measured on Ø of 85 mm | | | |
|  | Piston rings: | S 1* | 2.068 ÷ 2.097 | |
| | | S 2 | 1.970 ÷ 1.990 | |
| | | S 3 | 2.470 ÷ 2.490 | |
| | * measured on Ø 85 mm | | | |
|  | Piston rings – slots | 1 | 0.103 ÷ 0.162 | |
| | | 2 | 0,060 ÷ 0.100 | |
| | | 3 | 0.050 ÷ 0.090 | |
|  |  > | Piston rings | 0.4 | |
|  | Piston ring end opening in cylinder liner: | X1 | 0.20 ÷ 0.35 | |
| | | X2 | 0.60 ÷ 0.80 | |
| | | X3 | 0.25 ÷ 0.50 | |
|  | Small end bushing seat | Ø 1 | 34.460 ÷ 34.490 | |
| | Connecting rod bearing seat* | Ø 2 | 62.833 ÷ 62.841 | |
| | * connecting rod supplied as spare part | | | |
|  | Small end bushing diameter | | | |
| | outside | Ø 4 | 34.560 ÷ 34.585 | |
| | inside | Ø 3 | 31.010 ÷ 31.020 | |
| | Big end bearing shells supplied as spare part | S | - | |
|  | Small end bushing – seat (interference) | | 0.07 ÷ 0.125 | |
|  | Piston gudgeon pin – bushing | | 0.014 ÷ 0.030 | |
|  |  > | Big end bearing shells | 0.254 - 0.508 | |

|  | Type | FIAE0481 A | FIAE0481 B | FIAE0481 M |
|---|---|------------|------------------------------------|------------|
| CYLINDER ASSEMBLY AND CRANK MEMBERS | | | | |
| | | | mm | |
|  | Measurement | X | 125 | |
| | Maximum error on alignment of connecting rod axes | = | 0.09 | |
|  | Main journals No. 1-2-3-4 No. 5 | Ø 1 | 71.182 ÷ 71.208 76.182 ÷ 76.208 | |
| | Crankpins | Ø 2 | 59.015 ÷ 59.038 | |
| | Main bearing shells | S1* | 2.165 ÷ 2.174 | |
|  | Big end bearing shells | S2* | 1.883 ÷ 1.892 | |
| | * supplied as spare parts | | | |
|  | Main bearing housings No. 1-2-3-4 No. 5 | Ø 3 | 75.588 ÷ 75.614 80.588 ÷ 80.614 | |
|  | Bearing shells - main journals | | 0.032 ÷ 0.102 | |
| | Bearing shells - crankpins | | 0.035 ÷ 0.083 | |
|  | Main bearing shells | | 0.254 ÷ 0.508 | |
| | Big end bearing shells | | 0.254 ÷ 0.508 | |
|  | Main journal for shoulder | X 1 | 31.020 ÷ 31.170 | |
|  | Main bearing housing for shoulder | X 2 | 25.790 ÷ 25.840 | |
|  | Half thrust washers | X 3 | 30.810 ÷ 30.960 | |
|  | Crankshaft shoulder | | 0.060 ÷ 0.260 | |

|  Type | FIAE048I A | FIAE048I B | FIAE048I M |
|---|--|--|------------|
| CYLINDER HEAD – TIMING SYSTEM mm | | | |
|  Guide valve seats on cylinder head | Ø 1 | 9.980 ÷ 10.000 | |
|  Valve guides | Ø 2 Ø 3 | 6.023 ÷ 6.038 10.028 ÷ 10.039 | |
|  Valve guides and seats on head (interference) | | 0.028 ÷ 0.059 | |
|  Valve guides | | 0.05 - 0.10 - 0.25 | |
|  Valves: |  Ø 4 α  Ø 4 α | 5.975 ÷ 5.990 44°45' ± 7.5' 5.975 ÷ 5.990 44°45' ± 7.5' | |
|  Valve stem and relevant guide | | 0.033 ÷ 0.063 | |
|  Seat on head for valve seat: |  Ø 1  Ø 1 | 31.390 ÷ 31.415 31.390 ÷ 31.415 | |
|  Outside diameter of valve seats; angle of valve seats on cylinder head: |  Ø 2 α  Ø 2 α | 31.495 ÷ 31.510 44.5° ± 5' 31.495 ÷ 31.510 44.5° ± 5' | |
|  Recessing | ×  ×  | 0.5 ÷ 0.8 0.5 ÷ 0.8 | |
|  Between valve seat and head |   | 0.08 - 0.12 0.08 - 0.12 | |
|  Valve seats | | - | |

|  Type | FIAE0481 A | FIAE0481 B | FIAE0481 M |
|---|-------------------|---|------------|
| CYLINDER HEAD – TIMING SYSTEM | | | |
| mm | | | |
|  Valve spring height: free spring H under a load of: N243 ± 12 H1 N533 ± 24 H2 | | 54 | 45 35 |
|  Injector protrusion X | X | 2.77 ÷ 3.23 | |
|  Seats for tappets on cylinder head normal Ø | | 12.016 ÷ 12.034 | |
|  Normal diameter tappets | | 11.988 ÷ 12.000 | |
|  Between tappets and seats | | 0.016 ÷ 0.046 | |
|  Camshaft pin seats in cylinder overhead l ⇒ 7 | Ø 1 Ø 2 Ø 3 | 48.987 ÷ 49.013 46.987 ÷ 47.013 35.987 ÷ 36.013 | |
|  Camshaft supporting pins: | Ø 1 Ø 2 Ø 3 | 48.925 ÷ 48.950 46.925 ÷ 46.950 35.925 ÷ 35.950 | |
|  Supporting pins and seats | | 0.037 ÷ 0.088 | |
|  Useful cam height | H H | 3.77 4.203 | |

TOOLS







| TOOL NO. | DESCRIPTION |
|-----------------|---|
| 99305047 | Appliance to check spring loads |
| 99317915 | Set of six box-type wrenches (14-17-19 mm) |
| 99322205 | Rotary telescopic stand for overhauling assemblies (capacity 700 daN, torque 120 daN/m) |
| 99340028 | Extractor for camshaft pulley |
| 99340035 | High-pressure pump toothed pulley extractor |
| 99340057 | Tool to remove crankshaft front gasket |

TOOLS

| TOOL NO. | DESCRIPTION |
|-----------------|--|
| 99340058 | Tool to remove crankshaft rear gasket |
| 99342153 | Tool to extract injectors |
| 99346254 | Keying device for mounting crankshaft front gasket |
| 99346255 | Keying device for mounting crankshaft rear gasket |
| 99360076 | Tool to remove cartridge filters |
| 99360183 | Pliers for mounting rings on engine pistons |

TOOLS

| TOOL NO. | DESCRIPTION |
|-----------------|--|
| 99360191 | Guide for flexible belt |
| 99360260 | Tool for removing and refitting engine valves |
| 99360306 | Tool to retain engine flywheel |
| 99360544 | Arm for removing and refitting engine |
| 99360605 | Band to insert standard and oversized pistons into the cylinders |
| 99360608 | Tool for positioning timing gear |

| TOOLS | |
|-----------------|---|
| TOOL NO. | DESCRIPTION |
| 99360614 |  <p>Tool (2) for camshaft timing</p> |
| 99360615 |  <p>Tool for crankshaft timing</p> |
| 99361038 |  <p>Brackets securing engine to rotary stand 99322205</p> |
| 99367121 |  <p>Manual pump to measure pressure and vacuum</p> |
| 99370415 |  <p>Comparator holder base</p> |
| 99374458 |  <p>Keying device for mounting oil seal gasket on camshaft front cover</p> |


TOOLS

| TOOL NO. | DESCRIPTION |
|----------|--|
| 99389819 | Torque wrench (0-10 Nm) with square 1/4" connection |
| 99389829 | 9x12 coupling torque wrench (5-60 Nm) |
| 99394038 | Milling cutter to regrind injector seat (8140.63 engine excluded) |
| 99395216 | Pair of meters for angular tightening with square 1/2" and 3/4" connection |
| 99395363 | Complete square to check for connecting rod distortion |
| 99395603 | Comparator (0-5 mm) |



TOOLS

TOOL NO.

DESCRIPTION

99395687

Bore meter (50 – 178 mm)


99395849Device for checking belt tension
(frequency from 10.0 to 600 Hz)**99396037**

Centring ring for crankshaft front gasket cover

EXPERIMENTAL TOOLS

This section shows the working drawings for the experimental tools (S.P.) used in overhauling the engine described in this section, which may be made by the repair shops.

VARIA DA ART. COMMERCIALE USAG cod.235L 1/2" - Ch.19
SOLO PER QUANTO INDICATO




Modification: _____

For the permissible errors on the dimensions without tolerance and for other general specifications, see **IVECO** STD 10-2311


| | | | | | |
|---|--|---------------------------------|---------------------------|------------------------------|-------------------|
| MAT. / | | COVER. / | DRAWN UTS (B) | N°DRAWING SP. 2262 | |
| All proprietary rights reserved by IVECO . This drawing shall not be reproduced or in any way utilized, for the manufacture or the component or unit herein illustrated and must not be released to other parties, without written consent. Any infringement will be legally pursued. C/ I.S. 18-0011 | ISO \leq IT8 $\alpha \leq 30'$ Ra \leq 0.4 | Chiave poligonale (19mm) | APPROVED | EXPER. 2262 | SIZE A4 |
| | | per sensore pompa acqua | DATE 19/06/2001 | SHEET | |
| | | | SUPERSEDES | | |
| | | MOTORE F1A | SCALE 1:1 | | |
| | Q.TY 1 | | | | |

02




12 / (6) Sm. 0.5x45°

DETT. PERNO "A"




DETT. PERNO "B"
Varia dal dett. "A"

solo x quanto indicato



For the permissible errors on the dimensions without tolerance and for other general specifications, see **IVECO** STD 10-2311


| | | | |
|---|--------------------------|---------------------------|------------------------------|
| MAT. Ved. dls. ISO 478 R 4 30 R 4 0+ | COVER. Fosfat. | DRAWING UTS (B) | M/DRAWING SP. 2263 |
| | Attrezzo per ritagno | APPROVED | EXPER. SHEET 2263 |
| puleggia dentata comando | | DATE 09/01/2002 | SIZE A3 |
| pompa alta pressione | | SUPERSEDES | |
| MOTORE FIA | | SCALE 1:1 | IVECO |
| L.S. 10-0011 | | Q.TY 1 | |



Modification:

For the permissible errors on the dimensions without tolerance and for other general specifications, see **IVECO** STD 10-2311


| | | | | | | |
|---|---|--|---------------------------|------------------------------|-------------------|--|
| MAT. Pom / Nylon | | COVER. / | DRAWN UTS (B) | N°DRAWING SP. 2264 | | |
| All proprietary rights reserved by IVECO . This drawing shall not be reproduced or in any way utilized, for the manufacture of the component or unit herein illustrated and must not be released to other parties, without written consent. Any infringement will be legally pursued. C/ I.S. 18-0011 | ISO \leq IT8 4 \leq 30' Ra \leq 0.4 | Perni di centraggio sovratesta e per piantaggio guarnizione | APPROVED | EXPER. 2264 | SIZE A4 | |
| | | guida valvole | DATE 19/06/2001 | SHEET | | |
| | | | SUPERSEDES | | | |
| | | MOTORE F1A | SCALE 1:1 | IVECO | | |
| | | Q.TY 2 | | | | |



For the permissible errors on the dimensions without tolerance and for other general specifications, see **IVECO** STD 10-2311

| | | | | | |
|--|--|-----------------------|----------------|-----------------|-----------------|
| MAT. | | COVER | DRAWING | NDRAWING | |
| Vedi dis. | | Vedi dis. | UTS (B) | SP. 2271 | SP. 2271 |
| N° 50x50xsp.7 spigoli vivi Mat. Fe430 Fosfatato | | Supporto per sostegno | APPROVED | EXPER. | SIZE |
| N° 8 VITI T.E. M8x16 Mat. CL. 8.8 | | testa cilindri | DATE | 2271 | A3 |
| N° 8 FORI Ø9 | | | SUPERSIDES | 22/11/2001 | SHEET |
| N° 4 FORI M11x1.5 | | | SCALE | 1:2 | |
| N° 4 FORI M12x1.5 | | | Q.TY | 1 | |
| Mat. Alluminio Anticorodal 6060 T6 | | | | | |
| Sm. 5x45° | | | | | |
| Sm. 3x45° | | | | | |
| Sm. 20x45° | | | | | |
| M8 | | | | | |
| 3 | | | | | |
| 12 | | | | | |
| 0 / (3) Sm. 0.5x45° | | | | | |
| ISO 9001 | | | | | |
| I.S. 10-0011 | | | | | |
| IVECO | | | | | |

VARIA DA ART. COMMERCIALE USAG cod.235EL 1/4" - Ch.8
SOLO PER QUANTO INDICATO




6
Sm. 0.5x45°

Modification:

For the permissible errors on the dimensions without tolerance and for other general specifications, see **IVECO** STD 10-2311

| | | | | | | | | |
|---|----------------------------------|--------------------------------------|--|-------------------------|-------------------|------------------------------|--|--|
| MAT. / | | COVER. / | | DRAWN UTS (B) | | N°DRAWING SP. 2275 | | |
| All proprietary rights reserved by IVECO . This drawing shall not be reproduced or in any way utilised, for the manufacture or the component or unit herein illustrated and must not be released to other parties, without written consent. Any infringement will be legally pursued. C/ I.S. 18-0011 | ISO ≤ IT8 α ≤ 30° Ra ≤ 0.4 | Bussola (8 mm) per montaggio/ | | APPROVED | EXPER. | SIZE | | |
| | | smontaggio candele | | DATE | 2275 | A4 | | |
| | | | | SUPERSEDES | 25/07/2001 | SHEET | | |
| | | | | SCALE | 1:1 | | | |
| | | MOTORE F1A | | Q.TY | 1 | IVECO | | |


PARTIC. DENTE - Scala 10:1



N° 6 DENTI - ELICA SINISTRA - INCLINAZIONE 6°

For the permissible errors on the dimensions without tolerance and for other general specifications, see **IVECO** STD 10-2311


| | | |
|--|---------------------------|------------------------------|
| MAT. UNI U100WC HRC 62±64 COVER / | DRAWN UTS (B) | M/DRAWING SP. 2310 |
| | APPROVED | EXPR. 2310 |
| Lisciatolo per guida valvole | DATE 10/12/2001 | SHEET A3 |
| ISO 4178 Ra 0.4 Ra 0.8 | SUPERSEDES | |
| 1.8.18-0011 C | SCALE 1:1 | IVECO |
| Any infringement will be legally pursued. IVECO hereby illustrated and must not be released to other users, for the manufacture of the component or unit. This drawing shall not be reproduced or in any way used, without written consent. | Q.TY 1 | |



Modification:

For the permissible errors on the dimensions without tolerance and for other general specifications, see **IVECO** STD 10-2311

| | | | | | |
|---|----------------------------------|---------------------------------|---------------------------|------------------------------|-------------------|
| MAT. 39NiCrMo3 Bon. | | COVER. Fosfat. | DRAWN UTS (B) | N°DRAWING SP. 2311 | |
| All proprietary rights reserved by IVECO . This drawing shall not be reproduced or in any way utilized, for the manufacture of the component or unit herein illustrated and must not be released to other parties, without written consent. Any infringement will be legally pursued. C/ I.S. 18-0011 | ISO ≤ IT8 4 ≤ 30' Ra ≤ 0.4 | Battitolo per piantaggio | APPROVED | EXPER. 2311 | SIZE A4 |
| | | guida valvole | DATE 10/12/2001 | SHEET | |
| | | (usare con sp. 2312) | SUPERSEDES | | |
| | | MOTORE F1A | SCALE 1:1 | | |
| | | Q.TY 1 | | | |





For the permissible errors on the dimensions without tolerance and for other general specifications, see **IVECO** STD 10-2311

Modification:

| | | | | | |
|--|----------------------------------|----------------------------------|---------------------------|------------------------------|-------------------|
| MAT. 39NiCrMo3 Bon. | | COVER. Fosfat. | DRAWN UTS (B) | N°DRAWING SP. 2312 | |
| All proprietary rights reserved by IVECO . This drawing shall not be reproduced or in any way utilized, for the manufacture or the component or unit herein illustrated and must not be released to other parties, without written consent. Any infringement will be legally pursued. q I.S. 18-0011 | ISO ≤ IT8 α ≤ 30° Ra ≤ 0.4 | Battitoio per spiantaggio | APPROVED | EXPER. 2312 | SIZE A4 |
| | | guida valvole | DATE 10/12/2001 | SHEET | |
| | | | SUPERSEDES | | |
| | | MOTORE F1A | SCALE 1:1 | | |
| | | Q.TY 1 | | | |

N°4 viti autoperforanti a testa bombata



$\phi 4.8 \times 45$ - UNI 8118



Modification:




For the permissible errors on the dimensions without tolerance and for other general specifications, see **IVECO** STD 10-2311

| | | | | | |
|---|---|---|---------------------------|------------------------------|-------------------|
| MAT. Fe430B | | COVER. Fosfat. | DRAWN UTS (B) | N°DRAWING SP. 2325 | |
| All proprietary rights reserved by IVECO . This drawing shall not be reproduced or in any way utilized, for the manufacture or the component or unit herein illustrated and must not be released to other parties, without written consent. Any infringement will be legally pursued. C/ I.S. 18-0011 | ISO \leq IT8 $\alpha \leq 30^\circ$ Ra \leq 0.4 | Attrezzo per estrazione | APPROVED | EXPER. 2325 | SIZE A4 |
| | | guarnizione albero distribuzione | DATE 01/02/2002 | SHEET | |
| | | | SUPERSEDES | | |
| | | MOTORE F1A | SCALE 1:1 | IVECO | |
| | | Q.TY 1 | | | |



Modification:

For the permissible errors on the dimensions without tolerance and for other general specifications, see **IVECO** STD 10-2311

| | | | | | |
|---|----------------------------------|---|---------------------------|---|-------------------|
| MAT. C40 Bon. | | COVER. Fosfat. | DRAWN UTS (B) | N°DRAWING SP.2341 | |
| All proprietary rights reserved by IVECO . This drawing shall not be reproduced or in any way utilized, for the manufacture or the component or unit herein illustrated and must not be released to other parties, without written consent. Any infringement will be legally pursued.  I.S. 18-0011 | ISO ≤ ITB α ≤ 30° Ra ≤ 0.4 | Chiave per tensionamento tenditore | APPROVED | EXPER. 2341 | SIZE A4 |
| | | cinghia compressore condizionatore | DATE 05/03/2002 | SHEET | |
| | | | SUPERSEDES |  | |
| | | | SCALE 1:1 |  | |
| | MOTORE F1A | Q.TY 1 | | | |

TIGHTENING TORQUE

| PART | TORQUE | |
|--|------------|-----------|
| | Nm | kgm |
| Cylinder head central fixing screw | | |
| first phase: pre-tightening | 100 | 9.8 |
| second phase: angle | 90° | |
| third phase: angle | 90° | |
| Cylinder head side fixing screw | | |
| first phase: pre-tightening | 50 | 4.9 |
| second phase: angle | 60° | |
| third phase: angle | 60° | |
| Hex screw with flange M8x1.25 L 40 fixing overhead | 25 | 2.5 |
| Hex screw with flange M8x1.25 L 77 fixing overhead | 25 | 2.5 |
| Central base fastening screw | | |
| first phase: pre-tightening | 50 ± 5 | 5 ± 0.5 |
| second phase: angle | 60° ± 2.5° | |
| third phase: angle | 60° ± 2.5° | |
| Outer base fastening screw | 36 + 30 | 3.6 + 3 |
| Connecting rod cap fixing screw | | |
| first phase: pre-tightening | 40 | 4 |
| second phase: angle | 60° | |
| Hex screw with flange M12x1.25 L 43 fixing engine flywheel | | |
| first phase: pre-tightening | 30 | 3 |
| second phase: angle | 90° | |
| Cylindrical socket head screw fixing phonic wheel to crankshaft • | 15 | 1.5 |
| Nozzle union | 25 | 2.5 |
| Tapered threaded socket plug R 3/8" x 10 oil circuit | 22 | 2.2 |
| Water drain plug M14x1.50 L 10 | 25 | 2.5 |
| Union on crankcase for oil return from turbocharger R 3/8" | 50 | 5 |
| Screw M6x1 fixing suction strainer | 10 | 1 |
| Male threaded socket plug M28x1.5 L11 fixing | 100 | 9.8 |
| Hex screw with flange M8x1.5 L 35 fixing frame retaining oil sump | 25 | 2.5 |
| Hex screw with flange M6x1 L30 fixing frame retaining oil sump | 10 | 1 |
| Hex screw with flange M6x1 L25 fixing frame retaining oil sump | 10 | 1 |
| Tapered threaded socket plug M6x1x8.5* | 2 | 0.2 |
| Male threaded plug with O-ring M22x1.5 L16 | 50 ± 10 | 5 ± 1 |
| Hex screw with flange M6x1 L20 fixing oil vacuum pump assembly | 10 | 1 |
| Hex screw with flange M6x1 L50 fixing oil vacuum pump assembly | 10 | 1 |
| Oil filter cartridge M22x1.5 L7 | 25 | 2.5 |
| Union fixing heat exchanger M22x1.5 | 80 ± 5 | 7.8 ± 0.5 |
| Hex screw with flange M12x1.25 L55 fixing toothed pulley controlling timing system | 90 | 8.8 |
| Hex screw with flange M18x1.5 L78 fixing pulley on crankshaft | 300 | 30 |
| Hex screw with flange M8x1.25 L45 fixing pulley on damper | 30 | 3 |
| Hex screw with flange M8x1.25 L60 fixing automatic tightener | 36 | 3.6 |
| High pressure pump gear fastening hex nut with flange M14x1.5 | 70 | 6.9 |
| Fastener for complete guide pulley roller for timing belt M8x1.25 L45 | 25 | 2.5 |


• Thread pre-treated with Loctite.

* Apply Loctite on the thread.

| PART | TORQUE | |
|--|---------|-----------|
| | Nm | kgm |
| Tapered threaded socket plug R 3/8" x 10 | 17 | 1.7 |
| Tapered threaded socket plug R 1/8" x 8 | 7 | 0.7 |
| Tapered threaded socket plug R 1/4" x 9 | 9 | 0.9 |
| Hex screw with flange M12x1.25 L65 fixing gear for camshaft chain | 115 | 11.3 |
| Hex screw with flange M6x1 L25 fixing chain cover | 10 | 1 |
| Hex screw with flange M6x1 L35 automatic tightener | 10 | 1 |
| Threaded plug M14x1.5 L10 | 25 | 2.5 |
| Ball joint fastening screw M6x1x9 | 10 | 1 |
| Hex screw with split washer and flat washer fixing water pump M8x1.25 L28 | 25 | 2.5 |
| Hex screw with split washer and flat washer fixing water pump M6x1 L20 | 10 | 1 |
| Flanged screw M8x1.25 fixing water outlet union | 25 | 2.5 |
| Flanged screw M8x1.25 fixing piezometric tube on intake manifold | 25 | 2.5 |
| Flanged nut M8x1.25 fixing piezometric tube on bracket | 18 | 1.8 |
| Self-tapping screw L16 fixing bracket on coalescence filter cover | 6 | 0.6 |
| Flanged screw M6x1x16 fixing piezometric tube | 10 | 1 |
| Self-tapping flanged screw L14 fixing piezometric tube on front cover | 2 | 0.2 |
| Coupling M10x1x10 fixing vapour outlet | 12 | 1.2 |
| Union M10x1x19 fixing vapour outlet | 14 ÷ 16 | 1.4 ÷ 1.6 |
| Hex screw with flange M8x1.25 L25 fixing thermostat | 25 | 2.5 |
| Hex screw with flange M8x1.25 L100 fixing air-conditioner compressor | 25 | 2.5 |
| Hex screw with flange M8x1.25 L120 fixing air-conditioner compressor | 25 | 2.5 |
| Hex screw with flange M8x1.25 L50 fixing air-conditioner compressor mounting | 25 | 2.5 |
| Cylindrical socket head screw M8x1.25x40 fixing air-conditioner compressor drive belt guide pulley | 25 | 2.5 |
| Hex screw fixing bottom of alternator M10x1.25 L40 and M10x1.5 L50 | 50 | 5 |
| Hex nut with flange fixing top of alternator M10x1.25 L10 | - | - |
| Fastener for complete guide pulley roller for timing belt M10x1.25 L50 | 40 | 4 |
| Allen head screw fixing automatic tightener M8x1.25 L65 | 25 | 2.5 |
| Hex screw with flange M8x1.25 L45 fixing pulley on damper | 30 | 3 |
| Screw plug with washer M12x1.5 L20 | 30 | 3 |
| Vacuum pump coupling M10x1 on oil vacuum pump assembly | 10 | 1 |
| Flanged screw M6x1x27 fixing timing cover | 7.5 | 0.7 |
| Hex screw with flange M6x1 L27 fixing coalescence filter assembly | 10 | 1 |
| Screw M6x1 L12 fixing sump blow-by oil drain pipes | 10 | 1 |
| Union M20x1.5 blow-by breather socket | 30 | 3 |
| Hex screw with flange M8x1.25 L90 fixing intake manifold | 30 | 3 |
| Flanged nut M8x1.25 fixing exhaust manifold | 25 | 2.5 |
| Flanged screw M6x1 fixing oil fillpipe | 10 | 1 |
| Flanged screw M8x1.25 fixing oil dipstick pipe | 18 | 1.8 |
| Glow plug M8x1 L11.5 | 8 ÷ 11 | 0.8 ÷ 1.1 |
| High-pressure injection system | | |
| Hex screw fixing hydraulic accumulator M8x1.25 L50 | 28 | 2.8 |
| Screw M8x1.25 L30 fixing high-pressure pump | 25 | 2.5 |
| Screw M8x1.25 fixing bracket anchoring fuel delivery pipe | 25 | 2.5 |
| Fitting for fuel pipe M14x1.50 (forged hydraulic accumulator) | 25 ± 2 | 2.5 ± 0.2 |
| Fitting for fuel pipe M12x1.50 (forged hydraulic accumulator) | 25 ± 2 | 2.5 ± 0.2 |
| Hex screw fixing electro-injector retaining bracket | 28 | 2.8 |
| Hex screw with flange fixing low-pressure fuel pipes M6x1 L30 | 10 | 1 |

| PART | TORQUE | |
|--|----------|-----------|
| | Nm | kgm |
| Pipe fitting M12x1.5 to secure electric injectors side and high pressure pump side piping (welded hydraulic accumulator) | 25 ± 2 | 2.5 ± 0.2 |
| Pipe fitting M14x1.5 to secure hydraulic accumulator side piping (welded hydraulic accumulator) | 19 ± 0.2 | 1.9 ± 0.2 |
| Union M12x1.5 L23 - L24 and M12x1.5 L12 for fixing fuel pipes | 25 | 2.5 |
| Fitting for fastening multiple filler to high pressure pump M12x1.5 L24 | 25 | 2.5 |
| Flanged screw M12x1.5 fixing water temperature sensor | 30 | 3 |
| Flanged screw M6x1 fixing air temperature sensor | 10 | 1 |
| Flanged screw M6x1 fixing engine speed sensor | 10 | 1 |
| Socket-head screw M6x1 fixing timing sensor | 10 | 1 |
| Screw M8x1.25 fixing air duct bracket | 28 | 2.8 |
| Screw M8x1.25 fixing air duct | 25 | 2.5 |
| Cylindrical socket-head screw M6x1 for V-clamp | 8 | 0.8 |
| Nut M8x1.25 fixing turbocharger | 25 | 2.5 |
| Flanged screw M8x1.25 fixing turbocharger outlet pipe | 25 | 2.5 |
| Fitting M14x1.5 or M12x1.5 for pipe delivering oil to turbocharger | 35 | 3.5 |
| Fitting M22x1.5 for oil return pipe from turbocharger | 45 | 4.5 |
| Flanged screw fixing oil return pipe from turbocharger | 10 | 1 |
| Hex screw with flange M8x1.25 L40 fixing power steering pump | 25 | 2.5 |
| Hex screw with flange M12x1.25 L155 fixing electromagnetic coupling mounting | 90 | 8.8 |
| Hex screw with flange M8x1.25 L20 fixing manoeuvring hooks | 25 | 2.5 |
| Flanged screws M10x1.25 fixing engine mounts | 50 | 5 |
| Oil level sensor M12x1.25 | 25 | 2.5 |
| Thermometric switch/transmitter M16x1.5 | 25 | 2.5 |
| Oil pressure switch M14x1.5 | 40 | 4 |
| Cylindrical socket-head screw M8x1.25 fixing E.G.R. valve | 25 | 2.5 |
| Flanged screw M8x1.25 fixing E.G.R. heat exchanger | 25 | 2.5 |
| Flanged nut M8x1.25 fixing elbow | 25 | 2.5 |
| Compensator fastening nut M8x1.25 | 25 | 2.5 |
| Oil pressure regulation valve cap | 100 | 10 |
| Power unit suspension | | |
| Screw (M8x16) securing the elastic dowel to the gearbox cross-member | 23.5±2.5 | 2.3±0.2 |
| Nut (M12) securing the gearbox cross-member to the chassis | 92±9 | 9.2±0.9 |
| Nut (M12) securing the engine supports to the elastic dowels | 49±4 | 4.9±0.4 |
| Nut (M12) securing the gearbox bracket onto the rear cross-member elastic dowel | 49±4 | 4.9±0.4 |
| Locknut (M10) with flange, securing the engine supports to the chassis | 52.5±5.5 | 5.2±0.5 |
| Screw (M10x30) securing the gearbox support to the gearshift | 46.5±4.5 | 4.6±0.4 |


Figure 23



75815

LONGITUDINAL CROSS-SECTION OF ENGINE WITH E.G.R.

Figure 24




75816

TRANSVERSE CROSS-SECTION OF ENGINE WITH E.G.R.

OVERHAULING ENGINE FIA

540110 DISASSEMBLING THE ENGINE AT THE BENCH

Figure 25



75245


If the following parts have not already been removed, do so now:

- top soundproofing cover;
- rail guard;
- engine cable, disconnecting its electrical connections from: thermostat temperature sensor, timing sensor, engine speed sensor, pressure regulator, rail pressure sensor, intake manifold air temperature/pressure sensor.

To be able to fit the brackets 99361038 onto the crankcase to secure the engine to the stand for overhauling, it is necessary to remove the left and right engine mounts (3) and disconnect the oil pipe (2) from the turbocharger (1) and from the crankcase.

NOTE Block the turbocharger air/exhaust gas inlets and outlets to prevent foreign bodies getting inside.

Figure 26




75246

Fit the brackets 99361038 (2) to the crankcase and use these to secure the engine to the rotary stand 99322205 (3). Drain the oil from the engine by removing the plug from the oil sump.

Disconnect the fan from the electromagnetic coupling (1).


Figure 27



75247

Take off screw (2), if present, and dismount belt tensioner (1). Take off the belt (4) driving the air-conditioner compressor (3).


Figure 28



88614

Or, on the engines with elastic belt (2), with a suitable tool, take the belt off pulleys (1 and 3).


Figure 29



75248

Using the specific wrench on the automatic tightener (2), slacken the tension of the belt (1) and remove it.


Figure 30



75249

Take out the screw (4) and remove the automatic tightener (3). Take out the screw (2) and remove the fixed tightener (1). Take out the screws (5) and remove the pulley (6).


Figure 31



75250

Take out the bolt (1), the bottom screws (3 and 4) and remove the alternator (2) from the mounting (5).


Figure 32



75251

Take out the screw (3) and remove the mounting (1) of the power steering pump (4). Using a suitable wrench, remove the oil level sensor (2).


Figure 33



75252

Take out the screws (2) and (3) and remove the mounting (1) together with the electromagnetic coupling (4).


Figure 34



75253

Take out the screws (1) and remove the timing cover (2).


Figure 35



75254


Take out the screw (3) and remove the tightener (4). Take out the screws (1) and (5) and remove the gears (2) and (6). Remove the toothed belt (7).

Figure 36




Take out the screws (2) and remove the bracket (1). Take out the screws (4) and remove the coalescence filter (3). Take off the nuts (6) and remove the oil fillpipe (5).

Figure 37




Press the springs (3) in the direction shown by the arrow and disconnect the fittings of the pipe (1) recovering fuel from the electro-injectors (2).

Figure 38




Disconnect the fuel pipes (2) from the electro-injectors (3) and from the hydraulic accumulator (1) (rail).

Figure 39




Take out the screws (2) and the brackets (3) fixing the electro-injectors (1) to the cylinder overhead.

Figure 40




Using tool 99342153 (1) extract the electro-injectors (2) from the overhead.

Figure 41



Take out the screw (4) and extract the oil dipstick pipe (3) from the crankcase. Disconnect the pipe (2) from the hydraulic accumulator (1) and from the high-pressure pump (5).

Figure 42




75261

Only for forged version hydraulic accumulator, take off pipe fitting (4) and disconnect piping (5) for fuel recovery from overpressure valve (3).

Take out the screws (1) and remove the hydraulic accumulator (2).


Figure 43



75262

Disconnect the fuel recovery pipes (4), (5) and (6) from the high-pressure pump (2), removing the couplings (1) and (3).

Figure 44



75263


For engines with E.G.R. only

Loosen the clamp (3) and disconnect the pipe (4) from the heat exchanger (1).

Take off the nuts (2) and (6) and remove the heat exchanger (1) together with the E.G.R. valve (5).

Take out the screws (8) and remove the flange (7).


Figure 45



75264

Take out the screw (4), loosen the clamp (1) and disconnect the air duct (5) from the turbocharger (2) and from the overhead (3).

Figure 46





75265

Disconnect the oil pipe (7) from the coupling of the cylinder head (1) and from the coupling of the turbocharger (3).

Take off the nuts (2) and remove the turbocharger (3) with the associated gasket from the exhaust manifold (6).

Take off the nuts (5) and the spacers (4), remove the exhaust manifold (6) with the associated gasket from the cylinder head (1).


Figure 47



75266

Take off screws (1) and disconnect inlet manifold (2) with its gasket.
Using wrench SP.2275 (3), remove the glow plugs (4).


Figure 48



75267

Dismount sensor (3).
Take off the nut (1) and remove the timing sensor (2). Using wrench SP.2262 (7), remove the temperature sensors (4).
Take out the screws (5) and remove the thermostat box (6).


Figure 49



75268

Take out the screws (1) and remove the overhead (2).


Figure 50



75269

Take off the gasket (1) and remove the hydraulic tappets together with the rocker arms (2).

Figure 51




75270

Take out the screws (1) and remove the cylinder head (2).

NOTE Check the protrusion of the pistons as described under the relevant heading to check the possibility of facing the crankcase if it has deformed.


Figure 52



75271

Block rotation of the high-pressure pump gear (1) by applying tool SP 2263 (2) as shown in the figure. Take off the nut (3) and remove the tool (2).


Figure 53



75272

Using tool 99340035 (2), applied as in the figure, extract the gear (1) from the shaft of the high-pressure pump (3).


Figure 54



75273

Take out the screws (1) and remove the high-pressure pump (2) from the water pump mounting (3).


Figure 55



75274

Take out the screws (2) and remove the water pump assembly (2).

Figure 56




75275

Remove the plug (6) from the oil pump – vacuum pump assembly (1).

Position the crankshaft so as to be able to insert tool 99360615 (5) into its hole through the hole in the plug (6) and block rotation of the crankshaft.

Take out the screw (3) with the spacer (4) beneath and remove the gear (2).

Figure 57




75276

Apply tool 99340057 (4) to the front O-ring (3) of the crankshaft and remove it from the oil pump – vacuum pump assembly (2).


Take out the screws (1) and remove the oil pump – vacuum pump assembly (2).

Figure 58




Using tool 99360076 (1), remove the oil filter (2).

Figure 59




Take out the coupling (2) and remove the heat exchanger (1).

Figure 60




Take out the screws (2) and remove the air-conditioner compressor (1) (if applicable).

Figure 61




Take out the screw (2) and remove the speed sensor (1). Take out the screws (4) and remove the compressor mounting (3).

Figure 62




Take out the plug (2) with the seal (3) and extract the oil pressure control valve (1).

Figure 63



Undo the screws (2) and remove the oil sump (1) with the associated gasket and frame (3).


Figure 64



75283

Take out the screws (2), (3), (4) and (5) and remove the suction strainer (1) together with the pipe (6).


Figure 65



75284

Take out the screws (2) and remove the connecting rod caps (3).
Extract the pistons (1) from the top of the crankcase.


Figure 66



75285

Block rotation of the flywheel (1) with tool 99360306 (3).
Take out the screws (2) and remove the engine flywheel (1).
Take out the screw (5) and remove the guard (4).

Figure 67




75286

Apply tool 99340058 (2) to the rear O-ring (1) and extract it from the crankcase.


NOTE On the same side of the connecting rod and its associated cap, indicate the number of the cylinder from which the connecting rod has been removed. Keep the bearing shells in their respective housings since, if they are used, they will need to be fitted in the position found during removal.

Figure 68




Using an appropriate wrench and a hex-fluted wrench, unscrew the screws (1) and (2) and remove the crankcase base (3).

Figure 69



NOTE Note the assembly position of the bottom main bearing shells (1) since, if they are reused, they will need to be fitted in the position found during removal.

Figure 70




With the aid of a hoist and a rope, remove the crankshaft (1).

NOTE Note the assembly position of the top main bearing shells (2) since, if they are reused, they will need to be fitted in the position found during removal.

The central half ring (3) is fitted with thrust half-washers.

Figure 71




Take out the couplings (1) and remove the oil jets (2).

NOTE On completing engine removal, it is necessary to clean the removed parts thoroughly and check their integrity. The following pages give the instructions for the main checks and measurements to make in order to determine whether the parts can be reused.

REPAIRS CYLINDER BLOCK Checks and measurements


Figure 72



After removing the engine, thoroughly clean the cylinder-crankcase assembly. Use the rings 99365508 to carry the cylinder block.

Carefully check that the crankcase has no cracks in it. Check the state of the plugs. If they are rusty or there is any doubt about their seal, replace them. Examine the surfaces of the cylinder liners; they must show no sign of meshing, scoring, ovalization, taper or excessive wear. The inside diameter of the cylinder liners is checked, to ascertain the extent of ovalization, taper and wear, using the bore meter 99395687 (I) fitted with a dial gauge previously reset on the ring gauge of the diameter of the cylinder liner or on a micrometer.

Figure 73



* Surface roughness parameters:


- Rt = 4 ÷ 10 μm
- Rz = 3 ÷ 8 μm
- Ra = 0.25 ÷ 0.6 μm
- Wt < 1.5 μm

Permissible surface porosity for machined cylinder (see Figure 75)

ZONE B1 = Area of greatest mechanical stress, segment/liner contact: No.2 non-continuous porosities are permissible max. 0.5x0.5.

ZONE B2 = Surface involved in segment rubbing: No.2 non-contiguous porosities are permissible max. 1x0.8.


Figure 74



The measurements must be made for each single cylinder at three different heights up the liner and on two planes at right angles to each other: one parallel to the longitudinal axis of the engine (B) and the perpendicular (A); the greatest wear is generally found on this last plane with the first measurement.


On finding ovalization, taper or wear, go ahead and bore/grind and finish the face of the cylinder liners. The refacing of the cylinder liners should be done in relation to the diameter of the pistons supplied as spare parts oversized by 0.4 mm of the nominal value and to the prescribed assembly clearance.

Figure 75



Checking head mating surface on cylinder block

Figure 76



75296


See that the head mating surface, on the cylinder block, has no deformation.

This check can be made, after taking out the grub screws (3), with a surface plate spread with carbon black or with a calibrated rule (1) and a feeler gauge (2). After ascertaining the areas of deformation, level the bearing surface with a grinding machine.

NOTE The crankcase can only be surfaced after making sure that, on completing the work, the piston protrudes from the cylinder liner by no more than the prescribed value.

5408 CRANKSHAFT
540810 Measuring main journals and crank pins

Figure 78



75298

On finding signs of seizure, scoring or excessive ovalization on main journals and crankpins, it is necessary to regrind the pins. Before grinding the pins (2), measure the shaft pins with a micrometer (1) to establish to what diameter it is necessary to decrease the pins.

NOTE It is advisable to enter the measurements in a table. See Figure 77.

Figure 77

| | NOMINAL VALUE | | NOMINAL VALUE | | |
|-----------|---------------|--|---------------|--|---------------|
| | 71.182 | | 76.182 | | |
| | 71.208 | | 76.208 | | |
| MINIMUM Ø | | | | | |
| MAXIMUM Ø | | | | | |
| | | | | | |
| MINIMUM Ø | | | | | NOMINAL VALUE |
| MAXIMUM Ø | | | | | 59.015 |
| | | | | | 59.038 |

75297

TABLE IN WHICH TO ENTER THE MEASUREMENTS OF THE CRANKSHAFT MAIN JOURNALS AND CRANKPINS


NOTE The main journals and crankpins must always be ground to the same undersize class. The undersizing performed, on the main journals or crankpins, must be marked by punching on the side of crank arm no. 1.

For undersized crankpins, letter M.
For undersized main journals, letter B.
For undersized crankpins and main journals, letter MB.

The undersize classes are:
0.254 – 0.508 mm.

Checking crankshaft

Figure 79




MAIN CRANKSHAFT TOLERANCES

| TOLERANCES | TOLERANCE CHARACTERISTIC | SYMBOL |
|-------------|-----------------------------|----------|
| SHAPE | Circularity | ○ |
| | Cylindricality | <i>d</i> |
| DIRECTION | Parallelism | // |
| | Perpendicularity | ⊥ |
| POSITION | Concentricity or coaxiality | ⊙ |
| OSCILLATION | Circular oscillation | ↗ |
| | Total oscillation | ↗↘ |

| CLASS OF IMPORTANCE ASCRIBED TO THE PRODUCT CHARACTERISTICS | SYMBOL |
|---|--------|
| CRITICAL | ⊙ |
| IMPORTANT | ⊕ |
| SECONDARY | ⊖ |

Figure 80



45066

NOTE The checks on the tolerances indicated in the figures must be made after grinding the crankshaft pins.

SYMMETRY BETWEEN MAIN JOURNALS AND CRANKPINS


1. Crankpins
2. Main journals
3. Normal position

After grinding, keep to the following:

- Round off the edges of deburring the holes for lubrication of the main journals and crankpins.

JOURNAL ON TIMING SYSTEM SIDE


Figure 81



75300

INTERMEDIATE JOURNALS No. 2-4


Figure 82



75301

INTERMEDIATE JOURNAL No. 3

Figure 83




75302

MAIN DATA OF MAIN JOURNALS AND CRANKPINS

JOURNAL ON FLYWHEEL SIDE


Figure 84



75303

CRANKPINS

Figure 85



75304

* On both races, on all 360°.

NOTE Since, during the 0.254 and 0.508 mm undersizing on the diameter of the crankpins and main journals, the rolled portion of the side races of the pins may get involved, it is necessary to turn the races keeping to the data given in the figure and to do the rolling keeping to the following instructions.


Rolling force:

- 1st main journal 925 ± 25 daN.
- 2nd – 3rd – 4th – 5th main journal 1850 ± 50 daN.
- crankpin 1850 ± 50 daN.

- Rolling turns: 3 approach, 12 effective, 3 out.
- Rolling speed: 56 rpm.
- Decrease in crankpin race depth after rolling: 0.15 – 0.30 mm*.
- Decrease in main journal race depth after rolling: 0.15 – 0.30 mm*.

* Measured with calibrated rollers Ø 2.5 mm.

Figure 86



Take out the screws (4) and replace the phonic wheel (3). The screws (4) are coated with LOCTITE 218 and must be replaced with fresh ones after each disassembly. They must be tightened to a torque of 15 Nm.

Replacing timing control gear

On finding the timing control gear teeth (1) damaged or worn, remove them from the crankshaft (2) using a suitable extractor.


The new gear is fitted onto the crankshaft by heating it to a temperature of 200°C for no longer than 15 minutes.

On completing assembly and after the gear has cooled, it must withstand a torque of 150 Nm without slipping.

ENGINE ASSEMBLY

The following parts must be replaced with new ones at the time of assembly: retaining rings, seals and gaskets, screws whose thread is coated with sealant.


Figure 87



Fit on the oil spray nozzles (2) and tighten the couplings (1) to the prescribed torque.

Assembling main bearings

Figure 88



NOTE Not having found it necessary to replace the main bearings, they need to be fitted back on in the same sequence and position found upon disassembly.

The main bearings (1) are supplied as spare parts undersized on the inside diameter by 0.254 ± 0.508 mm.


NOTE Do not do any accommodating on the bearings.

Thoroughly clean the top main bearing shells (1) and position them in the crankcase.

NOTE The middle half ring (2) is fitted with thrust washers.

540811 Measuring main journal assembly clearance


Figure 89



Mount the crankshaft (1). Check the clearance between the crankshaft main journals and their respective bearings by proceeding as follows:

- Thoroughly clean the pins.
- Apply a calibrated wire onto the main journals.


Figure 90



75288

Thoroughly clean the bottom main bearing shells (2) and mount them in the crankcase base (1).

Figure 91



75309


Mount the crankcase base (12).

Tighten the screws in the sequence shown in the figure in three steps:

- Step 1: with a torque wrench, to a torque of 50 Nm.
- Step 2: closing to an angle of 60°.
- Step 3: closing to an angle of 60°.

NOTE Use tool 99395216 (11) for the angle closing.

Figure 92




75310

- Remove the bottom crankcase.

The clearance between the main bearings and their associated pins is measured by comparing the length of the calibrated wire (1), at the point of greatest crushing, with the graduated scale on the casing containing the calibrated wire. The numbers on the scale indicate the clearance of the coupling in millimetres, which must be 0.032 ± 0.102 mm. If the clearance is not as prescribed, replace the bearings and repeat the check.

Checking crankshaft end float

Figure 93



75311


The end float is checked by setting a dial gauge (1) with a magnetic base on the crankshaft (2) as shown in the figure. The normal assembly clearance is 0.060 – 0.310 mm.

If you find the clearance to be greater than as required, replace the rear main bearing shells carrying the thrust bearings and repeat the clearance check between the crankshaft pins and the main bearing shells.

If the end float of the crankshaft does not come within the prescribed values, it is necessary to grind the crankshaft and accordingly change the main bearing shells.

NOTE: The middle main bearing has half thrust washers integrated in it, so it performs the function of a thrust bearing. It is supplied as a spare part only with the normal shoulder thickness.

Figure 94




85842

Thoroughly clean the crankcase / crankcase base mating surface.

Apply, on base, sealant LOCTITE 510 IVECO no. 93162432, as indicated in the scheme. The sealant must result to be even, not patchy.

NOTE Mount the crankcase base within 10 minutes of applying the sealant.

Figure 95




75309

Mount the crankcase base (12) and tighten the fixing screws in three stages, following the sequence shown in the figure:

- Step 1: with a torque wrench, to a torque of 50 Nm.
- Step 2: closing to an angle of 60°.
- Step 3: closing to an angle of 60°.

NOTE Use tool 99395216 (11) for the angle closing.

Figure 96




75406

Then tighten the outer screws (I) to a torque of 36 – 30 Nm.

540460 Assembling rear seal

Figure 97



85843


Carefully clean the seal seat. Apply LOCTITE 510 IVECO nr. 2992504 on the seal (1) for 30° in the points shown in the figure.

Lubricate the rear shank of the crankshaft with engine oil. Fit part (2) of tool 99346255 onto the rear shank of the crankshaft; secure it with the screws (3) and key the fresh seal (1) onto it.

Position part (4) on part (2); screw down the nut (5) to fit the seal (1) fully inside the crankcase.

540850 ENGINE FLYWHEEL

Figure 98



75389

Check clutch disk rest surface: if it shows deep scoring, a replacement must be performed.


NOTE The nominal thickness of the engine flywheel is 50 ±0.6 mm.

540852 Replacing bearing supporting gearbox input shaft

The bearing (2) supporting the gearbox input shaft is removed and fitted using a general-purpose drift.

Check conditions of the teeth of crown wheel (1); where excessive cracking or wear is found, replace engine flywheel.


Figure 99



75390

Mount the sheet metal guard (1) and secure it to the crankcase tightening the screw (2) to the prescribed torque.
Mount the engine flywheel (3) and screw down the screws (4).

Figure 100



75391

Fit tool 99360351 (4) onto the crankcase to block rotation of the engine flywheel (1).


Tighten the screws (3) fixing the engine flywheel (1) in two steps:

- Step 1: with a torque wrench, to a torque of 30 Nm.
- Step 2: closing to an angle of 90°.

NOTE Use tool 99395216 (2) for the angle closing.

5408 CONNECTING ROD – PISTON ASSEMBLY

Figure 101




75392

PISTON – CONNECTING ROD ASSEMBLY

- 1. Piston – 2. Piston ring – 3. Pin – 4. Trapezoidal ring –
- 5. Oil scraper ring – 6. Slotted oil scraper ring with spiral spring – 7. Connecting rod body – 8. Bearing shells –
- 9. Connecting rod cap – 10. Cap fixing screws.

Check the pistons. They must show no signs of seizure, scoring, cracking or excessive wear; replace them if they do.


Figure 102



75393

Remove the piston rings (1) from the piston (2) using pliers 99360183 (3).

Figure 103




75394

Using a micrometer (2), measure the diameter of the piston (1) to determine the assembly clearance. The diameter has to be measured at the value shown.

540840 Pistons
Measuring piston diameter

Figure 104




88403

MAIN DATA ON PISTON FEDERAL MOGUL, PINS AND SPRING RINGS
ENGINE FIAE 0481A (96 HP)

* Measured on the diameter of 85 mm.

Figure 105




88404

MAIN DATA ON PISTON MAHLE MONDIAL, PINS AND SPRING RINGS
ENGINE FIAE 0481B (116 HP)

* Measured on the diameter of 85 mm.

Figure 106




88405

By means of micrometer (2), measure the diameter of piston (1) to determine mounting clearance; the diameter must be detected at distance X from piston base:

- 46 mm - engine FIAE0481A (96 HP)
- 45.5 mm - engine FIAE0481B (116 HP).

NOTE The pistons are supplied as spare parts with the standard, normal and 0.4mm oversize diameters together with rings, pin and retaining rings.

Figure 107




75395

The clearance between the piston and cylinder liner can also be checked using a feeler gauge (1) as illustrated in the figure.

540841 Piston pins

Figure 108




18857

Measuring the diameter of the piston pin (1) with a micrometer (2).

Conditions for correct pin-piston coupling

Figure 109




75397

Lubricate the pin (1) and its seat on the hubs of the piston (2) with engine oil. The pin must go into the piston by lightly pressing with the fingers and must not drop out by gravity.

540842 Piston rings


Figure 110



74947

The trapezoidal split rings (1st slot) and the oil scraper rings (2nd slot) have the word TOP etched in them; when fitting them on the piston, the word TOP must be facing upwards.


Figure 111



16552

Check the thickness of the piston rings (2) with a micrometer (1).


Figure 112



74948

Check the clearance between the trapezoidal ring (2) (1st slot) and the associated slot on the piston with a feeler gauge (1), proceeding as follows: insert the piston into the cylinder liner so that the ring (2) comes approximately half way out of it.

Figure 113




41104

DIAGRAM FOR MEASURING THE CLEARANCE X BETWEEN THE FIRST PISTON SLOT AND THE TRAPEZOIDAL RING

- 1. Piston slot – 2. Trapezoidal piston ring –
- 3. Cylinder liner

Using a feeler gauge (1, Figure 112), check the clearance (X) between the ring (2) and the slot (1); this clearance must have the prescribed value.


Figure 114



75398

Check the clearance between the piston rings (2) of the 2nd and 3rd slot and the associated seats on the piston (3) with a feeler gauge (1).

Figure 115




75399

Check the opening between the ends of the piston rings (2) inserted in the cylinder liner using a feeler gauge (1).

540830 Connecting rods

Figure 116



75400

MAIN DATA OF THE CONNECTING ROD, BUSHING, PISTON PIN AND BEARING SHELLS

- * Internal diameter to obtain after driving into the small end and grinding with a reamer.
- ** Dimension cannot be measured in the free state.
- *** Thickness of the bearing shell supplied as a spare part.

NOTE Each connecting rod has its cap marked:

- with a letter: O or X indicating the diameter class of the big end mounted in production;

- with a number indicating the weight class of the connecting rod mounted in production.

In addition, it could be stamped with the number of the cylinder in which it is fitted.

In the event of replacement it is therefore necessary to number the new connecting rod with the same number as the one replaced.

The numbering must be done on the opposite side to the bearing shell retaining slots.

The connecting rods are supplied as spare parts with the diameter of the big end 62.842 – 62.848 mm marked with the letter O and the weight class marked with the number 33.


It is not permissible to remove material.

540834 Bushes

Check that the bush in the small end has not come loose and shows no sign of seizure or scoring. If it does, replace the complete connecting rod.

Checking connecting rods

Figure 117




Check the alignment of the axes of the connecting rods (1) with device 99395363 (5), proceeding as follows:

- Fit the connecting rod (1) on the spindle of the tool 99395363 (5) and lock it with the screw (4).
- Set the spindle (3) on the V-prisms, resting the connecting rod (1) on the stop bar (2).

Checking torsion

Figure 118




Check the torsion of the connecting rod (5) by comparing two points (A and B) of the pin (3) on the horizontal plane of the axis of the connecting rod.

Position the mount (1) of the dial gauge (2) so that this pre-loads by approx. 0.5 mm on the pin (3) at point A and zero the dial gauge (2). Shift the spindle (4) with the connecting rod (5) and compare any deviation on the opposite side B of the pin (3): the difference between A and B must be no greater than 0.08 mm.

Checking bending

Figure 119



Check the bending of the connecting rod (5) by comparing two points C and D of the pin (3) on the vertical plane of the axis of the connecting rod.


Position the vertical mount (1) of the dial gauge (2) so that this rests on the pin (3) at point C.

Swing the connecting rod backwards and forwards seeking the highest position of the pin and in this condition zero the dial gauge (2).

Shift the spindle with the connecting rod (5) and repeat the check on the highest point on the opposite side D of the pin (3). The difference between point C and point D must be no greater than 0.08 mm.


Assembling connecting rod-piston assembly

Figure 120



Etched on the top of the piston are: the type of engine (1), class selection (2) and supplier (3) as well as the direction of fitting the piston in the cylinder liner (4). The mark (5) is for passing the 1st slot insert adhesion test.


Figure 121



75402

Connect the piston (1) to the connecting rod (2) together with its cap so that the piston assembly reference, position of the connecting rod and of the cap are observed as shown in the figure.

Figure 122




75394

Position the piston (1) on the connecting rod, insert the pin (3) and secure it with the split rings (2).

Checking for connecting rod – piston distortion

Figure 123




75403

After fitting the connecting rod – piston assembly together, check for distortion with the tool 99395363 (8) as follows:

- Fit the connecting rod (7) together with the piston (3) on the spindle (4) of tool 99395363 (8) and lock it with the screw (5).
- Rest the connecting rod (7) on the bar (6).
- Position the mount (1) of the dial gauge (2) so that this is positioned at point A of the piston with a pre-load of 0.5 mm and zero the dial gauge (2).
- Shift the spindle (4) so as to position the dial gauge (2) at point B of the piston (3) and check for any deviation.

Assembling piston rings

Figure 124




41097

Fit the piston rings (1) on the piston (2) using the pliers 99360183 (3).

NOTE The 1st and 2nd slot rings need to be mounted with the word "TOP" facing upwards.

Assembling connecting rod – piston assemblies in cylinder barrels

Figure 125



75404

Lubricate the pistons well, including the piston rings and the inside of the cylinder liners.

With the aid of the clamp 99360605 (2), fit the connecting rod – piston assembly (1) in the cylinder liners, checking that:


- The number of each connecting rod corresponds to the cap mating number.

- The openings of the piston rings are staggered 120° apart.
- The pistons are all of the same weight.
- The symbol punched on the top of the pistons faces the engine flywheel, or the recess in the skirt of the pistons tallies with the oil spray nozzles.

NOTE Not finding it necessary to replace the connecting rod bearings, you need to fit them back in exactly the same sequence and position found on disassembly.

540831 Measuring crankpin assembly clearance


Figure 126



To measure the clearance, carry out the following steps:

- Thoroughly clean parts (1) and (4) and eliminate all traces of oil.
- Place a length of calibrated wire (3) on the crankshaft pins (4).

Figure 127



- Fit the connecting rod caps (2) with the associated bearing shells.
- Tighten the screws (3) in two steps:
 - Step 1: with a torque wrench, to a torque of 50 Nm.
 - Step 2: closing to an angle of 60°.

NOTE Use tool 99395216 (1) for the angle closing.

- Remove the cap (2) and determine the existing clearance by comparing the width of the calibrated wire (3, Figure 126) with the graduated scale on the case (2, Figure 126) that contained the calibrated wire. On finding a clearance other than as prescribed, replace the bearing shells and repeat the check.


On obtaining the prescribed clearance, lubricate the connecting rod bearing shells and fit them permanently by tightening the connecting rod cap fixing screws as described.

NOTE The connecting rod cap fixing screws must always be replaced for permanent assembly.

Manually check that the connecting rods slide axially on the pins of the crankshaft.

Checking piston protrusion

Figure 128




After mounting the connecting rod – piston assemblies, check the protrusion of the pistons (2) at the T.D.C. in relation to the top surface of the crankcase with a dial gauge (1).

NOTE The difference between the minimum and maximum protrusions of the four pistons must be = 0.15 mm.


The cylinder head gasket in the set of spare gaskets needed for complete engine overhaul is supplied with a single thickness. Clearly, it is supplied separately too.

Figure 129



Mount the suction strainer (1) together with the pipe (6). Screw down the fixing screws (2-3-4-6) and tighten them to the prescribed torque.

Figure 130




75410

Fit the gasket (4) and the frame (3) onto the oil sump (1). Screw down the fixing screws (2) and tighten them to the prescribed torque. Screw down the oil drain plug (5) and tighten it to the prescribed torque.

560610 CYLINDER HEAD

Disassembly

Figure 131




75411

Place the cylinder head (1) on the mounting SP.2271 (7). Remove the brackets (6) for lifting the engine. Use the wrench SP 2262 to remove the timing sensors (2 and 3). Take out the screws (5) and remove the thermostat casing (4).

541210 Removing valves

Figure 132



75412

Fit part (4) of tool 99360260 onto the cylinder head (5) and secure it with the screws (3).


Fit part (2) of tool 99360260 onto part (4), screw down the nut (1) so that on compressing the springs (8) it is possible to remove the cottoers (6). Then take out the plates (7) and the springs (8).

Using suitable pliers, remove the oil seal (9).

Repeat these operations on the remaining valves.

Turn the cylinder head over.

Figure 133



75413

The intake (1) and exhaust (2) valves have the same diameter mushroom.

The central cavity (→) of the mushroom of the intake valve (1) is distinguished from that of the exhaust valve (2).

NOTE Before dismantling the valves from cylinder head, number them, to the purpose of being able to remount them in the position that was found on dismantling operation where they should not be replaced.

A = intake side – S = exhaust side

Remove the intake (1) and exhaust (2) valves.

Checking cylinder head seal

Check the hydraulic seal using a suitable tool.
Pump in water heated to approx. 90°C at a pressure of 2 + 3 bars.


Replace the cup plugs if they are found to leak at oil, using a suitable drift for their removal – assembly.

NOTE Before mounting the plugs, apply LOCTITE 270 water-reacting sealant on their sealing surfaces.

If there is any leakage from the cylinder head, it must be replaced.

Checking cylinder head mating surface

Figure 134



75451

The mating surface of the head (1) with the cylinder block is checked using a rule (2) and a feeler gauge (3).

The deformation found on the entire length of the cylinder head must be no greater than 0.20 mm.


For greater values, regrind the cylinder head according to the values and instructions given in the following figure.

The nominal thickness A of the cylinder head is 112 ± 0.1 mm; the maximum permissible removal of metal must not exceed a thickness of 0.2 mm.

NOTE After regrinding, check the valve recessing and if necessary regrind the valve seats to make the prescribed valve recessing.

540662 VALVES

Figure 135




75452

MAIN DATA OF INTAKE AND EXHAUST VALVES

Removing deposits, refacing and checking valves


Figure 136



18625

Remove the carbon deposits on the valves with a wire brush. Check that the valves show no signs of seizure, cracking or burning.

Figure 137




18882

Using a micrometer (2), measure the stem of the valves (1): it must be 5.975 – 5.990 mm. If necessary, regrind the seats on the valves with a grinding machine 99305018, removing as little material as possible.

Checking clearance between valve stem and valve guide and centring valves

Figure 138



75453


The checks are made using a dial gauge (2) with a magnetic base, positioned as illustrated. The assembly clearance is 0.033 – 0.063 mm.

Making the valve (1) turn, check that the centring error is no greater than 0.03 mm.

540667 VALVE GUIDES

Replacing valve guides

Figure 139




88774

MAIN DATA OF VALVE GUIDES – SEATS

- Valve guide seat inside \varnothing 9.980 ± 10.000 mm
- Valve guide outside \varnothing 10.028 ± 10.039 mm

* Measurement to be made after driving in the valve guides.


Figure 140



75455

Remove the valve guides (2) with the drift SP.2312 (1).

Figure 141




75456

Heat the cylinder head to 80 – 100°C and, using the drift SP.2312 (1) provided with part SP.2311 (2), mount the new valve guides (3) previously chilled in liquid nitrogen.

Where above indicated tools are not available, mount valve guides positioning them in cylinder head according to dimension indicated in Figure 139.

Boring valve guides

Figure 142




75457

After driving in the valve guides (2), regrind them with the smoother SP.2310 (1).

540661 VALVE SEATS
Regrinding - replacing valve seats

Figure 143



75458

Check the valve seats. On finding any slight scoring or burns, regrind them with an appropriate tool according to the angles given in Figure 143.


Having to replace them, with the same tool and taking care not to affect the cylinder head, remove as much material from the valve seats as possible until, with a punch, it is possible to extract them from the cylinder head.

Heat the cylinder head to $80 \pm 100^\circ\text{C}$ and, using a suitable drift, fit in it the new valve seats, previously chilled in liquid nitrogen.

Using a specific tool, regrind the valve seats according to the angles given in Figure 143.

Mount the valves, block the seat of the electro-injectors and glow plugs; using a suitable tool, check the seal of the valves/seats.


Figure 144



75459

Using the milling cutter 99394038 (1), clean the injector seat of any deposits.

Figure 145





54760

Using a dial gauge (1), check that, from the plane of the cylinder head, the valve recessing (2) and the protrusion of the injector (3) and of the glow plug have the prescribed value:

- Valve recessing: 0.5 ± 0.8 mm.
- Injector protrusion: 2.77 ± 3.23 mm.
- Glow plug protrusion: 3.78 mm.

540665 VALVE SPRINGS


Figure 146



62386

Before assembly, check the flexibility of the valve springs with the tool 99305047. Compare the load and elastic deformation data with those of the new springs given in the following figures.

Figure 147




50676

MAIN DATA TO CHECK INTAKE AND EXHAUST VALVE SPRINGS

| Height mm | Under a load of kg |
|--------------|-----------------------|
| H 54 | Free |
| H1 45 | P 243 ±12 |
| H2 35 | PI 533 ±24 |

ROCKER ARMS – TAPPETS

Figure 148




75461

COMPLETE ROCKER ARM ASSEMBLY

The rocker arm assembly is composed of the rocker arm (1), hydraulic tappet (3), made integral with each other by the clip (2).

Figure 149




75942

CROSS-SECTION OF THE HYDRAULIC TAPPET

- A = 32.44 ±0.3, end of stroke
- B = 31.30, working position
- C = 29.75 ±0.25, start of stroke

Figure 150



MAIN DATA HYDRAULIC TAPPETS – SEATS

75462


Checks

The sliding surface of the tappets must have no scoring/dents; replace them if they do.

Using a micrometer, measure the diameter of the tappets and, using a bore meter, measure the diameter of the seats in the cylinder head; the difference in the measurements will give the assembly clearance.

ASSEMBLING CYLINDER HEADS


Figure 151



75463

Lubricate the stem of the valves (1) and insert them into the associated valve guides (4) according to the position marked during removal. Using tool SP.2264 (2), mount the oil seals (3) on the valve guides (4).

Figure 152



75587


Position the springs (8) and plates (7) on the cylinder head (5).

Fit the part (4) of tool 99360260 onto the cylinder head (5) and secure it with the screws (3).

Fit the part (2) of tool 99360260 onto part (4), screw down the nut (1) so that by compressing the springs (8) it is possible to insert the retaining cotters (6); then unscrew the nut (1) checking that the cotters (6) have settled in correctly.

Repeat these operations on the remaining valves.

Figure 153



75464

Fit the thermostat casing (5) with a new seal and tighten the fixing screws (4) to the prescribed torque.


Mount temperature sensors (1 and 2), and tighten them at prescribed torque.

For tightening sensor (2), use wrench SP.2262 (3).

Mount the temperature sensors (1 and 2) and, using the wrench SP.2263 (3), tighten them to the prescribed torque.

540650 Overhead
Overhead removal

Figure 154




75465

Position the overhead (2) together with the pins 99360614 (1) on the mounting SP. 2271.

Take out the screw (4) with the washer (5) beneath fastening the toothed pulley (3).


Figure 155



75466

Using the extractor 99340028 (2) extract the toothed pulley (1) driving the camshaft.

Figure 156




75467

Using four self-tapping screws (2), apply the tool SP. 2325 (3) to the seal (1) and with the extractor (5 and 6) remove the seal (1) from the overhead (4).

NOTE The screws (2) must be screwed down so they get positioned at the dimension shown in the figure.


Figure 157



75468

Remove the circlip (1) and take off the cover (2) together with the seal (3).


Figure 158



75469

Take out the screws (1) and remove the rear cover (2) together with its gasket.


Figure 159



75470

Insert a suitable pin (2) in the hole (⇒) of the chain drive (3). Take out the screws (4) and (6) with their washers (5) for fixing gears to the camshafts. Take out the screws (7) and remove the chain drive (3) from the overhead (1).

Figure 160




75471

Turn over the overhead (1) and, taking care not to damage the seats, extract the camshafts (2) and (3) from it.

5412 TIMING SYSTEM

Figure 161



75472

- 1. Camshaft on intake side – 2. Hydraulic tightener –
- 3. Camshaft on exhaust side – 4. MORSE chain –
- 5. Rocker arms – 6. Hydraulic reacting tappet –
- 7. Valve assembly.

Description

The timing system is the type with a twin camshaft in the head and four valves per cylinder with hydraulic tappets.


Motion is transmitted by the crankshaft, via a toothed belt, to the gear keyed onto the intake valve drive shaft. The drive transmission of the exhaust valve drive shaft takes place via a MORSE-type chain kept under tension by a hydraulic tightener.

The toothed belt, moreover, drives the water pump and the high-pressure pump CP3 and is kept at the right tension by an automatic tightener roller.

The four valves move by the action of the “free” rocker arms (with no supporting shaft).

The rocker arms, one per valve, are always in contact with the corresponding cam and are kept in this position by a hydraulic reacting tappet, thereby eliminating the need for periodical adjustment.

Figure 162




75473

TIMING SYSTEM DIAGRAM

541210 Camshaft Checks

The surfaces of the shaft supporting pins and of the cams must be finely honed; if there is any sign of meshing or scoring, replace the shaft.


Figure 163



Using a micrometer (1), measure the diameter of the pins (2) of the camshaft and, using a bore meter, measure the diameter of the supporting seats in the overhead. The difference between these two measurements gives the existing clearance. The nominal assembly clearance is 0.037 ± 0.088 mm.


541211 Checking cam lift and pin alignment

Figure 164



Set the shaft (1) on tailstocks and, using a dial gauge on the middle mounting, check that the alignment error is no greater than 0.04 mm; replace the shaft if it is. In addition, check the cam lift: it must be as prescribed; replace the shaft if it is any different.

Figure 165




MAIN DATA, CAMSHAFT PINS AND SEATS

1. Intake valve camshaft seats – 2. Exhaust valve camshaft seats – 3. Intake valve camshaft – 4. Exhaust valve camshaft.

Assembling overhead

Figure 166




75471

Lubricate the supporting pins of the shafts (2 and 3) and fit them in the overhead (1).

NOTE In this operation, take care not to damage the overhead supporting seats.

Figure 167




75477

Position the overhead (1) and secure it on the mounting SP.2271 (2).

Position the camshafts (4 and 5) so as to be able to insert the pins 99360614 (3) into their radial holes through the threaded holes of the overhead.


Figure 168



75478

Compress the tightener so as to be able to insert a suitable pin (2) into the hole (→) of the chain drive (1).

Figure 169



75479


Fit the chain drive (2) on the camshafts (1) and secure it to the overhead (1) tightening the screws (8) to the prescribed torque.

Screw down the screws (4) and (7) with the washers (5) and (6) and tighten them as follows:

- Tighten the screw (7) to a torque of 50 Nm.
- Close further with an angle of 60°.
- Take out the pin (5).
- Tighten the screw (4) to a torque of 50 Nm.
- Close further with an angle of 60°.

NOTE Use the goniometer 99395216 for the angle closing.


Figure 170



75469

Fit on the rear cover (2) with a new gasket and tighten the fixing screws (1) to the prescribed torque.


Figure 171



75468

Fit a new seal (3) on the cover (2) and fit this in the overhead.
Fit on the seal (1).

Figure 172




75481

Lubricate the shank of the camshaft.

Using the keying device 99374458 (3), fit the seal (2) in the overhead (1).

Figure 173




75482

Fit the toothed pulley (1) onto the camshaft so as to align the hole of the pulley with that of the overhead and insert the tool 99360608 (4) into these holes. Screw down the screw (3) together with the washer (2) without tightening fully.

NOTE The toothed pulley (1, Figure 173) is not locked on the shaft since it must be able to turn when fitting and tensioning the timing belt. For the same reason, keep the tools 99360608 (4, Figure 173) and 99360614 (3, Figure 167) fitted.

Figure 174




75281

Fit the oil pressure control valve (1) in the crankcase.

Fit on the plug (2) with the seal (3) and tighten it to the prescribed torque.

540442 Assembling front seal ring

Figure 175




75483

Fit the centring tool 99396037 (2) onto the shank of the crankshaft.

Mount the oil vacuum pump assembly (1) with a new gasket and tighten the screws (1-15) according to the following procedures:

- Tighten the screws from no. 1 to no. 6 to a torque of 5 ± 1 Nm while checking that the tool 99360037 (2) turns freely.
- Tighten the screws from no. 7 to no. 15 to a torque of 10 ± 1 Nm.
- Tighten the screws from no. 1 to no. 6 to a torque of 10 ± 1 Nm.
- After checking that tool 99360037 (2) turns freely, remove it.

Figure 176



75484


Lubricate the shank of the crankshaft.

Screw down part (3) of tool 99346254 in the crankshaft and place the seal (2) on the part (3).

Key part (5) of tool 99346254 onto part (3), screw down the nut (4) until the seal (2) gets into position in the seat of the oil vacuum pump assembly (1).

Take out the tool 99346254 (3, 4 and 5).

Figure 177




75485

Turn the crankshaft so as to be able to insert tool 99360615 (5) into the hole in the crank of the crankshaft, through the hole in the oil vacuum pump assembly (1), to block crankshaft rotation.

Mount the gear (2), screw down the screw (3) together with the spacer (4) and tighten it to the prescribed torque.

NOTE Do not remove the tool 99360615 (5) as it will be needed for fitting the timing drive belt.

Figure 178




75280

Mount the speed sensor (1) with a fresh gasket and tighten the fixing screw (2) to the prescribed torque (if applicable).

Fit on the compressor mounting (3) and tighten the fixing screws (4) to the prescribed torque.


Figure 179



75279

Mount the air-conditioner compressor (1) (if applicable) and tighten its fixing (2) screws to the prescribed torque.

Figure 180




75486

Mount the oil pressure transmitter (3) with a fresh gasket.

Mount the heat exchanger (1) with a fresh seal and tighten the coupling (2) to the prescribed torque.


Figure 181



75487

Lubricate the seal of the oil filter (1) with engine oil. Using tool 99360076 (2), tighten the oil filter to the prescribed torque.


Figure 182



75488

Thoroughly clean the mating surface (à) of the water pump (1) and position fresh seals (2 and 3) on it.


Figure 183



75489

Mount the water pump (1) and tighten the fixing screws (2) to the prescribed torque.


Figure 184



75490

Fit the high-pressure pump (2) onto the flange of the water pump (1) and tighten the fixing screws (3) to the prescribed torque.

Figure 185




75271

Fit the driving gear (1) onto the shaft of the high-pressure pump and block rotation of this shaft by applying tool SP.2263 (2) as illustrated in the figure. Tighten the nut (3) to the prescribed torque and remove the tool (2).

Refitting cylinder head


Figure 186



Check that tool 99360619 (2) inserted in the hole (→) of the oil vacuum pump assembly (1) blocks crankshaft rotation.

This condition is necessary for setting up the timing system and to prevent the valves interfering with the pistons.

Figure 187




Check that the mating surfaces of the cylinder head and crankcase are clean.

Keep the cylinder head gasket clean.

Position the cylinder head gasket (1) of the thickness determined under the heading "checking piston protrusion" with the lettering "TOP" facing the cylinder head.

NOTE It is essential to keep the gasket sealed in its package until just before assembly.

Figure 188



Mount the cylinder head (1).

Screw down the fixing screws (3) and tighten them, in three successive stages, following the order and methods shown in the following figure.

NOTE The angle closure is done with tool 99395216 (2).

Figure 189





Diagram of the tightening sequence for the cylinder head fixing screws:

- 1st phase: pre-tightening with torque wrench
 - screws 1-2-3-4-5-6 to a torque of 100 ± 5 Nm;
 - screws 7-8-9-10 to a torque of 50 ± 2.5 Nm.
- 2nd phase: angle closing
 - screws 1-2-3-4-5-6 $90^\circ \pm 5^\circ$;
 - screws 7-8-9-10 $60^\circ \pm 3^\circ$.
- 3rd phase: angle closing
 - screws 1-2-3-4-5-6 $90^\circ \pm 5^\circ$;
 - screws 7-8-9-10 $60^\circ \pm 3^\circ$.


A = flywheel side.

Figure 190



Thoroughly clean the hydraulic tappets (2), lubricate them and fit them in the cylinder head (3), positioning the rocker arms (1) on the valves correctly.
Fit on the gasket (5).
Insert the two tools SP. 2264 (4) into the electro-injector seats for subsequent centring of the overhead on the cylinder head.


Figure 191



Mount the overhead (1) together with the tools 99360614 (3) for the timing and tighten the fixing screws (2) to the prescribed torque.

Take out the tools SP. 2264 (4).


Figure 192



Mount the fixed tightener (1) and tighten the fixing screw (2) to the prescribed torque.

Mount the automatic tightener (4) without fully tightening the fixing screw (3), max. closing torque 5 Nm.

Figure 193



X = Direction of movement of the tightener –
Y = Direction of rotation of the key.

Turn the automatic tightener (1) clockwise, positioning it as shown in frame A.

Turn the timing belt (10) as shown in the figure observing the precautions below.

Do not bend the timing belt. Arrows indicating the direction of assembly of the timing belt on the engine are shown on the back of the belt. The arrows must correspond to the direction of rotation of the belt and the notches must coincide with those on the pulley (7) and the gear (12).

If required to fit the timing belt (10) on the pulley (7), remove tool 99360608 (8) and turn the pulley (7) clockwise by no more than half a pulley tooth.

NOTE If the engine has run for a period equivalent to $\geq 25,000$ km, the toothed belt must be replaced with a fresh one, no matter what its state of wear.

On completing assembly, adjust the toothed pulley (7) to put the section X of the belt under tension and tighten the screw (9) to a torque of 90 Nm

Keeping the screw (2) stationary and using a suitable wrench on the hexagon of the plate (3) of the tightener, turn it anticlockwise to cover the reference hole (5) located on the fixed portion of the tightener (see frame B).

In the above conditions, tighten the fixing screw (2) to a torque of 36 ± 4 Nm

Remove the tools 99360614 (6) and 99360615 (11) for the timing.


Turn the engine in its direction of rotation by 8 turns to be able to put the tools (6) and (11) back in to do the timing. In these conditions, the notches of the timing belt (10) must coincide with those of the pulley (7) and the gear (12).

NOTE Do not turn the engine in the opposite direction; if, on turning the engine, you pass the point for inserting the tools (6) and (11), turn the engine clockwise by another two turns.

See frame C: Figure 193, holding the tightener plate (3) stationary with the wrench inserted in its hexagon, loosen the fixing screw (2). Keeping the fixing screw (2) stationary, turn the plate (3) clockwise until its reference mark (4) coincides with the reference hole (5) of the fixed portion of the tightener. In the above conditions, tighten the screw (2) to a torque of 36 ± 4 Nm.

After assembly, the belt (10) tension measured using tool 99395849 must be as follows in the following points: $X = 212 \pm 12$ Hz - $X_1 = 178 \pm 10$ Hz.


Figure 194



Remove the tools (6 and 11, Figure 193).

Screw the plug (1) into the oil-vacuum pump mounting (2) and the plugs on the holes of the overhead.


Figure 195



Mount the timing cover (1) and tighten the screws (2) to the prescribed torque.


Mount the damper pulley (3) and tighten the screws (4) to the prescribed torque.

Figure 196



Fit on the mounting (1) together with the electromagnetic coupling (4) and tighten the fixing screws (2 and 3) to the prescribed torque.


Figure 197



Mount the oil level sensor (1).


Fit on the power steering (2) pump mounting (4) and tighten the fixing screws (3) to the prescribed torque.

Figure 198



Position the alternator (2) on the mounting (5) and secure it with the bottom screws (3 and 4) and the bolt.


Figure 199



Mount the fixed tightener (2) and tighten the fixing screw (1).

Mount the automatic tightener (3) and tighten the screw (4) to the prescribed torque.


Figure 200



Using a wrench on the automatic tightener (2), mount the drive belt (1), taking care to position its ribs correctly in the respective races of the pulleys.

544035 Adjusting air-conditioner – compressor drive belt tension

Figure 201



Fit the tightener (1) without tightening the screw (4).
Fit the drive belt (5) taking care to position its ribs correctly in the respective races of the pulleys.

With tool SP. 2341 (2) inserted in the holes of the tightener (1) and torque wrench (3), turn the tightener (1) with a torque of 8.2 – 10 Nm; in this condition, tighten the screw (4) to a torque of 25 Nm.


Turn the engine in its direction of rotation to have the belt (5) make two full turns.

With appliance 99395849, measure the tension of the belt (5) in section A, which must be 204 ± 10 Hz corresponding to a load on the tightener of $1010 \pm$ Nm.

In the case of engines with a compressor drive belt of elastic type, no tensioning is needed. For mounting, operate as follows.

NOTE The elastic belt must be replaced by a new elastic belt at each dismantling operation.

Figure 202




Fit the flexible belt (3) equipped with tool 99360191 (2) on the pulley (4) and apply the tool on the pulley (1).

Fit the drive ring (5) on the flexible belt (3) and fasten the ring on the compressor support.


Turn the drive shaft clockwise until the belt fits perfectly on the pulley (1).

Figure 203




Fit a new seal (3) on the electro-injector (1) and mount this in the overhead (2).

Figure 204




Mount the brackets (3) fastening the electro-injectors (1) and screw down the screws (2) without locking them. Mount the hydraulic accumulator (4) and tighten the fixing screws to the prescribed torque.

Figure 205



Forged version: on hydraulic accumulator (2), mount: pressure sensor (1) tightening it at 35 ± 5 Nm torque, and pressure relief valve (3) tightening it at 27 ± 2 Nm torque. Welded version: mount pressure sensor and tighten it at 70 ± 5 Nm torque.


Figure 206



Connect the fuel pipes (2) to the electro-injectors (1) and to the hydraulic accumulator (3). Tighten the screws (4) fixing the electro-injector brackets to the prescribed torque.


NOTE Whenever they get removed, the fuel pipes must be replaced with new ones.

Figure 207




Using the wrench (4) of the 99317915 series and the torque wrench 99389829 (3), tighten the fuel pipe fittings (1) and (2) to the prescribed torque.

Figure 208




Mount the glow plugs (1) and, using the box-type wrench SP. 2275 (2) and torque wrench 99389819 (3), tighten them to a torque of 8 ± 10 Nm.

Figure 209



Mount the intake manifold (1) with a new gasket and, using a torque wrench (3), tighten the fixing screws (2) to the prescribed torque.

Figure 210




75510

Connect the fuel pipe (4) to the hydraulic accumulator (7) and to the high-pressure pump (5).

With wrench (2) of series 99317915 and dynamometric wrench 99389829 (1), tighten pipe fittings (3 and 6) at prescribed torque.

NOTE Whenever they get removed, the fuel pipes (4) must be replaced with new ones.

Figure 211




75511

Connect the fuel recovery pipe (1) with new seals to the pressure relief valve (6) tightening the coupling (7) to the prescribed torque (only for forged version hydraulic accumulator).

Connect the fuel recovery pipes (1) and (5) with new seals to the high-pressure pump (2) with the couplings (3) and (4). Insert the oil dipstick tube (9) with a new seal into the crankcase and secure it together with the pipe (10), using the screw (8) tightened to the prescribed torque, to the intake manifold.


Figure 212



75256

Press the clips (3) in the direction shown by the arrow and connect the fuel recovery pipe fittings (1) to the electro-injectors (2).

Figure 213




75512

Fit the exhaust manifold (5) with a new gasket and the spacers (6) and tighten the nuts (7) to the prescribed torque. On the exhaust manifold (6), mount: the turbocharger (4) with a new gasket and tighten the nuts (3) with washers to the prescribed torque, the compensator pipe (1) (if applicable) with a new seal and tighten the nuts (2) with washers to the prescribed torque.

NOTE Before fitting the turbocharger on the engine, it is necessary to fill the central body with engine lubricating oil.


Figure 214



75513

Connect the pipe (4) to the cylinder head (6) and to the turbocharger (7).
Using the wrench (2) in the 99317915 series and the torque wrench 99389829 (1), tighten the couplings (3 and 5) to the prescribed torque.


Figure 215



75264

Connect the air duct (5) to the turbocharger (2) and to the overhead (3).
Tighten the clamp (1) and the screw (4) to the prescribed torque.

Figure 216




75263

For engines with E.G.R. only

Mount the flange (7) with a new gasket and tighten the screws (8) to the prescribed torque.
Mount the heat exchanger (1) together with the E.G.R. valve (5) and new gaskets and tighten the screws (2 and 6) to the prescribed torque.
Connect the pipe (4) to the exchanger (1) and to the flange (7) securing it with the clamps (3).


Figure 217



75255


Mount the oil fillpipe (5) with a new seal and tighten the nuts (6) to the prescribed torque.
Mount the coalescence filter (3) and tighten its fixing nuts (4) to the prescribed torque.
Mount the bracket (1) and tighten the screws (2) to the prescribed torque.

Figure 218



Fit the cooling fan (1) back onto the electromagnetic coupling. Fit the arm 99360549 onto the engine lifting hooks. Hook the arm onto the hoist and remove the engine from the rotary stand (3). Take out the brackets 99361028 (2).

Figure 219




Complete engine assembly.
Fit on the left and right engine mountings (3) and tighten the fixing screws to the prescribed torque.
Connect the oil pipe (2) to the turbocharger (1) and to the crankcase and tighten the fixing screws and the coupling of the oil pipe (2) to the prescribed torque.
If applicable, mount the following parts:

- Engine cable, connecting its electrical connections to the thermostat temperature sensor, timing sensor, engine speed sensor, pressure regulator, rail pressure sensor and intake manifold air pressure/temperature sensor.
- Hydraulic accumulator guard.
- Top soundproofing cover.
- Add the prescribed grade and quantity of lubricating oil to the engine.

764264 Timing speed sensor 764266 Engine speed sensor

Figure 220



The sensor gap is:

- 1 ± 0.5 mm, between the camshaft pulley (2) and timing sensor (1).
- 1 mm, between the phonic wheel (4) and speed sensor (3).

5450 LUBRICATION

General

The engine is lubricated by forced circulation performed by the following parts:

- An oil gear pump is incorporated in an assembly that also includes the vacuum pump (GPOD).
- A pressure control valve incorporated in the crankcase.
- A Modine-type heat exchanger with built-in safety valve.
- A double filtration oil filter with built-in safety valve.

Operation (see Figure 221)


Engine oil is drawn up from the sump by the oil pump (3) via the suction strainer (2) and delivered under pressure to the heat exchanger (5) where it is cooled.

The oil continues through the oil filter (6) and goes to lubricate the relevant parts through ducts or pipes.

At the end of the lubrication cycle, the oil returns to the sump by gravity. The oil filter can be excluded by the safety valve built into it if it gets clogged. The heat exchanger is also excluded by a safety valve if it gets clogged.

In addition, the lubrication oil supplies the hydraulic automatic tightener (7) of the camshaft drive (8).

Figure 221



OIL VACUUM PUMP ASSEMBLY (GPOD)

Figure 222





DIAGRAM OF GPOD ASSEMBLY ON ENGINE

- 1. Vacuum pump – 2. Oil pump – 3. Crankshaft –
- A. Vacuum pump oil supply hole.

Clearance between the crankshaft gear teeth and the oil pump drive gear 0.003 ± 0.2 mm.
The assembly must not be overhauled; in the event of defective operation, it must be replaced.

503010 Oil pump

Figure 223



The oil pump (3) is a gear pump driven directly by the crankshaft.

Characteristic data

| | |
|---------------------------------|----------------------|
| transmission ratio | 1.15 |
| displacement | 16.2 cm ³ |
| pumping diameter | 49.5 mm |
| number of teeth | 7 |
| height | 11 |
| oil pump minimum speed | 862 rpm |
| oil pump max. speed | 4485 rpm |
| oil pump over-revs | 5247 rpm |
| oil pump forced over-revs speed | 2500 rpm |
| torque | 2.1 Nm |
| power draw (calc.) | 550 W |

| | |
|---|------------------|
| Oil temperature: 100°C – closed recirculation – max. outlet pressure 5 bars | |
| engine speed rpm (oil pump speed – rpm) | capacity (l/min) |
| 750 (862) | 12 |
| 3900 (4485) | 68 |

Vacuum pump


The vacuum pump (2, Figure 223), with radial blades, is also incorporated in the GPOD (1, Figure 223). It is driven directly by the oil pump.

| | |
|--|--------------------|
| transmission ratio | 3.25 |
| displacement | 86 cm ³ |
| volume to drain | 4.5 litres |
| volume to drain with EGR | 9 litres |
| chamber diameter | 65 mm |
| rotor diameter | 50 mm |
| cam | 7.5 mm |
| number of blades | 3 |
| height | 34 mm |
| vacuum pump minimum speed | 994 rpm |
| vacuum pump max. speed | 5168 rpm |
| vacuum pump over-revs | 6046 rpm |
| vacuum pump forced over-revs | 7235 rpm |
| theoretical flow rate at minimum (air) | 85.5 l/min |
| actual flow rate at minimum (air) – at atmospheric pressure | 46 l/min |
| Theoretical speed at max. speed – (air) | 444.4 l/min |
| Actual flow rate at max. speed – (air) at atmospheric pressure | 60 l/min |
| measured power draw (maximum) speed | 2500 rpm |
| torque | 2.1 Nm |
| power draw (calc.) | 550 W |

| | | | |
|--|--------------|-----|------|
| Oil temperature: 100°C – engine speed 750 rpm (pump speed 994 rpm) | | | |
| tank (litres) | vacuum (bar) | 0.5 | 0.8 |
| 4.5 | time (sec) | 4.5 | 12.5 |
| 5.6 | | 6.0 | 16.0 |
| 9 | | 9.0 | 24.0 |

543475 Oil pressure control valve

Figure 224




75520

CROSS-SECTION OF OIL PRESSURE CONTROL VALVE MOUNTED IN CRANKCASE

Valve removed from crankcase L = 51.75 mm.
 Valve fitted in crankcase L = 50.75 mm.
 Start of opening 4 bar L = 49.5
 maximum opening 4.6 bar L = 44.

Figure 225




75521

PARTS COMPRISING THE OIL PRESSURE CONTROL VALVE

1. Split ring – 2. Washer – 3. Spring – 4. Valve –
 5. Valve casing.

Figure 226




75522

MAIN DATA OF THE OIL PRESSURE CONTROL VALVE SPRING

543070 Oil filter

Figure 227




75523

Oil filter with single filtration with built-in by-pass valve – opening pressure 2.5 ± 0.3 bar.

543110 Modine heat exchanger

Figure 228



75524

Thoroughly clean the heat exchanger (1).
 Always change the seals (2 and 4).
 Built-in safety valve (3).
 Opening pressure

0.82 - 1.03 bar

540480 Oil vapour recirculation system

Figure 229


Description

The oil vapours formed in the sump while the engine is running, passing through the overhead cover, are channelled into the separator / condenser filter known as the blow-by. The filter is structured in two sections:

- ❑ The first one with a labyrinth, where most of the vapours are condensed and return to the sump through an umbrella outlet valve.
- ❑ The second one includes a coalescence filter that condenses the remaining vapours that return to the sump through another umbrella valve.

The portion of vapour that has not condensed is sent, via a MANN-HUMMEL valve, to the intake duct and burnt during normal engine operation.

NOTE The blow-by filter cannot be taken apart and must therefore be replaced entirely.



OIL VAPOUR RECIRCULATION DIAGRAM

I. MANN-HUMMEL valve – 2. Umbrella valves – 3. Blow-by filter – A. Labyrinth – B. Intake oil vapour recovery flow – C. Oil return flow into sump – D. Flow of oil vapours from the sump – E. Flow of oil vapours from the overhead – F. Coalescence filter.

5432 COOLING**Description**

The engine cooling system is the type with forced circulation in a closed circuit. It comprises the following parts:

- An expansion tank whose plug has two valves incorporated in it: an outlet and an inlet, which govern the pressure of the system.
- A coolant level sensor at the base of the expansion tank.
- An engine cooling module to dissipate the heat taken from the engine by the coolant with a heat exchanger for the intercooler.
- A heat exchanger to cool the lubricating oil.
- A heat exchanger to cool the exhaust gases (engines with EGR).
- A centrifugal water pump incorporated in the crankcase.
- An electric fan comprising an electromagnetic coupling on whose shaft a hub turns idle that is fitted with an axially mobile metal plate on which is mounted the impeller.
- A 3-way thermostat governing the circulation of the coolant.

Operation

The water pump driven by a poly-V belt by the crankshaft sends coolant into the crankcase and with a greater head into the cylinder head.

When the coolant temperature reaches and exceeds the working temperature, it causes the thermostat to open and the fluid is channelled from here to the radiator and cooled by the fan.

The pressure in the system due to the change in temperature is governed by the outlet (2) and inlet (1) valves incorporated in the expansion tank filler plug (detail A).

The outlet valve (2) has a twofold function:


- to keep the system slightly pressurized so as to raise the boiling point of the coolant;
- to discharge into the atmosphere the excess pressure produced in case of high coolant temperatures.

The function of the inlet valve (1) is to permit transferring the coolant from the expansion tank to the radiator when a lower pressure is created in the system due to the reduction in volume of the coolant as a result of its temperature lowering.

Outlet valve opening $1 \pm 0.1 \text{ kg/cm}^2$.


Inlet valve opening $0.005 - 0.02 \text{ kg/cm}^2$.

Figure 230



543212 Electromagnetic pulley

Figure 231



CROSS-SECTION OF THE ELECTROMAGNETIC JOINT

Characteristics

Transmissible torque at 20°C with clutch run in 45 Nm
 Voltage 12 Volts
 Power input 26 W

The electric fan control relay is activated or deactivated according to the temperatures of: the engine coolant, the fuel supercharging air and the pressure of the air conditioner fluid (if present).

Coolant temperature

(if the sensor is not defective)
 It activates at > 96°C and deactivates at < 84°C.

Turbocharging air temperature

It activates at > 75°C and deactivates at < 65°C.

Fuel temperatures


(if the coolant temperature sensor is acknowledged to be defective by the EDC control unit)
 It activates at > 20°C and deactivates at < 10°C.

With climate control system

With pressure in the system
 it turns on 18.5 ± 0.98 bar
 it turns off 14.58 ± 0.98 bar


543210 Water pump

Figure 232



The water pump (3) cannot be overhauled. In case of coolant leaking from the seal or damage, it must be replaced. The water pump casing (1) is also used as a mounting for the high-pressure pump. The seals (3 and 4) must always be replaced.

Figure 233




LONGITUDINAL CROSS-SECTION OF THE WATER PUMP

1. Pump casing – 2. Pump drive shaft together with bearing – 3. Seal – 4. Impeller.

543250 Thermostat

Figure 234




The by-pass thermostat (1) needs no adjustment. If there is any doubt about its operation, replace it. The thermostat casing is fitted with the thermometric switch/transmitter and water temperature sensor.

- A. – A1 Start of stroke at 78°C ± 2°C.
 - B. Valve (1) stroke at 94°C = 7 mm.
 - B1 Valve (2) stroke 94°C, 6.4 mm
- The stroke of 7 mm less than 60".

TURBOCHARGING

Figure 235



75531

TURBOCHARGING DIAGRAM


Description

The turbocharging system comprises an air filter, turbocharger and intercooler. The air filter is the dry type comprising a filtering cartridge to be periodically replaced.

The function of the turbocharger is to use the energy of the engine's exhaust gas to send pressurized air to the cylinders. The intercooler comprises a radiator included in the engine coolant radiator and its function is to lower the temperature of the air leaving the turbocharger to send it to the cylinders.


542410 Turbocharger

Figure 236



75532

Figure 237



75533

It is basically composed of:

- a central casing housing a shaft supported by bushings at whose opposite ends are fitted the turbine wheel and the compressor rotor;
- a turbine casing and a compressor casing mounted on the end of the central body;


- an overpressure relief valve fitted on the turbine casing. Its function is to choke the exhaust gas outlet (detail B), sending a portion of the exhaust gas straight into the exhaust pipe when the turbocharging pressure downstream from the turbocharger reaches the setting.

REPAIRS

NOTE On finding irregular engine operation due to the turbocharging system, it is first expedient to perform the checks on the turbocharger, check the efficiency of the seals and the fixing of the couplings, additionally checking there is no clogging in the intake sleeves, air filter or radiators. If the turbocharger damage is due to a lack of lubrication, check that the oil circulation pipes are not burst or clogged, in which case replace them or eliminate the trouble.


54249 Pressure relief valve Checking and adjusting pressure relief valve

Figure 238



Cover the air, exhaust gas and lubricating oil inlets and outlets. Thoroughly clean the outside of the turbocharger using anticorrosive and antioxidant fluid. Disconnect the pipe (2) from the union of the pressure relief valve (1) and fit on it the pipe of the device 99367121 (1, Figure 239).


Figure 239



Rest the tip of the dial gauge (1) with a magnetic base on the end of the tie rod (2) and zero it. Using the device 99367121 (5), introduce compressed air into the valve casing (6) at the prescribed pressure and make sure this value stays constant throughout the check; replace the valve if it doesn't. In the above conditions, the tie rod must have made the prescribed travel. On finding a different value, use the nuts (3 and 4).

Replacing pressure relief valve

Figure 240



Take off the nut (2).

Take out the screws (5) and detach the bracket together with the relief valve (7) from the turbocharger.

Mount the new valve, performing the operations for disassembly in reverse order, and register it as follows:

Screw the nut (3) onto the stem (4) of the valve down to the end of the thread. Mount the lever (1) on the valve stem.

Using device 99367121 (5, Figure 239), introduce compressed air into the valve (7) at the prescribed pressure; in this condition, screw down the nut (2) until the throttle valve controlled by the lever (1) gets positioned in its seat.

Unscrew the nut (3) to bring it into contact with the lever (1) and at the same time block the nuts (2 and 3).


Adjust the pressure relief valve (7) as described under the relevant heading.

Afterwards, paint the nuts (2 and 3) with safety paint and connect the pipe (6) to the valve (7), securing it with a new retaining clamp.

NOTE Before fitting the turbocharger on the engine, it is necessary to fill the central body with engine lubricating oil.

EXHAUST GAS RECIRCULATION (EGR) SYSTEM

Figure 241



a. Brake booster vacuum circuit - b. EGR modulated vacuum circuit

1. ECU - 2. High pressure pump - 3. Coolant temperature sensor - 4. Engine rpm sensor - 5. EGR pneumatic valve - 6. Flow meter - 7. Suction air cleaner - 8. Modulating solenoid valve - 9. Air cleaner - 10. Vacuum brake booster - 11. Reservoir - 12. Vacuum unit.

EGR system operation

The EGR system is similar to that fitted on 8140.63 engines and described in the specific system section.

Differences with respect to the previous version fitted on 8140.63 engines include: application of an exhaust gas heat exchanger and air flow meter; governing system implementing EDC MS6.3 or EDC I6, different modulating solenoid valve and pneumatic EGR calibration values.

Operating principles

The ECU (MS6.3 or EDC I6) processes the data from the atmospheric pressure sensor, coolant sensor, engine rpm sensor, accelerator pedal potentiometer and controls the modulating solenoid valve via a PWM signal according to programmed settings.


The control signal output by the ECU controls the modulating solenoid valve which puts the brake booster vacuum circuit into communication with that of the EGR. The vacuum created in the EGR circuit depends on the control signal.

The vacuum acts on the pneumatic EGR valve by recalling and lifting the shutter which normally closes the passage of exhaust gasses to suction.

This puts the exhaust manifold into communication with the suction manifold and part of the exhaust gasses flows into the intake manifold.

The control signal from the ECU to the modulating valve is cancelled during engine conditions not requiring exhaust gas recirculation (cranking, cold engine, idling, load request, high altitude). The solenoid valve closes the connection between the brake booster vacuum circuit and the EGR circuit; at the same time, atmospheric pressure is re-established in the EGR circuit by letting in air through the specific air cleaner.

Figure 242



86036

Air flow meter

- 1. Connector - 2. Flow meter body - 3. Air and recirculated gas inlet mesh - 4. Suction air temperature sensor - 5. Power - 6. Ground - 7. Reference voltage - 8. Output signal.

The heated film flow meter is arranged between the turbine and the intercooler.

The suction air temperature sensor is built into the flow meter; the flow meter is connected to the ECU pins A5/A17/A18/A26/A28.


Operation

The hot film membrane temperature is kept constant (approximately 120 °C higher than suction air temperature) by a heating resistor.

The air mass crossing the duct tends to subtract heat from the membrane. Consequently more current is required through the resistor to keep the temperature constant.

Current uptake is proportional to the mass of air flowing into the engine. It is measured by a Wheatstone bridge and the resulting signal is sent to the ECU.

Figure 243



75537

EXHAUST GAS COOLING

- A. Intake exhaust gas – B. Cooled exhaust gas – C. Coolant to heater – D. Gas from E.G.R. valve – E. Coolant arriving from cylinder head.

FUEL SUPPLY HIGH-PRESSURE ELECTRONIC INJECTION SYSTEM (MS 6.3 - EDC 16) General

Common Rail MS6.3 is a high-pressure electronic injection system for fast diesel engines with direct injection. Its main features comprise:

- high injection pressures available (1600 bar);
- these pressures can be modulated between 150 bar up to the maximum operating pressure of 1600 bar, irrespective of the speed of rotation and engine load;
- capacity to operate at very high speeds (up to 6000 rpm);
- injection control precision (injection duration and advance);
- lower consumption;
- lower emissions.

The main functions of the system are basically as follows:

- checking fuel temperature;
- checking engine coolant temperature;
- checking amount of fuel injected;
- checking idling speed;
- cutting off fuel in release phase;
- checking cylinder balancing when idling;
- checking anti-sawing;
- checking smokiness at exhaust on acceleration;
- checking exhaust gas recirculation (E.G.R. if present);
- checking top speed limit;
- checking glow plugs;
- checking activation of air-conditioning system (if any);
- checking auxiliary fuel pump;
- checking position of cylinders;
- checking main and pilot injection advance;
- checking closed cycle of injection pressure;
- checking turbocharging pressure;
- self-diagnosis;
- connection with immobilizer unit;
- checking maximum torque limitation.


The system makes pre-injection (pilot injection) possible before the TDC with the advantage of decreasing the derivative of the pressure in the combustion chamber, lowering the noise level of combustion, which is typical of direct injection engines.

The control unit checks the amount of fuel injected, adjusting the line pressure and injection times.

The information the control unit processes to regulate the amount of fuel to be injected comprises:

- engine speed;
- coolant temperature;
- turbocharging pressure;
- air temperature;
- intake air quantity;
- battery voltage;
- diesel pressure;
- position of throttle pedal.

Figure 244



HIGH-PRESSURE ELECTRONIC INJECTION SYSTEM COMPONENTS LAYOUT

1 Timing phase sensor – 2 Electro-injectors – 3 Glow plug – 4 Coolant temperature sensor – 5 Electromagnetic fan – 6 E.G.R. valve modulator (if present) – 7. Engine speed sensor – 8 Compressor (if present) – 9 High-pressure pump – 10 Pressure regulator – 11 Fuel filter – 12 Fuel temperature sensor – 13 Fuel filter clogging sensor – 14 Electric supply pump – 15 Fuel pre-filter – 16 Fuel tank – 17 Battery – 18 Control unit with atmospheric pressure sensor – 19 Throttle pedal sensor – 20 Clutch pedal sensors – 21 Brake pedal sensors – 22 Fuel check valve – 23 Heater – 24 Air temperature pressure sensor – 25 Hydraulic accumulator (rail) pressure relief device – 26 Forged version hydraulic accumulator (rail) – 27 Hydraulic accumulator (rail) fuel pressure sensor – 28 Engine rev counter – 29 Tachograph – 30 Starter heater indicator light – 31. Welded version hydraulic accumulator.

In box A, there is shown the variant with welded version hydraulic accumulator.

SYSTEM OPERATION

Self-diagnosis – BLINK CODE

The control unit self-diagnosis system checks the signals from the sensors, comparing them with the admitted limits (see relative heading):

Immobilizer recognition

When the control unit receives the signal of the key on "MAR" it communicates with the immobilizer control unit to enable starting.

Checking fuel temperature

With the fuel temperature greater than 75°C, detected by the sensor on the fuel filter, the control unit operates the pressure regulator to decrease the line pressure (injection times are not changed). If the temperature exceeds 90°C, the power is reduced to 60%.

Checking engine coolant temperature

The control unit, depending on the temperature:

- of the engine coolant, turbocharging air and fuel, operates the electromagnetic fan (Baruffaldi) and switches on the coolant temperature warning light.

Checking quantity of fuel injected

According to the signals from the sensors and the mapped values, the control unit:

- operates the pressure regulator;
- varies the "pilot" injection time to 2200 rpm;
- varies the "main" injection time.

Checking idling adjustment

The control unit processes the signals from the various sensors and regulates the amount of fuel injected:

- it operates the pressure regulator;
- it varies the injection times of the electro-injectors.

Within certain thresholds the speed takes account of the battery voltage.

Fuel cut-off in release phase

In the phase of releasing the throttle pedal the control unit actuates the following logic elements:

- it cuts off supply to the electro-injectors;
- it partially reactivates supply to the electro-injectors before reaching idling speed;
- it operates the fuel pressure regulator.

Checking cylinder balancing on idling

According to the signals received from the sensors, the control unit controls the regularity of the torque at idling speed:

- it varies the amount of fuel injected into the single electro-injectors (injection time).

Checking regular engine rotation (anti-sawing)

It ensures regular engine rotation at a constant rate while increasing revs.

The control unit processes the signals received from the sensors and determines the amount of fuel to be injected via:

- the pressure regulator;
- the electro-injector opening time.

Checking smokiness at exhaust on acceleration

With heavy acceleration, on the basis of the signals received from the air introduction meter and engine speed sensor, the control unit determines the optimum amount of fuel to inject:

- it operates the pressure regulator;
- it varies the electro-injector injection time.

Checking exhaust gas recirculation (E.G.R. if present)

Depending on the engine load and the signal from the accelerator pedal sensor, the control unit limits the amount of air taken in, actuating partial suction of the exhaust gases.

Checking top speed limit

Depending on the number of revs, the control unit actuates two action strategies:

- at 4250 rpm it cuts off the fuel, decreasing the electro-injector opening time;
- over 5000 rpm it deactivates the electro-injectors.

Checking regular rotation on acceleration

Regular progression is assured in all conditions by the control of the pressure regulator and the electro-injector opening time.

Checking glow plug control unit

The injection control unit, in the phase of:

- starting
- after-starting

times operation of the glow plugs according to the engine temperature.

Checking activation of air-conditioning system

The control unit operates the air-conditioning compressor:

- switching it on/off when the relative switch is pressed;
- momentarily turning it off (approximately 6 sec.) if the engine coolant reaches the set temperature.

Checking fuel pump

Irrespective of the speed, the control unit:

- supplies the auxiliary fuel pump with the key on MAR;
- cuts off auxiliary pump supply if the engine is not started up within a few seconds.

Checking diesel warming

It times operation of diesel warming in relation to ambient temperature.

Checking cylinder position

During each turn of the engine, the control unit recognizes which cylinder is in the power stroke and operates the injection sequence for the appropriate cylinder.

Checking pilot and main injection timing

According to the signals from the various sensors, including the absolute pressure sensor built into the control unit, the control unit determines the optimum point of injection according to internal mapping.

Checking injection pressure closed cycle

Depending on the engine load, determined by processing the signals from the various sensors, the control unit operates the regulator to obtain optimum line pressure.

Fuel supply

The fuel supply is calculated in relation to:

- accelerator pedal position
- engine speed
- quantity of air introduced.

The outcome may be corrected in relation to:

- the water temperature.

Or to avoid:

- noise
- smoke
- overloading
- overheating
- turbine over-revving.

The delivery can be modified in the case of:

- action of external devices (ABS), ABD, EDB
- serious trouble decreasing the load or stopping the engine.

After determining the mass of air introduced by measuring its volume and temperature, the control unit calculates the corresponding mass of fuel to inject into the relevant cylinder (mg per delivery) also taking into account the temperature of the diesel.

The mass of fuel calculated in this way is first converted into volume (mm³ per delivery) and then into degrees of throw, or duration of injection.

Correcting flow rate according to water temperature

A cold engine meets with greater resistance during operation: friction is high, the oil is still very viscous, and the various clearances are not yet optimized.

In addition, the injected fuel tends to condense on the metal surfaces that are still cold.

The fuel supply for a cold engine is therefore greater than for a warm one.

Correcting flow rate to avoid noise, smoke or overloading

The behaviour that could lead to this kind of trouble is well known.

The designer has therefore included special instructions in the control unit to avoid it.

De-rating

In the event of the engine overheating, injection is modified, decreasing the delivery to a varying degree, in proportion to the temperature reached by the coolant.

Injection timing electronic test

The advance (start of delivery, expressed in degrees) may be different from one injection to the next, also differentiated from one cylinder to another. It is calculated, similarly to the delivery, in relation to the engine load (accelerator position, engine speed and air introduced).

The advance is appropriately corrected:

- in phases of acceleration;
- according to the water temperature.

And also to obtain:

- lower emissions, noise and overloading;
- better vehicle acceleration.

An extremely high advance is set on starting, depending on the water temperature.

Feedback from the start of delivery is supplied by the change in impedance of the injector solenoid valve.

Speed governor

The electronic speed governor has both features of governors:

- idling and top speed
- all speeds

It is stable in ranges where conventional, mechanical governors are imprecise.

Engine starting

During the first few turns of the engine, the timing and cylinder no. 1 recognition signals (flywheel sensor and camshaft sensor) are synchronized.

The accelerator pedal signal is ignored on starting. Starting delivery is set only according to water temperature, by a special map.

When the control unit detects such speed and acceleration of the flywheel as to be able to consider the engine started up and no longer driven by the starter motor, it re-enables the accelerator pedal.

Cold starting

If even just one of the three temperature sensors (water, air or diesel) records a temperature lower than 10°C, pre-post heating is activated.

When the key makes contact the pre-heating indicator light comes on and stays on for a length of time that varies in relation to the temperature (while the glow plugs in the cylinder head heat the air), then flashes. It is now possible to start up the engine.

When the motor is running this indicator light goes out, while the glow plugs continue to be powered for a certain length of time (variable) for post-heating.

If, with the indicator light flashing, the engine is not started up within 20-25 seconds (inattention time), the operation is cancelled so as not to run down the batteries pointlessly.

The pre-heating curve is also variable in relation to the battery voltage.

Warm starting

If the reference temperatures all exceed 10°C, when the key makes contact the indicator light comes on for approximately 2 sec., for a short test, and then goes out. It is now possible to start up the engine.

Run up

When the key makes contact, the control unit transfers the information stored in memory when the engine was last stopped into the main memory (see After Run) and makes a diagnosis of the system.

After run

Whenever the engine is switched off with the key, the control unit stays powered for a few seconds by the main relay.

This makes it possible for the microprocessor to transfer some data from the main memory (volatile) to a non-volatile memory, which can be erased and written over (EEPROM), so as to make it available at the next start up (see Run Up).

These data basically consist of:

- various settings (engine idling adjustment, etc.);
- settings of some components;
- fault memory.

The process lasts a few seconds, typically from 2 to 7 (depending on the amount of data to save), after which the ECU sends a command to the main relay and makes it disconnect from the battery.

NOTE It is extremely important for this procedure not to be broken off, for example by switching off the engine with the battery cut-out, or by disconnecting the battery cut-out before 10 seconds have passed since switching off the engine. If this happens, the functioning of the system is ensured, but repeated interruptions may damage the control unit.

Cut-off

This function cuts off fuel delivery when the vehicle is decelerating (accelerator pedal released).

Cylinder balancing

Individual cylinder balancing contributes to increasing comfort and handling.

This function permits individual, customized control over the delivery of fuel and the start of delivery for each cylinder, even differently from one cylinder to another, to compensate for the hydraulic tolerances of the injector.

The differences in flow (delivery specifications) between the various injectors cannot be evaluated directly by the control unit. This information is supplied by Modus reading the bar code of each injector at the time of assembly.

Synchronization search

If there is no signal from the camshaft sensor, the control unit is anyhow able to recognize the cylinders into which the fuel is to be injected.

If this occurs when the engine is already running, the combustion sequence has already been acquired, so the control unit continues with the sequence on which it has already been synchronized.

If this occurs when the machine is at a standstill, the control unit energizes a single solenoid valve. Within at most 2 turns of the crankshaft, injection will take place in that cylinder, so the control unit just needs to get synchronized on the firing sequence and to start up the engine.

OPERATION

In this injection system, the pressure regulator, located upstream from the high-pressure pump, governs the flow of fuel needed in the low-pressure system. Afterwards, the high-pressure pump correctly supplies the hydraulic accumulator.

This solution, pressurizing solely the necessary fuel, improves the energy efficiency and limits heating the fuel in the system. The relief valve fitted on the high-pressure pump has the function of keeping the pressure, at the pressure regulator inlet, constant at 5 bars; irrespective of the efficiency of the fuel filter and of the system upstream. The action of the relief valve causes an increase in the flow of fuel in the high-pressure pump cooling circuit.

The high-pressure pump continually keeps the fuel at the working pressure, irrespective of the timing and the cylinder that is to receive the injection and accumulates it in a duct common to all the electro-injectors.

At the electro-injector inlet, there is therefore always fuel at the injection pressure calculated by the electronic control unit.

When the solenoid valve of an electro-injector is energized by the electronic control unit, fuel taken straight from the hydraulic accumulator gets injected into the relevant cylinder.

The hydraulic system is made out of a low-pressure fuel recirculation circuit and a high-pressure circuit.

The high-pressure circuit is composed of the following pipes:

- pipe connecting the high-pressure pump outlet to the Rail;
- hydraulic accumulator;
- pipes supplying the electro-injectors.

The low-pressure circuit is composed of the following pipes:

- fuel intake pipe from the tank to the pre-filter;
- pipes supplying the mechanical supply pump and the pre-filter;
- pipes supplying the high-pressure pump via the fuel filter.


The fuel system is completed by the fuel outlet circuit from the hydraulic accumulator and from the electro-injectors.

According to the high performance of this hydraulic system, for reasons of safety it is necessary to:

- avoid connecting high-pressure pipe fittings with approximate tightening;
- avoid disconnecting the high-pressure pipes with the engine running (NEVER try bleeding, which is both pointless and dangerous).

The integrity of the low-pressure circuit is also essential for the system to work properly; it is therefore necessary to avoid all manipulation and modifications and act only in the event of leakage.

Figure 245



FUEL RECIRCULATION AND SUPPLY SYSTEM DIAGRAM

1. CP3 high-pressure pump with integrated supply pump – 2. Fuel arrival pipe from the filter – 3. Pressure regulator – 4. Water in filter sensor – 5. Fuel filter with water separator – 6. Fuel temperature sensor – 7. Fuel warming – 8. Fuel delivery pipe to the filter – 9. Fuel return pipe to the tank – 10. Fuel check valve – 11. Multiple coupling – 12. Fuel return low pressure piping - 13. Welded version hydraulic accumulator - 14. High-pressure delivery pipe to the hydraulic accumulator – 15. Low-pressure return pipe from the hydraulic accumulator to the multiple coupling – 16. Overpressure valve – 17. Forged version hydraulic accumulator – 18. Pressure sensor – 19. High-pressure pipe between hydraulic accumulator and electro-injectors – 20. Electro-injectors – 21. Return pipe from the electro-injectors to the high-pressure pump CP3.

NOTE The pipes connected to the fuel filter mounting are quick-coupling ones. Before fitting them, make sure the couplings and the associated fittings on the mounting are clean.

HYDRAULIC SYSTEM

The hydraulic system is composed of:

- tank
- pre-filter
- electric supply pump
- fuel filter
- high pressure supply pump with supply pump built in pressure regulator
- manifold (rail)
- electro-injectors
- supply pipes and fuel recirculation

773010 Fuel pump

This rotary positive displacement pump with integrated by-pass is mounted on the suction pipe, on the left-hand side of the chassis frame.

The fuel pump is the roller-type with positive displacement, a brush motor with energizing by permanent magnets.

The impeller turns, driven by the motor, creating volumes that shift from the inlet port to the delivery port.


These volumes are defined by the rollers that stick to the outer ring when the motor turns.

The pump has two valves, a check valve to prevent the fuel circuit from emptying (with the pump stationary) and an overpressure valve that recirculates the delivery with the inlet when pressures over 5 bar are produced.

Specifications


| | |
|--------------------------|----------------|
| Delivery pressure: | 2.5 bar |
| Flow rate: | > 155 litres/h |
| Power supply: | 13.5 V - < 5 A |
| Coil resistance at 20°C: | 28.5 Ohms |

Figure 246



50707

CROSS-SECTION OF FUEL PUMP

542011 Fuel filter**Figure 247**

88613

1. Clogging signalling sensor - 2. Temperature sensor connector - 3. Heater support - 4. Water in signalling sensor - 5. Overpressure valve - 6. Heater connector - 7. Bending insert - 8. Fuel filter - 9. Water separator - 10. Connector - 11. Connector - 12. Purging screw.

The fuel filter is composed of a cartridge (8) equipped with a water separator (9).

The water accumulation capacity (A) of the filter is approx. 100 cm³.

The water indicator (4) is mounted on the bottom end. Unscrewing the indicator (4) drains off any water.

Heater support (3) has an integrated temperature sensor.

On heater support (3) there are screwed up sensor (1) to signal filter clogging and non return valve (5).

When the temperature of the diesel is less than 6 °C, an electric heating element warms it up to at most 15 °C before sending it to the high pressure pump.

Check valve characteristics

opening pressure $0.5 \begin{smallmatrix} +0.05 \\ -0.1 \end{smallmatrix}$ bar

differential pressure less than 0.2 bar at 120 litres/h of fuel.


Clogging indicator characteristics

differential working pressure 1.1 bar

Tightening torques

| | |
|--|------------|
| 1. Tightening clogging signalling sensor | 20±2 Nm |
| 4. Water in signalling sensor | 0.8±1.2 Nm |
| 5. Check valve tightening | 25±2 Nm |
| 8. Fuel filter tightening | 18±2 Nm |
| 10. Connector | 35±2 Nm |
| 11. Connector | 35±2 Nm |
| 12. Bleed screw | 4 Nm |
| 7.* Threaded insert | 35±2 Nm |


* Before mounting, apply thread holding down Loctite on thread.

Fuel pipes**Figure 248**

75585

1. High-pressure pump supply pipe quick-coupling fitting – 2. Supply pipe quick-coupling fitting – 3. Fuel return pipe quick-coupling fitting – 4. Fuel filter mounting.

If disconnecting the fuel pipes (1-2-3) from the mounting (4), it is necessary, when refitting, to make sure their fittings are perfectly clean. This is to avoid an imperfect seal and fuel getting out.

775010 High-pressure pump**Figure 249**


85846

1. Mechanical feeding pump - 2. CP3 high pressure pump - 3. Pressure regulator
 A. To the tank - B. Return from rail - C. Return from fuel filter - D. Delivery to rail - E. From tank - F. Return to injectors.

Pump with 3 radial pumping elements controlled via a gear by the timing belt; it needs no timing. On the rear of the high-pressure pump there is the mechanical supply pump, controlled by the shaft of the high-pressure pump. The pump is lubricated and cooled by the fuel.

NOTE The high-pressure pump – supply pump assembly cannot be overhauled and therefore the fixing screws must be neither removed nor tampered with. The only permissible job is replacing the driving gear.

Figure 250




85847

1 Delivery valve on single pumping element – 2. Relief valve 5 bar – 3. Pressure regulator – 4. Fuel inlet from filter – 5. Pump shaft – 6. Delivery valve to common rail – 7. Fuel return from high-pressure pump – 8. Mechanical supply pump.

High-pressure pump internal structure

Figure 251



70498

1. Cylinder – 2. Three-lobed element – 3. Plate intake valve – 4. Ball delivery valve – 5. Plunger – 6. Pump shaft – 7. Low-pressure fuel inlet – 8. Fuel ducts to supply pumping elements.

Each pumping assembly comprises:


- a plunger (5) operated by a three-lobed element (2) floating on the shaft of the pump (6). Since the element (2) floats on a misaligned portion of the shaft (6), during shaft rotation, it does not turn with it but is only shifted

in a circular movement on a wider radius, with the result of working the three pumping elements alternately:

- a plate intake valve (3);
- a ball delivery valve (4).


Working principle

Figure 252



Sec. B - B

Figure 253



Sec. D - D


72597

1. Outlet for delivery to rail – 2. Delivery valve to rail – 3. Pumping element – 4. Pump shaft – 5. Pumping element supply duct – 6. Pressure regulator supply duct – 7. Pressure regulator.

The pumping element (3) is arranged on the cam on the pump shaft. In the suction phase, the pumping element is supplied through the supply duct (5). The amount of fuel to send to the pumping element is determined by the pressure regulator (7). The pressure regulator, on the basis of the PWM command

received from the control unit, chokes the flow of fuel to the pumping element. During the compression phase of the pumping element, the fuel, on reaching such a pressure as to open the delivery valve to the common rail (2), supplies it through the outlet (1).

Figure 254

**Sec. C – C** (Figure 253)

72598

72599

1, 3, 6 Pumping element inlet – 2. Pump lubrication ducts – 4. Main pumping element supply duct – 5. Pressure regulator – 7. Regulator outlet duct – 8. Relief valve 5 bar – 9. Fuel outlet from regulator inlet.



Figure 254 shows the low-pressure fuel routing in the pump; it highlights the main supply duct of the pumping elements (4), the supply ducts of the pumping elements (1-3-6), the ducts used to lubricate the pump (2), the pressure regulator (5), the 5-bar relief valve (8) and the fuel outlet.

The pump shaft is lubricated by the fuel through the delivery and return ducts (2).

The pressure regulator (5) determines the amount of fuel with which to supply the pumping elements; excess fuel flows out through the duct (9).

The 5-bar relief valve, besides acting as a manifold for the fuel outlets, has the function of keeping the pressure constant at 5 bars at the regulator inlet.

Figure 255



72600

72601

Sec. A – A (Figure 253)

1, 2 Fuel outlet ducts – 3. Fuel outlet from the pump with coupling for high-pressure pipe for the common rail.

The figure shows the high-pressure fuel flow through the outlet ducts of the pumping elements.

771034 Pressure control valve


The fuel pressure regulator is mounted on the low-pressure circuit of the CP3 pump. The pressure regulator modulates the amount of fuel sent to the high-pressure circuit according to the commands received directly from the engine control unit. The pressure regulator is mainly composed of the following components:

- connector
- casing
- solenoid
- pre-load spring
- shutter cylinder.

When there is no signal, the pressure regulator is normally open, therefore with the pump providing maximum delivery. The engine control unit, via the PWM (Pulse Width Modulation) signal, modulates the change in fuel flow rate in the high-pressure circuit by partially closing or opening the sections of passage of the fuel in the low-pressure circuit.

Operation

Figure 256




75574

1. Solenoid – 2. Magnetic core – 3. Shutter cylinder –
4. Fuel inlet – 5. Fuel outlet.

When the engine control unit governs the pressure regulator (via PWM signal), the solenoid (1) is energized that, in its turn, generates the movement of the magnetic core (2). The shift of the core causes the shutter cylinder (3) to move axially, choking the flow of fuel.

Figure 257




75575

1. Solenoid – 2. Magnetic core – 3. Pre-load spring –
4. Shutter cylinder.

When the solenoid (1) is not energized, the magnetic core is pushed into the rest position by the pre-load spring (3). In this condition, the shutter cylinder (4) is in such a position as to offer the fuel the greatest section of passage.

Replacing pressure regulator.


Figure 258



88406

Accurately clean high pressure pump. Take off screws (2) and unthread pressure regulator (3) from high pressure pump.

Figure 259




88407

Accurately clean the seat (→) of pressure regulator and the connection surface (→) of the regulator.

NOTE For cleaning, do not use a tool which could damage the surfaces and pay attention that impurities are not introduced into channels.


Figure 260



88408

Mount new seal rings (1 and 2) on pressure regulator (3) and lubricate the rings with vaseline.


Figure 261



Mount pressure regulator (1) on high pressure pump (2).

NOTE Mounting operation must be performed keeping the regulator perpendicular to connection plane without angling it, in order not to damage seal rings (1-2, Figure 260).

Figure 262




Screw up screws (1) and tighten them at 6 ± 7 Nm (0.6 ± 0.7 kgm) torque.

NOTE Where pressure regulator is replaced on the engine mounted on the vehicle, it is needed, after replacement, to check that there are no fuel leaks after an engine working period.

MECHANICAL SUPPLY PUMP

Normal working condition

Figure 263




A. Fuel inlet from the tank – B. Fuel outlet to the filter –
1, 2 By-pass valves in closed position.

The function of the gear pump, mounted on the rear of the high-pressure pump, is to supply the high-pressure pump. It is governed by the shaft of the high-pressure pump. In normal working conditions, the flow of fuel inside the mechanical pump is shown in the figure.

Conditions of outlet overpressure


Figure 264



The by-pass valve (1) trips when overpressure is generated at the outlet B. The pressure, overcoming the elastic resistance of the spring of the valve (1), sets the outlet in communication with the inlet via the duct (2).

Conditions of bleeding

Figure 265



The by-pass valve (1) trips when, with the engine switched off, you want to fill the supply system via the priming pump. In this situation, the by-pass valve (2) opens, due to the effect of the inlet pressure, and the fuel flows out via the outlet B.


774510 Hydraulic accumulator (rail)

The hydraulic accumulator is mounted on aspiration side cylinder head.

Its task is to damp pressure oscillations caused:

- the operation of the high-pressure pump;
- the opening of the electro-injectors.


Figure 266



75576

I. Forged version hydraulic accumulator, inner volume ~ 22 cm³ - 2. Fuel pressure sensor - 3. Overpressure valve.

Figure 267




88418

I. Welded version hydraulic accumulator, inner volume ~ 23 cm³ - 2. Fuel pressure sensor.

Overpressure valve (for forged hydraulic accumulator)

Figure 268




70500

I. Casing – 2. Plunger – 3. Stop – 4. Spring – 5. Direct outlet to tank – 6. Seat on rail.

The pressure relief valve protects the system components if the fuel pressure exceeds the setting: 1750 bars.

A. The tapered end of the plunger normally keeps the outlet to the tank shut.

Figure 269




70502

B. If the pressure of the fuel in the hydraulic accumulator exceeds 1750 bars, the plunger gets shifted and the excess pressure is discharged into the tank.

775010 ELECTRO-INJECTORS

Figure 270



75588


The electro-injectors have high-pressure supply (up to 1600 bar) and recirculation at atmospheric pressure, necessary for the diesel used to operate the pilot valve.

The temperature of the diesel put back into circulation by the electro-injector can get very high (approximately 120°C).

The head of the electro-injector has a fitting for the electrical connector.

They are mounted on the cylinder head and operated by the injection control unit.

Figure 271



1 Pressure rod – 2 Pin – 3 Nozzle – 4 Coil – 5 Pilot valve –
6 Ball shutter – 7 Control area – 8. Pressure chamber –
9 Control volume – 10 Low-pressure fuel return –
11 Control pipe – 12 Supply pipe – 13 Electrical connection
– 14 High-pressure fuel inlet fitting – 15 Spring.

The electro-injector can be divided into two parts:

- actuator/jet composed of pressure rod (1), pin (2) and nozzle (3);
- control solenoid valve composed of coil (4) and pilot valve (5).

Operation

Electro-injector operation can be broken down into three phases:

- "rest position"

Coil (4) is de-energised, and shutter (6) is in closing position and prevents fuel from being introduced into the cylinder, $F_c > F_a$ (F_c : caused by fuel pressure acting on control area (7) of rod (1); F_a : caused by line pressure acting on pressure chamber (8)).

- "start of injection"

The coil (4) is energized and causes the shutter (6) to rise. The fuel of the control volume (9) flows off towards the return manifold (10) causing a drop in pressure in the control area (7).

At the same time, line pressure through feed duct (12) applies a force $F_a > F_c$ in pressure chamber (8) lifting peg (2), with fuel being consequently introduced into cylinders.


- "end of injection"

The coil (4) is de-energized and makes the shutter (6) return to its closed position. This recreates such a balance in the forces as to make the pin (2) return to its closed position and consequently end injection.

ELECTRIC/ELECTRONIC COMPONENTS

766161 Electronic control unit MS6.3 or EDC 16

Figure 272



The control unit is a "flash EPROM" and so it can be reprogrammed from outside without changing the hardware. It processes the signals from the sensors by applying software algorithms and controls the actuators (especially the electro-injectors and pressure regulator).

The injection control unit has the absolute pressure sensor built in to further improve the control of the injection system. The control unit is mounted on the left-hand side of the engine bay and is connected to the vehicle's wiring harness by two 43-pin connectors:

MS6.3:

- 43-pin connector **A** for the components on the engine
- 43-pin connector **B** for the components on the vehicle


EDC.16:

- 60-pin connector **A** for the components on the engine
- 94-pin connector **K** for the components on the vehicle

In addition to handling the operation of the system described under the relevant heading, the electronic control unit is interfaced with the other electronic systems on the vehicles such as ABS – EBD cruise control, speed limiting device, immobilizer (IVECO CODE), EGR and glow plugs.

761917 Glow plug electronic control unit

Figure 273



75578

The engine control unit, in the phase of:

- starting
- after-starting


times the operation of the glow plug control unit according to the engine temperature.

Glow plugs drive is through glow plugs pre-heating central unit depending on engine temperature under close control of engine control central unit.

The pre-heating control unit contains an "intelligent" contactor that sends feedback to the control unit that is thus informed about any fault with the pre-heating control unit or shorting to earth of the glow plugs.

761915 Glow plugs

Figure 274



75579

CONTROL VALUES

With a constant supply voltage of 11 V:

- | | |
|----------------------------|-----------|
| - max. current drawn | 18 A |
| - in 5 sec. | 11 ±1.5 A |
| - in 30 sec. | 6 ±0.9 A |
| - temperature after 7 sec. | 850°C |
| - tightening torque | 8-10 Nm |

SENSORS

Engine speed sensor

It is an inductive type sensor and is positioned on the phonic wheel mounted on engine shaft front end.

It generates signals obtained from magnetic flux lines which close through phonic wheel teeth. Teeth number: 58.

The electronic control unit uses this signal to measure the speed of rotation of the engine, its angular position and to operate the electronic rev counter.

If this signal fails the rev counter will not work.

Camshaft timing sensor

It is a Hall effect type sensor positioned on camshaft pulley.

It generates signals obtained from lines of magnetic flux that close through a notch in the pulley.

The signal generated by this sensor is used by the electronic control unit as a redundant signal to measure the different engine speeds.

772655 Air temperature and pressure sensor

Positioned on the intake manifold, it measures the pressure of the turbocharging air introduced into the intake manifold.

This value, together with that of the air temperature sensor, makes it possible for the electronic control unit to calculate the exact quantity of air introduced into the cylinders so as to operate the injectors adjusting the fuel delivery, limiting harmful emissions, improving consumption and performance. The sensor contains an electronic temperature correction circuit to optimize the pressure measurement in relation to the temperature of the intake air.

772656 Fuel temperature sensor

Integrated in the fuel filter, it measures the fuel temperature and transmits it to the electronic control unit.

When the fuel temperature is too high (ambient temperature condition, engine at full load and tank in reserve), correct lubrication of the high-pressure pump is no longer assured. On the basis of the values received, the control unit determines the density and volume of the fuel, correcting the delivery limiting engine performance.

774511 Fuel pressure sensor

This is mounted in the middle of the hydraulic accumulator (rail) and it has the task of providing feedback for the injection control unit to:

- adjust injection pressure
- adjust the duration of injection.

766161 Atmospheric pressure sensor

This is integrated in the electronic control unit. It provides a criterion of correction for the measurement of the air flow rate and to calculate the reference air flow rate to check the EGR.

764254 Engine coolant temperature sensor

This provides the control unit with an index of the thermal status of the engine in order to determine corrections for the fuel delivery, injection pressure, EGR injection advance when starting cold (if mounted) and warm-up.

505910 Throttle pedal position sensor

The accelerator pedal position sensor provides the control unit with a voltage value in proportion to the angle of operation of the pedal determining fuel delivery.

772641 Clutch pedal position sensor

Mounted on the pedal board, it provides the control unit with a positive signal when the clutch is engaged (pedal released). Every time the clutch is disengaged to change gear, the control unit fails to receive this signal and deactivates the Cruise Control function.

772642 Brake pedal position sensor

There are two of these sensors mounted on the pedal board. With the brake pedal released, they provide the control unit with a positive signal that is used to detect brake operation so as to deactivate the Cruise Control function and stop delivery of fuel.

In addition, a sensor switches on the brake lights.

764261 Vehicle speed sensor

This sensor, mounted on the gearbox by the drive output shaft, transmits the vehicle speed signal, through the electronic tachograph, to the control unit.

ACTUATORS

The injection system comprises three classes of actuators interlocked with the electronic control unit:

- electro-injectors (see relevant heading);
- regulators (see relevant headings) requiring PWM control (Pulse Width Modulation):
 - for pressure
 - EGR (if mounted)
 - turbocharger with variable geometry (if mounted);
- actuators with continuous ON/OFF signal to:
 - engage electromagnetic coupling for radiator cooling fan;
 - turn on/off air-conditioner compressor (if mounted);
 - Cruise Control;
 - starter heater control;
 - fuel filter heating;
 - electric supply pump.

NOTE All the power controls are made with relays located in the cab.

PWM (Pulse Width Modulation) controls

A PWM control has an active and an inactive state that alternate within a constant set length of time. During the active state the actuator control circuit is closed, which is thus powered with the control voltage; whereas, during the inactive state the circuit is open.

The duration of the two states may be varied with the condition that the sum of the two times is equal to the length of the modulation delivery.

The duration of the active state determines the duty-cycle, which is normally expressed as a percentage of the total time. Therefore, if the duration of the two active and passive states are the same, the duty-cycle is equal to 50%.

For reasons of diagnostics, the duty-cycle is limited between 1% and 99%; the control resolution is equal to 0.005% (1/20000 of the time).

The time length has been chosen taking account of the dynamic actuator response specifications.

Too low a carrier frequency could cause oscillations in the actuator, while too high a frequency would decrease control resolution.

The E.G.R. and variable geometry turbocharger (if mounted) are controlled through a vacuum modulating valve.


GUIDE TO TROUBLESHOOTING

INTRODUCTION

During vehicle operation, the control unit can detect a series of electric faults. Each fault is associated to a failure code that will be stored in the ECU memory.

Failure codes can be read by connecting IVECO test tools to 38-pole diagnostic socket.

Figure 275



I. 38-pole diagnostic socket.

For the MS 6.3 ECU there is a code for each failure called blink Code, whereas for EDC 16 ECU a double failure code, called DTC and FMI will be stored.

The DTC code represents the failing component whereas the FMI code identifies the failure type.

Good diagnosis is made above all with the electronic diagnosis instruments developed by Iveco (Modus / IT2000 / IWT).

When the vehicle comes into the garage, the information provided by the driver is given due consideration, but the first thing to do is to hook up Modus / IT2000 / IWT and carefully run a full diagnosis:

- reading fault memory;
- reading parameters;
- engine test;
- etc.

Print the entire diagnosis outcomes, specially when Help Desk assistance is required.

The Help Desk will actually reject any demand of assistance if the workshop does not comply with the above procedure.

Here follows a GUIDE TO TROUBLESHOOTING drawn up by the engineers that have designed and implemented the Common Rail with MS 6.3 and EDC 16 ECUs.

Troubleshooting consists of two different sections:

- the first one, organised by Blink Codes for engine versions with MS 6.3 ECU and DTC-FMI for engine versions with EDC 16 ECU, concerns electric-electronic failures that can be directly detected by the control units.
- the second one for troubleshooting by symptoms describes possible trouble that cannot be identified by the electronic control unit. This kind of trouble is chiefly of a mechanical – hydraulic nature.

Ist Section
for engine versions with MS 6.3 ECU

Blink code (on vehicles up to chassis No. 5383302/D187233)

With the key turned off, press the diagnosis button.


- Two sets of flashes of the EDC warning light with a short pause in between indicate the code number of the first error stored in memory.
- Press the button again to pass on to the next error.
- After reaching the last error, the first one is repeated.
- The list of errors contains all the errors stored in memory and not only the active ones.
- The order of presentation of the errors respects the chronological order in which they appeared.

The table gives the error codes.

To delete the list of errors from the control unit memory, follow this procedure:

- with the key turned off, press the diagnosis button;
- keeping the button pressed, turn the key on;
- keep the button pressed for 5 seconds;
- let go of the button;
- turn the key off.

Figure 276



1. 38-pin diagnosis socket – 2. Blink code switch

The diagnosis socket (1) and the blink code switch are located in the glove compartment in front of the passenger's seat.

| Blink code | Indicator light | Fault description | Power reduction |
|-----------------|-----------------|--------------------------------------|-----------------|
| VEHICLE | | | |
| 1.1 | On | Vehicle speed | |
| 1.2 | | (not used) | |
| 1.3 | Off | Cruise Control buttons | |
| 1.4 | Blinking | Throttle pedal | * |
| 1.5 | Off | Clutch switch | |
| 1.6 | On | Brake switch | |
| 1.7 | Off | Throttle/brake plausibility | Idling |
| 1.8 | Off | Main EDC / diagnosis indicator light | |
| 1.9 | Off | Air-conditioner control contactor | |
| ENGINE 1 | | | |
| 2.1 | Blinking | Water temperature sensor | * |
| 2.2 | Off | Air temperature sensor | |
| 2.3 | On | Fuel temperature sensor | |
| 2.4 | Blinking | Turbocharging pressure sensor | * |
| 2.5 | Off | Atmospheric pressure sensor | |
| 2.7 | On | Fuel motor pump control contactor | |
| 2.8 | Off | Fuel filter heater control contactor | |
| 2.9 | On | Fan control contactor | |
| ENGINE 2 | | | |
| 3.1 | Off | Cylinder 1 balancing | |
| 3.2 | Off | Cylinder 2 balancing | |
| 3.3 | Off | Cylinder 3 balancing | |
| 3.4 | Off | Cylinder 4 balancing | |
| 3.5 | Off | Battery voltage | |
| 3.6 | Off | Glow plug indicator light | |
| 3.7 | Off | Glow plug control contactor | |
| 3.9 | Off | Pre-heating monitoring | |

| Blink code | Indicator light | Fault description | Power reduction |
|--------------------------|-----------------|---------------------------------------|----------------------------|
| ELECTRO-INJECTORS | | | |
| 5.1 | Blinking | Cylinder 1 injector solenoid valve | |
| 5.2 | Blinking | Cylinder 2 injector solenoid valve | |
| 5.3 | Blinking | Cylinder 3 injector solenoid valve | |
| 5.4 | Blinking | Cylinder 4 injector solenoid valve | |
| 5.7 | Blinking | Bank 1 (cylinders 1 – 4) | |
| 5.8 | Blinking | Bank 2 (cylinders 2 – 3) | |
| ENGINE SPEED | | | |
| 6.1 | Blinking | Crankshaft sensor | * |
| 6.2 | Blinking | Timing sensor | * |
| 6.4 | Off | Engine overspeed | |
| FUEL PRESSURE | | | |
| 8.1 | Blinking | Fuel pressure control | * or cutting out engine |
| 8.2 | Blinking | Fuel pressure sensor | * |
| 8.3 | Blinking | Pressure regulator solenoid valve | |
| 8.5 | On | EGR monitoring | |
| 8.6 | On | EGR solenoid valve | |
| 8.7 | On | Debimeter | |
| 8.8 | Off | Air temperature sensor (debimeter) | |
| CONTROL UNIT | | | |
| 9.1 | Blinking | Control unit error (Gate array) | * or cutting out engine |
| 9.2 | On | Control unit error (EEPROM) | |
| 9.3 | Blinking | EDC – Immobilizer communication | |
| 9.4 | On | Main contactor | |
| 9.5 | Off | After run test | |
| 9.6 | Blinking | Engine Stop Test (ECU) | |
| 9.7 | Blinking | Sensor power supply | * or cutting out engine |
| 9.8 | Blinking | Control unit error (Checksum) | Starting not possible |
| 9.9 | Blinking | Control unit error (Operating system) | Cutting out engine |

(*) Cases when there is a power reduction.

| BLINK CODE | EDC LAMP | POSSIBLE CAUSE | POSSIBLE TROUBLE | TESTS OR RECOMMENDED ACTION | NOTES |
|------------|----------|--|---|---|---|
| 1.1 | On | Vehicle speed sensor signal not plausible (circuit may be open or sensor defective). | <p>The speedometer does not work (if the fault is between the sensor and the speedometer).</p> <p>Cruise Control / PTO are not working.</p> | <p>Read measurable parameters with the diagnostic instrument: when there is this error, the vehicle speed read on the control unit will be fixed on 5 km/h.</p> <p>Read fault memory with the diagnosis instrument: if the error is intermittent, check the connectors for an uncertain contact.</p> <p>If the error is present, perform the following checks:</p> <ul style="list-style-type: none"> If the speedometer doesn't work, use a multimeter to check the sensor power supply (12V) between its pin 1 and earth. <p>If the power supply is correct, check the wiring between the sensor's pin 3 and the instrument panel's pin B1* (A22**), between the sensor's pin 2 and the instrument panel's pin B10* (A21**).</p> <ul style="list-style-type: none"> If the speedometer works but indicates an implausible speed, check the sensor is fitted properly, it is clean and its magnetic gap is correct. <p>If the defect persists, check the wiring between the instrument panel's pin B5* (A20**) and the EDC connector's pin B14, and between the instrument panel's pin B13* (A1**) and the EDC connector's pin B4.</p> | <p>Error detected only with vehicle travelling and only in the event of a short circuit.</p> <p>If signal is not present no error is detected because the control unit considers vehicle to be at a standstill.</p> <p>* old code ** new code</p> |

| BLINK CODE | EDC LAMP | POSSIBLE CAUSE | POSSIBLE TROUBLE | TESTS OR RECOMMENDED ACTION | NOTES |
|------------|----------|--|--|---|--|
| 1.3 | Off | Cruise Control / PTO control buttons not plausible. | Cruise Control / PTO and idling adjustment fail to work. | <p>Read status parameters with the diagnosis instrument to identify the defective control (does not switch ON-OFF).</p> <p>Check the wiring from OFF (pin 4 drive control system) to EDC connector pin B32, RESUME (pin 5 drive control system) to EDC connector pin B25, from SET + button (pin 6 drive control system) to EDC connector pin B33, from SET - button (pin 3 drive control system) to EDC connector pin B1.</p> <p>Check there is voltage (approximately 12V) between pins 1, 2 and earth of the Cruise Controls.</p> <p>If the voltage is right and the wiring sound, but the fault remains, change the right-hand lever of the drive control system.</p> | Not plausible if Set+ and Set- or Resume and Off are activated at the same time. |
| 1.4 | Blinking | Throttle pedal potentiometer shorted. | <p>Power loss.</p> <p>Engine runs at fast idle speed (1500 rpm) with throttle pedal in rest position.</p> <p>Pressing the pedal causes the engine rpm to increase progressively and uncontrollably up to a reduced top speed (3900 rpm).</p> | <p>Read measurable parameters with the diagnostic instrument to check potentiometer malfunctioning (the signal does not change from 0% to 100%).</p> <p>Check the integrity of the potentiometer (R total = approx. 1 kOhm between pins 4 and 6), check the linear change in resistance of the potentiometer between pins 5 - 6 and 5 - 4 between the minimum and the maximum. If the potentiometer is working correctly, check the wiring between the pedal connector pin 6 and the EDC connector pin B27, between the pedal connector pin 4 and the EDC connector pin B35, between the pedal connector pin 5 and the EDC connector pin B2.</p> | |
| 1.4 | Blinking | No signal from the throttle pedal potentiometer (circuit may be open). | Fast idling 1500 rpm in any pedal position. | Check the integrity of the potentiometer. If the potentiometer is sound, check the wiring between the potentiometer and the EDC control unit connector. | |

| BLINK CODE | EDC LAMP | POSSIBLE CAUSE | POSSIBLE TROUBLE | TESTS OR RECOMMENDED ACTION | NOTES |
|------------|----------|---|---|---|--|
| 1.4 | Blinking | Throttle pedal: implausible signal between idling switch and potentiometer. | Fast idling 1500 rpm in idling position and normal acceleration position when pressing the pedal. | <p>Read status parameters with the diagnosis instrument to check the idling switch works properly.</p> <p>If the outcome is negative, use a multimeter on the component to check the integrity of the idling switch (ON-OFF switching between pins 3 and 2 of the pedal connector).</p> <p>If the switch is sound, look for a break in the wiring between the switch pin 2 and EDC connector pin B29, between switch pin 3 and EDC connector pin B13.</p> | (The potentiometer signal is good and indicates the pedal has been released, but the switch status indicates the pedal is pressed.) |
| 1.4 | Blinking | Throttle pedal: implausible signal between idling switch and potentiometer. | Idling normal, but on pressing the pedal the engine speed settles on an intermediate fixed value. | <p>Using a multimeter on the component, check the integrity of the potentiometer.</p> <p>If the potentiometer is sound, look for a break or short-circuiting in the wiring between the potentiometer and the connector.</p> | (The potentiometer signal is good and indicates the pedal has been released, but the potentiometer signal indicates the pedal is pressed.) |

| BLINK CODE | EDC LAMP | POSSIBLE CAUSE | POSSIBLE TROUBLE | TESTS OR RECOMMENDED ACTION | NOTES |
|------------|----------|---|--|--|---|
| 1.5 | Off | Clutch switch: signal not plausible (at the EDC control unit it seems the speed of the vehicle has changed from 0 to at least 30 km/h without the clutch getting pressed) or not present. | Cruise Control / PTO fail to work. | <p>Read status parameters with the diagnosis instrument to check correct switchover on pressing the pedal.</p> <p>If the result is negative, use a multimeter on the component to check continuity and switchover on pressing the pedal between pins 1 and 2.</p> <p>If the switch is sound, check the continuity of the wiring between switch pin 2 and EDC connector B38.</p> <p>With the key ON, check there is voltage (approx. 12V) between EDC pin B31 and earth. Also check the fuse 24 and the wiring between the switch pin 1 and pin 13 of fuse 24.</p> | If everything turns out satisfactory with the check, the trouble could be with not pressing the clutch fully down (it is sometimes possible to change gear without operating the switch). |
| 1.6 | On | Brake switch – signals not plausible between primary and secondary. | <p>Brake lights might not work.</p> <p>The Cruise Control / PTO fails to work.</p> | <p>Read status parameters with the diagnosis instrument to check correct and simultaneous switchover of the primary and secondary brake switches.</p> <p>If the outcome is negative, use a multimeter to check the integrity and correct switchover of the switches (one between pins 3 and 2 and the other between pins 1 and 2).</p> <p>If the switches are sound, with the key ON and the pedal pressed (brake lights on), check for approx. 12V on EDC pin B26 (secondary switch) and on EDC pin B31 (primary switch). If there is no voltage, check the wiring and the relays between the switches and EDC connector.</p> | <p>Check the pedal switches are fitted correctly (they must activate at the same time).</p> <p>If the trouble occurs too frequently, change both switches.</p> |

| BLINK CODE | EDC LAMP | POSSIBLE CAUSE | POSSIBLE TROUBLE | TESTS OR RECOMMENDED ACTION | NOTES |
|------------|----------|--|--|---|--|
| 1.7 | Off | Throttle / brake pedal plausibility: simultaneous brake and throttle activation. | Engine speed drops down to idling. If the brake is applied with the throttle pressed, the engine drops down to idling until the brake is released so it is possible to stop the vehicle even if the throttle pedal jams in an intermediate position. Whereas, it is possible to accelerate with the brake pedal pressed without any safety mechanisms tripping. | Read parameters with the diagnosis instrument, check that the throttle pedal potentiometer signal resets on release, otherwise the driver might have pressed the brake and the throttle together. | This error is stored in memory only if the brake and throttle signals are integral. If the error is saved to memory when the pedals are not pressed, it is likely that one of the brake switches is stuck or shorted to +Batt. Make the user aware about using the pedals correctly. |
| 1.8 | Off | EDC lamp shorted or circuit open. | The EDC lamp fails to come on when turning the key ON or it stays on even with the key OFF. | Check continuity between the instrument panel pin B17 and EDC connector pin B23. Check that with the key ON there is approx. 12V between the instrument panel pin B16 and earth. Check the LED works between B16 and B17 on the instrument panel. Check continuity between the instrument panel pin B17 and EDC connector pin B23. | The operation of the indicator light is extremely important for the operation and integrity of the system. Make the user aware to check the indicator light works properly with each ignition (if there are no faults in memory, it has to come on for 2 sec. and then go out). |

| BLINK CODE | EDC LAMP | POSSIBLE CAUSE | POSSIBLE TROUBLE | TESTS OR RECOMMENDED ACTION | NOTES |
|------------|----------|--|---|---|--|
| 1.9 | Off | AC compressor control relay coil shorted to +Batt or to earth or circuit open. | The air-conditioning compressor is not disconnected when the EDC requires it. | <p>Active diagnosis with the diagnostic instrument.</p> <p>If the outcome is negative, check that, with the key ON and engine off, between the EDC pin A35 and earth there is no voltage (if there is also 9.7, call the Help Desk to have the control unit replaced, if necessary).</p> <p>If the compressor does cut out, disconnect the relay 25337. If on disconnecting the relay the compressor stops, replace the relay.</p> <p>If the compressor never works, try replacing the relay and check continuity between the EDC connector pin A8 and earth.</p> | <p>If the circuit is open at pin A8 level 2.7-2.8-2.9 are saved to memory as well.</p> <p>The control unit only sees the integrity of the coil between pins 8 – 35 and not any stuck contacts.</p> <p>During active diagnosis, besides the relay tripping the compressor clutch must disconnect-reconnect.</p> |
| 2.1 | Blinking | Water temperature sensor short-circuited or circuit open. | <p>Less power (and noise as pre-injection is not implemented) in all cases.</p> <p>Engine cooling fan always on (if there is no temperature signal or it is not valid, in order to protect the engine the control unit turns on the fan).</p> | <p>Read measurable parameters with the diagnosis instrument to check plausibility between EDC water temperature and that signalled by the vehicle's instrument.</p> <p>Read parameters: if there is this error, the water temperature read on the control unit will be the same as that of the fuel.</p> <p>In the event of contrasting indications, use a multimeter to check the integrity of the sensor between its pins 1 and 2 (R = approx. 2.5 kOhm at 20°C).</p> <p>If the sensor is integral, check the wiring between the sensor and EDC connector pin A1-A30.</p> | <p>In the event of trouble with the wiring pin A30, simultaneous signalling of trouble with the fuel temperature sensor and indication (reading measurable parameters) of a fixed temperature of 60°C.</p> <p>In the event of a high temperature, check the engine cooling fan comes on and if necessary the contacts of relay 25336 and fuse no. 5.</p> |

| BLINK CODE | EDC LAMP | POSSIBLE CAUSE | POSSIBLE TROUBLE | TESTS OR RECOMMENDED ACTION | NOTES |
|------------|----------|--|--|--|--|
| 2.2 | Off | Air temperature sensor on intake manifold short-circuited or circuit open. | The control unit calculates the fuel metering basing itself on a set temperature value. It is therefore possible to have slight decreases or increases in performance and smoke depending on the difference between the substitution temperature and the actual one. | <p>Read measurable parameters with the diagnosis instrument: if there is this error, the turbocharging air temperature will be fixed at 20°C.</p> <p>If the temperature is fixed at 20°C, check the integrity of the sensor (R = approx. 2.5 kOhm at 20°C) pin 1 and 2.</p> <p>If the sensor is sound, check the wiring between the sensor and EDC connector pin A2-A19.</p> | The temperature sensor is integrated with the pressure sensor. |
| 2.3 | On | Fuel temperature sensor short-circuited or circuit open. | The control unit calculates the fuel metering basing itself on the water temperature, but in this case there is no reaction the driver can detect. | <p>Read measurable parameters: if there is this error, the fuel temperature will be the same as that of the water.</p> <p>If the temperature indicated has the same value as that of the water, check the integrity of the sensor (R = approx. 2.5 kOhm at 20°C).</p> <p>If the sensor is sound, check the wiring between the sensor and EDC connector pin A15-A30.</p> | <p>In the event of trouble with the wiring pin A30, simultaneous signalling of trouble with the water temperature sensor and indication (reading parameters) of a fixed temperature of 50°C.</p> <p>If the signal exceeds 85°C, reduction to 60% power, if it exceeds 90°C, reduction in injection pressure, if it exceeds 110°C, the error is stored in memory (even if the signal is sound).</p> <p>If the flight recorder reading detects too much time at high temperatures, make the user aware of not driving with the fuel tank level always low.</p> |

| BLINK CODE | EDC LAMP | POSSIBLE CAUSE | POSSIBLE TROUBLE | TESTS OR RECOMMENDED ACTION | NOTES |
|------------|----------|--|---|---|---|
| 2.4 | Blinking | Air pressure sensor on intake manifold short-circuited or circuit open. Or waste-gate valve malfunctioning. | Decrease in power. Possible oscillation while driving with engine at full load. | Read measurable parameters with the diagnosis instrument: if there is this error, the value read on the control unit will be fixed on 2000 mbar. If the indicated value is fixed at 2000 mbar, check the wiring between the sensor and EDC connector A3 – A34. If the wiring is sound: Check that the waste-gate valve is not jammed shut or open. | The pressure sensor is integrated with the temperature sensor. If the waste-gate valve is jammed shut, there may be surging with the engine under load because: <ul style="list-style-type: none"> - power limitation trips when accelerating under load; - the turbocharging pressure drops; - the engine goes back to normal operation and the pressure increases; - limitation trips again; - etc. If the turbocharging pressure really is too high, there is a risk of turbine over-revving with its associated damage. |
| 2.5 | Off | Ambient pressure sensor short-circuited or circuit open. | Possibly some black smoke at altitude, especially with EGR (it is not excluded at altitude). | The sensor is integrated in the EDC control unit and cannot be replaced on its own. | Any painting on the engine/control unit may prevent the ambient pressure getting measured correctly. |
| 2.7 | On | Fuel motor pump relay coil short-circuited or circuit open. | Fuel motor pump always on even with key OFF. The battery discharges. Early deterioration of the motor pump. Or | Active diagnosis of the relay with the diagnosis instrument. Take out the relay 25837, located in the contactor control unit (left-hand side of driver). If the pump cuts out, replace the relay. If the pump does not cut out, check the wiring between 87 of the relay and battery positive. | You hear the noise of the pump turning continuously, even with the key off. |

| BLINK CODE | EDC LAMP | POSSIBLE CAUSE | POSSIBLE TROUBLE | TESTS OR RECOMMENDED ACTION | NOTES |
|------------|----------|---|--|--|---|
| | | | The engine starts with difficulty and fails to reach its top performance. | If the motor pump fails to work, check the continuity of the coil between pin A7 and A8 of the EDC connector. In addition, check the wiring between the EDC connector pin A7 and relay 86, EDC connector pin A8 and relay 85. | |
| 2.8 | Off | Fuel filter heater relay defective. | Heater always on even with fuel temperature > 5°C. The battery discharges. Heater fails to come on even with fuel temperature < 5°C. Filter may be clogged due to the fuel paraffining with harsh outdoor temperatures (< -15°C). | Active diagnosis of the relay with the diagnosis instrument. Check continuity of the coil between the EDC connector pin A32 and relay pin A8. In addition, check the wiring between the EDC connector pin A32 and relay 86, EDC connector pin A8 and relay 85. Check the continuity of the coil between the EDC connector pin A32 and relay A8. In addition, check the wiring between pins A32 of the control unit and relay 86, control unit A8 and relay 85. | 2.3 may get stored in memory since the fuel gets too warm. Starting may be difficult with very cold temperatures. Engine starting may produce too much smoke. |
| 2.9 | On | Fan relay coil short-circuited or circuit open. | Increase in fuel consumption. Engine cooling fan always on even with engine cold. Or | Active diagnosis of the relay with the diagnosis instrument. Check coil continuity between EDC connector pin A39 and relay A8. In addition, check the wiring between the EDC connector pin A39 and relay 86, EDC connector pin A8 and relay 85. | In active diagnosis, besides the relay activating, you hear the fan's electromagnetic clutch cutting in and out. |

| BLINK CODE | EDC LAMP | POSSIBLE CAUSE | POSSIBLE TROUBLE | TESTS OR RECOMMENDED ACTION | NOTES |
|------------|----------|----------------------------|---|--|---|
| | | | <p>Engine overheating and accordingly possible power limitation.</p> <p>Engine cooling fan fails to work.</p> | <p>Check coil continuity between EDC connector pin A39 and relay A8.</p> <p>In addition, check the wiring between the EDC connector pin A39 and relay 86, EDC connector pin A8 and relay 85.</p> | |
| 3.1 | Off | Injector no. 1 unbalanced. | <p>Injector inefficient.</p> <p>There may be irregular rotation and smoke.</p> | <p>Engine test, cylinder efficiency test.</p> <p>Check the wiring and connections between the injector and the EDC connector pin A12 and A40.</p> <p>If the wiring is good, perform the compression test with the diagnosis instrument.</p> <p>If the compression in cylinder no. 1 is OK, replace the injector.</p> | The control unit has to modify the signal to injector no. 1 (Cylinder Balancing) too far beyond the normal value. |
| 3.2 | Off | Injector no. 2 unbalanced. | <p>Injector inefficient.</p> <p>There may be irregular rotation and smoke.</p> | <p>Engine test, cylinder efficiency test.</p> <p>Check the wiring and connections between the injector and the EDC connector pin A10 and A43.</p> <p>If the wiring is good, perform the compression test with the diagnosis instrument.</p> <p>If the compression in cylinder no. 2 is OK, replace the injector.</p> | The control unit has to modify the signal to injector no. 2 (Cylinder Balancing) too far beyond the normal value. |
| 3.3 | Off | Injector no. 3 unbalanced. | <p>Injector inefficient.</p> <p>There may be irregular rotation and smoke.</p> | <p>Engine test, cylinder efficiency test.</p> <p>Check the wiring and connections between the injector and the EDC connector pin A23 and A42.</p> <p>If the wiring is good, perform the compression test with the diagnosis instrument.</p> <p>If the compression in cylinder no. 3 is OK, replace the injector.</p> | The control unit has to modify the signal to injector no. 3 (Cylinder Balancing) too far beyond the normal value. |

| BLINK CODE | EDC LAMP | POSSIBLE CAUSE | POSSIBLE TROUBLE | TESTS OR RECOMMENDED ACTION | NOTES |
|------------|----------|--|---|---|---|
| 3.4 | Off | Injector no. 4 unbalanced. | Injector inefficient. There may be irregular rotation and smoke. | Engine test, cylinder efficiency test. Check the wiring and connections between the injector and the EDC connector pin A24 and A41. If the wiring is good, perform the compression test with the diagnosis instrument. If the compression in cylinder no. 4 is OK, replace the injector. | The control unit has to modify the signal to injector no. 4 (Cylinder Balancing) too far beyond the normal value. |
| 3.5 | Off | Battery voltage too low (or recognized as such by the EDC control unit). | Fast idling up to 1250 rpm (depending on the voltage detected) with pedal released. | Check the efficiency of the batteries and recharging circuit, the efficiency of the earth points and that there are no deposits or oxidation on the connectors. | The engine cuts out or fails to start if the battery voltage < 6.5V. |
| 3.6 | Off | Pre-heating indicator lamp short-circuited or defective. | a) Pre-heating indicator light always on. b) Pre-heating indicator light always off. | Perform active diagnosis of the indicator light with the diagnosis instrument. Check the wiring between the EDC connector pin B21 and the vehicle's panel B6* (A30**). Check for power between pins B16* (A14**) of the vehicle's panel and earth. | Even at low ambient temperatures, the driver fails to wait for pre-heating as no information is provided by the indicator light. * old code ** new code |

| BLINK CODE | EDC LAMP | POSSIBLE CAUSE | POSSIBLE TROUBLE | TESTS OR RECOMMENDED ACTION | NOTES |
|------------|----------|--|---|---|-------|
| 3.7 | Off | Glow plug relay short-circuited or circuit open. | Shorted to +Batt or circuit open: the glow plugs do not work, starting may be difficult and smokiness on starting. Shorted to earth: the glow plugs are always powered (short life). | Check the wiring of the EDC connector pin B42 to find the shorting to +Batt or to earth or the break in the circuit. Check the integrity of the pre-heating control unit. Check the 60A fuse connected between the battery positive and the pre-heating control unit connector pin 30. Check the power supply is correct on pin 86 of the pre-heating control unit and on the EDC connector pin B42. Check the earth connection of the pre-heating control unit pin 31. | |
| 3.9 | Off | Glow plugs short-circuited or circuit open. | Starting difficult with very rigid outdoor temperatures. Smokiness on starting. | Check the integrity of the single glow plugs. Check the glow plug power supply between the pre-heating control unit connector pin G1 – G2 – G3 – G4 and earth. If all OK, change the pre-heating control unit. | |
| 5.1 | Blinking | Electro-injector cylinder no. 1 shorted to +Batt. or shorted to earth or circuit open. | Drop in power made by the EDC control unit. The engine runs on 2 cylinders. Possibly 3.1. The engine runs on 3 cylinders. | Check the wiring and connections between the injector and the EDC connector pin A12 – A40. If the wiring is good, change the injector. | |

| BLINK CODE | EDC LAMP | POSSIBLE CAUSE | POSSIBLE TROUBLE | TESTS OR RECOMMENDED ACTION | NOTES |
|------------|----------|---|--|--|-------|
| 5.2 | Blinking | Electro-injector cylinder no. 2 shorted to +Batt. or shorted to earth or circuit open. | Drop in power made by the EDC control unit. The engine runs on 2 cylinders. Possibly 3.2. The engine runs on 3 cylinders. | Check the wiring and connections between the injector and the EDC connector pin A10 – A43. If the wiring is good, change the injector. | |
| 5.3 | Blinking | Electro-injector cylinder no. 3 shorted to +Batt. or shorted to earth or circuit open. | Drop in power made by the EDC control unit. The engine runs on 2 cylinders. Possibly 3.3. The engine runs on 3 cylinders. | Check the wiring and connections between the injector and the EDC connector pin A23 – A42. If the wiring is good, change the injector. | |
| 5.4 | Blinking | Electro-injector cylinder no. 4 shorted to +Batt. or shorted to earth or circuit open. | Drop in power made by the EDC control unit. The engine runs on 2 cylinders. Possibly 3.4. The engine runs on 3 cylinders. | Check the wiring and connections between the injector and the EDC connector pin A24 – A41. If the wiring is good, change the injector. | |
| 5.7 | Blinking | Power stage to supply the electro-injectors of cylinders 1 and 4 (in control unit) defective. | Possibly 3.1 – 3.4. The engine runs on 2 cylinders | Delete the fault memory and try again. If the error remains <u>and only after excluding the injector 1 or 4 defect</u> , call the Help Desk and follow their instructions to replace the control unit if necessary. | |

| BLINK CODE | EDC LAMP | POSSIBLE CAUSE | POSSIBLE TROUBLE | TESTS OR RECOMMENDED ACTION | NOTES |
|------------|----------|---|---|--|---|
| 5.8 | Blinking | Power stage to supply the electro-injectors of cylinders 2 and 3 (in control unit) defective. | Possibly 3.2 – 3.3. The engine runs on 2 cylinders | Delete the fault memory and try again. If the error remains <u>and only after excluding the injector 2 or 3 defect</u> , call the Help Desk and follow their instructions to replace the control unit if necessary. | |
| 6.1 | Blinking | Crankshaft sensor: no signal or implausible signal. | The engine will not start cold, it could start warm with difficulty. With the engine running, power reduction and increased noise. | Check the integrity of the sensor (R = approx. 850 Ohm). If the sensor is sound, check the wiring between the sensor and EDC connector pin A29 – A37. Check the sensor is fastened properly. | If there is no crankshaft signal, the camshaft sensor speed signal is used instead. Power reduction (and noise reduction because the control unit cannot manage advance and duration of injection and bases itself on a recovery map. Pre-injection is not implemented). |
| 6.2 | Blinking | Camshaft sensor: no signal or implausible signal. | The engine will not start cold, it could start warm with difficulty. With the engine running, power reduction and increased noise. False injections during starting and smoke at the exhaust. | Check the integrity of the sensor (R = approx. 850 Ohm). If the sensor is sound, check the wiring between the sensor and EDC connector pin A4 – A31. Check the sensor is fastened properly. | If there is no camshaft signal, the flywheel sensor timing signal is used instead. |
| 6.4 | Off | The engine has over-revved (over 5500 rpm), probably driven, or crankshaft sensor signal not plausible (in this case, error 6.1 signalled). | If the over-revving occurred when driven, the driver can detect no reaction (other than the indicator light blinking). | Data saved to memory, check the duration and frequency of the over-revving. Delete the fault memory. | Make the driver aware about using the vehicle correctly. |

| BLINK CODE | EDC LAMP | POSSIBLE CAUSE | POSSIBLE TROUBLE | TESTS OR RECOMMENDED ACTION | NOTES |
|-------------------|-----------------|--|---|--|--|
| 8.1 | Blinking | Pressure in rail too great. The electric command fails to reach the pressure regulator. | The engine cuts out, loud noise before cutting out. | Check that the connector on the pressure regulator is connected. If it is connected, check the wiring between the regulator and the EDC connector pin A9 – A20. | After a few times, the pressure relief valve might remain open, in which case it has to be changed. |
| 8.1 | Blinking | Pressure in rail too great. Pressure regulator mechanically jammed open. | The engine cuts out, loud noise before cutting out. | Perform the high-pressure test with the diagnosis instrument. If the outcome is negative, replace the high-pressure pump – regulator assembly. | After a few times, the pressure relief valve might remain jammed open, in which case it has to be changed. |
| 8.1 | Blinking | Pressure in rail too low. Pressure regulator mechanically jammed shut. | The engine cuts out or fails to start. | Perform the high-pressure test with the diagnosis instrument. If the outcome is negative, replace the high-pressure pump – regulator assembly. | |
| 8.1 | Blinking | Pressure in rail too low. Shorting to +Batt. on the pressure regulator. | The engine cuts out or fails to start. | Check the wiring between the regulator and EDC connector pin A9 – A20. | |
| 8.1 | Blinking | Pressure in rail too low. High-pressure pump defective. | The engine cuts out or fails to start. | Perform the high-pressure test with the diagnosis instrument. If the outcome is negative, replace the high-pressure pump together with the regulator. | |
| 8.1 | Blinking | Injector mechanically jammed open. | The engine cuts out or fails to start. | Perform the cylinder efficiency test with the diagnosis instrument. If the outcome is negative, replace the defective injector. | |
| 8.1 | Blinking | Pressure in rail too low. Major fuel leak from the high-pressure circuit. | The engine cuts out or fails to start. | Check the high-pressure circuit and eliminate the leak (beware, there could be a leak inside the head between the high-pressure union and the injector). | |

| BLINK CODE | EDC LAMP | POSSIBLE CAUSE | POSSIBLE TROUBLE | TESTS OR RECOMMENDED ACTION | NOTES |
|------------|----------|---|---|---|--|
| 8.1 | Blinking | Pressure in rail too low. Fuel supply problem in the low-pressure circuit. | The engine cuts out or fails to start. | Check the motor pump works properly, check for any clogging in the filter and pre-filter, crushed or leaking pipes, and check the fuel supply gear pump works properly. | |
| 8.2 | Blinking | Rail pressure sensor short-circuited or circuit open. | The engine cuts out. | Check the sensor is powered correctly. If the power supply is correct (approx. 5V) change the sensor. If it is greater than approx. 5V, check the wiring between the sensor and the EDC connector pin A33-A6. | |
| 8.3 | Blinking | Pressure regulator short-circuited or circuit open. | If shorted to +Batt., the pressure in the rail drops too much, the engine cuts out and fails to restart. Or If shorted to earth or the circuit is open, the pressure in the rail rises above the maximum value and the engine cuts out. | Check the wiring between the pressure regulator and the EDC connector pin A9 – A20. Check the wiring between the pressure regulator and the EDC connector pin A9 – A20. | 8.1 – 8.2 may also be signalled. 8.1 may also be signalled. |

| BLINK CODE | EDC LAMP | POSSIBLE CAUSE | POSSIBLE TROUBLE | TESTS OR RECOMMENDED ACTION | NOTES |
|------------|----------|--|---|--|---|
| 8.5 | On | EGR monitoring: incorrect implementation of EGR percentage calculated by the control unit. | EGR is turned off. Emissions not conforming to legislation. Poor performance and smokiness at high engine speeds. | Check that the EGR pneumatic valve is not jammed shut or open (or intentionally tampered with). Check that the pipe between the solenoid valve and EGR pneumatic valve is not crushed, perforated or disconnected. Check the EGR solenoid valve works properly (active diagnosis with the diagnostic instrument). Using a multimeter, check the integrity of the solenoid valve. If the solenoid valve is sound, check the wiring between the solenoid valve and the EDC connector pin A25 – A8. | If there is a defect on the wiring of pin A8, the errors associated with all the devices connected to this pin will be saved to memory. |
| 8.6 | On | EGR solenoid valve short-circuited or circuit open. | EGR doesn't work or works constantly. Emissions not conforming to legislation. No reaction the driver can detect. | Check the EGR solenoid valve works properly (active diagnosis with the diagnostic instrument). Using a multimeter, check the integrity of the solenoid valve. If the solenoid valve is sound, check the wiring between the solenoid valve and the EDC connector pin A25 – A8. | If there is a defect on the wiring of the EDC connector pin A8, the errors associated with all the devices connected to this pin will be saved to memory. |
| 8.7 | On | Debimeter short-circuited or circuit open. | Power reduction and EGR function turned off. | Check the integrity of the debimeter and the wiring between the debimeter connector and the EDC connector pin A17 – A18 – A26 – A28. | |
| 8.8 | Off | EGR air temperature sensor short-circuited or circuit open. | No reaction the driver can perceive. | Read measurable parameters with the diagnosis instrument: in the event of this trouble, the ambient temperature read on the control unit will be fixed on 30°C. Check the wiring between the debimeter and EDC connector pin A5 – A18. | |

| BLINK CODE | EDC LAMP | POSSIBLE CAUSE | POSSIBLE TROUBLE | TESTS OR RECOMMENDED ACTION | NOTES |
|-------------------|-----------------|---|--|--|---|
| 9.1 | Blinking | Defect inside the control unit. | The engine cuts out or fails to start. In some cases, it might not cut out, but go onto the power reduction level. | Delete the fault memory. If the error remains, call the Help Desk and follow their instructions to replace the control unit if necessary. | This may occur when the power supply to the control unit is cut off without using the key. Perhaps no defect has been saved to memory, it depends on the state of defectiveness of the control unit. |
| 9.2 | On | EEPROM defect in control unit. | The data are not saved to memory when turning off the engine. The fault memory is lost, it is only possible to read the faults that are present but not the intermittent ones. Any idling speed set with the Cruise Control commands is not stored in memory. | Delete the fault memory. If the error remains, call the Help Desk and follow their instructions to replace the control unit if necessary. | |
| 9.3 | Blinking | Communication trouble with the immobilizer; short-circuiting or circuit open on the CAN line. | The engine cuts out or fails to start. | Perform Immobilizer diagnosis and check the integrity of the CAN line. | |
| 9.4 | On | a) Main relay broken. b) Main relay short-circuited. | a) The control unit is not powered (the engine fails to start or cuts out). b) The control unit is constantly powered and the indicator light stays on even with the key turned OFF (the battery discharges). | Replace the main relay. | |

| BLINK CODE | EDC LAMP | POSSIBLE CAUSE | POSSIBLE TROUBLE | TESTS OR RECOMMENDED ACTION | NOTES |
|-------------------|-----------------|--|---|--|---|
| 9.5 | Off | After Run broken off several times. | Fault memory and other working data are not corrected saved in EEPROM. EDC inhibits starting the engine after a certain number of unsuccessful After Runs. | Check the control unit power supply wiring for any intermittent false contacts. If the wiring is good, replace the main relay. | Investigate any incorrect use of the vehicle. |
| 9.6 | Blinking | Failure of the internal test procedure that takes place in the control unit every time the engine stops. | The engine fails to stop in the set time when the +15 key is turned onto OFF. | This could occur if the engine is turned off but it continues to be driven (vehicle moving with gear engaged). Check the wiring between the key +15 and the control unit connector pin B20. Delete the fault memory; if in normal conditions of turning off the engine the error signal persists, call the Help Desk to have the control unit replaced if necessary. | |
| 9.7 | Blinking | Internal defect of the control unit in the sensor power supply circuit. | Reduction in power (and noise because pre-injection is not implemented). Irregular engine operation due to sensors not being powered correctly. | Call the Help Desk and follow their instructions to replace the control unit if necessary. | Defects may be signalled for various sensors powered by the control unit. |

| BLINK CODE | EDC LAMP | POSSIBLE CAUSE | POSSIBLE TROUBLE | TESTS OR RECOMMENDED ACTION | NOTES |
|-------------------|-----------------|--|--|--|--|
| 9.8 | Blinking | Internal problem with the control unit software or an attempt to tamper with the data-set. | The engine fails to start or starts only occasionally. | Delete the fault memory; if the error remains, call the Help Desk and follow their instructions to reprogram or replace the control unit if necessary. | |
| 9.9 | Blinking | Internal problem with the control unit software (operating system). | Possible short breaks in injection because the control unit resets irregularly while the engine is running. Other defects may be signalled. | Delete the fault memory; if the error remains, call the Help Desk and follow their instructions to replace the control unit if necessary. | If this error is signalled together with other defects, resolve this problem first as it could be the cause of the others. |

Ist Section
DTC-FMI error codes
with EDC central unit
software version P 3 I 5 V 3 2

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--------------------------------|----------------------|--|---|---|------------------------|----------------------|-----------------------|---|
| 0D | 02 | EGR - AIR MASS SUPPLY TOO HIGH | BELOW LOWER LIMIT | EGR off. Emissions not compliant with law. Derated performance and smoke at high engine rpm. | EGR monitoring: incorrect EGR percentage actuation calculated by ECU. | Check, if the EGR pneumatic valve is not locked in Open or Closed-Position 2) Check, that the solenoid valve and the EGR pneumatic valve is not squashed or holed or detached 3) Check the EGR solenoid valve-functionality 4) Check the solenoid valve-integrity by means of a multimeter 5) Check the wiring harness between the solenoid valve and the EDC connector. | | | | |
| 11 | 01 | ENGINE BOOST PRESSURE SENSOR | EXCEEDED UPPER LIMIT | Positive power reduction and smoke in exhaust. | | Check wiring and connections. Possibly replace sensor. Check in "measurable parameter" environment that atmospheric pressure sensor and turbo charger air pressure sensor values are similar when engine is off. | | | | Possible smoke in exhaust during acceleration. Replace if required. |
| 11 | 02 | ENGINE BOOST PRESSURE SENSOR | BELOW LOWER LIMIT | Positive power reduction and smoke in exhaust. | | Check wiring and connections. Replace sensor if required. | | | | Possible smoke in exhaust during acceleration. Replace if required. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------------------------------|----------------------|--|--|---|------------------------|----------------------|-----------------------|---|
| 11 | 08 | ENGINE 1 - BOOST PRESSURE SENSOR | SIGNAL NOT PLAUSIBLE | Positive power reduction and smoke in exhaust. | Faulty sensor. | Check wiring and connections. Replace sensor if required. | | | | |
| 12 | 01 | ENGINE 2 - BATTERY VOLTAGE | EXCEEDED UPPER LIMIT | Problematic cranking. | Flat battery, interrupted wiring. | Check battery state with diagnostic tool (measurable parameters). Check wiring and connections. | | | | Replace alternator, regulator or battery. |
| 12 | 02 | ENGINE 2 - BATTERY VOLTAGE | BELOW LOWER LIMIT | Engine does not start. Possible power reduction. | Faulty battery, faulty alternator, faulty ECU. | Check with diagnostic tool. | | | | Replace battery, alternator or ECU if required. |
| 13 | 08 | VEHICLE - BRAKE PEDAL SIGNAL ERROR | SIGNAL NOT PLAUSIBLE | Brake signal plausibility, possibly no brake lights, Cruise Control / PTO not working. | The two switch states are different. | Check wiring and connections. Replace sensor if required. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|---------------------------------------|----------------------|--|------------------------------------|--|--|--|---|---------|
| 14 | 01 | ENGINE 1 - COOLANT TEMPERATURE SENSOR | EXCEEDED UPPER LIMIT | Problematic cold cranking. Possible power reduction. | Faulty sensor, interrupted wiring. | Check wiring and connections. Replace sensor if required. | 1- Measure type: Resistance (KOhm) Measure point 1: Sensor Pin: 1 Measure point 2: Sensor Pin: 2 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A58 Measure point 2: Sensor Pin: 1 3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A41 Measure point 2: Sensor Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Min. value: 0,11 KOhm; Max. value: 48,3 KOhm; Typical Value: 2,5 KOhm; 2- Typical Value: 0,1 Ohm; 3- Typical Value: 0,1 Ohm; | |
| 14 | 02 | ENGINE 1 - COOLANT TEMPERATURE SENSOR | BELOW LOWER LIMIT | Problematic cold cranking. Possible power reduction. | Faulty sensor, interrupted wiring. | Check wiring and connections. Replace sensor if required. | 1- Measure type: Resistance (KOhm) Measure point 1: Sensor Pin: 1 Measure point 2: Sensor Pin: 2 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A58 Measure point 2: Sensor Pin: 1 3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A41 Measure point 2: Sensor Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Min. value: 0,11 KOhm; Max. value: 48,3 KOhm; Typical Value: 2,5 KOhm; 2- Typical Value: 0,1 Ohm; 3- Typical Value: 0,1 Ohm; | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|--|------------------------------------|--|--|--|--|---------|
| 14 | 08 | ENGINE 1 - COOLANT TEMPERATURE SENSOR | SIGNAL NOT PLAUSIBLE | Problematic cold cranking. Possible power reduction. | Faulty sensor, interrupted wiring. | Check wiring and connections. Replace sensor if required. | 1- Measure type: Resistance (KOhm) Measure point 1: Sensor Pin: 1 Measure point 2: Sensor Pin: 2 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A58 Measure point 2: Sensor Pin: 1 3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A41 Measure point 2: Sensor Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Min. value: 0,11 KOhm; Max. value: 48,3 KOhm; Typical Value: 2,5 KOhm; 2- Typical Value: 0,1 Ohm; 3- Typical Value: 0,1 Ohm; | |
| 15 | 01 | ENGINE 1 - COOLANT TEMPERATURE SENSOR (TEST) | EXCEEDED UPPER LIMIT | | Faulty coolant temperature sensor. | Replace sensor. | 1- Measure type: Resistance (KOhm) Measure point 1: Sensor Pin: 1 Measure point 2: Sensor Pin: 2 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A58 Measure point 2: Sensor Pin: 1 3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A41 Measure point 2: Sensor Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Min. value: 0,11 KOhm; Max. value: 48,3 KOhm; Typical Value: 2,5 KOhm; 2- Typical Value: 0,1 Ohm; 3- Typical Value: 0,1 Ohm; | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|---|---|--|------------------------|----------------------|-----------------------|--|
| 1E | 08 | VEHICLE CLUTCH SIGNAL SUSPECT | SIGNAL NOT PLAUSIBLE | Clutch switch: signal either not plausible or not present. Cruise Control / PTO not working or engine revs up to maximum speed when clutch pedal is pressed and Cruise control / PTO is on. | Gear shift detected without pressing brake pedal. | Check wiring and connections. Replace sensor if required. | | | | The anomaly caused by incomplete clutch operation if everything is OK. |
| 20 | 01 | EGR - EGR POWER SHORT TO BATT. | EXCEEDED UPPER LIMIT | | EGR solenoid valve short-circuit to battery. | 1) Check integrity of solenoid valve with multimeter. 2) Check wiring between solenoid valve and EDC connector. | | | | EGR either not working or always working. Emissions not compliant with law. No reaction perceivable by driver. |
| 21 | 02 | EGR - SHORT CIRCUIT TO GROUND ON EGR VALVE | BELOW LOWER LIMIT | | Solenoid valve short-circuit to ground. | 1) Check integrity of solenoid valve with multimeter. 2) Check wiring between solenoid valve and EDC connector. | | | | EGR either not working or always working. Emissions not compliant with law. No reaction perceivable by driver. |
| 22 | 04 | EGR - OPEN CIRCUIT ON EGR VALVE | NO SIGNAL | | EGR solenoid valve short-circuit or open circuit. | 1) Check integrity of solenoid valve with multimeter. 2) Check wiring between solenoid valve and EDC connector. | | | | EGR either not working or always working. Emissions not compliant with law. No reaction perceivable by driver. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|----------------------------------|----------------------|--|---|--|------------------------|----------------------|-----------------------|--|
| 22 | 08 | EGR - OPEN CIRCUIT ON EGR VALVE | SIGNAL NOT PLAUSIBLE | | EGR solenoid valve short-circuit or open circuit. | 1) Check integrity of solenoid valve with multimeter. 2) Check wiring between solenoid valve and EDC connector. | | | | EGR either not working or always working. Emissions not compliant with law. No reaction perceivable by driver. |
| 24 | 01 | ENGINE SPEED - CAMSHAFT SENSOR | EXCEEDED UPPER LIMIT | Possible problematic cold cranking. | No signal, open circuit. | Check wiring and connections. | | | | Flywheel sensor timing signal adopted if camshaft signal is not correct. |
| 24 | 02 | ENGINE SPEED - CAMSHAFT SENSOR | BELOW LOWER LIMIT | Possible problematic cold cranking. | No signal, open circuit, faulty sensor. | Check correct assembly of sensor and phonic wheel, check engine timing. | | | | Flywheel sensor timing signal adopted if camshaft signal is not correct. |
| 25 | 01 | ENGINE SPEED - CRANKSHAFT SENSOR | EXCEEDED UPPER LIMIT | Problematic cold cranking, power reduction (possible noise due to missed pre-injection). | Faulty sensor. | Check wiring and connections. | | | | Camshaft sensor speed adopted if signal is not present. |
| 25 | 02 | ENGINE SPEED - CRANKSHAFT SENSOR | BELOW LOWER LIMIT | Problematic cold cranking, power reduction (possible noise due to missed pre-injection). | Faulty sensor. | Check wiring and connections. | | | | Camshaft sensor speed adopted if signal is not present. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|---|----------------------|---------------------------|---|--|--|---|---|-----------------------|
| 26 | 01 | ENGINE SPEED - FAULT BETWEEN FLYWHEEL SENSOR AND CAMSHAFT | EXCEEDED UPPER LIMIT | Possible power reduction. | Incorrect camshaft phonic wheel assembly. | Check wiring, connections and sensor, check that phonic wheel is fitted correctly. | | | | Longer cranking time. |
| 28 | 01 | ENGINE I - FUEL TEMPERATURE SENSOR | EXCEEDED UPPER LIMIT | Possible power reduction. | Short-circuit to positive, excessively low temperature is detected. | Check wiring and connections. Replace sensor if required. | <p>1- Measure type: Resistance (Ohm) Measure point 1: Sensor Pin: 1 Measure point 2: Sensor Pin: 2</p> <p>2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A52 Measure point 2: Sensor Pin: 1</p> <p>3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A51 Measure point 2: Sensor Pin: 2</p> | <p>1- Connector Not connected; Key +15 OFF;</p> <p>2- Connector Not connected; Key +15 OFF;</p> <p>3- Connector Not connected; Key +15 OFF;</p> | <p>1- Typical Value: 1 Ohm;</p> <p>2- Typical Value: 0,1 Ohm;</p> <p>3- Typical Value: 0,1 Ohm;</p> | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------------------------------|----------------------|---------------------------|--|--|---|--|--|--|
| 28 | 02 | ENGINE I - FUEL TEMPERATURE SENSOR | BELOW LOWER LIMIT | Possible power reduction. | Short-circuit to ground, excessively high temperature is detected. | Check wiring and connections. Replace sensor if required. | 1- Measure type: Resistance (Ohm) Measure point 1: Sensor Pin: 1 Measure point 2: Sensor Pin: 2 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A52 Measure point 2: Sensor Pin: 1 3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A51 Measure point 2: Sensor Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Typical Value: 1 Ohm; 2- Typical Value: 0,1 Ohm; 3- Typical Value: 0,1 Ohm; | |
| 29 | 01 | ENGINE I - FAN RELAY | EXCEEDED UPPER LIMIT | Fan relay not working. | Fan relay short-circuit to positive. | Check wiring and connections. Replace relay if required. | | | | Possible increased fuel consumption. Possible engine overheating and power reduction. |
| 29 | 02 | ENGINE I - FAN RELAY | BELOW LOWER LIMIT | Fan relay not working. | Fan relay short-circuit to ground. | Check wiring and connections. Replace relay if required. | | | | Possible increased fuel consumption. Possible engine overheating and power reduction. |
| 29 | 04 | ENGINE I - FAN RELAY | NO SIGNAL | Fan relay not working. | | Check wiring and connections. Replace relay if required. | | | | Possible increased fuel consumption. Possible engine overheating and power reduction. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|---|---|---|------------------------|----------------------|-----------------------|--|
| 29 | 08 | ENGINE 1 - FAN RELAY | SIGNAL NOT PLAUSIBLE | Fan relay not working. | | Check wiring and connections. Replace relay if required. | | | | Possible increased fuel consumption. Possible engine overheating and power reduction. |
| 2A | 01 | ENGINE 1 - PRE-HEATING RELAY FUEL FILTER | EXCEEDED UPPER LIMIT | Fuel filter pre-heater relay not working. | Filter heater relay short-circuit to positive - Heater always on also at fuel temperature > 5° C. | Check wiring and connections. Replace relay if required. | | | | Battery goes flat. |
| 2A | 02 | ENGINE 1 - PRE-HEATING RELAY FUEL FILTER | BELOW LOWER LIMIT | Fuel filter pre-heater relay not working. | Filter heater relay short-circuit to ground. | Check wiring and connections. Replace relay if required. | | | | Battery goes flat. |
| 2A | 04 | ENGINE 1 - PRE-HEATING RELAY FUEL FILTER | NO SIGNAL | Fuel filter pre-heater relay not working. | | Check wiring and connections. Replace relay if required. | | | | Battery goes flat. |
| 2A | 08 | ENGINE 1 - PRE-HEATING RELAY FUEL FILTER | SIGNAL NOT PLAUSIBLE | Fuel filter pre-heater relay not working. | | Check wiring and connections. Replace relay if required. | | | | Battery goes flat. |
| 2F | 01 | ENGINE 2 - GLOW PLUGS RELAY | EXCEEDED UPPER LIMIT | Possible problematic cold cranking. | Short-circuit to positive, glow plugs always on also with ECU off, possible battery deployment. | Check wiring and connections. Replace relay if required. | | | | |
| 2F | 02 | ENGINE 2 - GLOW PLUGS RELAY | BELOW LOWER LIMIT | | Short-circuit to ground, glow plugs always on. | Check wiring and connections. Replace relay if required. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------------------------|----------------------|--|-----------------------------------|---|------------------------|----------------------|-----------------------|--|
| 2F | 04 | ENGINE 2 - GLOW PLUGS RELAY | NO SIGNAL | Possible problematic cold cranking. | Faulty wiring. | Check wiring and connections. Replace relay if required. | | | | Faulty diagnostic light. |
| 2F | 08 | ENGINE 2 - GLOW PLUGS RELAY | SIGNAL NOT PLAUSIBLE | Possible problematic cold cranking. | Faulty relay, wiring interrupted. | Check wiring and connections. Replace relay if required. | | | | Possible increased fuel consumption. Possible engine overheating and power reduction. |
| 30 | 01 | ENGINE 2 - GLOW PLUG W/LIGHT | EXCEEDED UPPER LIMIT | Warning light always off. Problematic cold cranking. Pre-heater warning light always on. | Short-circuit to positive. | Check wiring and connections. Replace sensor if required. | | | | The driver does not wait preheating even when the room temperatures are low, because no warning light signal is enabled. Preheating works, but with cold start-up no indication is available that tells you when to start the motor because the light is always turned on. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------------------------------|----------------------------|--|-------------------------------|---|------------------------|----------------------|-----------------------|--|
| 30 | 02 | ENGINE 2 - GLOW PLUG W/LIGHT | BELOW LOWER LIMIT | Warning light always off. Problematic cold cranking. Pre-heater warning light always on. | Short-circuit to ground. | Check wiring and connections. Replace sensor if required. | | | | The driver does not wait preheating even when the room temperatures are low, because no warning light signal is enabled. Preheating works, but with cold start-up no indication is available that tells you when to start the motor because the light is always turned on. |
| 30 | 04 | ENGINE 2 - GLOW PLUG W/LIGHT | NO SIGNAL | Warning light always off. Problematic cold cranking. Pre-heater warning light always on. | | Check wiring and connections. Replace sensor if required. | | | | Warning light off during pre-heating. Replace bulb if required. |
| 30 | 08 | ENGINE 2 - GLOW PLUG W/LIGHT | SIGNAL NOT PLAUSIBLE | Warning light always off. Problematic cold cranking. Pre-heater warning light always on. | | Check wiring and connections. Replace sensor if required. | | | | Warning light off during pre-heating. Replace bulb if required. |
| 31 | 01 | ENGINE 2 - GLOW PLUGS | EXCEEDED UPPER LIMIT | Possible problematic cold cranking. | Short-circuit to positive. | Check wiring and connections. Check electrical system between relay and glow plugs. | | | | Relay unit always on also with ECU off, possible battery deployment. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|---|--------------------|---|------------------------|----------------------|-----------------------|---------|
| 32 | 01 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | EXCEEDED UPPER LIMIT | | Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 33 | 01 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | EXCEEDED UPPER LIMIT | The engine switching off-data are not memorized. The failures memory is lost, only the present failures and not the intermittent ones can be read, the idling speed, which can be eventually set by the Cruise Control commands, remains not memorized. | Faulty ECU EEPROM. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|-------------------|---|--------------------|---|------------------------|----------------------|-----------------------|---------|
| 33 | 02 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | BELOW LOWER LIMIT | The engine switching off-data are not memorized. The failures memory is lost, only the present failures and not the intermittent ones can be read, the idling speed, which can be eventually set by the Cruise Control commands, remains not memorized. | Faulty ECU EEPROM. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 33 | 04 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | NO SIGNAL | The engine switching off-data are not memorized. The failures memory is lost, only the present failures and not the intermittent ones can be read, the idling speed, which can be eventually set by the Cruise Control commands, remains not memorized. | Faulty ECU EEPROM. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|---|---|---|------------------------|----------------------|-----------------------|---------|
| 33 | 08 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | SIGNAL NOT PLAUSIBLE | The engine switching off-data are not memorized. The failures memory is lost, only the present failures and not the intermittent ones can be read, the idling speed, which can be eventually set by the Cruise Control commands, remains not memorized. | Faulty ECU EEPROM. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 34 | 08 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | SIGNAL NOT PLAUSIBLE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 35 | 08 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | SIGNAL NOT PLAUSIBLE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|--|---|---|---|---------------------------------------|--------------------------|--|
| 36 | 08 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | SIGNAL NOT PLAUSIBLE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 37 | 01 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | EXCEEDED UPPER LIMIT | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 38 | 02 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | BELOW LOWER LIMIT | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 39 | 01 | ENGINE 1 - AIR TEMPERATURE SENSOR | EXCEEDED UPPER LIMIT | Problematic cranking, smoke, problematic acceleration. | | Check wiring and connections. Replace sensor if required. | Measure type: Resistance (KOhm) Measure point 1: Sensor Pin: 1 Measure point 2: Sensor Pin: 2 | Connector Not connected; Key +15 OFF; | Typical Value: 2,5 KOhm; | Air temperature sensor and built-in pressure sensor. The sensor is fitted on flow meter in engines with EGR. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|---------------------------------------|----------------------|--|--|---|--|---------------------------------------|----------------------------|--|
| 39 | 02 | ENGINE 1 - AIR TEMPERATURE SENSOR | BELOW LOWER LIMIT | Problematic cranking, smoke, problematic acceleration. | Short-circuit to ground, excessively high temperature is detected. | Check wiring and connections. Replace sensor if required. | Measure type: Resistance (KOhm) Measure point 1: Sensor Pin: 1 Measure point 2: Sensor Pin: 2 | Connector Not connected; Key +15 OFF; | Typical Value: 2,5 KOhm; | Air temperature sensor and built-in pressure sensor. The sensor is fitted on flow meter in engines with EGR. |
| 3A | 02 | ELECTRONIC CONTROL UNIT - IMMOBILISER | BELOW LOWER LIMIT | The engine fails to start | Communication with Immobilizer ECU problems on CAN Line. | Check integrity of CAN Line, run Immobilizer ECU diagnostics and wait for indications provided. | Measure type: Resistance (Ohm) Measure point 1: Diagnostic socket. Pin: 21 Measure point 2: Diagnostic socket. Pin: 22 | Connector Connected; Key +15 OFF; | Typical Value: 60 Ohm Ohm; | |
| 3C | 01 | INJECTOR BENCH 1 | EXCEEDED UPPER LIMIT | Engine not working properly, possible power reduction. | Injector wiring short-circuit. | Check wiring and connections. Replace injector if required. | | | | Only two cylinders running. |
| 3C | 02 | INJECTOR BENCH 1 | BELOW LOWER LIMIT | Engine not working properly, possible power reduction. | Short-circuit to ground. | Check wiring and connections. | | | | Only two cylinders running. |
| 3C | 08 | INJECTOR BENCH 1 | SIGNAL NOT PLAUSIBLE | Engine not working properly, possible power reduction. | Injector electrical system failure. | Check wiring and connections. Replace injector if required. | | | | Only two cylinders running. |
| 3D | 04 | INJECTOR BENCH 1 | NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring disconnected. | Check wiring and connections. Replace injector if required. | | | | Only two cylinders running. |
| 3E | 01 | INJECTOR BENCH 2 | EXCEEDED UPPER LIMIT | Engine not working properly, possible power reduction. | Injector wiring short-circuit. | Check wiring and connections. Replace injector if required. | | | | Only two cylinders running. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--------------------------|--------------------------|--|-------------------------------------|--|------------------------|----------------------|-----------------------|-----------------------------|
| 3E | 02 | INJECTOR BENCH 2 | - BELOW LOWER LIMIT | Engine not working properly, possible power reduction. | Short-circuit to ground. | Check wiring and connections. | | | | Only two cylinders running. |
| 3E | 08 | INJECTOR BENCH 2 | - SIGNAL NOT PLAUSIBLE | Engine not working properly, possible power reduction. | Injector electrical system failure. | Check wiring and connections. Replace injector if required. | | | | Only two cylinders running. |
| 3F | 04 | INJECTOR BENCH 2 | - NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring disconnected. | Check wiring and connections. Replace injector if required. | | | | Only two cylinders running. |
| 40 | 01 | INJECTOR INJECTOR SUPPLY | - A EXCEEDED UPPER LIMIT | Engine off. | Internal ECU problem. | Clear failure memory. If the error persists, ensure that the failure does not concern the injectors and call the Help Desk for instructions on how to replace the ECU. | | | | |
| 40 | 02 | INJECTOR INJECTOR SUPPLY | - A BELOW LOWER LIMIT | Engine off. | Internal ECU problem. | Clear failure memory. If the error persists, ensure that the failure does not concern the injectors and call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--------------------------------|--------------------------------------|-----------------|--------------------------|--|------------------------|----------------------|-----------------------|---------|
| 40 | 04 | INJECTOR INJECTOR SUPPLY | - A NO SIGNAL | Engine off. | Internal ECU problem. | Clear failure memory. If the error persists, ensure that the failure does not concern the injectors and call the Help Desk for instructions on how to replace the ECU. | | | | |
| 40 | 08 | INJECTOR INJECTOR SUPPLY | - A SIGNAL NOT PLAUSIBLE | Engine off. | Internal ECU problem. | Clear failure memory. If the error persists, ensure that the failure does not concern the injectors and call the Help Desk for instructions on how to replace the ECU. | | | | |
| 41 | 01 | INJECTOR INJECTOR SUPPLY | - B EXCEEDED UPPER LIMIT | Engine off. | Internal ECU problem. | Clear failure memory. If the error persists, ensure that the failure does not concern the injectors and call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--------------------------|-----------------|----------------------|--|----------------------------|--|----------------------|-----------------------|-------------------------------|
| 41 | 02 | INJECTOR INJECTOR SUPPLY | - B | BELOW LOWER LIMIT | Engine off. | Internal ECU problem. | Clear failure memory. If the error persists, ensure that the failure does not concern the injectors and call the Help Desk for instructions on how to replace the ECU. | | | |
| 41 | 04 | INJECTOR INJECTOR SUPPLY | - B | NO SIGNAL | Engine off. | Internal ECU problem. | Clear failure memory. If the error persists, ensure that the failure does not concern the injectors and call the Help Desk for instructions on how to replace the ECU. | | | |
| 41 | 08 | INJECTOR INJECTOR SUPPLY | - B | SIGNAL NOT PLAUSIBLE | Engine off. | Internal ECU problem. | Clear failure memory. If the error persists, ensure that the failure does not concern the injectors and call the Help Desk for instructions on how to replace the ECU. | | | |
| 42 | 01 | INJECTOR INJECTOR I | - | EXCEEDED UPPER LIMIT | Engine not working properly, possible power reduction. | Short-circuit to positive. | Check wiring and connections. Replace injector if required. | | | Only three cylinders running. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------------------|------------------------|--|--------------------------------|---|---|--|--|-----------------------------|
| 42 | 01 | INJECTOR INJECTOR 1 | - EXCEEDED UPPER LIMIT | | | | 1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A47 Measure point 2: Injector Pin: 2 2- Measure type: Resistance (Ohm) Measure point 1: Injector Pin: 1 Measure point 2: Injector Pin: 2 3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A16 Measure point 2: Injector Pin: 1 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Typical Value: 0.1 Ohm; 2- Min. value: 0.5 Ohm; Max. value: 0.9 Ohm; Typical Value: 0.7 Ohm; 3- Typical Value: 0,1 Ohm; | |
| 42 | 04 | INJECTOR INJECTOR 1 | - NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring short-circuit. | Check wiring and connections. Replace injector if required. | | | | Only two cylinders running. |
| 42 | 04 | INJECTOR INJECTOR 1 | - NO SIGNAL | | | | 1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A47 Measure point 2: Injector Pin: 2 2- Measure type: Resistance (Ohm) Measure point 1: Injector Pin: 1 Measure point 2: Injector Pin: 2 3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A16 Measure point 2: Injector Pin: 1 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Typical Value: 0.1 Ohm; 2- Min. value: 0.5 Ohm; Max. value: 0.9 Ohm; Typical Value: 0.7 Ohm; 3- Typical Value: 0,1 Ohm; | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|---------------------|------------------------|--|--------------------------------|---|---|--|--|-------------------------------|
| 42 | 08 | INJECTOR INJECTOR 1 | - SIGNAL NOT PLAUSIBLE | Engine not working properly, possible power reduction. | Injector not working properly. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |
| 42 | 08 | INJECTOR INJECTOR 1 | - SIGNAL NOT PLAUSIBLE | | | | 1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A47 Measure point 2: Injector Pin: 2 2- Measure type: Resistance (Ohm) Measure point 1: Injector Pin: 1 Measure point 2: Injector Pin: 2 3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A16 Measure point 2: Injector Pin: 1 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Typical Value: 0.1 Ohm; 2- Min. value: 0.5 Ohm; Max. value: 0.9 Ohm; Typical Value: 0.7 Ohm; 3- Typical Value: 0,1 Ohm; | |
| 43 | 04 | INJECTOR INJECTOR 1 | - NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring open circuit. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |
| 44 | 01 | INJECTOR INJECTOR 2 | - EXCEEDED UPPER LIMIT | Engine not working properly, possible power reduction. | Short-circuit to positive. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------------------|------------------------------|--|-----------------------------------|--|--|--|--|-----------------------------------|
| 44 | 01 | INJECTOR INJECTOR 2 | - EXCEEDED UPPER LIMIT | | | | 1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A17 Measure point 2: Injector Pin: 1 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A13 Measure point 2: Injector Pin: 2 3- Measure type: Resistance (Ohm) Measure point 1: Injector Pin: 1 Measure point 2: Injector Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Typical Value: 0,1 Ohm; 2- Typical Value: 0,1 Ohm; 3- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm; | |
| 44 | 04 | INJECTOR INJECTOR 2 | - NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring short-circuit. | Check wiring and connections. Replace injector if required. | | | | Only two cylinders running. |
| 44 | 04 | INJECTOR INJECTOR 2 | - NO SIGNAL | | | | 1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A17 Measure point 2: Injector Pin: 1 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A13 Measure point 2: Injector Pin: 2 3- Measure type: Resistance (Ohm) Measure point 1: Injector Pin: 1 Measure point 2: Injector Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Typical Value: 0,1 Ohm; 2- Typical Value: 0,1 Ohm; 3- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm; | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|---------------------|------------------------|--|--------------------------------|---|---|--|---|-------------------------------|
| 44 | 08 | INJECTOR INJECTOR 2 | - SIGNAL NOT PLAUSIBLE | | | | 1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A17 Measure point 2: Injector Pin: 1 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A13 Measure point 2: Injector Pin: 2 3- Measure type: Resistance (Ohm) Measure point 1: Injector Pin: 1 Measure point 2: Injector Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Typical Value: 0,1 Ohm; 2- Typical Value: 0,1 Ohm; 3- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm; | |
| 44 | 08 | INJECTOR INJECTOR 2 | - SIGNAL NOT PLAUSIBLE | Engine not working properly, possible power reduction. | Injector not working properly. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |
| 45 | 04 | INJECTOR INJECTOR 2 | - NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring open circuit. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |
| 46 | 01 | INJECTOR INJECTOR 3 | - EXCEEDED UPPER LIMIT | Engine not working properly, possible power reduction. | Short-circuit to positive. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |
| 46 | 04 | INJECTOR INJECTOR 3 | - NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring short-circuit. | Check wiring and connections. Replace injector if required. | | | | Only two cylinders running. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|---------------------|------------------------|--|--------------------------------|---|--|--|--|-------------------------------|
| 46 | 08 | INJECTOR INJECTOR 3 | - SIGNAL NOT PLAUSIBLE | Engine not working properly, possible power reduction. | Injector not working properly. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |
| 47 | 04 | INJECTOR INJECTOR 3 | - NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring open circuit. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |
| 47 | 04 | INJECTOR INJECTOR 3 | - NO SIGNAL | | | | 1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A31 Measure point 2: Injector Pin: 2 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A1 Measure point 2: Injector Pin: 1 3- Measure type: Resistance (Ohm) Measure point 1: Injector Pin: 1 Measure point 2: Injector Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Typical Value: 0,1 Ohm; 2- Typical Value: 0,1 Ohm; 3- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm; | |
| 48 | 01 | INJECTOR INJECTOR 4 | - EXCEEDED UPPER LIMIT | Engine not working properly, possible power reduction. | Short-circuit to positive. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |
| 48 | 04 | INJECTOR INJECTOR 4 | - NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring short-circuit. | Check wiring and connections. Replace injector if required. | | | | Only two cylinders running. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------------------------------|------------------------|--|---|--|---|---|---|--|
| 48 | 08 | INJECTOR INJECTOR 4 | - SIGNAL NOT PLAUSIBLE | Engine not working properly, possible power reduction. | Injector not working properly. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |
| 49 | 04 | INJECTOR INJECTOR 4 | - NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring open circuit. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |
| 49 | 04 | INJECTOR INJECTOR 4 | - NO SIGNAL | | | | <p>1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A46 Measure point 2: Injector Pin: 2</p> <p>2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A1 Measure point 2: Injector Pin: 1</p> <p>3- Measure type: Resistance (Ohm) Measure point 1: Injector Pin: 1 Measure point 2: Injector Pin: 2</p> | <p>1- Connector Not connected; Key +15 OFF;</p> <p>2- Connector Not connected; Key +15 OFF;</p> <p>3- Connector Not connected; Key +15 OFF;</p> | <p>1- Typical Value: 0,1 Ohm;</p> <p>2- Typical Value: 0,1 Ohm;</p> <p>3- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm;</p> | |
| 4E | 08 | VEHICLE CRUISE CONTROL SWITCH UNIT | - SIGNAL NOT PLAUSIBLE | Cruise control / PTO not working. | Press SET+ / SET- and RESUME/ OFF at the same time. | Check correct operation of the switch by reading state parameters. | | | | Replace wiring and connections if state does not change when Cruise Control buttons are pressed. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|--|--|--|--|---------------------------------------|---|-------------|
| 50 | 01 | ELECTRONIC CONTROL UNIT - MAIN RELAY DEFECT | EXCEEDED UPPER LIMIT | Engine does not start, ECU not powered or ECU always powered and EDC off also at key-on. | Main relay interrupted or short-circuit. | Check wiring and connections. Replace relay if required. | | | | |
| 50 | 02 | ELECTRONIC CONTROL UNIT - MAIN RELAY DEFECT | BELOW LOWER LIMIT | Engine does not start, ECU not powered or ECU always powered and EDC off also at key-on. | Main relay interrupted or short-circuit. | Check wiring and connections. Replace relay if required. | | | | |
| 51 | 01 | VEHICLE - MULTIPOSITION SELECTOR / PTO | EXCEEDED UPPER LIMIT | Incorrect PTO operation. | Voltage exceeding max. threshold, short-circuit to positive. | Check wiring and connections. Replace sensor if required. | | | | |
| 51 | 02 | VEHICLE - MULTIPOSITION SELECTOR / PTO | BELOW LOWER LIMIT | Incorrect PTO operation. | Voltage under min. threshold, short-circuit to ground. | Check wiring and connections. Replace sensor if required. | | | | |
| 51 | 08 | VEHICLE - MULTIPOSITION SELECTOR / PTO | SIGNAL NOT PLAUSIBLE | Incorrect PTO operation. | Faulty device. | Check wiring and connections. Replace sensor if required. | | | | |
| 52 | 04 | FUEL PRESSURE - PRESSURE MPROP REGULATOR ERROR | NO SIGNAL | Engine off. | Faulty MPROP. | Check wiring and connections. | Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A49 Measure point 2: ECU Pin: A19 | Connector Not connected; Key +15 OFF; | Min. value: 3.2 Ohm; Max. value: 3.6 Ohm; Typical Value: 3.4 Ohm; | High noise. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|-----------------|---|---|--|---------------------------------------|---|---------|
| 52 | 08 | FUEL PRESSURE - PRESSURE MPROP REGULATOR ERROR | SIGNAL NOT PLAUSIBLE | | | Check wiring and connections. Replace ECU if required. | Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A49 Measure point 2: ECU Pin: A19 | Connector Not connected; Key +15 OFF; | Min. value: 3.2 Ohm; Max. value: 3.6 Ohm; Typical Value: 3.4 Ohm; | |
| 53 | 01 | FUEL PRESSURE - PRESSURE MPROP REGULATOR ERROR (SHORT CIRCUIT TO POSITIVE) | EXCEEDED UPPER LIMIT | | Short-circuit to battery, faulty MPROP. | Check wiring and connections. Replace MPROP if required. | | | | |
| 54 | 01 | FUEL PRESSURE - PRESSURE MPROP REGULATOR ERROR (SHORT CIRCUIT TO NEGATIVE) | EXCEEDED UPPER LIMIT | | Short-circuit to ground. Faulty MPROP. | Check wiring and connections. Replace MPROP if required. | | | | |
| 56 | 08 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | SIGNAL NOT PLAUSIBLE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 5A | 01 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | EXCEEDED UPPER LIMIT | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|---|---|---|------------------------|----------------------|-----------------------|---------|
| 5A | 02 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | BELOW LOWER LIMIT | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 5B | 01 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | EXCEEDED UPPER LIMIT | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 5E | 01 | ENGINE I - FUEL PUMP RELAY | EXCEEDED UPPER LIMIT | Fuel pump on always when engine is off. | Faulty relay, short-circuit to positive in wiring. | Turn key-on: pump must run for approximately 10 seconds (it should hum). Check pump relay if pump remains on. Check wiring if all checks are OK. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|------------------------|--|---|------------------------|----------------------|-----------------------|----------------------|
| 5E | 02 | ENGINE I - FUEL PUMP RELAY | BELOW LOWER LIMIT | Fuel pump not working. | Faulty relay, short-circuit to ground in wiring. | Turn key-on: pump must run for approximately 10 seconds (it should hum). Check the pump relay, protection fuse and wiring if this does not occur. | | | | |
| 5E | 04 | ENGINE I - FUEL PUMP RELAY | NO SIGNAL | Fuel pump not working. | Faulty relay, wiring interrupted. | Check wiring and connections. Replace relay if required. | | | | |
| 5E | 08 | ENGINE I - FUEL PUMP RELAY | SIGNAL NOT PLAUSIBLE | Fuel pump not working. | Faulty relay, wiring interrupted. | Check wiring and connections. Replace relay if required. | | | | |
| 5F | 01 | FUEL PRESSURE - RAIL PRESSURE SENSOR OR SIGNAL ERROR | EXCEEDED UPPER LIMIT | | Short-circuit to positive. Faulty sensor. Rail pressure not regular. | Check wiring and connections. Replace sensor if required. | | | | Check DTC 103 error. |
| 5F | 02 | FUEL PRESSURE - RAIL PRESSURE SENSOR OR SIGNAL ERROR | BELOW LOWER LIMIT | | Short-circuit to ground, faulty sensor. | Check wiring and connections. Replace sensor if required. | | | | |
| 60 | 01 | FUEL PRESSURE - RAIL PRESSURE SENSOR OFFSET | EXCEEDED UPPER LIMIT | | Faulty rail pressure sensor. | Replace sensor. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|-----------------|--|---|------------------------|----------------------|-----------------------|---|
| 60 | 02 | FUEL PRESSURE - RAIL PRESSURE SENSOR OFFSET | BELOW LOWER LIMIT | | Faulty rail pressure sensor. | Replace sensor. | | | | |
| 62 | 01 | FUEL PRESSURE - FAULT ON THE FUEL DRUCK CONTROL OF THE RAIL (POSITIVE DEVIATION) | EXCEEDED UPPER LIMIT | | High pressure circuit fuel leakage. | Check fuel feed system. | | | | Fuel management and pressure failure in rail. |
| 62 | 01 | FUEL PRESSURE - FAULT ON THE FUEL DRUCK CONTROL OF THE RAIL (POSITIVE DEVIATION) | EXCEEDED UPPER LIMIT | | Injector jammed in fuel passage open position. | Check hydraulic and mechanical efficiency of injectors. | | | | Fuel management and pressure failure in rail. |
| 62 | 01 | FUEL PRESSURE - FAULT ON THE FUEL DRUCK CONTROL OF THE RAIL (POSITIVE DEVIATION) | EXCEEDED UPPER LIMIT | | MPROP adjuster open movement jammed. | Check efficiency of MPROP adjuster. | | | | Fuel management and pressure failure in rail. |
| 62 | 01 | FUEL PRESSURE - FAULT ON THE FUEL DRUCK CONTROL OF THE RAIL (POSITIVE DEVIATION) | EXCEEDED UPPER LIMIT | | Faulty high pressure pump. | Check efficiency of high pressure pump. | | | | Fuel management and pressure failure in rail. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|--|--------------------------------------|--|------------------------|----------------------|-----------------------|---|
| 63 | 01 | FUEL PRESSURE - FAULT ON THE FUEL DRUCK CONTROL OF THE RAIL (NEGATIVE DEVIATION) | EXCEEDED UPPER LIMIT | | MPROP adjuster open movement jammed. | Check efficiency of MPROP adjuster. | | | | Fuel management and pressure failure in rail. |
| 64 | 01 | FUEL PRESSURE - RAIL PRESSURE ERROR: TOO LOW | EXCEEDED UPPER LIMIT | | High pressure circuit fuel leakage. | Check high pressure system. Replace high pressure pump if required. | | | | Fuel management and pressure failure in rail. |
| 65 | 01 | FUEL PRESSURE - RAIL PRESSURE ERROR: TOO HIGH | EXCEEDED UPPER LIMIT | | MPROP regulator jammed. | Check MPROP regulator, replace if required. | | | | |
| 66 | 01 | FUEL PRESSURE - ERROR ON THE RAIL PRESSURE (EXCESSIVE DUTY CYCLE) | EXCEEDED UPPER LIMIT | Negative vehicle reaction with smoke in exhaust during acceleration. | High pressure circuit fuel leakage. | Check fuel feed system, replace high pressure pump if required. Faulty fuel feed system (fuel pump and filter jammed). | | | | |
| 67 | 01 | FUEL PRESSURE - ERROR ON THE RAIL PRESSURE (EXCESSIVE) | EXCEEDED UPPER LIMIT | Engine off. | MPROP regulator jammed. | Check MPROP regulator, replace if required. | | | | Replace pressure relief valve. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|-----------------|---|---|------------------------|----------------------|-----------------------|---------|
| 68 | 02 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | BELOW LOWER LIMIT | | | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 68 | 04 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | NO SIGNAL | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 68 | 08 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | SIGNAL NOT PLAUSIBLE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|---|----------------------|---|------------------------------------|---|------------------------|----------------------|-----------------------|---|
| 69 | 01 | ELECTRONIC CONTROL UNIT - SENSOR POWER SUPPLY | EXCEEDED UPPER LIMIT | Anomalous engine operation due to incorrectly powered sensors. Reduced power. | Sensor power circuit fault in ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | Possible fault indications of various sensors powered by ECU. |
| 69 | 02 | ELECTRONIC CONTROL UNIT - SENSOR POWER SUPPLY | BELOW LOWER LIMIT | Anomalous engine operation due to incorrectly powered sensors. Reduced power. | Sensor power circuit fault in ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | Possible fault indications of various sensors powered by ECU. |
| 6A | 01 | ELECTRONIC CONTROL UNIT - SENSOR POWER SUPPLY | EXCEEDED UPPER LIMIT | Anomalous engine operation due to incorrectly powered sensors. Reduced power. | Sensor power circuit fault in ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | Possible fault indications of various sensors powered by ECU. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|---|----------------------|---|------------------------------------|---|------------------------|----------------------|-----------------------|--|
| 6A | 02 | ELECTRONIC CONTROL UNIT - SENSOR POWER SUPPLY | BELOW LOWER LIMIT | Anomalous engine operation due to incorrectly powered sensors. Reduced power. | Sensor power circuit fault in ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | Possible fault indications of various sensors powered by ECU. |
| 6B | 01 | ELECTRONIC CONTROL UNIT - SENSOR POWER SUPPLY | EXCEEDED UPPER LIMIT | Anomalous engine operation due to incorrectly powered sensors. Reduced power. | Sensor power circuit fault in ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | Possible fault indications of various sensors powered by ECU. |
| 6B | 02 | ELECTRONIC CONTROL UNIT - SENSOR POWER SUPPLY | BELOW LOWER LIMIT | Anomalous engine operation due to incorrectly powered sensors. Reduced power. | Sensor power circuit fault in ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | Possible fault indications of various sensors powered by ECU. |
| 6C | 01 | VEHICLE - EDC LAMP | EXCEEDED UPPER LIMIT | Warning light not working. | Short-circuit to positive. | Check correct operation of warning light using "Active diagnostic" procedure. | | | | Warning light should come on for approximately 5 seconds at key-on. Check wiring and connections if this does not occur. |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------|----------------------------|---|---|------------------------|----------------------|-----------------------|--|
| 6C | 02 | VEHICLE - EDC LAMP | BELOW LOWER LIMIT | Warning light not working. | Short-circuit to ground. | Check correct operation of warning light using "Active diagnostic" procedure. | | | | Warning light should come on for approximately 5 seconds at key-on. Check wiring and connections if this does not occur. |
| 6C | 04 | VEHICLE - EDC LAMP | NO SIGNAL | Warning light not working. | Open circuit, bulb disconnected. | Check correct operation of warning light using "Active diagnostic" procedure. | | | | Warning light should come on for approximately 5 seconds at key-on. Check wiring and connections if this does not occur. |
| 6C | 08 | VEHICLE - EDC LAMP | SIGNAL NOT PLAUSIBLE | Warning light not working. | Wiring problems. | Check wiring and connections. Replace sensor if required. | | | | Warning light should come on for approximately 5 seconds at key-on. Check wiring and connections if this does not occur. |
| 6D | 08 | ENGINE 2 - INTERNAL ECU FAULT (PLAUSIBILITY ERROR +15) | SIGNAL NOT PLAUSIBLE | | | Check wiring and connections. | | | | Key 15 off during initialisation. |
| 6E | 08 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | SIGNAL NOT PLAUSIBLE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|---------------------------|---|---|---|------------------------|----------------------|-----------------------|--|
| 75 | 01 | VEHICLE SPEED SENSOR / VEHICLE SPEED SIGNAL | - EXCEEDED UPPER LIMIT | Speed of 170 km/h exceeded. | | Check correct calibration of speedometer. | | | | Encourage driver to use the vehicle correctly. |
| 75 | 04 | VEHICLE SPEED SENSOR / VEHICLE SPEED SIGNAL | - NO SIGNAL | | Interrupted wiring between vehicle speed sensor and instrument panel. | Check wiring and connections between vehicle speed sensor and instrument panel. | | | | |
| 75 | 04 | VEHICLE SPEED SENSOR / VEHICLE SPEED SIGNAL | - NO SIGNAL | | Wiring interrupted between instrument panel and EDC ECU. | Check wiring and connections between instrument panel and EDC ECU. | | | | Intervention required if instrument panel indicates vehicle speed. |
| 75 | 04 | VEHICLE SPEED SENSOR / VEHICLE SPEED SIGNAL | - NO SIGNAL | | Vehicle speed sensor disconnected or failed. | Check correct assembly and efficiency of vehicle speed sensor. | | | | |
| 75 | 08 | VEHICLE SPEED SENSOR / VEHICLE SPEED SIGNAL | - SIGNAL NOT PLAUSIBLE | | Vehicle speed sensor disconnected or failed. | Check correct assembly and efficiency of vehicle speed sensor. | | | | |
| 75 | 08 | VEHICLE SPEED SENSOR / VEHICLE SPEED SIGNAL | - SIGNAL NOT PLAUSIBLE | Vehicle speed on instrument panel does not increase sensibly. | Wrong speedometer setting. | Check correct calibration of speedometer. | | | | |
| 77 | 01 | VEHICLE SPEED SENSOR / VEHICLE SPEED SIGNAL | - EXCEEDED UPPER LIMIT | Wrong vehicle speed indication. | Wrong speedometer setting. | Check correct calibration of speedometer. | | | | |
| 77 | 02 | VEHICLE SPEED SENSOR / VEHICLE SPEED SIGNAL | - BELOW LOWER LIMIT | Wrong vehicle speed indication. | Wrong speedometer setting. | Check correct calibration of speedometer. | | | | |

| DTC | FMI | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|--|----------------------------|---------------------------------------|--|---|------------------------|----------------------|-----------------------|---------|
| 77 | 08 | VEHICLE - VEHICLE SPEED SENSOR / SIGNAL | SIGNAL NOT PLAUSIBLE | Wrong vehicle speed indication. | Wrong speedometer setting. | Check correct calibration of speedometer. | | | | |
| 79 | 08 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT | SIGNAL NOT PLAUSIBLE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |

2nd Section

SYMPTOMS

The second section describes possible trouble that is **not identifiable by the control unit and is**

SPECIFIC TO THE COMMON RAIL SYSTEM AND THE NEW HW ENGINE

HYDRAULIC

ELECTRIC

MECHANICAL

other than conventional defects

(the aim is to guide the diagnostic approach to a new system, not to restate basic concepts that are considered to have already been acquired by the repairer).



The possible trouble already identified by the control unit, described in the 1st Section, is not repeated here (e.g., the engine cuts out as a result of defect 8.1).

If there are errors stored in the control unit memory, refer to the 1st troubleshooting section.

- The engine cuts out or fails to start.
- The engine fails to start (considerable exhaust smoke).
- The engine starts with difficulty.
- The engine fails to reach its top performance.

| SYMPTOM | SYSTEM REACTION | POSSIBLE CAUSE | TESTS OR RECOMMENDED ACTION | NOTES |
|--|--|--|--|--|
| The engine cuts out or fails to start. | The EDC indicator light fails to come on. The starter motor turns but the engine fails to start. | EDC control unit not powered: fuse blown. | Check fuse No. 23 (25A). If the fuse has blown, find and eliminate the cause of the overload before replacing it. | |
| The engine cuts out or fails to start. | The EDC indicator light fails to come on. The starter motor turns but the engine fails to start. | EDC control unit not powered: the main relay is not powered. | Check the wiring upstream from the main relay to find any break in the circuit. | |
| The engine cuts out or fails to start. | The EDC control unit is powered, the starter motor turns but the engine fails to start. The rail pressure does NOT reach 200 bar. | Air intake in the supply circuit between the tank and motor pump. | Check the integrity of the pipe and check that the quick couplings on the CILC (fuel level indicator assembly) and on the motor pump inlet are fitted properly. Replace any non-conforming parts. | |
| The engine cuts out or fails to start. | The EDC control unit is powered, the starter motor turns but the engine fails to start. The rail pressure does NOT reach 200 bar. | Pre-filter clogged. | Inspect and replace the pre-filter if any debris is found inside. | The pre-filter is transparent and any debris is easy to see. |
| The engine cuts out or fails to start. | The EDC control unit is powered, the starter motor turns but the engine fails to start. The rail pressure does NOT reach 200 bar. | Low-pressure pipe between motor pump and high-pressure pump inlet choked or with large leak. | Inspect the pipe and replace the relevant section. | |
| The engine cuts out or fails to start. | The EDC control unit is powered, the starter motor turns but the engine fails to start. The rail pressure does NOT reach 200 bar. | Fuel filter greatly clogged (within certain limits it only involves difficult starting). | Replace the filter. | If the filter clogging indicator system has not worked, check the relevant electric circuit and restore its operation. |

| SYMPTOM | SYSTEM REACTION | POSSIBLE CAUSE | TESTS OR RECOMMENDED ACTION | NOTES |
|--|--|--|--|---|
| The engine cuts out or fails to start. | The EDC control unit is powered, the starter motor turns but the engine fails to start. The rail pressure does NOT reach 200 bar. | Rail pressure relief valve jammed open or lost its setting (continually discharges towards the tank). | If fuel has come out of the valve exhaust pipe while driving with the starter motor, change the valve. | |
| The engine cuts out or fails to start. | The EDC control unit is powered, the starter motor turns but the engine fails to start. The rail pressure does NOT reach 200 bar. | Mechanical defect in the gear pump, pressure regulator and the pumping elements of the high-pressure pump. | After checking there is fuel in the tank and excluding every other possibility (see 1 st Troubleshooting Section), replace the high-pressure pump together with the pressure regulator. | |
| The engine cuts out or fails to start. | The starter motor turns but the engine fails to start. The rail pressure during starting regularly rises above 200 bar. | EGR pneumatic valve jammed open and air throttle valve jammed shut. | Check and replace the defective components. | |
| The engine starts with difficulty. | The EDC control unit is powered, the starter motor turns but the engine starts only after insisting a long time. Very slow increase in rail pressure. | The fuel motor pump is not powered (no buzzing is heard with the key ON for 9 sec.). | Check that no electric cable has disconnected from the motor pump. Check the wiring between the control relay and the motor pump to identify any break in the circuit. | After starting, with a load request the engine goes into recovery (if due to insufficient fuel reaching the high-pressure pump error 8.1 is detected, see 1 st Section). |
| The engine starts with difficulty. | The rail pressure during starting regularly rises above 200 bar. | Injector mechanically jammed shut. | Perform the Engine Test (cylinder efficiency) to identify the defective injector and replace it. | Depending on the extent of the jamming, the control unit might detect a lack of balance between the cylinders (See error 3.1 – 3.2 – 3.3 – 3.4, 1 st Section). |
| The engine starts with difficulty. | The rail pressure during starting regularly rises above 200 bar. | EGR pneumatic valve jammed open or air throttle valve mechanically jammed shut. | Check which component is defective and replace it. | |

| SYMPTOM | SYSTEM REACTION | POSSIBLE CAUSE | TESTS OR RECOMMENDED ACTION | NOTES |
|---|---|---|--|---|
| The engine starts with difficulty. | The rail pressure during starting does not reach 200 bar immediately. | Air intake in the supply circuit between the tank and motor pump. | Check the integrity of the pipe and check that the quick couplings on the CILC (fuel level indicator assembly) and on the motor pump inlet are fitted properly. Replace any non-conforming parts. | |
| The engine starts with difficulty. | The rail pressure during starting does not reach 200 bar immediately. | The motor pump is not powered (no buzzing is heard with the key ON for 9 sec.). | Check the wiring between the control relay and the motor pump. | |
| The engine starts with difficulty. | The rail pressure during cranking does not reach 200 bar immediately. | Low-pressure pipe choked or broken or leaking. | Inspect the pipe and replace the relevant section. | |
| The engine starts with difficulty. | The rail pressure during cranking does not reach 200 bar immediately. | Fuel filter very clogged. | Replace the filter. If the filter clogging indicator system has not worked, check the relevant circuit and restore its operation. | |
| The engine fails to reach top performance | (with no derating implemented by the control unit) | Throttle pedal potentiometer does not go to the end of its travel. | Read parameters, check the signal reaches 100%. If it does not, check the physical integrity of the potentiometer and replace it if necessary. | If there are errors saved in the control unit memory, refer to the 1 st Troubleshooting Section. |
| The engine fails to reach top performance | (with no derating implemented by the control unit) | EGR pneumatic valve jammed open or throttle valve jammed shut. | Check which is the defective component and replace it. | |
| The engine fails to reach top performance | (with no derating implemented by the control unit) | Injector jammed shut. | Find the defective injector (cylinder efficiency test with the diagnostic instrument) and replace it. | |

| SYMPTOM | SYSTEM REACTION | POSSIBLE CAUSE | TESTS OR RECOMMENDED ACTION | NOTES |
|---|--|---|---|--------------|
| The engine fails to reach top performance | (with no derating implemented by the control unit) | Fuel filter greatly clogged. | Change the filter. If the filter clogging indicator system has not worked, check the relevant circuit and restore its operation. | |
| The engine fails to reach top performance | (with no derating implemented by the control unit) | The motor pump is not powered (no buzzing is heard with the key ON for 9 sec.). | Check the wiring between the control relay and the motor pump. | |

Ist Section
EDT-FMI error codes
with EDC 16 central unit
version software P315 V4b

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--|------------------------|---|---|---|------------------------|----------------------|-----------------------|---------|
| 01 | 01 | 19 | VEHICLE - AIR-CONDITIONER COMPRESSOR RELAY (DTC 1) | EXCEEDING NORMAL RANGE | A/C compressor always on. | Short-circuit to positive. | Check wiring and connections. Replace relay if required. | | | | |
| 01 | 02 | 19 | VEHICLE - AIR-CONDITIONER COMPRESSOR RELAY (DTC 1) | EXCEEDING NORMAL RANGE | Check correct operation of warning light using "Active diagnostic" procedure. | Short-circuit to ground. | Check wiring and connections. Replace relay if required. | | | | |
| 01 | 04 | 19 | VEHICLE - AIR-CONDITIONER COMPRESSOR RELAY (DTC 1) | NO SIGNAL | A/C compressor not working. | Open circuit, relay disconnected. | Check wiring and connections. Replace relay if required. | | | | |
| 01 | 08 | 19 | VEHICLE - AIR-CONDITIONER COMPRESSOR RELAY (DTC 1) | SIGNAL NOT PLAUSIBLE | A/C compressor not working. | Open circuit, relay disconnected. | Check wiring and connections. Replace relay if required. | | | | |
| 02 | 04 | 19 | VEHICLE - AIR-CONDITIONER COMPRESSOR RELAY (DTC 2) | NO SIGNAL | A/C compressor not working. | No CAN line signal. | Check wiring and connections. Replace relay if required. | | | | |
| 02 | 08 | 19 | VEHICLE - AIR-CONDITIONER COMPRESSOR RELAY (DTC 2) | SIGNAL NOT PLAUSIBLE | A/C compressor not working. | Non plausible CAN line signal. | Check wiring and connections. Replace relay if required. | | | | |
| 03 | 01 | 97 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT (DTC 3) | EXCEEDING NORMAL RANGE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--|------------------------|--|---|---|------------------------|----------------------|-----------------------|---|
| 03 | 02 | 97 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT (DTC 3) | EXCEEDING NORMAL RANGE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 03 | 04 | 97 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT (DTC 3) | NO SIGNAL | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 03 | 08 | 97 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT (DTC 3) | SIGNAL NOT PLAUSIBLE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 05 | 01 | 87 | EGR - INCORRECT DEBIT-METER SIGNAL | EXCEEDING NORMAL RANGE | Possible poor performance in acceleration. | Flow meter short-circuit or open circuit. | Check integrity of flow meter and wiring between flow meter connector and EDC connector. | | | | Power reduction and deactivated EGR function. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|---------------------------------------|------------------------|---|---|---|------------------------|----------------------|-----------------------|--|
| 05 | 02 | 87 | EGR - INCORRECT DEBIT-METER SIGNAL | EXCEEDING NORMAL RANGE | Possible poor performance in acceleration. | Flow meter short-circuit or open circuit. | Check integrity of flow meter and wiring between flow meter connector and EDC connector. | | | | Power reduction and deactivated EGR function. |
| 07 | 01 | 87 | EGR - DEBIT-METER SIGNAL OUT OF LIMIT | EXCEEDING NORMAL RANGE | Possible poor performance in acceleration. | Flow meter short-circuit or open circuit. | Check integrity of flow meter and wiring between flow meter connector and EDC connector. | | | | Power reduction and deactivated EGR function. |
| 07 | 02 | 87 | EGR - DEBIT-METER SIGNAL OUT OF LIMIT | EXCEEDING NORMAL RANGE | Possible poor performance in acceleration. | Flow meter short-circuit or open circuit. | Check integrity of flow meter and wiring between flow meter connector and EDC connector. | | | | Power reduction and deactivated EGR function. |
| 08 | 01 | 14 | VEHICLE - ACCELERATOR PEDAL I | EXCEEDING NORMAL RANGE | Incorrect accelerator pedal operation, engine idling at 1500 rpm. | Short-circuit to positive, voltage exceeding 4700 mV. | In "Measurable parameters" environment, check that the "accelerator pedal position" parameter changes proportionally to the position of the pedal from 0% to 100%. Check wiring and connections. Replace accelerator pedal if required. | | | | Make sure that accelerator pedal travel is not hindered. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|-------------------------------|------------------------|---|---|---|------------------------|----------------------|-----------------------|--|
| 08 | 02 | 14 | VEHICLE - ACCELERATOR PEDAL I | EXCEEDING NORMAL RANGE | Incorrect accelerator pedal operation, engine idling at 1500 rpm. | Short-circuit to ground. | In "Measurable parameters" environment, check that the "accelerator pedal position" parameter changes proportionally to the position of the pedal from 0% to 100%. Check wiring and connections. Replace accelerator pedal if required. | | | | Make sure that accelerator pedal travel is not hindered. |
| 08 | 08 | 14 | VEHICLE - ACCELERATOR PEDAL I | SIGNAL NOT PLAUSIBLE | Incorrect accelerator pedal operation, engine idling at 1500 rpm. | Accelerator pedal potentiometer 1 and accelerator pedal potentiometer 2 values not plausible. | In "Measurable parameters" environment, check that the "accelerator pedal position" parameter changes proportionally to the position of the pedal from 0% to 100%. Check wiring and connections. Replace accelerator pedal if required. | | | | Make sure that accelerator pedal travel is not hindered. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|-------------------------------|------------------------|---|---|---|------------------------|----------------------|-----------------------|--|
| 09 | 01 | 14 | VEHICLE - ACCELERATOR PEDAL 2 | EXCEEDING NORMAL RANGE | Incorrect accelerator pedal operation, engine idling at 1500 rpm. | Short-circuit to positive, voltage exceeding 4700 mV. | In "Measurable parameters" environment, check that the "accelerator pedal position" parameter changes proportionally to the position of the pedal from 0% to 100%. Check wiring and connections. Replace accelerator pedal if required. | | | | Make sure that accelerator pedal travel is not hindered. |
| 09 | 02 | 14 | VEHICLE - ACCELERATOR PEDAL 2 | EXCEEDING NORMAL RANGE | Incorrect accelerator pedal operation, engine idling at 1500 rpm. | Short-circuit to ground. | In "Measurable parameters" environment, check that the "accelerator pedal position" parameter changes proportionally to the position of the pedal from 0% to 100%. Check wiring and connections. Replace accelerator pedal if required. | | | | Make sure that accelerator pedal travel is not hindered. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--|------------------------|---|---|---|------------------------|----------------------|-----------------------|--|
| 09 | 08 | 14 | VEHICLE - ACCELERATOR PEDAL 2 | SIGNAL NOT PLAUSIBLE | Incorrect accelerator pedal operation, engine idling at 1500 rpm. | Accelerator pedal potentiometer 1 and accelerator pedal potentiometer 2 values not plausible. | In "Measurable parameters" environment, check that the "accelerator pedal position" parameter changes proportionally to the position of the pedal from 0% to 100%. Check wiring and connections. Replace accelerator pedal if required. | | | | Make sure that accelerator pedal travel is not hindered. |
| 0A | 01 | 25 | ENGINE I - ATMOSPHERIC PRESSURE SENSOR | EXCEEDING NORMAL RANGE | Possible smokiness at high altitude. Problematic cranking at high altitude. | Faulty environmental pressure sensor in ECU. | Replace ECU. | | | | |
| 0A | 02 | 25 | ENGINE I - ATMOSPHERIC PRESSURE SENSOR | EXCEEDING NORMAL RANGE | Possible smokiness at high altitude. Problematic cranking at high altitude. | Faulty environmental pressure sensor in ECU. | Replace ECU. | | | | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|---|----------------------|---|---|---|------------------------|----------------------|-----------------------|--|
| 0B | 08 | 17 | VEHICLE - ACCELERATOR PEDAL/BRAKE PEDAL SUSPECT | SIGNAL NOT PLAUSIBLE | Power reduction: engine rpm drop to idling speed. | Press brake and accelerator at the same time. | Check wiring and connections. Replace sensor if required. | | | | If the brake is actuated while the accelerator is pressed, the motor runs on slow idling until the brake is released, so that the vehicle can be stopped even if the pedal of the accelerator remains stuck on the intermediate position. Instead you can accelerate while the pedal is pressed without the interference of safety measures. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|-------------------------------|------------------------|--|---|--|------------------------|----------------------|-----------------------|---------|
| 0C | 01 | 44 | EGR - AIR MASS SUPPLY TOO LOW | EXCEEDING NORMAL RANGE | EGR off. Emissions not compliant with law. Derated performance and smoke at high engine rpm. | EGR monitoring: incorrect EGR percentage actuation calculated by ECU. | <p>Check, if the EGR pneumatic valve is not locked in Open or Closed-Position 2) Check, that the solenoid valve and the EGR pneumatic valve is not squashed or holed or detached 3)</p> <p>Check the EGR solenoid valve-functionality 4) Check the solenoid valve-integrity by means of a multimeter 5) Check the wiring harness between the solenoid valve and the EDC connector.</p> | | | | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--------------------------------|------------------------|--|---|---|------------------------|----------------------|-----------------------|---------|
| 0D | 02 | 44 | EGR - AIR MASS SUPPLY TOO HIGH | EXCEEDING NORMAL RANGE | EGR off. Emissions not compliant with law. Derated performance and smoke at high engine rpm. | EGR monitoring: incorrect EGR percentage actuation calculated by ECU. | Check, if the EGR pneumatic valve is not locked in Open or Closed-Position 2) Check, that the solenoid valve and the EGR pneumatic valve is not squashed or holed or detached 3) Check the EGR solenoid valve-functionality 4) Check the solenoid valve-integrity by means of a multimeter 5) Check the wiring harness between the solenoid valve and the EDC connector. | | | | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|----------------------------------|------------------------|--|--|--|------------------------|----------------------|-----------------------|---|
| 11 | 01 | 24 | ENGINE 1 - BOOST PRESSURE SENSOR | EXCEEDING NORMAL RANGE | Positive power reduction and smoke in exhaust. | | Check wiring and connections. Possibly replace sensor. Check in "measurable parameter" environment that atmospheric pressure sensor and turbo charger air pressure sensor values are similar when engine is off. | | | | Possible smoke in exhaust during acceleration. Replace if required. |
| 11 | 02 | 24 | ENGINE 1 - BOOST PRESSURE SENSOR | EXCEEDING NORMAL RANGE | Positive power reduction and smoke in exhaust. | | Check wiring and connections. Replace sensor if required. | | | | Possible smoke in exhaust during acceleration. Replace if required. |
| 11 | 08 | 24 | ENGINE 1 - BOOST PRESSURE SENSOR | SIGNAL NOT PLAUSIBLE | Positive power reduction and smoke in exhaust. | Faulty sensor. | Check wiring and connections. Replace sensor if required. | | | | |
| 12 | 01 | 35 | ENGINE 2 - BATTERY VOLTAGE | EXCEEDING NORMAL RANGE | Problematic cranking. | Flat battery, interrupted wiring. | Check battery state with diagnostic tool (measurable parameters). Check wiring and connections. | | | | Replace alternator, regulator or battery. |
| 12 | 02 | 35 | ENGINE 2 - BATTERY VOLTAGE | EXCEEDING NORMAL RANGE | Engine does not start. | Faulty battery, faulty alternator, faulty ECU. | Check with diagnostic tool. | | | | Replace battery, alternator or ECU if required. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|---------------------------------------|------------------------|--|--------------------------------------|---|---|---|--|---------|
| 13 | 08 | 16 | VEHICLE BRAKE PEDAL SIGNAL ERROR - | SIGNAL NOT PLAUSIBLE | Brake signal plausibility, possibly no brake lights, Cruise Control / PTO not working. | The two switch states are different. | Check wiring and connections. Replace sensor if required. | | | | |
| 14 | 01 | 21 | ENGINE COOLANT TEMPERATURE SENSOR I - | EXCEEDING NORMAL RANGE | Problematic cold cranking. Possible power reduction. | Faulty sensor, interrupted wiring. | Check wiring and connections. Replace sensor if required. | <p>1- Measure type: Resistance (KOhm) Measure point 1: Sensor Pin: 1 Measure point 2: Sensor Pin: 2</p> <p>2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A58 Measure point 2: Sensor Pin: 1</p> <p>3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A41 Measure point 2: Sensor Pin: 2</p> | <p>1- Connector Not connected; Key +15 OFF;</p> <p>2- Connector Not connected; Key +15 OFF;</p> <p>3- Connector Not connected; Key +15 OFF;</p> | <p>1- Min. value: 0,11 KOhm; Max. value: 48,3 KOhm; Typical Value: 2,5 KOhm;</p> <p>2- Typical Value: 0,1 Ohm;</p> <p>3- Typical Value: 0,1 Ohm;</p> | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|---------------------------------------|--------------------------|--|------------------------------------|---|---|---|--|---------|
| 14 | 02 | 21 | ENGINE 1 - COOLANT TEMPERATURE SENSOR | EXCEED-ING NOR-MAL RANGE | Problematic cold cranking. Possible power reduction. | Faulty sensor, interrupted wiring. | Check wiring and connections. Replace sensor if required. | <p>1- Measure type: Resistance (KOhm) Measure point 1: Sensor Pin: 1 Measure point 2: Sensor Pin: 2</p> <p>2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A58 Measure point 2: Sensor Pin: 1</p> <p>3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A41 Measure point 2: Sensor Pin: 2</p> | <p>1- Connector Not connected; Key +15 OFF;</p> <p>2- Connector Not connected; Key +15 OFF;</p> <p>3- Connector Not connected; Key +15 OFF;</p> | <p>1- Min. value: 0,11 KOhm; Max. value: 48,3 KOhm; Typical Value: 2,5 KOhm;</p> <p>2- Typical Value: 0,1 Ohm;</p> <p>3- Typical Value: 0,1 Ohm;</p> | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|---------------------------------------|----------------------|--|------------------------------------|---|---|---|--|---------|
| 14 | 08 | 21 | ENGINE 1 - COOLANT TEMPERATURE SENSOR | SIGNAL NOT PLAUSIBLE | Problematic cold cranking. Possible power reduction. | Faulty sensor, interrupted wiring. | Check wiring and connections. Replace sensor if required. | <p>1- Measure type: Resistance (KOhm) Measure point 1: Sensor Pin: 1 Measure point 2: Sensor Pin: 2</p> <p>2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A58 Measure point 2: Sensor Pin: 1</p> <p>3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A41 Measure point 2: Sensor Pin: 2</p> | <p>1- Connector Not connected; Key +15 OFF;</p> <p>2- Connector Not connected; Key +15 OFF;</p> <p>3- Connector Not connected; Key +15 OFF;</p> | <p>1- Min. value: 0,11 KOhm; Max. value: 48,3 KOhm; Typical Value: 2,5 KOhm;</p> <p>2- Typical Value: 0,1 Ohm;</p> <p>3- Typical Value: 0,1 Ohm;</p> | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--|------------------------|---|---|---|--|--|---|--|
| 15 | 01 | 21 | ENGINE COOLANT TEMPERATURE SENSOR (TEST) | EXCEEDING NORMAL RANGE | | Faulty coolant temperature sensor. | Replace sensor. | 1- Measure type: Resistance (KOhm) Measure point 1: Sensor Pin: 1 Measure point 2: Sensor Pin: 2 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A58 Measure point 2: Sensor Pin: 1 3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A41 Measure point 2: Sensor Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Min. value: 0,11 KOhm; Max. value: 48,3 KOhm; Typical Value: 2,5 KOhm; 2- Typical Value: 0,1 Ohm; 3- Typical Value: 0,1 Ohm; | |
| IE | 08 | 15 | VEHICLE CLUTCH SIGNAL SUSPECT | SIGNAL NOT PLAUSIBLE | Clutch switch: signal either not plausible or not present. Cruise Control / PTO not working or engine revs up to maximum speed when clutch pedal is pressed and Cruise control / PTO is on. | Gear shift detected without pressing brake pedal. | Check wiring and connections. Replace sensor if required. | | | | The anomaly caused by incomplete clutch operation if everything is OK. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--|------------------------|-------------------------------------|---|---|------------------------|----------------------|-----------------------|--|
| 20 | 01 | 86 | EGR - EGR POWER SHORT TO BATT. | EXCEEDING NORMAL RANGE | | EGR solenoid valve short-circuit to battery. | 1) Check integrity of solenoid valve with multimeter. 2) Check wiring between solenoid valve and EDC connector. | | | | EGR either not working or always working. Emissions not compliant with law. No reaction perceivable by driver. |
| 21 | 02 | 86 | EGR - SHORT CIRCUIT TO GROUND ON EGR VALVE | EXCEEDING NORMAL RANGE | | Solenoid valve short-circuit to ground. | 1) Check integrity of solenoid valve with multimeter. 2) Check wiring between solenoid valve and EDC connector. | | | | EGR either not working or always working. Emissions not compliant with law. No reaction perceivable by driver. |
| 22 | 04 | 86 | EGR - OPEN CIRCUIT ON EGR VALVE | NO SIGNAL | | EGR solenoid valve short-circuit or open circuit. | 1) Check integrity of solenoid valve with multimeter. 2) Check wiring between solenoid valve and EDC connector. | | | | EGR either not working or always working. Emissions not compliant with law. No reaction perceivable by driver. |
| 22 | 08 | 86 | EGR - OPEN CIRCUIT ON EGR VALVE | SIGNAL NOT PLAUSIBLE | | EGR solenoid valve short-circuit or open circuit. | 1) Check integrity of solenoid valve with multimeter. 2) Check wiring between solenoid valve and EDC connector. | | | | EGR either not working or always working. Emissions not compliant with law. No reaction perceivable by driver. |
| 24 | 01 | 62 | ENGINE SPEED - CAMSHAFT SENSOR | EXCEEDING NORMAL RANGE | Possible problematic cold cranking. | No signal, open circuit. | Check wiring and connections. | | | | Flywheel sensor timing signal adopted if camshaft signal is not correct. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|---|------------------------|--|---|--|------------------------|----------------------|-----------------------|--|
| 24 | 02 | 62 | ENGINE SPEED - CAMSHAFT SENSOR | EXCEEDING NORMAL RANGE | Possible problematic cold cranking. | No signal, open circuit, faulty sensor. | Check correct assembly of sensor and phonic wheel, check engine timing. | | | | Flywheel sensor timing signal adopted if camshaft signal is not correct. |
| 25 | 01 | 61 | ENGINE SPEED - CRANKSHAFT SENSOR | EXCEEDING NORMAL RANGE | Problematic cold cranking, power reduction (possible noise due to missed pre-injection). | Faulty sensor. | Check wiring and connections. | | | | Camshaft sensor speed adopted if signal is not present. |
| 25 | 02 | 61 | ENGINE SPEED - CRANKSHAFT SENSOR | EXCEEDING NORMAL RANGE | Problematic cold cranking, power reduction (possible noise due to missed pre-injection). | Faulty sensor. | Check wiring and connections. | | | | Camshaft sensor speed adopted if signal is not present. |
| 26 | 01 | 63 | ENGINE SPEED - FAULT BETWEEN FLYWHEEL SENSOR AND CAMSHAFT | EXCEEDING NORMAL RANGE | Possible power reduction. | Incorrect camshaft phonic wheel assembly. | Check wiring, connections and sensor, check that phonic wheel is fitted correctly. | | | | Longer cranking time. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|------------------------------------|------------------------|---------------------------|---|---|--|---|---|---------|
| 28 | 01 | 23 | ENGINE I - FUEL TEMPERATURE SENSOR | EXCEEDING NORMAL RANGE | Possible power reduction. | Short-circuit to positive, excessively low temperature is detected. | Check wiring and connections. Replace sensor if required. | <p>1- Measure type: Resistance (Ohm) Measure point 1: Sensor Pin: 1 Measure point 2: Sensor Pin: 2</p> <p>2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A52 Measure point 2: Sensor Pin: 1</p> <p>3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A51 Measure point 2: Sensor Pin: 2</p> | <p>1- Connector Not connected; Key +15 OFF;</p> <p>2- Connector Not connected; Key +15 OFF;</p> <p>3- Connector Not connected; Key +15 OFF;</p> | <p>1- Typical Value: 1 Ohm;</p> <p>2- Typical Value: 0,1 Ohm;</p> <p>3- Typical Value: 0,1 Ohm;</p> | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|------------------------------------|------------------------|---------------------------|--|---|---|--|--|---|
| 28 | 02 | 23 | ENGINE I - FUEL TEMPERATURE SENSOR | EXCEEDING NORMAL RANGE | Possible power reduction. | Short-circuit to ground, excessively high temperature is detected. | Check wiring and connections. Replace sensor if required. | 1- Measure type: Resistance (Ohm) Measure point 1: Sensor Pin: 1 Measure point 2: Sensor Pin: 2 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A52 Measure point 2: Sensor Pin: 1 3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A51 Measure point 2: Sensor Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Typical Value: 1 Ohm; 2- Typical Value: 0,1 Ohm; 3- Typical Value: 0,1 Ohm; | |
| 29 | 01 | 29 | ENGINE I - FAN RELAY | EXCEEDING NORMAL RANGE | Fan relay not working. | Fan relay short-circuit to positive. | Check wiring and connections. Replace relay if required. | | | | Possible increased fuel consumption. Possible engine overheating and power reduction. |
| 29 | 02 | 29 | ENGINE I - FAN RELAY | EXCEEDING NORMAL RANGE | Fan relay not working. | Fan relay short-circuit to ground. | Check wiring and connections. Replace relay if required. | | | | Possible increased fuel consumption. Possible engine overheating and power reduction. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--|------------------------|---|---|--|------------------------|----------------------|-----------------------|---|
| 29 | 04 | 29 | ENGINE I - FAN RELAY | NO SIGNAL | Fan relay not working. | | Check wiring and connections. Replace relay if required. | | | | Possible increased fuel consumption. Possible engine overheating and power reduction. |
| 29 | 08 | 29 | ENGINE I - FAN RELAY | SIGNAL NOT PLAUSIBLE | Fan relay not working. | | Check wiring and connections. Replace relay if required. | | | | Possible increased fuel consumption. Possible engine overheating and power reduction. |
| 2A | 01 | 28 | ENGINE I - PRE-HEATING RELAY FUEL FILTER | EXCEEDING NORMAL RANGE | Fuel filter pre-heater relay not working. | Filter heater relay short-circuit to positive - Heater always on also at fuel temperature > 5° C. | Check wiring and connections. Replace relay if required. | | | | Battery goes flat. |
| 2A | 02 | 28 | ENGINE I - PRE-HEATING RELAY FUEL FILTER | EXCEEDING NORMAL RANGE | Fuel filter pre-heater relay not working. | Filter heater relay short-circuit to ground. | Check wiring and connections. Replace relay if required. | | | | Battery goes flat. |
| 2A | 04 | 28 | ENGINE I - PRE-HEATING RELAY FUEL FILTER | NO SIGNAL | Fuel filter pre-heater relay not working. | | Check wiring and connections. Replace relay if required. | | | | Battery goes flat. |
| 2A | 08 | 28 | ENGINE I - PRE-HEATING RELAY FUEL FILTER | SIGNAL NOT PLAUSIBLE | Fuel filter pre-heater relay not working. | | Check wiring and connections. Replace relay if required. | | | | Battery goes flat. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|-----------------------------|--------------------------|--------------------------------------|---|---|------------------------|----------------------|-----------------------|---|
| 2F | 01 | 37 | ENGINE 2 - GLOW PLUGS RELAY | EXCEED-ING NOR-MAL RANGE | Possible prob-lematic cold cranking. | Short-circuit to positive, glow plugs always on also with ECU off, possible bat-tery deploy-ment. | Check wiring and connec-tions. Replace relay if required. | | | | |
| 2F | 02 | 37 | ENGINE 2 - GLOW PLUGS RELAY | EXCEED-ING NOR-MAL RANGE | | Short-circuit to ground, glow plugs always on. | Check wiring and connec-tions. Replace relay if required. | | | | |
| 2F | 04 | 37 | ENGINE 2 - GLOW PLUGS RELAY | NO SIG-NAL | Possible prob-lematic cold cranking. | Faulty wiring. | Check wiring and connec-tions. Replace relay if required. | | | | Faulty diagnostic light. |
| 2F | 08 | 37 | ENGINE 2 - GLOW PLUGS RELAY | SIGNAL NOT PLAUS-IBLE | Possible prob-lematic cold cranking. | Faulty relay, wir-ing interrupted. | Check wiring and connec-tions. Replace relay if required. | | | | Possible in-creased fuel consumption. Possible engine overheating and power reduc-tion. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|------------------------------|-------------------------|--|----------------------------|---|------------------------|----------------------|-----------------------|---|
| 30 | 01 | 36 | ENGINE 2 - GLOW PLUG W/LIGHT | EXCEED-ING NORMAL RANGE | Warning light always off. Problematic cold cranking. Pre-heater warning light always on. | Short-circuit to positive. | Check wiring and connections. Replace sensor if required. | | | | The driver does not wait pre-heating even when the room temperatures are low, because no warning light signal is enabled. Preheating works, but with cold start-up no indication is available that tells you when to start the motor because the light is always turned on. |
| 30 | 02 | 36 | ENGINE 2 - GLOW PLUG W/LIGHT | EXCEED-ING NORMAL RANGE | Warning light always off. Problematic cold cranking. Pre-heater warning light always on. | Short-circuit to ground. | Check wiring and connections. Replace sensor if required. | | | | The driver does not wait pre-heating even when the room temperatures are low, because no warning light signal is enabled. Preheating works, but with cold start-up no indication is available that tells you when to start the motor because the light is always turned on. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|---|------------------------|--|----------------------------|---|------------------------|----------------------|-----------------------|--|
| 30 | 04 | 36 | ENGINE 2 - GLOW PLUG W/LIGHT | NO SIGNAL | Warning light always off. Problematic cold cranking. Pre-heater warning light always on. | | Check wiring and connections. Replace sensor if required. | | | | Warning light off during pre-heating. Replace bulb if required. |
| 30 | 08 | 36 | ENGINE 2 - GLOW PLUG W/LIGHT | SIGNAL NOT PLAUSIBLE | Warning light always off. Problematic cold cranking. Pre-heater warning light always on. | | Check wiring and connections. Replace sensor if required. | | | | Warning light off during pre-heating. Replace bulb if required. |
| 31 | 01 | 39 | ENGINE 2 - GLOW PLUGS | EXCEEDING NORMAL RANGE | Possible problematic cold cranking. | Short-circuit to positive. | Check wiring and connections. Check electrical system between relay and glow plugs. | | | | Relay unit always on also with ECU off, possible battery deployment. |
| 32 | 01 | 91 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT (DTC 50) | EXCEEDING NORMAL RANGE | | Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|---|------------------------|---|--------------------|---|------------------------|----------------------|-----------------------|---------|
| 33 | 01 | 92 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT (DTC 51) | EXCEEDING NORMAL RANGE | The engine switching off-data are not memorized. The failures memory is lost, only the present failures and not the intermittent ones can be read, the idling speed, which can be eventually set by the Cruise Control commands, remains not memorized. | Faulty ECU EEPROM. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 33 | 02 | 92 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT (DTC 51) | EXCEEDING NORMAL RANGE | The engine switching off-data are not memorized. The failures memory is lost, only the present failures and not the intermittent ones can be read, the idling speed, which can be eventually set by the Cruise Control commands, remains not memorized. | Faulty ECU EEPROM. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|---|----------------------|---|--------------------|---|------------------------|----------------------|-----------------------|---------|
| 33 | 04 | 92 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT (DTC 51) | NO SIGNAL | The engine switching off-data are not memorized. The failures memory is lost, only the present failures and not the intermittent ones can be read, the idling speed, which can be eventually set by the Cruise Control commands, remains not memorized. | Faulty ECU EEPROM. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 33 | 08 | 92 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT (DTC 51) | SIGNAL NOT PLAUSIBLE | The engine switching off-data are not memorized. The failures memory is lost, only the present failures and not the intermittent ones can be read, the idling speed, which can be eventually set by the Cruise Control commands, remains not memorized. | Faulty ECU EEPROM. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|---|----------------------|---|---|---|------------------------|----------------------|-----------------------|---------|
| 34 | 08 | 91 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT (DTC 52) | SIGNAL NOT PLAUSIBLE | There have been cases in which this fault is stored by the E.C.U. following after failures in engine speed measurement. Failure is usually associated to sudden ignition missing at >3000 rpm engine speed, with engine disconnection following. Reading failure memory, fault code DTC52 is displayed, sometimes followed by DTC56 (relating to fault on Immobilizer). | The fault is attributable to the gear wheel, which probably presents incorrect tooth shape. | Check there are no mechanical faults on the teeth of the gear wheel fitted to the engine drive shaft. | | | | |
| 35 | 08 | 91 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT (DTC 53) | SIGNAL NOT PLAUSIBLE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|---|------------------------|-----------------|---|---|------------------------|----------------------|-----------------------|---------|
| 36 | 08 | 91 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT (DTC 54) | SIGNAL NOT PLAUSIBLE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 37 | 01 | 91 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT (DTC 55) | EXCEEDING NORMAL RANGE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 38 | 02 | 91 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT (DTC 56) | EXCEEDING NORMAL RANGE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|---------------------------------------|------------------------|--|--|---|--|---------------------------------------|----------------------------|--|
| 39 | 01 | 22 | ENGINE I - AIR TEMPERATURE SENSOR | EXCEEDING NORMAL RANGE | Problematic cranking, smoke, problematic acceleration. | | Check wiring and connections. Replace sensor if required. | Measure type: Resistance (KOhm) Measure point 1: Sensor Pin: 1 Measure point 2: Sensor Pin: 2 | Connector Not connected; Key +15 OFF; | Typical Value: 2,5 KOhm; | Air temperature sensor and built-in pressure sensor. The sensor is fitted on flow meter in engines with EGR. |
| 39 | 02 | 22 | ENGINE I - AIR TEMPERATURE SENSOR | EXCEEDING NORMAL RANGE | Problematic cranking, smoke, problematic acceleration. | Short-circuit to ground, excessively high temperature is detected. | Check wiring and connections. Replace sensor if required. | Measure type: Resistance (KOhm) Measure point 1: Sensor Pin: 1 Measure point 2: Sensor Pin: 2 | Connector Not connected; Key +15 OFF; | Typical Value: 2,5 KOhm; | Air temperature sensor and built-in pressure sensor. The sensor is fitted on flow meter in engines with EGR. |
| 3A | 02 | 93 | ELECTRONIC CONTROL UNIT - IMMOBILISER | EXCEEDING NORMAL RANGE | The engine fails to start | Communication with Immobilizer ECU problems on CAN Line. | Check integrity of CAN Line, run Immobilizer ECU diagnostics and wait for indications provided. | Measure type: Resistance (Ohm) Measure point 1: Diagnostic socket. Pin: 21 Measure point 2: Diagnostic socket. Pin: 22 | Connector Connected; Key +15 OFF; | Typical Value: 60 Ohm Ohm; | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|-----------------------------|------------------------|--|-------------------------------------|---|---|--|--|-----------------------------|
| 3C | 01 | 57 | INJECTOR - BENCH 1 (DTC 60) | EXCEEDING NORMAL RANGE | Engine not working properly, possible power reduction. | Injector wiring short-circuit. | Check wiring and connections. Replace injector if required. | 1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A31 Measure point 2: Pin: 2 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A1 Measure point 2: Pin: 1 3- Measure type: Resistance (Ohm) Measure point 1: Pin: 1 Measure point 2: Pin: 2 4- Measure type: Resistance (Ohm) Measure point 1: Pin: 1 Measure point 2: Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; 4- Connector Not connected; Key +15 OFF; | 1- Typical Value: 0,1 Ohm; 2- Typical Value: 0,1 Ohm; 3- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; 4- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm; | Only two cylinders running. |
| 3C | 02 | 57 | INJECTOR - BENCH 1 (DTC 60) | EXCEEDING NORMAL RANGE | Engine not working properly, possible power reduction. | Short-circuit to ground. | Check wiring and connections. | | | | Only two cylinders running. |
| 3C | 08 | 57 | INJECTOR - BENCH 1 (DTC 60) | SIGNAL NOT PLAUSIBLE | Engine not working properly, possible power reduction. | Injector electrical system failure. | Check wiring and connections. Replace injector if required. | | | | Only two cylinders running. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|-----------------------------|------------------------|--|--------------------------------|---|--|---|---|-----------------------------|
| 3D | 04 | 57 | INJECTOR - BENCH 1 (DTC 61) | NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring disconnected. | Check wiring and connections. Replace injector if required. | | | | Only two cylinders running. |
| 3E | 01 | 58 | INJECTOR - BENCH 2 (DTC 62) | EXCEEDING NORMAL RANGE | Engine not working properly, possible power reduction. | Injector wiring short-circuit. | Check wiring and connections. Replace injector if required. | <p>1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A1 Measure point 2: Pin: 1</p> <p>2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A31 Measure point 2: Pin: 2</p> <p>3- Measure type: Resistance (Ohm) Measure point 1: Pin: 1 Measure point 2: Pin: 2</p> <p>4- Measure type: Resistance (Ohm) Measure point 1: Injector 2 Pin: 1 Measure point 2: Injector 2 Pin: 2</p> | <p>1- Connector Not connected; Key +15 OFF;</p> <p>2- Connector Not connected; Key +15 OFF;</p> <p>3- Connector Connected; Key +15 OFF;</p> <p>4- Connector Not connected; Key +15 OFF;</p> | <p>1- Typical Value: 0,1 Ohm;</p> <p>2- Typical Value: 0,1 Ohm;</p> <p>3- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm;</p> <p>4- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm;</p> | Only two cylinders running. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--|------------------------|--|-------------------------------------|--|------------------------|----------------------|-----------------------|-----------------------------|
| 3E | 02 | 58 | INJECTOR - BENCH 2 (DTC 62) | EXCEEDING NORMAL RANGE | Engine not working properly, possible power reduction. | Short-circuit to ground. | Check wiring and connections. | | | | Only two cylinders running. |
| 3E | 08 | 58 | INJECTOR - BENCH 2 (DTC 62) | SIGNAL NOT PLAUSIBLE | Engine not working properly, possible power reduction. | Injector electrical system failure. | Check wiring and connections. Replace injector if required. | | | | Only two cylinders running. |
| 3F | 04 | 58 | INJECTOR - BENCH 2 (DTC 63) | NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring disconnected. | Check wiring and connections. Replace injector if required. | | | | Only two cylinders running. |
| 40 | 01 | 57 | INJECTOR - STAGE A INJECTORS CHECK (INTERNAL ECU) (DTC 64) | EXCEEDING NORMAL RANGE | Engine off. | Internal ECU problem. | Clear failure memory. If the error persists, ensure that the failure does not concern the injectors and call the Help Desk for instructions on how to replace the ECU. | | | | |
| 40 | 02 | 57 | INJECTOR - STAGE A INJECTORS CHECK (INTERNAL ECU) (DTC 64) | EXCEEDING NORMAL RANGE | Engine off. | Internal ECU problem. | Clear failure memory. If the error persists, ensure that the failure does not concern the injectors and call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--|------------------------|-----------------|-----------------------|--|------------------------|----------------------|-----------------------|---------|
| 40 | 04 | 57 | INJECTOR - STAGE A INJECTORS CHECK (INTERNAL ECU) (DTC 64) | NO SIGNAL | Engine off. | Internal ECU problem. | Clear failure memory. If the error persists, ensure that the failure does not concern the injectors and call the Help Desk for instructions on how to replace the ECU. | | | | |
| 40 | 08 | 57 | INJECTOR - STAGE A INJECTORS CHECK (INTERNAL ECU) (DTC 64) | SIGNAL NOT PLAUSIBLE | Engine off. | Internal ECU problem. | Clear failure memory. If the error persists, ensure that the failure does not concern the injectors and call the Help Desk for instructions on how to replace the ECU. | | | | |
| 41 | 01 | 57 | INJECTOR - STAGE B INJECTORS CHECK (INTERNAL ECU) (DTC 65) | EXCEEDING NORMAL RANGE | Engine off. | Internal ECU problem. | Clear failure memory. If the error persists, ensure that the failure does not concern the injectors and call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--|------------------------|-----------------|-----------------------|--|------------------------|----------------------|-----------------------|---------|
| 41 | 02 | 57 | INJECTOR - STAGE B INJECTORS CHECK (INTERNAL ECU) (DTC 65) | EXCEEDING NORMAL RANGE | Engine off. | Internal ECU problem. | Clear failure memory. If the error persists, ensure that the failure does not concern the injectors and call the Help Desk for instructions on how to replace the ECU. | | | | |
| 41 | 04 | 57 | INJECTOR - STAGE B INJECTORS CHECK (INTERNAL ECU) (DTC 65) | NO SIGNAL | Engine off. | Internal ECU problem. | Clear failure memory. If the error persists, ensure that the failure does not concern the injectors and call the Help Desk for instructions on how to replace the ECU. | | | | |
| 41 | 08 | 57 | INJECTOR - STAGE B INJECTORS CHECK (INTERNAL ECU) (DTC 65) | SIGNAL NOT PLAUSIBLE | Engine off. | Internal ECU problem. | Clear failure memory. If the error persists, ensure that the failure does not concern the injectors and call the Help Desk for instructions on how to replace the ECU. | | | | |
| 42 | 01 | 51 | INJECTOR - INJECTOR I (DTC 66) | EXCEEDING NORMAL RANGE | | | | | | | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--------------------------------|------------------------|--|----------------------------|---|---|---|---|-------------------------------|
| 42 | 01 | 53 | INJECTOR - INJECTOR 1 (DTC 66) | EXCEEDING NORMAL RANGE | Engine not working properly, possible power reduction. | Short-circuit to positive. | Check wiring and connections. Replace injector if required. | <p>1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A46 Measure point 2: Pin: 2</p> <p>2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A1 Measure point 2: Pin: 1</p> <p>3- Measure type: Resistance (Ohm) Measure point 1: Pin: 1 Measure point 2: Pin: 2</p> | <p>1- Connector Not connected; Key +15 OFF;</p> <p>2- Connector Not connected; Key +15 OFF;</p> <p>3- Connector Not connected; Key +15 OFF;</p> | <p>1- Typical Value: 0,1 Ohm;</p> <p>2- Typical Value: 0,1 Ohm;</p> <p>3- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm;</p> | Only three cylinders running. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--------------------------------|-----------------|--|--------------------------------|---|---|--|--|-----------------------------|
| 42 | 04 | 51 | INJECTOR - INJECTOR 1 (DTC 66) | NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring short-circuit. | Check wiring and connections. Replace injector if required. | 1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A1 Measure point 2: Pin: 1 2- Measure type: Resistance (Ohm) Measure point 1: Pin: 1 Measure point 2: Pin: 2 3- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A31 Measure point 2: Pin: 2 4- Measure type: Resistance (Ohm) Measure point 1: Pin: 1 Measure point 2: Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; 4- Connector Connected; Key +15 OFF; | 1- Typical Value: 0,1 Ohm; 2- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm; 3- Typical Value: 0,1 Ohm; 4- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm; | Only two cylinders running. |
| 42 | 04 | 51 | INJECTOR - INJECTOR 1 (DTC 66) | NO SIGNAL | | | | | | | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--------------------------------|----------------------|--|--------------------------------|---|---|---|---|-------------------------------|
| 42 | 08 | 51 | INJECTOR - INJECTOR 1 (DTC 66) | SIGNAL NOT PLAUSIBLE | Engine not working properly, possible power reduction. | Injector not working properly. | Check wiring and connections. Replace injector if required. | <p>1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A1 Measure point 2: Pin: 1</p> <p>2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A31 Measure point 2: Pin: 2</p> <p>3- Measure type: Resistance (Ohm) Measure point 1: Pin: 1 Measure point 2: Pin: 2</p> | <p>1- Connector Not connected; Key +15 OFF;</p> <p>2- Connector Not connected; Key +15 OFF;</p> <p>3- Connector Not connected; Key +15 OFF;</p> | <p>1- Typical Value: 0,1 Ohm;</p> <p>2- Typical Value: 0,1 Ohm;</p> <p>3- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm;</p> | Only three cylinders running. |
| 42 | 08 | 51 | INJECTOR - INJECTOR 1 (DTC 66) | SIGNAL NOT PLAUSIBLE | | | | | | | |
| 43 | 04 | 51 | INJECTOR - INJECTOR 1 (DTC 67) | NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring open circuit. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--------------------------------|------------------------|--|----------------------------|---|--|--|--|-------------------------------|
| 44 | 01 | 54 | INJECTOR - INJECTOR 2 (DTC 72) | EXCEEDING NORMAL RANGE | Engine not working properly, possible power reduction. | Short-circuit to positive. | Check wiring and connections. Replace injector if required. | 1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A46 Measure point 2: Injector 2 Pin: 2 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A1 Measure point 2: Injector 2 Pin: 1 3- Measure type: Resistance (Ohm) Measure point 1: Injector 2 Pin: 1 Measure point 2: Injector 2 Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Typical Value: 0,1 Ohm; 2- Typical Value: 0,1 Ohm; 3- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm; | Only three cylinders running. |
| 44 | 01 | 54 | INJECTOR - INJECTOR 2 (DTC 72) | EXCEEDING NORMAL RANGE | | | | | | | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--------------------------------|-----------------|--|--------------------------------|---|--|---|---|-----------------------------|
| 44 | 04 | 54 | INJECTOR - INJECTOR 2 (DTC 72) | NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring short-circuit. | Check wiring and connections. Replace injector if required. | <p>1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A1 Measure point 2: Pin: 1</p> <p>2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A31 Measure point 2: Pin: 2</p> <p>3- Measure type: Resistance (Ohm) Measure point 1: Pin: 1 Measure point 2: Pin: 2</p> <p>4- Measure type: Resistance (Ohm) Measure point 1: Pin: 1 Measure point 2: Pin: 2</p> | <p>1- Connector Not connected; Key +15 OFF;</p> <p>2- Connector Not connected; Key +15 OFF;</p> <p>3- Connector Connected; Key +15 OFF;</p> <p>4- Connector Not connected; Key +15 OFF;</p> | <p>1- Typical Value: 0,1 Ohm;</p> <p>2- Typical Value: 0,1 Ohm;</p> <p>3- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm;</p> <p>4- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm;</p> | Only two cylinders running. |
| 44 | 04 | 54 | INJECTOR - INJECTOR 2 (DTC 72) | NO SIGNAL | | | | | | | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--------------------------------|----------------------|--|--------------------------------|---|--|--|--|-------------------------------|
| 44 | 08 | 54 | INJECTOR - INJECTOR 2 (DTC 72) | SIGNAL NOT PLAUSIBLE | Engine not working properly, possible power reduction. | Injector not working properly. | Check wiring and connections. Replace injector if required. | 1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A1 Measure point 2: Pin: 1 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A31 Measure point 2: Pin: 2 3- Measure type: Resistance (Ohm) Measure point 1: Pin: 1 Measure point 2: Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Typical Value: 0,1 Ohm; 2- Typical Value: 0,1 Ohm; 3- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm; | Only three cylinders running. |
| 44 | 08 | 54 | INJECTOR - INJECTOR 2 (DTC 72) | SIGNAL NOT PLAUSIBLE | | | | | | | |
| 45 | 04 | 54 | INJECTOR - INJECTOR 2 (DTC 73) | NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring open circuit. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--------------------------------|------------------------|--|----------------------------|---|---|---|---|-------------------------------|
| 46 | 01 | 52 | INJECTOR - INJECTOR 3 (DTC 68) | EXCEEDING NORMAL RANGE | Engine not working properly, possible power reduction. | Short-circuit to positive. | Check wiring and connections. Replace injector if required. | <p>1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A46 Measure point 2: Pin: 2</p> <p>2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A1 Measure point 2: Pin: 1</p> <p>3- Measure type: Resistance (Ohm) Measure point 1: Pin: 1 Measure point 2: Pin: 2</p> | <p>1- Connector Not connected; Key +15 OFF;</p> <p>2- Connector Not connected; Key +15 OFF;</p> <p>3- Connector Not connected; Key +15 OFF;</p> | <p>1- Typical Value: 0,1 Ohm;</p> <p>2- Typical Value: 0,1 Ohm;</p> <p>3- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm;</p> | Only three cylinders running. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--------------------------------|-----------------|--|--------------------------------|---|--|---|---|-----------------------------|
| 46 | 04 | 52 | INJECTOR - INJECTOR 3 (DTC 68) | NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring short-circuit. | Check wiring and connections. Replace injector if required. | <p>1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A1 Measure point 2: Pin: 1</p> <p>2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A31 Measure point 2: Pin: 2</p> <p>3- Measure type: Resistance (Ohm) Measure point 1: Pin: 1 Measure point 2: Pin: 2</p> <p>4- Measure type: Resistance (Ohm) Measure point 1: Pin: 1 Measure point 2: Pin: 2</p> | <p>1- Connector Not connected; Key +15 OFF;</p> <p>2- Connector Not connected; Key +15 OFF;</p> <p>3- Connector Connected; Key +15 OFF;</p> <p>4- Connector Not connected; Key +15 OFF;</p> | <p>1- Typical Value: 0,1 Ohm;</p> <p>2- Typical Value: 0,1 Ohm;</p> <p>3- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm;</p> <p>4- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm;</p> | Only two cylinders running. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--------------------------------|----------------------|--|--------------------------------|---|---|---|---|-------------------------------|
| 46 | 08 | 52 | INJECTOR - INJECTOR 3 (DTC 68) | SIGNAL NOT PLAUSIBLE | Engine not working properly, possible power reduction. | Injector not working properly. | Check wiring and connections. Replace injector if required. | <p>1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A1 Measure point 2: Pin: 1</p> <p>2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A31 Measure point 2: Pin: 2</p> <p>3- Measure type: Resistance (Ohm) Measure point 1: Pin: 1 Measure point 2: Pin: 2</p> | <p>1- Connector Not connected; Key +15 OFF;</p> <p>2- Connector Not connected; Key +15 OFF;</p> <p>3- Connector Not connected; Key +15 OFF;</p> | <p>1- Typical Value: 0,1 Ohm;</p> <p>2- Typical Value: 0,1 Ohm;</p> <p>3- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm;</p> | Only three cylinders running. |
| 47 | 04 | 52 | INJECTOR - INJECTOR 3 (DTC 69) | NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring open circuit. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |
| 47 | 04 | 52 | INJECTOR - INJECTOR 3 (DTC 69) | NO SIGNAL | | | | | | | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--------------------------------|------------------------|--|----------------------------|---|---|---|---|-------------------------------|
| 48 | 01 | 53 | INJECTOR - INJECTOR 4 (DTC 70) | EXCEEDING NORMAL RANGE | Engine not working properly, possible power reduction. | Short-circuit to positive. | Check wiring and connections. Replace injector if required. | <p>1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A46 Measure point 2: Pin: 2</p> <p>2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A1 Measure point 2: Pin: 1</p> <p>3- Measure type: Resistance (Ohm) Measure point 1: Pin: 1 Measure point 2: Pin: 2</p> | <p>1- Connector Not connected; Key +15 OFF;</p> <p>2- Connector Not connected; Key +15 OFF;</p> <p>3- Connector Not connected; Key +15 OFF;</p> | <p>1- Typical Value: 0,1 Ohm;</p> <p>2- Typical Value: 0,1 Ohm;</p> <p>3- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm;</p> | Only three cylinders running. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--------------------------------|-----------------|--|--------------------------------|---|--|---|---|-----------------------------|
| 48 | 04 | 58 | INJECTOR - INJECTOR 4 (DTC 70) | NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring short-circuit. | Check wiring and connections. Replace injector if required. | <p>1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A1 Measure point 2: Pin: 1</p> <p>2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A31 Measure point 2: Pin: 2</p> <p>3- Measure type: Resistance (Ohm) Measure point 1: Pin: 1 Measure point 2: Pin: 2</p> <p>4- Measure type: Resistance (Ohm) Measure point 1: Pin: 1 Measure point 2: Pin: 2</p> | <p>1- Connector Not connected; Key +15 OFF;</p> <p>2- Connector Not connected; Key +15 OFF;</p> <p>3- Connector Not connected; Key +15 OFF;</p> <p>4- Connector Connected; Key +15 OFF;</p> | <p>1- Typical Value: 0,1 Ohm;</p> <p>2- Typical Value: 0,1 Ohm;</p> <p>3- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm;</p> <p>4- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm;</p> | Only two cylinders running. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--------------------------------------|----------------------|--|---|--|--|--|--|--|
| 48 | 08 | 53 | INJECTOR - INJECTOR 4 (DTC 70) | SIGNAL NOT PLAUSIBLE | Engine not working properly, possible power reduction. | Injector not working properly. | Check wiring and connections. Replace injector if required. | 1- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A1 Measure point 2: Pin: 1 2- Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A31 Measure point 2: Pin: 2 3- Measure type: Resistance (Ohm) Measure point 1: Pin: 1 Measure point 2: Pin: 2 | 1- Connector Not connected; Key +15 OFF; 2- Connector Not connected; Key +15 OFF; 3- Connector Not connected; Key +15 OFF; | 1- Typical Value: 0,1 Ohm; 2- Typical Value: 0,1 Ohm; 3- Min. value: 0,5 Ohm; Max. value: 0,9 Ohm; Typical Value: 0,7 Ohm; | Only three cylinders running. |
| 49 | 04 | 53 | INJECTOR - INJECTOR 4 (DTC 71) | NO SIGNAL | Engine not working properly, possible power reduction. | Injector wiring open circuit. | Check wiring and connections. Replace injector if required. | | | | Only three cylinders running. |
| 49 | 04 | 53 | INJECTOR - INJECTOR 4 (DTC 71) | NO SIGNAL | | | | | | | |
| 4E | 08 | 13 | VEHICLE - CRUISE CONTROL SWITCH UNIT | SIGNAL NOT PLAUSIBLE | Cruise control / PTO not working. | Press SET+ / SET- and RESUME/ OFF at the same time. | Check correct operation of the switch by reading state parameters. | | | | Replace wiring and connections if state does not change when Cruise Control buttons are pressed. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|---|------------------------|--|--|---|------------------------|----------------------|-----------------------|---------|
| 50 | 01 | 94 | ELECTRONIC CONTROL UNIT - MAIN RELAY DEFECT | EXCEEDING NORMAL RANGE | Engine does not start, ECU not powered or ECU always powered and EDC off also at key-on. | Main relay interrupted or short-circuit. | Check wiring and connections. Replace relay if required. | | | | |
| 50 | 02 | 94 | ELECTRONIC CONTROL UNIT - MAIN RELAY DEFECT | EXCEEDING NORMAL RANGE | Engine does not start, ECU not powered or ECU always powered and EDC off also at key-on. | Main relay interrupted or short-circuit. | Check wiring and connections. Replace relay if required. | | | | |
| 51 | 01 | 12 | VEHICLE MULTIPOSITION SELECTOR / PTO | EXCEEDING NORMAL RANGE | Incorrect PTO operation. | Voltage exceeding max. threshold, short-circuit to positive. | Check wiring and connections. Replace sensor if required. | | | | |
| 51 | 02 | 12 | VEHICLE MULTIPOSITION SELECTOR / PTO | EXCEEDING NORMAL RANGE | Incorrect PTO operation. | Voltage under min. threshold, short-circuit to ground. | Check wiring and connections. Replace sensor if required. | | | | |
| 51 | 08 | 12 | VEHICLE MULTIPOSITION SELECTOR / PTO | SIGNAL NOT PLAUSIBLE | Incorrect PTO operation. | Faulty device. | Check wiring and connections. Replace sensor if required. | | | | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--|------------------------|-----------------|---|--|--|---------------------------------------|---|-------------|
| 52 | 04 | 83 | FUEL PRESSURE - PRESSURE MPROP REGULATOR ERROR | NO SIGNAL | Engine off. | Faulty MPROP. | Check wiring and connections. Replace MPROP if required. | Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A49 Measure point 2: ECU Pin: A19 | Connector Not connected; Key +15 OFF; | Min. value: 3.2 Ohm; Max. value: 3.6 Ohm; Typical Value: 3.4 Ohm; | High noise. |
| 52 | 08 | 83 | FUEL PRESSURE - PRESSURE MPROP REGULATOR ERROR | SIGNAL NOT PLAUSIBLE | | | Check wiring and connections. Replace MPROP if required. | Measure type: Resistance (Ohm) Measure point 1: ECU Pin: A49 Measure point 2: ECU Pin: A19 | Connector Not connected; Key +15 OFF; | Min. value: 3.2 Ohm; Max. value: 3.6 Ohm; Typical Value: 3.4 Ohm; | |
| 53 | 01 | 83 | FUEL PRESSURE - PRESSURE MPROP REGULATOR ERROR (SHORT CIRCUIT TO POSITIVE) | EXCEEDING NORMAL RANGE | | Short-circuit to battery, faulty MPROP. | Check wiring and connections. Replace MPROP if required. | | | | |
| 54 | 01 | 83 | FUEL PRESSURE - PRESSURE MPROP REGULATOR ERROR (SHORT CIRCUIT TO NEGATIVE) | EXCEEDING NORMAL RANGE | | Short-circuit to ground. Faulty MPROP. | Check wiring and connections. Replace MPROP if required. | | | | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|---|------------------------|-----------------|---|---|------------------------|----------------------|-----------------------|---------|
| 56 | 08 | 91 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT (DTC 86) | SIGNAL NOT PLAUSIBLE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 5A | 01 | 64 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT (DTC 90) | EXCEEDING NORMAL RANGE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 5A | 02 | 64 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT (DTC 90) | EXCEEDING NORMAL RANGE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|---|------------------------|---|---|---|------------------------|----------------------|-----------------------|---------|
| 5B | 01 | 64 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT (DTC 91) | EXCEEDING NORMAL RANGE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 5E | 01 | 27 | ENGINE I - FUEL PUMP RELAY | EXCEEDING NORMAL RANGE | Fuel pump on always when engine is off. | Faulty relay, short-circuit to positive in wiring. | Turn key-on: pump must run for approximately 10 seconds (it should hum). Check pump relay if pump remains on. Check wiring if all checks are OK. | | | | |
| 5E | 02 | 27 | ENGINE I - FUEL PUMP RELAY | EXCEEDING NORMAL RANGE | Fuel pump not working. | Faulty relay, short-circuit to ground in wiring. | Turn key-on: pump must run for approximately 10 seconds (it should hum). Check the pump relay, protection fuse and wiring if this does not occur. | | | | |
| 5E | 04 | 27 | ENGINE I - FUEL PUMP RELAY | NO SIGNAL | Fuel pump not working. | Faulty relay, wiring interrupted. | Check wiring and connections. Replace relay if required. | | | | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--|------------------------|--------------------------------|--|---|------------------------|----------------------|-----------------------|---|
| 5E | 08 | 27 | ENGINE I - FUEL PUMP RELAY | SIGNAL NOT PLAUSIBLE | Fuel pump not working. | Faulty relay, wiring interrupted. | Check wiring and connections. Replace relay if required. | | | | |
| 5F | 01 | 82 | FUEL PRESSURE - RAIL PRESSURE SENSOR OR SIGNAL ERROR | EXCEEDING NORMAL RANGE | Possible engine disconnection. | Short-circuit to positive. Faulty sensor. Rail pressure not regular. | Check wiring and connections. Replace sensor if required. | | | | Check DTC 103 error. |
| 5F | 02 | 82 | FUEL PRESSURE - RAIL PRESSURE SENSOR OR SIGNAL ERROR | EXCEEDING NORMAL RANGE | Possible engine disconnection. | Short-circuit to ground, faulty sensor. | Check wiring and connections. Replace sensor if required. | | | | |
| 60 | 01 | 82 | FUEL PRESSURE - RAIL PRESSURE SENSOR OFFSET | EXCEEDING NORMAL RANGE | Possible engine disconnection. | Faulty rail pressure sensor. | Replace sensor. | | | | |
| 60 | 02 | 82 | FUEL PRESSURE - RAIL PRESSURE SENSOR OFFSET | EXCEEDING NORMAL RANGE | Possible engine disconnection. | Faulty rail pressure sensor. | Replace sensor. | | | | |
| 62 | 01 | 81 | FUEL PRESSURE - FAULT ON THE FUEL DRUCK CONTROL OF THE RAIL (POSITIVE DEVIATION) | EXCEEDING NORMAL RANGE | Possible engine disconnection. | High pressure circuit fuel leakage. | Check fuel feed system. | | | | Fuel management and pressure failure in rail. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--|--------------------------|--------------------------------|--|---|------------------------|----------------------|-----------------------|---|
| 62 | 01 | 81 | FUEL PRESSURE - FAULT ON THE FUEL DRUCK CONTROL OF THE RAIL (POSITIVE DEVIATION) | EXCEED-ING NOR-MAL RANGE | Possible engine disconnection. | Injector jammed in fuel passage open position. | Check hydraulic and mechanical efficiency of injectors. | | | | Fuel management and pressure failure in rail. |
| 62 | 01 | 81 | FUEL PRESSURE - FAULT ON THE FUEL DRUCK CONTROL OF THE RAIL (POSITIVE DEVIATION) | EXCEED-ING NOR-MAL RANGE | Possible engine disconnection. | MPROP adjuster open movement jammed. | Check efficiency of MPROP adjuster. | | | | Fuel management and pressure failure in rail. |
| 62 | 01 | 81 | FUEL PRESSURE - FAULT ON THE FUEL DRUCK CONTROL OF THE RAIL (POSITIVE DEVIATION) | EXCEED-ING NOR-MAL RANGE | Possible engine disconnection. | Faulty high pressure pump. | Check efficiency of high pressure pump. | | | | Fuel management and pressure failure in rail. |
| 63 | 01 | 81 | FUEL PRESSURE - FAULT ON THE FUEL DRUCK CONTROL OF THE RAIL (NEGATIVE DEVIATION) | EXCEED-ING NOR-MAL RANGE | Possible engine disconnection. | MPROP adjuster open movement jammed. | Check efficiency of MPROP adjuster. | | | | Fuel management and pressure failure in rail. |
| 64 | 01 | 81 | FUEL PRESSURE - RAIL PRESSURE ERROR: TOO LOW | EXCEED-ING NOR-MAL RANGE | Possible engine disconnection. | High pressure circuit fuel leakage. | Check high pressure system. Replace high pressure pump if required. | | | | Fuel management and pressure failure in rail. |
| 65 | 01 | 81 | FUEL PRESSURE - RAIL PRESSURE ERROR: TOO HIGH | EXCEED-ING NOR-MAL RANGE | Possible engine disconnection. | MPROP regulator jammed. | Check MPROP regulator, replace if required. | | | | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|---|------------------------|--|---|---|------------------------|----------------------|-----------------------|--------------------------------|
| 66 | 01 | 81 | FUEL PRESSURE - ERROR ON THE RAIL PRESSURE (EXCESSIVE DUTY CYCLE) | EXCEEDING NORMAL RANGE | Negative vehicle reaction with smoke in exhaust during acceleration. | High pressure circuit fuel leakage. | Check fuel feed system, replace high pressure pump if required. Faulty fuel feed system (fuel pump and filter jammed). | | | | |
| 67 | 01 | 81 | FUEL PRESSURE - ERROR ON THE RAIL PRESSURE (EXCESSIVE) | EXCEEDING NORMAL RANGE | Possible engine disconnection. | MPROP regulator jammed. | Check MPROP regulator, replace if required. | | | | Replace pressure relief valve. |
| 68 | 04 | 96 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT (DTC I04) | NO SIGNAL | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 68 | 08 | 96 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT (DTC I04) | SIGNAL NOT PLAUSIBLE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|---|------------------------|---|------------------------------------|---|------------------------|----------------------|-----------------------|---|
| 69 | 01 | 97 | ELECTRONIC CONTROL UNIT - SENSOR POWER SUPPLY (DTC 105) | EXCEEDING NORMAL RANGE | Anomalous engine operation due to incorrectly powered sensors. Reduced power. | Sensor power circuit fault in ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | Possible fault indications of various sensors powered by ECU. |
| 69 | 02 | 97 | ELECTRONIC CONTROL UNIT - SENSOR POWER SUPPLY (DTC 105) | EXCEEDING NORMAL RANGE | Anomalous engine operation due to incorrectly powered sensors. Reduced power. | Sensor power circuit fault in ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | Possible fault indications of various sensors powered by ECU. |
| 6A | 01 | 97 | ELECTRONIC CONTROL UNIT - SENSOR POWER SUPPLY (DTC 106) | EXCEEDING NORMAL RANGE | Anomalous engine operation due to incorrectly powered sensors. Reduced power. | Sensor power circuit fault in ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | Possible fault indications of various sensors powered by ECU. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|---|------------------------|---|------------------------------------|---|------------------------|----------------------|-----------------------|---|
| 6A | 02 | 97 | ELECTRONIC CONTROL UNIT - SENSOR POWER SUPPLY (DTC 106) | EXCEEDING NORMAL RANGE | Anomalous engine operation due to incorrectly powered sensors. Reduced power. | Sensor power circuit fault in ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | Possible fault indications of various sensors powered by ECU. |
| 6B | 01 | 97 | ELECTRONIC CONTROL UNIT - SENSOR POWER SUPPLY (DTC 107) | EXCEEDING NORMAL RANGE | Anomalous engine operation due to incorrectly powered sensors. Reduced power. | Sensor power circuit fault in ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | Possible fault indications of various sensors powered by ECU. |
| 6B | 02 | 97 | ELECTRONIC CONTROL UNIT - SENSOR POWER SUPPLY (DTC 107) | EXCEEDING NORMAL RANGE | Anomalous engine operation due to incorrectly powered sensors. Reduced power. | Sensor power circuit fault in ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | Possible fault indications of various sensors powered by ECU. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--------------------|------------------------|----------------------------|----------------------------------|---|------------------------|----------------------|-----------------------|--|
| 6C | 01 | 18 | VEHICLE - EDC LAMP | EXCEEDING NORMAL RANGE | Warning light not working. | Short-circuit to positive. | Check correct operation of warning light using "Active diagnostic" procedure. | | | | Warning light should come on for approximately 5 seconds at key-on. Check wiring and connections if this does not occur. |
| 6C | 02 | 18 | VEHICLE - EDC LAMP | EXCEEDING NORMAL RANGE | Warning light not working. | Short-circuit to ground. | Check correct operation of warning light using "Active diagnostic" procedure. | | | | Warning light should come on for approximately 5 seconds at key-on. Check wiring and connections if this does not occur. |
| 6C | 04 | 18 | VEHICLE - EDC LAMP | NO SIGNAL | Warning light not working. | Open circuit, bulb disconnected. | Check correct operation of warning light using "Active diagnostic" procedure. | | | | Warning light should come on for approximately 5 seconds at key-on. Check wiring and connections if this does not occur. |
| 6C | 08 | 18 | VEHICLE - EDC LAMP | SIGNAL NOT PLAUSIBLE | Warning light not working. | Wiring problems. | Check wiring and connections. Replace sensor if required. | | | | Warning light should come on for approximately 5 seconds at key-on. Check wiring and connections if this does not occur. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--|------------------------|--|---|---|------------------------|----------------------|-----------------------|--|
| 6D | 08 | 38 | ENGINE 2 - INTERNAL ECU FAULT (PLAUSIBILITY ERROR +15) | SIGNAL NOT PLAUSIBLE | | | Check wiring and connections. | | | | Key 15 off during initialisation. |
| 6E | 08 | 99 | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT (DTC 110) | SIGNAL NOT PLAUSIBLE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |
| 75 | 01 | 11 | VEHICLE - VEHICLE SPEED SENSOR / SIGNAL (DTC 117) | EXCEEDING NORMAL RANGE | Maximum speed threshold has been exceeded. | | Check correct calibration of speedometer. | | | | Encourage driver to use the vehicle correctly. |
| 75 | 04 | 11 | VEHICLE - VEHICLE SPEED SENSOR / SIGNAL (DTC 117) | NO SIGNAL | | Interrupted wiring between vehicle speed sensor and instrument panel. | Check wiring and connections between vehicle speed sensor and instrument panel. | | | | |
| 75 | 04 | 11 | VEHICLE - VEHICLE SPEED SENSOR / SIGNAL (DTC 117) | NO SIGNAL | | Wiring interrupted between instrument panel and EDC ECU. | Check wiring and connections between instrument panel and EDC ECU. | | | | Intervention required if instrument panel indicates vehicle speed. |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|---|------------------------|---|--|--|------------------------|----------------------|-----------------------|---------|
| 75 | 04 | 11 | VEHICLE - VEHICLE SPEED SENSOR / SIGNAL (DTC 117) | NO SIGNAL | | Vehicle speed sensor disconnected or failed. | Check correct assembly and efficiency of vehicle speed sensor. | | | | |
| 75 | 08 | 11 | VEHICLE - VEHICLE SPEED SENSOR / SIGNAL (DTC 117) | SIGNAL NOT PLAUSIBLE | | Vehicle speed sensor disconnected or failed. | Check correct assembly and efficiency of vehicle speed sensor. | | | | |
| 75 | 08 | 11 | VEHICLE - VEHICLE SPEED SENSOR / SIGNAL (DTC 117) | SIGNAL NOT PLAUSIBLE | Vehicle speed on instrument panel does not increase sensibly. | Wrong speedometer setting. | Check correct calibration of speedometer. | | | | |
| 77 | 01 | 11 | VEHICLE - VEHICLE SPEED SENSOR / SIGNAL (DTC 119) | EXCEEDING NORMAL RANGE | Wrong vehicle speed indication. | Wrong speedometer setting. | Check correct calibration of speedometer. | | | | |
| 77 | 02 | 11 | VEHICLE - VEHICLE SPEED SENSOR / SIGNAL (DTC 119) | EXCEEDING NORMAL RANGE | Wrong vehicle speed indication. | Wrong speedometer setting. | Check correct calibration of speedometer. | | | | |
| 77 | 08 | 11 | VEHICLE - VEHICLE SPEED SENSOR / SIGNAL (DTC 119) | SIGNAL NOT PLAUSIBLE | Wrong vehicle speed indication. | Wrong speedometer setting. | Check correct calibration of speedometer. | | | | |

| DTC | FMI | BLINK CODE | Failing component | Type of Failure | Visible failure | Possible Cause | Repair action | Checks to be performed | Measuring conditions | Values to be detected | Remarks |
|-----|-----|------------|--|----------------------|-----------------|---|---|------------------------|----------------------|-----------------------|---------|
| 79 | 08 | | ELECTRONIC CONTROL UNIT - INTERNAL ECU FAULT (DTC I21) | SIGNAL NOT PLAUSIBLE | | Wrong ECU programming. Probable electromagnetic interference. Faulty ECU. | Switch key on/off and wait for a few seconds, clear failure memory. If the error persists, call the Help Desk for instructions on how to replace the ECU. | | | | |

FIC engine

| | Page |
|--|--------|
| MAIN OPERATIONS ON ENGINE MOUNTED ON VEHICLE | 492/1 |
| ENGINE REMOVAL-REFITTING | 492/3 |
| <input type="checkbox"/> Removal | 492/3 |
| <input type="checkbox"/> Refitting | 492/7 |
| <input type="checkbox"/> Checks and tests | 492/7 |
| <input type="checkbox"/> Power steering system air bleed | 492/7 |
| REPLACING AIR-CONDITIONING COMPRESSOR DRIVE BELT (VERSION WITH BELT TENSIONER) | 492/8 |
| <input type="checkbox"/> Disassembly | 492/8 |
| <input type="checkbox"/> Assembly | 492/8 |
| POWER STEERING PUMP-ALTERNATOR BELT REPLACEMENT | 492/8 |
| <input type="checkbox"/> Assembly | 492/8 |
| <input type="checkbox"/> Disassembly | 492/8 |
| REPLACING THE WATER PUMP | 492/8 |
| <input type="checkbox"/> Removal | 492/8 |
| <input type="checkbox"/> Refitting | 492/8 |
| REPLACING THE HIGH-PRESSURE PUMP | 492/9 |
| <input type="checkbox"/> Removal | 492/9 |
| <input type="checkbox"/> Refitting | 492/9 |
| REPLACING THE POWER STEERING PUMP .. | 492/10 |
| <input type="checkbox"/> Removal | 492/10 |
| <input type="checkbox"/> Refitting | 492/10 |
| REPLACING THE DRIVE SHAFT SEAL RING AND THE FRONT COVER GASKET | 492/10 |
| <input type="checkbox"/> Removal | 492/10 |
| <input type="checkbox"/> Refitting | 492/11 |
| REPLACING THE VACUUM PUMP OIL PUMP ASSEMBLY (GPOD) | 492/12 |
| <input type="checkbox"/> Removal | 492/12 |
| <input type="checkbox"/> Refitting | 492/12 |
| REPLACING THE DRIVE SHAFT REAR SEAL RING | 492/13 |
| <input type="checkbox"/> Removal | 492/13 |

| | Page |
|---|--------|
| <input type="checkbox"/> Refitting | 492/13 |
| REPLACING ELECTRO-INJECTORS | 492/14 |
| <input type="checkbox"/> Removal | 492/14 |
| <input type="checkbox"/> Refitting | 492/14 |
| DETACHING/RE-ATTACHING THE CYLINDER HEAD | 492/15 |
| <input type="checkbox"/> Removal | 492/15 |
| <input type="checkbox"/> Refitting | 492/17 |
| ENGINE VIEWS | 493 |
| ENGINE IDENTIFICATION CODE | 496 |
| CHARACTERISTIC CURVES | 500 |
| GENERAL SPECIFICATIONS | 502 |
| ASSEMBLY DATA – CLEARANCES | 505 |
| TOOLS | 510 |
| EXPERIMENTAL TOOLS | 516 |
| TIGHTENING TORQUE | 523 |
| OVERHAULING ENGINE FIC <input type="checkbox"/> | 526 |
| DISASSEMBLING THE ENGINE AT THE BENCH | 526 |
| REPAIRS | 536 |
| CYLINDER BLOCK | 536 |
| <input type="checkbox"/> Checks and measurements | 536 |
| <input type="checkbox"/> Checking head mating surface on cylinder block | 537 |
| CRANKSHAFT | 537 |
| <input type="checkbox"/> Measuring main journals and crank pins | 537 |
| <input type="checkbox"/> Checking crankshaft | 538 |
| <input type="checkbox"/> Replacing timing control gear | 540 |
| ENGINE ASSEMBLY | 540 |
| <input type="checkbox"/> Assembling main bearings | 540 |
| <input type="checkbox"/> Measuring main journal assembly clearance ... | 540 |
| <input type="checkbox"/> Checking crankshaft end float | 541 |
| <input type="checkbox"/> Assembling rear seal | 542 |
| ENGINE FLYWHEEL | 543 |
| CONNECTING ROD – PISTON ASSEMBLY ... | 543 |
| <input type="checkbox"/> Replacing bearing supporting gearbox input shaft | 543 |
| <input type="checkbox"/> Pistons | 544 |
| <input type="checkbox"/> Measuring piston diameter | 544 |

| | Page |
|---|------|
| <input type="checkbox"/> Piston pins | 545 |
| <input type="checkbox"/> Conditions for correct pin-piston coupling ... | 545 |
| <input type="checkbox"/> Piston rings | 545 |
| <input type="checkbox"/> Connecting rods | 546 |
| <input type="checkbox"/> Bushing | 546 |
| <input type="checkbox"/> Checking connecting rods | 546 |
| <input type="checkbox"/> Checking torsion | 547 |
| <input type="checkbox"/> Checking bending | 547 |
| <input type="checkbox"/> Assembling connecting rod-piston assembly ... | 547 |
| <input type="checkbox"/> Checking for connecting rod – piston distortion | 548 |
| <input type="checkbox"/> Assembling piston rings | 548 |
| <input type="checkbox"/> Assembling connecting rod – piston assemblies in cylinder barrels | 548 |
| <input type="checkbox"/> Measuring crankpin assembly clearance | 548 |
| <input type="checkbox"/> Checking piston protrusion | 549 |
| CYLINDER HEAD | 550 |
| <input type="checkbox"/> Disassembly | 550 |
| <input type="checkbox"/> Disassembling valves | 550 |
| <input type="checkbox"/> Checking cylinder head seal | 551 |
| <input type="checkbox"/> Checking cylinder head mating surface | 551 |
| VALVES | 551 |
| <input type="checkbox"/> Removing deposits, refacing and checking valves | 551 |
| <input type="checkbox"/> Checking clearance between valve stem and valve guide and centring valves | 552 |
| VALVE GUIDES | 552 |
| <input type="checkbox"/> Replacing valve guides | 552 |
| <input type="checkbox"/> Boring valve guides | 552 |
| VALVE SEATS | 553 |
| <input type="checkbox"/> Regrinding - replacing valve seats | 553 |
| VALVE SPRINGS | 554 |
| ROCKER ARMS – TAPPETS | 554 |
| <input type="checkbox"/> Checks | 555 |
| ASSEMBLING CYLINDER HEADS | 555 |
| <input type="checkbox"/> Overhead | 556 |
| <input type="checkbox"/> Overhead removal | 556 |

| | Page |
|---|------|
| TIMING SYSTEM | 557 |
| <input type="checkbox"/> Description | 557 |
| <input type="checkbox"/> Camshaft | 558 |
| <input type="checkbox"/> Checks | 558 |
| <input type="checkbox"/> Checking cam lift and pin alignment | 558 |
| <input type="checkbox"/> Assembling overhead | 559 |
| AUXILIARY ORGAN CONTROLS | 559 |
| <input type="checkbox"/> Cylinder head refitting | 561 |
| TIMING SYSTEM CONTROL | 562 |
| <input type="checkbox"/> Replacement of alternator free wheel | 567 |
| <input type="checkbox"/> Timing speed sensor | 572 |
| <input type="checkbox"/> Engine speed sensor | 572 |
| LUBRICATION | 573 |
| <input type="checkbox"/> General | 573 |
| OIL PUMP/DEPRESSOR UNIT | 575 |
| <input type="checkbox"/> Oil pump | 575 |
| <input type="checkbox"/> Characteristic data | 575 |
| <input type="checkbox"/> Vacuum pump | 576 |
| <input type="checkbox"/> Oil pressure adjusting valve | 576 |
| <input type="checkbox"/> Disassembly | 576 |
| <input type="checkbox"/> Assembly | 577 |
| <input type="checkbox"/> Oil filter | 577 |
| <input type="checkbox"/> Heat exchanger | 577 |
| <input type="checkbox"/> Disassembly | 577 |
| <input type="checkbox"/> Assembly | 577 |
| <input type="checkbox"/> Oil vapour recirculation (Blow-by) | 579 |
| <input type="checkbox"/> Operation | 579 |
| COOLING | 580 |
| <input type="checkbox"/> Description | 580 |
| <input type="checkbox"/> Operation | 580 |
| <input type="checkbox"/> Electromagnetic pulley | 581 |
| <input type="checkbox"/> Water pump | 581 |
| <input type="checkbox"/> Thermostat | 581 |

| | Page |
|---|------|
| TURBOCHARGING | 582 |
| <input type="checkbox"/> Description | 582 |
| <input type="checkbox"/> Turbocharger type MITSUBISHI TD 4 HL-13T - 6 | 583 |
| REPAIRS | 584 |
| <input type="checkbox"/> Pressure relief valve | 584 |
| <input type="checkbox"/> Checking and adjusting pressure relief valve ... | 584 |
| <input type="checkbox"/> Changing the pressure relief valve | 584 |
| <input type="checkbox"/> GARRET GT 2256 T variable geometry turbosupercharger | 585 |
| <input type="checkbox"/> General | 585 |
| <input type="checkbox"/> Operation at low engine rpm | 585 |
| <input type="checkbox"/> Operation at high engine rpm | 585 |
| <input type="checkbox"/> Proportional solenoid valve controlling turbocharger actuator | 586 |
| <input type="checkbox"/> Actuator | 586 |
| REPAIRS | 587 |
| <input type="checkbox"/> Checking and adjusting the actuator | 587 |
| FUEL SUPPLY | 589 |
| HIGH-PRESSURE ELECTRONIC INJECTION SYSTEM (EDC 16) | 589 |
| <input type="checkbox"/> General | 589 |
| SYSTEM OPERATION | 591 |
| <input type="checkbox"/> Self-diagnosis – BLINK CODE | 591 |
| <input type="checkbox"/> Immobilizer recognition | 591 |
| <input type="checkbox"/> Checking fuel temperature | 591 |
| <input type="checkbox"/> Checking engine coolant temperature | 591 |
| <input type="checkbox"/> Checking quantity of fuel injected | 591 |
| <input type="checkbox"/> Checking idling adjustment | 591 |
| <input type="checkbox"/> Fuel cut-off in release phase | 591 |
| <input type="checkbox"/> Checking cylinder balancing on idling | 591 |
| <input type="checkbox"/> Checking regular engine rotation (anti-sawing) . | 591 |
| <input type="checkbox"/> Checking smokiness at exhaust on acceleration | 591 |

Page

| | |
|--|-----|
| <input type="checkbox"/> Checking exhaust gas recirculation (E.G.R. if present) | 591 |
| <input type="checkbox"/> Checking top speed limit | 591 |
| <input type="checkbox"/> Checking regular rotation on acceleration | 591 |
| <input type="checkbox"/> Checking glow plug control unit | 591 |
| <input type="checkbox"/> Checking activation of air-conditioning system | 591 |
| <input type="checkbox"/> Checking fuel pump | 591 |
| <input type="checkbox"/> Checking diesel warming | 592 |
| <input type="checkbox"/> Checking cylinder position | 592 |
| <input type="checkbox"/> Checking pilot and main injection timing | 592 |
| <input type="checkbox"/> Checking injection pressure closed cycle | 592 |
| <input type="checkbox"/> Fuel supply | 592 |
| <input type="checkbox"/> Correcting flow rate according to water temperature | 592 |
| <input type="checkbox"/> Correcting flow rate to avoid noise, smoke or overloading | 592 |
| <input type="checkbox"/> De-rating | 592 |
| <input type="checkbox"/> Injection timing electronic test | 592 |
| <input type="checkbox"/> Speed governor | 592 |
| <input type="checkbox"/> Engine starting | 592 |
| <input type="checkbox"/> Cold starting | 593 |
| <input type="checkbox"/> Warm starting | 593 |
| <input type="checkbox"/> Run up | 593 |
| <input type="checkbox"/> After run | 593 |
| <input type="checkbox"/> Cut-off | 593 |
| <input type="checkbox"/> Cylinder balancing | 593 |
| <input type="checkbox"/> Synchronization search | 593 |
| OPERATION | 595 |
| HYDRAULIC SYSTEM | 595 |
| <input type="checkbox"/> Fuel pipes | 595 |
| <input type="checkbox"/> Fuel pump | 596 |
| <input type="checkbox"/> Specifications | 596 |
| <input type="checkbox"/> Fuel filter | 597 |
| <input type="checkbox"/> Tightening torques | 597 |
| <input type="checkbox"/> High-pressure pump | 598 |

Page

| | |
|--|-----|
| <input type="checkbox"/> High-pressure pump internal structure | 600 |
| <input type="checkbox"/> Working principle | 601 |
| <input type="checkbox"/> Pressure regulator | 604 |
| <input type="checkbox"/> Replacing pressure regulator | 604 |
| MECHANICAL SUPPLY PUMP | 605 |
| <input type="checkbox"/> Hydraulic accumulator (rail) | 606 |
| ELECTRO-INJECTORS | 606 |
| <input type="checkbox"/> Operation | 606 |
| ELECTRIC/ELECTRONIC COMPONENTS | 607 |
| <input type="checkbox"/> Electronic control unit EDC 16 | 607 |
| <input type="checkbox"/> Glow plug electronic control unit | 607 |
| <input type="checkbox"/> Glow plugs | 607 |
| SENSORS | 607 |
| <input type="checkbox"/> Engine speed sensor | 607 |
| <input type="checkbox"/> Camshaft timing sensor | 607 |
| <input type="checkbox"/> Air temperature and pressure sensor | 608 |
| <input type="checkbox"/> Fuel temperature sensor | 608 |
| <input type="checkbox"/> Fuel pressure sensor | 608 |
| <input type="checkbox"/> Atmospheric pressure sensor | 608 |
| <input type="checkbox"/> Engine coolant temperature sensor | 608 |
| <input type="checkbox"/> Throttle pedal position sensor | 608 |
| <input type="checkbox"/> Clutch pedal position sensor | 608 |
| <input type="checkbox"/> Brake pedal position sensor | 608 |
| <input type="checkbox"/> Vehicle speed sensor | 608 |
| ACTUATORS | 608 |
| <input type="checkbox"/> PWM (Pulse Width Modulation) controls | 608 |
| TROUBLESHOOTING GUIDE | 609 |

MAIN OPERATIONS ON ENGINE MOUNTED ON VEHICLE



Keep to the following instructions before doing any work on the engine involving components of the fuel supply system.

- Before doing any work on the engine, perform the engine/vehicle fault diagnosis with specific IVECO diagnosis equipment and print out the results.
- Replacement of the MS6.3 or EDC 16 control unit must be authorized by the **Help Desk**.
- Following components in feed system cannot be overhauled but have to be replaced: pressure relief valve, if present, fuel pressure sensor, hydraulic accumulator, complete CPI high pressure feed pump, pressure control valve, electric injectors.
- All the parts of the Common Rail system are packaged by the supplier in sheets of oiled paper and are stored in cardboard boxes. They must therefore be protected against moisture and unpacked just prior to assembly.
- The greatest care must be taken over the cleanliness of parts, making sure that when handling or assembling (starting with straightforward filter and pre-filter replacement) no dirt or foreign bodies can get inside. For this reason, the plugs protecting the hydraulic parts and sensors must be removed just prior to positioning in their seats.
- Take care over the direction of assembly for all electrical connections.
- All threaded connections must be tightened to the prescribed torque.
- All the quick-coupling connectors (on the engine they are found on the high-pressure pump and on the diesel drain manifold) must be fully inserted. To drive them out, press on the tabs at the base of the connectors.

Electro-injector

None of the couplings/unions/nuts on the injector body may be handled. It is neither necessary nor permitted to dismantle the nozzle body or the electromagnet.

If working on the high-pressure pipe, the hexagon on the injector side must be kept stationary with a wrench.

Before working on pipes, make sure the injector is stationary in its seat on the cylinder head.

When assembling/disassembling the injector drain, the retaining spring must not be removed from its seat in the injector: pushing the spring towards the engine and applying a vertical force on the connector frees the recirculation. When assembling, rest the recirculation connector in its seat and apply a vertical force while keeping the retaining spring pressed in the direction of the engine. Fitting in has to be easy.

CP3 High-pressure pump

If working on the high-pressure pipe, the hexagon on the pump side must be kept stationary with a wrench.

Before working on the high-pressure pipe, make sure the pump is secured in its seat.

High-pressure pipes

Each high-pressure pipe must be replaced after disassembly operations.

The couplings must be tightened or loosened with the injectors, hydraulic accumulator (rail) and high-pressure pump well secured and taking care to keep the hexagon on the component side stationary, space permitting.

Hydraulic accumulator (rail) and accessories

The pressure sensor can be assembled five consecutive times; after that, it must be replaced.

They must be lubricated with a thin layer of oil before being mounted.

540110 ENGINE REMOVAL-REFITTING**Removal**

Place the vehicle in the pit or on an auto lift.

Lift engine hood (2), remove fastening screws (1), then remove hood (2).

Remove the supporting rod.

Disconnect negative cable (7) from battery (6).

Disengage cable (11) from the hood opening device.

Disconnect front headlamp electric connections (10 and 13).

Remove nuts (8), screws (9), then remove front cross-member (11) complete with the headlamps.


Remove cap (3) from expansion tank (4).

Carry out the following operations, from under the vehicle (see Figure 0/4):

- remove screws (15), and then take off central shelf (12);
- remove screws (8 and 10), then take off side guards (11).

Place a suitable container under radiator (14), remove plug (→), located on the right side of the radiator, then drain the engine coolant.

Figure 0/1



Loosen the straps, then remove air pipe (6) from heat exchanger (11) and (12), from the inlet manifold.

Loosen the straps, then disconnect the following coolant vent ducts: (22), from the cylinder head; (24), from radiator inlet pipe (8); (23), from radiator (10).

Loosen the straps, then disconnect the following coolant pipes: (13), from the heat exchanger; (28), from the thermostat body.

Remove screws (7) fastening air baffle (9) to radiator (10).

Remove screws (15) fastening radiator (10) to the supports. Disengage, from the left side, electric connection (16) supporting bracket (14).

Remove, by properly turning air baffle (9), radiator (10) complete with the heat exchanger, from the supports.

NOTE In case of vehicles equipped with cabin air-conditioner, proceed as follows:

- blow gas off the air-conditioning system, as described in the relevant chapter in the "Bodywork and chassis" section;
- disconnect the electric connection from the drying filter;
- disconnect the pipes from the condenser, and then seal the pipes and their respective fittings, to prevent moisture and impurities from penetrating into the system.

From water pump pipe (26), disconnect both expansion tank (17) pipe (25) and cabin heater pipe (1).

Disconnect the following electric connections: (19), from the pressure switch; (27), from level sensor (27) located on expansion tank (17).

Remove expansion tank (17) fastening nuts (18), and then take the expansion tank off the wall.


Remove oil filling plug (20), then take off sound-proofing cover (21).

Loosen the strap, then disconnect pipe (2) from its respective oil vapour recirculation pipe.

Loosen the straps, then remove air duct (4) both from turbocharger (3) and air filter (5).

NOTE As regards the engines equipped with variable-geometry turbochargers, properly plug the turbocharger air outlet, in order to prevent foreign bodies from getting into accidentally.

Figure 0/2



Disconnect vacuum pipe (3) from variable-geometry turbocharger actuator (2) (where available).

Cut the straps securing the wiring to the engine, then disconnect the following electric connections: VGT solenoid valve (6, where available), alternator (4), oil level sensor (7), engine revs sensor (8), electro-magnetic joint (9), coolant temperature sensors (22), phase sensor (10), electric injectors (26), air temperature sensor (23), pre-heating spark plugs (24), fuel pressure sensor (25), fuel pressure regulator (20), oil pressure sensor (16).

Remove the screw, and then take off earth cable (14).

Remove the nuts, and then remove the cables from starting motor (17).

Disconnect power brake vacuum pipe (15) from union (11), from the low-pressure fuel pipes, then disconnect both supply pipe (18) and return pipe (19).


Place a container under the power steering pump to recover the oil from the system, and then disconnect oil supply and delivery pipes (12 and 13).

Loosen the fastening strap, then remove power steering tank (2) from the support.

Apply tool 99360543 (27) to the brackets of the engine to remove the latter from its compartment, and then secure it to the hoist.

NOTE In case of vehicles equipped with cabin air-conditioning system, disconnect the cooling gas pipes from the compressor, then seal the pipes and their respective fittings on the compressor, to prevent moisture and impurities from penetrating into the system.

Figure 0/3



- Disconnect the screws (16 and 20) securing the brackets (17 and 19) and disconnect the "bowdens" (18 and 21) from the gearbox.
- Unscrew the fixing screws (22), move the clutch control cylinder (23), with its bracket, and fasten it to the chassis frame appropriately.
- Remove the sealing from the ring nut (1), unscrew it and disconnect the speedometer control cable.
- Disconnect the electrical connection (4) from the reversing light switch.
- Disconnect the exhaust pipe (9) from the turbocharger outlet pipe.
- Put a jack under the gearbox to support it.
- Disconnect the bracket supporting the gearbox on the rear crosspiece by undoing the four screws (5).
- Unscrew the fixing screws (6) and remove the crosspiece (7) supporting the gearbox complete with the gearbox/support bracket.
- Remove nuts (14) securing elastic supports (13) to the chassis.
- Remove bolts (3) securing drive shaft (2) to the gear shift. Remove, if necessary, screws (24) securing elastic support (25) to the chassis, then properly secure the drive shaft to the chassis.
- Take the jack out from under the gearbox.
- Lift the engine assembly and take it out of the engine bay.

NOTE The power unit must be removed from the engine compartment with the greatest care, to avoid damaging the remaining parts on the vehicle, in particular the steering box oil pipes.


If it is necessary to detach the gearbox from the engine, take out the fixing screws and remove the starter motor.

Take out the fixing screws and detach the gearbox from the engine.

Should this prove difficult, take the inspection cover off the front cover of the gearbox.

Using special pliers, open out the circlip retaining the thrust-bearing sleeve to the clutch plate while detaching the gearbox from the engine.

Figure 0/4





Refitting

To refit the engine assembly, carry out the operations described for removal in reverse order, following these instructions:

- Before refitting the gearbox to the engine, it is necessary to remove the pressure plate bearing from the diaphragm spring by opening out the retaining circlip. Fit the pressure plate bearing on the sleeve of the drive input shaft cover, connecting it to the clutch release lever. Spread the gearbox input shaft with Molikote molybdenum disulphide grease. Engage a gear to let the main shaft turn, rotating the propeller shaft connecting flange. Push the gearbox fully in so that the pressure plate bearing couples with the diaphragm spring correctly.
- Pay special attention to the operations needed to install the engine assembly in the engine bay.
- Check the conditions of the coolant pipes or sleeves and of the air ducts. Replace them if they show any sign of deterioration.
- Check the flexible mountings of the assemblies: engine and gearbox. Replace them if they show any sign of deterioration.
- Check that the exhaust pipe members have not deteriorated and are not about to deteriorate. If this is so, replace them along with the flexible parts for securing them.
- Tighten the screws or nuts to the required torque.
- Meticulously check the state of the vacuum pipe. It must show no sign of cracking, cutting, scoring or of being crushed. Replace it if there is any doubt at all about its soundness. When mounting it, make sure the pipe does not come into contact with sharp metal parts or corners or with any particularly hot parts. In addition, after assembly, the pipe must have no bends or constrictions, its radius of curvature should be broad and it must be secured to the vacuum pump fitting with a suitable clamp.
- Make sure the quick-coupling fittings of the fuel pipes are thoroughly clean and, after connection to the relevant high-pressure pump unions or fuel filter mount, are fully inserted and do not come loose.
- Fill the cooling system with coolant.
- Fill the hydraulic power steering circuit and bleed the air as described under the relevant heading.
- Check the level of oil in the engine and gearbox.
- Recharge the air-conditioning system (if any), as described in the relevant chapter in the "Bodywork and chassis" section.

NOTE When positioning the engine in the engine bay, take special care not to damage the top pipe of the power steering and the soundproof-heatproof cladding of the engine bay. Once positioned, meticulously check that the top pipe of the power steering is sound. Before using it again, check that the power steering oil and coolant contain no impurities. If they do, filter with suitable mesh filters. For any topping up, refer to the REPLENISHING FLUIDS table in the "GENERAL" section.

Checks and tests



Start up the engine, leave it running just a little faster than idling speed and wait for the coolant temperature to reach the value for opening the thermostat, then check that:



- No water leaks from the connecting sleeves of the engine cooling and cab heating circuit pipes; tighten the collars if necessary.
- No oil leaks from between the cover and cylinder head, oil sump and crankcase, oil filter and its seat, heat exchanger and crankcase or from between the various pipes of the lubricating circuit.
- No fuel leaks from injection pump and injector lines. Tighten fittings if necessary.
- Check the indicator and warning lights on the instrument panel and the devices disconnected on removing the engine all work properly.



501430 Power steering system air bleed

Check the level of oil in the tank and top it up if necessary. Lift the vehicle at the front, start up the engine and let it idle for some time.

Check there is no oil leakage from the hydraulic circuit and check the level in the tank.


Slowly turn the steering wheel in both directions of steering so that the air in the hydraulic system comes out.

Check the level of oil in the tank again and top up if necessary.

543910 REPLACING AIR-CONDITIONING COMPRESSOR DRIVE BELT (VERSION WITH BELT TENSIONER)

Disassembly

Figure 0/5



Place the vehicle in a pit or on an auto lift. Remove, from under the vehicle, the central sound-proofing guard. Remove elastic belt (4) from pulleys (1 and 5).

Assembly


Apply wedge 99360161 (2) with elastic belt (4) to pulley (1), then place the elastic belt onto roller (3) and pulley (5), taking care to place the pulley ribs in the corresponding races of pulleys (1 and 5).

Rotate the drive shaft counterclockwise (→) until belt (4) is correctly coupled with pulley (1).

543910 POWER STEERING PUMP-ALTERNATOR BELT REPLACEMENT

Disassembly

Figure 0/6



Disassemble the compressor drive belt, if there is one, as described under the relevant heading. Slacken off the tension of the belt (1) using a specific wrench on the automatic tightener (2) and remove the belt.

Assembly


Mount the drive belt (1) taking care to position its ribs correctly in the respective races of the pulleys. Release the automatic tightener (2). Turn the crankshaft by one turn to settle the belt.

Mount the compressor drive belt, if there is one, and adjust the tension as described under the relevant heading. Fit the middle soundproofing guard back on.

543210 REPLACING THE WATER PUMP

Removal

Figure 0/7



Drain the cooling fluid, and then remove both the front cross-member and the radiator, as described in the "Power unit detachment/re-attachment" chapter.

Take the fan off the electro-magnetic joint.

Remove electric connection (3) from the engine cable.

Stop rotation of electro-magnetic joint (6), then remove nut (8).

NOTE Unscrew nut (8) in a clockwise direction, since the nut thread goes leftwards.

Take off hub (6) and pulley (5).

Cut the strap (→), remove electric cable (3) retaining strap fastening screw (1), remove nuts (2), then take electro-magnet (4) off water pump (7).

Remove the fastening screws, and then take off water pump (7).

Refitting


Re-attachment is carried out by reversing the order of detachment operations. In particular, tighten the screws and nuts to the specified torque values.

After re-attachment has been completed, fill the engine cooling system, start the engine and check for cooling fluid leaks.

771010 REPLACING THE HIGH-PRESSURE PUMP

Removal

Figure 0/8



102203

Remove plug (2), then take cover (1) off the cylinder head. Loosen the straps, then remove air duct (3) both from the inlet manifold and the heat exchanger.

Use tool 99360076 to take oil filter (4) off the heat exchanger.

Remove the electric connection from pressure regulator (15).

Remove fittings (9, 11 and 13), then disconnect low-pressure pipes (5, 12, 14 and 16) from high-pressure pump (10).

Remove pipe (6) retaining bracket (8) fastening screw (7), and then disconnect the pipe both from hydraulic accumulator (17) and high-pressure pump (10).

Remove screws (21), and then take high-pressure pump (10) off support (18). Remove joint (19).

Refitting



Re-attachment is carried out by reversing the order of detachment operations. In particular, comply with the following instructions:



replace the seal rings, gaskets, high-pressure pipe and oil filter with new parts;



lubricate, prior to assembling, seal ring (20) with engine oil;




tighten the screws, nuts, fittings and oil filter to the specified torque value;

check the engine oil level; top up, if necessary.

501450 REPLACING THE POWER STEERING PUMP

Removal


Figure 0/9



102204

Remove oil filling plug (1) from oil tank (2).
 Remove, from under the engine compartment, the central sound-proofing guard.
 Place a container under power steering pump (6) to recover the oil from the system, and then remove fittings (3 and 8) and disconnect oil pipes (4 and 7) from power steering pump (6).

Figure 0/10



102205

Remove screws (6) and take power steering pump (5) off support (4). Remove joint (2) from drive arbor (3).

Refitting



Re-attachment is carried out by reversing the order of detachment operations. In particular, take care of the following:



- replace seal ring (1) with a new part, and lubricate the same with engine oil prior to assembling;



- replace the oil pipe gaskets (as above);
- tighten the nuts, screws and fittings to the specified torque values.




After re-attachment has been completed, fill the hydraulic power steering circuit and bleed the air as described under the relevant heading.

540440 REPLACING THE DRIVE SHAFT SEAL RING AND THE FRONT COVER GASKET

Removal

Figure 0/11




102206

Proceed as follows, by operating as described in the "Power unit detachment/re-attachment" chapter:

- drain the engine cooling fluid;
- remove the front cross-member;
- remove the radiator.

Remove fan (1) from the electro-magnetic joint.
 Take off the air-conditioning compressor drive belt (if any) as well as the water pump-alternator drive belt, as described in the relevant chapters.

Figure 0/12




102207

Use tool 99360190 (3) to stop drive shaft rotation, then remove screw (2) and take off damper pulley (1).

Apply tool 99340059 (6) as shown in the figure to remove seal ring (5) from cover (4).

Figure 0/13



102209


Remove screw (11), and then take off dipstick pipe (4). Loosen strap (3), remove screw (2), then take pipe (1) off cover (5). Remove screws (6), and then take off cover (5). Remove snap ring (8). Take out centrifugal filter (7).

NOTE Both centrifugal filter (7) and cover seal ring (5) must be replaced every time they are dismantled.

Remove screws (9), and then take off front cover (10).

Refitting


Figure 0/14



102214

Mount cover (1) with a new gasket. Screw down screws (2) without tightening them up.


Figure 0/15



102215

Thoroughly clean cover (1) seal ring seat. Screw down part (2) of tool 99346258 into the drive shaft shank. Lubricate the drive shaft shank and the outside of part (2), then couple the new seal ring (3) with part (2). Place part (4) onto part (2), screw down nut (5) until seal ring (3) is fully assembled to cover (1).


Figure 0/16



102216

Fit cover (1) centring tool 99396030 (3) into the centrifugal filter seat, then tighten screws (2) to the specified torque. Remove tools 99346258 (4) and 99396039 (3).

Figure 0/17



102217

Fit a new centrifugal filter (1).
 Fit a new snap ring (2).
 Fit cover (3), and then tighten screws (4) to the specified torque.

NOTE Both centrifugal filter (1) and cover (3) seal ring must be replaced every time they are dismantled.

Re-attachment is carried out by reversing the order of detachment operations. In particular, tighten the screws and nuts to the specified torque values.


After re-attachment has been completed, fill the engine cooling system, check the engine oil level (top up, if necessary), start the engine and check for cooling fluid leaks.

503010 REPLACING THE VACUUM PUMP OIL PUMP ASSEMBLY (GPOD)

Removal

Remove the front cover, as described in the "Replacing the drive shaft seal ring and the front cover gasket" chapter.

Figure 0/18



102218

Remove screws (3), and then take off vacuum pump oil pump assembly (2).

Remove connecting joint (1) from gear (4).

Refitting



Position connecting joint (1) into gear (4).



Fit vacuum pump oil pump assembly (2) by placing a new gasket in between.



Tighten screws (3) to the specified torque.



Re-attachment is carried out by reversing the order of detachment operations. In particular, tighten the screws and nuts to the specified torque values.

After re-attachment has been completed, fill the engine cooling system, start the engine and check for cooling fluid leaks.

540640 REPLACING THE DRIVE SHAFT REAR SEAL RING


Removal



This operation involves:

- detaching/re-attaching the drive shafts (see relevant section 505620);
- detaching/re-attaching the gear shift (see relevant section 530210);
- detaching/re-attaching the clutch (see relevant section 505210).



Figure 0/19



102219

Stop flywheel (1) rotation by means of tool 99360306 (4). Remove screws (2), and then take off engine flywheel (1).

Figure 0/20





102220

Apply tool 99340060 (2) to rear seal ring (1), then take the latter out of the engine base.

Refitting


Figure 0/21



102221

Thoroughly clean the seal ring seat. Lubricate the drive shaft rear shank with engine oil. Apply part (2) of tool 99346259 to the drive shaft rear shank, then secure it with screws (5) and couple the new seal ring (3) with the same. Place part (1) onto part (2), screw down nut (4) until seal ring (3) is fully assembled to the base.

Figure 0/22



102222

Fit engine flywheel (1), then tighten screws (4). Apply tool 99360351 (3) to the base in order to stop engine flywheel (1) rotation. Tighten engine flywheel (1) fastening screws (4) in two separate steps:

- step 1: tighten to 30 Nm by means of a torque wrench;
- step 2: tighten to 90° angle lock.


NOTE Angle lock is performed by means of tool 99395216 (2).

Disassemble tool 99360351 (3).

Then fit the clutch, gear shift and drive shaft back into position, as described in the relevant sections.

775010 REPLACING ELECTRO-INJECTORS

Figure 0/23



102223

**Removal**

Disconnect the following electric connections: (4), from the pressure sensor, and (2), from the level sensors, both of them located on expansion tank (1).

Remove nuts (3) securing expansion tank (1) to the wall, then put the expansion tank aside.

Remove plug (6), and then take off sound-proofing cover (5).

Disconnect electric connections (7) from electric injectors (16) and (9) from fuel pressure sensor (8).

Press clips (15) in the direction shown by the arrow, then disconnect fuel recovery pipe (14) fittings from electric injectors (16).

Disconnect fuel pipes (11) from electric injectors (16) and hydraulic accumulator (10).

Remove screws (12) and brackets (13) securing electric injectors (16) to the cylinder head.

Use tool 99342153 (17) to take electric injectors (16) off the overhead.

**Refitting**

Thoroughly clean the electric injector seat, taking care not to introduce foreign bodies into the cylinder liners.


Fit a new gasket (18) onto electric injector (16), and then fit the latter into the overhead.

Re-attachment is carried out by reversing the order of detachment operations. In particular, comply with the following instructions:

- fuel pipes must be replaced with new parts every time they are disassembled;
- tighten the nuts, screws and fittings to the specified torque values;
- to tighten the fuel pipe fittings, use a wrench of the 99317915 series as well as torque wrench 99389829.

540610 DETACHING/RE-ATTACHING THE CYLINDER HEAD

Figure 0/24



102224



Removal

Proceed as follows, by operating as described in the "Power unit detachment/re-attachment" chapter:

- drain the cooling fluid;
- remove the front cross-member;
- remove the expansion tank.

Cut the straps that secure the wiring to the engine, then disconnect the following electric connections:

- (13) thermostat;
- (18) pre-heating spark plugs;
- (21) pressure sensor;
- (22) electric injectors;
- (1) electro-magnetic joint;
- (23) phase sensor;
- (10) pressure regulator;
- (16) air temperature sensor.

Remove the electric injectors, as described in the relevant chapter. Remove screw (15), and then take fuel pipe (17) off high-pressure pump (11) and hydraulic accumulator (19). Remove the fastening screws, and then take off hydraulic accumulator (19).

Use tool 99360076 to remove the oil filter from the heat exchanger.

Remove bracket (12) securing the low-pressure pipe assembly to the inlet manifold.

Remove screws, and then take oil vapour pipe (6) off the cylinder head.

Remove the screw, and then take cooling fluid pipe (2) securing strap (8) off bracket (7).

Remove air baffle (3) from the overhead, turbocharger (4) and pipe (6).

Disconnect oil pipe (9) from the fitting on the cylinder head.

Remove nuts (5), and then disconnect turbocharger (4) from the exhaust manifold.


NOTE Properly plug the turbocharger air outlet/inlet, to prevent foreign bodies from penetrating accidentally into the turbocharger (and, therefore, damaging the same).

Remove the fan from the electro-magnetic joint.

Take off the air-conditioning compressor drive belt (if any) as well as the water pump-alternator drive belt, as described in the relevant chapters.

Remove the front cover, as described in the "Replacing the seal ring and the front cover gasket" chapter".

Figure 0/25



102225

Remove the screws, and then take upper cover (2) off overhead (19).

Remove plugs (20) from overhead (19).

Rotate the drive shaft clockwise, so that pins 99360614 (13) can be inserted, through the holes of plugs (20), into the corresponding holes of the drive shafts, and pin 99360615 (5) can be inserted into the drive shaft through the base unit hole.

Remove upper chain stretcher (1).

Remove pin (4), then take off upper shoe (3).

Remove both screw (17) and washer (16), and then disassemble gear (15).

Remove both screw (10) and washer (11), then disassemble gear (12) and chain (14).

Remove both plug (6) and screws (7 and 8), then disassemble fixed upper shoe (9).

Remove screws (18), then take off overhead (19) complete with pins 99360614 (13).

NOTE Pins 99360614, applied in order to avoid modifying timing after the toothed chain has been disassembled, must be removed from the overhead only when the latter has been disassembled.

Remove the overhead gasket.

Remove the tappets and put them apart carefully.

Remove the pre-heating spark plugs by means of tool 99355041.

Remove the cylinder head fastening screws, and then take the head off the base unit.

Remove the cylinder head gasket.

Refitting



Unless otherwise specified, re-attachment is carried out by reversing the order of detachment operations. In particular, comply with the following instructions:

Verify the conditions listed below, which refer to the tools used for valve timing:

- tool 99360614 (6, Figure 0/25) must be inserted into the overhead;
- tool 99360615 (11, Figure 0/25) must be inserted into the base unit.

Verify that the junction planes of the cylinder head and the base unit are clean.

Do not soil the cylinder head gasket.


Place the cylinder head gasket with the "TOP" writing facing the head itself.

NOTE The gasket must strictly be kept sealed in its own package and be unwrapped soon before being fitted.

Fit the cylinder head, insert the screws and tighten up in three subsequent steps, by following the sequence and indications shown in the next figure.

NOTE Angle lock is carried out by means of tool 99395216.

Figure 0/26




88355

Cylinder head fastening screw tightening sequence:

- step 1: preliminary tightening by means of a torque wrench:
 - tighten screws 1-2-3-4-5-6 to 130 Nm;
 - tighten screws 7-8-9-10 to 65 Nm.
- step 2: angle locking:
 - tighten screws 1-2-3-4-5-6 to 90°;
 - tighten screws 7-8-9-10 to 90°.
- step 3: angle locking:
 - tighten screws 1-2-3-4-5-6 to 90°;
 - tighten screws 7-8-9-10 to 60°.
- Tighten screws A to 25 Nm.

Figure 0/27




102226

Thoroughly clean hydraulic tappets (2), then lubricate and fit them to cylinder head (3), by correctly positioning rocker arms (1) on the valves.

Fit gasket (5).

Insert the two tools Sp. 2264 (4) into the electric injector seats for subsequent overhead centring on the cylinder head.

Figure 0/28




102273

Fit overhead (1) complete with tools 99360614 (3) for valve timing, then tighten fastening screws (2) to the specified torque.

Remove tools Sp. 2264 (4).

Figure 0/29




88270

Fit fixed upper shoe (1). Tighten screws (2 and 3) to the specified torque.

Fit plug (4) together with a new basket, then tighten it to the specified torque.

Figure 0/30




Place chain (1) on gear (5) and on gear (2).
Fit the gear in such a way that when it is inserted onto the dowel bolt of the intake valve distributing shaft, slots A will be positioned as shown in the figure.

102229

NOTE The chain (1) branch included between the two gears must be subjected to tension.

Screw down fastening screw (4) with washer (3) without tightening up.


Figure 0/31



Place chain (1) on gear (2), then fit the latter onto the exhaust valve distributing shaft.
Screw down fastening screw (4) with washer (3) without tightening up.

88359


Figure 0/32



Check the conditions of moving shoes (1 and 3), and replace them if they are worn. Position moving shoes (1 and 3), then secure them to the base unit with pin (2) by tightening the latter to the specified torque.

102231

Figure 0/33




NOTE Chain stretcher (1) cannot be re-used for any reason after it has been disassembled. Moreover, in the event that piston (1) has been unintentionally made to escape from chain stretcher (2), the latter must be replaced.
Chain stretcher reconditioning is not permitted.

102127

Screw down hydraulic chain stretcher (2), then tighten it to the specified torque.


Insert, through the opening on the overhead, a suitable screwdriver, then press on moving shoe (4) fin (3) until chain stretcher (2) piston (1) is pushed to its end of stroke. Release moving shoe (4), and make sure that piston (1) causes, by escaping from its seat, chain (5) to be subjected to tension.

Figure 0/34



Tighten the screw securing gear (1) to the intake valve distributing shaft to the specified torque.

Figure 0/35




Make sure that chain (3) is subjected to tension in the length included between gear (2) and gear (4).
Tighten the screw securing gear (2) to the exhaust valve distributing shaft to the specified torque.
Remove tools 99360614 (1) and 99360615 (5, Figure 0/25).

Re-attachment is carried out by reversing the order of detachment operations. In particular, comply with the following instructions:

- replace the seal rings, gaskets, safety snap rings and high-pressure pipes with new parts;
- lubricate the seal rings with engine oil prior to assembling;
- tighten the screws, nuts and pipe fittings to the specified torque values;
- check the engine oil level; top up, if necessary;
- fill the engine cooling system, start the engine, and check for cooling fluid leaks.


ENGINE VIEWS

Figure 1



87237


Figure 2



102128

LEFT-HAND SIDE VIEW


Figure 4



102130

FRONT VIEW


Figure 3



102129

REAR VIEW

Figure 5




102131

RIGHT-HAND SIDE VIEW

A. Turbocharger with pressure relief valve (Waste-Gate, ENGINE I 36 HP)

Figure 6



102132

TOP VIEW

ENGINE IDENTIFICATION CODE






Figure 7



88683

Figure 8




88684

| | EXAMPLE |
|--|------------------|
| A = IVECO trademark | IVECO |
| B = IVECO name of engine variant ** | F1CE0481A * A001 |
| C = Engine serial number | 1359862 |
| D = 1 st digit, main journal no. 1 (engine front) | |
| E = Main bearing selection diameters | 12345 |
| F = Barrel selection diameters | 1234 |
| G = 1 st digit, cylinder no. 1 (engine front) | |

(**) Data obtainable from "XZ" engine ordering number information


Figure 9



102123

LONGITUDINAL SECTION


Figure 10



102125

FICE0481A ENGINE CYLINDER AXIS CROSS SECTION (136 HP)


Figure 10/1



102124

FICE0481A ENGINE SUPPORT AXIS CROSS SECTION (136 HP)

Figure 10/2




102126

FICE0481B ENGINE CROSS SECTION (166 HP)

CHARACTERISTIC CURVES

Figure 11

136 HP



88237

CHARACTERISTIC CURVES OF ENGINE FICE0481 A (136 HP)

Max OUTPUT 100 kW

136 HP

at 3500 rpm


Max TORQUE 340 Nm

34.6 kgm

at 1400 ÷ 2800 rpm

Figure 12

166 HP



88238

CHARACTERISTIC CURVES OF ENGINE FIC E0481 B (166 HP)

Max OUTPUT 122 kW

166 HP












at 3500 rpm

Max TORQUE 380 Nm









38.7 kgm






at 1250 ÷ 3070 rpm

GENERAL SPECIFICATIONS













|  | | Type | FICE048I A | FICE048I B |
|---|---|--------------------|-------------------------------|------------------------------|
|  | Cycle | | Diesel 4 strokes | |
| | Feeding | | Turbocharged with intercooler | |
| | Injection | | Direct | |
|  | N. of cylinders | | 4 on-line | |
|  | Diameter | mm | 95.8 | |
|  | Stroke | mm | 104 | |
|  | Total displacement | cm ³ | 2998 | |
|  | Max. power | KW (HP) | 100 (136) | 122 (166) |
| | | rpm | 3500 | 3500 |
|  | Torque at 1000 rpm | Nm | 240 | 250 |
| | Max. power | Nm (kgm) rpm | 340 (34.5) 1400 ÷ 2800 | 380 (38.7) 1250 ÷ 3070 |
|  | Engine idling speed, no load | rpm | 850 ± 25 | |
|  | Maximum engine speed, no load | rpm | 4200 ± 50 | |
|  | Pressure at T.D.C. | *bar | 20 ÷ 26 | |
| | Minimum permissible pressure at T.D.C. | *bar | 16 | |














(*) The pressure value is recorded by turning the engine over with the electric starter motor, with oil temperature at 40°- 50°C and the injection pump in the stop condition.












|  | Type | FICE048I A | FICE048I B |
|---|---|---|-------------------------------------|
|  | <p>VALVE TIMING</p> <p>opens before T.D.C. A</p> <p>closes after B.D.C. B</p> <p>opens before B.D.C. D</p> <p>closes after T.D.C. C</p> | <p>24°</p> <p>26°</p> <p>70°</p> <p>24°</p> | |
|  | <p>For timing check</p> <p>Running</p> | <p>X mm</p> <p>X mm</p> <p>X mm</p> <p>X mm</p> | <p>-</p> <p>-</p> <p>-</p> <p>-</p> |
|  | FEED | <p>High pressure electronic fuel feed system BOSCH EDC16 Composed of CP3.2 high-pressure pump, electro-injectors, hydraulic accumulator (rail), EDC control unit, pressure and temperature sensors</p> | |
|  | <p>Pump arrangement With piston n. 1 at T.D.C.</p> <p>Start of delivery</p> | <p>mm</p> | <p>-</p> <p>-</p> |
|  | BOSCH injector nozzle type | | |
|  | <p>Injection order</p> <p>- injection pump</p> <p>- engine</p> | <p>1- 3 - 4 - 2</p> | |
|  | Release pressure | bar | 1350 |

























|  | | Type | FICE048I A | FICE048I B |
|---|-----------------------------------|-------------------|--|--|
|  | | SUPERCHARGING | With intercooler | |
| Turbocharger type: | | | MITSUBISHI TD 04 - HL - 13T-6 with Waste-Gate | GARRETT GT 2260 V variable geometry |
| Turbocharger shaft radial clearance | | | 0.396 ± 0.602 | 0.086 ± 0.117 |
| Turbocharger shaft axial clearance | | | 0.034 ± 0.106 | 0.030 ± 0.083 |
| Minimum opening stroke of pressure relief valve | | mm | 1 | - |
| Maximum opening stroke of pressure relief valve | | mm | 5 | - |
| Pressure corresponding to the minimum stroke | | bar | 1.21 ± 0.0026 | - |
| Pressure corresponding to the maximum stroke | | bar | 1.45 ± 0.0039 | - |
| Actuator setting: | | | | |
| - low pressure | 0 mmHg | valve fully open | | |
| - low pressure | 180 mmHg | valve stroke | | 2.5 |
| mm | | | | 10.5 |
| - low pressure | 500 mmHg | valve stroke | | 11 ÷ 12.4 |
| mm | | | | |
| - valve fully shut | valve stroke | mm | | |
|   | | LUBRICATION | Forced feed by gear pump, relief valve, dual action oil filter | |
| Oil pressure with engine hot (100 ± 5 °C): | | | | |
| at idling speed | | bar | 0,1 | |
| at maximum speed | | bar | 5,0 | |
| COOLING | | | by centrifugal pump, thermostat for adjustment, coolant temperature, fan with electromagnetic coupling, radiator, heat exchanger | |
| Water pump control: | | | by belt | |
| Thermostat: | | | N. I. | |
| starts to open: | | | 79 ± 2 °C | |
| fully open: | | | 94 ± 2 °C | |
|  | Urania Daily Urania Turbo LD 5 | OIL REPLENISHMENT | | |
| Total capacity at 1st filling | | liters | 7.6 | |
| | | kg | 6.79 | |
| Quantity at periodical replacements: | | | | |
| - engine sump | | liters | 6.6 | |
| | | kg | 5.81 | |













ASSEMBLY DATA – CLEARANCES

|  | Type | FICE048I A | FICE048I B |
|---|--|------------|---|
| CYLINDER BLOCK AND CRANK MECHANISM COMPONENTS | | | |
| mm | | | |
|  | Cylinder liners: Ø 1 | | 95.802 ÷ 95.822 |
|  | Cylinder liners: outside diameter Ø length L | | - - - |
|  | Cylinder liners – crankcase seats (interference) | | - |
|  | Outside diameter Ø 2 | | - |
|  | Cylinder liners: (protrusion from bottom of crankcase) inside diameter Ø 3 | | - - |
|  | Pistons: supplied as spares type measurement X outside diameter Ø 1 seat for pin Ø 2 | | MAHLE 58 95.591 ÷ 95.605 36.003 ÷ 36.009 |
|  | Piston – cylinder liners | | 0.197 ÷ 0.231 |
|  | Piston diameter Ø 1 | | 0.4 |
|  | Piston protrusion from crankcase X | | 0.3 ÷ 0.6 |
|  | Piston gudgeon pin Ø 3 | | 35.990 ÷ 35.996 |
|  | Piston gudgeon pin – pin seat | | 0.07 ÷ 0.019 |

|  | Type | FICE048I A | FICE048I B |
|---|---|-----------------|-----------------|
| CYLINDER BLOCK AND CRANK MECHANISM COMPONENTS | | | |
| | | mm | |
| | Piston type | | - |
|  | Piston ring grooves | X1* | 2.200 ÷ 2.230 |
| | | X2 | 2.050 ÷ 2.070 |
| | | X3 | 2.540 ÷ 2.560 |
| * measured on \varnothing of 92.8 mm | | | |
|  | Anelli elastici | S 1* | 2.068 ÷ 2.097 |
| | Piston rings | S2 | 1.970 ÷ 1.990 |
| | | S3 | 2.470 ÷ 2.490 |
| * measured at 1.5 mm from outer \varnothing | | | |
|  | Piston rings - grooves | 1 | 0.103 ÷ 0.162 |
| | | 2 | 0.060 ÷ 0.100 |
| | | 3 | 0.050 ÷ 0.090 |
|  |  > | Piston rings | 0.4 |
|  | Piston ring end gap in cylinder liners | X1 | 0.20 ÷ 0.35 |
| | | X2 | 0.60 ÷ 0.80 |
| | | X3 | 0.30 ÷ 0.60 |
|  | Small end bush housing | \varnothing 1 | 39.460 ÷ 39.490 |
| | Big end bearing housing | \varnothing 2 | 67.833 ÷ 67.848 |
|  | Small end bush diameter | | |
| | outside | \varnothing 4 | 39.570 ÷ 39.595 |
| | inside | \varnothing 3 | 36.010 ÷ 36.020 |
| | Big end bearing shell supplied as spare parts | S | |
| | superior | S | 1.883 ÷ 1.892 |
| inferior | S | 1.885 ÷ 1.891 | |
|  | Small end bush - housing | | 0.08 ÷ 0.135 |
|  | Piston pin - bush | | 0.014 ÷ 0.030 |
|  |  > | Piston rings | 0.254 - 0.508 |

|  Type | FICE048I A | FICE048I B |
|---|--------------------------------------|--|
| CYLINDER ASSEMBLY AND CRANK MEMBERS | | |
| mm | | |
|  Measurement X Maximum error on alignment of connecting rod axes = | 125 | 0.09 |
|  Main journals No. 1-2-3-4 No. 5 Crankpins Main bearing shells Big end bearing shells - superior - inferior * supplied as spare parts | Ø 1 Ø 2 S1* S2* | 76.182 ÷ 76.208 83.182 ÷ 83.208 64.015 ÷ 64.038 2.165 ÷ 2.174 1.883 ÷ 1.892 1.885 ÷ 1.891 |
|  Main bearing housings No. 1-2-3-4 No. 5 | Ø 3 Ø 3 | 80.588 ÷ 80.614 87.588 ÷ 87.614 |
|  Bearing shells - main journals | | 0.032 ÷ 0.102 |
|  Bearing shells - crankpins | | 0.035 ÷ 0.083 |
|  Main bearing shells Big end bearing shells | | 0.254 ÷ 0.508 0.254 ÷ 0.508 |
|  Main journal for shoulder X 1 | X 1 | 32.500 ÷ 32.550 |
|  Main bearing housing for shoulder X 2 | X 2 | 27.240 ÷ 27.290 |
|  Half thrust washers X 3 | X 3 | 32.310 ÷ 32.460 |
|  Crankshaft shoulder | | 0.040 ÷ 0.240 |

|  Type | FICE048I A | FICE048I B |
|---|--|------------|
| CYLINDER HEADS - VALVE GEAR mm | | |
|  Valve guide housings in the cylinder heads $\varnothing 1$ | 9.980 \pm 10.000 | |
|  Valve guide $\varnothing 2$ $\varnothing 3$ | 6.023 \pm 6.038 10.028 \pm 10.039 | |
|  Valve guides and seats on head (interference) | 0.028 \pm 0.059 | |
|   Valve guide | 0.05 - 0.10 - 0.25 | |
|  Valves: <div style="display: inline-block; vertical-align: middle; margin-left: 20px;">  $\varnothing 4$ α </div> <div style="display: inline-block; vertical-align: middle; margin-left: 20px;">  $\varnothing 4$ α </div> | 5.985 \pm 6.000 60° \pm 7.5' 5.975 \pm 5.990 60° \pm 7.5' | |
|  Valve stem and its guide | 0.023 \pm 0.053 | |
|  Seat on head for valve seat: <div style="display: inline-block; vertical-align: middle; margin-left: 20px;">  $\varnothing 1$ </div> <div style="display: inline-block; vertical-align: middle; margin-left: 20px;">  $\varnothing 1$ </div> | 34.490 \pm 34.515 34.490 \pm 34.515 | |
|  Outside diameter of valve seats; angle of valve seats on cylinder head: <div style="display: inline-block; vertical-align: middle; margin-left: 20px;">  $\varnothing 2$ α </div> <div style="display: inline-block; vertical-align: middle; margin-left: 20px;">  $\varnothing 2$ α </div> | 34.590 \pm 34.610 59.5° \pm 5' 34.590 \pm 34.610 59.5° \pm 5' | |
|  Recessing | <div style="display: inline-block; vertical-align: middle; margin-right: 20px;">  </div> 0.375 \pm 0.525 <div style="display: inline-block; vertical-align: middle; margin-right: 20px;">  </div> 0.375 \pm 0.525 | |
|  Between valve seat and head | <div style="display: inline-block; vertical-align: middle; margin-right: 20px;">  </div> 0.075 - 0.12 <div style="display: inline-block; vertical-align: middle; margin-right: 20px;">  </div> 0.075 - 0.12 | |
|   Valve seats | - | |

|  | Type | FICE048I A | FICE048I B |
|---|---|--|---|
| CYLINDER HEAD – TIMING SYSTEM | | mm | |
|  | Valve spring height: free spring H under a load of: N243 ± 12 H1 N533 ± 24 H2 | | 54 45 35 |
|  | Injector protrusion X | | 2.77 ÷ 3.23 |
|  | Seats for tappets on cylinder head normal Ø | | 12.016 ÷ 12.034 |
|  | Normal diameter tappets | | 11.988 ÷ 12.000 |
|  | Between tappets and seats | | 0.016 ÷ 0.046 |
|  | Camshaft pin seats in cylinder overhead l ⇒ 7 | Ø 1 Ø 2 Ø 3 | 48.988 ÷ 49.012 46.988 ÷ 47.012 35.988 ÷ 36.012 |
|  | Camshaft supporting pins: | Ø 1 Ø 2 Ø 3 | 48.925 ÷ 48.950 46.925 ÷ 46.950 35.925 ÷ 35.950 |
|  | Supporting pins and seats | | 0.032 ÷ 0.087 |
|  | Useful cam height |  H  H | 3.622 4.328 |

TOOLS

| TOOL NO. | DESCRIPTION |
|-----------------|--|
| 99305047 | Appliance to check spring loads |
| 99317915 | Set of six box-type wrenches (14-17-19 mm) |
| 99322205 | Rotary telescopic stand for overhauling assemblies (capacity 700 daN, torque 120 daN/m) |
| 99340059 | Extractor for camshaft pulley |
| 99340060 | High-pressure pump toothed pulley extractor |
| 99342153 | Tool to remove crankshaft front gasket |







TOOLS

| TOOL NO. | DESCRIPTION |
|-----------------|---|
| 99346258 | Keying device for mounting crankshaft front gasket |
| 99346259 | Keying device for mounting crankshaft rear gasket |
| 99358026 | Wrench for alternator pulley (free wheel) removal/refitting |
| 99360076 | Tool to remove cartridge filters |
| 99360183 | Pliers for mounting rings on engine pistons |
| 99360186 | Guide for flexible belt |

TOOLS

| TOOL NO. | DESCRIPTION |
|-----------------|--|
| 99360187 | Retaining tool for hydraulic power steering control shaft |
| 99360190 | Damper pulley retaining tool |
| 99360260 | Tool for removing and refitting engine valves |
| 99360306 | Tool to retain engine flywheel |
| 99360543 | Swing bar for engine detachment/re-attachment |
| 99360605 | Band to insert standard and oversized pistons into the cylinders |





TOOLS

| TOOL NO. | DESCRIPTION |
|---|---|
| 99360614 | Tool (2) for camshaft timing |
|  | |
| 99360615 | Tool for crankshaft timing |
|  | |
| 99361041 | Brackets securing engine to rotary stand 99322205 |
|  | |
| 99367121 | Manual pump to measure pressure and vacuum |
|  | |
| 99370415 | Dial-gauge base for various measurements (to be used with 99395603) |
|  | |
| 99389817 | Dynamometric wrench (60 ÷ 320 Nm) with 3/4" coupling |
|  | |

TOOLS


| TOOL NO. | DESCRIPTION |
|-----------------|--|
| 99389818 | Dynamometric wrench (150-800 Nm) with 3/4" square coupling |
| 99389819 | Torque wrench (0-10 Nm) with square 1/4" connection |
| 99389829 | 9x12 coupling torque wrench (5-60 Nm) |
| 99394038 | Milling cutter to regrind injector seat (8140.63 engine excluded) |
| 99395216 | Pair of meters for angular tightening with square 1/2" and 3/4" connection |
| 99395363 | Complete square to check for connecting rod distortion |

TOOLS

| TOOL NO. | DESCRIPTION |
|---|--|
| 99395603 | Dial gauge (0-5 mm) |
|  | |
| 99395687 | Bore meter (50 – 178 mm) |
|  | |
| 99395849 | Belt tension control device (frequency from 10.0 bis 600 Hz) |
|  | |
| 99396039 | Centring ring for timing gear cover |
|  | |

EXPERIMENTAL TOOLS


This section shows the working drawings for the experimental tools (S.P.) used in overhauling the engine described in this section, which may be made by the repair shops.



Modification:

For the permissible errors on the dimensions without tolerance and for other general specifications, see **IVECO** STD 10-2311

| | | | | | |
|---|----------------------------------|---------------------------------------|---------------------------|------------------------------|-------------------|
| MAT. Pom / Nylon | | COVER. / | DRAWN UTS (B) | N°DRAWING SP. 2264 | |
| All proprietary rights reserved by IVECO . This drawing shall not be reproduced or in any way utilized, for the manufacture or the component or unit herein illustrated and must not be released to other parties, without written consent. Any infringement will be legally pursued. CI I.S. 18-0011 | ISO ≤ IT8 α ≤ 30° Ra ≤ 0.4 | Perni di centraggio sovratesta | APPROVED | EXPER. 2264 | SIZE A4 |
| | | e per piantaggio guarnizione | DATE 19/06/2001 | SHEET | |
| | | guida valvole | SUPERSEDES | | |
| | | MOTORI FIA - FIC | SCALE 1:1 | | |
| | | Q.TY 2 | | | |



For the permissible errors on the dimensions without tolerance and for other general specifications, see **IVECO** STD 10-2311


| | | | | |
|---|--|--|---------------------------------------|--|
| MAT. Vedi dis. N° 8 VITI T.E. M8x16 Mat. CL. 8.8 N° 8 FORI Ø9 Mat. Alluminio Anticorrosal 6060 T6 N° 4 FORI M12x1.5 Sm. 20x45° Sm. 3x45° Sm. 5x45° | | COVER Vedi dis. Supporto per sostegno testa cilindri | DRAWING UTS (B) APPROVED | N° DRAWING SP. 2271 EXPER. 2271 SHEET |
| N° 8 VITI T.E. M8x16 Mat. CL. 8.8 N° 8 FORI Ø9 Mat. Alluminio Anticorrosal 6060 T6 N° 4 FORI M12x1.5 Sm. 20x45° Sm. 3x45° Sm. 5x45° | | DATE 22/11/2001 SUPERSEDES | SCALE 1:2 | SIZE A3 |
| 0 (3) Sm. 0.5x45° | | Q.TY 1 | IVECO | |

All proprietary rights reserved by IVECO. The drawing shall not be reproduced or in any way used, for the manufacture or the component or unit herein illustrated and must not be released to other parties, without written consent. Any infringement will be legally pursued.

ISO 9001
 IATF 16949
 TS 16949

Modification:

VARIA DA ART. COMMERCIALE USAG cod.235EL 1/4" - Ch.8
SOLO PER QUANTO INDICATO




6
Sm. 0.5x45°

Modification:

For the permissible errors on the dimensions without tolerance and for other general specifications, see **IVECO** STD 10-2311

| | | | | | |
|---|----------------------------------|--|---------------------------|------------------------------|-------------------|
| MAT. / | | COVER. / | DRAWN UTS (B) | N°DRAWING SP. 2275 | |
| All proprietary rights reserved by IVECO . This drawing shall not be reproduced or in any way utilised, for the manufacture or the component or unit herein illustrated and must not be released to other parties, without written consent. Any infringement will be legally pursued. CI I.S. 18-0011 | ISO ≤ IT8 α ≤ 30° Ra ≤ 0.4 | Bussola (8 mm) per montaggio/ smontaggio candele | APPROVED | EXPER. 2275 | SIZE A4 |
| | | | DATE 25/07/2001 | SHEET | |
| | | | SUPERSEDES | | |
| | | | SCALE 1:1 | IVECO | |
| | | | Q.TY 1 | | |
| MOTORI FIA - FIC | | | | | |


PARTIC. DENTE - Scala 10:1



N° 6 DENTI - ELICA SINISTRA - INCLINAZIONE 6°

For the permissible errors on the dimensions without tolerance and for other general specifications, see **IVECO** STD 10-2311


| | | | |
|---|--|---------------------------|-------------------------------|
| MAT. UNI U100WC HRC 62±64 / COVER. / | | DRAWN UTS (B) | N° DRAWING SP. 2310 |
| Lisciatolo per guida valvole | | APPROVED | EXPER. SIZE 2310 A3 |
| ISO A 1TB ISO A 30° ISO A 0,4 | | DATE 10/12/2001 | SHEET |
| + | | SUPERSEDES | |
| 1.8. 18-0011 5 | | SCALE 1:1 | |
| All proprietary rights reserved by IVECO. This drawing shall not be reproduced or in any way used, for the manufacture or the component or unit parts, without written consent. Any infringement will be legally pursued. | | Q.TY 1 | IVECO |



Modification:

For the permissible errors on the dimensions without tolerance and for other general specifications, see **IVECO** STD 10-2311

| | | | | | | |
|---|----------------------------------|---------------------------------|---------------------------|------------------------------|-------------------|--|
| MAT. 39NiCrMo3 Bon. | | COVER. Fosfat. | DRAWN UTS (B) | N°DRAWING SP. 2311 | | |
| All proprietary rights reserved by IVECO . This drawing shall not be reproduced or in any way utilized, for the manufacture or the component or unit herein illustrated and must not be released to other parties, without written consent. Any infringement will be legally pursued. CI I.S. 18-0011 | ISO ≤ IT8 α ≤ 30° Ra ≤ 0.4 | Battitoio per piantaggio | APPROVED | EXPER. 2311 | SIZE A4 | |
| | | guida valvole | DATE 10/12/2001 | SHEET | | |
| | | (usare con sp. 2312) | SUPERSEDES | | | |
| | | | SCALE 1:1 | | | |
| | | | Q.TY 1 | | | |



Modification:

For the permissible errors on the dimensions without tolerance and for other general specifications, see **IVECO** STD 10-2311

| | | | | | |
|---|----------------------------------|----------------------------------|---------------------------|------------------------------|-------------------|
| MAT. 39NiCrMo3 Bon. | | COVER. Fosfat. | DRAWN UTS (B) | N°DRAWING SP. 2312 | |
| All proprietary rights reserved by IVECO . This drawing shall not be reproduced or in any way utilized, for the manufacture or the component or unit herein illustrated and must not be released to other parties, without written consent. Any infringement will be legally pursued. C/ I.S. 18-0011 | ISO ≤ IT8 4 ≤ 30' Ra ≤ 0.4 | Battitoio per spiantaggio | APPROVED | EXPER. 2312 | SIZE A4 |
| | | guida valvole | DATE 10/12/2001 | SHEET | |
| | | | SUPERSEDES | | |
| | | | SCALE 1:1 | | |
| | | Q.TY 1 | | | |

TIGHTENING TORQUE

| PART | TORQUE | |
|---|---------|------------|
| | Nm | kgm |
| M15x1.5 L 193 fastening screw for cylinder head inside | | |
| First stage: pre-tightening | 130 | 13 |
| Second stage: angle | | 90° |
| Third stage: angle | | 90° |
| M12x1.5 L 165 fastening screw for cylinder head side | | |
| First stage: pre-tightening | 65 | 6.5 |
| Second stage: angle | | 90° |
| Third stage: angle | | 60° |
| M8x1.25 L 117/58 fastening screw for side with chain compartment, cylinder head | 25 | 2.5 |
| R 1/2" bevel threaded cap with socket head | 25 | 2.5 |
| R 3/8" bevel threaded cap with socket head | 17 | 1.7 |
| R 1/4" bevel threaded cap with socket head | 9 | 0.9 |
| M26x1.5 threaded screw tap | 50 | 5 |
| Screw with flange M6x1 for camshaft rear cover fastening | 10 | 1 |
| Screw with flange M6x1 for camshaft shoulder plate fastening | 10 | 1 |
| Socket head screw with flange M8x1.25 L 30/40/77/100 for over-head fastening | 25 | 2.5 |
| M14x1.5 L 10 threaded screw tap | 25 | 2.5 |
| M6x1 socket head screw for timing system control cover | 10 | 1 |
| M12x1.5 L 125 inner fastening screw for lower cylinder block | | |
| First stage: pre-tightening | 50 ± 5 | 5 ± 0.5 |
| Second stage: angle | | 60° ± 2.5° |
| Third stage: angle | | 60° ± 2.5° |
| M8x1.25 L 77.5/40 outer fastening screw for lower cylinder block | 26 | 2.6 |
| Socket head screw with flange M11x1.25 for connecting rod cap fastening | | |
| First stage: pre-tightening | 50 | 5 |
| Second stage: angle | | 70° |
| Socket head screw with flange M12x1.25 for engine flywheel fastening | | |
| First stage: pre-tightening | 30 | 3 |
| Second stage: angle | | 90° |
| Socket cylinder head screw for phonic wheel fastening on drive shaft | 15 | 1.5 |
| Connection M10x1 for piston cooling nozzle | 25 | 2.5 |
| Bevel threaded cap with socket head R 3/8"x10 oil circuit | 17 | 1.7 |
| Socket head screw with flange M18x1.5 for drive shaft damper pulley fastening | 350 | 35 |
| Bevel cap R 1/8 x 8 | 7 | 0.7 |
| Water draining plug M14x1.5 L10 | 25 | 2.5 |
| Pipe union on block for oil return from turbocharger G 3/8" x 12 | 50 | 5 |
| Suction rose M6x1 fastening screw | 10 | 1 |
| Socket head nut with flange M8x1.25 for depressor – oil pump unit support fastening | 25 | 2.5 |
| Oil pump – depressor unit control pin | 110 | 11 |
| Threaded cap M26x1.5 | 50 | 5 |
| Socket head screw with flange M8x1.5 L35 for oil sump retaining frame fastening | 25 | 2.5 |
| Threaded screw tap with O-ring M22x1.5 L10 | 50 ± 10 | 5 ± 1 |
| Socket head screw with flange M8x1.25 L60 for depressor - oil pump unit fastening | 25 | 2.5 |
| Socket head screw with flange M8x1.25 L50 for depressor - oil pump unit fastening | 25 | 2.5 |
| Flanged screw M8x1.25 L20/30 for camshaft cover fastening | 25 | 2.5 |
| Flanged screw M6x1 L20 for blow-by unit fastening | 10 | 1 |
| M14x1.5 L10 cap | 25 | 2.5 |

| PART | TORQUE | |
|--|--------|-----------|
| | Nm | kgm |
| Socket head screw with flange M8x1.25 L40 for suction manifold fastening | 30 | 3 |
| Flanged nut M8x1.25 for exhaust manifold fastening | 25 | 2.5 |
| Socket cylinder head screw M8x1.25 L65 for Poli-V belt automatic backstand | 25 | 2.5 |
| Flanged screw M10x1.25 L22 for Poli-V belt take-up pulley fastening | 40 | 4 |
| Flanged head M12x1.75 L30 for camshaft gear fastening | 80 | 8 |
| Timing chain tightener fastener M22x1.5 | 50 | 5 |
| Timing chain mobile skid fastener | 40 | 4 |
| Socket cylinder head screw M8x1.25x30 for fixed skid fastening | 25 | 2.5 |
| Socket cylinder head screw M6x1 L16/20 for skid fastening | 10 | 1 |
| Socket cylinder head screw M12x1.5 for water temperature/pressure sensor fastening | 30 | 3 |
| Socket cylinder head screw M6x1.5 for air temperature/pressure sensor fastening | 10 | 1 |
| Socket cylinder head screw M6x1 for engine rev sensor fastening | 10 | 1 |
| Socket head screw M6x1 for phase sensor fastening | 10 | 1 |
| High-pressure injection system | | |
| Flanged nut M8x1.25 for high pressure pump support fastening | 25 | 2.5 |
| Hydraulic accumulator fastening screw M8x1.25 L50 | 28 | 2.8 |
| High pressure pump fastening screw M8x1.25 L58 | 25 | 2.5 |
| Screw M8x1.25 for fastening of fuel delivery pipe anchoring bracket | 25 | 2.5 |
| Pipe union for fuel delivery pipes to rail and electric injectors: | | |
| - M14x1.5 | 19 ± 2 | 1.9 ± 0.2 |
| - M12x1.5 | 25 ± 2 | 2.5 ± 0.2 |
| Socket cylinder head screw for fastening of electric injector retaining bracket | 28 | 2.8 |
| Flanged nut for anchoring bracket support fastening | 25 | 2.5 |
| Pin fastener M12x1.25 for high pressure pump | 110 | 11 |
| Flanged screw M6x1 for low pressure fuel pipe fastening | 10 | 1 |
| Flanges screw M8x1.25 for pipe support bracket fastening | 40 | 4 |
| Filler neck M12x1.5 for adjustable pipe union | 25 | 2.5 |
| Filler neck M16x1.5 for adjustable pipe union | 40 | 4 |
| Pipe union for multi-way filler fastening to high pressure pump M12x1.5 L24 | 25 | 2.5 |
| Nut M8x1.25 for turbocharger fastening | 25 | 2.5 |
| Flanged screw M8x1.25 for turbocharger output pipe fastening | 25 | 2.5 |
| Pipe union M14x1.5 or M12x1.5 for oil delivery pipe to turbocharger | 35 | 3.5 |
| Pipe union M22x1.5 for oil return pipe from turbocharger | 45 | 4.5 |
| Flanged screw for fastening of oil return pipe from turbocharger | 10 | 1 |
| Pipe union M14x1.5 for fastening of oil delivery pipe to turbocharger | 35 | 3.5 |
| Screw M8x1.25 for air inlet bracket fastening | 28 | 2.8 |
| Screw M8x1.25 for air inlet bracket fastening | 28 | 2.8 |
| Socket cylinder head screw M6x1 for V-clamp closing ring | 8 | 0.8 |
| Flanged screw M6x1 for oil inlet pipe fastening | 10 | 1 |
| Pre-warming plug M8x1 | 8 ÷ 11 | 0.8 ÷ 1.1 |
| Screw M8x1.25 for electric injector retaining bracket fastening | 28 | 2.8 |
| Oil filter cartridge M22x1.5 | 25 | 2.5 |
| Socket cylinder head screw M8x1.25 for water inlet pipe fastening | 25 | 2.5 |


| PART | TORQUE | |
|---|----------|---------|
| | Nm | kgm |
| Pipe union M24x1.5 for oil filter cartridge | 30 | 3 |
| Flanged screw M8x1.25 for heat exchanger inner element fastening | 25 | 2.5 |
| Socket cylinder head screw for water pump fastening: | | |
| - M10x1.5 | 50 | 5 |
| - M8x1.25 | 25 | 2.5 |
| Flanged screw M8x1.25 for rear cover fastening to cylinder head | 25 | 2.5 |
| Flanged screw M8x1.25 for coolant delivery pipe fastening | 25 | 2.5 |
| Flanged nut M8x1.25 for coolant delivery pipe support bracket fastening | 25 | 2.5 |
| Pipe union M10x1x10 for vapour vent fastening | 12 | 1.2 |
| Flanged screw M8x1.25 for thermostat fastening | 25 | 2.5 |
| Flanged nut M6x1 for electro-magnetic joint fastening | 10 | 1 |
| Ring nut M30x1.5 for electro-magnetic joint | 150 | 15 |
| Flanged screw M8x1.25 for air conditioner compressor fastening | 25 | 2.5 |
| Flanged screw M8x1.25 L50 for air conditioner compressor support fastening | 25 | 2.5 |
| Socket cylinder head screw M8x1.25 for fastening of air conditioner compressor control belt idler | 25 | 2.5 |
| Socket cylinder head screw M10x1.5 for alternator fastening | 50 | 5 |
| Flanged screw M8x1.25 for hydraulic power steering pump fastening | 25 | 2.5 |
| Flanged screw M10x1.25x10 securing the power steering pump | 40 | 4 |
| Flanged screw M12x1.25 securing the power steering tank support | 50 | 5 |
| Flanged screws M8x1.25 for power take off cover fastening | 25 | 2.5 |
| Flanged screws M8x1.25 for handling hook fastening | 25 | 2.5 |
| Flanged screws M10x1.25 for engine support fastening | 50 | 5 |
| Depressor pipe union M14x1.5 | 35 | 3.5 |
| Oil level sensor M12x1.25 | 25 | 2.5 |
| Thermometric transmitter/switch M16x1.5 (conical) | 25 | 2.5 |
| Oil pressure switch M14x1.5 | 25 | 2.5 |
| Power unit suspension | | |
| Screw (M8x16) securing the elastic dowel to the gearbox cross-member | 23.5±2.5 | 2.3±0.2 |
| Nut (M12) securing the gearbox cross-member to the chassis | 92±9 | 9.2±0.9 |
| Nut (M12) securing the engine supports to the elastic dowels | 49±4 | 4.9±0.4 |
| Nut (M12) securing the gearbox bracket onto the rear cross-member elastic dowel | 49±4 | 4.9±0.4 |
| Locknut (M10) with flange, securing the engine supports to the chassis | 52.5±5.5 | 5.2±0.5 |
| Screw (M10x30) securing the gearbox support to the gearshift | 46.5±4.5 | 4.6±0.4 |

* On the threading apply LOCTITE 577

OVERHAULING ENGINE FIC

540110 DISASSEMBLING THE ENGINE AT THE BENCH

Figure 13



88239


If the following parts have not already been removed, do so now:

- top soundproofing cover;
- rail guard;
- engine wire, by disconnecting its electrical connections from: thermostat temperature sensor; phase sensor; engine rev sensor; rail pressure sensor; air pressure/temperature sensor of suction manifold.

To be able to fit the brackets onto the crankcase to secure the engine to the stand for overhauling, it is necessary to remove the left and right engine mounts (3) and disconnect the oil pipe (2) from the turbocharger (1) and from the crankcase.

NOTE Block the turbocharger air/exhaust gas inlets and outlets to prevent foreign bodies getting inside.


Figure 14



88240

Fit the brackets 99361041 (3) to the crankcase and use these to secure the engine to the rotary stand 99322205 (4). Drain the oil from the engine by removing the plug from the oil sump.
If fitted, remove the fan (1) from the electro-magnetic joint (2).


Figure 15



88241

Press the springs (3) in the direction shown by the arrow and disconnect the fittings of the pipe (1) recovering fuel from the electro-injectors (2).


Figure 16



88242

Disconnect the fuel pipes (2) from the electro-injectors (3) and from the hydraulic accumulator (1) (rail).


Figure 17



88243

Take out the screws (2) and the brackets (3) fixing the electro-injectors (1) to the cylinder overhead.


Figure 18



88244

Using tool 99342153 (1) extract the electro-injectors (2) from the overhead (3).


Figure 19



88245

Remove the fastening screw (3) of the pipe retaining bracket (2). Disconnect the pipe (2) from the hydraulic accumulator (1) and the high pressure pump (4).


Figure 20



88246

Remove the screws (1) and the hydraulic accumulator (2) from the overhead device (3).


Figure 21



88247

Use tool 99360076 (1) to remove the oil filter (2) from the heat exchanger (3).


Figure 22



88248

Remove the screws (1 and 3) and the heat exchanger (4) with the relevant gasket and pipe (2).


Figure 23



88249

Remove the screw (6) and the low pressure pipes (5) from the bracket (4). Slacken the pipe unions (1 and 3) and remove the low pressure pipes (5) from the high pressure pump (2).


Figure 24



88250

Remove the fastening screws and take off the high pressure pump (1) and the hydraulic power steering pump (2).

Figure 25




88251

If fitted, use the suitable tool to remove the elastic belt (2) from the pulleys (1 and 5).

Remove the screws (4) and take off the climate control system compressor (3) from the support.

NOTE The elastic belt (2) must be changed at every removal.


Figure 26



88252

Remove the screws (4) and take off the support (3).
Remove the screw (1) and the fixed backstand (2).

Figure 27




88253

Remove the screw (5) and take off the air temperature and pressure sensor (6).

Remove the screws (1) and take off the suction manifold (2) with the relevant gasket.

Using wrench SP.2275 (3), remove the glow plugs (4).

Figure 28



88254


Slacken the pipe unions (1 and 6) and take off the oil pipe (2).
Remove the screws (11 and 13) and the bracket (12).

Remove the screw (9) fastening the pipe (10) to the inlet (8).

Remove the screws (7) and take off the inlet (8) from the turbocharger (5).

Remove the nuts (4) and take off the turbocharger (5) with the relevant gasket from the exhaust manifold (3).


Figure 29



88255

Remove the nuts (2), the spacers (1) and take off the exhaust manifold (3) with the relevant gasket from the cylinder head.


Figure 30



88256

Remove the screw (4) and take off the pipe (5) of the oil level dip rod. Slacken the clamp (3), remove the screw (1) and the pipe (2) from the cover (6).

Figure 31




88257

Remove the screws (3) and the cover (4). Take off the snap ring (2). Pull out the centrifugal filter (1).

NOTE The centrifugal filter (1) and the seal ring of the cover (4) must be changed at every removal.


Figure 32



88330

Using the specific wrench on the automatic tightener (2), slacken the tension of the belt (1) and remove it.


Figure 33



88258

Take out the screw (2) and remove the automatic tightener (1).


Figure 34



88259

Remove the screw (2), the bolt (4) and pull the alternator (3) out of the support (1).


Figure 35



88260

Remove the screws (1) and take off the support (2) from the cylinder block.


Figure 36



88261

Use the suitable wrench to remove the oil level sensor (1). Remove the fastening screw and the rev sensor (2).

Figure 37




88262

Stop the rotation of the electro-magnetic joint (1) and remove the nut (2).

NOTE Slacken the nut (2) anticlockwise because its threading is left-handed.


Figure 38



88263

Remove the hub (5) and the pulley (4). Cut the clamp (→), remove the fastening screw (1) of the wire clamp, the nuts (2) and take off the electric magnet (3) from the water pump (6).


Figure 39



88264

Stop the rotation of the engine flywheel (2) by means of tool 99360306 (1).


Figure 40



88265

Remove the screw (2) and the damper pulley (1).


Figure 41



Remove the screws (1) and the distribution cover (2).


NOTE Tool 99340059 (4) is used to remove the seal ring (3) from the cover (2) when the engine is installed on the vehicle.

Figure 42




Remove the nut (1) and the phase sensor (2).
Remove the nuts (3) and the cover (4).

Figure 43



Remove the screws (3) and disassemble the depressor/oil pump unit (2).
Remove the connection key (1).


Figure 44



Remove the hydraulic chain tightener: top (1) and lower (2).
Remove the pin (4) and disassemble the mobile skid: lower (5) and top (3).


NOTE Upper hydraulic chain stretcher (1) is equipped with an anti-return device that makes it necessary to replace the chain stretcher every time it is disassembled.

Figure 45




Remove the screw (3), the washer (2) and the gear (1).
Remove the screw (7), the washer (6), the gear (5) and the chain (4).

Figure 46



Remove the cap (4), the screws (2 and 3) and the top fixed skid (1).


Figure 47



88272

Remove the screws (2) and the side fixed skid (1).
Remove the screws (4) and the lower fixed skid (3).


Figure 48



90311

Stop the rotation of the high pressure pump control shaft (1) by inserting the suitable wrench inside it.


Figure 49



88274

Remove the screw (3) and the stem with the drive gear (2) from the high pressure pump control shaft (1).


Figure 50



88275

Remove the gear (1) and the chain (3) from the high pressure pump control shaft (2).


Figure 51



88276

Remove the high pressure pump control shaft (3).
Remove the nuts (2) and the support (1).


Figure 52



88277

Stop the rotation of the hydraulic power steering pump control shaft (2) by inserting tool 99360187 (3) in the shaft and fastening the tool on the support (1) by means of the screws (4).


Figure 53



88278

Remove the screw (2) and the gear (1) from the hydraulic power steering control shaft (3).


Figure 54



88279

Remove the hydraulic power steering control shaft (3). Remove the nuts (2) and the support (1).


Figure 55



88280

Remove the screws (1) and take off the over-head (2) from the cylinder head (3).


Figure 56



88281

Remove the hydraulic tappets (1) with the rocker arms. Remove the gasket (2).


Figure 57



88282

Take out the screws (1) and remove the cylinder head (2).

Figure 58




88283

Remove the cylinder head gasket (1).


NOTE Check the protrusion of the pistons (2) as described under the relevant heading to check the possibility of facing the crankcase if it has deformed.

Figure 59




Remove the screws (2) and take off the oil sump (1) with its gasket and frame (3).

Figure 60



Remove the screws (2) and the suction rose (1).

Figure 61




Take out the screws (2) and remove the connecting rod caps (3).
Extract the pistons (1) from the top of the crankcase.

NOTE


On the same side of the connecting rod and its associated cap, indicate the number of the cylinder from which the connecting rod has been removed. Keep the bearing shells in their respective housings since, if they are used, they will need to be fitted in the position found during removal.

Figure 62




Block rotation of the flywheel (1) with tool 99360306 (4).
Take out the screws (2) and remove the engine flywheel (1).
Take out the guard (3).

Figure 63



Apply tool 99340060 (2) to the rear O-ring (1) and extract it from the crankcase.


Figure 64



88288

Remove the screws (2) and take off the oil sump (1) with its gasket and frame (3).


Figure 65



88289

NOTE Note the assembly position of the top main bearing shells (2) since, if they are reused, they will need to be fitted in the position found during removal.

Figure 66




87793

With the aid of a hoist and a rope, remove the crankshaft (1).

NOTE Note the assembly position of the top main bearing shells (2) since, if they are reused, they will need to be fitted in the position found during removal.

The central half-bearing (3) is fitted with shoulder half-rings.

Figure 67




75290

Take out the couplings (1) and remove the oil jets (2).

NOTE On completing engine removal, it is necessary to clean the removed parts thoroughly and check their integrity. The following pages give the instructions for the main checks and measurements to make in order to determine whether the parts can be reused.

REPAIRS CYLINDER BLOCK Checks and measurements


Figure 68



Once the engine removal is complete, carefully clean the cylinder block. For the cylinder block transportation use the suitable rings.

Carefully check that the crankcase has no cracks in it. Check the state of the plugs. If they are rusty or there is any doubt about their seal, replace them. Examine the surfaces of the cylinder liners; they must show no sign of meshing, scoring, ovalization, taper or excessive wear. The inside diameter of the cylinder liners is checked, to ascertain the extent of ovalization, taper and wear, using the bore meter 99395687 (I) fitted with a dial gauge previously reset on the ring gauge of the diameter of the cylinder liner or on a micrometer.

Figure 69



The measurements must be made for each single cylinder at three different heights up the liner and on two planes at right angles to each other: one parallel to the longitudinal axis of the engine (B) and the perpendicular (A); the greatest wear is generally found on this last plane with the first measurement.

On finding ovalization, taper or wear, go ahead and bore/grind and finish the face of the cylinder liners. The refacing of the cylinder liners should be done in relation to the diameter of the pistons supplied as spare parts oversized by 0.4 mm of the nominal value and to the prescribed assembly clearance.

Figure 70





Figure 71



* Surface roughness parameters:

- R1 = 4 ÷ 10 μm
- Rz = 3 ÷ 8 μm
- Ra = 0.3 ÷ 0.6 μm
- W1 < 2 μm


Permissible surface porosity for machined cylinder (see Figure 71)

ZONE B1 = Area of greatest mechanical stress, segment/liner contact: No.2 non-continuous porosities are permissible max. 0.5x0.5. (C) 100%

ZONE B2 = Surface involved in segment rubbing: No.2 non-contiguous porosities are permissible max. 1x0.8. (C) 100%

Checking head mating surface on cylinder block

Figure 72




See that the head mating surface, on the cylinder block, has no deformation. This check can be made, after taking out the grub screws (3), with a surface plate spread with carbon black or with a calibrated rule (1) and a feeler gauge (2). After ascertaining the areas of deformation, level the bearing surface with a grinding machine.

NOTE The crankcase can only be surfaced after making sure that, on completing the work, the piston protrudes from the cylinder liner by no more than the prescribed value.

5408 CRANKSHAFT
540810 Measuring main journals and crank pins

Figure 74



On finding signs of seizure, scoring or excessive ovalization on main journals and crankpins, it is necessary to regrind the pins. Before grinding the pins (2), measure the shaft pins with a micrometer (1) to establish to what diameter it is necessary to decrease the pins.

NOTE It is advisable to enter the measurements in a table. See Figure 73.

Figure 73

| | | NOMINAL VALUE | | | | NOMINAL VALUE | |
|-----------|--|---------------|--|--|--|---------------|--|
| | | 76.182 | | | | 83.182 | |
| | | 76.208 | | | | 83.208 | |
| MINIMUM Ø | | | | | | | |
| MAXIMUM Ø | | | | | | | |
| | | | | | | NOMINAL VALUE | |
| | | | | | | 64.015 | |
| MINIMUM Ø | | | | | | | |
| MAXIMUM Ø | | | | | | | |
| | | | | | | 64.038 | |

TABLE IN WHICH TO ENTER THE MEASUREMENTS OF THE CRANKSHAFT MAIN JOURNALS AND CRANKPINS

NOTE The main journals and crankpins must always be ground to the same undersize class. The undersizing performed, on the main journals or crankpins, must be marked by punching on the side of crank arm no. 1.


For undersized crankpins, letter M.
For undersized main journals, letter B.
For undersized crankpins and main journals, letter MB.



The undersize classes are: 0.254 – 0.508 mm.

Checking crankshaft

Figure 75




87785

| TOLERANCES | TOLERANCE CHARACTERISTIC | SYMBOL |
|-------------|-----------------------------|----------|
| SHAPE | Circularity | ○ |
| | Cylindricality | <i>d</i> |
| ORIENTATION | Parallelism | // |
| | Perpendicularity | ⊥ |
| POSITION | Concentricity or coaxiality | ◎ |
| OSCILLATION | Circular oscillation | ↗ |
| | Total oscillation | ↗↘ |

| CLASS OF IMPORTANCE ASCRIBED TO THE PRODUCT CHARACTERISTICS | SYMBOL |
|---|--------|
| CRITICAL | ◎ |
| IMPORTANT | ⊕ |
| SECONDARY | ⊖ |

Figure 76



87786

NOTE The checks on the tolerances indicated in the figures must be made after grinding the crankshaft pins.

SYMMETRY BETWEEN MAIN JOURNALS AND CRANKPINS


1. Crankpins
2. Main journals
3. Normal position

After grinding, keep to the following:

- Round off the edges of deburring the holes for lubrication of the main journals and crankpins.

JOURNAL ON TIMING SYSTEM SIDE


Figure 77



87787

INTERMEDIATE JOURNALS No. 2-4


Figure 78



87788

INTERMEDIATE JOURNAL No. 3

Figure 79




87789

MAIN DATA OF MAIN JOURNALS AND CRANKPINS

JOURNAL ON FLYWHEEL SIDE


Figure 80



87790

CRANKPINS

Figure 81



87791

* As far as both values are concerned, for the whole 360°.

NOTE Since, during the 0.254 and 0.508 mm undersizing on the diameter of the crankpins and main journals, the rolled portion of the side races of the pins may get involved, it is necessary to turn the races keeping to the data given in the figure and to do the rolling keeping to the following instructions.


Rolling force:

- 1st main journal 925 ± 25 daN.
- 2nd – 3rd – 4th – 5th main journal 1850 ± 50 daN.
- crankpin 1850 ± 50 daN.

- Rolling turns: 3 approach, 12 effective, 3 out.
- Rolling speed: 56 rpm.
- Reduction of the connecting rod pin slot diameter after rolling: 0.15 ÷ 0.30 mm*.
- Reduction of the journal slots after rolling: 0.15 ÷ 0.30 mm.

* Measured with calibrated rollers Ø 2.5 mm.

Figure 82



Take out the screws (4) and replace the phonic wheel (3). The screws (4) are coated with LOCTITE 218 and must be replaced with fresh ones after each disassembly. They must be tightened to a torque of 10 ± 1 Nm.

Replacing timing control gear

On finding the timing control gear teeth (1) damaged or worn, remove them from the crankshaft (2) using a suitable extractor.


The new gear is fitted onto the crankshaft by heating it to a temperature of 180°C for no longer than 15 minutes.

On completing assembly and after the gear has cooled, it must withstand a torque of 150 Nm without slipping.

ENGINE ASSEMBLY

The following parts must be replaced with new ones at the time of assembly: retaining rings, seals and gaskets, screws whose thread is coated with sealant.


Figure 83



Fit on the oil spray nozzles (2) and tighten the couplings (1) to the prescribed torque.

Assembling main bearings

Figure 84



NOTE Not having found it necessary to replace the main bearings, they need to be fitted back on in the same sequence and position found upon disassembly.

The main bearings (1) are supplied as spare parts undersized on the inside diameter by 0.254 ± 0.508 mm.


NOTE Do not do any accommodating on the bearings.

Thoroughly clean the top main bearing shells (1) and position them in the crankcase.

NOTE The middle half ring (2) is fitted with thrust washers.

540811 Measuring main journal assembly clearance

Figure 85




Mount the crankshaft (1).

Check the clearance between the crankshaft main journals and their respective bearings by proceeding as follows:

- Thoroughly clean the pins.
- Apply a calibrated wire onto the main journals.


Figure 86



88289

Thoroughly clean the bottom main bearing shells (2) and mount them in the crankcase base (1).

Figure 87



88292

Mount the crankcase base (12).


Tighten the screws in the sequence shown in the figure in three steps:

- Step 1: with a torque wrench, to a torque of 50 Nm.
- Step 2: closing to an angle of 60°.
- Step 3: closing to an angle of 60°.

NOTE Use tool 99395216 (11) for the angle closing.

Then tighten the outer screws to torque 26 Nm.

Figure 88




75310

- Remove the bottom crankcase.

The clearance between the main bearings and their associated pins is measured by comparing the length of the calibrated wire (1), at the point of greatest crushing, with the graduated scale on the casing containing the calibrated wire. The numbers on the scale indicate the clearance of the coupling in millimetres, which must be 0.032 ± 0.102 mm. If the clearance is not as prescribed, replace the bearings and repeat the check.

Checking crankshaft end float

Figure 89



88293


The end float is checked by setting a dial gauge (2) with a magnetic base on the crankshaft (1) as shown in the figure. The normal assembly clearance is 0.060 – 0.310 mm.

If you find the clearance to be greater than as required, replace the rear main bearing shells carrying the thrust bearings and repeat the clearance check between the crankshaft pins and the main bearing shells.

If the end float of the crankshaft does not come within the prescribed values, it is necessary to grind the crankshaft and accordingly change the main bearing shells.

NOTE: The middle main bearing has half thrust washers integrated in it, so it performs the function of a thrust bearing. It is supplied as a spare part only with the normal shoulder thickness.

Figure 90




88294

Thoroughly clean the crankcase / crankcase base mating surface.

Apply, on base, sealant LOCTITE 510 IVECO no. 93162432, as indicated in the scheme. The sealant must result to be even, not patchy.

NOTE Mount the crankcase base within 10 minutes of applying the sealant.

Figure 91




88292

Mount the crankcase base (12) and tighten the fixing screws in three stages, following the sequence shown in the figure:

- Step 1: with a torque wrench, to a torque of 50 Nm.
- Step 2: closing to an angle of 60°.
- Step 3: closing to an angle of 60°.

NOTE Use tool 99395216 (11) for the angle closing.

Figure 92




88296

Then tighten the outer screws (1) to a torque of 26–30 Nm.

540460 Assembling rear seal

Figure 93



88297

Carefully clean the seal seat.


Lubricate the rear shank of the crankshaft with engine oil.

Fit part (2) of tool 99346259 onto the rear shank of the crankshaft; secure it with the screws (3) and key the fresh seal (1) onto it.

Position part (4) on part (2); screw down the nut (5) to fit the seal (1) fully inside the crankcase.

540850 ENGINE FLYWHEEL

Figure 94



88054

Double-mass engine flywheel, one integral with the drive shaft and one with the input shaft of the gearbox and in between a torsion elastic dampening system.

The advantages of this type of flywheel compared to the normal one are:

- Dampening of engine irregularities transmitted to the gearbox and resulting drive noise reduction;
- Noise reduction in the cabin as a result of the overall noise reduction.


Check the clutch disc mating surface, if there are too many scratches, change the engine flywheel (3).

Check conditions of the teeth of crown wheel (1); where excessive cracking or wear is found, replace engine flywheel.

540852 Replacing bearing supporting gearbox input shaft

The bearing (2) supporting the gearbox input shaft is removed and fitted using a general-purpose drift.


Figure 95



88298

Position the metal sheet guard (3) on the cylinder block. Mount the engine flywheel (1) and screw down the screws (2). Fit tool 99360351 (4) onto the crankcase to block rotation of the engine flywheel (1).

Figure 96



88299

Tighten the screws (2) fixing the engine flywheel (3) in two steps:


- Step 1: with a torque wrench, to a torque of 30 Nm.
- Step 2: closing to an angle of 90°.

NOTE Use tool 99395216 (1) for the angle closing.

Take off tool 99360351 (4).

5408 CONNECTING ROD – PISTON ASSEMBLY

Figure 97




75392

PISTON – CONNECTING ROD ASSEMBLY

- 1. Piston – 2. Piston ring – 3. Pin – 4. Trapezoidal ring – 5. Oil scraper ring – 6. Slotted oil scraper ring with spiral spring – 7. Connecting rod body – 8. Bearing shells – 9. Connecting rod cap – 10. Cap fixing screws.

Check the pistons. They must show no signs of seizure, scoring, cracking or excessive wear; replace them if they do.


Figure 98



75393

Remove the piston rings (1) from the piston (2) using pliers 99360183 (3).


Figure 99



75394

Remove the piston (1) from the connecting rod, taking out the piston ring (2) and extracting the pin (3).

Figure 102



87795


MAIN DATA FOR MONDIAL PISTON, PINS AND PISTON RINGS

* The value is measured at 1.5 mm from the outer diameter

** The value of the diameter measured is 91.4 mm

540840 Pistons
Measuring piston diameter

Figure 100




87794

Using a micrometer (2), measure the diameter of the piston (1) to determine the assembly clearance. The diameter has to be measured at the value shown.

NOTE The pistons are supplied as spare parts with the standard, normal and 0.4mm oversize diameters together with rings, pin and retaining rings.

Figure 101




88300

The clearance between the piston and cylinder liner can also be checked using a feeler gauge (1) as illustrated in the figure.

540841 Piston pins

Figure I03




18857

Measuring the diameter of the piston pin (1) with a micrometer (2).

Conditions for correct pin-piston coupling

Figure I04




75397

Lubricate the pin (1) and its seat on the hubs of the piston (2) with engine oil. The pin must go into the piston by lightly pressing with the fingers and must not drop out by gravity.

540842 Piston rings


Figure I05



74947

The trapezoidal split rings (1st slot) and the oil scraper rings (2nd slot) have the word TOP etched in them; when fitting them on the piston, the word TOP must be facing upwards.


Figure I06



16552

Check the thickness of the piston rings (2) with a micrometer (1).


Figure I07



88301

Check the clearance between the trapezoidal ring (2) (1st slot) and the associated slot on the piston with a feeler gauge (1), proceeding as follows: insert the piston into the cylinder liner so that the ring (2) comes approximately half way out of it.

Figure I08




41104

DIAGRAM FOR MEASURING THE CLEARANCE X BETWEEN THE FIRST PISTON SLOT AND THE TRAPEZOIDAL RING

- 1. Piston slot – 2. Trapezoidal piston ring –
- 3. Cylinder liner

Using a feeler gauge (1, Figure I07), check the clearance (X) between the ring (2) and the slot (1); this clearance must have the prescribed value.


Figure 109



75398

Check the clearance between the piston rings (2) of the 2nd and 3rd slot and the associated seats on the piston (3) with a feeler gauge (1).

Figure 110




75399

Check the opening between the ends of the piston rings (2) inserted in the cylinder liner using a feeler gauge (1).

540830 Connecting rods

Figure 111



87796

MAIN DATA OF THE CONNECTING ROD, BUSHING, PISTON PIN AND BEARING SHELLS

- * Internal diameter to obtain after driving into the small end and grinding with a reamer.
- ** Dimension cannot be measured in the free state.
- *** Thickness of the bearing shell supplied as a spare part.

NOTE Each connecting rod has its cap marked:

- with a letter: O or X indicating the diameter class of the big end mounted in production;
- with a number indicating the weight class of the connecting rod mounted in production.

In addition, it could be stamped with the number of the cylinder in which it is fitted.

In the event of replacement it is therefore necessary to number the new connecting rod with the same number as the one replaced.

The numbering must be done on the opposite side to the bearing shell retaining slots.

The connecting rods are supplied as spare parts with the diameter of the big end 67.833 – 67.848 mm marked with the letter O and the weight class marked with the number 33.


It is not permissible to remove material.

540834 Bushing

Check that the bush in the small end has not come loose and shows no sign of seizure or scoring. If it does, replace the complete connecting rod.

Checking connecting rods

Figure 112




61696

Check the alignment of the axes of the connecting rods (1) with device 99395363 (5), proceeding as follows:

- Fit the connecting rod (1) on the spindle of the tool 99395363 (5) and lock it with the screw (4).
- Set the spindle (3) on the V-prisms, resting the connecting rod (1) on the stop bar (2).

Checking torsion


Figure 113



Check the torsion of the connecting rod (5) by comparing two points (A and B) of the pin (3) on the horizontal plane of the axis of the connecting rod. Position the mount (1) of the dial gauge (2) so that this pre-loads by approx. 0.5 mm on the pin (3) at point A and zero the dial gauge (2). Shift the spindle (4) with the connecting rod (5) and compare any deviation on the opposite side B of the pin (3): the difference between A and B must be no greater than 0.08 mm.

Checking bending


Figure 114



Check the bending of the connecting rod (5) by comparing two points C and D of the pin (3) on the vertical plane of the axis of the connecting rod. Position the vertical mount (1) of the dial gauge (2) so that this rests on the pin (3) at point C. Swing the connecting rod backwards and forwards seeking the highest position of the pin and in this condition zero the dial gauge (2). Shift the spindle with the connecting rod (5) and repeat the check on the highest point on the opposite side D of the pin (3). The difference between point C and point D must be no greater than 0.08 mm.


Assembling connecting rod-piston assembly

Figure 115




Etched on the top of the piston are: the type of engine (1), class selection (2) and supplier (3) as well as the direction of fitting the piston in the cylinder liner (4). The mark (5) is for passing the 1st slot insert adhesion test.

Figure 116



Connect the piston (1) to the connecting rod (2) together with its cap so that the piston assembly reference, position of the connecting rod and of the cap are observed as shown in the figure.


Figure 117



Position the piston (1) on the connecting rod, insert the pin (3) and secure it with the split rings (2).

Checking for connecting rod – piston distortion

Figure 118




After fitting the connecting rod – piston assembly together, check for distortion with the tool 99395363 (8) as follows:

- Fit the connecting rod (7) together with the piston (3) on the spindle (4) of tool 99395363 (8) and lock it with the screw (5).
- Rest the connecting rod (7) on the bar (6).
- Position the mount (1) of the dial gauge (2) so that this is positioned at point A of the piston with a pre-load of 0.5 mm and zero the dial gauge (2).
- Shift the spindle (4) so as to position the dial gauge (2) at point B of the piston (3) and check for any deviation.

Assembling piston rings

Figure 119




Fit the piston rings (1) on the piston (2) using the pliers 99360183 (3).

NOTE The 1st and 2nd slot rings need to be mounted with the word "TOP" facing upwards.

Assembling connecting rod – piston assemblies in cylinder barrels

Figure 120



Lubricate the pistons well, including the piston rings and the inside of the cylinder liners.


With the aid of the clamp 99360605 (2), fit the connecting rod – piston assembly (1) in the cylinder liners, checking that:

- The number of each connecting rod corresponds to the cap mating number.
- The openings of the piston rings are staggered 120° apart.
- The pistons are all of the same weight.
- The symbol punched on the top of the pistons faces the engine flywheel, or the recess in the skirt of the pistons tallies with the oil spray nozzles.

NOTE Not finding it necessary to replace the connecting rod bearings, you need to fit them back in exactly the same sequence and position found on disassembly.

540831 Measuring crankpin assembly clearance


Figure 121



To measure the clearance, carry out the following steps:

- Thoroughly clean parts (1) and (4) and eliminate all traces of oil.
- Place a length of calibrated wire (3) on the crankshaft pins (4).

Figure 122



- Fit the connecting rod caps (3) with the associated bearing shells.
- Tighten the screws (2) in two steps:
 - Step 1: with a torque wrench, to a torque of 50 Nm.
 - Step 2: closing to an angle of 70°.

NOTE Use tool 99395216 (1) for the angle closing.


- Remove the cap (3) and determine the existing clearance by comparing the width of the calibrated wire (3, Figure 121) with the graduated scale on the case (2, Figure 121) that contained the calibrated wire. On finding a clearance other than as prescribed, replace the bearing shells and repeat the check. On obtaining the prescribed clearance, lubricate the connecting rod bearing shells and fit them permanently by tightening the connecting rod cap fixing screws as described.

NOTE The connecting rod cap fixing screws must always be replaced for permanent assembly.

Manually check that the connecting rods slide axially on the pins of the crankshaft.

Checking piston protrusion

Figure 123




At the end of the connecting rod-piston assembly refitting, check the piston protrusion (2) at the T.D.C. compared to the top level of the cylinder block by means of a dial gauge (1) and relevant base 99370415.

NOTE The difference between the minimum and maximum protrusions of the four pistons must be = 0.15 mm.


The cylinder head gasket in the set of spare gaskets needed for complete engine overhaul is supplied with a single thickness. Clearly, it is supplied separately too.

Figure 124



Mount the suction strainer (1) together with the pipe. Screw down the fixing screws (2) and tighten them to the prescribed torque.

Figure 125



88329


Fit the gasket (4) and the frame (3) onto the oil sump (1). Screw down the fixing screws (2) and tighten them to the prescribed torque.

Screw down the oil drain plug (5) and tighten it to the prescribed torque.

560610 CYLINDER HEAD

Disassembly

Figure 126



88328

Apply the support SP. 2271 (5) on the cylinder head and tighten the support in a vice.


Remove the brackets (6) for lifting the engine.

Remove the sensors (1 and 2), if needed.

Take out the screws (3) and remove the thermostat casing (4).

541210 Disassembling valves

Figure 127



75412

Fit part (4) of tool 99360260 onto the cylinder head (5) and secure it with the screws (3).


Fit part (2) of tool 99360260 onto part (4), screw down the nut (1) so that on compressing the springs (8) it is possible to remove the cotters (6). Then take out the plates (7) and the springs (8).

Using suitable pliers, remove the oil seal (9).

Repeat these operations on the remaining valves.

Turn the cylinder head over.

Figure 128



88426

The intake (1) and exhaust (2) valves have the same diameter mushroom.

The central cavity (→) of the mushroom of the intake valve (1) is distinguished from that of the exhaust valve (2).

NOTE Before removing the valves from the cylinder heads, number the valves in order to refit them correctly if they are not changed.

A = intake side – S = exhaust side

Remove the intake (1) and exhaust (2) valves.

Checking cylinder head seal

Check the hydraulic seal using a suitable tool.
Pump in water heated to approx. 90°C at a pressure of 2 + 3 bars.


Replace the cup plugs if they are found to leak at oil, using a suitable drift for their removal – assembly.

NOTE Before mounting the plugs, apply LOCTITE 270 water-reacting sealant on their sealing surfaces.

If there is any leakage from the cylinder head, it must be replaced.

Checking cylinder head mating surface

Figure 129



88331


The mating surface of the head (1) with the cylinder block is checked using a rule (2) and a feeler gauge (3). The deformation found on the entire length of the cylinder head must be no greater than 0.20 mm. For greater values, regrind the cylinder head according to the values and instructions given in the following figure.

The nominal thickness A of the cylinder head is 112 ± 0.1 mm; the maximum permissible removal of metal must not exceed a thickness of 0.2 mm.

NOTE After regrinding, check the valve recessing and if necessary regrind the valve seats to make the prescribed valve recessing.

540662 VALVES

Figure 130




MAIN DATA OF INTAKE AND EXHAUST VALVES

87799

Removing deposits, refacing and checking valves


Figure 131



18625

Remove the carbon deposits on the valves with a wire brush. Check that the valves show no signs of seizure, cracking or burning.

Figure 132




18882

Use a micrometer (2) to measure the valve stem (1): it must have the value shown in Figure 132. If necessary, grind the valve seats by means of the grinding machine 99305018, and remove as little material as possible.

Checking clearance between valve stem and valve guide and centring valves

Figure 133



88332


The checks are made using a dial gauge (2) with a magnetic base, positioned as illustrated. The assembly clearance is 0.033 – 0.063 mm.

Making the valve (1) turn, check that the centring error is no greater than 0.03 mm.

540667 VALVE GUIDES

Replacing valve guides

Figure 134




87800

MAIN DATA OF VALVE GUIDES – SEATS

- Valve guide seat inside \varnothing 9.980 + 10.000 mm
- Valve guide outside \varnothing 10.028 + 10.039 mm

* Measurement to be made after driving in the valve guides.


Figure 135



88333

Remove the valve guides (2) with the drift SP.2312 (1).

Figure 136




88334

Warm up the cylinder head to 80° ± 100°C and, by means of beater SP.2312 (1) fitted with element SP.2311 (2), fit the new valve guides (3) previously lubricated with engine oil. Driving force 10 ± 25 kN.

If the above mentioned tools are not available, fit the valve guides by positioning them in the cylinder head according to the value shown in Figure 134.

Boring valve guides

Figure 137




88335

After driving in the valve guides (2), regrind them with the smoother SP.2310 (1).

540661 VALVE SEATS
Regrinding - replacing valve seats

Figure 138



87801


Check the valve seats. On finding any slight scoring or burns, regrind them with an appropriate tool according to the angles given in Figure 138.

Having to replace them, with the same tool and taking care not to affect the cylinder head, remove as much material from the valve seats as possible until, with a punch, it is possible to extract them from the cylinder head.

Heat the cylinder head to $80 \pm 100^\circ\text{C}$ and, using a suitable drift, fit in it the new valve seats, previously chilled in liquid nitrogen.

Using a specific tool, regrind the valve seats according to the angles given in Figure 138.

Figure 139




88336

Using the milling cutter 99394038 (1), clean the injector seat of any deposits.

Mount the valves, block the seat of the electro-injectors and glow plugs; using a suitable tool, check the seal of the valves/seats.

Figure 140




88337

Using a dial gauge (1), check that, from the plane of the cylinder head, the valve recessing (2) and the protrusion of the injector (3) and of the glow plug have the prescribed value:

- Valve recessing: 0.375 ± 0.525 mm.
- Injector protrusion: 2.77 ± 3.23 mm.
- Glow plug protrusion: 3.78 mm.

540665 VALVE SPRINGS


Figure 141



62386

Before assembly, check the flexibility of the valve springs with the tool 99305047. Compare the load and elastic deformation data with those of the new springs given in the following figures.

Figure 142




50676

MAIN DATA TO CHECK INTAKE AND EXHAUST VALVE SPRINGS

| Height mm | Under a load of kg |
|--------------|-----------------------|
| H 54 | Free |
| H1 45 | P 243 ±12 |
| H2 35 | PI 533 ±24 |

ROCKER ARMS – TAPPETS

Figure 143




75461

COMPLETE ROCKER ARM ASSEMBLY

The rocker arm assembly is composed of the rocker arm (1), hydraulic tappet (3), made integral with each other by the clip (2).

Figure 144




75942

CROSS-SECTION OF THE HYDRAULIC TAPPET

- A = 32.44 ±0.3, end of stroke
- B = 31.30, working position
- C = 29.75 ±0.25, start of stroke

Figure 145



MAIN DATA HYDRAULIC TAPPETS – SEATS

87802


Checks

The sliding surface of the tappets must have no scoring/dents; replace them if they do.

Using a micrometer, measure the diameter of the tappets and, using a bore meter, measure the diameter of the seats in the cylinder head; the difference in the measurements will give the assembly clearance.

ASSEMBLING CYLINDER HEADS

Figure 146




87803

Lubricate the stem of the valves (1) and insert them into the associated valve guides (4) according to the position marked during removal. Using tool SP.2264 (2), mount the oil seals (3) on the valve guides (4).

NOTE The suction valves (5) are different from the exhaust ones for a slot (→) in the centre of the valve head.

Figure 147



75587


Position the springs (8) and plates (7) on the cylinder head (5).

Fit the part (4) of tool 99360260 onto the cylinder head (5) and secure it with the screws (3).

Fit the part (2) of tool 99360260 onto part (4), screw down the nut (1) so that by compressing the springs (8) it is possible to insert the retaining cotters (6); then unscrew the nut (1) checking that the cotters (6) have settled in correctly.

Repeat these operations on the remaining valves.

Figure 148




Fit the thermostat casing (3) with a new seal and tighten the fixing screws (4) to the prescribed torque.

Fit the temperature sensors (1 and 2) and tighten them to the prescribed torque.

Fit the brackets for lifting the engine and tighten the fixing screws to the prescribed torque.


540650 Overhead Overhead removal

Figure 149




Remove the screws (2 and 3) and the covers (1 and 4) together with the over-head seal rings.

Figure 150



Remove the nuts (4) and the top skid (3).
Remove the screws (1) and the shoulder plate (2).


Figure 151



Tilt the over-head (1) and take care not to damage the seats, then take off the camshafts (2 and 3) from the overhead.

5412 TIMING SYSTEM

Figure I52



- 1. Rocker arm - 2. Reaction hydraulic tappet -
- 3. Valve assembly - 4. Camshaft on exhaust side -
- 5. Camshaft on suction side - 6. Camshaft control chain.

Description

The timing system is the type with a twin camshaft in the head and four valves per cylinder with hydraulic tappets.

The control is transmitted by two chains:


- a double chain by 3/8" is set in motion by the driving shaft and sets the control shafts in motion: oil pump/depressor – high pressure pump;
- a single chain is set in motion by the high pressure control shaft gear and sets the camshafts in motion.

The camshaft gears are mutually interchangeable and are fitted with slots to make it possible for the phase sensor to detect the phase.

The rocker arms, one for the valve, are kept in contact with the corresponding cam by an hydraulic tappet, thus eliminating the need for regular adjustments.

NOTE Hydraulic chain stretcher (3, Figure I53) equipped with anti-return device must be replaced every time it is disassembled: moreover, it cannot be re-assembled after the piston has escaped from the hydraulic chain stretcher seat.


Figure I53



TIMING SYSTEM AND AUXILIARY SYSTEM DIAGRAM

- 1. Camshaft control gear - 2. Single chain - 3. Hydraulic chain stretcher with anti-return device - 4. Chain -
- 5. Drive gear on driving shaft - 6. Fixed skid - 7. Oil pump/depressor control shaft gear – Hydraulic power steering pump - 8. Double chain -
- 9. High pressure pump control shaft gear.

Figure I54




TIMING SYSTEM DIAGRAM

541210 Camshaft Checks

The surfaces of the shaft supporting pins and of the cams must be finely honed; if there is any sign of meshing or scoring, replace the shaft.

Figure 155




75474

Using a micrometer (1), measure the diameter of the pins (2) of the camshaft and, using a bore meter, measure the diameter of the supporting seats in the overhead. The difference between these two measurements gives the existing clearance. The nominal assembly clearance is 0.037 ± 0.088 mm.

541211 Checking cam lift and pin alignment


Figure 156



87806

Place the shaft (1) on the parallels and use a centesimal dial gauge fitted on the central support to check that the alignment error does not exceed 0.04 mm; otherwise, change the shaft. Check also the cam lift: it must correspond to the prescribed value; if different values are detected, change the shaft.

Figure 157



87807

MAIN DATA, CAMSHAFT PINS AND SEATS


1. Intake valve camshaft seats – 2. Exhaust valve camshaft seats – 3. Intake valve camshaft – 4. Exhaust valve camshaft.



The camshaft (3) of the suction valves can be recognised through the spring cup (4) and the dowel (6).

Assembling overhead

Figure 158




88343

Lubricate the new seal rings (1) with engine oil and fit them on the covers (2).

Fit the covers (2) on the overhead, drive in the fastening screws (3) and tighten them to the prescribed torque.

Figure 159



88344


Lubricate the support pins of the suction camshafts (2) and exhaust camshafts (4) and fit them on the overhead (1).

NOTE During this operation do not exchange the assembly position of the shafts.

The suction camshaft can be recognised (2) through the dowel (3) on the front side and the retainer on the rear side.

In addition, take care not to damage the support seats of the over-head shafts.

Figure 160




88340

Fit the top skid (3) and drive in the nuts (4), then tighten them to the prescribed torque.

Fit the shoulder plate (2) and drive in the screws (1), then tighten them to the prescribed torque.

Figure 161




88346

Position the camshafts (3 and 4) so that the pins 99360614 (1) can be inserted in the camshaft slots (2) through the over-head threaded holes.

AUXILIARY ORGAN CONTROLS


Figure 162



88347

Rotate the driving shaft so that the tool 99360615 (1) can be inserted in the shaft crank hole through the cylinder block hole, in order to stop the engine in the timing system setting condition.


Figure 163



88348

Lubricate the seal rings (1 and 2) with engine oil and fit them on the support (3).


Figure 164



88279

Fit the support (1) and drive in the nuts (2), then tighten them to the prescribed torque. Fit the stem (3).


Figure 165



88277

Stop the stem rotation (2) of the hydraulic power steering pump by inserting in the latter the tool (3) and fastening the tool on the support (1) by means of the screws (4).


Figure 166



88278

Fit the gear (1) on the stem (3) of the hydraulic power steering pump. Drive in the screw (2) without locking it.


Figure 167



88349

Lubricate the new seal rings (1 and 2) with engine oil and fit them on the support (3).


Figure 168



88276


Fit the support (1), drive in the nuts (2) and tighten them to the prescribed torque. Fit the control stem (3) of the high pressure pump.

Figure 169




Position the chain (1) on the gears (2, 3 and 5) and fit the gear (3) on the stem (4) so that the chain (1) in tracts A and B is tensioned.

Figure 170



Fit the stem with the drive gear (2) on the high pressure pump control stem (1). Drive in the fastening screw (3).


Figure 171



Check the conditions of the fixed skids (1 and 3) and change them if worn out. Fit the skid (1) and drive in the fastening screws (2), then tighten them to the prescribed torque. Fit the skid (3) and drive in the fastening screws (4), then tighten them to the prescribed torque.

Cylinder head refitting


Figure 172



Check that the mating surfaces of the cylinder head and crankcase are clean. Keep the cylinder head gasket clean. Place the gasket (1) of the cylinder head with the thickness given in section "Check piston protrusion", with the "TOP" sign facing the head.

NOTE It is essential to keep the gasket sealed in its package until just before assembly.

Figure 173



Mount the cylinder head (2). Screw down the fixing screws (3) and tighten them, in three successive stages, following the order and methods shown in the following figure.

NOTE The angle closure is done with tool 99395216 (1).

Figure 174





Diagram of the tightening sequence for the cylinder head fixing screws:

- 1st phase: pre-tightening with torque wrench
 - screws 1-2-3-4-5-6 to a torque of 130 Nm;
 - screws 7-8-9-10 to a torque of 65 Nm.
- 2nd phase: angle closing
 - screws 1-2-3-4-5-6 90°;
 - screws 7-8-9-10 90°.
- 3rd phase: angle closing
 - screws 1-2-3-4-5-6 90°;
 - screws 7-8-9-10 60°.
- Screws A, to a torque of 25 Nm

Figure 176




Thoroughly clean the hydraulic tappets (2), lubricate them and fit them in the cylinder head (3), positioning the rocker arms (1) on the valves correctly.

Fit on the gasket (5).

Insert the two tools SP. 2264 (4) into the electro-injector seats for subsequent centring of the overhead on the cylinder head.

Figure 175




Mount the overhead (1) together with the tools 99360614 (3) for the timing and tighten the fixing screws (2) to the prescribed torque.

Take out the tools SP. 2264 (4).

TIMING SYSTEM CONTROL


Figure 177



Fit the top fixed skid (1). Drive in the screws (2 and 3) and tighten them to the prescribed torque.

Fit the rubber cap (4) of the new gasket and tighten it to the prescribed torque.

Figure 178




Position the chain (1) on the gear (5) and gear (2).
 Mount the gear in such a way that fitting on aspiration valve timing system shaft dowel makes slots A to result to be positioned as in figure.

NOTE The chain arm (1) between the two gears must be tensioned.


Drive in the fastening screw (4) with the washer (3) without tightening it completely.

Figure 179




Position the chain (1) on the gear (2) and fit the latter on the camshaft of the exhaust valves.
 Drive in the fastening screw (4) with the washer (3) without tightening it completely.

Figure 180




Check the conditions of the mobile skids (1 and 3), if worn out change them.
 Position the mobile skids (1 and 3) and clamp them on the cylinder block by the pin (2) and tighten it to the prescribed torque.

Figure 181




Drive in the chain hydraulic tightener (1) and lock it to the prescribed torque.

Figure 182




Tighten the fastening screw of the gear (1) on the hydraulic power steering control stem to the prescribed torque.

Figure 183




Stop the rotation of the high pressure pump control shaft (1) by inserting the suitable wrench inside it.

Figure 184



Make sure that the chain (2) and the tract between the gear (1) and gear (3) is tensioned. Tighten the fastening screw of the stem with the drive gear (1) on the high pressure pump control stem to the prescribed torque.

Figure 185




NOTE Chain stretcher (1) cannot be re-used for any reason after it has been disassembled. Moreover, in the event that piston (1) has been unintentionally made to escape from chain stretcher (2), the latter must be replaced. Chain stretcher reconditioning is not permitted.

Screw down hydraulic chain stretcher (2), then tighten it to the specified torque.

Insert, through the opening on the overhead, a suitable screwdriver, then press on moving shoe (4) fin (3) until chain stretcher (2) piston (1) is pushed to its end of stroke.


Release moving shoe (4), and make sure that piston (1) causes, by escaping from its seat, chain (5) to be subjected to tension.

Figure 186




Tighten the fastening screw of the gear (1) on the suction valve camshaft to the prescribed torque.

Figure 187



Make sure that the chain (3) in the tract between the gear (2) and gear (4) is tensioned. Tighten the fastening screw of the gear (2) on the exhaust valve camshaft to the prescribed torque. Remove tools 99360614 (1).

Figure 188




Fit a new gasket (5) in the cover (2).

Fit the cover (2), drive in the screws (1) and tighten them to the prescribed torque.

Fit the phase sensor (4).

Drive in the fastening nut (3) and tighten it to the prescribed torque.


Figure 189



88375

Position the joint (5) in the gear (6).
Fit the oil pump/depressor unit (4) by inserting a new gasket (1).
Drive in the screws (2) and tighten them to the prescribed torque.
Remove tool 99360615 (2).


Figure 190



88376

Fit the cover (2) with a new gasket. Drive in the screws (2) without tightening them completely.

Figure 191




88377

Clean accurately the seat of the cover seal ring (1).
Drive in the element (2) of tool 99346258 in the driving shaft tang.

Lubricate the tang of the driving shaft and the element outside (2) and fit flush the new seal ring on this element (3).
Position the element (4) on element (2), lock the nut (5) until fitting the seal ring (3) completely in the cover (1).


Figure 192



90156

Mount tool 99396030 (3), for centering cover (1), into centrifugal filter seat and tighten screws (2) at prescribed torque. Remove: 99346258 (4) and 99396039 (3) tools.


Figure 193



90157

Fit a new centrifugal filter (1).
Fit a new snap ring (2).
Fit the cover (3), drive in the screws (4) and tighten them to the prescribed torque.


Figure 194



Stop the rotation of the engine flywheel (2) by means of tool 99360306 (1).


Fit the damper pulley (3). Drive in the screw (4) and tighten it to the prescribed torque.

Figure 195



Fit the water pump (2) with a new gasket. Drive in the screws (1) and tighten them to the prescribed torque.

Figure 196




Fit the electric magnet (3) of the cooling fan joint on the water pump (6).

Drive in the nuts (2) and tighten them to the prescribed torque.

Drive in the fastening screw (1) of the wire clamp and tighten it to the prescribed torque.

Lock the electric magnet (3) wire by means of the clamp (→). Fit the pulley (4) and the hub (5).


Figure 197



Stop the rotation of the electro-magnetic joint (1). Drive in the nut (2) and tighten it to the prescribed torque.

NOTE The nut (2) must be driven in anticlockwise because its threading is left-handed.


Figure 198



Drive in the oil level sensor (1) and tighten it to the prescribed torque.

Fit the rev sensor (2), drive in the fastening screw and tighten it to the prescribed torque.


Figure 199



Fit the support (2), drive in the screws (1) and tighten them to the prescribed torque.

544017 Replacement of alternator free wheel


Figure 200



The free wheel (2) function is to prevent that the engine idling oscillations bounce back through the control belt on the alternator (1).
If it is necessary to change the free wheel (2), operate as follows.


Remove the protection cap from the free wheel (2).
Apply tool 99358026 (3 and 4) as illustrated in the figure.
Stop the rotation of the free wheel (2) with the element (3) and slacken the stem (5) of the alternator (1) with the element (4).
Fit the new free wheel (2) by reversing the removal operations. The free wheel (2) must be clamped on the stem (5) by applying a max torque of 85 Nm.

Figure 201




Fit the alternator (3) on the support (1), lock it with the bolt (4) and the screw (2) and tighten them to the prescribed torque.

Figure 202




Fit the automatic backstand (1), drive in the screw (2) and tighten it to the prescribed torque.

Figure 203




Operate the automatic backstand (2) with the suitable wrench, fit the belt (1) and make sure the ribs are positioned correctly in the respective pulley races.

Figure 204



Fit the exhaust manifold (3) with a new gasket.
Fit the spacers (1), drive in the nuts (2) and tighten them to the prescribed torque.

Figure 205




88421

Fit the turbocharger (3) with the relevant gasket on the exhaust manifold (1). Drive in the nuts (2) and tighten them to the prescribed torque.

Connect the oil pipe (5) to the turbocharger (3) and the cylinder head, and tighten the pipe unions (4 and 6) to the prescribed torque.

Figure 206




88422

Fit a new seal ring (2) in the air vent (1). Slightly lubricate the seal ring (2), fit the air vent (1) on the turbocharger (3), position the bracket (7), drive in the fastening screws (6 and 8) and tighten them to the prescribed torque.

Drive in the fastening screws (4) of the bracket (5) on the cylinder head and tighten them to the prescribed torque.


Figure 207



88423

Remove the fastening screws (1) and remove tool 99360187 (2).

Figure 208




88424

Position the joint (2) on the stem (3). Slightly lubricate the seal ring (1) and fit it on the power steering pump (5).

Fit the power steering pump on the support (4).

Drive in the fastening screws (6) and tighten them to the prescribed torque.


Figure 209



88425

Lubricate a new seal ring (3) and fit it on the high pressure pump (4). Position the joint (2) on the high pressure pump stem (4). Fit the high pressure pump (4) on the support (1), drive in the screws (5) and tighten them to the prescribed torque.


Figure 210



88249

Connect the low pressure pipes (5) with the new gaskets to the high pressure pump (2) and tighten the pipe unions (1 and 3) to the prescribed torque. Drive in the fastening screw (6) of the pipe (5) on the bracket (4) and tighten it to the prescribed torque.


Figure 211



88248

Fit the heat exchanger (4) with the new gasket and the pipe (2) on the cylinder block. Drive in the screws (1 and 3) and tighten them to the prescribed torque.


Figure 212



75508

Mount the glow plugs (1) and, using the box-type wrench SP. 2275 (2) and torque wrench 99389819 (3), tighten them to a torque of 8 ÷ 10 Nm.


Figure 213



88428

Fit the suction manifold (1) with a new gasket. Drive in the screws (2) and tighten them to the prescribed torque. Fit the air temperature and pressure sensor (3). Drive in the screw (4) and tighten it to the prescribed torque.


Figure 214



75503

Fit a new seal (3) on the electro-injector (1) and mount this in the overhead (2).


Figure 215



88429

Mount the brackets (3) fastening the electro-injectors (1) and screw down the screws (2) without locking them.


Figure 216



88430

Mount the hydraulic accumulator (1) and tighten the fixing screws (2) to the prescribed torque. Fit the pressure sensor (3) on the hydraulic accumulator (1) and tighten it to the prescribed torque.

Figure 217




88431

Connect the fuel pipes (2) to the electro-injectors (3) and to the hydraulic accumulator (1). Tighten the screws (4) fixing the electro-injector brackets (5) to the prescribed torque.

NOTE Whenever they get removed, the fuel pipes must be replaced with new ones.


Figure 218



88432

Using the wrench (2) of the 99317915 series and the torque wrench 99389829 (1), tighten the fuel pipe fittings (3) and (4) to the prescribed torque.

Figure 219




88433

Connect the fuel pipe (3) to the hydraulic accumulator (1) and to the high-pressure pump (8). Tighten the couplings (2 and 5) using a wrench (7) in the 99317915 series and the torque wrench 99389829 (6).

NOTE Whenever they get removed, the fuel pipes (3) must be replaced with new ones.

Fasten the pipe (3) on the support bracket with the bolt (4) tightened to the prescribed torque.


Figure 220



88434

Lubricate the seal ring of the oil filter (2) with engine oil and fasten it on the heat exchanger (3). Use tool 99360076 (1) to tighten the oil filter to the prescribed torque.


Figure 221



88252

If present, fit the support (3), drive in the screws (4) and tighten them to the prescribed torque. Fit the fixed backstand (2), drive in the screw (1) and tighten it to the prescribed torque.

Figure 222




90650

Fit (if present) the compressor of the air conditioner and tighten the fastening screws to the prescribed torque.

Fit the flexible belt (3) equipped with tool 99360191 (2) on the pulley (4) and apply the tool on the pulley (1). Turn the drive shaft counterclockwise (⇨) until the belt fits perfectly on the pulley (1).

Figure 223




88256

Connect the pipe (2) to the cover (6) and fasten it with the clamp (3).

Drive in the screw (1) and tighten it to the prescribed torque. Fit the pipe (5) of the oil level dip rod and fasten the support bracket on the cylinder head by tightening the screw (4) to the prescribed torque.


Figure 224



88240

If present, refit the cooling fan (1) to the electro-magnetic joint (2). Apply the spring equalizing rocker arm on the engine lifting hooks, fasten the rocker arm to the hoist and remove the engine from the rotating stand (3). Remove the brackets 99361041(3).

Figure 225



88239

Complete engine assembly.

Fit on the left and right engine mountings (3) and tighten the fixing screws to the prescribed torque.

Connect the oil pipe (2) to the turbocharger (1) and to the crankcase and tighten the fixing screws and the coupling of the oil pipe (2) to the prescribed torque.


If applicable, mount the following parts:

- Engine cable, connecting its electrical connections to the thermostat temperature sensor, timing sensor, engine speed sensor, pressure regulator, rail pressure sensor and intake manifold air pressure/temperature sensor.
- Hydraulic accumulator guard.
- Top soundproofing cover.
- Add the prescribed grade and quantity of lubricating oil to the engine.

764264 Timing speed sensor

764266 Engine speed sensor

Figure 226



88056

The sensor gap is:

- 1 mm, between the gear (4) of the camshaft and the phase sensor (1).
- 1 mm, between the phonic wheel (2) and speed sensor (1).

5450 LUBRICATION

General

The engine is lubricated by forced circulation performed by the following parts:

- a gear oil pump with built-in depressor (GPOD);
- a pressure relief valve integrated in the oil pump;
- a heat exchanger made up of five elements;
- A double filtration oil filter with built-in safety valve.

Operation (see Figure 227)


Engine oil is drawn up from the sump by the oil pump via the suction strainer and delivered under pressure to the heat exchanger where it is cooled.

The oil continues through the oil filter and goes to lubricate the relevant parts through ducts or pipes.

At the end of the lubrication cycle, the oil returns to the sump by gravity. The oil filter can be excluded by the safety valve built into it if it gets clogged.

In addition, the lubricating oil feeds the chain hydraulic tightening devices for the control of the auxiliary elements and the timing system and the hydraulic tappet.


Figure 227



A. Pressure regulating valve closed - B. Pressure regulating valve open

OIL PUMP/DEPRESSOR UNIT


Figure 228



1. Oil pump - 2. Oil pressure adjusting valve -
3. Depressor.

NOTE Should the unit be faulty, not due to the oil pressure adjusting valve, change the whole unit.

Figure 229



SECTIONS OF OIL PUMP/DEPRESSOR UNIT

1. Oil input pipe from cylinder block - 2. Oil suction pipe -
3. Oil pressure adjusting valve - 4. Oil delivery pipe -
5. Depressor air suction pipe - 6. Depressor oil suction pipe.


503010 Oil pump

Characteristic data

| | |
|---------------------------------|-----------------------|
| transmission ratio | 1 |
| displacement | 23.52 cm ³ |
| pumping diameter | 49.5 mm |
| number of teeth | 7 |
| height | 16 mm |
| oil pump minimum speed | 780 rpm |
| oil pump max. speed | 3500 rpm |
| oil pump over-revs | 4200 rpm |
| oil pump forced over-revs speed | 4900 rpm |
| speed | 3500 rpm |
| torque | - Nm |
| power draw (calc.) | - W |


| | |
|--|------------------|
| Oil temperature: 100°C – closed recirculation – max. outlet pressure 5 bars | |
| engine speed rpm (oil pump speed – rpm) | capacity (l/min) |
| 780 (862) | - |
| 3500 (4485) | |

Figure 230



SECTION B-B

Figure 231



SECTION A-A

Vacuum pump


The vacuum pump (2, Figure 228), with radial blades, is also incorporated in the GPOD (1, Figure 229). It is driven directly by the oil pump.

| | |
|--|---------------------|
| transmission ratio | 1 |
| displacement | 150 cm ³ |
| volume to drain | 4.5 litres |
| chamber diameter | 65 mm |
| rotor diameter | 45.5 mm |
| cam | 7.5 mm |
| number of blades | 3 |
| height | 34 mm |
| vacuum pump minimum speed | 780 rpm |
| vacuum pump max. speed | 3500 rpm |
| vacuum pump over-revs | 4200 rpm |
| vacuum pump forced over-revs | 4900 rpm |
| theoretical flow rate at minimum (air) | - l/min |
| actual flow rate at minimum (air) – at atmospheric pressure | - l/min |
| Theoretical speed at max. speed – (air) | - l/min |
| Actual flow rate at max. speed – (air) at atmospheric pressure | - l/min |
| measured power draw (maximum) speed | 3500 rpm |
| torque | - Nm |
| power draw (calc.) | - W |

| Oil temperature: 100°C – engine speed 780 rpm (pump speed 994 rpm) | | | |
|---|--------------|-----|------|
| tank (litres) | vacuum (bar) | 0.5 | 0.8 |
| 4.5 | time (sec) | 4.5 | 12.5 |
| 9 | | 9.5 | 26.0 |

543475 Oil pressure adjusting valve

Figure 232




1. Oil input pipe from cylinder block - 2. Oil suction pipe - 3. Oil pressure adjusting valve - 4. Oil delivery pipe - 5. Depressor air suction pipe - 6. Depressor oil suction pipe.

Pressure at opening start: 4.4 bar

Description of oil pressure adjusting valve closed

If in pipe C the oil pressure is below 4.4 bar, the valve (1) closes the holes D - E.

Figure 233




88627

Oil pressure adjusting valve open

If in pipe C the oil pressure is equal or above 4.4 bar, the valve (1), as a result of the pressure itself, wins through the spring reaction (2) and goes down, thus opening communication between the delivery pipe A and the suction pipe B, through draining holes D-E, and therefore the pressure drops. When the pressure falls below 4.4 bar, the spring (2) takes the valve (1) to the initial position of closed valve.

Disassembly


Figure 234



88058

Use the suitable wrench to remove the oil pressure adjusting valve (1) from the oil pump.

Figure 235




PARTS COMPRISING THE OIL PRESSURE CONTROL VALVE

1. Split ring – 2. Valve – 3. Spring – 4. Valve casing.

Use the suitable pliers to remove the snap ring (1), take off the valve (4) and the spring (3) from the valve body (2).

88059

Figure 236



MAIN DATA OF THE OIL PRESSURE CONTROL VALVE SPRING


88060

Assembly

For refitting, reverse the removal operations.

543070 Oil filter

Figure 237




88061

Oil filter with built in by-pass valve – differential opening pressure 2.5 ± 0.2 bar.

543110 Heat exchanger

Figure 238



88773

HEAT EXCHANGER COMPONENT DETAILS

1. Heat exchanger made up of five elements - 2. Gasket - 3. Box - 4. Pipe union - 5. Screw - 6. Oil filter support - 7. Screw - 8. Heat exchanger box - 9. Gasket.

Disassembly

Remove the screws (5) and take off the heat exchanger (1) from the box (3) with the gasket (8).

Remove the screws (7) and take off the oil filter support (6) from the box (3).


Assembly

For refitting, reverse the removal operations and observe the following warnings.

Clean accurately the heat exchanger (1).


Always change the gaskets (2, 9 and 8). Apply LOCTITE 577 on the threading of the pipe union (4) (if removed), drive it in the support (1) and tighten it to the prescribed torque. Tighten the screws to the prescribed torque.

Figure 239




88685

Figure 240




88686

Figure 241



88687

Figure 242



88688

HEAT EXCHANGER SECTIONS

- Oil flow from heat exchanger to oil filter
- Oil flow from oil filter to cylinder block
- Oil flow from cylinder block to heat exchanger

540480 Oil vapour recirculation (Blow-by)


Part of the gas produced by the combustion during the engine operation blows by the piston snap ring ports, in the oil sump, and mixes with the oil vapours present in the oil sump. This mixture, conveyed from the chain compartment to the top, is partially separated from the oil by means of a device situated on the top side of the distribution cover and is introduced in the air suction system. This device consists mainly of a rotating filter (3), fit flush on the stem (1), a high pressure/shaft control and a cover (2) where the valves (4 and 5), usually closed, are fitted. The diaphragm valve (4) regulates the partially purified mixture and keeps the pressure inside the chain compartment around a value of $\sim 10 \pm 15$ mbar.

The umbrella valve (5) discharges some of the oil still present in the mixture coming from the filter (3) in the chain compartment and the oil condenses in the chamber (6).


Operation

The mixture which passes through the rotating filter (3) is partially purified from the oil particles, as a result of centrifugation, and so these particles condense on the cover walls to return to the lubrication circuit. The resulting purified mixture is let in through the stem holes (1) and the diaphragm valve consensus (4) inside the air vent upstream of the turbocharger. The opening/closing of the valve (4) depends mainly in the ratio between the pressure operating the diaphragm (4) and the depression below it. The oil still present in the mixture coming from the rotating filter (3) and which condenses in the chamber (6) is drained into the chain compartment through the umbrella valve (5), when the pressure that keeps it closed drops as a result of the engine stop.

Figure 243



- Gas with oil level above 10 g/h
- Gas with oil level $\sim 0,2$ g/h
- Condensed oil returning to the oil sump



5432 COOLING**Description**

The engine cooling system is the type with forced circulation in a closed circuit. It comprises the following parts:

- ❑ An expansion tank whose plug has two valves incorporated in it: an outlet and an inlet, which govern the pressure of the system.
- ❑ A coolant level sensor at the base of the expansion tank.
- ❑ A pressure switch (3) notifies EDC central unit when pressure inside expansion tank exceeds 0.4 bar value; in this case, the central unit reduces engine performance level by modifying injection flow rate (De-rating).
- ❑ An engine cooling module to dissipate the heat taken from the engine by the coolant with a heat exchanger for the intercooler.
- ❑ A heat exchanger to cool the lubricating oil.
- ❑ A centrifugal water pump incorporated in the crankcase.
- ❑ An electric fan comprising an electromagnetic coupling on whose shaft a hub turns idle that is fitted with an axially mobile metal plate on which is mounted the impeller.
- ❑ A 3-way thermostat governing the circulation of the coolant.

Operation

The water pump driven by a poly-V belt by the crankshaft sends coolant into the crankcase and with a greater head into the cylinder head.

When the coolant temperature reaches and exceeds the working temperature, it causes the thermostat to open and the fluid is channelled from here to the radiator and cooled by the fan.

The pressure in the system due to the change in temperature is governed by the outlet (2) and inlet (1) valves incorporated in the expansion tank filler plug (detail A).

The outlet valve (2) has a twofold function:


- ❑ to keep the system slightly pressurized so as to raise the boiling point of the coolant;
- ❑ to discharge into the atmosphere the excess pressure produced in case of high coolant temperatures.

The function of the inlet valve (1) is to permit transferring the coolant from the expansion tank to the radiator when a lower pressure is created in the system due to the reduction in volume of the coolant as a result of its temperature lowering.

Outlet valve opening $1 \pm 0.1 \text{ kg/cm}^2$.


Inlet valve opening $0.005 - 0.02 \text{ kg/cm}^2$.

Figure 244



543212 Electromagnetic pulley

Figure 245



88064

CROSS-SECTION OF THE ELECTROMAGNETIC JOINT

Characteristics

Transmissible torque at 20°C with clutch run in 85 Nm
 Voltage 12 Volts
 Power input at 20°C 48 W
 The electric fan control relay is activated or deactivated according to the temperatures of the engine coolant, the fuel supercharging air and the pressure of the air conditioner fluid (if present).

Turbocharging air temperature

It activates at > 75°C and deactivates at < 65°C.
 Coolant temperature (if the sensor is not defective)
 It activates at > 96°C and deactivates at < 84°C.

Fuel temperatures

(if the coolant temperature sensor is acknowledged to be defective by the EDC control unit)
 It activates at > 20°C and deactivates at < 10°C.


With climate control system

With pressure in the system
 it turns on 18.5 ± 0.98 bar
 it turns off 14.58 ± 0.98 bar

543210 Water pump

The water pump cannot be overhauled. In case of coolant leaking from the seal or damage, it must be replaced.

Figure 246




88065

LONGITUDINAL CROSS-SECTION OF THE WATER PUMP

1. Pump casing – 2. Pump drive shaft together with bearing – 3. Seal – 4. Impeller.

543250 Thermostat

Figure 247




88066

The by-pass thermostat (1) needs no adjustment. If there is any doubt about its operation, replace it. The thermostat casing is fitted with the thermometric switch/transmitter and water temperature sensor.

- A. – A1 Start of stroke at 79 ± 2 °C.
 - B. Valve (1) stroke at 94 ± 2 °C ≥ 7 mm.
 - B1 Valve (2) stroke 94 ± 2 °C, 6.4 mm
- The stroke of 7 mm less than 60".

TURBOCHARGING

Figure 248



88068

TURBOCHARGING DIAGRAM


Description

The turbocharging system comprises an air filter, turbocharger and intercooler. The air filter is the dry type comprising a filtering cartridge to be periodically replaced.

The function of the turbocharger is to use the energy of the engine's exhaust gas to send pressurized air to the cylinders. The intercooler comprises a radiator included in the engine coolant radiator and its function is to lower the temperature of the air leaving the turbocharger to send it to the cylinders.

542410 Turbocharger type MITSUBISHI TD 4 HL-13T - 6


Figure 249



A. THROTTLE VALVE SHUT

B. THROTTLE VALVE OPEN

Figure 250



The turbocharger installed on the engine FIC AE0481 A (136 CV) is fitted with pressure relief valve (waste-gate). It is basically composed of:

- a central casing housing a shaft supported by bushings at whose opposite ends are fitted the turbine wheel and the compressor rotor;
- a turbine casing and a compressor casing mounted on the end of the central body;


- a pressure relief valve applied on the turbine body. Its function is to choke the output of the exhaust gases (detail B) and send part of them directly into the exhaust pipe, when the supercharging pressure downstream of the turbocharger is above the rated value;

REPAIRS

NOTE On finding irregular engine operation due to the turbocharging system, it is first expedient to perform the checks on the turbocharger, check the efficiency of the seals and the fixing of the couplings, additionally checking there is no clogging in the intake sleeves, air filter or radiators. If the turbocharger damage is due to a lack of lubrication, check that the oil circulation pipes are not burst or clogged, in which case replace them or eliminate the trouble.

542418 Pressure relief valve Checking and adjusting pressure relief valve


Figure 251



88622

Cover the air, exhaust gas and lubricating oil inlets and outlets. Thoroughly clean the outside of the turbocharger using anticorrosive and antioxidant fluid. Disconnect the pipe (2) from the union of the pressure relief valve (1) and fit on it the pipe of the device 99367121 (3, Figure 252).


Figure 252



88623

Rest the tip of the dial gauge (1) with a magnetic base on the end of the tie rod (2) and zero it. Using the device 99367121 (3), introduce compressed air into the valve casing (4) at the prescribed pressure and make sure this value stays constant throughout the check; replace the valve if it doesn't. In the above conditions, the tie rod must have made the prescribed travel.

Figure 253



88624

If a different value is detected, slacken the nut (3) and rotate the tie rod (4) as required.

Changing the pressure relief valve

Remove the fastener (2) of the tie rod on the lever (1) and take off the valve (5) from the turbocharger by pulling out the fastening screws (6).

Fit the new valve by carrying out the operations for removal in reverse order and adjust the travel of the tie rod as described under the relevant heading.

NOTE Before fitting the turbocharger on the engine, it is necessary to fill the central body with engine lubricating oil.

542410 GARRET GT 2256 T variable geometry turbosupercharger (engine FIC E048I B - 166 HP)

General

The variable geometry turbosupercharger consists of the following:

- centrifugal supercharger (1);
- turbine (2);
- set of mobile blades (3);
- mobile blade control pneumatic actuator (4), vacuum controlled by proportional solenoid valve controlled by EDC 16 ECU.


Variable geometry enables:

- to increase the speed of the exhaust gases running into the turbine at low engine rpm;
- to decrease the speed of the exhaust gases running into the turbine at high engine rpm.

To obtain the max. engine volumetric efficiency also at low rpm (with on-load engine).

Operation at low engine rpm

Figure 254



62870


1. TURBINE - 2. MOBILE BLADES - 3. PNEUMATIC ACTUATOR - 4. REVOLVING RING

When engine is running at low speed, the exhaust gases show weak kinetic energy; under these conditions a traditional turbine shall rotate slowly, thus providing a limited booster pressure.

In the variable geometry turbine (1), the mobile blades (2) are set to max. closed position and the small through-sections between the blades increase the inlet gas speed. Higher inlet speeds involve higher tip speeds of the turbine and therefore of the turbosupercharger.

Engine speed increase results in a gradual increase of exhaust gas kinetic energy, and also in turbine (1) speed and booster pressure increase.


Figure 255



82871

Operation at high engine rpm

Figure 256



62872


The ECU, through the actuator control solenoid valve, modulates the vacuum acting on the diaphragm, so actuator (3) controls through the tie rod, the gradual opening of the mobile blades (2) until reaching the max. open position.

Blade through-sections results larger thus producing a speed decrease in exhaust gas flow through the turbine (1) with speeds equal to or lower than those of the low rpm condition.

Turbine (1) speed is therefore adjusted to a proper value enabling suitable engine operation at high speeds.

Proportional solenoid valve controlling turbocharger actuator

Figure 257




62876

The solenoid valve modulates the low pressure controlling the turbocharger actuator, taken from the air circuit of the servo brake, according to the information exchanged between the electronic control unit and the sensors: engine speed, throttle pedal position and pressure/temperature fitted on the intake manifold.

As a result, the actuator varies the opening of the blades of the turbocharger that adjust the flow of exhaust gases.

Actuator

Figure 259




62875

SECTION ON THE ACTUATOR

The actuator diaphragm, connected to the control rod, is governed by the low pressure on the top of the actuator.

The low pressure modulated by the proportional solenoid valve varies the movement of the diaphragm and, as a result, of the rod governing the turbine's mobile blades.

Figure 258




62869

TURBOCHARGING FUNCTIONAL DIAGRAM

- 1. Variable geometry turbocharger - 2. Pneumatic actuator - 3. Proportional solenoid valve - 4. Air filter -
- 5. EDC 16 control unit - 6. Servo brake - 7. Vacuum device - 8. High-pressure pump.

REPAIRS**542451 Checking and adjusting the actuator**

Figure 260



62873

Cover air, exhaust gas and lubricant inlets and outlets.

Clean the turbosupercharger outside accurately using anticorrosive and antioxidant fluid and check the actuator (6).

Clamp the turbosupercharger in a vice.

Apply vacuumeter 99367121 (1) pipe to actuator (6) hose.

Apply the magnetic base gauge (2) to exhaust gas inlet flange in the turbine.

Set gauge (2) feeler pin on tie rod (3) end and set gauge (2) to zero.

Operate the vacuum pump and check whether the tie rod (3) stroke values correspond to the vacuum values shown in the following table:

| | |
|--------------------|-------------------------|
| - vacuum 0 mm Hg | Fully open valve |
| - vacuum 180 mm Hg | Valve stroke 2.5 mm |
| - vacuum 450 mm Hg | Valve stroke 10.5 mm |

If a different value is found, loosen nut (5) and operate on the knurled ring nut (4) as required.

Once the adjustment has been carried out, tighten the nut (5) to torque 5.6 ± 6.8 Nm.

NOTE During the check the vacuum value shall not fall, otherwise the actuator shall be replaced.

NOTE NOT ALLOWED ARE:

- any replacement or regulation of the actuator, since the calibration of such component is made in an optimal way for each turbocharger and is guaranteed for the turbocharger;
- any operation on nut (5) and ring nut (4), since such operation does not change engine supply characteristics but may impair engine reliability and duration.

Ring nut (4) is sealed with antitempering yellow paint.

In case of engines under guarantee, each above specified intervention and/or alteration to paint applied on ring nut (4) causes the lapse of the guarantee.

FUEL SUPPLY**HIGH-PRESSURE ELECTRONIC INJECTION SYSTEM (EDC 16)****General**

The main characteristics of the high pressure electronic injection system are:

- high injection pressures available (1600 bar);
- these pressures can be modulated between 150 bar up to the maximum operating pressure of 1600 bar, irrespective of the speed of rotation and engine load;
- capacity to operate at very high speeds (up to 6000 rpm);
- injection control precision (injection duration and advance);
- lower consumption;
- lower emissions.

The main functions of the system are basically as follows:

- checking fuel temperature;
- checking engine coolant temperature;
- checking amount of fuel injected;
- checking idling speed;
- cutting off fuel in release phase;
- checking cylinder balancing when idling;
- checking anti-sawing;
- checking smokiness at exhaust on acceleration;
- checking exhaust gas recirculation (E.G.R. if present);
- checking top speed limit;
- checking glow plugs;
- checking activation of air-conditioning system (if any);
- checking auxiliary fuel pump;
- checking position of cylinders;
- checking main and pilot injection advance;
- checking closed cycle of injection pressure;
- checking turbocharging pressure;
- self-diagnosis;
- connection with immobilizer unit;
- checking maximum torque limitation.


The system makes pre-injection (pilot injection) possible before the TDC with the advantage of decreasing the derivative of the pressure in the combustion chamber, lowering the noise level of combustion, which is typical of direct injection engines.

The control unit checks the amount of fuel injected, adjusting the line pressure and injection times.

The information the control unit processes to regulate the amount of fuel to be injected comprises:

- engine speed;
- coolant temperature;
- turbocharging pressure;
- air temperature;
- intake air quantity;
- battery voltage;
- diesel pressure;
- position of throttle pedal.

Figure 261



HIGH PRESSURE ELECTRONIC INJECTION SYSTEM COMPONENTS LOCATION SCHEME

1. Stroke sensor - 2. Electric injectors - 3. Pre-heating glow plug - 4. Coolant temperature sensor for EDC - 5. Electromagnetic fan - 6. Modulator for E.G.R. valve (if present) - 7. Engine speed sensor - 8. Compressor (if present) - 9. High pressure pump - 10. Pressure regulator - 11. Fuel temperature sensor - 12. Fuel filter clogging sensor - 13. Fuel filter - 14. Electric feed pump - 15. Fuel pre-filter - 16. Fuel tank - 17. Battery - 18. Central unit with atmospheric pressure sensor - 19. Accelerator pedal sensor - 20. Clutch pedal sensors - 21. Brake pedal sensors - 22. Fuel non return valve - 23. Heater - 24. Air pressure/temperature sensor - 25. Hydraulic accumulator (rail) pressure sensor - 26. Hydraulic accumulator (rail) - 27. Transmitter for thermometer and warning lamp temperature dangerous - 28. Gear with slots to detect stroke from sensor (1) - 29. Engine revolution indicator - 30. Tachograph - 31. Thermostarter warning indicator.

SYSTEM OPERATION

Self-diagnosis – BLINK CODE

The control unit self-diagnosis system checks the signals from the sensors, comparing them with the admitted limits (see relative heading):

Immobilizer recognition

When the control unit receives the signal of the key on "MAR" it communicates with the immobilizer control unit to enable starting.

Checking fuel temperature

With the fuel temperature greater than 75°C, detected by the sensor on the fuel filter, the control unit operates the pressure regulator to decrease the line pressure (injection times are not changed). If the temperature exceeds 90°C, the power is reduced to 60%.

Checking engine coolant temperature

The control unit, depending on the temperature:

- of the engine coolant, turbocharging air and fuel, operates the electromagnetic fan (Baruffaldi) and switches on the coolant temperature warning light.

Checking quantity of fuel injected

According to the signals from the sensors and the mapped values, the control unit:

- operates the pressure regulator;
- varies the "pilot" injection time to 2200 rpm;
- varies the "main" injection time.

Checking idling adjustment

The control unit processes the signals from the various sensors and regulates the amount of fuel injected:

- it operates the pressure regulator;
- it varies the injection times of the electro-injectors.

Within certain thresholds the speed takes account of the battery voltage.

Fuel cut-off in release phase

In the phase of releasing the throttle pedal the control unit actuates the following logic elements:

- it cuts off supply to the electro-injectors;
- it partially reactivates supply to the electro-injectors before reaching idling speed;
- it operates the fuel pressure regulator.

Checking cylinder balancing on idling

According to the signals received from the sensors, the control unit controls the regularity of the torque at idling speed:

- it varies the amount of fuel injected into the single electro-injectors (injection time).

Checking regular engine rotation (anti-sawing)

It ensures regular engine rotation at a constant rate while increasing revs.

The control unit processes the signals received from the sensors and determines the amount of fuel to be injected via:

- the pressure regulator;
- the electro-injector opening time.

Checking smokiness at exhaust on acceleration

With heavy acceleration, on the basis of the signals received from the air introduction meter and engine speed sensor, the control unit determines the optimum amount of fuel to inject:

- it operates the pressure regulator;
- it varies the electro-injector injection time.

Checking exhaust gas recirculation (E.G.R. if present)

Depending on the engine load and the signal from the accelerator pedal sensor, the control unit limits the amount of air taken in, actuating partial suction of the exhaust gases.

Checking top speed limit

Depending on the number of revs, the control unit actuates two action strategies:

- at 4250 rpm it cuts off the fuel, decreasing the electro-injector opening time;
- over 5000 rpm it deactivates the electro-injectors.

Checking regular rotation on acceleration

Regular progression is assured in all conditions by the control of the pressure regulator and the electro-injector opening time.

Checking glow plug control unit

The injection control unit, in the phase of:

- starting
- after-starting

times operation of the glow plugs according to the engine temperature.

Checking activation of air-conditioning system

The control unit operates the air-conditioning compressor:

- switching it on/off when the relative switch is pressed;
- momentarily turning it off (approximately 6 sec.) if the engine coolant reaches the set temperature.

Checking fuel pump

Irrespective of the speed, the control unit:

- supplies the auxiliary fuel pump with the key on MAR;
- cuts off auxiliary pump supply if the engine is not started up within a few seconds.

Checking diesel warming

It times operation of diesel warming in relation to ambient temperature.

Checking cylinder position

During each turn of the engine, the control unit recognizes which cylinder is in the power stroke and operates the injection sequence for the appropriate cylinder.

Checking pilot and main injection timing

According to the signals from the various sensors, including the absolute pressure sensor built into the control unit, the control unit determines the optimum point of injection according to internal mapping.

Checking injection pressure closed cycle

Depending on the engine load, determined by processing the signals from the various sensors, the control unit operates the regulator to obtain optimum line pressure.

Fuel supply

The fuel supply is calculated in relation to:

- accelerator pedal position
- engine speed
- quantity of air introduced.

The outcome may be corrected in relation to:

- the water temperature.

Or to avoid:

- noise
- smoke
- overloading
- overheating
- turbine over-revving.

The delivery can be modified in the case of:

- action of external devices (ABS), ABD, EDB
- serious trouble decreasing the load or stopping the engine.

After determining the mass of air introduced by measuring its volume and temperature, the control unit calculates the corresponding mass of fuel to inject into the relevant cylinder (mg per delivery) also taking into account the temperature of the diesel.

The mass of fuel calculated in this way is first converted into volume (mm³ per delivery) and then into degrees of throw, or duration of injection.

Correcting flow rate according to water temperature

A cold engine meets with greater resistance during operation: friction is high, the oil is still very viscous, and the various clearances are not yet optimized.

In addition, the injected fuel tends to condense on the metal surfaces that are still cold.

The fuel supply for a cold engine is therefore greater than for a warm one.

Correcting flow rate to avoid noise, smoke or overloading

The behaviour that could lead to this kind of trouble is well known.

The designer has therefore included special instructions in the control unit to avoid it.

De-rating

In the event of the engine overheating, injection is modified, decreasing the delivery to a varying degree, in proportion to the temperature reached by the coolant.

Injection timing electronic test

The advance (start of delivery, expressed in degrees) may be different from one injection to the next, also differentiated from one cylinder to another. It is calculated, similarly to the delivery, in relation to the engine load (accelerator position, engine speed and air introduced).

The advance is appropriately corrected:

- in phases of acceleration;
- according to the water temperature.

And also to obtain:

- lower emissions, noise and overloading;
- better vehicle acceleration.

An extremely high advance is set on starting, depending on the water temperature.

Feedback from the start of delivery is supplied by the change in impedance of the injector solenoid valve.

Speed governor

The electronic speed governor has both features of governors:

- idling and top speed
- all speeds

It is stable in ranges where conventional, mechanical governors are imprecise.

Engine starting

During the first few turns of the engine, the timing and cylinder no. 1 recognition signals (flywheel sensor and camshaft sensor) are synchronized.

The accelerator pedal signal is ignored on starting. Starting delivery is set only according to water temperature, by a special map.

When the control unit detects such speed and acceleration of the flywheel as to be able to consider the engine started up and no longer driven by the starter motor, it re-enables the accelerator pedal.

Cold starting

If even just one of the three temperature sensors (water, air or diesel) records a temperature lower than 10°C, pre-post heating is activated.

When the key makes contact the pre-heating indicator light comes on and stays on for a length of time that varies in relation to the temperature (while the glow plugs in the cylinder head heat the air), then flashes. It is now possible to start up the engine.

When the motor is running this indicator light goes out, while the glow plugs continue to be powered for a certain length of time (variable) for post-heating.

If, with the indicator light flashing, the engine is not started up within 20-25 seconds (inattention time), the operation is cancelled so as not to run down the batteries pointlessly.

The pre-heating curve is also variable in relation to the battery voltage.

Warm starting

If the reference temperatures all exceed 10°C, when the key makes contact the indicator light comes on for approximately 2 sec., for a short test, and then goes out. It is now possible to start up the engine.

Run up

When the key makes contact, the control unit transfers the information stored in memory when the engine was last stopped into the main memory (see After Run) and makes a diagnosis of the system.

After run

Whenever the engine is switched off with the key, the control unit stays powered for a few seconds by the main relay.

This makes it possible for the microprocessor to transfer some data from the main memory (volatile) to a non-volatile memory, which can be erased and written over (EEPROM), so as to make it available at the next start up (see Run Up).

These data basically consist of:

- various settings (engine idling adjustment, etc.);
- settings of some components;
- fault memory.

The process lasts a few seconds, typically from 2 to 7 (depending on the amount of data to save), after which the ECU sends a command to the main relay and makes it disconnect from the battery.

NOTE It is extremely important for this procedure not to be broken off, for example by switching off the engine with the battery cut-out, or by disconnecting the battery cut-out before 10 seconds have passed since switching off the engine.
If this happens, the functioning of the system is ensured, but repeated interruptions may damage the control unit.

Cut-off

This function cuts off fuel delivery when the vehicle is decelerating (accelerator pedal released).

Cylinder balancing

Individual cylinder balancing contributes to increasing comfort and handling.

This function permits individual, customized control over the delivery of fuel and the start of delivery for each cylinder, even differently from one cylinder to another, to compensate for the hydraulic tolerances of the injector.

The differences in flow (delivery specifications) between the various injectors cannot be evaluated directly by the control unit. This information is supplied by Modus reading the bar code of each injector at the time of assembly.


Synchronization search

If there is no signal from the camshaft sensor, the control unit is anyhow able to recognize the cylinders into which the fuel is to be injected.

If this occurs when the engine is already running, the combustion sequence has already been acquired, so the control unit continues with the sequence on which it has already been synchronized.

If this occurs when the machine is at a standstill, the control unit energizes a single solenoid valve. Within at most 2 turns of the crankshaft, injection will take place in that cylinder, so the control unit just needs to get synchronized on the firing sequence and to start up the engine.

Figure 262



FUEL SUPPLY AND RECIRCULATION SYSTEM DIAGRAM

87245

1. Injector fuel exhaust pipe - 2. Plug - 3. Electric injector - 4. Multiple pipe union - 5. Pressure regulator - 6. High pressure pump CP3.2 with built-in feeding pump - 7. Fuel delivery pipe to high pressure pump - 8. Sensor for water presence in the fuel filter - 9. Fuel filter - 10. Fuel return pipe to the filter - 11. Fuel inlet pipe from the reservoir - 12. Temperature sensor connector - 13. Fuel return pipe to the reservoir - 14. Fuel filter clogged sensor - 15. Non-return valve - 16. High pressure fuel delivery pipe to the hydraulic accumulator (rail) - 17. Pressure sensor - 18. High pressure fuel delivery pipe to the electric injectors - 19. Hydraulic accumulator (rail).

Check valve characteristics

opening pressure $0.5^{+0.05}_{-0.1}$ bar
 differential pressure less than 0.2 bar at 120 litres/h of fuel.



High pressure fuel pipes



Low pressure fuel recirculation pipes

OPERATION

In this injection system, the pressure regulator, located upstream from the high-pressure pump, governs the flow of fuel needed in the low-pressure system. Afterwards, the high-pressure pump correctly supplies the hydraulic accumulator.

This solution, pressurizing solely the necessary fuel, improves the energy efficiency and limits heating the fuel in the system. The relief valve fitted on the high-pressure pump has the function of keeping the pressure, at the pressure regulator inlet, constant at 5 bars; irrespective of the efficiency of the fuel filter and of the system upstream. The action of the relief valve causes an increase in the flow of fuel in the high-pressure pump cooling circuit.

The high-pressure pump continually keeps the fuel at the working pressure, irrespective of the timing and the cylinder that is to receive the injection and accumulates it in a duct common to all the electro-injectors.

At the electro-injector inlet, there is therefore always fuel at the injection pressure calculated by the electronic control unit.

When the solenoid valve of an electro-injector is energized by the electronic control unit, fuel taken straight from the hydraulic accumulator gets injected into the relevant cylinder.

The hydraulic system is made out of a low-pressure fuel recirculation circuit and a high-pressure circuit.

The high-pressure circuit is composed of the following pipes:

- pipe connecting the high-pressure pump outlet to the Rail;
- hydraulic accumulator;
- pipes supplying the electro-injectors.

The low-pressure circuit is composed of the following pipes:

- fuel intake pipe from the tank to the pre-filter;
- pipes supplying the mechanical supply pump and the pre-filter;
- pipes supplying the high-pressure pump via the fuel filter.

The fuel system is also fitted with the fuel exhaust circuit and the electric injectors.

According to the high performance of this hydraulic system, for reasons of safety it is necessary to:

- avoid connecting high-pressure pipe fittings with approximate tightening;
- avoid disconnecting the high-pressure pipes with the engine running (NEVER try bleeding, which is both pointless and dangerous).

The integrity of the low-pressure circuit is also essential for the system to work properly; it is therefore necessary to avoid all manipulation and modifications and act only in the event of leakage.


HYDRAULIC SYSTEM

The hydraulic system is composed of:

- tank
- fuel pre-filter
- electric supply pump
- fuel filter
- high pressure supply pump with supply pump built in pressure regulator
- manifold (rail)
- electro-injectors
- supply pipes and fuel recirculation

Fuel pipes


Figure 263



1. Fuel filter mounting - 2. High-pressure pump supply pipe quick-coupling fitting - 3. Supply pipe quick-coupling fitting.

If disconnecting the fuel pipes (2-3) from the mounting (1), it is necessary, when refitting, to make sure their fittings are perfectly clean. This is to avoid an imperfect seal and fuel getting out.

88619

773010 Fuel pump**Figure 264**

50707

CROSS-SECTION OF FUEL PUMP


This rotary positive displacement pump with integrated by-pass is mounted on the suction pipe, on the left-hand side of the chassis frame.

The fuel pump is the roller-type with positive displacement, a brush motor with energizing by permanent magnets. The impeller turns, driven by the motor, creating volumes that shift from the inlet port to the delivery port. These volumes are defined by the rollers that stick to the outer ring when the motor turns.

The pump has two valves, a check valve to prevent the fuel circuit from emptying (with the pump stationary) and an overpressure valve that recirculates the delivery with the inlet when pressures over 5 bar are produced.

Specifications

| | |
|--------------------------|----------------|
| Delivery pressure: | 2.5 bar |
| Flow rate: | > 155 litres/h |
| Power supply: | 13.5 V - < 5 A |
| Coil resistance at 20°C: | 28.5 Ohms |

542011 Fuel filter**Figure 265**

1. Bleeding screw - 2. Temperature sensor connector - 3. Heater support - 4. Water presence sensor - 5. Heater connector - 6. Threaded insert - 7. Fuel filter - 8. Water separator - 9. Filter clogged sensor - 10. Connector - 11. Connector.

88618

The fuel filter screwed on the heater support (3) consists of a cartridge (6) fitted with water sensor (7).

The water accumulation capacity (A) of the filter is approx. 100 cm³.

The water indicator (4) is mounted on the bottom end. Unscrewing the indicator (4) drains off any water.

The heater support (3) has the temperature sensor built-in (9).


A clogging warning sensor (9) is screwed on the support (3). When the temperature of the diesel is less than 6°C, an electric heating element warms it up to at most 15°C before sending it to the high pressure pump.

Clogging indicator characteristics

differential working pressure 1.1 bar

Tightening torques

| | |
|------------------------------|------------|
| 1. Bleed screw | 4 Nm |
| 4. Water indicator | 0.8±1.2 Nm |
| 6. Insert | 30±2 Nm |
| 7. Fuel filter tightening | 18±2 Nm |
| 9. Tightening of clog sensor | 20±2 Nm |
| 10. Connector | 35±2 Nm |
| 11. Connector | 35±2 Nm |

775010 High-pressure pump**Figure 266**


88070

1. Feed mechanical pump - 2. High pressure pump CP3 - 3. Pressure regulator
 A. Return to reservoir - B. Delivery to hydraulic accumulator (Rail) - C. Fuel inlet pipe from the filter -
 D. Return from injectors - E. Return from hydraulic accumulator (Rail).

Pump with 3 radial pumping elements controlled via a gear by the timing belt; it needs no timing. On the rear of the high-pressure pump there is the mechanical supply pump, controlled by the shaft of the high-pressure pump. The pump is lubricated and cooled by the fuel.

NOTE The high-pressure pump – supply pump assembly cannot be overhauled and therefore the fixing screws must be neither removed nor tampered with. The only permissible job is replacing the driving gear.

Figure 267




1. Pressure regulator – 2. Modulating valve 5 bar – 3. Fuel filler from the filter – 4. Pump shaft – 5. Delivery valve to hydraulic accumulator (rail) – 6. Fuel return from high pressure pump – 7. Feed mechanical pump – 8. Delivery valve on single pumping element.

88739

High-pressure pump internal structure

Figure 268



1. Cylinder – 2. Three-lobed element – 3. Plate intake valve – 4. Ball delivery valve – 5. Plunger – 6. Pump shaft –
7. Low-pressure fuel inlet – 8. Fuel ducts to supply pumping elements.

Each pumping assembly comprises:

- a plunger (5) operated by a three-lobed element (2) floating on the shaft of the pump (6). Since the element (2) floats on a misaligned portion of the shaft (6), during shaft rotation, it does not turn with it but is only shifted


in a circular movement on a wider radius, with the result of working the three pumping elements alternately:

- a plate intake valve (3);
- a ball delivery valve (4).

88071


Working principle

Figure 269



Sec. B - B

Figure 270



Sec. D - D


88072

1. Outlet for delivery to rail – 2. Delivery valve to rail – 3. Pumping element – 4. Pump shaft – 5. Pumping element supply duct – 6. Pressure regulator supply duct – 7. Pressure regulator.

The pumping element (3) is arranged on the cam on the pump shaft. In the suction phase, the pumping element is supplied through the supply duct (5). The amount of fuel to send to the pumping element is determined by the pressure regulator (7). The pressure regulator, on the basis of the PWM command

received from the control unit, chokes the flow of fuel to the pumping element. During the compression phase of the pumping element, the fuel, on reaching such a pressure as to open the delivery valve to the common rail (2), supplies it through the outlet (1).

Figure 271

**Sec. C - C** (Figure 270)

72598

88073

1, 3, 6 Pumping element inlet – 2. Pump lubrication ducts – 4. Main pumping element supply duct – 5. Pressure regulator – 7. Regulator outlet duct – 8. Relief valve 5 bar – 9. Fuel outlet from regulator inlet.



Figure 271 shows the low-pressure fuel routing in the pump; it highlights the main supply duct of the pumping elements (4), the supply ducts of the pumping elements (1-3-6), the ducts used to lubricate the pump (2), the pressure regulator (5), the 5-bar relief valve (8) and the fuel outlet.

The pump shaft is lubricated by the fuel through the delivery and return ducts (2).

The pressure regulator (5) determines the amount of fuel with which to supply the pumping elements; excess fuel flows out through the duct (9).

The 5-bar relief valve, besides acting as a manifold for the fuel outlets, has the function of keeping the pressure constant at 5 bars at the regulator inlet.

Figure 272

**Sec. A - A** (Figure 270)

1, 2 Fuel outlet ducts – 3. Fuel outlet from the pump with coupling for high-pressure pipe for the common rail.

The figure shows the high-pressure fuel flow through the outlet ducts of the pumping elements.

771034 Pressure regulator


The fuel pressure regulator is mounted on the low-pressure circuit of the CP3 pump. The pressure regulator modulates the amount of fuel sent to the high-pressure circuit according to the commands received directly from the engine control unit. The pressure regulator is mainly composed of the following components:

- connector
- casing
- solenoid
- pre-load spring
- shutter cylinder.

When there is no signal, the pressure regulator is normally open, therefore with the pump providing maximum delivery. The engine control unit, via the PWM (Pulse Width Modulation) signal, modulates the change in fuel flow rate in the high-pressure circuit by partially closing or opening the sections of passage of the fuel in the low-pressure circuit.

Operation

Figure 273




75574

1. Solenoid – 2. Magnetic core – 3. Shutter cylinder –
4. Fuel inlet – 5. Fuel outlet.

When the engine control unit governs the pressure regulator (via PWM signal), the solenoid (1) is energized that, in its turn, generates the movement of the magnetic core (2). The shift of the core causes the shutter cylinder (3) to move axially, choking the flow of fuel.

Figure 274




75575

1. Solenoid – 2. Magnetic core – 3. Pre-load spring –
4. Shutter cylinder.

When the solenoid (1) is not energized, the magnetic core is pushed into the rest position by the pre-load spring (3). In this condition, the shutter cylinder (4) is in such a position as to offer the fuel the greatest section of passage.

Replacing pressure regulator

Figure 274/1




88406

Accurately clean high pressure pump.

Take off screws (2) and unthread pressure regulator (3) from high pressure pump.

Figure 274/2




88407

Accurately clean the seat (→) of pressure regulator and the connection surface (→) of the regulator.

NOTE For cleaning, do not use a tool which could damage the surfaces and pay attention that impurities are not introduced into channels.


Figure 274/3



88408

Mount new seal rings (1 and 2) on pressure regulator (3) and lubricate the rings with vaseline.


Figure 274/4



Mount pressure regulator (1) on high pressure pump (2).

NOTE Mounting operation must be performed keeping the regulator perpendicular to connection plane without angling it, in order not to damage seal rings (1-2, Figure 260).

Figure 274/5




Screw up screws (1) and tighten them at $6 \div 7$ Nm ($0.6 \div 0.7$ kgm) torque.

NOTE Where pressure regulator is replaced on the engine mounted on the vehicle, it is needed, after replacement, to check that there are no fuel leaks after an engine working period.

MECHANICAL SUPPLY PUMP

Normal working condition

Figure 275




A. Fuel inlet from the tank – B. Fuel outlet to the filter –
1, 2 By-pass valves in closed position.

The function of the gear pump, mounted on the rear of the high-pressure pump, is to supply the high-pressure pump. It is governed by the shaft of the high-pressure pump. In normal working conditions, the flow of fuel inside the mechanical pump is shown in the figure.

Conditions of outlet overpressure


Figure 276



The by-pass valve (1) trips when overpressure is generated at the outlet B. The pressure, overcoming the elastic resistance of the spring of the valve (1), sets the outlet in communication with the inlet via the duct (2).

Conditions of bleeding


Figure 277



The by-pass valve (1) trips when, with the engine switched off, you want to fill the supply system via the priming pump. In this situation, the by-pass valve (2) opens, due to the effect of the inlet pressure, and the fuel flows out via the outlet B.

774510 Hydraulic accumulator (rail)

Figure 278



88418

The hydraulic accumulator is fitted on the cylinder head on the suction side.


With its volume of approximately 23 cm³ it dampens the pressure ripples of the fuel due to:

- the operation of the high-pressure pump;
- the opening of the electro-injectors.

On the hydraulic accumulator (1) there is the fuel pressure sensor (2).

775010 ELECTRO-INJECTORS

Figure 279



75588

The electro-injectors have high-pressure supply (up to 1600 bar) and recirculation at atmospheric pressure, necessary for the diesel used to operate the pilot valve.

The temperature of the diesel put back into circulation by the electro-injector can get very high (approximately 120°C). The head of the electro-injector has a fitting for the electrical connector.


They are mounted on the cylinder head and operated by the injection control unit.

The electric injector can be subdivided into two parts (see Figure 280):

The electro-injector can be divided into two parts:

- actuator/jet composed of pressure rod (1), pin (2) and nozzle (3);
- control solenoid valve composed of coil (4) and pilot valve (5).

Figure 280



50704

1 Pressure rod – 2 Pin – 3 Nozzle – 4 Coil – 5 Pilot valve – 6 Ball shutter – 7 Control area – 8. Pressure chamber – 9 Control volume – 10 Low-pressure fuel return – 11 Control pipe – 12. Feeding pipe - 13 Electrical connection – 14 High-pressure fuel inlet fitting – 15 Spring.

Operation

Electro-injector operation can be broken down into three phases:

- "rest position"

The coil (4) is de-energised and the shutter (6) is in closed position and does not allow the fuel to get in the cylinder, $F_c > F_a$ (F_c : due to the fuel pressure operating the rod (1) control area (7). F_a : due to the line pressure operating in the pressure chamber (8).

- "start of injection"

The coil (4) is energized and causes the shutter (6) to rise. The fuel of the control volume (9) flows off towards the return manifold (10) causing a drop in pressure in the control area (7).

At the same time, the line pressure through the fuel pipe (12) exerts in the pressure chamber (8) a force equal to $F_a > F_c$ and thus makes the pin (2) lift and so the fuel gets in the cylinders.


- "end of injection"

The coil (4) is de-energized and makes the shutter (6) return to its closed position. This recreates such a balance in the forces as to make the pin (2) return to its closed position and consequently end injection.

ELECTRIC/ELECTRONIC COMPONENTS

766161 Electronic control unit EDC 16

Figure 281



85711

The control unit is a "flash EPROM" and so it can be reprogrammed from outside without changing the hardware. It processes the signals from the sensors by applying software algorithms and controls the actuators (especially the electro-injectors and pressure regulator).


The injection control unit has the absolute pressure sensor built in to further improve the control of the injection system. The control unit is mounted on the left-hand side of the engine bay and is connected to the vehicle's wiring harness by two 60-pin connectors:

- 60-pin connector **A** for the components on the engine
- 94-pin connector **K** for the components on the vehicle

In addition to handling the operation of the system described under the relevant heading, the electronic control unit is interfaced with the other electronic systems on the vehicles such as ABS – EBD cruise control, speed limiting device, immobilizer (IVECO CODE), EGR and glow plugs.

761917 Glow plug electronic control unit

Figure 282



75578

The engine control unit, in the phase of:

- starting
- after-starting


times the operation of the glow plug control unit according to the engine temperature.

The spark plug control takes place through the spark plug pre-warming control unit according to the engine temperature under the direct control of the engine control unit EDC 16.

The pre-heating control unit contains an "intelligent" contactor that sends feedback to the control unit that is thus informed about any fault with the pre-heating control unit or shorting to earth of the glow plugs.

761915 Glow plugs

Figure 283



75579

CONTROL VALUES

With a constant supply voltage of 11 V:

- | | |
|----------------------------|------------|
| - max. current drawn | 18 A |
| - in 5 sec. | 11 ± 1.5 A |
| - in 30 sec. | 6 ± 0.9 A |
| - temperature after 7 sec. | 850°C |
| - tightening torque | 8-10 Nm |

SENSORS

Engine speed sensor

It is an inductive sensor and is positioned on the phonic wheel fitted on the front end of the drive shaft

It generates the signals resulting from the magnetic flow lines which close through the teeth of the phonic wheel.

Tooth number 58.

The electronic control unit uses this signal to measure the speed of rotation of the engine, its angular position and to operate the electronic rev counter.

If this signal fails the rev counter will not work.

Camshaft timing sensor

It is an inductive sensor and is positioned on the camshaft gear of the suction valves.

It generates the signals resulting from the magnetic flow lines which close through a slot on the gear itself.

The signal generated by this sensor is used by the electronic control unit as a redundant signal to measure the different engine speeds.

772655 Air temperature and pressure sensor

Positioned on the intake manifold, it measures the pressure of the turbocharging air introduced into the intake manifold. This value, together with that of the air temperature sensor, makes it possible for the electronic control unit to calculate the exact quantity of air introduced into the cylinders so as to operate the injectors adjusting the fuel delivery, limiting harmful emissions, improving consumption and performance. The sensor contains an electronic temperature correction circuit to optimize the pressure measurement in relation to the temperature of the intake air.

772656 Fuel temperature sensor

Integrated in the fuel filter, it measures the fuel temperature and transmits it to the electronic control unit. When the fuel temperature is too high (ambient temperature condition, engine at full load and tank in reserve), correct lubrication of the high-pressure pump is no longer assured. On the basis of the values received, the control unit determines the density and volume of the fuel, correcting the delivery limiting engine performance.

774511 Fuel pressure sensor

It is fitted on the hydraulic accumulator end (rail) and its function is to transmit a "feed-back" signal to the injection control unit for:

- adjust injection pressure
- adjust the duration of injection.

766161 Atmospheric pressure sensor

This is integrated in the electronic control unit. It provides a criterion of correction for the measurement of the air flow rate and to calculate the reference air flow rate to check the EGR.

764254 Engine coolant temperature sensor

This provides the control unit with an index of the thermal status of the engine in order to determine corrections for the fuel delivery, injection pressure, EGR injection advance when starting cold (if mounted) and warm-up.

505910 Throttle pedal position sensor

The accelerator pedal position sensor provides the control unit with a voltage value in proportion to the angle of operation of the pedal determining fuel delivery.

772641 Clutch pedal position sensor

Mounted on the pedal board, it provides the control unit with a positive signal when the clutch is engaged (pedal released). Every time the clutch is disengaged to change gear, the control unit fails to receive this signal and deactivates the Cruise Control function.

772642 Brake pedal position sensor

There are two of these sensors mounted on the pedal board. With the brake pedal released, they provide the control unit with a positive signal that is used to detect brake operation so as to deactivate the Cruise Control function and stop delivery of fuel.

In addition, a sensor switches on the brake lights.

764261 Vehicle speed sensor

This sensor, mounted on the gearbox by the drive output shaft, transmits the vehicle speed signal, through the electronic tachograph, to the control unit.

ACTUATORS

The injection system comprises three classes of actuators interlocked with the electronic control unit:

- electro-injectors (see relevant heading);
- regulators (see relevant headings) requiring PWM control (Pulse Width Modulation):
 - for pressure
 - EGR (if mounted)
 - turbocharger with variable geometry (if mounted);
- actuators with continuous ON/OFF signal to:
 - engage electromagnetic coupling for radiator cooling fan;
 - turn on/off air-conditioner compressor (if mounted);
 - Cruise Control;
 - starter heater control;
 - fuel filter heating;
 - electric supply pump.

NOTE All the power controls are made with relays located in the cab.

PWM (Pulse Width Modulation) controls

A PWM control has an active and an inactive state that alternate within a constant set length of time. During the active state the actuator control circuit is closed, which is thus powered with the control voltage; whereas, during the inactive state the circuit is open.

The duration of the two states may be varied with the condition that the sum of the two times is equal to the length of the modulation delivery.

The duration of the active state determines the duty-cycle, which is normally expressed as a percentage of the total time. Therefore, if the duration of the two active and passive states are the same, the duty-cycle is equal to 50%.

For reasons of diagnostics, the duty-cycle is limited between 1% and 99%; the control resolution is equal to 0.005% (1/20000 of the time).

The time length has been chosen taking account of the dynamic actuator response specifications.

Too low a carrier frequency could cause oscillations in the actuator, while too high a frequency would decrease control resolution.

The control of the E.G.R. (if fitted) and the turbocharger with variable geometry (if fitted) occurs through the idle modulating valve.

TROUBLESHOOTING GUIDE

NOTE Comply with the instruction below:

- Section 1: EDT FMI error code with EDC 16 control unit, software version: P331 V4b;
 - Section 2: SYMPTOMS.
-

SECTION 3**5052 Clutch**

| | Page |
|--|------|
| DESCRIPTION | 3 |
| DIAGNOSTICS | 4 |
| CHARACTERISTICS AND DATA | 7 |
| TIGHTENING TORQUES | 15 |
| TOOLS | 15 |
| CLUTCH REMOVAL AND REFITTING | 16 |
| <input type="checkbox"/> Removal | 16 |
| CHECKS | 16 |
| <input type="checkbox"/> Refitting | 17 |
| THRUST BEARING REMOVAL AND REFITTING | 17 |
| HYDRAULIC CLUTCH DRIVE | 18 |
| HYDRAULIC CLUTCH DRIVE REMOVAL - REFITTING | 20 |
| <input type="checkbox"/> Removal | 20 |
| <input type="checkbox"/> Refitting | 20 |
| PEDAL BOARD REMOVAL - REFITTING | 22 |
| <input type="checkbox"/> Removal | 22 |
| <input type="checkbox"/> Refitting | 22 |
| PEDAL BOARD | 23 |
| CLUTCH WITH AUTOMATIC WEAR RECOVERY - COMBINED WITH 6 AS'300 VD GEARBOX | 24 |
| <input type="checkbox"/> Description | 24 |
| <input type="checkbox"/> Operation | 24 |
| REMOVAL AND REFITTING OF CLUTCH WITH DEVICE RECOVERY COMBINED | 26 |
| <input type="checkbox"/> Removal | 26 |
| CHECKS | 26 |
| <input type="checkbox"/> Refitting | 27 |

DESCRIPTION

The clutch unit consists of the following:


- a driven disk - lined on both sides with friction seals and fitted with a hub at the centre. Additionally, a hub spring is provided to make it more elastic and soft;
- a thrust pad - fixed to the cover or body of the friction clutch mechanism by means of plates that allow for axial movement when the diaphragm spring is driven by the collar bearing;
- a diaphragm spring made from a certain number of blades arranged in a dial form;
- a collar bearing mounted on the diaphragm spring and locked to the same by means of the split ring. With this solution it is no longer necessary to adjust the clearance between the collar bearing and diaphragm spring since both the components are in contact. Moreover, the clutch is released by traction of the collar bearing.

The introduction of a diaphragm spring (or Belleville washer) as an elastic driving brings about important advantages, such as:

- smaller axial size and reduced sensibility of the centrifugal force, due to the absence of the release lever;
- greater constructive accuracy due to the reduced number of components;
- improved cooling capacity due to the reduced contact surfaces between diaphragm and disk driver;
- less unbalance;
- easy maintenance thanks to:
 1. no regulation required for clearance;
 2. no further need to level-off the thrust pad.

Finally, it must be noted how the non-linear characteristics of the diaphragm spring offer a reduced variation of the release force as the control pedal gradually completes its travel and, with a load on the disk driver not less than the rated value even with worn seals.

Figure 1



VIEW OF CLUTCH ASSEMBLY

52233

DIAGNOSTICS

Main operating faults of the clutch are:

- 1 - Noise when the clutch pedal is pressed;
- 2 - Noise when the pedal is released;
- 3 - Clutch jerks;
- 4 - The clutch does not release;
- 5 - The clutch slips;
- 6 - Abnormal wear of driven disk seals.

1 NOISE WHEN CLUTCH PEDAL IS PRESSED



Collar bearing excessively worn, damaged or not properly lubricated.

- YES ->

Replace the collar bearing.

NO
↓

Excessive play between the clutch engagement grooves on the shaft and the relevant seat on the hub of the driven disk.

- YES ->

Replace the shaft and, if necessary, the driven disk also.

2 NOISE WHEN THE PEDAL IS RELEASED



Driven disk springs are broken or weakened.

- YES ->

Replace the driven disk.

NO
↓

Clutch engagement shaft worn.

- YES ->


Replace the shaft and, if necessary, the driven disk also.

NO
↓

Collar bearing has excessive play in the joint.

- YES ->

Replace the collar bearing.



Clutch pedal height not adjusted (only mechanical control).

- YES ->

Adjust the height of the clutch pedal.

NO

Clutch release hydraulic control not efficient.

- YES ->

Replace the hydraulic control.

5 THE CLUTCH SLIPS



Driven disk seals worn or burnt.

- YES ->

Replace the driven disk.

NO

Clutch diaphragm springs weak or broken.

- YES ->

Replace the clutch.

NO

Oil or grease on the seals of the driven disk.

- YES ->

Remove the oil or grease, and replace the driven disk.

6 ABNORMAL WEAR OF DRIVEN DISK SEALS



The driver keeps the clutch pedal pressed while driving.

- YES ->

The driver must stop this habit and use the clutch pedal only when necessary.


















NO

Clutch diaphragm spring blades weakened or broken.

- YES ->

Replace the clutch.


















CHARACTERISTICS AND DATA**Models 29 L 9/II - 35 S 9/II - 35 C 9 - 35 C II - 40 C 9 - 40 C II* - 45 C II* - 50 C II***

| | | |
|---|---|--------------------------------|
| 9" 1/4 CLUTCH | | VALEO |
|  | Type | Dry single disk |
| |  | |
|  | Clutch mechanism | "Pull" with diaphragm spring |
|  | Driven disk | With friction seals |
| |  | |
|  | Driven disk hub | With double hub springs |
|  | External Ø seal | mm |
| | | 235 ⁰ ₋₁ |
|  | Internal Ø seal | mm |
| | | 165 ⁰ ₋₁ |
|  | Disk thickness (new) | mm |
| | | 7.7 ± 0.3 |
| | Under load | N |
| | | 6000 |
| | Minimum thickness due to wear | mm |
| | | 1.25 |
|  | Max. off centring driven disk | mm |
| | | ~ 0.3 |
|  | Minimum load on thrust plate | N |
| | | 6800 |
|  | Max. release load at 9 mm. release height | N |
| | | 1500 |
|  | Minimum rise thrust pad at 9 mm. release height | mm |
| | | 1.4 |
|  | Disengagement stroke | mm |
| | | 9 + 1 |
|  | Max. depression stroke | mm |
| | | 12 |
|  | Disengagement control | hydraulic |
|  | Lubricant | - |

NOTE Values refer to new clutch


















* Only vehicles with 5 speed gearbox 5 S 200 - 5 S 270

Models 29 L 10 - 29 L 12 - 35 S 10 - 35 S 12 - 35 C 10 - 35 C 12 - 40 C 10 - 40 C 12

| | | | |
|---|---|------------------------------|---------------------------------|
| 9" 1/4 CLUTCH | | BORG & BECK | |
|  | Type | Dry single disk | |
|  | | | |
|  | Clutch mechanism | "Pull" with diaphragm spring | |
|  | Driven disk | With friction seals | |
|  | | | |
|  | Driven disk hub | with single elastic coupling | |
|  | External Ø seal | mm | 235 ⁻⁰ ₋₁ |
|  | Internal Ø seal | mm | 165 ^{+1.5} |
|  | Disk thickness (new) | mm | 7.7 ± 0.3 |
| | Under load | N | 6850 |
| | Minimum thickness due to wear | mm | 1.25 |
|  | Max. off centring driven disk | mm | ~ 0.2 |
|  | Minimum load on thrust plate | N | 6850 |
|  | Max. release load at 9 mm. release height | N | 1400 |
|  | Minimum rise thrust pad at 9 mm. release height | mm | 1.6 |
|  | Disengagement stroke | mm | 9 + 1 |
|  | Max. depression stroke | mm | 9.5 |
|  | Disengagement control | hydraulic | |
|  | Lubricant | - | |


















NOTE Values refer to new clutch

Models 29 L 10 - 29 L 12 - 35 S 10 - 35 S 12 - 35 C 10 - 35 C 12 - 40 C 10 - 40 C 12
Models with 6 AS 300 VD gearbox

| 10" 1/2 CLUTCH | | SACHS | |
|---|---|--|--------------------------------|
|  | Type | Dry single disk | |
|  | | | |
|  | Clutch mechanism | Pull-type, with automatic wear recovery diaphragm spring | |
|  | Driven disk | With friction seals | |
|  | | | |
|  | Driven disk hub | with double elastic coupling springs | |
|  | External Ø seal | mm | 265 ⁰ ₋₁ |
|  | Internal Ø seal | mm | 180 ^{+1.5} |
|  | Disk thickness (new) | mm | 7.6 ± 0.3 |
| | Under load | N | 9000 |
| | Minimum thickness due to wear | mm | 1.25 |
|  | Max. off centring driven disk | mm | ~ 0.4 |
|  | Minimum load on thrust plate | N | 7900 |
|  | Max. release load at 9 mm. release height | N | 1100 |
|  | Minimum rise thrust pad at 9 mm. release height | mm | 1.1 |
|  | Disengagement stroke | mm | 12 ⁺¹ |
|  | Max. depression stroke | mm | 14 |
|  | Disengagement control | Electric actuator controlled by the gearbox control unit | |
|  | Lubricant | - | |

NOTE Values refer to new clutch


















Models 35 S 13 - 35 C 13 - 40 C 11* - 40 C 13 - 45 C 11* - 45 C 13 - 50 C 11* - 50 C 13
A 35 S 13 - A 40 C 13 - A 50 C 13

| | | | |
|---|---|------------------------------|-----------|
| 10" 1/2 CLUTCH | | BORG & BECK | |
|  | Type | Dry single disk | |
|  | | | |
|  | Clutch mechanism | "Pull" with diaphragm spring | |
|  | Driven disk | With friction seals | |
|  | | | |
|  | Driven disk hub | With double hub springs | |
|  | External Ø seal | mm | 267 |
|  | Internal Ø seal | mm | 171.5 |
|  | Disk thickness (new) | mm | 8.5 ± 0.3 |
| | Under load | N | 6800 |
| | Minimum thickness due to wear | mm | 1.5 |
|  | Max. off centring driven disk | mm | ~ 0.2 |
|  | Minimum load on thrust plate | N | 6800 |
|  | Max. release load at 9 mm. release height | N | 1950 |
|  | Minimum rise thrust pad at 9 mm. release height | mm | 1.6 |
|  | Disengagement stroke | mm | 9 + 1 |
|  | Max. depression stroke | mm | 11.2 |
|  | Disengagement control | hydraulic | |
|  | Lubricant | - | |

NOTE Values refer to new clutch

* Only vehicles with 6 speed gearbox 6 S 300


















Models 35 S 13 - 35 C 13 - 40 C 11* - 40 C 13 - 45 C 11* - 45 C 13 - 50 C 11* - 50 C 13
A 35 S 13 - A 40 C 13 - A 50 C 13

| | | | |
|---|---|------------------------------|-----------|
| 10" 1/2 CLUTCH | | VALEO | |
|  | Type | Dry single disk | |
| |  | | |
|  | Clutch mechanism | "Pull" with diaphragm spring | |
| | Driven disk | With friction seals | |
|  |  | | |
|  | Driven disk hub | With double hub springs | |
|  | External Ø seal | mm | 267 |
|  | Internal Ø seal | mm | 171.5 |
|  | Disk thickness (new) | mm | 8.5 ± 0.3 |
| | Under load | N | 6800 |
| | Minimum thickness due to wear | mm | 1.5 |
|  | Max. off centring driven disk | mm | ~ 0.2 |
|  | Minimum load on thrust plate | N | 6800 |
|  | Max. release load at 9 mm. release height | N | 1900 |
|  | Minimum rise thrust pad at 9 mm. release height | mm | 1.5 |
|  | Disengagement stroke | mm | 9 + 1 |
|  | Max. depression stroke | mm | 12.6 |
|  | Disengagement control | hydraulic | |
|  | Lubricant | - | |

NOTE Values refer to new clutch


















* Only vehicles with 6 speed gearbox 6 S 300

Models 35 C 14 - 40 C 14 - 45 C 14 - 50 C 14

| | | | |
|---|---|---|-----------------------------------|
| 11" CLUTCH | | VALEO | |
|  | Type |  | Dry single disk |
|  | Clutch mechanism | | "Pull" with diaphragm spring |
|  | Driven disk |  | With friction seals |
|  | Driven disk hub | | With double hub springs |
|  | External Ø seal | mm | 280 ⁺⁰ ₋₁ |
|  | Internal Ø seal | mm | 170 ⁺¹ _{-0.5} |
|  | Disk thickness (new) | mm | 8.5 ± 0.3 |
| | Under load | N | 8000 |
| | Minimum thickness due to wear | mm | 1.5 |
|  | Max. off centring driven disk | mm | ~ 0.2 |
|  | Minimum load on thrust plate | N | 7000 |
|  | Max. release load at 9 mm. release height | N | 1850 |
|  | Minimum rise thrust pad at 9 mm. release height | mm | 1.5 |
|  | Disengagement stroke | mm | 9 ⁺² ₋₀ |
|  | Max. depression stroke | mm | 13.6 |
|  | Disengagement control | | hydraulic |
|  | Lubricant | | - |


















NOTE Values refer to new clutch

Models 35 C 15 - 50 C 15 - 60 C 15 - 65 C 15 - A 40 C 15 - A 50 C 15 - A 65 C 15

| | | | |
|---|---|------------------------------|-----------------------------------|
| 11" CLUTCH | | VALEO | |
|  | Type | Dry single disk | |
| |  | | |
|  | Clutch mechanism | "Pull" with diaphragm spring | |
|  | Driven disk | With friction seals | |
| |  | | |
|  | Driven disk hub | With double hub springs | |
|  | External Ø seal | mm | 280 |
|  | Internal Ø seal | mm | 171 ⁺¹ _{-0.5} |
|  | Disk thickness (new) | mm | 8.5 ± 0.3 |
| | Under load | N | 8000 |
| | Minimum thickness due to wear | mm | 1.5 |
|  | Max. off centring driven disk | mm | ~ 0.2 |
|  | Minimum load on thrust plate | N | 6800 |
|  | Max. release load at 9 mm. release height | N | 1850 |
|  | Minimum rise thrust pad at 9 mm. release height | mm | 1.5 |
|  | Disengagement stroke | mm | 9 - 1 |
|  | Max. depression stroke | mm | 13.6 |
|  | Disengagement control | hydraulic | |
|  | Lubricant | - | |


















NOTE Values refer to new clutch

Models 35 C 15 - 40 C 15 - 60 C 15 - 65 C 15 - A 40 C 15 - A 50 C 15 - A 65 C 15

| | | | |
|---|---|------------------------------|-----------------------------------|
| 11" CLUTCH | | BORG & BECK | |
|  | Type | Dry single disk | |
|  | | | |
|  | Clutch mechanism | "Pull" with diaphragm spring | |
|  | Driven disk | With friction seals | |
|  | | | |
|  | Driven disk hub | With double hub springs | |
|  | External Ø seal | mm | 280 |
|  | Internal Ø seal | mm | 171 ⁺¹ _{-0,5} |
|  | Disk thickness (new) | mm | 8.5 ± 0.3 |
| | Under load | N | 8000 |
| | Minimum thickness due to wear | mm | 1.5 |
|  | Max. off centring driven disk | mm | ~ 0.2 |
|  | Minimum load on thrust plate | N | 6800 |
|  | Max. release load at 9 mm. release height | N | 1850 |
|  | Minimum rise thrust pad at 9 mm. release height | mm | 1.5 |
|  | Disengagement stroke | mm | 9 - 1 |
|  | Max. depression stroke | mm | 13.6 |
|  | Disengagement control | hydraulic | |
|  | Lubricant | - | |

NOTE Values refer to new clutch

Models 35 S 17 - 35 C 17 - 40 C 17 - 45 C 17 - 50 C 17 - 60 C 17 - 65 C 17

| | | | |
|---|---|---|-----------------------------------|
| 10" 1/2 CLUTCH | | VALEO | |
|  | Type |  | Dry single disk |
|  | Clutch mechanism | | "Pull" with diaphragm spring |
|  | Driven disk |  | With friction seals |
|  | Driven disk hub | | With double hub springs |
|  | External Ø seal | mm | 280 ⁺⁰ ₋₁ |
|  | Internal Ø seal | mm | 170 ⁺¹ _{-0.5} |
|  | Disk thickness (new) | mm | 8.5 ± 0.3 |
| | Under load | N | 8000 |
| | Minimum thickness due to wear | mm | 1.5 |
|  | Max. off centring driven disk | mm | ~ 0.2 |
|  | Minimum load on thrust plate | N | 7500 |
|  | Max. release load at 9 mm. release height | N | 1850 |
|  | Minimum rise thrust pad at 9 mm. release height | mm | 1.4 |
|  | Disengagement stroke | mm | 9 ⁺¹ ₀ |
|  | Max. depression stroke | mm | 13.6 |
|  | Disengagement control | | hydraulic |
|  | Lubricant | | - |

NOTE Values refer to new clutch

TIGHTENING TORQUES

| PART | TORQUE | |
|---|----------------|---------------|
| | Nm | kgm |
| Screw securing clutch to engine flywheel | 46.5 | 4.7 |
| Screw securing operator cylinder mounting to gearbox | 17 ± 2 | 1 ± 0.1 |
| Screw securing pedal board mounting | - | - |
| Screw to secure clutch disengagement lever support to gearbox front cover | 23.5 ± 2.5 | $2,3 \pm 0.2$ |

TOOLS



| TOOL NO. | DESCRIPTION |
|-----------------|--|
| 99370205 |  <p>Guide pin for centring clutch driven disk</p> |

Figure 2



52230


505210 CLUTCH REMOVAL AND REFITTING

Removal

The operation consists of:

- removal-refitting of transmission shafts (see section 505620);
- removal-refitting of gear box (see section 530210).


Figure 3



Insert the centering pin 99370205 (1) in the gear infeed shaft support bearing, to facilitate clutch removal operations.

Remove the fixing screws (2) and remove the thrust pad (3) from the engine flywheel.

Figure 4



Remove the clutch disk (3) by extracting the centering pin 99370205 (2).

Disk plate centering pin (1) located on the engine flywheel.

CHECKS

The checks to be made are as follows:

- the mating surface, on the engine flywheel, of the driven disk must not be excessively worn or scored.
- the teeth of the toothed crown must not be worn or broken.

If this is not the case, disassemble the engine flywheel (operation 540850) as described in the relevant paragraph at section 2.

Proceed on the engine flywheel as described in relevant paragraph (operation 540853) at section 2.

Check that there are no oil leaks, even of a slight entity, from the seal of the rear drive shaft; otherwise remove the flywheel as described in the relevant paragraph. Remove the rear cover complete with sealing rings and replace the same as described at section 2.

Check that the support bearing or bushing of the take up shaft on the gears fitted to the drive shaft are not worn or broken and, if necessary, replace them as described in the relevant paragraph (540852).

Check the condition of the thrust pad; the driven disk support surface must not be scored or excessively worn or should there be signs of overheating; the diaphragm spring must be in perfect condition.

Check the condition of the driven disk:

- the friction seals must not be excessively worn or present signs of overheating, or traces of oil or grease;
- there should be very little backlash between the hub and gear take up shaft;
- the hub rings must not be loose or broken.

When any defects are found, replace the part in question.


The complete clutch is supplied with a spare kit.

The following are supplied singularly:

- the driven disk and collar bearing.

In this case it will necessary to assemble the new parts of the driven disk spring that is to be reused.

Figure 5




Before fitting a new driven disk check that it is centred as follows:

Position the driven disk (1) on a lathe and, with the use of a magnetic base dial gauge (2), check that the surface of the disk is not out of line at any point.

Maximum tolerance allowed for the driven disk is 0.20 mm.


Figure 6



If the disk is out of line use a hook wrench (1) as in the figure.

Refitting


Follow the same procedures as for removal in reverse order and:

-  carefully clean the faying surface of the flywheel disk using methylated spirits or petrol; if any slight scratches are noted remove with an abrasive cloth;
- position the driven disk (3, Figure 4), using the guide pin (2, Figure 4) to obtain perfect centring and to avoid straining the hub when the gears are reconnected;
- position the thrust pad by aligning the holes with the centring grub screws (1, Figure 4) on the engine flywheel;
- assemble and lock the thrust pad fixing screws to the correct torque;

- remove the guide pin;
- reconnect the gears after spreading the grooved shaft with molybdenum disulphide Molikote as described in Section 4;
- adjust the clutch travel as described in the relevant paragraph (operation).

505254 THRUST BEARING REMOVAL AND REFITTING

Figure 7



36800


The operation consists of:

- removal-refitting of transmission shafts (see section 505620);
- removal-refitting of gear box (see section 530210).

By using the appropriate pliers open the split pin (1) and extract the collar bearing (2) from the thrust pad.

To assemble, carry out the disassembly operations in reverse.

NOTE The new part must be of the same supply as the driven disk that is to be reused.

505260 HYDRAULIC CLUTCH DRIVE**Figure 8**

50967

The hydraulic clutch drive is composed of:

- a master cylinder (1) mounted on the pedal board and connected to the clutch pedal (5), with an integrated oil tank (3).
- an operating cylinder (7) fixed to the gearbox (6).
- an oil pipe (4).


NOTE The components of the hydraulic drive must never be dismantled or separated from each other in any way. The cover (2) of the oil tank (3) must not be removed.

This assembly requires no maintenance and the hydraulic circuit must not be vented.

In the event of defectiveness, the entire assembly needs to be replaced as it is supplied as a spare part, proceeding as described under the relevant heading.

The clip (8) holding the push rod (9) on the assembly supplied as a spare part must not be removed or cut.

Figure 9



SPECIFICATIONS AND DATA


62090

| | |
|----------------------------------|-------------------------------|
| Main cylinder diameter | 18 mm |
| Main cylinder section | 254.47 mm ² |
| Operating cylinder diameter | 22 mm |
| Operating cylinder section | 346.36 mm ² |
| Clutch pedal ratio | 5.85 |
| Hydraulic ratio | 1.36 |
| Clutch disengagement lever ratio | 1.67 |
| Overall reduction ratio | 13.28 |
| Max disengagement stroke X | ▲ (94) ● (99) ■ (98.7) mm |
| Max wear stroke Y | ▲ (67.5) ● (70.8) ■ (69.1) mm |

- ▲ 9 " 1/4 CLUTCH
- 10 " 1/2 CLUTCH
- 11" CLUTCH

HYDRAULIC CLUTCH DRIVE REMOVAL - REFITTING

Figure 10

**Removal**

Position the vehicle over the pit or on the lift.
From inside the cab, using a screwdriver, unhook the swivel head (2) of the master cylinder push rod from the clutch pedal link pin (3).

NOTE Do not act on the pin (3) to prevent it coming out of the pedal board (1).

Working from the engine bay, turn the master cylinder (4) to the right (approx. 1/8 of a turn) to align the square of the hole (A) in the pedal board (1) with the square (B) of the master cylinder body and extract it from the pedal board (1).

Working under the vehicle, disengage the operating cylinder (8 detail C) by unscrewing the screws (6 detail C) securing the cylinder mounting (7 detail C) from the gearbox.

Remove the hydraulic clutch drive assembly from the vehicle.


**Refitting**

50968

For refitting, carry out the operations for removal in reverse order, taking the following precautions:

- Do not press the clutch pedal until refitting is complete.
- During assembly, handle parts carefully.
- Lubricate the contact surfaces of the clutch disengagement lever with the clutch pedal link pin.
- Lubricate the contact surface of the master cylinder swivel head with the clutch pedal link pin.
- After refitting the operating cylinder mounting to the gearbox, check that the cylinder push rod is aligned with the clutch disengagement lever seat.
- If replacing with a new hydraulic drive assembly, after refitting, press firmly on the clutch pedal so as to break or free the clamp holding the push rod (9).
- Lift the clutch pedal by hand with a force of no greater than 5 daN to its limit and hold it in this position for at least five seconds so that the oil from the tank will supply the master cylinder. Repeat this operation if necessary.


Figure 11



MASTER CYLINDER

52235


Figure 12



OPERATING CYLINDER

52236

Figure 13



87895

The operating cylinder makes up for the wear of the driven disc marking an increase in load on the pedal during disengagement when the wear on the driven disc gets to be 90%.

Maximum disengagement position when new

a = 121.8 mm.

a1 = 112.8 mm.

Engagement position when new

b = 99.3 5.8 mm.

b1 = 89.8 mm

Minimum position with worn disc


c = 73.3 mm.

c1 = 63.8 mm


502601 PEDAL BOARD REMOVAL - RE-FITTING

Removal

Figure 14




Set a proper container under the brake pipes (4) and remove them from the brake pump (1) of the vacuum brake (3).

 When draining the brake oil, take care it does not come into contact with anyone, clothes, or painted parts.

Disconnect the electrical connection (2) from the brake liquid tank plug.

Figure 15



From inside the cab:

For vehicles with electronic injection only


Remove the side guard (7), disconnect the electrical connection (6) from the accelerator pedal (4). Take out the screws (5) and remove the accelerator pedal (4) from the pedal board.

For vehicles with mechanical injection pump and mechanical clutch drive only

Disconnect the accelerator cable and the clutch disengagement cable from their respective pedals.

Remove the fastener (1) and disconnect the brake pedal (8) from the servo brake fork (3) by extracting the pin (2).

Figure 16




Remove the four nuts (2) fixing the servo brake (3) and take this out of the engine bay.

For vehicles with electronic injection only

Disconnect the electrical connection (1) from the sensor on the clutch pedal and the electrical connection (4) from the sensor on the brake pedal. Disconnect the electrical connection (5) from the switch on the brake pedal.

Figure 17



Disconnect the clutch drive master cylinder (1) from the pedal board as described under the relevant heading and set it aside appropriately in the engine bay, taking care not to damage or bend the oil pipe.

Take out the nuts (2) and remove the pedal board (3).





Refitting

For refitting, carry out the operations described for removal in reverse order, taking the following precautions:

- tighten the nuts/screws to the required tightening torque under the relevant heading;
- refit the clutch drive cylinder as described under the relevant heading;
- fill the brake liquid tank with the required quantity and grade and bleed the air (operation 784010) as described under the relevant heading;
- after making the electrical connections, check the efficiency of the connected components.

PEDAL BOARD

Figure 18



62091

A. Pedal board with mechanical accelerator pedal
B. Electronic accelerator pedal


NOTE The only repair operations to be performed on the pedal-assy are the following:

- accelerator pedal replacement;
- sensor replacement.

In any other case, replace the pedal using the above-mentioned components if they are serviceable.

CLUTCH WITH AUTOMATIC WEAR RECOVERY - COMBINED WITH 6 AS'300 VD GEARBOX

Figure 19



102089

1. Sliding wedge - 2. Wedge (1) actuating spring - 3. Wear recovery ring (6 & 7) actuating spring - 4. Wear indicator - 5. Retainer - 6. Wear recovery upper sliding ring - 7. Wear recovery lower ring - 8. Diaphragm spring

Description


The automatic wear recovery device is placed between the diaphragm spring and the thrust plate of the pressure plate assembly. It is essentially made up of wedge-shaped rings which recover, under sliding conditions, the clutch disc wear real-time, while keeping both the diaphragm spring characteristics and the force required to actuate the spring unchanged.

Operation

Automatic wear recovery takes place in two separate phases:

- Phase 1: every time the clutch is closed (engaged) and the clutch disc wear – as detected by retainer (3) – is such that the pressure plate is made to travel an extra stroke, spring (4) will disengage wedge (1), which will be pulled by spring (2) and will stop again against spring (4) and retainer (5) after travelling a stroke equal to the disc wear.
- Phase 2: when the clutch is opened (disengaged), diaphragm spring (8) will release wear recovery rings (6 & 7); as a result, spring (3) will, by causing lower ring (6) to slide over upper ring (7) due to the inclined planes of the same, lift the latter by an amount equal to the clutch disc wear.

Figure 20



102090

CLUTCH DISC AUTOMATIC WEAR RECOVERY DIAGRAM

A. Position of the diaphragm spring with a new clutch disc - B. Position of the diaphragm spring with a worn clutch disc prior to operation of the automatic wear recovery device - C. Position of the diaphragm spring with a worn clutch disc after operation of the automatic wear recovery device

1. Retainer - 2. Lower ring - 3. Upper ring - 4. Clutch disc - 5. Retainer (1) spring -
6. Diaphragm spring - 7. Wear recovery ring actuating spring

← = ring (2) sliding
↑ = ring (3) lifting


505210 REMOVAL AND REFITTING OF CLUTCH WITH RECOVERY COMBINED

Removal

The operation consists of:

- removal-refitting of transmission shafts (see section 505620)
- removal-refitting of gear box (see section 530210).


Figure 21



Insert clutch centring pin 99370205 (1) in the shaft support bearing.

Locate the position of retainer (2): it is positioned between the engine flywheel plug for clutch assembly centering and a hole for the screw used to fasten the same. It sticks out the clutch assembly by approximately 3 mm.


Figure 22



Loosen screws (4) that secure pressure plate (1) to the flywheel in 5 steps in crossed sequence until a distance of 2 mm is obtained between retainer (2) and the clutch. Also make sure that retainer (2) is released from pressure plate (1); otherwise, use a suitable beater (3) to hit the top of retainer (2).

Then remove screws (4) and take the pressure plate off the engine flywheel.

Figure 23



Remove the clutch disk (3) by extracting the centring pin 99370205 (2).

Disk plate centering pin (1) located on the engine flywheel.

CHECKS

The checks to be made are as follows:

- the faying surface, on the engine flywheel, of the driven disk must not be excessively worn or scored.
- the teeth of the toothed crown must not be worn or broken.

If this is not the case, disassemble the engine flywheel (operation 540850) as described in the relevant paragraph at section 2.

Proceed on the engine flywheel as described in relevant paragraph (operation 540853) at section 2.

Check that there are no oil leaks, even of a slight entity, from the seal of the rear drive shaft; otherwise remove the flywheel as described in the relevant paragraph.

Replace the seal ring as described in section 2.

Check that the support bearing or bushing of the take up shaft on the gears fitted to the drive shaft are not worn or broken and, if necessary, replace them as described in the relevant paragraph (540852).

Check the condition of the thrust pad; the driven disk support surface must not be scored or excessively worn or should there be signs of overheating; the diaphragm spring must be in perfect condition.

Check the condition of the driven disk:

- the friction seals must not be excessively worn or present signs of overheating, or traces of oil or grease;
- there should be very little backlash between the hub and gear take up shaft;
- the hub rings must not be loose or broken.

Should any anomaly be found, the full clutch shall be replaced. Inspect the conditions of the clutch-release bearing and the release lever, should any anomaly be found, the concerned part shall be replaced.

NOTE In the event that the clutch release lever is replaced, calibration shall be carried out after re-attaching the gearbox, as described in the relevant charter of the "Gearbox" section.

Refitting

Follow the same procedures as for removal in reverse order and:



- carefully clean the faying surface of the flywheel disk using methylated spirits or petrol; if any slight scratches are noted remove with an abrasive cloth;
- position the driven disk (3, Figure 23), using the guide pin to obtain perfect centring and to avoid straining the hub when the gears are reconnected;
- position the thrust pad by aligning the holes with the grub screws (1, Figure 23) on the engine flywheel;
- screw down the pressure plate fastening screws in four subsequent steps and in crossed sequence, then tighten them to the specified torque

SECTION 4

5302 Transmission

| | Page |
|---|-------|
| DIAGNOSTICS | 3 |
| TRANSMISSION REMOVAL - REFITTING | 7 |
| <input type="checkbox"/> Removal | 7 |
| <input type="checkbox"/> Refitting | 7 |
| GEAR CONTROL | 8 |
| 5 S 200 - 5 S 270 - 5 S 300 - TRANSMISSIONS . | 9 |
| 6 S 300 TRANSMISSION | 43 |
| 6 S 380 O.D. TRANSMISSION | 83 |
| 6 AS 300 VD TRANSMISSION | 122/1 |
| POWER TAKE-OFFS | 123 |

DIAGNOSTICS

Main transmission operation faults:

1 - noisy transmission;

2 - noisy transmission only in reverse speed;

3 - gear spontaneous disengagement;

4 - difficult speed engagement or selection;

5 - leakages of lubricant.

1 NOISY TRANSMISSION



Insufficient lubricating oil level.

- YES ->

Add **TUTELA TRUCK GEARLITE** oil up to proper level.

NO



Screws which fasten the transmission to the chassis are loose.

- YES ->

Tighten loose screws properly.

NO



Excessive backlash between gears.

- YES ->

Overhaul transmission and replace worn gears.

NO



Gears, bearings, synchronizer rings and sliding sleeves worn. Springs broken.

- YES ->

Replace worn or damaged components.


2 NOISY TRANSMISSION ONLY IN REVERSE SPEED




Reverse speed or connected gears damaged.

- YES ->

Overhaul transmission.





TRANSMISSION REMOVAL - REFITTING

Removal

Here we describe the removal-refitting operations for the 6 S 300 transmission that, unless specified otherwise, also hold for the 5 S 200 - 5 S 270 - 5 S 300 - 6 S 380 O.D. transmission.

Position the vehicle over the pit or on a lift or on special stands.

From the engine bay remove the screws fastening the starter motor to the front cover of the transmission.

Remove the starter motor and put it appropriately aside in the engine bay.

From underneath the vehicle:

- remove the soundproofing guards;
- disconnect the exhaust pipe (17) from the turbocharger pipe.

Remove the seal from the ring nut (25), unscrew it and disconnect the speedometer control cable.

Disconnect the electrical connection (22) of the reversing light.

Unscrew the screws (23) securing the propeller shaft (24) to the transmission.

Secure the propeller shaft to the chassis frame appropriately.

Unscrew the screws (4 and 6) securing the brackets (5 and 7) and disconnect the bowdens (3 and 8) of the gear levers.

For vehicles with hydraulic clutch drive

Unscrew the fixing screws (2), shift the clutch drive cylinder (1) with its bracket and secure it to the chassis frame appropriately.

For vehicles with mechanical clutch drive

Take out the nut (13), flanged nut (12) and the flexible plug beneath. Remove the cable (10) from the clutch disengagement lever (11) and from the bracket (9). Remove the bracket (9).

For all vehicles

Using a hydraulic jack, position bracket 99370629 under the transmission. Lay the chain on the transmission and put one of its links into the slot in the bracket. Screw on the nut so as to firmly secure the transmission to the bracket with the chain. Take out the screws (20) securing the transmission to the crankcase. Unscrew the fixing screws (19), the fixing screw (21) and the plug and remove the crosspiece (18) supporting the transmission with its plug. Retract the gearbox to withdraw gear input shaft from clutch plate hub, then lower the hydraulic jack. During lowering the gearbox must not hit or be caught in other components.

At the same time, another operator should move the transmission back to remove its drive input shaft from the clutch disc hub. Then, lower the hydraulic jack while checking that the transmission does not knock against or get caught up with any other parts as it comes down.

Refitting

NOTE Before re-attaching the gearbox, check gear selection and engagement levers mounting, as described on pages 24, 60 and 100.

Refitting the transmission is not particularly difficult. It is sufficient to carry out the operations described for removal in reverse order. Only when coupling the clutch to the transmission is it necessary to take the following precautions.


Using appropriate pliers, open the retaining ring (16) and extract the pressure plate bearing (15) from the diaphragm spring (14) of the clutch. Mount the pressure plate bearing on the sleeve of the drive input shaft cover, connecting it to the clutch disengagement lever. Spread the transmission input shaft with Molikote molybdenum disulphide grease.

Engage a gear to permit rotation of the main shaft by turning the propeller shaft connection flange. Push the transmission fully in so that the pressure plate bearing (15) is correctly engaged in the diaphragm spring.

When connecting the propeller shaft, use new nuts for the screws securing the relative flanges. All nuts and bolts must be tightened to the required torques given in the relevant tables.

Adjust the height of the clutch pedal as described in the relevant paragraph (vehicles with mechanical clutch drive). After refitting the transmission, check that the electrical cables are connected properly. Check that the gears engage correctly. If they do not, proceed as described under the gear control heading.

Figure 1



GEAR CONTROL

Gear control is accomplished with two Bowden cables. The blue cable (6) with the IVECO trademark operates the lever (4) for engaging gears.

The white cable (1) with the IVECO trademark operates the lever (8) for selecting gears.

The length of the cables measured between the c/c distances of the swivel heads must be:

- 780 ±2 mm engagement cable (6);
- 1280 ±2 mm selection cable (1).

The selection (8) and engagement (4) levers must be mounted on their respective shafts so that:

- between the c/c distance of the pin of the lever (8) for connecting the swivel head and the outside of the bracket (2) there is a distance X of 134 ±0.75 mm;
- between the c/c distance of the pin of the lever (4) for connecting the swivel head (3) and the outside of the bracket (5) there is a distance Y of 135 ±0.75 mm.

NOTE Before assembly, lubricate the points of connection of the swivel heads with the Bowden cables with TUTELA MRM2 grease.

- Engagement cable (6):
 - Left-hand drive vehicles, 758.5 ±2 mm.
 - Right-hand drive vehicles, 1058.5 ±2 mm.
- Selector cable (1):
 - Left-hand drive vehicles, 1216 ±2 mm.
 - Right-hand drive vehicles, 1566.5 ±2 mm.

For vehicles fitting 6S300 transmission and synchronised reverse only.


SELECTION WIRE (1) ADJUSTMENT.

Remove the screw (13) and detach the cover (12) from the gear lever support.

Engage either 1st or 2nd gear and check that there is a distance of 2 mm between the gear lever (10) and the stop (9); proceed as follows if this is not so:

- remove the ball joint (14) from the connecting ball pin (15);
- loosen the fastening nut (16);
- arrange a 2 mm shim (11) between stop (9) and lever (10);
- hold the lever (10), shim (11) and stop (9) in contact and turn the ball joint (15) until it reaches the ball pin (15);
- fasten and check that all the gears can be engaged;
- tightening the fastening nut (16);
- reattach the cover (12) and tighten the fastening screws (13).

Figure 2



5 S 200 - 5 S 270 - 5 S 300 Transmissions

| | Page |
|--|------|
| GENERAL | 11 |
| GEAR SELECTION AND ENGAGEMENT CONTROL | 12 |
| SAFETY DEVICES | 13 |
| <input type="checkbox"/> Engagement locking device | 13 |
| <input type="checkbox"/> Reverse gear anti-engagement device | 13 |
| SPECIFICATIONS AND DATA | 14 |
| TIGHTENING TORQUES | 16 |
| TOOLS | 17 |
| OVERHAULING THE TRANSMISSION | 23 |
| <input type="checkbox"/> Gear control box | 23 |
| <input type="checkbox"/> Disassembly | 23 |
| <input type="checkbox"/> Assembly | 23 |
| <input type="checkbox"/> Disassembling the transmission | 25 |
| <input type="checkbox"/> Disassembling the rear cover bearings | 27 |
| <input type="checkbox"/> Disassembling the transmission bearings | 27 |
| <input type="checkbox"/> Disassembling the main shaft | 28 |
| <input type="checkbox"/> Drive input shaft | 30 |
| <input type="checkbox"/> Disassembling the transmission shaft | 30 |
| CHECKS | 33 |
| <input type="checkbox"/> Transmission | 33 |
| <input type="checkbox"/> Hubs - sliding sleeves - forks | 33 |
| <input type="checkbox"/> Bearings | 33 |
| <input type="checkbox"/> Shafts - gears | 33 |
| <input type="checkbox"/> Synchronizing devices | 33 |
| <input type="checkbox"/> Mounting the transmission shaft | 34 |
| <input type="checkbox"/> Mounting the main shaft | 34 |
| <input type="checkbox"/> Rods - forks - selector - driver | 37 |

Page

| | |
|--|----|
| <input type="checkbox"/> Disassembly - assembly | 37 |
| <input type="checkbox"/> Mounting the transmission | 37 |
| <input type="checkbox"/> Adjusting the transmission shaft bearing end float | 37 |

GENERAL

The 5 S 200 - 5 S 270 and 5 S 300 transmission is mechanical with synchronized engagement of forward gears.

It is composed of a light alloy box (which also serves as a clutch cover), a rear cover (where the speed engagement controls and gearing are housed) and a control box.

There is an opening on the side of the transmission to apply a power take-off.

Drive transmission is accomplished by a set of helical-toothed constant mesh gears, for both forward and reverse gears.

The splined or machined gears are on four shafts: input, main, transmission and reverse gear.

The gears splined on the main and reverse gear shafts idle on straight roller bearings.

The input and main shafts are supported, in the transmission, by watertight, non-adjustable ball bearings.

The transmission shaft is supported, in the transmission, by tapered roller bearings that can be adjusted axially by means of ring shims.


Gear engagement synchronization is accomplished by means of free ring synchronizing devices with a single cone for 5th - 4th - 3rd gears -R.G. and dual cone for 1st - 2nd gears.

Control inside the transmission is accomplished with four rods:

- a main rod to select and engage gears;
- three rods equipped with forks for engaging gears.

The external engagement lever is equipped with two opposing masses. These have the task of attenuating the force of engagement of the control cable (BOWDEN) and consequently the noise level.

Figure 1



51380

GEAR SELECTION AND ENGAGEMENT CONTROL

The combined action of the selection (2) and engagement (1) levers bring about the rotation and/or axial shift of the rod (4) in two successive stages, engaging the desired gear by means of one of the rods (9, 8 or 7).

First Stage


Depending on the angular position of the selection lever (2), the driver (3) (integral with it) turns the selector (5) with the rod (4) (connected together), setting the selector on the rod of the chosen gear.

Second Stage

Depending on the movement given to the engagement lever (1), the driver (3) (integral with it) shifts the selector (5) (already prepared) axially with the rod (4) and consequently also the engagement rod of the chosen gear.

Position of transmission in neutral and/or ready to select 3rd/4th gear


Figure 2



49373

Ready for 1st/2nd gear

Figure 3



49372

- 1. Gear engagement lever - 2. Gear selection lever - 3. Driver - 4. Gear selection/engagement control rod -
- 5. Selector - 6. Driver - 7. Rod for 3rd/4th gear engagement fork - 8. Rod for 1st/2nd gear engagement fork -
- 9. Rod for 5th/reverse gear engagement fork.


The position of the transmission in neutral coincides with being ready to select 3rd/4th gear.

In this case the vertical axis of the selection lever (2) is exactly 90° from the horizontal control axis, corresponding to no change in the angle of the rod (4).

This arrangement is accomplished by shifting the selection lever (2) anticlockwise by 7.1° to the control axis, which corresponds to a clockwise change in the angle of the rod (4) of 10°.


Ready to select 5th/reverse gear

Figure 4



- 1. Gear engagement lever - 2. Gear selection lever -
- 3. Driver - 4. Gear selection/engagement control rod -
- 5. Selector - 6. Driver - 7. Rod for 3rd/4th gear engagement fork -
- 8. Rod for 1st/2nd gear engagement fork -
- 9. Rod for 5th/reverse gear engagement fork.

Above presetting is implemented by moving selector (2) clockwise by 7.1° with respect to control vertical axis, that corresponds to 10° anticlockwise angular displacement of rod (4).



51381

This device is composed of a plate (8) and a spring (7) housed in the transmission. When passing from the 4th gear position (Figure A) to the 5th gear position (Figure B), the driver (9), moving in the direction of the arrow, disengages the plate (8), which under the action of the spring (7) moves onto the driver (9) preventing reverse gear from getting engaged in the opposite manoeuvre.

SAFETY DEVICES


The transmission is equipped with two mechanical safety devices:

Engagement locking device to prevent more than one gear getting engaged at the same time.

Reverse gear anti-engagement device when passing from 5th to 4th gear.

Engagement locking device

Figure 5










49375














This device is composed of a plate (1), housed in the rear cover, operated by the gear selection/engagement control rod (2). When selecting/engaging a gear, the rod (2) simultaneously turns the plate (1) in which it is inserted. In this way, the plate (1) will free itself from the slot of the rod involved in engaging the gear and will lock the other two rods by inserting itself into their slots.

Reverse gear anti-engagement device

Figure 6

SPECIFICATIONS AND DATA


| | TRANSMISSION | 5 S 200 | 5 S 270 | 5 S 300 |
|---|---|---|---------|---------|
|  | Type | Mechanical | | |
| | Input torque Nm | 250 | 270 | 300 |
| | Weight kg | 44.6 | | |
|  | Speeds | 5 forward speeds 1 reverse speed | | |
| | Speed control | Mechanical | | |
|  | Power take-off | Optional | | |
|  | Speed engagement: Forward speeds <input type="checkbox"/> 5 th / 4 th / 3 rd <input type="checkbox"/> 2 nd / 1 st Reverse speed Speed retention mechanism | Single-cone synchronizer Dual-cone synchronizer Single-cone synchronizer Sliding sleeves retained by pawls and springs | | |
|  | Gears | Helical-toothed constant mesh gears | | |
|  | Gear ratio First Second Third Fourth Fifth (overdrive) Reverse | 4.99 2.60 1.52 1.00 0.78 4.51 | | |
|  | Shaft bearings: Main shaft Transmission shaft | watertight ball bearing tapered roller | | |

| | TRANSMISSION | 5 S 200 | 5 S 270 | 5 S 300 |
|---|--|--|---------|---------|
|  | Transmission shaft bearing end play: | 0 ± 0.05 mm | | |
|  | Transmission shaft bearing end play adjustment | by shims | | |
|  | Shim thickness for transmission shaft bearing end play adjustment | 2.00 - 2.30 - 2.45 mm with 0.05 mm progressive sequence | | |
|  | Main shaft Assembly temperatures: sliding sleeve hubs 2 nd and 3 rd speed gear bushings and spacer 5 th speed gear spacer | 150°C 170°C ± 160°C 90°C | | |
|  | Secondary shaft Assembly temperatures: bearings 5 th speed gear 5 th speed gear driving load 5 th speed gear removing load | 80°C (max 120°C) 140°C ± 170°C 31 KN 50 KN | | |
|  | Input shaft Assembly temperatures: front bearing* | 80°C (max 120°C) | | |
|  | Gear axial backlash: 1 st - 3 rd - 4 th - R - 5 th speed 2 nd speed | 0.15 ± 0.3 mm 0.25 ± 0.4 mm | | |
|  | 3 rd and 4 th speed sliding sleeve hub retaining circlip axial backlash | 0 ± 0.05 mm | | |
|  | 3 rd and 4 th speed sliding sleeve hub retaining circlip thickness | 2 - 2.85 mm with progression of 0.05 mm | | |
|  | Transmission shaft rear bearing retaining ring end float | 0 ± 0,05 mm | | |
|  | Transmission shaft rear bearing retaining ring thickness | 2.05 ± 2.45 mm with progression of 0.05 mm | | |
|  | LOCTITE sealant | 242 510 5206 | | |
|  | Type of oil: Quantity | TUTELA TRUCK GEARLITE 2 litres 1,8 kg | | |

* = Do not use hot air equipment to heat bearing.

TIGHTENING TORQUES

Figure 7









50969

| | DESCRIPTION | TORQUE | |
|-----|--|--------------|--------------|
| | | Nm | kgm |
| 1 | Clutch housing, screw to fasten clutch housing to chassis | 80 | 8 |
| 2 | Screw to fasten clutch housing to box | 23 ±15% | 2.3 ±15% |
| 3 | Constant mesh shaft cover fastening screw | 23 ±15% | 2.3 ±15% |
| 4 | Spring retaining plug | 32 ±10% | 3.2 ±10% |
| 5 | Grub screw securing gear selection sector to rod | 60 ±15% | 6 ±15% |
| 6** | Screw securing p.t.o. side cover | 46 ±15% | 4.6 ±15% |
| 7 | Plug | 28 ÷ 30 ±15% | 2.8 ÷ 3 ±15% |
| 8 | Screw securing reverse gear shaft | 22 ±15% | 2.2 ±15% |
| 9 | Screw securing rear cover | 23 ±15% | 2.3 ±15% |
| 10 | Screw locking sleeve for transmission coupling on main shaft | 120 ±15% | 12 ±15% |
| 11● | Screw securing ball bearing retaining ring | 9.5 ±15% | 0.9 ±15% |
| 12 | Screw securing control cable bracket | 23 ±15% | 2.3 ±15% |
| 13 | Screw securing gear control mounting | 23 ±15% | 2.3 ±15% |
| 14 | Nut for screw securing lever to control rod | 34 ±15% | 3.4 ±15% |
| 15 | Nut securing articulation pin to control lever | 23 ±15% | 2.3 ±15% |
| 16 | Nut for screw securing lever to control rod | 34 ±15% | 3.4 ±15% |
| 17 | Oil vapour breather | 10 ±15% | 1 ±15% |
| 18 | Nut to secure articulation pin to control lever | 23 ±15% | 2.3 ±15% |

* Spread LOCTITE 5206 sealant on the contact surfaces

● Spread LOCTITE 242 on the thread

** Spread LOCTITE 510 on the thread

| TOOLS | |
|-----------------|--|
| TOOL NO. | DESCRIPTION |
| 99322205 |  <p>Assemblies overhaul revolving stand</p> |
| 99322225 |  <p>Unit support (to use with stand 99322205)</p> |
| 99340205 |  <p>Percussion extractor</p> |
| 99341002 |  <p>Single-acting scaffold</p> |
| 99341003 |  <p>Single-acting scaffold</p> |
| 99341004 |  <p>Single-acting scaffold</p> |

TOOLS

| TOOL NO. | DESCRIPTION |
|----------|---|
| 99341012 | Pair of brackets |
| 99341015 | Press |
| 99341017 | Couple of brackets whit hole |
| 99341019 | Pair of tie rods with grips |
| 99341025 | Grips |
| 99345003 | Extractor for gearbox front half-casing |


TOOLS

| TOOL NO. | DESCRIPTION |
|-----------------|---|
| 99348001 | Extractor with locking device |
| 99348004 | Universal male extractor from 5 to 70 mm |
| 99360521 | Tool to extract and insert main shaft, transmission shaft and rod - fork assembly |
| 99370006 | Handle for interchangeable drivers |
| 99370007 | Handle for interchangeable drivers |
| 99370234 | Tool for fitting main shaft in rear bearing and fitting output flange on main shaft |

TOOLS

| TOOL NO. | DESCRIPTION |
|-----------------|---|
| 99370317 | Reaction lever with extension for holding flange |
| 99370629 | Transmission support during removal from and refitting to vehicle |
| 99371057 | Bracket for supporting gearbox during overhaul (use with 99322205-99322225) |
| 99374091 | Punch for fitting bearing external races (dia. 55 ÷ 69 mm) (use with 99370007) |
| 99374452 | Keying device to fit gasket on transmission rear cover (use with 99370006) |
| 99374453 | Keying device to fit gasket on transmission |


Figure 8



75420

LONGITUDINAL SECTION


Figure 9



47371

TRANSVERSE SECTION ON THE GEAR
SELECTION/ENGAGEMENT ROD
POSITIONING PUSH ROD


Figure 10



47369

TRANSVERSE SECTION ON THE REVERSE GEAR
ANTI-ENGAGEMENT DEVICE


Figure 11



49364

SECTION ON GEAR ENGAGEMENT ROD POSITIONING PAWLS

Figure 12




49368

TRANSVERSE SECTION ON INTERNAL CONTROL BOX

530210 OVERHAULING THE TRANSMISSION

Figure 13



Remove the plug and drain off the lubricating oil.




The used oil must be disposed of according to the law in force.

Fit the gearbox (1) with the bracket 99371057 (4) and secure this to the brackets 99322225 (3) on the rotary stand 99322205 (2).


530220 Gear control box Disassembly

Figure 14




Take out the fixing screws (1) and remove the gear control box (2).

Figure 15




Mark the assembly position of the levers (2 and 7) on their respective shafts (1 and 8). Loosen the nuts (3) for the retaining screws (6). Extract the levers (2 and 7) from the shafts (1 and 8) and extract these from the box (5). Take off the caps (4).

Figure 16



With a punch (3), remove the spring pin (4) and extract the shaft (2) from the internal lever (1). Repeat these steps for the other shaft.


Figure 17



Use a punch on the point shown by the arrow and eject the O-rings and roller bushes (2) from the box (1).


Assembly

Figure 18



Thoroughly clean the oil vapour vent (3). With a suitable punch, mount the roller bearings (1) in the box (2).


Figure 19



Using a suitable punch, mount the O-rings (1) in the box (2), positioning them at the height shown.

Pack the gap between the O-ring and roller bearing with grease.


Figure 20



Mount the selection and engagement levers (1) on their respective shafts (2) and fasten them with the spring pins (3).


NOTE The spring pin (3) must be positioned with the cut horizontal. Fit spring peg (4), with cutting edge positioned at 180° from spring peg (3) cutting edge, in spring peg (3) engagement lever.

Figure 21



Lubricate the roller bearings (1, Figure 19) with TUTELA MR3 grease and mount the shafts (3 and 6) complete with the internal levers (4 and 5) in the box (2). Mount the caps (8 and 9) and levers (1 and 10) on the shafts (3 and 6) in the position marked during disassembly without tightening the nuts for the fixing screw (7).

Figure 22




Thoroughly clean the mating surfaces of the gear control box (2) and apply LOCTITE 5206 sealant on them.

Fit the box (2) on the transmission, taking care that the levers and shafts are positioned correctly in their respective seats.

Tighten the screws (1) to the required torque.

Check levers mounting

Figure 23



Check the assembly of the selection (6) and engagement (3) levers. The selection (6) and engagement (3) levers must be mounted on their respective shafts so that:


- between the c/c distance of the pin (5) of the selection lever (6) and the outside of the bracket (1) there is a distance **X** of 134 mm;
- between the c/c distance of the pin (2) of the engagement lever (3) and the outside of the bracket (4) there is a distance **Y** of 135 mm.

If a different value is measured, orientate the lever concerned on the respective shaft appropriately.

Then tighten the nuts (7) for the screws (8) to the required tightening torque.

Disassembling the transmission

Figure 24




51393

Dismantle the gear control box as described under the relevant heading.

Remove the reverse gear stop plate (2) and the spring (1).

Figure 25




74955

Block rotation of the sleeve (1) by applying the lever 99370317 (3). With the bushing (2) remove the screw (5) with the washer beneath (4).

Take out the lever 99370317 (3).


Figure 26



74956

Apply the bridge 99341003 (1) and clamps 99341017 (2) onto the sleeve (3).
Extract the sleeve (3) from the main shaft.


Figure 27



51396

Remove the screws (1) and take off the cover (2) protecting the input shaft (3).

Figure 28




51397

Drill the O-ring (2).

Using a suitable hook and extractor (1), remove the O-ring (2) from the transmission.


Figure 29



51398


Remove the circlip (2) retaining the front bearing (3) from the input shaft (1).

Figure 30




Take out the plug with the washer (1), extract the springs (2 and 3) and the push rod (4). Remove the screw (6) securing the reverse gear shaft to the transmission (5). Push the two centring pins (7) downwards to free them from the transmission (5). Remove the screws (8) securing the rear cover (9) to the transmission (5).

Figure 31




Fit the drive input shaft (1) with tool 99345003 (2) and secure this to the gearbox (4) with screws (3). Screw down the screw (5) of the tool (2) to extract the gearbox from the bearing (6).

Figure 32




Take out the screw (3) and extract the shaft (1) from the rear cover (4). Remove the reverse gear (2). Drill the cups (10) screw a special screw into them; with the aid of the screw, extract the cups (10) from the rear cover (4). Remove the springs (9) and the pawls (8). Extract the rod (7) together with the selector (5) and driver (6).

Figure 33



Insert an Allen wrench (2) into the engagement locking plate (5). Turn the Allen wrench (2) to position the engagement locking plate (5) outside the slots (⇒) in the engagement rods (1, 3 and 4).


Figure 34



Mount the tool 99360521 (3) onto the rods (4, 5 and 6), on the input shaft (1) and on the transmission shaft (10). Secure the tool 99360521 (3) on the input shaft (1) with the retaining ring (2) and with the screw (9) to the transmission shaft (10). Hook the tool 99360521 (3) onto the lift. Apply the extractor composed of the bridge 99341004 (13) and ties 99341012 (12) onto the rear cover (7). Use the screw of the bridge (13) and work on the lift to extract the main shaft (11) from the rear bearing. Set this assembly on the workbench. Remove the tool 99360521 (3) and separate the transmission shaft (10), input shaft with relative synchronizing ring and the rods (4, 5 and 6) from the main shaft.

Disassembling the rear cover bearings


Figure 35



51404

Remove the screws (2) securing the plates (3).
Take out the plates (3) and the engagement locking plate (1).


Figure 36



74960

Using universal extractor 99348004 (1), remove the outer ring (2) of the transmission shaft bearing.


Figure 37



51406

Using the percussion extractor 99340205 (1) and part 99348004 (2), extract the bushing with the ball bearings (3).

Figure 38




74961

Turn over the rear cover (3). Take out the O-ring (1) and the "phonic wheel" (2). Using a suitable punch, remove the ball bearing (4, Figure 36). Remove the tachograph sensor (5) and the reversing light switch (4).

Disassembling the transmission bearings


Figure 39



74962

Using universal extractor 99348004 (1), remove the outer ring (2) of the transmission shaft bearing.


Figure 40



51409

Using the percussion extractor 99340205 (1) and part 99348004 (2), extract the bushing with the ball bearings (3).


Figure 41



51410

Remove the screws (1) securing the plates (2).
Take out the plates (2).


Figure 42



51411

Turn over the transmission.
Using a suitable punch, remove the ball bearing (1).

Figure 43




51412

Using the percussion extractor 99340205 (1) and part 99348004 (2), extract the roller bearing (3).

Disassembling the main shaft

NOTE Mark the assembly position of each synchronizing device on the respective gears.


Figure 44



51413

Clamp the main shaft (1) in a vice. Remove the roller bearing (2) and the synchronizer ring (3). Remove the sliding sleeve (6) for engaging 3rd-4th gear from the hub (5) and, taking care as the plugs (8) come out with their relative balls (9) and springs (7), recover them.


Figure 45



51414

Remove the retaining ring (4, Figure 44). Extract the hub (2) with the extractor 99348001 (1).


Figure 46



51415

Remove the synchronizer ring (1), 3rd gear (2) and roller bearing (3).


Figure 47



Using bridge 99341003 (1), screw stays 99341019 (2), grips 99341025 (4) and clamp 99341015 (3), take out the 2nd gear (7), spacer (6) and bushing (5).


NOTE Force of extraction of the bushing (4) 40 kN.

Figure 48




Take out the synchronizer ring (4), middle ring (3), ring (2) and roller bearing (1).

Figure 49



Remove the sleeve (2) for engaging 1st-2nd gear from the hub (1) and, taking care as the plugs (5) come out with their relative balls (3) and springs (4), recover them.


Figure 50



Using the bridge 99341003 (1), ties 99341012 (2) and clamp 99341015 (3), extract the 1st gear (6), with the synchronizer ring (7), middle ring (8) and ring (9), hub (5) and bushing (4). Remove the roller bearing (10).


NOTE Force of extraction of the bushing (4) 40 kN.

Figure 51




Turn over the main shaft (1). Take out the spacer ring (2) and remove the 5th gear (3).

Figure 52



Remove the half roller bearings (1), the synchronizer ring (3) and the retaining ring (4) holding the hub (2).


Figure 53



75416

Using the bridge 99341003 (1), ties 99341012 (2) and clamp 99341015 (3), extract the reverse gear (5) and the synchronizer assembly (4).


Figure 54



51423

Remove the roller bearing (1).


Figure 55



51424

Remove the sliding sleeve (2) for engaging reverse - 5th gear from the hub (1), taking care as the plugs (3) come out with their relative balls (4) and springs (5), recover them.

Figure 56




51425

If the cog-wheel (2) of the 5th gear (1) shows any sign of damage, take out the retaining ring (3), replace the cog-wheel (2) and refit the retaining ring (3).

Drive input shaft

Figure 57




51426

If the cog-wheel (2) of the input shaft gear (1) shows any sign of damage, take out the retaining ring (3), replace the cog-wheel (2) and refit the retaining ring (3).

Disassembling the transmission shaft


Figure 58



51427

Take out the retaining ring (1) and extract the internal ring (2) of the rear bearing. Turn over the shaft (3) and extract the internal ring (4) of the front bearing. Shaft (3) gear (5) removal, if required, shall be performed by hydraulic press; 50 kN removing load.


Figure 59



51428

INPUT SHAFT ASSEMBLY DRAWING


Figure 60



75413

MAIN SHAFT ASSEMBLY DRAWING


Figure 61



51430

TRANSMISSION SHAFT ASSEMBLY DRAWING


Figure 62



51431

1st-2nd GEAR DUAL CONE SYNCHRONIZER ASSEMBLY

Figure 63



75414

3rd - 4th - 5th GEAR SINGLE CONE SYNCHRONIZER ASSEMBLY

CHECKS

Transmission

The transmission and relative covers must show no sign of cracking.

The mating surfaces of the covers and transmission must not be damaged or deformed. Remove any remains of sealant from them.

The seats of the bearings, reverse gear shaft and gear control rods must be neither damaged nor too worn.

Hubs - sliding sleeves - forks

The grooves on the hubs and relative sliding sleeves must not be damaged. The sliding sleeve must run freely on the hub. The plugs and balls for positioning the sliding sleeve must be neither damaged nor worn. The tootthing of the sliding sleeves must not be damaged. The forks must be sound with an end float, in the radial groove of the sleeve, no greater than 1 mm.

Bearings

The roller bearings must be in perfect condition with no signs of wear or overheating. They must only be removed if they are to be replaced.

Shafts - gears

The seats on the shafts, for bearings, must be neither damaged nor worn. The tootthing of the gears must be neither damaged nor worn.


Synchronizing devices

Check the wear on the synchronizer rings (3, Figure 64) proceeding as follows:

- position the synchronizer ring (3) on the respective cog-wheel (2, 7, 8, 9 and 11, Figure 64);
- turn the synchronizer ring so as to ensure correct coupling on the tapered surface of the cog-wheel of the gear.
- With a feeler gauge, check the distance **A** on two diametrically opposite points.
If the average measured value **A** is less than 0.5 mm, replace the synchronizer ring.

NOTE After this check, the synchronizer rings must be marked on their respective gears to avoid swapping their positions over when assembling.

Figure 64



87897

1st - 2nd GEAR SYNCHRONIZERS

| | |
|--|--|
| A. Synchronization reserve | |
| 1 st -2 nd gear | 1.4 ^{+0.25} _{-0.35} mm |
| B. 1 st -2 nd gear release clearance | 0.9 ^{+0.6} _{-0.35} mm |

3rd - 4th GEAR SYNCHRONIZERS

| | |
|---|----------------|
| A. Synchronization reserve | |
| 3 rd - 4 th gear | 1.15 + 0.2 mm |
| B. 3 rd - 4 th gear release clearance | 1.40 + 0.65 mm |

5th GEAR SYNCHRONIZER


| | |
|---|---------------|
| A. Synchronization reserve | |
| 5 th gear | 1.15 + 0.2 mm |
| B. 5 th gear release clearance | 1.10 + 0.4 mm |

Force of sliding of sliding sleeves 80 ÷ 95 Nm.
Maximum admitted wear on the synchronizers, distance **A** - 0,5 mm

1. Sliding sleeve - 2. 1st gear cog-wheel - 3. Synchronizer ring - 4. Middle ring - 5. Ring - 6. Hub -
7. 2nd gear cog-wheel - 8. 3rd gear cog-wheel - 9. 4th gear cog-wheel - 10. Reverse gear - 11. 5th gear cog-wheel

Mounting the transmission shaft


Figure 65



Gear (5) fitting on shaft (3), if required, shall be performed by hydraulic press after heating the gear to $140^{\circ}\text{C} \pm 170^{\circ}\text{C}$; 31 kN driving load.

Heat the internal rings (2 and 4) of the tapered roller bearings to a temperature of approx. 80°C and, with a suitable punch (1), mount them on the transmission shaft (3).

Figure 66




Mount the retaining ring (1) whose thickness gives an end float when in its seat of $0 \pm 0.05 \text{ mm}$.

Mounting the main shaft


NOTE Mount the synchronizer rings on their respective gears according to the marks made during disassembly or when checking in the case of replacement.

Figure 67



Tighten the main shaft (1) in a vice and mount on it: the roller cage (2), reverse gear (4) and synchronizer ring (3).


Figure 68



Heat the hub (2) for the 5th - reverse gear engagement sliding sleeve to a temperature no higher than 150°C and mount it on the main shaft with a suitable punch (1).

NOTE When fitting, make sure that the projecting parts (3) of the synchronizer ring get positioned in the hub (2) correctly.


Figure 69



Mount the retaining ring (1) whose thickness makes for null clearance in its seat.

Check the end float of the reverse gear (2). It should be $0.15 \pm 0.3 \text{ mm}$.


Figure 70



Mount the sliding sleeve (5) on the hub (4) facing as shown in the figure.


Put the springs (3), plugs (1) and balls (2) into the seats of the hub (4), settling them under the sliding sleeve.

Figure 71




Positioning the synchronizer ring (2) and the half roller bearings (1).

Figure 72




Install the 5th speed gear (3).
Heat spacer ring (2) to 90°C and install it.
Upset the main shaft (1).

Figure 73



Position the roller bearing (2) on the main shaft (1).


Figure 74



Mount the 1st gear (1).
Lubricate the ring (4), middle ring (3), synchronizer ring (2) with TUTELA MR3 grease and mount them on the gear (1).

NOTE Make sure the tongues of the rings (2 and 3) are positioned correctly in their respective seats.


Figure 75



Heat the hub (1) for the 1st - 2nd gear sliding sleeve to a temperature no higher than 150°C and mount it on the main shaft with a suitable punch.

NOTE When assembling, make sure the tongues of the rings (3 and 4, Figure 74) and the projections of the synchronizer ring (2) are positioned correctly in the hub (1). Check that the end float of the 1st gear (3) is 0.15 ÷ 0.30 mm.

Figure 76




51443

Heat the bushing (2) to a temperature no higher than 170°C and mount it on the main shaft (1).

Mount the sliding sleeve (4) on the hub (3).

Put (3) the springs (7), plugs (5) and balls (6) into the seats in the hub, settling them under the sliding sleeve (4).

Figure 77




51417

Lubricate the synchronizer ring (4), middle ring (3) and the ring (2) with TUTELA MR3 grease.

NOTE Make sure the tongues of the rings (2 - 3) and the projections of the synchronizer ring (4) are positioned correctly in their respective seats.

Mount the roller bearing (1).

Figure 78



51445


Mount the 2nd gear (4).

Heat the spacer (3) to a temperature no higher than 170°C and mount it on the main shaft (1).

Check the end float of the 2nd gear (4). It should be 0.15 ± 0.30 mm.

Heat the bushing (2) to a temperature no higher than 170°C and mount it on the main shaft (1).


Figure 79



51446

Mount the roller bearing (1) and the 3rd gear (3). Position the synchronizer ring (2) on the 3rd gear (3).

Figure 80




51447

Heat the hub (2) to a temperature no higher than 150°C and mount it on the main shaft (1) checking that the projections (3) of the synchronizer ring are positioned in the compartments of the hub (2).

Mount the retainer ring (4) whose thickness determines an end float in its seat of $0 \div 0.05$ mm.

Check the end float of the 3rd gear (5). It should be $0.15 \div 0.30$ mm.

Figure 81



51413


Mount the sliding sleeve (6) on the hub (5). Put the springs (7), plugs (8) and balls (9) into the seats in the hub (5), settling them under the sliding sleeve (6).

Grease the roller bearing (2) and fit it on the main shaft (1).

Position the synchronizer bearing (3) on the hub (5).

Rods - forks - selector - driver Disassembly - assembly

Figure 82



51449

To replace the forks of the selector and driver from their respective control rods it is sufficient to remove the retaining spring pins with a suitable punch.

For assembly, carry out these steps in reverse order, replacing the spring pins.

NOTE Spring pegs must be positioned with the cutting edge placed level.


Mounting the transmission

NOTE During assembly, the gaskets, retaining rings, O-rings, spring pins, safety plates and springs must always be replaced with new parts.

The nuts and screws must be tightened to the required torque unless specified otherwise, with the thread dry and greased.

Adjusting the transmission shaft bearing end float

Figure 83




51450

Determine the thickness **S** of the ring (1) for adjusting the transmission shaft bearing (2) end float, proceeding as follows:


□ measure the distance **A** between the end of the transmission (3) and the seat of the ring of the front bearing (2);

Figure 84



- measure the distance **B** between the end of the rear cover (1) and the seat of the ring of the rear bearing;

Figure 85



- mount the internal rings (2 - 4) of the tapered roller bearings on the transmission shaft (5);
- position the external rings (1 - 3) on the internal ones (2 - 4);
- apply a load **F** of 100 ÷ 120 N on the external rings (1 - 3).
- In these conditions, measure the distance **C** between the ends of the rings (1 - 3).
- The thickness **S** of the bearing end float adjustment ring is given by:


$$S = A + B - C - 0,10$$

Where:

A - B - C are the measured values

0.10 = constant value, including the deformation of the external rings (1 - 3) after driving them into their seats and the end float of the bearings of 0.05 mm.

Figure 86



Position the adjustment ring (1, Figure 83) of the thickness determined with the above measurement in the transmission (1).


Heat the bearing seats of the box (1) to a temperature of approx. 80°C and mount:

- the external ring (6) of the front tapered roller bearing with punch 99374091 and grip 99370007;
- the ball bearing (7) with a general punch;
- the bushing with ball bearing (4) and the roller bearing (5) with a general punch.

Position the retaining plates (3) and secure them to the box, tightening the screws (2) to the required torque.

NOTE Apply LOCTITE 242 onto the thread of the screws (2, Figure 86 and 5, Figure 87).

Figure 87




Heat the bearing seats of the box (1) to a temperature of approx. 80°C and mount:

- the external ring (7) of the tapered roller bearing with punch 99374091 and grip 99370007;
- the ball bearing (4) and the bushing with ball bearings (2) with a general punch.

Position the retaining plates (6) and the engagement locking plate (3) in their seats.

Secure these to the box, tightening the screws (5) to the required torque.

Figure 88




Clamp the main shaft in a vice.

Mount the input shaft (8) on the main shaft (4) and couple this with the transmission shaft (5).

Fit tool 99360521 (6) on shafts (8 and 5) and tie it to input shaft (8) by circlip (9) and to secondary shaft (5) by screw (7).

Set forks and rods thereof (1 - 2 - 3) on sliding sleeves and tie by tool 99360521 sleeves (6).


Figure 89



Hook the hoist onto tool 99360521 (1). Lift the assembly (2) as put together beforehand and mount it in the rear cover (3).

During this operation, check that the output shaft (7) goes into the supporting ball bearing and the control rods (4 - 5 - 6) go into their respective seats.

Figure 90




Set properly clutch locking plate (5) by setscrew wrench (2) to avoid control rods (1 - 3 - 4) interference with plate during next operation.

Screw the pin (11) of tool 99370234 into the hole in the output shaft (6). Mount the bushing (8) and spacer (9) on the tool 99370234.

Screw on the nut (10) and at the same time lower the hoist so the output shaft (6) is positioned on the ball bearing (7). Remove the tool 99360521 and the parts (8 - 9 - 10 - 11) of the tool 99370234.

Figure 91




Mount the rod (7) complete with selector (5) and driver (6). Put the pawls (8) and springs (9) into the rear cover (4). Mount the cups (10).

Mount the reverse gear idler (2) with the shaft (1) and secure the shaft to the rear cover (4) tightening the screw (3) to the required torque.

Apply LOCTITE 5206 sealant to the mating surfaces of the transmission.


Figure 92



74966

Warm up the roller bearing inner ring (→) at 80°C and fit the gearbox (1) on the rear cover and check that the shafts and the control rods fit correctly in the respective seats.


Figure 93



51459

Insert the centring pins (⇒) in the rear cover (5).
 Screw on the screws (11) fixing the rear cover (5) to the transmission (3) and tighten them to the required torque.
 Tighten the screw (4) fixing the reverse gear idler shaft to the transmission (3) to the required torque.
 Insert the push rod (6) and springs (7 - 8) and tighten the plug (10) with a new gasket (9) to the required torque.
 If the side cover (1) has been removed, apply LOCTITE 5206 sealant on the mating surface and tighten the screws (2) to the required tightening torque.


Figure 94



51398

Mount the front bearing (3) retaining ring (2) on the input shaft (1).


Figure 95



51461

Mount the O-ring (2) with the key 99374453 (1).


Figure 96



51396

Mount input shaft (3) protection cover (2) and tighten screws (1) to the required torque.


Figure 97



Mount the phonic wheel (2) onto the main shaft (3).
 Mount the reversing light switch (4) and the tachograph sensor (1).

74967


Figure 98



Mount the O-ring (3) in the rear cover (4) with the key 99374452 (1) and the grip 99370007 (2).

74968

Figure 99




Mount the output flange (1) on the main shaft with the tool 99370234 (2).

Remove the tool 99370234 (2).

74969

Figure 100



Mount the washer (3) and screw on the screw (4).
 Lock the rotation of the flange (1) with the lever 99370317 (2) and tighten the screw (4) to the required torque.

Mount the control box as described under the relevant heading.
 Fill the transmission with lubricating oil in the required quantity and grade.

74970

6 S 300 Transmission

| | Page |
|--|------|
| GENERAL | 45 |
| GEAR SELECTION AND ENGAGEMENT | 46 |
| SPECIFICATIONS AND DATA | 48 |
| TIGHTENING TORQUES | 50 |
| TOOLS | 51 |
| OVERHAULING THE TRANSMISSION | 59 |
| <input type="checkbox"/> Gear control box | 59 |
| <input type="checkbox"/> Disassembly | 59 |
| <input type="checkbox"/> Assembly | 59 |
| <input type="checkbox"/> Check levers mounting | 60 |
| <input type="checkbox"/> Disassembling the transmission | 61 |
| <input type="checkbox"/> Disassembling the rear cover bearings | 64 |
| <input type="checkbox"/> Disassembling the transmission bearings | 64 |
| <input type="checkbox"/> Disassembling the main shaft | 65 |
| <input type="checkbox"/> Disassembling the drive input shaft | 66 |
| <input type="checkbox"/> Disassembling the transmission shaft | 66 |
| CHECKS | 71 |
| <input type="checkbox"/> Transmission | 71 |
| <input type="checkbox"/> Hubs - sliding sleeves - forks | 71 |
| <input type="checkbox"/> Bearings | 71 |
| <input type="checkbox"/> Shafts - gears | 71 |
| <input type="checkbox"/> Synchronizing devices | 71 |
| <input type="checkbox"/> Mounting the transmission shaft | 73 |
| <input type="checkbox"/> Mounting the main shaft | 74 |
| <input type="checkbox"/> Rods - forks - selector - driver | 77 |
| <input type="checkbox"/> Disassembly - assembly | 77 |
| <input type="checkbox"/> Mounting the transmission | 77 |
| <input type="checkbox"/> Adjusting the transmission shaft bearing end float | 77 |

GENERAL

The 6 S 300 transmission is mechanical with synchronized engagement of forward gears.

It is composed of a light alloy box (which also serves as a clutch cover), a rear cover (where the speed engagement controls and gearing are housed) and a control box.

There is an opening on the side of the transmission to apply a power take-off.

Drive transmission is accomplished by a set of helical-toothed constant mesh gears, for both forward and reverse gears.

The splined or machined gears are on four shafts: input, main, transmission and reverse gear.

The input and main shafts are supported, in the transmission, by watertight, non-adjustable ball bearings.


The transmission shaft is supported, in the transmission, by roller bearings that can be adjusted axially by means of ring shims.

6th, 5th, 4th, 3rd and reverse gears (new version transmissions) are synchronised by means of single taper free synchroniser rings; double taper wheels are used for 1st and 2nd gear.

Control inside the transmission is accomplished with five rods: a main rod to select and engage gears; four rods equipped with forks for engaging gears.

The outer engagement lever is provided with two counterpoised weights. They dampen the control (Bowden) wire engagement thrust and consequently attenuate noise.

Figure 1




85939

GEAR SELECTION AND ENGAGEMENT


The combined action of the selector lever (2) and the engagement lever (1) cause the rotation and axial movement of the rod (4) in two subsequent steps to engage the required gear by means of the rods (8-7-6 and 9).

Neutral arrangement and/or 3rd/4th gear selection and engagement arrangement

Figure 2



SECTION A-A



3rd/4th gear selection

According to the angular position of the selector lever (2), the slider (3) turns with the rod (4) (which is integral) and the selector (5) arranges the slider on the 3rd/4th gear rod (9). At the same time, the slider (3) moves the rod (10) to prevent the simultaneous engagement of two gears, to keep the 3rd and 4th gear engagement rod (9) free and to prevent movement of the other rods by engaging the grooves in the rods.

3rd/4th gear engagement


According to the movement of the engagement lever (1), the slider (3) axial moves the rod (4) (which is integral), the selector (5) (previously arranged) and consequently the chosen 3rd and 4th gear engagement rod (9).

Neutral position coincides with the 3rd/4th gear selection arrangement.


In this case, the vertical axis of the selector lever (2) is exactly at 90° with respect to the horizontal axis of the control corresponding to no angular variation of the rod (4).

1st/3rd gear selection election and engagement arrangement

Figure 3



SECTION A-A




This arrangement is obtained by moving the selector lever (2) anticlockwise. In this way, the selector (4) is inserted in the 1st/2nd gear engagement rod (5).


By moving the lever (1), the slider (3) will axially move the 1st/2nd gear engagement rod (5).

5th/6th gear selection and engagement arrangement

Figure 4



SECTION A-A




This arrangement is obtained by moving the selector lever (2) clockwise. In this way, the selector (4) is inserted in the 5th/6th gear engagement rod (5).


By moving the lever (1), the slider (3) will axially move the 5th/6th gear engagement rod.

Reverse gear selection and engagement arrangement

Figure 5



SECTION A-A



This arrangement is obtained by moving the selector lever (2) anticlockwise. In this way, the selector (4) is inserted in the reverse gear engagement rod (5).

By moving the lever (1), the slider (3) will axially move the reverse gear engagement rod (5).








Safety device

The transmission is equipped with a device which prevents the simultaneous engagement of two gears.













It consists of a suitably shaped rod (6) fitted transversally in the transmission box.

The slider (3), moves the rod (6) under the action of the lever (2). This keeps the selected gear engagement rod free and prevents movement of the other gears by engaging their respective grooves.

SPECIFICATIONS AND DATA

| | | |
|---|--|---|
| | TRANSMISSION | 6 S 300 |
|  | Type | Mechanical |
| | Input torque | 320 Nm |
| | Weight | 63 kg |
|  | Speeds | 6 forward speeds 1 reverse speed |
| | Speed control | Mechanical |
|  | Power take-off | Optional |
|  | Speed engagement: Forward speeds <input type="checkbox"/> 5 th /6 th - 3 rd /4 th <input type="checkbox"/> 1 st /2 nd Reverse speed Speed retention mechanism | Single-cone synchronizer Dual-cone synchronizer clip-on, in new version transmission with single taper synchroniser ring Sliding sleeves retained by pawls and springs |
|  | Gears | Helical-toothed constant mesh gears |
|  | Gear ratio First Second Third Fourth Fifth Sixth Reverse | 6.72 3.94 2.55 1.77 1.29 1.00 6.05 |
|  | Shaft bearings: Main shaft Transmission shaft | watertight ball bearing tapered roller |


SPECIFICATIONS AND DATA

| | | |
|---|--|---|
|  | Transmission shaft bearing end play | $0 \pm -0.05 \text{ mm}$ |
|  | Transmission shaft bearing end play adjustment | by shims |
|  | Shim thickness for transmission shaft bearing end play adjustment | - |
|  | <p>Main shaft</p> <p>Temperature for fitting:</p> <ul style="list-style-type: none"> <input type="checkbox"/> hubs for sliding sleeves $80^\circ \pm 110^\circ\text{C}$ <input type="checkbox"/> 1st-R gear bushes and spacer ring $80^\circ \pm 110^\circ\text{C}$ <input type="checkbox"/> front bearing* $90^\circ \pm 110^\circ\text{C}$ | |
|  | <p>Transmission shaft</p> <p>Temperature for fitting:</p> <ul style="list-style-type: none"> <input type="checkbox"/> bearings 80°C (max 120°C) <input type="checkbox"/> 5th-4th gears $170^\circ \pm 160^\circ\text{C}$ | |
|  | <p>Gear end float:</p> <ul style="list-style-type: none"> 1st - 3rd - 4th - R - 5th gear $0.15 \pm 0.40 \text{ mm}$ 2nd gear $0.25 \pm 0.5 \text{ mm}$ | |
|  | 5 th - 4 th gear sliding sleeve hub retaining ring end float | $0 \pm 0.15 \text{ mm}$ |
|  | 5 th - 4 th gear sliding sleeve hub retaining ring thickness | - |
|  | <p>Retaining ring end float:</p> <ul style="list-style-type: none"> <input type="checkbox"/> transmission shaft front bearing $0 \pm 0.1 \text{ mm}$ <input type="checkbox"/> main shaft roller bearing $0 \pm 0.1 \text{ mm}$ | |
|  | Transmission shaft rear bearing retaining ring thickness | - |
|  | Sealant | <p>LOCTITE 510</p> <p>LOCTITE 242</p> <p>LOCTITE 5206</p> |
|  | Type of oil: | TUTELA TRUCK GEARLITE |
| | Quantity | <p>2.7 litres</p> <p>2.43 kg</p> |

* = Do not use hot air equipment to heat bearing.

TIGHTENING TORQUES

Figure 6



52506







| | DESCRIPTION | TORQUE | |
|-----|--|----------|----------|
| | | Nm | kgm |
| 1 | Plug retaining spring and reverse gear hardening push rod | 32 ±10% | 3.2 ±10% |
| 2 | M22x1.5 plug | 50 | 5 |
| 3● | 3rd and 4th gear fork articulation pins | 45● | 4.5 |
| 4 | Plugs for rod preventing gear engagement | 32 | 3.2 |
| 5 | Clutch housing, screw to fasten clutch housing to crankcase | 80 | 8 |
| 6 | Constant mesh shaft cover fastening screw | 23 ±15% | 2.3 ±15% |
| 7■ | Screw securing p.t.o. side cover | 46 ±15% | 4.6 ±15% |
| 8 | Screw securing control cable mounting | 23 ±15% | 2.3 ±15% |
| 9 | Screw securing reverse gear shaft | 23 ±15% | 2.3 ±15% |
| 11 | Side plug on rear cover | 35 | 3.5 |
| 12* | Screw securing rear cover | 23 ±15% | 2.3 ±15% |
| 13 | Speedometer transmitter fixing | 50 | 5 |
| 14 | Screw locking sleeve for transmission coupling on main shaft | 235 | 23.5 |
| 15 | Fixing switches and reversing lights | 40 | 4 |
| 16● | Screw securing ball bearing retaining ring | 9.5 ±15% | 0.9 ±15% |
| 17 | Nut for screw securing lever to control rod | 34 ±15% | 3.4 ±15% |
| 18 | Screw securing gear control mounting | 23 ±15% | 2.3 ±15% |
| 19 | Oil vapour breather | 10 ±15% | 1 ±15% |
| 20● | Screw securing driver to main rod | 9.5● | 0.9 |

* Spread LOCTITE 5206 sealant on the contact surfaces

● Spread LOCTITE 242 on the thread

■ Spread LOCTITE 510 on the thread


TOOLS

| TOOL NO. | DESCRIPTION |
|-----------------|---|
| 99322205 |  <p data-bbox="805 421 1184 454">Assemblies overhaul revolving stand</p> |
| 99322225 |  <p data-bbox="815 719 1270 752">Unit support (to use with stand 99322205)</p> |
| 99340205 |  <p data-bbox="815 1016 1034 1050">Percussion extractor</p> |
| 99341002 |  <p data-bbox="805 1312 1024 1346">Single-acting scaffold</p> |
| 99341003 |  <p data-bbox="805 1610 1008 1644">Single-acting bridge</p> |
| 99341004 |  <p data-bbox="805 1895 970 1928">Pair of brackets</p> |


TOOLS

TOOL NO.


DESCRIPTION

99341012


Pair of brackets

99341015


Constrictor

99341017


Pair of brackets with hole

99341019

Pair of tie rods with grips







99341025

Grips







99345003

Extractor for gearbox front half-casing

TOOLS


| TOOL NO. | DESCRIPTION |
|-----------------|---|
| 99348001 |  <p>Extractor with locking device</p> |
| 99348004 |  <p>Universal male extractor from 5 to 70 mm</p> |
| 99360522 |  <p>Tool to extract and insert main shaft, transmission shaft and rod - fork assembly</p> |
| 99370006 |  <p>Handle for interchangeable drivers</p> |
| 99370007 |  <p>Handle for interchangeable drivers</p> |
| 99370234 |  <p>Tool for fitting rear bearing and sleeve on main shaft</p> |

TOOLS

| TOOL NO. | DESCRIPTION | |
|-----------------|---|---|
| 99370317 |  | Reaction lever with extension for holding flange |
| 99370629 |  | Transmission support during removal from and refitting to vehicle |
| 99371057 |  | Bracket for supporting gearbox during overhaul (use with 99322205-99322225) |
| 99374091 |  | Punch for fitting bearing external races (dia. 55 ÷ 69 mm use with 99370007) |
| 99374452 |  | Keying device to fit gasket on transmission rear cover (use with 99370006) |
| 99374453 |  | Keying device to fit gasket on transmission |

LONGITUDINAL SECTION


Figure 7



87899

Figure 8


C-C



87881


LONGITUDINAL SECTION

Figure 9




87900

Figure 10



87901


Figure 11



87902

TRANSMISSION TRANSVERSAL CROSS-SECTIONS


Figure 12



E-E

87885


Figure 14



F-F

87888

Figure 13




N-N

87903


TRANSMISSION TRANSVERSAL CROSS-SECTIONS

Figure 15



87889


Figure 16



87890

530210 OVERHAULING THE TRANSMISSION

Figure 17




Fit the gearbox (1) with the bracket 99371057 (5) and secure this to the brackets 99322225 (3) on the rotary stand 99322205 (2).
Remove the plug (4) and drain off the lubricating oil.



The used oil must be disposed of according to the law in force.


530220 Gear control box Disassembly

Figure 18




Shift to neutral.
Take out the fixing screws (1) and remove the gear control box (2).

Figure 19



Mark the assembly position of the levers (1 and 7) on their respective shafts (2 and 6). Loosen the nuts (4) for the retaining screws (5).
Extract the levers (1 and 7) from the shafts (2 and 6) and extract these from the box (8). Take off the caps (4).


Figure 20



With a punch (3), remove the spring pin (4) and extract the shaft (2) from the internal lever (1).
Repeat these steps for the other shaft.

NOTE The coupling lever is bound to the stem by two snap pins.


Figure 21



Use a punch on the point shown by the arrow and eject the O-rings and roller bushes (2) from the box (1).


Assembly

Figure 22



Thoroughly clean the oil vapour vent (3).
With a suitable punch, mount the roller bearings (1) in the box (2).


Figure 23



Using a suitable punch, mount the O-rings (1) in the box (2), positioning them at the height shown.

Pack the gap between the O-ring and roller bearing with grease.


Figure 24



Mount the selection and engagement levers (1) on their respective shafts (2) and fasten them with the spring pins (3).


NOTE The spring pin (3) must be positioned with the cut horizontal. Fit spring peg (4), with cutting edge positioned at 180° from spring peg (3) cutting edge, in spring peg (3) engagement lever.

Figure 25



Lubricate the roller bearings (1, Figure 23) with TUTELA MR3 grease and mount the shafts (3 and 6) complete with the internal levers (4 and 5) in the box (2). Mount the caps (8 and 9) and levers (1 and 10) on the shafts (3 and 6) in the position marked during disassembly without tightening the nuts for the fixing screw (7).

Figure 26




Thoroughly clean the mating surfaces of the gear control box (2) and apply LOCTITE 5206 sealant on them.

Fit the box (2) on the transmission, taking care that the levers and shafts are positioned correctly in their respective seats.

Tighten the screws (1) to the required torque.

Check levers mounting

Figure 27



Check the assembly of the selection (6) and engagement (3) levers.

The selection (6) and engagement (3) levers must be mounted on their respective shafts so that:


- between the c/c distance of the pin (5) of the selection lever (6) and the outside of the bracket (1) there is a distance **X** of 134 mm;
- between the c/c distance of the pin (2) of the engagement lever (3) and the outside of the bracket (4) there is a distance **Y** of 135 mm.

If a different value is measured, orientate the lever concerned on the respective shaft appropriately.

Then tighten the nuts for the screws to the required tightening torque.

Disassembling the transmission

Figure 28




51924

Shift to neutral.
Dismantle the gear control box as described under the relevant heading.

Remove the two side plugs (1 - 3). Take out the screw (2) fixing the driver (4) to the rod (5).


Figure 29



51925

Mark the assembly position of the rod (1) preventing engagement of more than one gear at the same time and remove it from the transmission.

Figure 30




51926

Block rotation of the sleeve (1) by applying the lever 99370317 (3). With the bushing (2) remove the screw (5) with the washer beneath (4).

Take out the lever 99370317 (3).

Figure 31




51927

Extract the sleeve (3) from the main shaft.

NOTE If this is difficult, extract the sleeve (3) with the extractor composed of bridge 99341003 (1) and clamps 99341017 (2).


Figure 32



51928

NOTE When putting away the sleeve (1) take care not to damage the phonic wheel (→) obtained by machining.


Figure 33



51829

Remove the screws (1) and take off the cover (2) protecting the input shaft (3).


Figure 34



51930

Perforate the o-ring (2) with a suitable hook and ram extractor 99340205 (1) and remove the o-ring from the transmission box.


Figure 35



51931

Remove the circlip (2) retaining the front bearing (3) from the input shaft (1).


Figure 36



51932

Take out the plug (4) with the washer (3), and extract the spring (2) and the push rod (1).


Figure 37



51933

Remove the two link pins (1) of the fork controlling the 3rd and 4th gears.


Figure 38



51934

Push the two centring pins (2) downwards to free them from the transmission (1). Remove the screws (3) securing the rear cover (4) to the transmission (1).


Figure 39



74957


Fit the drive input shaft (1) with tool 99345003 (2) and secure this onto the gearbox (4), with the screws (3); screw down the screw (5) of tool (2) to extract the gearbox from the bearing (6).

Figure 40




Drill the cups (2), screw a special screw into them.
Using the screw, extract the cups (2) from the rear cover (1).
Remove the springs (3) and pawls (4).

Figure 41




Remove the rod (1) controlling the 3rd/4th gear and the main rod (2) from the rear cover (3).

Figure 42



Take out the screw (3) and remove the reverse gear shaft (1) with the mounting (2) from the rear cover (4).

Figure 43




Mount the tool 99360522 (3) onto the rods (4, 5 and 6), on the input shaft (1) and on the transmission shaft (9).
Secure the tool 99360522 (3) on the input shaft (1) with the retaining ring (2) and with the screw (8) to the transmission shaft (9).
Insert the part (13) of the bracket (11) into the reverse gear (14) and tighten the screw (12).
Hook the tool 99360522 (3) onto the lift.
Apply the extractor composed of the bridge 99341004 (16) and ties 99341012 (15) onto the rear cover (7).

NOTE In order not to damage the rear cover (7), place special protections between it and the ties (15).

Using the extractor screw and the lift on the main shaft (10), remove the main shaft (10) from the rear ball bearing and extract the shaft-rod assembly from the rear cover (7).


Figure 44



Put the assembly you have just removed onto the workbench. Remove the tool 99360522 (6), separate the input shaft (4) from the reverse gear (8) together with the roller bearings, transmission shaft (5), drive input shaft (7) with the relevant synchronizer ring and the rods (1-2-3).


Disassembling the rear cover bearings

Figure 45




- Remove the screws (1) securing the plates (2).
- Take out the plates (2).
- Turn over the rear cover (4) and remove the bearing (3).

Figure 46




Using universal extractor 99348004 (1), remove the outer ring (2) of the transmission shaft bearing.

Figure 47



Using the percussion extractor 99340205 (1) and part 99348004 (2), extract the bushing with the ball bearings (3).


Figure 48



- Turn over the rear cover (4).
- Take out the O-ring (6).
- Using a suitable punch, remove the ball bearing (5). Remove the tachograph sensor (7) and the reversing light switch (1) with the washer (2) and extract the push rod (3).


Disassembling the transmission bearings

Figure 49




Using universal extractor 99348004 (1), remove the outer ring (2) of the transmission shaft bearing.

Figure 50



Using the percussion extractor 99340205 (1) and part 99348004 (2), extract the bushing with the ball bearings (3).

Figure 51




Remove the screws (1) securing the plates (2).

Take out the plates (2).

Turn over the transmission. Using a suitable punch, remove the ball bearing (3).

Figure 52




Using the percussion extractor 99340205 (1) and part 99348004 (2), extract the roller bearing (4-3).

Disassembling the main shaft


NOTE Mark the assembly position of each synchronizing device on the respective gear.

Figure 53




Tighten the primary shaft (1) in a vice. Remove the synchroniser ring (4) and the circlip (2). Remove the circlip (3) from its housing.

Figure 54




Remove the sliding sleeve (2) for engaging 5th - 6th gear from the hub (1) and, taking care as the plugs (5) come out with the balls (4) and springs (3), recover them.

Figure 55




Use extractor 99348001 (6) as shown in the figure to extract the primary shaft (1), the 5th gear (7), the synchroniser ring (5), the hub (4), the circlip (3) and the roller bearing (2).

Figure 56



Remove the roller half cages (1).


Figure 57



85948

With the hydraulic press, remove the following from the primary shaft (1): 1st gear (10), shim (9), bushing (8), roller cage (7); for transmission without synchronised reverse: reverse gear (6); sliding sleeve (5), outer gear wheel (4), inner gear wheel (3) and shim (2); for transmission with synchronised reverse: reverse gear (11) with engagement parts, synchroniser ring (12) and gear (13).


Figure 58



85949

Remove the reverse gear engagement sliding sleeve (2) from the reverse gear (1). Retrieve hub (1) and pads (3) with respective balls (4) and springs (5).

Figure 59




51954

Take out the synchronizer ring (4), middle ring (3), ring (2) and roller bearing (1).

Using a hydraulic press, remove the 2nd gear (10), ring (9), middle ring (8), synchronizer ring (7), synchronizer assembly (6) and the bushing (5). Take out the roller bearing (11).

Figure 60




51424

Remove the sliding sleeve (2) for engaging 1st-2nd gear from the hub (1) and, taking care as the plugs (3) come out with their relative balls (4) and springs (5), recover them.

Disassembling the drive input shaft

Figure 61




51956

To replace the cog-wheel (1), use the same general tools for disassembly as for assembly, heat it to a temperature of 80°C.

Disassembling the transmission shaft


Figure 62



51957

Take out the retaining ring (1) holding the 6th gear (2).


Figure 63



51958

Using general tools, extract the internal ring (2) of the rear tapered roller bearing from the transmission shaft (1).


Figure 64



51959

Using a hydraulic press, extract the 6th gear (2) and the internal ring (1) of the tapered roller bearing from the transmission shaft.


Figure 65



51960

Using a hydraulic press, remove the 5th gear (2) from the transmission shaft (1).


Figure 66



51961

Remove the 3rd gear (1) and the roller bearing (2). Remove the synchronizer ring (3). Remove the retaining ring (5) securing the hub (4).


Figure 67



51962

Using a hydraulic press, remove the 4th gear (3), the synchronizer ring (2) and the synchronizer assembly (1). Remove the half roller bearings (4).


Figure 68



51424

Remove the sleeve (2) for engaging the 3rd-4th gear from the hub (1) and, taking care over the plugs (3) coming out with their relative balls (4) and springs (5), recover them.

Figure 69




51964

TRANSMISSION SHAFT ASSEMBLY DRAWING

I. Transmission shaft assembly - 2. Tapered roller bearing - 3. Transmission shaft with reverse gear tooting (A), 1st gear (B), 2nd gear (C) - 4. Tapered bearing - 5. 4th gear - 6. Synchronizer ring - 7. Sliding sleeve - 8. Ball - 9. Spring - 10. Plug - 11. Hub - 12. Retaining ring - 13. Half roller bearings - 14. 3rd gear - 15. 5th gear - 16. 6th gear.

Figure 70




52509

INPUT SHAFT ASSEMBLY DRAWING

I - Input shaft - 2. Cog-wheel

Figure 71




90233

MAIN SHAFT ASSEMBLY DRAWING

I. Single cone synchronizer ring - 2. Roller bearing - 3. Retaining ring - 4. Sliding sleeve - 5. Plug - 6. Ball - 7. Spring - 8. Hub - 9. 5th gear - 10. Main shaft with 3rd gear tootinging (A), 4th gear tootinging (B) - 11. Roller bearing - 12. 2nd gear - 13. Dual cone synchronizer - internal ring C, middle ring D, synchronizer ring E - 14. Bushing - 15. 1st gear - 16. Spacer ring - 17.* Reverse gear - 18.* Ring with external tootinging - 19.* Ring with internal tootinging - 20.* Spacer ring - 21.* Reverse gear - 22.* Synchroniser ring - 23.* Gear.

- * Transmission without synchronised reverse
- Transmission with synchronised reverse


Figure 72



85977

1ST-2ND GEAR DUAL CONE SYNCHRONIZER ASSEMBLY


Figure 73



85978

3RD - 4TH - 5TH - 6TH GEAR SINGLE CONE SYNCHRONIZER ASSEMBLY

Figure 74



86130

SINGLE CONE SYNCHRONIZER ASSEMBLY REVERSE GEAR

CHECKS

Transmission

The transmission and relative covers must show no sign of cracking.

The mating surfaces of the covers and transmission must not be damaged or deformed. Remove any remains of sealant from them.

The seats of the bearings, reverse gear shaft and gear control rods must be neither damaged nor too worn.

Hubs - sliding sleeves - forks

The grooves on the hubs and relative sliding sleeves must not be damaged. The sliding sleeve must run freely on the hub. The plugs and balls for positioning the sliding sleeve must be neither damaged nor worn. The tothing of the sliding sleeves must not be damaged. The forks must be sound with an end float, in the radial groove of the sleeve, no greater than 1 mm.

Bearings

The roller bearings must be in perfect condition with no signs of wear or overheating. They must only be removed if they are to be replaced.

Shafts - gears

The seats on the shafts, for bearings, must be neither damaged nor worn. The tothing of the gears must be neither damaged nor worn.

Synchronizing devices

Check the wear on the synchronizer rings, proceeding as follows:




After this check, the synchronizer rings must be marked on their respective gears to avoid swapping their positions over when assembling.

- See that the friction surface is not undulated.

BK-type single cone synchronizers for 3rd/4th/5th/6th gears

Figure 75



52510

Arrange the synchroniser ring (1) on the respective gear or reverse taper ring (2).


With a feeler gauge, check the distance **S** on two diametrically opposite points.

If the measured value **S** is less than 0.8 mm, replace the synchronizer ring.

Turn the synchronizer ring (1) so as to ensure correct coupling on the cog-wheel.

D-type dual cone synchronizers for 1st/2nd gears

Figure 76



52511


Position the internal ring (3), middle ring (2) and the synchronizer ring (1) on the tapered cog-wheel (4) of the gear.

Turn the synchronizer ring (1) so as to ensure correct coupling between the parts.

Applying a uniform force of 50 N on the synchronizer ring (1), measure the distance **S** on two diametrically opposite points with a feeler gauge.

If the average measured value **S** is less than 1.5 mm, replace all the rings.

Figure 77




85916

6TH/5TH GEAR SYNCHRONISERS

A. synchronization reserve 6th/5th gear: 1 ± 1,4 mm
 B. 6th/5th release clearance: 0,3 ± 0,7 mm

Figure 78




85917

3TH/4TH GEAR SYNCHRONISERS

A. synchronization reserve 1st/2nd gear: 1 ± 1,4 mm
 B. 1st/2nd release clearance: 0,3 ± 0,7 mm

Figure 79




85918

1ST/2ND GEAR SYNCHRONISERS

A. synchronization reserve 1st/2nd gear: 1,6 ± 2,0 mm
 B. 1st/2nd release clearance: 0,9 ± 1,5 mm

Figure 80



85919


REVERSE GEAR SYNCHRONISER

A. Synchronization reserve: 0,9 ± 1,4 mm
 B. release clearance: 0,35 ± 0,85 mm

- 1. Hub - 2. 6th gear - 3. Synchronizer ring - 4. Sliding sleeve - 5. th gear cog-wheel - 6. 3rd gear cog-wheel - 7. th gear cog-wheel - 8. 2nd gear cog-wheel - 9. Reverse gear - 10. Middle ring - 11. Ring - 12. Reverse gear - 13. Reverse gear ring

Mounting the transmission shaft


Figure 81



51966

Clamp the transmission shaft (1) in a vice and position the half roller bearings (2) on it.


Figure 82



51967

Mount the 4th gear (2) and position the synchronizer ring (1) on this.


Figure 83



51968

Heat the hub (2) to a temperature of $110^{\circ} \pm 150^{\circ}\text{C}$ and mount it on the transmission shaft (1), taking care that the protrusions (3) of the synchronizer ring are positioned correctly in their seats in the hub (2).

Figure 84




51969

Mount the retaining ring (1) whose thickness produces null end float in its seat.

Check the end float of the 4th gear (2). It should be $0.15 \div 0.40$ mm.


Figure 85



51970

Mount the sliding sleeve (1) on the hub (2). Put the springs (5), plugs (3) and balls (4) into the seats in the hub (2), settling them under the sliding sleeve (1).


Figure 86



51971


Position the synchronizer ring (2) on the hub (3) so that its protrusions enter the seats in the hub (3). Mount the roller bearing (1).

Figure 87



Mount the 3rd gear (1).


Figure 88



With a hydraulic press, mount the 5th gear (1) pre-heated to approx. 170°C.


Check the end float of the 3rd gear (2). It should be 0.15 ÷ 0.40 mm.

Figure 89




With a hydraulic press, mount the 6th gear (1) pre-heated to approx. 170°C.

Figure 90



Mount the retaining ring (1) whose thickness produces null end float in its seat.

Figure 91




Heat the internal rings (1 - 3) of the tapered roller bearings to a temperature of approx. 80°C and, with a suitable punch (1), mount them on the transmission shaft (2).

Mounting the main shaft


NOTE Mount the synchronizer rings on their respective gears according to the marks made during disassembly or when checking in the case of replacement.

Figure 92



Tighten the main shaft (1) and position the roller bearing (2) on it.


Figure 93



51980

Mount the 2nd gear (4) and position the ring (3), middle ring (2) and synchronizer ring (1) on it, taking care that the tongues (→) of the middle ring (2) enter the slots (→) in the gear (4).

Figure 94




51981

Heat the hub (2) to a temperature of $80^{\circ} \pm 110^{\circ}\text{C}$ and mount it on the main shaft (1), taking care that the projections (3) of the synchronizer ring and the tongues (→) of the ring (3, Figure 93) are positioned correctly in the seats in the hub (2).

Check the end float of the gear (4). It should be $0.25 \div 0.5 \text{ mm}$.


Figure 95



51982

Mount the sliding sleeve (2) on the hub (1). Put the springs (5), plugs (4) and balls (3) into the seats in the hub (1), settling them under the sliding sleeve (2).


Figure 96



51983

Position the synchronizer ring (3), middle ring (2) and ring (1) on the hub (4), taking care that the tongues (→) of the ring (1) and the projections (→) of the ring (3) enter the seats in the hub (4).


Figure 97



51984

Position the roller bearing (2). Mount the 1st gear (1) taking care that the tongues (3) of the middle ring enter the slots in the gear (1).

Figure 98




85961

Heat the spacer ring (2) to a temperature of approx. $80^{\circ} \pm 110^{\circ}\text{C}$ and mount it on the main shaft (1). Check the end float of the gear (4); this should be 0.15 ± 0.3 mm. Heat the bushing (3) to a temperature of approx. $80^{\circ} \pm 110^{\circ}\text{C}$ and mount it on the main shaft (1). Mount the roller bearing (5).

For transmission without synchronised reverse, proceed as follows

Figure 99




51988

Mount the reverse gear (4), heat the hub (2) to a temperature of $80^{\circ} \pm 110^{\circ}\text{C}$ and mount it on the main shaft (1). Check the clearance of the gear (4); it should be 0.15 ± 0.4 mm.

Mount the sliding sleeve (3).

Figure 100




51989

Heat the ring with internal tothing (3) and the spacer ring (2) to a temperature of $80^{\circ} \pm 110^{\circ}\text{C}$ and mount them on the main shaft (1).

For transmission with synchronised reverse, proceed as follows

Figure 101




85950

Fit reverse gear (1).

Fit sliding sleeve (2) on reverse gear hub (1).

Insert the springs (5), the pads (3) and the balls (4) in the hub seats (1) and arrange them with respect to the sliding sleeve (2).

Figure 102




85951

Fit the synchroniser ring (2).

Heat the gear ring (3) to $110^{\circ} \pm 150^{\circ}$ and fit on primary shaft (1).

Check reverse gear play (4) which must be 0.15 ± 0.4 mm.

Figure 103




51952

Turn the main shaft over and position the half roller bearings (3) on it.

Mount the 5th gear (2) and position the synchronizer ring (1) on it.

Figure 104




51990

Heat the hub (2) to a temperature of approx. $80^{\circ} \pm 110^{\circ}\text{C}$ and mount it on the main shaft (1) taking care that the projections (3) of the synchronizer ring are positioned in the seats in the hub (2).

Mount the retaining ring (4) whose thickness produces null end float in its seat.

Figure 105




51991

Mount the sliding sleeve (2).

Put the springs (3), plugs (5) and balls (4) into the seats in the hub (1) and position them under the sliding sleeve (2).

Figure 106




85952

Heat the bearing (2) to $80^{\circ} \pm 110^{\circ}\text{C}$ and fit on primary shaft (1). Fit the circlip (4) and synchroniser ring (3).

Rods - forks - selector - driver Disassembly - assembly

Figure 107



51992

1. Rod with 3rd/4th gear engagement fork - 2. Plugs - 3. Rod with 5th/6th gear engagement fork - 4. Main rod - 5. Rod with reverse gear engagement fork - 6. Rod with 1st/2nd gear engagement fork.

Check the state of the plugs (2) of the 3rd/4th gear engagement fork and replace them if they are worn.

To replace the forks of the selector and driver from their respective control rods it is sufficient to remove the retaining spring pins with a suitable punch.

For assembly, carry out these steps in reverse order, replacing the spring pins.

NOTE Spring pegs must be positioned with the cutting edge placed level.

Mounting the transmission


NOTE During assembly, the gaskets, retaining rings, O-rings, spring pins, safety plates and springs must always be replaced with new parts.

The nuts and screws must be tightened to the required torque unless specified otherwise, with the thread dry and degreased.

Adjusting the transmission shaft bearing end float

NOTE The transmission shaft bearing end float is only adjusted if the bearings, transmission shaft gears, transmission shaft, transmission or rear cover have been replaced or if too much clearance has been found.

Figure 108




51993

Determine the thickness **S** of the ring (1) for adjusting the transmission shaft bearing end float, proceeding as follows:

- position the thinner adjustment ring (1) 1.65 mm thick in the seat in the transmission (3);
- heat the seat of the bearing (2) to approx. 60°C. Mount the external ring of the bearing (2) with the punch 99374091 and grip 99370007, see Figure 110;
- mount the transmission shaft complete with the internal rings of the tapered roller bearings;
- mount the external ring of the rear bearing in the rear cover in a similar manner to the front one (see Figure 111);
- mount the rear cover on the transmission;
- screw on the 8 fixing screws so that between one screw and another there is a hole for a free screw and tighten them to the required torque;
- turn the transmission shaft to settle the bearings;

Figure 109



52512

- using a comparator (2) zeroed on the 5th gear toothing of the transmission shaft (1) measure its end float **A** through the opening for the power take-off connection and note it down.

The thickness **S** is given by:

$$S = A + B + C$$

Where:

A = measured end float, e.g. 0.18 mm;


B = average bearing pre-load, e.g. 0.02 mm;

C = adjustment value used for the measurement 1.65 mm;

$$S = 0.18 + 0.02 + 1.65 = 1.85 \text{ mm}$$

Then mount the rear cover, transmission shaft and external ring of the front bearing.

Figure 110




51996

Position the adjustment ring (1, Figure 108) of the thickness determined with the above measurement. Heat the bearing seats of the box to a temperature of approx. 80°C and mount:

- the external ring (3) of the front tapered roller bearing with punch 99374091 (2) and grip 99370007 (1);
- the ball bearing (6) with a general punch;
- the bushing with ball bearing (9) and the roller bearings (4-5) with a general punch.

Position the retaining plates (7) and secure them to the box, tightening the screws (8) to the required torque.

Figure 111




51997

Heat the bearing seats of the rear cover (1) to a temperature of approx. 80°C and mount:

- the external ring (3) of the tapered roller bearing with punch 99374091 (2) and grip 99370007 (1);
- the ball bearing (4) and the bushing with ball bearings (7) with a general punch.


Position the retaining plates (6). Secure these to the rear cover, tightening the screws (5) to the required torque.

Figure 112



Clamp the main shaft in a vice (4).
 Tighten the primary shaft (4) in a vice. Fit tool 99360522 (6) on the input transmission shaft (1) and fasten with the circlip (7). Couple the secondary shaft (9) to the primary shaft (4) and fasten by tightening the screw (8) on the tool (6). Fit the 3rd/4th gear engagement fork (14) onto the respective sliding sleeve.
 Position the forks with their rods (2 - 3 - 5) on the sliding sleeves and secure them with the sleeves of tool 99360522 (6). Couple the reverse gear (13) with the shafts (4 and 9) and fasten it to them with the part (12) of the bracket (10) tighten the screw (11).


Figure 113



Hook hoist to tool 99360522 (1), lift the unit (2) as previously mounted, and partially insert it into the rear cover (6).

During this operation, check that the output shaft goes into the supporting ball bearing and the control rods (3 - 4 - 5) go into their respective seats.


Figure 114



Screw tool 99370234 pin (7) into output shaft hole (2) and fit bushing (4) and spacer (5) on tool.


Screw on the nut (6) and at the same time lower the hoist so the output shaft (2) is positioned on the rear ball bearing (3). Remove tools 99360522 (1) and 99370234 (4-5-6-7).

Figure 115




Place the roller bearings in the reverse gear.
 Mount the spindle (2) and the mounting (1) so that the relevant holes for the fixing screw are aligned with the relevant hole of the rear cover (4).
 Screw down the screw (3) fixing the spindle (2) and mounting (1) to the rear cover (4) and tighten it to the prescribed torque.

Figure 116




Mount the 3rd/4th gear control rod (2) in the rear cover (4), connecting it to the relative fork (1), and the main rod (3).

Figure 117



Put the pawls (4) and springs (3) in the rear cover (1) and drive in the retaining cups (2) with a suitable punch. Apply LOCTITE 5206 on gearbox attachment.


Figure 118



Warm up the front bearing inner ring (2) at $90 \pm 10^\circ\text{C}$ and fit the gearbox (1) on the rear cover.

NOTE When mounting the transmission, check that the shafts and control rods are positioned correctly in their respective seats and that the rod (2, Figure 116) stays connected to the 3rd/4th gear engagement fork (1).

Figure 119




Apply LOCTITE 242 to the thread of the pins (1).

Screw the pins (1) into the box, checking that their ends go into the hole of the 3rd/4th gear engagement fork link (1, Figure 116) and then tighten them to the required torque.

NOTE If during these assembly operations the fork (1, Figure 116.) comes free of the control rod, it will not be possible to mount the pins (1) until they have been reconnected.

Figure 120




Screw on the screws (2) securing the rear cover (3) to the transmission (1) without fully tightening them.

Mount the centring pins (4) in the rear cover (3) and in the transmission (1).

Tighten the screws (2) to the required torque.


Figure 121



51932

Mount the push rod (1) and the spring (2). Screw on the plug (4) with a new washer (3), tightening it to the required torque.


Figure 122



51931

Fit a new retaining ring (2) securing the front bearing (3) onto the input shaft (1).


Figure 123



52005

Using the key 9937455 (3), mount the O-ring (2) in the transmission (1).


Figure 124



52006

Mount the cover (1) protecting the input shaft and tighten the screws (2) to the required torque.


Figure 125



52007

Mount the O-ring (2) in the rear cover (1) with the key 99374454 (4) and the grip 9937006 (3).


Figure 126



52008

Fit the transmission shaft coupling (1) onto the output shaft. If there is any interference, use the tool 99370234 (2) for assembly with the lever 99370317 (3) to lock the coupling.

Figure 127




Mount the washer (3) and screw on the screw (4).

Lock the rotation of the flange (1) with the lever 99370317 (5) and tighten the screw (4) to the required torque.


Mount the tachograph sensor (2) and the reversing light switch.

Figure 128



Mount the rod (1) preventing engagement of more than one gear at the same time, in the position marked during disassembly.

Figure 129




Apply sealant to the thread of the plugs (1 - 3), screw them into the box, tightening them to the required torque.

Position the driver (4) on the rod (5).

Secure it with the screw (2) after applying LOCTITE 242 onto its thread.

Figure 130



Fit a new gasket (1) onto the transmission.

Apply LOCTITE 510 on the screw threading (2).

Mount the side cover (3) and tighten the fixing screws (2) to the required torque.

Mount the control box as described under the relevant heading.

Mount the oil drainage plug, tightening it to the required torque.

Fill the transmission with lubricating oil in the required quantity and grade.

Mount the oil filler and level indicator cap, tightening it to the required torque.

6 S 380 O.D. Transmission

| | Page |
|--|------|
| GENERAL | 85 |
| GEAR SELECTION AND ENGAGEMENT | 86 |
| SPECIFICATIONS AND DATA | 88 |
| TIGHTENING TORQUES | 90 |
| TOOLS | 91 |
| OVERHAULING THE TRANSMISSION | 99 |
| <input type="checkbox"/> Gear control box | 99 |
| <input type="checkbox"/> Disassembly | 99 |
| <input type="checkbox"/> Assembly | 99 |
| <input type="checkbox"/> Check levers mounting | 100 |
| <input type="checkbox"/> Disassembling the transmission | 101 |
| <input type="checkbox"/> Disassembling the rear cover bearings | 104 |
| <input type="checkbox"/> Disassembling the transmission bearings | 105 |
| <input type="checkbox"/> Disassembling the main shaft | 105 |
| <input type="checkbox"/> Disassembling the drive input shaft | 107 |
| <input type="checkbox"/> Disassembling the transmission shaft | 107 |
| CHECKS | 111 |
| <input type="checkbox"/> Transmission | 111 |
| <input type="checkbox"/> Hubs - sliding sleeves - forks | 111 |
| <input type="checkbox"/> Bearings | 111 |
| <input type="checkbox"/> Shafts - gears | 111 |
| <input type="checkbox"/> Synchronizing devices | 111 |
| <input type="checkbox"/> Mounting the transmission shaft | 113 |
| <input type="checkbox"/> Mounting the main shaft | 114 |
| <input type="checkbox"/> Rods - forks - selector - driver | 117 |
| <input type="checkbox"/> Disassembly - assembly | 117 |
| <input type="checkbox"/> Mounting the transmission | 117 |
| <input type="checkbox"/> Adjusting the transmission shaft bearing end float | 117 |

GENERAL

The 6 S 380 O.D. transmission is mechanical with synchronized engagement of forward gears.

It is composed of a light alloy box (which also serves as a clutch cover), a rear cover (where the speed engagement controls and gearing are housed) and a control box.

There is an opening on the side of the transmission to apply a power take-off.

Drive transmission is accomplished by a set of helical-toothed constant mesh gears, for both forward and reverse gears.

The splined or machined gears are on four shafts: input, main, transmission and reverse gear.

The input and main shafts are supported, in the transmission, by watertight, non-adjustable ball bearings.


The transmission shaft is supported, in the transmission, by roller bearings that can be adjusted axially by means of ring shims.

6th, 5th, 4th, 3rd and reverse gears (new version transmissions) are synchronised by means of single taper free synchroniser rings; double taper wheels are used for 1st and 2nd gear.

Control inside the transmission is accomplished with five rods: a main rod to select and engage gears; four rods equipped with forks for engaging gears.

The outer engagement lever is provided with two counterpoised weights. They dampen the control (Bowden) wire engagement thrust and consequently attenuate noise.

Figure 1




85939

GEAR SELECTION AND ENGAGEMENT


The combined action of the selector lever (2) and the engagement lever (1) cause the rotation and axial movement of the rod (4) in two subsequent steps to engage the required gear by means of the rods (8-7-6 and 9).

Neutral arrangement and/or 3rd/4th gear selection and engagement arrangement

Figure 2



SECTION A-A



3rd/4th gear selection

According to the angular position of the selector lever (2), the slider (3) turns with the rod (4) (which is integral) and the selector (5) arranges the slider on the 3rd/4th gear rod (9). At the same time, the slider (3) moves the rod (10) to prevent the simultaneous engagement of two gears, to keep the 3rd and 4th gear engagement rod (9) free and to prevent movement of the other rods by engaging the grooves in the rods.

3rd/4th gear engagement


According to the movement of the engagement lever (1), the slider (3) axial moves the rod (4) (which is integral), the selector (5) (previously arranged) and consequently the chosen 3rd and 4th gear engagement rod (9).

Neutral position coincides with the 3rd/4th gear selection arrangement.


In this case, the vertical axis of the selector lever (2) is exactly at 90° with respect to the horizontal axis of the control corresponding to no angular variation of the rod (4).

1st/3rd gear selection election and engagement arrangement

Figure 3



SECTION A-A




This arrangement is obtained by moving the selector lever (2) anticlockwise. In this way, the selector (4) is inserted in the 1st/2nd gear engagement rod (5).


By moving the lever (1), the slider (3) will axially move the 1st/2nd gear engagement rod (5).

5th/6th gear selection and engagement arrangement

Figure 4



SECTION A-A




This arrangement is obtained by moving the selector lever (2) clockwise. In this way, the selector (4) is inserted in the 5th/6th gear engagement rod (5).

By moving the lever (1), the slider (3) will axially move the 5th/6th gear engagement rod.


84149

Reverse gear selection and engagement arrangement

Figure 5



SECTION A-A



84150

This arrangement is obtained by moving the selector lever (2) anticlockwise. In this way, the selector (4) is inserted in the reverse gear engagement rod (5).

By moving the lever (1), the slider (3) will axially move the reverse gear engagement rod (5).








Safety device

The transmission is equipped with a device which prevents the simultaneous engagement of two gears.

It consists of a suitably shaped rod (6) fitted transversally in the transmission box.













The slider (3), moves the rod (6) under the action of the lever (2). This keeps the selected gear engagement rod free and prevents movement of the other gears by engaging their respective grooves.

SPECIFICATIONS AND DATA

| | TRANSMISSION | 6 S 380 O.D. |
|---|--|---|
|  | Type | Mechanical |
| | Input torque | 320 Nm |
| | Weight | 63 kg |
|  | Speeds | 6 forward speeds 1 reverse speed |
| | Speed control | Mechanical |
|  | Power take-off | Optional |
|  | Speed engagement: Forward speeds <input type="checkbox"/> 5 th /6 th - 3 rd /4 th <input type="checkbox"/> 1 st /2 nd Reverse speed Speed retention mechanism | Single-cone synchronizer Dual-cone synchronizer clip-on, in new version transmission with single taper synchroniser ring Sliding sleeves retained by pawls and springs |
|  | Gears | Helical-toothed constant mesh gears |
|  | Gear ratio First Second Third Fourth Fifth Sixth Reverse | 5.375 3.154 2.041 1.365 1 0.791 4.838 |
|  | Shaft bearings: Main shaft Transmission shaft | watertight ball bearing tapered roller |

O.D.. = Over Drive


SPECIFICATIONS AND DATA

| | | |
|---|---|---|
|  | Transmission shaft bearing end play | 0 ± -0.05 mm |
|  | Transmission shaft bearing end play adjustment | by shims |
|  | Shim thickness for transmission shaft bearing end play adjustment | - |
|  | Main shaft Temperature for fitting: <input type="checkbox"/> hubs for sliding sleeves <input type="checkbox"/> 1 st -R gear bushes and gear <input type="checkbox"/> front bearing* | $80^\circ \pm 110^\circ\text{C}$ $110^\circ \pm 150^\circ\text{C}$ $90^\circ \pm 110^\circ\text{C}$ |
|  | Transmission shaft Temperature for fitting: <input type="checkbox"/> bearings <input type="checkbox"/> 5 th -4 th gears | 80°C (max 120°C) $170^\circ \pm 160^\circ\text{C}$ |
|  | Gear end float: 1 st - 3 rd - 4 th - R - 5 th gear 2 nd gear | 0.15 ± 0.40 mm 0.25 ± 0.5 mm |
|  | 5 th - 4 th gear sliding sleeve hub retaining ring end float | 0 ± 0.15 mm |
|  | 5 th - 4 th gear sliding sleeve hub retaining ring thickness | - |
|  | Retaining ring end float: <input type="checkbox"/> transmission shaft front bearing <input type="checkbox"/> main shaft roller bearing | 0 ± 0.1 mm 0 ± 0.1 mm |
|  | Transmission shaft rear bearing retaining ring thickness | - |
|  | Sealant | LOCTITE 510 LOCTITE 242 LOCTITE 5206 |
|  | Type of oil: Quantity | TUTELA TRUCK GEARLITE 2.2 litres |

* = Do not use hot air equipment to heat bearing.

TIGHTENING TORQUES

Figure 6









52506







| | DESCRIPTION | TORQUE | |
|-----|--|----------|----------|
| | | Nm | kgm |
| 1 | Plug retaining spring and reverse gear hardening push rod | 32 ±10% | 3.2 ±10% |
| 2 | M22x1.5 plug | 50 | 5 |
| 3● | 3rd and 4th gear fork articulation pins | 45● | 4.5 |
| 4 | Plugs for rod preventing gear engagement | 32 | 3.2 |
| 5 | Clutch housing, screw to fasten clutch housing to crankcase | 80 | 8 |
| 6 | Constant mesh shaft cover fastening screw | 23 ±15% | 2.3 ±15% |
| 7■ | Screw securing p.t.o. side cover | 46 ±15% | 4.6 ±15% |
| 8 | Screw securing control cable mounting | 23 ±15% | 2.3 ±15% |
| 9 | Screw securing reverse gear shaft | 23 ±15% | 2.3 ±15% |
| 11 | Side plug on rear cover | 35 | 3.5 |
| 12* | Screw securing rear cover | 23 ±15% | 2.3 ±15% |
| 13 | Speedometer transmitter fixing | 50 | 5 |
| 14 | Screw locking sleeve for transmission coupling on main shaft | 235 | 23.5 |
| 15 | Fixing switches and reversing lights | 40 | 4 |
| 16● | Screw securing ball bearing retaining ring | 9.5 ±15% | 0.9 ±15% |
| 17 | Nut for screw securing lever to control rod | 34 ±15% | 3.4 ±15% |
| 18 | Screw securing gear control mounting | 23 ±15% | 2.3 ±15% |
| 19 | Oil vapour breather | 10 ±15% | 1 ±15% |
| 20● | Screw securing driver to main rod | 9.5● | 0.9 |
| 21● | 5th and 6th gear fork articulation pins | 45 | 4.5 |

- * Spread LOCTITE 5206 sealant on the contact surfaces
- Spread LOCTITE 242 on the thread
- Spread LOCTITE 510 on the thread







TOOLS

| TOOL NO. | DESCRIPTION |
|-----------------|--|
| 99322205 | Assemblies overhaul revolving stand  |
| 99322225 | Unit support (to use with stand 99322205)  |
| 99340205 | Percussion extractor  |
| 99341002 | Single-acting scaffold  |
| 99341003 | Single-acting bridge  |
| 99341004 | Pair of brackets  |







TOOLS

| TOOL NO. | DESCRIPTION |
|------------------------|--|
| <p>99341012</p> |  <p>Pair of brackets</p> |
| <p>99341015</p> |  <p>Constrictor</p> |
| <p>99341017</p> |  <p>Pair of brackets with hole</p> |
| <p>99341019</p> |  <p>Pair of tie rods with grips</p> |
| <p>99341025</p> |  <p>Grips</p> |
| <p>99345003</p> |  <p>Extractor for gearbox front half-casing</p> |

TOOLS


| TOOL NO. | DESCRIPTION |
|-----------------|---|
| 99348001 |  <p>Extractor with locking device</p> |
| 99348004 |  <p>Universal male extractor from 5 to 70 mm</p> |
| 99360522 |  <p>Tool to extract and insert main shaft, transmission shaft and rod - fork assembly</p> |
| 99370006 |  <p>Handle for interchangeable drivers</p> |
| 99370007 |  <p>Handle for interchangeable drivers</p> |
| 99370234 |  <p>Tool for fitting rear bearing and sleeve on main shaft</p> |

TOOLS

| TOOL NO. | DESCRIPTION | |
|-----------------|---|---|
| 99370317 |  | Reaction lever with extension for holding flange |
| 99370629 |  | Transmission support during removal from and refitting to vehicle |
| 99371057 |  | Bracket for supporting gearbox during overhaul (use with 99322205-99322225) |
| 99374091 |  | Punch for fitting bearing external races (dia. 55 ÷ 69 mm use with 99370007) |
| 99374452 |  | Keying device to fit gasket on transmission rear cover (use with 99370006) |
| 99374453 |  | Keying device to fit gasket on transmission |

LONGITUDINAL SECTION


Figure 7



87899

Figure 8


C-C



87881


LONGITUDINAL SECTION

Figure 9




87900

Figure 10



87901

Figure 11



87902

TRANSMISSION TRANSVERSAL CROSS-SECTIONS

Figure 12




Figure 14




Figure 13






Figure 15




TRANSMISSION TRANSVERSAL CROSS-SECTIONS

Figure 16




87889

Figure 17



87890


Figure 18



87891

530210 OVERHAULING THE TRANSMISSION

Figure 19




Remove the rev sensor (4).
 Fit the gearbox (1) with the bracket 99371057 (5) and secure this to the brackets 99322225 (3) on the rotary stand 99322205 (2).
 Remove the plug (4) and drain off the lubricating oil.



The used oil must be disposed of according to the law in force.


530220 Gear control box Disassembly

Figure 20




Shift to neutral.
 Take out the fixing screws (1) and remove the gear control box (2).

Figure 21



Mark the assembly position of the levers (1 and 7) on their respective shafts (2 and 6). Loosen the nuts (4) for the retaining screws (5).
 Extract the levers (1 and 7) from the shafts (2 and 6) and extract these from the box (8). Take off the caps (4).


Figure 22



With a punch (3), remove the spring pin (4) and extract the shaft (2) from the internal lever (1).
 Repeat these steps for the other shaft.

NOTE The coupling lever is bound to the stem by two snap pins.


Figure 23



Use a punch on the point shown by the arrow and eject the O-rings and roller bushes (2) from the box (1).


Assembly

Figure 24



Thoroughly clean the oil vapour vent (3).
 With a suitable punch, mount the roller bearings (1) in the box (2).


Figure 25



Using a suitable punch, mount the O-rings (1) in the box (2), positioning them at the height shown.

Pack the gap between the O-ring and roller bearing with grease.


Figure 26



Mount the selection and engagement levers (1) on their respective shafts (2) and fasten them with the spring pins (3).


NOTE The spring pin (3) must be positioned with the cut horizontal. Fit spring peg (4), with cutting edge positioned at 180° from spring peg (3) cutting edge, in spring peg (3) engagement lever.

Figure 27



Lubricate the roller bearings (1, Figure 25) with TUTELA MR3 grease and mount the shafts (3 and 6) complete with the internal levers (4 and 5) in the box (2). Mount the caps (8 and 9) and levers (1 and 10) on the shafts (3 and 6) in the position marked during disassembly without tightening the nuts for the fixing screw (7).

Figure 28




Thoroughly clean the mating surfaces of the gear control box (2) and apply LOCTITE 5706 sealant on them.

Fit the box (2) on the transmission, taking care that the levers and shafts are positioned correctly in their respective seats.

Tighten the screws (1) to the required torque.

Check levers mounting

Figure 29



Check the assembly of the selection (6) and engagement (3) levers.

The selection (6) and engagement (3) levers must be mounted on their respective shafts so that:


- between the c/c distance of the pin (5) of the selection lever (6) and the outside of the bracket (1) there is a distance **X** of 134 mm;
- between the c/c distance of the pin (2) of the engagement lever (3) and the outside of the bracket (4) there is a distance **Y** of 135 mm.

If a different value is measured, orientate the lever concerned on the respective shaft appropriately.

Then tighten the nuts for the screws to the required tightening torque.

Disassembling the transmission

Figure 30




51924

Shift to neutral.
Dismantle the gear control box as described under the relevant heading.
Remove the two side plugs (1 - 3). Remove the screw (2) and take off the rod (5) dragging device (4).

NOTE The screw threading (2) is treated with LOCTITE 242.


Figure 31



51925

Mark the assembly position of the rod (1) preventing engagement of more than one gear at the same time and remove it from the transmission.


Figure 32



51926

Block rotation of the sleeve (1) by applying the lever 99370317 (3). With the bushing (2) remove the screw (5) with the washer beneath (4).
Take out the lever 99370317 (3).

Figure 33




90250

Extract the sleeve (3) from the main shaft.

NOTE If difficult, remove the sleeve (3) with extractor made up of link 99341003 (1) and grips 99341017 (2) and block (4).


Figure 34



51928

NOTE When putting away the sleeve (1) take care not to damage the phonic wheel (→) obtained by machining.


Figure 35



51829

Remove the screws (1) and take off the cover (2) protecting the input shaft (3).


Figure 36



51930

Perforate the o-ring (2) with a suitable hook and ram extractor 99340205 (1) and remove the o-ring from the transmission box.


Figure 37



51931

Remove the circlip (2) retaining the front bearing (3) from the input shaft (1).


Figure 38



51932

Take out the plug (4) with the washer (3), and extract the spring (2) and the push rod (1).


Figure 39



90209

Remove the two fork knuckle pins (1) which control the 3rd – 4th speed and the two fork knuckle pins (2) which control the 5th – 6th speed.


Figure 40



51934

Push the two locating pins (2) downwards until taking them out of the rear cover (4). Remove the screws (3) securing the rear cover (4) to the transmission (1).


Figure 41



74957

Fit the drive input shaft (1) with tool 99345003 (2) and secure this onto the gearbox (4), with the screws (3); screw down the screw (5) of tool (2) to extract the gearbox from the bearing (6).


Figure 42



51936

Drill the cups (2), screw a special screw into them.
Using the screw, extract the cups (2) from the rear cover (1).
Remove the springs (3) and pawls (4).


Figure 43



90210

Remove the rod (1) controlling the 3rd/4th gear and the main rod (2) from the rear cover (3).


Figure 44



90211

Take out the screw (3) and remove the reverse gear shaft (1) with the mounting (2) from the rear cover (4).

Figure 45




90212

Mount the tool 99360522 (3) onto the rods (4, 5 and 6), on the input shaft (1) and on the transmission shaft (9).
Secure the tool 99360522 (3) on the input shaft (1) with the retaining ring (2) and with the screw (8) to the transmission shaft (9).
Insert the part (13) of the bracket (11) into the reverse gear (14) and tighten the screw (12).
Hook the tool 99360522 (3) onto the lift.
Apply the extractor composed of the bridge 99341004 (16) and ties 99341012 (15) onto the rear cover (7).

NOTE In order not to damage the rear cover (7), place special protections between it and the ties (15).

Using the extractor screw and the lift on the main shaft (10), remove the main shaft (10) from the rear ball bearing and extract the shaft-rod assembly from the rear cover (7).

Figure 46




90213


Remove the rod (1) from the rear cover (2).

0

Figure 47




Clamp the primary shaft (6) in a vice. Remove the rods (10 and 11) with the relevant forks. Remove the forks (3 and 4) and the small blocks.

 Support the secondary shaft (2), slacken the screw (1) and remove the secondary shaft (2).

Remove the RM gear (4). Remove the snap ring (8) and the tool 9936522 (9). Remove the input shaft (7).


Disassembling the rear cover bearings

Figure 48




Remove the screws (1) securing the plates (2). Take out the plates (2). Turn over the rear cover (4) and remove the bearing (3).

Figure 49




Using universal extractor 99348004 (1), remove the outer ring (2) of the transmission shaft bearing.

Figure 50



Using the percussion extractor 99340205 (1) and part 99348004 (2), extract the bushing with the ball bearings (3).


Figure 51



Turn over the rear cover (4). Take out the O-ring (6). Using a suitable punch, remove the ball bearing (5). Remove the tachograph sensor (7) and the reversing light switch (1) with the washer (2) and extract the push rod (3).


Disassembling the transmission bearings

Figure 52




Using universal extractor 99348004 (1), remove the outer ring (2) of the transmission shaft bearing.

Figure 53




Using the percussion extractor 99340205 (1) and part 99348004 (2), extract the bushing with the ball bearings (3).

Figure 54



Remove the screws (1) securing the plates (2). Take out the plates (2). Turn over the transmission. Using a suitable punch, remove the ball bearing (3).

Figure 55




Using the percussion extractor 99340205 (1) and part 99348004 (2), extract the roller bearing (4-3).

Disassembling the main shaft


NOTE Mark the assembly position of each synchronizing device on the respective gear.

Figure 56




Tighten the primary shaft (1) in a vice. Remove the synchroniser ring (4) and the circlip (2). Remove the circlip (3) from its housing.

Figure 57




Remove the sliding sleeve (2) for engaging 5th - 6th gear from the hub (1) and, taking care as the plugs (5) come out with the balls (4) and springs (3), recover them.

Figure 58




Use extractor 99348001 (6) as shown in the figure to extract the primary shaft (1), the 5th gear (7), the synchroniser ring (5), the hub (4), the circlip (3) and the roller bearing (2).

Figure 59




Remove the roller half cages (1).

Figure 60




Use the hydraulic vice to remove from the primary shaft (1): the 1st speed gear (8), the spacer (7), the bush (6), the roller cage (5), the R.M. gear (4) together with the coupling elements, the synchronising ring (3) and the serrated ring (2).

Figure 61




Remove the reverse gear engagement sliding sleeve (2) from the reverse gear (1). Retrieve hub (1) and pads (3) with respective balls (4) and springs (5).

Figure 62



Take out the synchronizer ring (4), middle ring (3), ring (2) and roller bearing (1). Using a hydraulic press, remove the 2nd gear (10), ring (9), middle ring (8), synchronizer ring (7), synchronizer assembly (6) and the bushing (5). Take out the roller bearing (11).


Figure 63



Remove the sliding sleeve (2) for engaging 1st-2nd gear from the hub (1) and, taking care as the plugs (3) come out with their relative balls (4) and springs (5), recover them.

Disassembling the drive input shaft

Figure 64




51956

To replace the cog-wheel (1), use the same general tools for disassembly as for assembly, heat it to a temperature of 80°C.

Disassembling the transmission shaft


Figure 65



90217

Take out the retaining ring (1) holding the 5th gear (2).


Figure 66



90216

Using general tools, extract the internal ring (2) of the rear tapered roller bearing from the transmission shaft (1).


Figure 67



51959

Using a hydraulic press, extract the 6th gear (2) and the internal ring (1) of the tapered roller bearing from the transmission shaft.


Figure 68



51960

Using a hydraulic press, remove the 5th gear (2) from the transmission shaft (1).


Figure 69



51961

Remove the 3rd gear (1) and the roller bearing (2). Remove the synchronizer ring (3). Remove the retaining ring (5) securing the hub (4).


Figure 70



51962

Using a hydraulic press, remove the 4th gear (3), the synchronizer ring (2) and the synchronizer assembly (1). Remove the half roller bearings (4).


Figure 71



51424

Remove the sleeve (2) for engaging the 3rd-4th gear from the hub (1) and, taking care over the plugs (3) coming out with their relative balls (4) and springs (5), recover them.

Figure 72




90218

TRANSMISSION SHAFT ASSEMBLY DRAWING

- 1. Transmission shaft assembly - 2. Tapered roller bearing - 3. Transmission shaft with reverse gear tooting (A), 1st gear (B), 2nd gear (C) - 4. Tapered bearing - 5. 4th gear - 6. Synchronizer ring - 7. Sliding sleeve - 8. Ball - 9. Spring - 10. Plug - 11. Hub - 12. Retaining ring - 13. Half roller bearings - 14. 3rd gear - 15. 6th gear - 16. 5th gear.

Figure 73




PRIMARY SHAFT AND INPUT SHAFT ASSEMBLY

- I. Input shaft with 5th speed gear - 2. Retaining ring - 3. Roller bearing - 4. Single cone synchronizer ring - 5. Sliding sleeve - 6. Plug - 7. Ball - 8. Spring - 9. Hub - 10. 6th gear - 11. Main shaft with 3rd gear tothing (A), 4th gear tothing (B) - 12. Roller bearing - 13. 2nd gear - 14. Dual cone synchronizer - internal ring C, middle ring D, synchronizer ring E - 15. Bushing - 16. 1st gear - 17. Spacer ring - 18. Reverse gear - 19. Synchroniser ring - 20. Gear.

90219


Figure 74



85977

1ST-2ND GEAR DUAL CONE SYNCHRONIZER ASSEMBLY


Figure 75



85978

3RD - 4TH - 5TH - 6TH GEAR SINGLE CONE SYNCHRONIZER ASSEMBLY

Figure 76



86130

SINGLE CONE SYNCHRONIZER ASSEMBLY REVERSE GEAR

CHECKS

Transmission

The transmission and relative covers must show no sign of cracking.

The mating surfaces of the covers and transmission must not be damaged or deformed. Remove any remains of sealant from them.

The seats of the bearings, reverse gear shaft and gear control rods must be neither damaged nor too worn.

Hubs - sliding sleeves - forks

The grooves on the hubs and relative sliding sleeves must not be damaged. The sliding sleeve must run freely on the hub. The plugs and balls for positioning the sliding sleeve must be neither damaged nor worn. The tothing of the sliding sleeves must not be damaged. The forks must be sound with an end float, in the radial groove of the sleeve, no greater than 1 mm.

Bearings

The roller bearings must be in perfect condition with no signs of wear or overheating. They must only be removed if they are to be replaced.

Shafts - gears

The seats on the shafts, for bearings, must be neither damaged nor worn. The tothing of the gears must be neither damaged nor worn.

Synchronizing devices

Check the wear on the synchronizer rings, proceeding as follows:




After this check, the synchronizer rings must be marked on their respective gears to avoid swapping their positions over when assembling.

- See that the friction surface is not undulated.

BK-type single cone synchronizers for 3rd/4th/5th/6th gears

Figure 77



52510

Arrange the synchroniser ring (1) on the respective gear or reverse taper ring (2).


With a feeler gauge, check the distance **S** on two diametrically opposite points.

If the measured value **S** is less than 0.8 mm, replace the synchronizer ring.

Turn the synchronizer ring (1) so as to ensure correct coupling on the cog-wheel.

D-type dual cone synchronizers for 1st/2nd gears

Figure 78



52511


Position the internal ring (3), middle ring (2) and the synchronizer ring (1) on the tapered cog-wheel (4) of the gear.

Turn the synchronizer ring (1) so as to ensure correct coupling between the parts.

Applying a uniform force of 50 N on the synchronizer ring (1), measure the distance **S** on two diametrically opposite points with a feeler gauge.

If the average measured value **S** is less than 1.5 mm, replace all the rings.


Figure 79



5TH - 6TH GEAR SYNCHRONISERS

- A. synchronization reserve 6th-5th gear: 1±1,4 mm
- B. 5th-6th release clearance: 0,3±0,7 mm


Figure 80



3TH/4TH GEAR SYNCHRONISERS

- A. synchronization reserve 1st-2nd gear: 1±1,4 mm
- B. 1st-2nd release clearance: 0,3±0,7 mm


Figure 81



2ND-1ST GEAR SYNCHRONISERS

- A. synchronization reserve 2nd-1st gear: 1,6±2,0 mm
- B. 1st-2nd release clearance: 0,9±1,5 mm

Figure 82




REVERSE GEAR SYNCHRONISER

- A. Synchronization reserve: 0,9±1,4 mm
- B. release clearance: 0,35±0,85 mm

- 1. Hub - 2. 5th gear - 3. Synchronizer ring - 4. Sliding sleeve - 5. 6th gear cog-wheel - 6. 3rd gear cog-wheel - 7. 4th gear cog-wheel - 8. 2nd gear cog-wheel - 9. 1st gear cog-wheel - 10. Middle ring - 11. Ring - 12. Reverse gear - 13. Reverse gear ring

Mounting the transmission shaft


Figure 83



51966

Clamp the transmission shaft (1) in a vice and position the half roller bearings (2) on it.


Figure 84



51967

Mount the 4th gear (2) and position the synchronizer ring (1) on this.


Figure 85



51968

Heat the hub (2) to a temperature of $110^{\circ} \pm 150^{\circ}\text{C}$ and mount it on the transmission shaft (1), taking care that the protrusions (3) of the synchronizer ring are positioned correctly in their seats in the hub (2).

Figure 86




51969

Mount the retaining ring (1) whose thickness produces null end float in its seat.

Check the end float of the 4th gear (2). It should be $0.15 \div 0.40$ mm.


Figure 87



51970

Mount the sliding sleeve (1) on the hub (2). Put the springs (5), plugs (3) and balls (4) into the seats in the hub (2), settling them under the sliding sleeve (1).


Figure 88



51971


Position the synchronizer ring (2) on the hub (3) so that its protrusions enter the seats in the hub (3). Mount the roller bearing (1).

Figure 89



Mount the 3rd gear (1).


Figure 90



With a hydraulic press, mount the 6th gear (1) pre-heated to approx. 170°C.


Check the end float of the 3rd gear (2). It should be $0.15 \div 0.40$ mm.

Figure 91




With a hydraulic press, mount the 5th gear (1) pre-heated to approx. 170°C.

Figure 92



Mount the retaining ring (1) whose thickness produces null end float in its seat.

Figure 93




Heat the internal rings (1-3) of the tapered roller bearings to a temperature of approx. 80°C and, with a suitable punch (1), mount them on the transmission shaft (2).

Mounting the main shaft


NOTE Mount the synchronizer rings on their respective gears according to the marks made during disassembly or when checking in the case of replacement.

Figure 94



Tighten the main shaft (1) and position the roller bearing (2) on it.


Figure 95



51980

Mount the 2nd gear (4) and position the ring (3), middle ring (2) and synchronizer ring (1) on it, taking care that the tongues (→) of the middle ring (2) enter the slots (→) in the gear (4).

Figure 96




51981

Heat the hub (2) to a temperature of $80^{\circ} \pm 110^{\circ}\text{C}$ and mount it on the main shaft (1), taking care that the projections (3) of the synchronizer ring and the tongues (→) of the ring (3, Figure 95) are positioned correctly in the seats in the hub (2).

Check the end float of the gear (4). It should be $0.25 \div 0.5 \text{ mm}$.


Figure 97



51982

Mount the sliding sleeve (2) on the hub (1). Put the springs (5), plugs (4) and balls (3) into the seats in the hub (1), settling them under the sliding sleeve (2).


Figure 98



51983

Position the synchronizer ring (3), middle ring (2) and ring (1) on the hub (4), taking care that the tongues (→) of the ring (1) and the projections (→) of the ring (3) enter the seats in the hub (4).


Figure 99



51984

Position the roller bearing (2). Mount the 1st gear (1) taking care that the tongues (3) of the middle ring enter the slots in the gear (1).


Figure 100



85961

Heat the spacer ring (2) to a temperature of approx. $80^{\circ} \pm 110^{\circ}\text{C}$ and mount it on the main shaft (1). Check the end float of the gear (4); this should be 0.15 ± 0.3 mm. Heat the bushing (3) to a temperature of approx. $80^{\circ} \pm 110^{\circ}\text{C}$ and mount it on the main shaft (1). Mount the roller bearing (5).


Figure 101



85950

Fit reverse gear (1). Fit sliding sleeve (2) on reverse gear hub (1). Insert the springs (5), the pads (3) and the balls (4) in the hub seats (1) and arrange them with respect to the sliding sleeve (2).


Figure 102



85951

Fit the synchroniser ring (2). Heat the gear ring (3) to $110^{\circ} \pm 150^{\circ}$ and fit on primary shaft (1). Check reverse gear play (4) which must be 0.15 ± 0.4 mm.


Figure 103



51952

Turn the main shaft over and position the half roller bearings (3) on it. Mount the 6th gear (2) and position the synchronizer ring (1) on it.

Figure 104




51990

Heat the hub (2) to a temperature of approx. $80^{\circ} \pm 110^{\circ}\text{C}$ and mount it on the main shaft (1) taking care that the projections (3) of the synchronizer ring are positioned in the seats in the hub (2).

Mount the retaining ring (4) whose thickness produces null end float in its seat.

Figure 105




51991

Mount the sliding sleeve (2).

Put the springs (3), plugs (5) and balls (4) into the seats in the hub (1) and position them under the sliding sleeve (2).

Figure 106




Heat the bearing (2) to $80 \pm 10^\circ\text{C}$ and fit on primary shaft (1). Fit the circlip (4) and synchroniser ring (3).

85952

Rods - forks - selector - driver Disassembly - assembly

Figure 107



1. Rod with reverse gear engagement fork - 2. Main rod - 3. Rod with 1st-2nd gear engagement fork - 4. Fork control rod (5). - 5. 3rd-4th gear engagement fork - 6. Fork control rod (7) - 7. 5th-6th gear engagement fork

90224

Check the state of the plugs (2) of the 3rd-4th-5th-6th gear engagement fork and replace them if they are worn.

To replace the forks of the selector and driver from their respective control rods it is sufficient to remove the retaining spring pins with a suitable punch.

For assembly, carry out these steps in reverse order, replacing the spring pins.

NOTE Spring pegs must be positioned with the cutting edge placed level.

Mounting the transmission


NOTE During assembly, the gaskets, retaining rings, O-rings, spring pins, safety plates and springs must always be replaced with new parts.

The nuts and screws must be tightened to the required torque unless specified otherwise, with the thread dry and degreased.

Adjusting the transmission shaft bearing end float

NOTE The transmission shaft bearing end float is only adjusted if the bearings, transmission shaft gears, transmission shaft, transmission or rear cover have been replaced or if too much clearance has been found.

Figure 108




51993

Determine the thickness **S** of the ring (1) for adjusting the transmission shaft bearing end float, proceeding as follows:

- position the thinner adjustment ring (1) 1.65 mm thick in the seat in the transmission (3);
- heat the seat of the bearing (2) to approx. 60°C . Mount the external ring of the bearing (2) with the punch 99374091 and grip 99370007, see Figure 110;
- mount the transmission shaft complete with the internal rings of the tapered roller bearings;
- mount the external ring of the rear bearing in the rear cover in a similar manner to the front one (see Figure 110);
- mount the rear cover on the transmission;
- screw on the 8 fixing screws so that between one screw and another there is a hole for a free screw and tighten them to the required torque;
- turn the transmission shaft to settle the bearings;

Figure 109



52512

□ using a comparator (2) zeroed on the 5th gear tooth of the transmission shaft (1) measure its end float **A** through the opening for the power take-off connection and note it down.

The thickness **S** is given by:

$$S = A + B + C$$

Where:

A = measured end float, e.g. 0.18 mm;


B = average bearing pre-load, e.g. 0.02 mm;

C = adjustment value used for the measurement 1.65 mm;

$$S = 0,18 + 0,02 + 1,65 = 1,85$$

Then mount the rear cover, transmission shaft and external ring of the front bearing.

Figure 110




51996

Position the adjustment ring (1, Figure 108) of the thickness determined with the above measurement. Heat the bearing seats of the box to a temperature of approx. 80°C and mount:

- the external ring (3) of the front tapered roller bearing with punch 99374091 (2) and grip 99370007 (1);
- the ball bearing (6) with a general punch;
- the bushing with ball bearing (9) and the roller bearings (4-5) with a general punch.

Position the retaining plates (7) and secure them to the box, tightening the screws (8) to the required torque.

Figure 111




51997

Heat the bearing seats of the rear cover (1) to a temperature of approx. 80°C and mount:

- the external ring (3) of the tapered roller bearing with punch 99374091 (2) and grip 99370007 (1);
- the ball bearing (4) and the bushing with ball bearings (7) with a general punch.

Position the retaining plates (6). Secure these to the rear cover, tightening the screws (5) to the required torque.

Figure 112



90225

Clamp the primary shaft (13) in a vice, fit on it the synchronising ring and the input shaft (8).

Fit tool 99360522 (10) on the input transmission shaft (8) and fasten with the circlip (9).


Couple the secondary shaft (2) to the primary shaft (13) and fasten by tightening the screw (1) on the tool (10).

Fit the clutch forks: 3rd – 4th speed (4) and 5th – 6th speed (3) on the relevant sliding sleeves.

Couple the rods (11 and 13), fit the relevant forks on the sliding sleeves and clamp the rods with the sleeves of tool 99360522 (10).

Couple the reverse gear (7) with the shafts (2 and 13) and fasten it to them with the part of the bracket (5) tighten the screw (6).

Figure 113




90226

Fit the rod (3) in the rear cover (4).

Hook hoist to tool 99360522 (1), lift the unit (2) as previously mounted, and partially insert it into the rear cover (4).

During this operation, check that the output shaft goes into the supporting ball bearing and the control rods (5-6) go into their respective seats.

Figure 114




52000

Screw tool 99370234 pin (7) into output shaft hole (2) and fit bushing (4) and spacer (5) on tool.

Screw on the nut (6) and at the same time lower the hoist so the output shaft (2) is positioned on the rear ball bearing (3).

Remove tools 99360522 (1) and 99370234 (4-5-6-7).

Figure 115




90227

Place the roller bearings (2) in the reverse gear (1).

Fit the stem (2) and the support (3) so that the respective holes for the fastening screw are aligned with the relevant hole on the rear cover (5).

Drive in the fastening screw (6) of the stem (3) and the support (4) on the rear cover (5) and tighten it to the prescribed torque.


Figure 116



90210

Fit the control rod (1) of the 3rd - 4th speed and the main rod (2) in the rear cover (3).


Figure 117



90229

Apply some grease on the pin of the dragging device (2) and fit the clutch fork (1) for the 3rd – 4th speed on this device.


Figure 118



51936

Put the pawls (4) and springs (3) in the rear cover (1) and drive in the retaining cups (2) with a suitable punch. Apply LOCTITE 5206 on gearbox attachment.

Figure 119




90230

Warm up the front bearing inner ring (2) at 90+| 10°C and fit the gearbox (1) on the rear cover.

NOTE When fitting the gearbox, check that the shafts and the control rods fit correctly in the respective seat and that the fork (1, Figure 117) does not disconnect from the clutch rod (2, Figure 117) for the 3rd – 4th speed.


Figure 120



51931

Fit a new retaining ring (2) securing the front bearing (3) onto the input shaft (1).

Figure 121




90231

Screw on the screws (2) securing the rear cover (3) to the transmission (1) without fully tightening them.

Mount the centring pins (4) in the rear cover (3) and in the transmission (1).

Tighten the screws (2) to the required torque.

Figure 122



NOTE Make sure that the clutch control rods are all in neutral position.


Apply LOCTITE 242 to the thread of the pins (1).

Screw the pins (1) into the box, checking that their ends go into the hole of the 3rd/4th gear engagement fork link (1, Figure 117) and then tighten them to the required torque.

Drive in the pins (2) and check that their ends fit in the knuckle hole of the clutch fork for the 5th – 6th speed and tighten it to the prescribed torque.


NOTE If during these assembly operations the fork (1, Figure 117.) comes free of the control rod, it will not be possible to mount the pins (1) until they have been reconnected.

Figure 123




Mount the push rod (1) and the spring (2). Screw on the plug (4) with a new washer (3), tightening it to the required torque.

Figure 124




Using the key 9937455 (3), mount the O-ring (2) in the transmission (1).

Figure 125




Mount the cover (1) protecting the input shaft and tighten the screws (2) to the required torque.

Figure 126



Mount the O-ring (2) in the rear cover (1) with the key 99374454 (4) and the grip 9937006 (3).


Figure 127



52008

Fit the transmission shaft coupling (1) onto the output shaft. If there is any interference, use the tool 99370234 (2) for assembly with the lever 99370317 (3) to lock the coupling.


Figure 128



52009

Mount the washer (3) and screw on the screw (4). Lock the rotation of the flange (1) with the lever 99370317 (5) and tighten the screw (4) to the required torque. Mount the tachograph sensor (2) and the reversing light switch.


Figure 129



51925

Mount the rod (1) preventing engagement of more than one gear at the same time, in the position marked during disassembly.


Figure 130



51924

Apply sealant to the thread of the plugs (1 - 3), screw them into the box, tightening them to the required torque. Position the driver (4) on the rod (5). Secure it with the screw (2) after applying LOCTITE 242 onto its thread.

Figure 131



52118

Fit a new gasket (1) onto the transmission. Apply LOCTITE 510 on the screw threading (2). Mount the side cover (3) and tighten the fixing screws (2) to the required torque. Mount the control box as described under the relevant heading. Mount the oil drainage plug, tightening it to the required torque. Fill the transmission with lubricating oil in the required quantity and grade. Mount the oil filler and level indicator cap, tightening it to the required torque.

6 AS 300 VD TRANSMISSION

| | Page |
|---|--------|
| GENERAL | 122/3 |
| GEAR SELECTION AND ENGAGEMENT | 122/4 |
| <input type="checkbox"/> Neutral arrangement and/or 3rd/4th gear selection and engagement arrangement | 122/4 |
| <input type="checkbox"/> 1st/3rd gear selection election and engagement arrangement | 122/4 |
| <input type="checkbox"/> 5th/6th gear selection and engagement arrangement | 122/5 |
| <input type="checkbox"/> Reverse gear selection and engagement arrangement | 122/5 |
| <input type="checkbox"/> Safety device | 122/5 |
| SPECIFICATIONS AND DATA | 122/6 |
| MOTION TRANSMISSION GEAR SEQUENCE | 122/8 |
| DIAGNOSIS EQUIPMENT | 122/12 |
| MODUS - IT 2000 - E.A.S.Y. CONNECTION .. | 122/13 |
| TIGHTENING TORQUES | 122/14 |
| TOOLS | 122/15 |
| GEARBOX REMOVAL-REFITTING | 122/16 |
| <input type="checkbox"/> Removal | 122/16 |
| <input type="checkbox"/> Refitting | 122/19 |
| REPAIR WORK | 122/23 |
| CONTROL UNIT | 122/23 |
| <input type="checkbox"/> Removal | 122/23 |
| <input type="checkbox"/> Refitting | 122/24 |
| CLUTCH ACTUATOR | 122/25 |
| <input type="checkbox"/> Removal | 122/25 |
| <input type="checkbox"/> Refitting | 122/26 |
| GEARBOX ACTUATOR | 122/26 |
| <input type="checkbox"/> Removal | 122/26 |

Page

| | |
|--|--------|
| <input type="checkbox"/> Refitting | 122/27 |
| CHASSIS WIRING - GEARBOX | 122/27 |
| <input type="checkbox"/> Removal | 122/27 |
| <input type="checkbox"/> Refitting | 122/28 |
| GEARBOX WIRING - GEARBOX | 122/28 |
| <input type="checkbox"/> Removal | 122/28 |
| <input type="checkbox"/> Refitting | 122/29 |
| CALIBRATION | 122/30 |

GENERAL

The 6 AS 300 VD gearbox is of the electro-mechanic type, with synchronized forward speed engagement.

This is the automatic version of mechanic transmission 6 AS 300.

It is made up of a light-alloy case (which also acts as the clutch cover), a rear cover (where the speed engagement controls and the gearing are housed), an actuator for speed selection and engagement, a clutch control actuator, and an electronic control unit.

There is an opening on the side of the transmission to apply a power take-off.

Drive transmission is accomplished by a set of helical-toothed constant mesh gears, for both forward and reverse gears.

The splined or machined gears are on four shafts: input, main, transmission and reverse gear.

The input and main shafts are supported, in the transmission, by watertight, non-adjustable ball bearings.


The transmission shaft is supported, in the transmission, by roller bearings that can be adjusted axially by means of ring shims.

Speed engagement synchronization is achieved by means of single-cone, free-ring synchronizers (for 3rd, 4th, 5th and 6th speeds) and double-cone, free-ring synchronizers (for 1st and 2nd speeds).

The reverse speed is not synchronized.

Control inside the transmission is accomplished with five rods: a main rod to select and engage gears; four rods equipped with forks for engaging gears.

Figure 131/1



1. Progressive production number - 2. 1st/6th speed ratio - 3. Amount of oil (in dry conditions) - 4. Oil standards - 5. Tachograph ratio - 6. IVECO number - 7. ZF serial number.

V= VAN

D = Direct drive

101934


GEAR SELECTION AND ENGAGEMENT

The combined action of the selector lever (2) and the engagement lever (1) cause the rotation and axial movement of the rod (4) in two subsequent steps to engage the required gear by means of the rods (8-7-6 and 9).

The motion of speed selection/engagement levers occurs through the action of two electric motors (M) managed directly by the gearbox electronic control unit.

Neutral arrangement and/or 3rd/4th gear selection and engagement arrangement

Figure I31/2



3rd/4th gear selection

According to the angular position of the selector lever (2), the slider (3) turns with the rod (4) (which is integral) and the selector (5) arranges the slider on the 3rd/4th gear rod (9). At the same time, the slider (3) moves the rod (10) to prevent the simultaneous engagement of two gears, to keep the 3rd and 4th gear engagement rod (9) free and to prevent movement of the other rods by engaging the grooves in the rods.

3rd/4th gear engagement


According to the movement of the engagement lever (1), the slider (3) axial moves the rod (4) (which is integral), the selector (5) (previously arranged) and consequently the chosen 3rd and 4th gear engagement rod (9).

Neutral position coincides with the 3rd/4th gear selection arrangement.

In this case, the vertical axis of the selector lever (2) is exactly at 90° with respect to the horizontal axis of the control corresponding to no angular variation of the rod (4).

1st/3rd gear selection election and engagement arrangement

Figure I31/3




This arrangement is obtained by moving the selector lever (2) anticlockwise. In this way, the selector (4) is inserted in the 1st/2nd gear engagement rod (5).


By moving the lever (1), the slider (3) will axially move the 1st/2nd gear engagement rod (5).

5th/6th gear selection and engagement arrangement

Figure 131/4



SECTION A-A




101937

This arrangement is obtained by moving the selector lever (2) clockwise. In this way, the selector (4) is inserted in the 5th/6th gear engagement rod (5).


By moving the lever (1), the slider (3) will axially move the 5th/6th gear engagement rod.

Reverse gear selection and engagement arrangement

Figure 131/5



SECTION A-A



101938

This arrangement is obtained by moving the selector lever (2) anticlockwise. In this way, the selector (4) is inserted in the reverse gear engagement rod (5).

By moving the lever (1), the slider (3) will axially move the reverse gear engagement rod (5).








Safety device

The transmission is equipped with a device which prevents the simultaneous engagement of two gears.













It consists of a suitably shaped rod (6) fitted transversally in the transmission box.

The slider (3), moves the rod (6) under the action of the lever (2). This keeps the selected gear engagement rod free and prevents movement of the other gears by engaging their respective grooves.

SPECIFICATIONS AND DATA

| | TRANSMISSION | 6 AS 300 VD |
|---|---|--|
|  | Type | Electro-mechanic |
| | Input torque | 300 Nm |
| | Weight | 72 kg |
|  | Speeds | 6 forward speeds 1 reverse speed |
| | Speed control | Electronic |
|  | Power take-off | Optional (HYDROCAR type only) |
|  | Speed engagement: Forward speeds <input type="checkbox"/> 5th/6th - 3rd/4th <input type="checkbox"/> 1st/2nd Reverse speed Speed retention mechanism | Single-cone synchronizer Dual-cone synchronizer Quick-connect (non-synchronized) type Sliding sleeves retained by pawls and springs |
|  | Gears | Helical-toothed constant mesh gears |
|  | Gear ratio First Second Third Fourth Fifth Sixth Reverse | 6.727 3.947 2.555 1.776 1.289 1.000 6.055 |
|  | Shaft bearings: Main shaft Transmission shaft | watertight ball bearing tapered roller |


SPECIFICATIONS AND DATA

| | | |
|---|---|---|
|  | Transmission shaft bearing end play | $0 \pm -0.05 \text{ mm}$ |
|  | Transmission shaft bearing end play adjustment | by shims |
|  | Shim thickness for transmission shaft bearing end play adjustment | - |
|  | <p>Main shaft</p> <p>Temperature for fitting:</p> <input type="checkbox"/> hubs for sliding sleeves $80^\circ \pm 110^\circ\text{C}$ <input type="checkbox"/> 1 st -R gear bushes and spacer ring $80^\circ \pm 110^\circ\text{C}$ <input type="checkbox"/> front bearing* $90^\circ \pm 110^\circ\text{C}$ | |
|  | <p>Transmission shaft</p> <p>Temperature for fitting:</p> <input type="checkbox"/> bearings 80°C (max 120°C) <input type="checkbox"/> 5 th -4 th gears $170^\circ \pm 160^\circ\text{C}$ | |
|  | <p>Gear end float:</p> <p>1st - 3rd - 4th - R - 5th gear $0.15 \pm 0.40 \text{ mm}$ 2nd gear $0.25 \pm 0.5 \text{ mm}$</p> | |
|  | 5 th - 4 th gear sliding sleeve hub retaining ring end float | $0 \pm 0.15 \text{ mm}$ |
|  | 5 th - 4 th gear sliding sleeve hub retaining ring thickness | - |
|  | <p>Retaining ring end float:</p> <input type="checkbox"/> transmission shaft front bearing $0 \pm 0.1 \text{ mm}$ <input type="checkbox"/> main shaft roller bearing $0 \pm 0.1 \text{ mm}$ | |
|  | Transmission shaft rear bearing retaining ring thickness | - |
|  | Sealant | <p>LOCTITE 510</p> <p>LOCTITE 242</p> <p>LOCTITE 5206</p> |
|  | Type of oil: | TUTELA TRUCK GEARLITE |
| | Quantity | <p>2.7 litres</p> <p>2.43 kg</p> |

* = Do not use hot air equipment to heat bearing.

MOTION TRANSMISSION GEAR SEQUENCE


Figure 131/6



101939

1ST SPEED


Figure 131/7



101940


2ST SPEED

Figure 131/8




3ST SPEED

Figure 131/9



4ST SPEED


Figure I31/10



101943

5ST SPEED


Figure I31/11



101945

6ST SPEED

Figure 131/12



101946


REVERSE SPEED

DIAGNOSIS EQUIPMENT

DISPLAY

First-level diagnosis, which makes it possible to display the errors (encoded) container in the control unit memory. Information is shown on the display only by means of diagnosis equipment.

Figure I31/I3



I01947

MODUS

Computer-assisted diagnosis station intended for diagnosis of electronically-controlled braking systems, pneumatic suspensions, engines and systems.]

This station is equipped with auxiliary functions such as electronic control unit programming, spare part catalogue referencing, time-charts, etc.

IT 2000

IT 2000 is a diagnosis instrument for all Electronic Systems fitted to IVECO vehicles. It allows you to promptly operate on a vehicle by recognizing the latter by means of the chassis number.

It stores the results of the diagnostic work carried out.

It can also be used as a laptop PC and is set for remote diagnosis.

Using MODUS as a mother station allows you to update and configure IT 2000.

E.A.SY.

The E.A.SY. system allows you to easily diagnose and program the various electronic controls unit fitted to the vehicle. It is made up of an ECI module for communication with the electronic control units and a Panasonic PC.


The ECI module allows you, by taking advantage of the Panasonic PC, to easily carry out work on the road; in particular, diagnostic work can be assisted by a specialized remote centre, thanks to the wireless technology incorporated into the Panasonic PC (e.g. GPRS).

MODUS - IT 2000 - E.A.S.Y. CONNECTION

The 38-pole connection makes it possible to perform the following operations:

- Gearbox control unit data reading
- Error (if any) detection and clearing
- Programming/calibrating
- Clutch engagement/release control
- Control unit programming and configuring

Figure 131/14




A. IT 2000 - B. E.A.S.Y. - C. MODUS

102266

TIGHTENING TORQUES

Figure 131/15



101948

| | DESCRIPTION | TORQUE | |
|-----|--|----------|----------|
| | | Nm | kgm |
| 1● | Screw securing driver to main rod | 9,5 | 0,9 |
| 2 | Gearbox actuator support fastening screw | 23 | 2,3 |
| 3 | Clutch housing, screw to fasten clutch housing to crankcase | 80 | 8 |
| 4 | Constant mesh shaft cover fastening screw | 23 ±15% | 2,3 ±15% |
| 5■ | Screw securing p.t.o. side cover | 46 ±15% | 4,6 ±15% |
| 6 | Plugs for rod preventing gear engagement | 32 | 3,2 |
| 7 | Clutch actuator fastening screws | 23 | 2,3 |
| 8 | Screw securing reverse gear shaft | 23 ±15% | 2,3 ±15% |
| 9* | Screw securing rear cover | 23 ±15% | 2,3 ±15% |
| 10 | Electronic control unit fastening screws | 9,5 | 0,9 |
| 11 | Side plug on rear cover | 35 | 3,5 |
| 12 | Speedometer transmitter fixing | 50 | 5 |
| 13 | Screw locking sleeve for transmission coupling on main shaft | 235 | 23,5 |
| 14 | Cap | 32 | 3,2 |
| 15● | Screw securing ball bearing retaining ring | 9,5 ±15% | 0,9 ±15% |
| 16 | Gearbox actuator fastening screws | 23 | 2,3 |
| 17 | Electric motor fastening screws | - | - |

* Spread LOCTITE 5206 sealant on the contact surfaces

● Spread LOCTITE 242 on the thread

■ Spread LOCTITE 510 on the thread

TOOLS

TOOL NO.


DESCRIPTION

99327030



E.A.S.Y.

99327001




Modus station

530210120 GEARBOX REMOVAL/REFITTING

Removal


Disconnect the battery cable in engine opening.
Place the vehicle in a pit, or on an auto lift or special supporting stands.

Figure I31/I6




Remove the straps (shown by arrows) that secure the electric cable to the gearbox.

Figure I31/I7




Remove reverse gear light connectors (1) and revs number sensor (2).
Remove the power take-off electric connections (if any) from the other side of the gearbox.

Figure I31/I8




Push the safety retainer downwards, then remove the connector from the control unit (see arrow).

Figure I31/I9




Remove electric cable fastening strap (1) on the clutch actuator side.

Figure I31/I20




Press clutch actuator connector pull-back spring (1), as shown by the arrow

Figure I31/I21



Remove connector (1) from clutch actuator (2).

Figure 131/22




Prior to removing the actuator, verify that the clutch is closed. This can be done either by means of the diagnosis instrument or by visually inspecting the position of the fork which must be perpendicular to the gearbox axis.

In the event that the clutch has been left open, due to a mechanic or electric fault, the fork will be loaded by the actuator internal spring


Therefore, avoid touching the engaging tip straight with your hands.

Figure 131/23




Remove the four clutch actuator fastening screws (1). Take off actuator (2).

Figure 131/24




Remove screws (1) securing the starting motor to the gearbox case front cover. Then, place it carefully in the engine compartment.

Figure 131/25




Unscrew the four screws (2) securing drive shaft (1) to the gearbox.

Figure 131/26




Properly secure drive shaft (1) to the chassis.

Figure 131/27




Remove the two hexagonal screws (1), then take off the engine lower cover (opposite the axle).

Figure 131/28




Before mounting bracket 99372069, remove a number of screws securing gearbox to block.

Figure 131/29




Use a hydraulic jack to position bracket 99370629 (1) under the gearbox; then, put the chain onto the gearbox and place a ring of the same into the bracket slotted hole. Screw down the nut so as to tightly secure, through the chain, the gearbox to the bracket.

Figure 131/30




Remove screw (1) centrally securing the rear crossbar to the gearbox.

Figure 131/31




Remove the crossbar fastening screws (1) on the left side.

Figure 131/32



Remove the crossbar fastening screws (1) on the right side, then remove the crossbar, taking care not to drop it on the floor.


Figure 131/33



Remove boot (1) from its housing. This operation is necessary to make the fork travel the full disengagement stroke when detaching the gearbox. Remove the remaining screws securing the gearbox to the clutch bell.

Move the gearbox backwards until the motion input shaft has come out of the clutch disc hub. Fully take out the gearbox, taking care not to hit it or get it caught in some component.


Figure 131/34



102152

After the detachment operation has been completed, pressure plate bearing (1) shall remain fitted into the clutch (as shown in the figure).


Figure 131/35



102153

Use pliers to act on the retaining ring to disassemble bearing (1).

Figure 131/36




102154

Remove bearing (1).

Refitting


Figure 131/37



102155

Press the pressure plate bearing onto the shaft and the fork against the bearing, as shown in the figure. Apply grease MRM2 to the fork at the bearing pressure point.


Figure 131/38



102156

Put rubber boot (1) into its housing.

Figure 131/39




102157

Couple gearbox (2) with clutch (1).


NOTE In order to facilitate coupling, two guiding pins, fitted onto two of the holes used to secure the gearbox to the base unit, can be used.

Figure I31/40




Manually screw down screws (1) securing the gearbox case to the base unit prior to tightening them to torque.

Figure I31/41




NOTE Pull the fork (3) towards the control unit, so that pressure plate bearing (2) is correctly engaged into diaphragm spring (1).

Figure I31/42




Secure the cable to the gearbox by means of the special fasteners (1).

Figure I31/43




Screw down gearbox fastening screws (1) by tightening them to torque.

Figure I31/44



Screw down screws (1), then fit the engine lower cover.


Figure 131/45



102163

Re-attach the starting motor to the gearbox case front cover by tightening the screws (1) to the specified torque.


Figure 131/46



102149

Secure crossbar (1) to the gearbox and to the chassis by tightening the screws to the specified torque.


Figure 131/47



102165

Fit the clutch actuator (1) engaging tip into the special fork slot, taking care not to touch it straight with your hands.


Figure 131/48



102141

Secure clutch actuator (1) to the gearbox by means of the four screws (2), then tighten to the specified torque.


Figure 131/49



102167

Connect connector (1) to the clutch actuator.


Figure 131/50



102168

Secure the gearbox cable by means of strap (1).


Figure 131/51



102169

Connect connectors (1) to the control unit.


Figure 131/52



102170

Properly secure the connector until the pull-back spring clicks into position (see arrow).

Figure 131/53




102171

Connect the reverse light (1) and revs number sensor (2) connectors.

Connect the electrical connections of the power take-off, if present, from the other side of gearbox.


Figure 131/54



102172

Secure the wiring to the gearbox, as shown by the arrows in the figure.

Figure 131/55



102143

Secure drive shaft (1) to the gearbox by tightening fastening screws (2) to torque.

After the gearbox has been re-attached completely, check for correct connection of electric cables.

NOTE After re-attachment has been completed, perform the specific calibration procedure by means of the diagnosis instrument described on page 122/30.

REPAIR WORK




This chapter describes the replacing operations for the components available as spare parts only. No overhauling work is permitted inside the gearbox. In such case, the entire gearbox complete with actuators, cable and control unit shall be forwarded to the ZF service centre.

66136114 CONTROL UNIT

Removal

Place the vehicle in a pit or on an auto lift.
Disconnect the battery cable in the engine compartment.

Figure 131/56



102162


Remove connector (4) from control unit (1) by pulling the safety retainer downwards, as shown by the arrow.

Remove strap (6). Unscrew screws (2, 3).

Remove screw (5) while holding the control unit and taking care to recover spacer (7) placed behind screw (3). Take off control unit (1).

Refitting

Figure 131/57



102164

Screw down screw (5), yet without tightening it to torque.

Fit spacer (7), between the control unit and the gearbox, behind screw (3), then screw down the latter.

Screw down screws (2).

Screw down all screws (2, 3 & 5) to the specified torque.




Insert control unit connector (4) by securing it with the safety hook, as shown by the arrow.

Connect the battery cable.

NOTE After re-attachment has been completed, perform the specific calibration procedure by means of the diagnosis instrument described on page 122/30.

505279104 CLUTCH ACTUATOR**Removal**

Figure 131/58



102166

Place the vehicle in a pit, or on an auto lift or special supporting stands.

Disconnect the battery cable in the engine compartment.

Remove strap (1).

Take off connector (5) by pressing onto the fastening springs, as shown by the arrows.



Prior to removing the clutch actuator, make sure that the clutch is closed.

Engaging lever (4) must be in the position shown in box A (perpendicular to the gearbox axle).

If the lever is not found in that position, the clutch will be open.

This condition can be inspected both visually and by getting connected to the vehicle by means of the diagnosis instrument and subsequently reading the data memory. In the event that the clutch is

open, it is required that the action of the lever is forced back, since the lever is loaded by the clutch diaphragm spring. Properly lock the motion of lever (4), and avoid, during the subsequent actuator releasing phase, getting your hands near the engaging tip area.


Remove the four fastening screws (3).

Take off clutch actuator (2).




In the event that the actuator has been taken off with the clutch open, release lever (4), previously engaged, with the utmost care.

Avoid touching the lever straight with your hands, owing to the lever being loaded.

Refitting**Figure 131/59**

Position clutch actuator tip (1) into fork aperture (3).
Tighten the four fastening screws (2) to the specified torque.

Figure 131/60

Fit connector (2) by pressing it until it gets engaged.
Secure the cable by means of strap (1).
Connect the battery cable.

NOTE After re-attachment has been completed, perform the specific calibration procedure by means of the diagnosis instrument described on page 122/31.


500520100 GEARBOX ACTUATOR**Removal**

Place the vehicle in a pit, or on an auto lift or special supporting stands.

Disconnect the battery cable in the engine compartment.
Take off the clutch actuator, as described on page 122/25.

NOTE The actuator, positioned in the upper part of the gearbox, cannot be accessed, owing to the very narrow space between the cabin floor and the actuator itself.


Proceed as it follows:

Figure 131/61

Place a pit lift (2) under gearbox (1). Unscrew the gearbox crossbar fastening screws. Lower the lift so as to obtain a distance "A" of 12-13 cm between the actuator and the cabin floor.

NOTE This operation must be carried out with the greatest care, avoiding hitting the front part of the power unit.

Figure I31/62



102191

Take electric connectors (2) off the actuator.

Unscrew electric motor support fastening screw (4). Take off supports (3).


Use a suitable tool (5) to remove the eight fastening screws (1), then take off gearbox actuator (6).

NOTE Clean the supporting surface of the actuator on the gearbox case.

Refitting

Re-attachment is carried out by reversing the order of detachment operations. Also follow the advice below:

Figure I31/63



102192

- Apply an even coat of LOCTITE 574 sealant on the gearbox actuator supporting surface.
- Position the actuator into its seat with the greatest care.
- Tighten the nuts or screws to the specified torque.


NOTE After re-attachment has been completed, perform the specific calibration procedure by means of the diagnosis instrument described on page 122/31.

769152104 CHASSIS WIRING - GEARBOX

Removal

Place the vehicle in a pit, or on an auto lift or special supporting stands.

Figure I31/64




102193

Open the engine hood.

Unscrew screw (1), disconnect the battery cables and take off battery (2). Take connector (3) off EDC central unit.


Figure 131/65



102194

Disconnect wiring (I) from the gearbox control unit, taking care that it is not hit or does not get caught.

Figure 131/66



102195

Take full wiring (I) off the vehicle.



Refitting

Re-attachment is carried out by reversing the order of detachment operations. Also tighten the nuts or screws to the specified torque.

NOTE After the re-attachment operation has been completed, verify, by getting connected to the vehicle by means of the diagnosis instrument, that no error is found in the gearbox control unit fault memory.


769152104 GEARBOX WIRING - GEARBOX

Removal

Place the vehicle in a pit, or on an auto lift or special supporting stands.

Disconnect the battery cable in the engine compartment.


Figure 131/67



102196


Remove the straps (shown by arrows) that secure the cable to the gearbox.

Figure I31/68




Remove connector (1) from control unit (2), by releasing the pull-back spring downwards, as shown by the arrow.

Figure I31/69



Press connector springs (2) inwards (see arrows).
Remove the connector from clutch actuator (1).

Figure I31/70



Remove the connectors (1) from the gearbox actuator electric motors by pressing the fastening springs, as shown by the arrows.



Refitting

Re-attachment is carried out by reversing the order of detachment operations. Also follow the advice below:

- Lay the wiring onto the gearbox by fitting the same with brackets at the specified points, then place it on the engine, taking care that it does not get pinched.
- Check for correct insertion of connectors, which can be felt when the locking bracket has been closed.

NOTE After the re-attachment operation has been completed, verify, by getting connected to the vehicle by means of the diagnosis instrument, that no error is found in the gearbox control unit fault memory.

CALIBRATION

Some modifications or repairs that affect the ESVI system components, automatic transmission, require a calibration procedure.

The repairs that require this operation are detailed as follows:

- Replacing the gearbox kit + control unit
- Replacing the control unit only
- Replacing the clutch actuator
- Replacing the gearbox actuator
- Replacing an electric motor of the gearbox actuator
- Replacing the engaging fork

NOTE Replacing the gearbox wiring requires no calibration procedure.

Calibration in case of replacement of the gearbox kit + control unit

The control unit must be programmed (no error in the memory) by providing the same with the vehicle data, e.g. axle ratio, rolling radius, strength curve, etc.

Get connected to the vehicle by means of the diagnosis instrument, with the vehicle stationary, engine OFF and gearshift lever in neutral.

Carry out the operations indicated by the instrument: key ON (engine ON), then the dedicated calibration procedure will be started → "Adaptation of touch Point".

Message "service" will appear on the display; the system in automatic mode will carry out the following operations:

- opening the clutch;
- engaging the 5th or 6th speed;
- the clutch closes three times searching for the point of initial slip (the vehicle will pick up three times);
- putting the lever in neutral;
- closing the clutch.

The procedure is interrupted when the engine is switched off.

NOTE Wait 10 seconds prior to the next KEY ON.

When the procedure has been completed, check the control unit memory and verify that no error is found.

Calibration in case of replacement of the control unit

The control unit must be programmed by providing the same with the vehicle data, e.g. axle ratio, rolling radius, strength curve, etc.

Get connected to the vehicle by means of the diagnosis instrument, with the vehicle stationary, engine OFF and gearshift lever in neutral.

Carry out the operations indicated by the instrument: key ON (engine OFF), then the dedicated calibration procedures will be started → *Measurement of Maximum Clutch Travel*
Transmission Self Adaptation

Message "service" will appear on the display; the system in automatic mode will carry out the aforesaid procedures. Upon completion of this step, the engine will be started and the → *Adaptation of touch Point* calibration procedure will be started.

Message "service" will appear on the display; the system in automatic mode will carry out the following operations:

- opening the clutch;
- engaging the 5th or 6th speed;
- the clutch closes three times searching for the point of initial slip (the vehicle will pick up three times);
- putting the lever in neutral;
- closing the clutch.

The procedure is interrupted when the engine is switched off.

NOTE Wait 10 seconds prior to the next KEY ON.

When the procedure has been completed, check the control unit memory and verify that no error is found.

Calibration in case of replacement of the clutch actuator

Clear the control unit error memory.

Get connected to the vehicle by means of the diagnosis instrument, with the vehicle stationary, engine OFF and gearshift lever in neutral.

Carry out the operations indicated by the instrument: key ON (engine OFF), then the dedicated calibration procedure will be started → *Measurement of Maximum Clutch Travel*.

Message "service" will appear on the display; the system in automatic mode will carry out the necessary operations. The procedure will be interrupted when the engine is switched off.

NOTE Wait 10 seconds prior to the next KEY ON.

When the procedure has been completed, check the control unit memory and verify that no error is found.

Calibration in case of replacement of the gearbox actuator or an electric motor of the gearbox actuator

Clear the control unit error memory.

Get connected to the vehicle by means of the diagnosis instrument, with the vehicle stationary, engine OFF and gearshift lever in neutral.

Carry out the operations indicated by the instrument: key ON (engine OFF), then the dedicated calibration procedure will be started → *Transmission Self Adaptation*.

Message "service" will appear on the display; the system in automatic mode will carry out the necessary operations. The procedure will be interrupted when the engine is switched off.

NOTE Wait 10 seconds prior to the next KEY ON.

When the procedure has been completed, check the control unit memory and verify that no error is found.

Calibration in case of replacement of the clutch engaging/release fork

Clear the control unit error memory.

Get connected to the vehicle by means of the diagnosis instrument, with the vehicle stationary, engine OFF and gearshift lever in neutral.

Carry out the operations indicated by the instrument: key ON (engine ON), then the dedicated calibration procedure will be started → *Adaptation of Touch Point*.

Message "service" will appear on the display; the system in automatic mode will carry out the following operations:

- opening the clutch;
- engaging the 5th or 6th speed;
- the clutch closes three times searching for the point of initial slip (the vehicle will pick up three times);
- putting the lever in neutral;
- closing the clutch.

The procedure is interrupted when the engine is switched off.

NOTE Wait 10 seconds prior to the next KEY ON.

When the procedure has been completed, check the control unit memory and verify that no error is found.

Power take off

| | Page |
|--|------|
| SPECIFICATIONS AND DATA | 125 |
| TIGHTENING TORQUES | 126 |
| ASSEMBLY STANDARDS | 127 |
| POWER TAKE OFF ELECTRIC ACTUATOR .. | 128 |
| <input type="checkbox"/> Description | 128 |
| <input type="checkbox"/> Operation | 128 |

SPECIFICATIONS AND DATA

| TYPE | Hidrocar 20Z1 | Hidrocar 20 Z2 |
|--|---------------|----------------|
| Application | 5 S 200 | 6 S 300 |
| Gear ratio I, PTO(*) output revs., normal PTO(*) input revs. | 1 | 0.910 |
| PTO(*) output rated torque at 1500 rpm (Nm) | 120 | 180 |
| Expected duration at rated torque and at 1500 rpm hours | 500 | |
| Rotation direction (with respect to engine) | Opposite | |
| Control | Electric | |
| Assembly side (with respect to running direction) | Left side | |
| Torque obtainable from gearbox (Nm) | 175 | 303 |
| Oil capacity (litres) | ~ 0.6 ± 0.4 | |

(*) = Power Take Off





| | | |
|---|---|--------------------------|
|  | Drive gear taper roller bearing axial backlash | 0 ± 0.1 mm |
|  | Drive gear taper roller bearing axial backlash adjustment | by shims |
|  | Drive gear taper roller bearing axial backlash adjusting ring thickness | 0.1 - 0.2 - 0.3 - 0.5 mm |


Figure 1



62092

Power take offs are applied to secondary shaft on gearbox left side instead of cover (1).

NOTE Fill and check gearbox oil level.


TIGHTENING TORQUES**Figure 2**

62181

| | DESCRIPTION | TORQUE | |
|----|------------------------------------|---------|-----------|
| | | Nm | kgm |
| 1 | M16x1.5 actuator fixing tang | 50 | 5 |
| 2 | Switch fixing | 50 | 5 |
| 3* | Flange fixing screw | 25 | 2.5 |
| - | M10 nuts for fixing PTO to gearbox | 35 ÷ 39 | 3.5 ÷ 3.9 |

* Smear screw thread with LOCTITE 242


Figure 3



POWER TAKE OFF COMPONENTS

62093

Figure 4



ASSEMBLY STANDARDS

Parts (*): sealing rings and bearings shall be smeared with grease POLIMER 400.

Adjusting ring (◆) thickness shall guarantee taper roller bearing axial backlash equal to 0 ± 0.1 mm.

Screw thread (•) shall be smeared with Loctite 242.


Sealing ring (1) shall be fitted with 6 mm sinking from power take off housing (2) surface.

62094

POWER TAKE OFF ELECTRIC ACTUATOR

Description

Figure 5



62095

The linear actuator (1) provides motion to control rod (5) controlling power takeoff connection and disconnection.

It is fixed to power takeoff through the bottom side (2), screwing it on the power takeoff box.

Control rod motion is generated by a system composed of electric motor and worm screw (7) which, being blocked in rotation, linearly moves along two directions enabling to connect and disconnect the PTO.

Axial power load is controlled by a spring, set inside actuator (1), providing approx. 350 N force on power takeoff control rod (5).

Operation

POWER TAKEOFF CONNECTION


PTO connection (Figure 5) is divided into two different phases:

The first phase consists in moving forward worm screw (7), rod (5) and sleeve (3), which, coming into contact with shaft tootinging (4), creates axial backstop of the rod and worm screw in an intermediate position as to the whole stroke.

The axial backstop of worm screw (7) preloads the spring inside the actuator and switches the electric motor off; the pretensioned spring exerts energises control rod (5) and keeps the axial load even after electric motor switching off.

The second phase consists in stroke continuation if sleeve (3) tootinging sustains a relative rotation as to the shaft (4) tootinging and therefore stops the axial backstop previously set by the two tootinging contrast.

Figure 6



62096

In this case, the spring inside the actuator, previously preloaded, provides a first motion to the elements (7, 5 and 3) and causes the electric motor, previously stopped, starting.

Subsequently, the stroke starts again until it meets a new obstacle, represented by rod (5) limit stop on the power takeoff box.

At this point, another axial backstop condition is created and the above-mentioned operation is repeated: rod (5) tension and electric motor switching off.

As long as the PTO engagement toothings stay on contact with each other, the electric motor is switched off because the pressure on the toothings (3 and 4) is kept by the spring, inside the actuator.

The axial load on the engagement toothings is calibrated (about 350 N) and gradually applied because the action spring (inside the actuator) carries out a determined stroke before being completely loaded. Toothing mouths (3 and 4) shall therefore be protected against violent impacts assuring, as to traditional mechanical or pneumatic system, less engagement element wear and consequently, an higher number of turns to be implemented before component deterioration.

The functionality is more serviceable since the engagement is softer and more silent as to the traditional systems.

Worm screw (7) limit stop is determined by axial load and distance covered by control rod (5).

It is therefore possible to install on PTO having different stroke values without modifying or adding compensation elements.

POWER TAKEOFF DISCONNECTION

The PTO disconnection phase (Figure 6) is divided into two motions:

The first motion consists in the worm screw return (7) through the reversal carried out on the electric motor.

The second motion consists in the control rod retrocession (5) through spring (6) and consequent shaft (4) sleeve (3) disengagement.

NOTE The retrocession motion of the worm screw (7) do not depend on the movement carried out by the control rod (5); this guarantees, if the sleeve (3) cannot be disengaged, the immediate backing of the worm screw (7) without causing overloads to the electric motor.

The PTO will be disconnected when the backstop condition is over.

This event can occur if during the disengagement request the shaft (4) is still in rotation or pretensioned by a residual torque.

SECTION 5

5056 Propeller shafts


| | Page |
|--|------|
| SPECIFICATIONS AND DATA | 3 |
| DIAGNOSTICS | 9 |
| TIGHTENING TORQUES | 10 |
| TOOLS <input type="checkbox"/> | 10 |
| PROPELLER SHAFT REMOVAL AND REFITTING | 11 |
| <input type="checkbox"/> Removal | 11 |
| <input type="checkbox"/> Refitting | 11 |
| CHECKING PROPELLER SHAFTS ON VEHICLE . | 11 |

SPECIFICATIONS AND DATA

| Name | mm |
|--|------|
| Complete spider assembly (radial) in the fork housings | 0,03 |
| Transmission shaft max. off-centring | |
| <input type="checkbox"/> measured at centre | 0,4 |
| <input type="checkbox"/> measured at extremities | 0,25 |
| <input type="checkbox"/> measured on tang | 0,15 |
| Max. working angle | 20° |

4x2 Vehicles


Figure 1



62123

GKN-TYPE ARTICULATED PROPELLER SHAFT

Figure 2




50826

DANA-TYPE ARTICULATED PROPELLER SHAFT

4x2 Vehicles


Figure 3



GKN-TYPE CONNECTING SHAFT

62122


Figure 4



DANA-TYPE CONNECTING SHAFT

50827

Figure 5



GKN-TYPE CONNECTING SHAFT

75213

| MODEL | VERSION | PITCH (mm) | Propeller shaft length (mm) Figure I-2 | | |
|--|------------|---------------|--|-------------|------------------------------|
| | | | L _I | L | |
| | | | | GKN supply | DANA supply |
| 29L-35S9/11 35S.10/.12(FIA) 29L-35S.14 (FIA VGT) | VAN | 3000 | 813 | 2120 ÷ 2210 | 2120 ÷ 2205 2130 ÷ 2215 * |
| | CHASSI CAB | | | | |
| | CHASSI CAB | 3450 | 1134 | 2565 ÷ 2655 | - |
| | 1135 | | - | 2580 ÷ 2665 | |
| 35S.13/15/17 + .10/.12(FIA) + .14/.17 (FIC) | VAN | 3000 | 763 | 2075 ÷ 2165 | 2075 ÷ 2160 2085 ÷ 2170 * |
| | CHASSI CAB | 3450 | 1085 | 2520 ÷ 2610 | 2520 ÷ 2605 |
| 35C-40C.9/11/15 + .10/.12 (FIA) + 35C.14 (FIA) | VAN | 3000 | 652 | 2080 ÷ 2170 | 2080 ÷ 2165 2090 ÷ 2175 * |
| | CHASSI CAB | | | | |
| 35C.13/15/17 + .10/.12 (FIA) + 40C.13 + 45C - 50 C.11 | VAN | 3000 | 602 | 2035 ÷ 2125 | 2035 ÷ 2120 |
| | CHASSI CAB | | | | |
| 35C - 40C.13/15 + .10/.12 (FIA) + .14/.17 (FIC) | CHASSI CAB | | | | |

(*) Power trains extended by 10 mm.

| MODEL | VERSION | PITCH (mm) | Propeller shaft length (mm) | | | |
|---|------------|---------------|-----------------------------|----------------|-----------------------|-----------------------------|
| | | | Front shaft Figure 3-4 | | Rear shaft Figure 1-2 | |
| | | | L | L ₁ | L | |
| | | | | | GKN supply | DANA supply |
| 29L.9/10/11/12 29L.14 (FIA) 35S.9/10/11/12 35S.14 (FIA) | VAN | 3300 | 891 | 343 | 1540 ÷ 1630 | 1540 ÷ 1625 |
| | CHASSI CAB | 3750 | 891 | 666 | 1980 ÷ 2070 | 1980 ÷ 2065 1990 ÷ 2075* |
| | VAN | 3950 | 891 | 866 | 2180 ÷ 2270 | 2180 ÷ 2265 2190 ÷ 2275* |
| 35S.13/15/17 + .10/12 (FIA) + .14/17 (FIC) | VAN | 3300 | 841 | 343 | 1540 ÷ 1630 | 1540 ÷ 1625 |
| | CHASSI CAB | 3750 | 841 | 666 | 1980 ÷ 2070 | 1980 ÷ 2065 1990 ÷ 2075* |
| | VAN | 3950 | 841 | 866 | 2180 ÷ 2270 | 2180 ÷ 2265 2190 ÷ 2275* |
| 35C-40C.9/11 + .10/12 (FIA) + 35C.14 (FIA) | VAN | 3300 | 730 | 608 | 1650 ÷ 1740 | 1650 ÷ 1735 1660 ÷ 1745* |
| | CHASSI CAB | 3450 | 730 | 607 | 1815 ÷ 1905 | 1815 ÷ 1900 |
| | CHASSI CAB | 3750 | 730 | 652 | 2090 ÷ 2180 | 2090 ÷ 2175 2110 ÷ 2195* |
| | VAN | 3950 | 730 | 986 | 2315 ÷ 2405 | 2315 ÷ 2400 |
| | CHASSI CAB | 4100 | 730 | 1024 | 2450 ÷ 2540 | 2450 ÷ 2530 2460 ÷ 2540* |
| 35C-50C.13/15 + 45C-50C.11 + .10/12 (FIA) + .14/17 (FIC) | CHASSI CAB | 3450 | 680 | 607 | 1800 ÷ 1905 | 1815 ÷ 1900 |
| | CHASSI CAB | 3750 | 680 | 652 | 2090 ÷ 2180 | 2090 ÷ 2175 2110 ÷ 2195* |
| | VAN | 3950 | 680 | 986 | 2295 ÷ 2385 | 2315 ÷ 2400 |

(*) Power trains extended by 10 mm.

| MODEL | VERSION | PITCH (mm) | Propeller shaft length (mm) | | | |
|--|------------|---------------|-------------------------------|----------------|-------------------------------|-----------------------------|
| | | | Front shaft Figure 3-4 (*) | | Rear shaft Figure 1-2 - (*) 5 | |
| | | | L | L _I | L | |
| | | | | GKN supply | DANA supply | |
| 35C-40C.13/15 + .10.12 (FIA) + .14.17 (FIC) | VAN | 4100 | 680 | 1024 | 2450 ÷ 2540 | 2460 ÷ 2545 |
| | CHASSI CAB | 3300 | 680 | 607 | 1650 ÷ 1740 | 1650 ÷ 1735 1660 ÷ 1745* |
| 45C-50C.11/13/15 + .14.17 (FIC) | VAN | 3300 | (*) 680 | | (*) 690 ÷ 790 | |
| 35C-50C.13/15 + 45C-50C.11 + .10.12 (FIA) ESVI + .14.17 (FIC) | VAN | 3950 | 680 | 986 | 2295 ÷ 2405 | 2315 ÷ 2400 |

| MODEL | VERSION | PITCH (mm) | Propeller shaft length (mm) | | | | | |
|-----------------------------------|---------------------|---------------|-----------------------------|-----------------------------------|---------------|----------------|-----------------------------|-----------------|
| | | | Front shaft Figure 3-4 | Central shaft Figure 3-4-(•) 5 | | L _I | Rear shaft Figure 1-2-(•) 5 | |
| | | | | L | | | L | |
| | | | L | GKN supply | DANA supply | GKN supply | DANA supply | |
| 45-50C.11/13/15 + .14.17 (FIC) | CHASSIS COWL | 3750 | (•) 680 | (•) 755 ÷ 855 | (•) 755 ÷ 855 | - | (•) 1080 ÷ 2180 | (•) 1080 ÷ 1190 |
| | CHASSI CAB | 4350 | 680 | 746 | | 722 | 1950 ÷ 2040 | 1965 ÷ 2050 |
| | CHASSIS COWL (•) | | | (•) 755 ÷ 855 | (•) 755 ÷ 865 | (•)440 | (•) 1630 ÷ 1720 | (•) 1630 ÷ 1715 |
| | CHASSI CAB | 4750 | 680 | 730 | | 1056 | 2380 ÷ 2470 | 2380 ÷ 2465 |
| | CHASSIS COWL (•) | | | (•) 755 ÷ 855 | (•) 755 ÷ 865 | (•)781 | (•) 2100 ÷ 2190 | (•) 2100 ÷ 2185 |
| VAN | 3950 | (*) 680 | (•) 1120 ÷ 1220 | | - | (•) 900 ÷ 1000 | - | |

(•) Vehicles with Telma retarder

(*) Power trains extended by 10 mm.

| MODEL | VERSION | PITCH (mm) | Propeller shaft length (mm) | | | | |
|------------------------------|------------|---------------|-----------------------------|--|-----------------------|-------------|-------------|
| | | | Front shaft Figure 3-4 | | Rear shaft Figure 1-2 | | |
| | | | L | | L ₁ | L | |
| | | GKN supply | DANA supply | | | | |
| 60C-65C.15 +.14/.17 (FIC) | VAN | 3300 | 670 | | 614 | 1630 ÷ 1720 | 1630 ÷ 1715 |
| | CHASSI CAB | 3450 | 670 | | 626 | 1780 ÷ 1870 | 1790 ÷ 1875 |
| | CHASSI CAB | 3750 | 670 | | 660 | 2075 ÷ 2165 | 2085 ÷ 2170 |
| | VAN | 3950 | 670 | | 995 | 2280 ÷ 2370 | 2280 ÷ 2365 |

| MODEL | VERSION | PITCH (mm) | Propeller shaft length (mm) | | | | | |
|-------------------------------|------------|---------------|-----------------------------|-----------------------------|--|-----------------------|-------------|-------------|
| | | | Front shaft Figure 3-4 | Central shaft Figure 3-4 | | Rear shaft Figure 1-2 | | |
| | | | L | L | | L ₁ | L | |
| | | GKN supply | DANA supply | | | | | |
| 60C-65C.15 + .14/.17 (FIC) | CHASSI CAB | 4350 | 670 | 801 | | 724 | 1885 ÷ 1975 | 1885 ÷ 1970 |
| | CHASSI CAB | 4750 | 670 | 730 | | 1065 | 2350 ÷ 2440 | 2350 ÷ 2435 |


| MODEL | VERSION | PITCH (mm) | Propeller shaft length (mm) | | | | | |
|-------------------------------|-----------------|---------------|-----------------------------|------------------------|-------------|----------------|-------------------------|-----------------|
| | | | Front shaft Figure 3-4 | Central shaft Figure 5 | | L ₁ | Rear shaft Figure 5.1.2 | |
| | | | | L | | | L | |
| | | GKN supply | DANA supply | GKN supply | DANA supply | | | |
| 60C-65C.15 + .14/.17 (FIC) | CHASSIS COWL | 3750 | 670 | (•) 970 ÷ 1070 | - | - | (•) 825 ÷ 925 | - |
| | CHASSIS COWL | 4350 | 670 | (•) 970 ÷ 1070 | - | - | (•) 1395 ÷ 1495 | - |
| | CHASSIS COWL | 4750 | 670 | (•) 1080 ÷ 1180 | - | 408 | - | (•) 1705 ÷ 1790 |

(•) Vehicles with Telma retarder


DIAGNOSTICS

The main operating faults of the propeller shaft are as follows:

- I - noise and vibrations




(Continues)



TIGHTENING TORQUES



| PART | TORQUE | |
|--|--|---|
| | Nm | kgm |
| Ring nut for fixing to connecting shaft | 250 ± 25 | 25.4 ± 2.5 |
| Nut for screw for fixing flanges to propeller shaft | $\left\{ \begin{array}{l} M10 \times 1,5 \\ M12 \times 1.25 \end{array} \right.$ | $\left\{ \begin{array}{l} 63.5 \pm 6.5 \\ 116.5 \pm 11.5 \end{array} \right.$ |
| Nut, linkage shaft to chassis side member fixing screw | 62.5 ± 6.5 | 6.3 ± 0.6 |

TOOLS

| TOOL NO. | DESCRIPTION |
|----------|---|
| 99370618 |  Support for removal-refitting propeller shaft |

505620 PROPELLER SHAFT REMOVAL AND REFITTING

Figure 6



Removal

NOTE When overhauling the propeller shaft, always begin by removing the rear shaft.

Arrange the support 99370618 on the hydraulic jack and apply the support to the propeller shaft. Remove the fixing bolts from the flange and remove the shaft; for the intermediate and front axles, also remove the chassis shaft support.


Refitting

Repeat the same operations for removal in the opposite order and observe the following:

- make sure that the arrows shown on the moving part and on the shaft are aligned;
- make sure that the holes of the front flange are aligned with those of the rear flange;
- the nuts for the flange coupling screws must be replaced and never reused;
- the flange coupling screws must be inserted into the holes of the flange from the side of the universal joint;
- the nuts and screws must be tightened to the required driving torque;
- the flange of the moving part of the propeller shaft must be connected to the output shaft flange.

CHECKING PROPELLER SHAFTS ON VEHICLE

Figure 7



The plates welded to the propeller shafts are counterweights. If the plates are missing the shaft must be re-balanced. By operating on the propeller shaft and at the same time, in the opposite direction, on the sliding sleeve, check that there is not too much slack between the splines. By operating on the sleeve forks, check that the spiders are not worn; if they are, replace them.

SECTION 6


5250 Rear axles

| | Page |
|------------------------------------|------|
| DIAGNOSTICS | 3 |
| REAR AXLE 450210 | 5 |
| REAR AXLES 450311/1 - 450511 | 35 |
| REAR AXLE 450517/2 | 61 |
| REAR AXLE 450310 | 91 |

DIAGNOSTICS

The main rear axle operating faults are as follows:

- 1 - Wheel hubs noise;
- 2 - Rear axle noise;
- 3 - Noise at release;
- 4 - Noise during acceleration;
- 5 - Cornering noise.



(Continues)

Bad adjustment or wear on differential gears or bearings. - YES → Locate the trouble and overhaul the unit.

3 NOISE AT RELEASE



Improper fitting clearance between pinion and ring bevel gear. - YES → Remove the gear housing inspection cover and adjust clearance between pinion and ring bevel gear.

4 NOISE DURING ACCELERATION



Insufficient lubrication. - YES → Check that there are no leaks from gaskets or the rear axle casing and top up oil to correct level.

NO



Gear housing bearings badly set or deteriorated. - YES → Overhaul the unit.

NO



Bad tooth contact between pinion and ring bevel gear. - YES → Adjust the contact.

5 CORNERING NOISE



Improper clearance between planetary gears and crown wheels. - YES → Overhaul or replace the unit.

Rear axle 450210

| | Page |
|---|------|
| REAR AXLE REMOVAL - REFITTING | 7 |
| <input type="checkbox"/> Removal | 7 |
| <input type="checkbox"/> Refitting | 7 |
| DESCRIPTION | 9 |
| SPECIFICATIONS AND DATA | 10 |
| TIGHTENING TORQUES | 12 |
| TOOLS | 15 |
| OVERHAULING THE REAR AXLE ASSEMBLY . | 19 |
| <input type="checkbox"/> Air breather disassembly - assembly | 19 |
| <input type="checkbox"/> Wheel hub overhaul | 19 |
| <input type="checkbox"/> Assembly | 20 |
| REPAIRING THE DIFFERENTIAL | 22 |
| <input type="checkbox"/> Disassembling the differential unit | 22 |
| <input type="checkbox"/> Gear housing removal | 23 |
| <input type="checkbox"/> Checking the parts comprising the differential | 25 |
| <input type="checkbox"/> Assembly | 25 |
| <input type="checkbox"/> Assembly of gear housing | 26 |
| <input type="checkbox"/> Assembling the bevel pinion assembly | 27 |
| <input type="checkbox"/> Assembly of differential unit | 30 |

525010 REAR AXLE REMOVAL - REFITTING

Removal

Position the vehicle on level ground and lock the front wheels.

Loosen rear wheel fixing screws.

Lift the vehicle at the back and set it on stands.

Put the hydraulic trolley 99321024 under the rear wheels. Take out the screws securing the wheels and remove the guard.

Unscrew the handbrake adjustment nut (2). Free the cables from the chassis frame, unhooking the retaining clamps (1).

Unscrew the screws (3) for the nuts securing the propeller shaft (4).

Disconnect the electric cables for indicating brake lining wear (11) and for the speed sensors, if present.

Disconnect the braking corrector adjustment tie (16) from the axle housing.

Unscrew the nuts (10) securing the shock absorbers (12).

Disconnect the brake hydraulic system pipes (13) from the axle housing.

Unscrew the screws (7) securing the connecting rods fastening the stabilizer bar (6) to the axle.

Disconnect the pipe (17) from the axle housing oil vapour vent.

Position a hydraulic jack equipped with the mounting 99370617 under the axle.

Remove the screw (14) and the nut securing the leaf springs (5) to the shackles (15) and put them on the ground.

Unscrew the nuts (8) of the brackets (9) securing the axle to the leaf spring (5).


Lower the hydraulic jack and extract the axle.

Refitting

For refitting, carry out the operations described for removal in reverse order, taking the following precautions:

- Check the thread of the brackets joining the leaf springs to the axle. If there are any irregularities, rectify the thread (operation 500412) or replace the brackets.
- Bleed the air from the brake hydraulic system as described under the relevant heading (operation 784010).
- Adjust the handbrake control ties as described under the relevant heading (operation 502710).
- Lock the nuts or screws to the required tightening torque.
- The self-locking nuts must not be reused.
- The lubricating oil in the axle housing should be at the right level.
- Check the state of the flexible pads (18) and replace them if they have deteriorated (operation 500417).

Figure 1



50970

DESCRIPTION

The rear axle is the load-bearing type with a single reduction using a hypoid crown wheel and pinion.

The axle housing is made of pressed sheet steel with hot pressed arms.

The central portion, seat of the differential unit, is equipped with cooling fins.

The bevel pinion is supported by two pre-lapped tapered roller bearings to hold the bearing pre-load better.

The bearings are factory lubricated by the manufacturer with rustproof protective oil.

The rolling torque of the bearings of the bevel pinion is adjusted by changing the thickness of the adjustment ring between the two tapered roller bearings.

In addition, it is possible to adjust the position of the bevel pinion with respect to the ring bevel gear by changing the thickness of the ring between the axle housing and the bevel pinion rear bearing external ring.

The gear housing is supported by two tapered roller bearings, also pre-lapped and lubricated with rustproof protective oil.

The rolling torque of the bearings is adjusted with adjustment rings between the housing and the spacer rings.

The clearance between pinion and crown wheel is adjusted by changing the thickness and/or position of the adjustment rings, though the total thickness must be the same as that of the adjustment rings removed.

The gear housing may be of two different sizes depending on the ratio of the crown wheel and pinion.

The differential gearing unit is made up of four planetary gears or, in newer versions, two planetary gears and two crown wheels.

The drive shafts are supported inside the arms of the axle housing by UNIT BEARINGS lubricated for life, which require no adjustment.


The brakes are disc brakes with floating brake calipers.

The disc brakes are splined onto the end of the drive shafts and secured with pins that also serve as centring for the wheel rims.

The brake calipers are secured with flanges welded onto the end of the arms of the axle housing.















The brake calipers are equipped with the parking brake device.










Figure 2




51857

SPECIFICATIONS AND DATA

| | | |
|---|--|--|
|  | Type of rear axle: Simple reduction type | 450210 |
|  | DIFFERENTIAL UNIT Reduction bevel gear pair ratio (No. of teeth: pinion/crown) | 15/44 (1/2.93) - 13/41 (1/3.15) - 12/41 (1/3.41) - 12/43 (1/3.58) - 12/47 (3.91) - 10/41 (1/4.10) - 9/40 (1/4.44) - 11/49 (1/4.45) - 9/44 (1/4.88) - 8/41 (1/5.12) - 8/45 (1/5.63) |
|  | Bevel pinion bearings | 2 with taper rollers |
|  | Bevel pinion bearings rolling torque (bearings lubricated and without gasket) Nm New bearings kgm | 2.3 ÷ 3.3 0.23 ÷ 0.33 |
|  | Adjustment of pre-load of bevel pinion bearings | By means of adjustment ring |
|  | Bevel pinion bearings pre-load adjustment ring thicknesses | 5.125 ÷ 6.150 mm with progression of 0.025 mm. |
|  | Temperature of assembly of inner bearing ring on bevel pinion | - |
|  | Position of bevel pinion with respect to differential casing | By means of adjustment ring |
|  | Thickness of adjustment rings placed between bevel pinion and differential casing | 3.2 ÷ 4.1 mm with progression of 0.05 mm. |
|  | Bearings for gear housing | 2 with taper rollers |
|  | Differential casing bearings rolling torque (bearings lubricated and without gasket) <input type="checkbox"/> 15/44 - 13/41 - 12/41 - 12/43 - 12/47 - 10/41: DaNm kgm <input type="checkbox"/> 11/49 - 9/40 - 9/44 - 8/41 - 8/45: DaNm kgm | 0.27 ÷ 0.39 0.27 ÷ 0.39 0.26 ÷ 0.37 0.26 ÷ 0.37 |
|  | Adjustment of differential casing bearings rolling torque | By means of adjustment rings |
|  | Thickness of adjustment rings of differential casing bearings rolling torque | 2.550 ÷ 3.350 mm with progression of 0.025 mm. |
|  | Clearance between pinion and ring bevel gear with reduction ratios <input type="checkbox"/> 13/41 - 12/43 - 9/43 - 8/45: <input type="checkbox"/> 10/41 - 9/40: | 0.13 ÷ 0.18 mm 0.15 ÷ 0.20 mm |

| | | |
|---|--|---|
|  | Type of rear axle: Simple reduction type | 450210 |
|  | Adjustment of clearance between pinion and ring bevel gear | By means of adjustment rings |
|  | Clearance between planetary and crown wheels | 0.05 ÷ 0.15 mm |
|  | WHEEL HUBS | |
|  | Wheel hub bearings | UNIT-BEARING |
|  | Wheel hub bearings end play | - |
|  | Wheel hub bearings rolling torque Nm kgm | - - |
|  | Adjustment of wheel hub bearings end play | Not adjustable Tighten fixing ring nut to torque |
|  | Rear axle oil Quantity Litres | TUTELA W140/M-DA (SAE 85 W 140) 1.85 |
| | Dry rear axle weight : <input type="checkbox"/> With ABS kg <input type="checkbox"/> Without ABS kg <input type="checkbox"/> Max capacity (GRW) kg | 112.1 110.6 2240 |

TIGHTENING TORQUES**Figure 3**

SECTIONAL VIEW OF 450210 REAR AXLE DIFFERENTIAL


| PART | TORQUE | |
|------|-------------|-------------|
| | Nm | kgm |
| 1 | 400 ÷ 500 | 40 ÷ 50 |
| 2 | 89 ÷ 108 | 8,9 ÷ 10,8 |
| 3** | 49 ÷ 62 | 4,9 ÷ 6,2 |
| 4 | 100 ÷ 120 | 10 ÷ 12 |
| 5 | 80 ÷ 95 | 8 ÷ 9,5 |
| 6 | 31,5 ÷ 38,5 | 3,15 ÷ 3,85 |
| *** | 49 ÷ 62 | 4,9 ÷ 6,2 |

* = Apply LOCTITE 5910 on the housing

** = Apply LOCTITE 577 on the plug thread

*** = Apply LOCTITE 573 on both sides of the gasket


Figure 4



51813

SECTION ON DIFFERENTIAL OF REAR AXLE 450210 WITH FOUR CROWN WHEELS


Figure 4/1



49359

SECTION ON DIFFERENTIAL OF REAR AXLE 450210 WITH TWO CROWN WHEELS

Figure 5



87906

SECTIONAL VIEW OF 450210 REAR AXLE HUB


| PART | TORQUE | | |
|------|---|-----------|-------------|
| | Nm | kgm | |
| 1 | Wheel fixing screw | 160 | 16 |
| 2 | Screw securing cover and guard in sheet metal to the axle housing | 64 ÷ 79 | 6.4 ÷ 7.9 |
| 3 | Screw securing disc and drive shaft | 13 ÷ 21 | 1.3 ÷ 2.1 |
| 4 | Screw securing cover and guard in sheet metal | 10 ÷ 16 | 1 ÷ 1.6 |
| 5 | Screw securing brake caliper | 176 ÷ 217 | 17.6 ÷ 21.7 |
| 6 | Ring nut securing drive shaft | 300 ÷ 350 | 30 ÷ 35 |

TOOLS

TOOL NO.


DESCRIPTION

99305121




Hot air drier

99322215




Front and rear axle overhaul stand

99340204




Tool to extract bearing and drive shaft from rear axle housing

99341003




Single-acting rear axle

99341009



Pair of brackets

99341011




Pair of brackets


TOOLS

TOOL NO.


DESCRIPTION

99341015


Clamp

99345057


Extractor reaction block

99348001


Extractor with locking device

99355176

Shaft bearing ring nut wrench

99370006

Handle, interchangeable drift

99370007

Grip for interchangeable punches


TOOLS

| TOOL NO. | DESCRIPTION |
|----------|---|
| 99370241 | Tool for fitting drive shaft bearing |
| 99370286 | Tool to determine thickness of adjustment of bevel pinion (use with 99395728) |
| 99370317 | Reaction lever with extension for flange retaining |
| 99370617 | Universal mounting to support axles during removal and refitting |
| 99372236 | Tool to move brake caliper piston back |
| 99374091 | Punch to fit external races of bearings (diameter 55 ÷ 69 mm use with 99370007) |


TOOLS

TOOL NO.


DESCRIPTION

99374092


Punch to fit external races of bearings (diameter 69 ± 91 mm use with 99370007)

99374456

Key to fit differential bevel pinion gasket (use with 99370006)

99389819

Dynamometric wrench (0 ± 10 Nm) with 1/4" square connection

99395728

Dial gauge with mounting to be used with the tools to determine the thickness of adjustment of the bevel pinion


525010 OVERHAULING THE REAR AXLE ASSEMBLY



The drive shafts, brake disc and calipers, air breather and differential can all be removed and refitted even with the unit mounted on the vehicle.

Before positioning the rear axle assembly on the stand for overhauling, drain off the oil by unscrewing the side plug of the axle housing.

Figure 6



51800


Set the entire rear axle assembly on stand 99322215.



The identification data of the rear axle unit are given on the plate (1) fixed near to the leaf spring attachment support.

525013 Air breather disassembly - assembly

Figure 7




75002

Check that the air breather (1) is not clogged; otherwise, disassemble and clean it thoroughly before refitting.

525030 Wheel hub overhaul

Figure 8



51802

Take out the screws (1) and remove the brake caliper (2) with its brake linings from the mounting.



The caliper must not be violently knocked or dropped.

Prevent the rubber caps coming into contact with sharp metal tools.

Do not dirty or wet the rubber caps with mineral grease or oil.


Do not dirty the pads with liquids or grease.

Do not operate the parking brake lever before mounting on the disc.

This makes the piston come out, decreasing the gap between the two brake linings and jeopardizing wearability on the disc.

Should this be done unexpectedly, it is necessary to take down the brake linings and move the piston back with tool 99372236, taking the precautions given in the BRAKES section.

Figure 9




51803

Take out the pins (1 - 2) centring/fixing the brake disc (3) to the drive shaft (4) and remove the brake disc (3).

NOTE Check brake disk as described in Brakes section. On putting away the brake disk, do not damage phonic wheel toothing (if phonic wheel is present).


Figure 10



51804

Remove the screws (2) securing the guard (1) and cover (3) to the axle housing (4).


Figure 11



51805

Extract the drive shaft (2) from the axle housing (1).
If this proves difficult, use tool 99340204 (3) applied as shown in the figure to extract the drive shaft (2).


Figure 12



51806

Clamp the drive shaft (1) in a vice.
Lift the deformation (⇒) of the washer on the ring nut (2).


Figure 13



51807

Using the wrench 99355176 (1), remove the ring nut (2) securing the bearing (4) to the drive shaft (3).


Figure 14



51808

Set the drive shaft (1) suitably on the hydraulic press and, with the extractor 99348001 (3), extract the bearing (2).

Figure 15




51809

Take out the screw (1) and remove the cover (3) from the guard (2).

Assembly

Position the guard (2) on the cover (3) and tighten the fixing screws (1) to the required torque.

Figure 16




51810

Set the tool 99370241 (4) on the press and position the bearing (3) and guard (2) with the cover on it.

Put the drive shaft (1) into the bearing (3) and with the action of the press (driving load $3300 \div 18000$ N) insert it to the limit.

NOTE The bearing (3) must not be heated.

Figure 17




51811

Fit the washer (2) and ring nut (1).

Using the wrench 99355176 (3) tighten the ring nut (1) to the required torque.

Notch the washer (2) (\Rightarrow) on the milling of the ring nut (1) as shown in the figure.

Figure 18



51812


Mount a new seal (3) onto the annular groove of the bearing (4).

Lubricate the seal (3) and the external surface of the bearing (4) with TUTELA MR3 grease.

Fit the drive shaft (2) assembled in this way into the axle housing.

Tighten fixing screws (1) to the prescribed torque.


Figure 19



51803

Mount the brake disc (3) onto the drive shaft (4) and tighten the fixing pins (1 - 2) to the required torque.

Figure 20



NOTE The brake lining with the wear indicator must be mounted on the piston side of the brake caliper.

Rest the brake caliper (2) with the brake linings on the mounting.

NOTE Should brake calliper piston be moved backward, use tool 99372236 and follow the recommendations set out in the BRAKES section.


Tighten the screws (1) securing the caliper (2) to the required torque.

After assembly, fill the axle housing with TUTELA W140/M - DA oil in the required quantity and grade.

526210 REPAIRING THE DIFFERENTIAL
Disassembling the differential unit


NOTE Before repairing the differential it is necessary to drain off the oil and dismantle the drive shafts, as described under the heading of overhauling the wheel hub (operation 525030).

Figure 21




Unscrew the screws (1) with their lock washers and spring washers (if any) and take off the gearing inspection cover (2) with its gasket (if present).

Figure 22



Mark the position of the caps (1 and 2), take out the screws (3) and remove them.

Figure 23




Extract the differential unit (1) from the axle housing.

NOTE Note the assembly position of the adjustment rings (2-4) of the spacers (3-5) and of the external rings (6) of the tapered roller bearings to position them for assembly in the same position.

Gear housing removal


Figure 24



51818

Use tool 99341003 (1), brackets 99341009 (2), clamp 99341015 (3) and reaction block 99345057 (4) to remove taper roller bearing inner rings (5 - 7) from gear housing (6).

Figure 25




18222

NOTE Mark cover (1) and gear housing (4).

Loosen screws (2), remove ring bevel gear (3) and gear housing (4) cover (1).


Figure 26



62099

Remove from gear housing (1) the sun gear (2) on cover side including shoulder washer (3). Use a universal beater to remove the long pin (4) and the two short pins (5) from gear housing (1).


Figure 27



18224

Use a standard beater to eject the long pin (2) and, as regards the differential with four planet gears, the two short pins (3) out of the wheelcase (1)


Figure 28



20378

As regards the differential with four planetary gears, remove spider (1) and the four planetary gears (2), or the two planetary gears with their respective shoulder washers (3), from the wheelcase.


Figure 29



18226


Remove the sun gear (1) on gear housing side and the shoulder washer.

Figure 30




Raise the securing ring (⇒) on the flange (1) nut (3).
Using tool 99370317 (2), block rotation of the coupling (1).
Remove the nut (3).

Figure 31




Take flange (1) out of bevel pinion (2).

Figure 32




Using a bronze punch, strike in the direction shown by the arrow to eject the bevel pinion (1), with the rear bearing, the fixed spacer and adjustment ring from the axle housing (2).

Figure 33




Remove the seal (1) and the internal ring (2) of the front bearing.

Figure 34




Use a punch to remove the external rings (3 - 4) of the tapered roller bearings from the axle housing (1) and take out the adjustment shim (2).

Figure 35



With axle 99341003 (2), brackets 99341011 (1), press 99341015 (5) extract the internal ring (3) on the bevel pinion (4).

Figure 36



61868

DIFFERENTIAL UNIT COMPONENTS

1. Nut - 2. Transmission coupling sleeve - 3. Seal ring - 4. Front bearing - 5. Pinion shim ring - 6. Fixed spacer - 7. Fixed ring - 8. Adjuster ring - 9. Rear bearing - 10. Bevel pinion - 11. Bevel ring - 12. Fixed ring - 13. Adjuster ring - 14. Bearing - 15. Gear casing - 16. Crown wheel thrust washer - 17*. Cross - 18. Crown wheel - 19. Gear casing - 20. Screw - 21. Fixed ring - 22. Adjuster ring - 23. Bearing - 24. Planetary gear thrust washer - 25. Planetary gear - 26*. Short pin - 27. Long pin.

* only for differential with four planetary gears.

Checking the parts comprising the differential

Carefully clean the single components of the differential locking.

Lubricate the bearings and rotate the roller cage freely; rotation must be even and without signs of stiffness. Check the support surfaces of the ring bevel gear and the striking surface of the half-casing so that the ring bevel gear fits perfectly. Deformations of such parts, could determine vibration of the ring bevel gear fastening screws, thus compromising the perfect operation of the unit.

NOTE Carefully clean all the threads in order to obtain exact adjustments and accurate tightening torque.

Check that the splined section for the flange-pinion connection is not badly worn, if it is, replace the pinion.

NOTE If it is necessary to replace the ring bevel gear or pinion, replace both parts since they are supplied in pairs.

Check the planetary gears with their shoulder washers, the pin and the crown wheels with their shoulder washers.

Replace all the sealing elements, the bevel pinion retaining nut and the gear housing bearing adjustment ring nut with new parts.

Assembly


NOTE The tapered roller bearings are supplied as spare parts, lubricated with rustproof oil.

They must not be washed or heated for assembly.

The differential housing support bearings must both be from the same supplier.


Assembly of gear housing

Figure 37




Position the crown wheel (1), gear housing side, complete with shoulder washer, into its own housing.

Figure 38




Position the two planetary gears (1) complete with shoulder washers, spider (2) only for differential with four planetary gears and then insert the long pin (3).

Figure 39




Only for differential with four planetary gears: position the other two planetary gears (1) complete with shoulder washers and then insert the two short pins (2). Rotate the planetary gears-crown wheel unit and check that it is free without stiffness. Assemble the other crown wheel complete with shoulder washer.

Figure 40




Assemble the cover and make the marks made during disassembly coincide. Assemble the ring bevel gear and fasten this to the half-casing by means of the fixing screws. By means of a dynamometric wrench (1) tighten the fixing screws (2) to the required tightening torque.

Figure 41



Only for axles with differential lock. Using tool 99305121, heat thrust ring (1) to a temperature of $120^{\circ}\text{C} \pm 150^{\circ}\text{C}$ for 15' and fit on the gear casing (2) from the side with the differential lock.

Figure 42




51837

Using the punch 99374091 (3) and grip 99370006 (4), mount the external ring (2) of the tapered roller bearing in the axle housing (1).

NOTE New bearings are lubricated with rustproof oil and must therefore not be washed or heated for assembly.

Figure 43




51838

Set adjusting ring (4), removed at disassembling, into rear axle casing (5).

Using the punch 99374092 (2) and grip 99370007 (1), mount the external ring (3) of the tapered roller bearing.

Assembling the bevel pinion assembly


Figure 44



18241

On a surface plate (2), zero a dial gauge (1) set on the mounting 99395728 (3) and pre-load it slightly.


Figure 45



101977

Fit tapered-roller bearing internal ring (2) onto false pinion 99370286 (1) with the washer supplied (3).

Figure 46




51839

Position the dummy pinion 99370286 (1), assembled as shown in Figure 45, on the external ring (2) of the tapered roller bearing.

On the opposite side, fit the taper bearing internal ring (3) on the dummy pinion (1) and the transmission shaft flange (4).

Screw on the nut (5) so that the dummy pinion turns freely with no end float.

Figure 47



51840

Fit the mounting 99395728 (2) with the dial gauge (1) on the dummy pinion 99370286 (3).

Orientate the, previously zeroed, dial gauge so as to position the rod on the lowest portion of the seat of the bearing supporting the gear housing and note the difference **A1**.

Repeat the same operation on the seat of the other bearing and note the difference **A2**.

Thickness **S** to be added to adjusting ring thickness (4, Figure 49) used for measuring, for pinion positioning is obtained by the following formula:

$$S = \frac{A1 + A2}{2} - (\pm B)$$

A1 indicates the value measured on the right-hand seat.

A2 indicates the value measured on the left-hand seat.

B indicates the value marked on the bevel pinion (see Figure 48).


For example:

$$S = \frac{1.05 + 1.10}{2} - (-0.05) = \frac{2.15}{2} + 0.05 = 1,125$$

The result of the formula must be added algebraically to the value of the adjusting ring used to make the measurements. Example:

if the value of the adjusting ring used is 3.00 mm, replace with one measuring 4.125 mm (3.00 + 1.125).

Figure 48




18246

NOTE If the value marked on the pinion is preceded by a positive sign (+), it must be subtracted from the value of the sum divided by two for both seats, whereas it has to be added if it is preceded by a negative sign (-).

Unscrew the retaining nut, the transmission connection flange and remove it and the bearing from the dummy pinion.

Remove the dummy pinion with the mounting 99395728, dial gauge and rear bearing from the axle housing.

Figure 49




51838

If required, replace adjusting ring (4) with a new one having the calculated thickness, after removing bearing outer ring (3) from rear axle casing (5) by beater.

Then fit the new adjusting ring (4) into rear axle casing (5).

Using the punch 99374092 (2) and grip 99370007 (1), mount the external ring (3) of the tapered roller bearing.


Figure 50



18251

Using a suitable punch (1) and a hydraulic press, mount the internal ring (2) of the tapered roller bearing on the bevel pinion (3).


Figure 51



18252

Position the fixed spacer (3) and the adjustment ring (2), used previously to obtain the required rolling torque, on the bevel pinion (1).


Figure 52



62097

Position the axle casing as indicated in the figure. Fit the taper bearing internal ring (1) and the transmission shaft flange (2). Position a suitable pipe (3) on the stand so that the flange (2) and the taper bearing internal ring (1) are correctly supported.

Figure 53




51845

Mount the bevel pinion (1) in the axle housing so as to enter the internal ring (2) of the tapered roller bearing.

Tap on the end of the pinion (1) so that the transmission shaft flange retaining nut (3) can be fitted.

Figure 54




51846

Use tool 99370317 (2) to prevent the flange (1) from rotating.

Tighten the bevel pinion retainer nut to the required torque with a torque wrench (3).

Figure 55



Using the torque wrench 99389819 (1), measure the rolling torque of the bevel pinion.

NOTE The rolling torque must be measured at an ambient temperature of 25°C, making the pinion turn at a speed of 50 rpm after it has made 10 turns.


If the reading differs from the prescribed value, disassemble the pinion (1, Figure 53), replace the adjuster ring (2, Figure 51) with a ring of the correct thickness.

Refit the pinion and repeat the rolling torque check.

Assembly of differential unit

NOTE When fitting the differential unit, carefully comply with the tightening torque values specified, and make use of a torque wrench.


Figure 56



Fit the differential (1) unit and support (4) bearings in the axle casing.

Refit the spacers and adjuster rings in exactly the original positions and in the following order: adjuster ring (2), spacer (3 and 5) and adjuster ring (4).


Figure 57



NOTE Position the caps (2) making the marks made during disassembly coincide.

Screw on the screws (1) and tighten them to the required torque with the dynamometric wrench (3).

Figure 58




Check the total rolling torque with the torque wrench 99389819 (1).

NOTE The rolling torque must be measured at an ambient temperature of 25°C, making the pinion turn at a speed of 50 rpm after it has made 10 turns.

If the value of the measurement is not as required, replace the adjustment rings (2 and 4, Figure 56) with another one of a suitable thickness.

Figure 59



51850

Position the dial gauge 99395684 (1) with a magnetic base and measure the clearance between the pinion and crown wheel on four opposite teeth of the crown wheel (2).

The average of the measurements must equal the required value.

If a different clearance is found, remove the caps (3) again and swap over the assembly position of the adjustment rings (1 and 3, Figure 56).

If this is not sufficient, replace the adjustment rings with ones of a different thickness, but the total thickness must still be the same as that of the adjustment rings removed.


This is so as not to change the total rolling torque.

Apply a thin layer of Prussian blue on ring gear teeth by brush.

Turn the pinion and measure the impression of the contact of the pinion tooting on the crown wheel tooting.

Here we illustrate the possible contacts with the corrections to obtain precise coupling of the crown wheel and pinion.

Figure 60



44603


A = Coupling depth
B = Crest
C = Side
D = Play

E = Greater base
F = Heel
G = Top land
H = Contact surface
I = Lateral surface

Figure 61



Correct contact





44604

Figure 62



Excessive contact on tooth bottom or flank.

Move away pinion and put ring gear to pinion to adjust clearance.





44605

Figure 63




Excessive contact on heel of tooth.

Move the ring bevel gear towards the pinion and then move the pinion away from the ring bevel gear to adjust clearance.



44606

Figure 64




Excessive contact in the upper part or crest of the tooth.

Move the pinion towards the ring bevel gear and then move the ring bevel gear away from the pinion to adjust clearance.

44607

Figure 65




Excessive contact on the top land of the tooth.

Move the ring bevel gear away from the pinion then move the pinion towards the ring bevel gear to adjust clearance.

44608

Figure 66




51851

After having determined the prescribed coupling clearance, tool 99370317 (2) prevents the flange (1) from rotating.

Unscrew the retaining nut and extract the flange (1) from the bevel pinion.

Figure 67




51852

Lubricate the internal lip of the seal (1).

With the key 99374456 (2) and grip 99370006 (3), mount the seal in the axle housing.

Figure 68




51846

Mount the coupling (1) and with the tool 99370317 (2) block its rotation with the torque wrench (3).

Tighten the bevel pinion retaining nut to the required torque.

Figure 69




* DIRECTION OF ROTATION OF THE NUT

51853

Deform the collar of the nut (1) as shown in the figure at the milling of the bevel pinion (2).

Figure 70



51854

Thoroughly clean the flange of the axle housing.

Apply LOCTITE 5910 sealant on the flange of the axle housing to form a bead of approx. 5 mm diameter.

It must be uniform (no lumps), without any air bubbles, thin areas or gaps.

Any flaws must be corrected in as short a time as possible.

Avoid using too much material to seal the joint.


Too much sealant would tend to come out on both sides of the joint.

After applying the sealant, the joints need to be assembled immediately (10 - 20 minutes).

To seal at a later date, there is product 21623 capable of softening or liquefying the above-mentioned sealant.

It is essential to clean the surface to be sealed in order to achieve good future sealing.

Figure 71




51855

Mount the cover (1) and screw on the screws (2).

- Flanged screws (for solution without gasket).
- Screws with washer (for solution with gasket).

Figure 72



62098

Following the order shown in the figure, tighten the screws to the torque of:

- flanged screws (for solution without gasket) $80 \div 95$ Nm;
- screws with washer (for solution with gasket) $31.5 \div 38.5$ Nm.

Complete assembly taking the following precautions:

Mount the drive shafts as described under the heading: "525030 overhauling hubs".

Apply LOCTITE 577 thread-locking oil on the oil drain plug thread, screw it into the axle housing, tightening it to the required torque.

Add lubricating oil in the required quantity and grade through the hole.

Apply LOCTITE 577 thread-locking oil on the inspection plug thread, screw it into the axle housing, tightening it to the required torque.

Take the assembly off the stand.

NOTE The assembly should be put back on its mounting to prevent the dust guards and/or brake discs from getting damaged.

Rear axles **450311/1** **450511**

| | Page |
|---|------|
| REAR AXLE REMOVAL - REFITTING | 37 |
| <input type="checkbox"/> Removal | 37 |
| <input type="checkbox"/> Refitting | 37 |
| DESCRIPTION | 39 |
| SPECIFICATIONS AND DATA | 40 |
| TIGHTENING TORQUES | 43 |
| TOOLS | 45 |
| OVERHAULING THE REAR AXLE ASSEMBLY . | 48 |
| <input type="checkbox"/> Wheel hub overhaul | 48 |
| <input type="checkbox"/> Replacing the wheel hub bearing | 49 |
| DIFFERENTIAL REPAIR OPERATIONS | 52 |
| <input type="checkbox"/> Disassembly of differential locking | 52 |
| <input type="checkbox"/> Differential locking removal | 52 |
| <input type="checkbox"/> Assembling the differential locking device | 52 |
| <input type="checkbox"/> Differential locking refitting | 52 |
| <input type="checkbox"/> Adjusting the differential locking device | 53 |
| <input type="checkbox"/> Disassembling the differential unit | 53 |
| <input type="checkbox"/> Disassembly of gear housing | 54 |
| <input type="checkbox"/> Assembly of gear housing | 56 |
| <input type="checkbox"/> Assembling bevel pinion unit | 56 |
| <input type="checkbox"/> Differential unit refitting | 57 |

REAR AXLE REMOVAL - REFITTING**Removal**

Position the vehicle on level ground and lock the front wheels.

Loosen the nuts securing the rear wheels.

Lift the vehicle at the back and set it on stands.

Put the hydraulic trolley 99321024 under the rear wheels. Take out the nuts securing the wheels.

Unscrew the handbrake adjustment nut (4). Free the cables from the vehicle crosspiece, unhooking the retaining clamps (3).

Unscrew the screws (6) securing the propeller shaft.

Disconnect the electric cables for indicating brake lining wear (2) and (13), for the ABS speed sensors, if present.

Disconnect the braking corrector adjustment tie (14) from the axle housing.

Unscrew the nuts (5) securing the shock absorbers.

Disconnect the oil pipe (1) from the fitting secured to the axle housing.

Unscrew the screws (9) securing the stabilizer bar (10) to the axle.

Disconnect the pipe (16) from the axle housing oil vapour vent.

For axles with differential locking only

Release the spring (17) and remove the differential locking flexible tie (18) support bracket (19) from the axle housing.

Disconnect the electric cable of the differential locking indicator transmitter (15).

For all vehicles

Position a hydraulic jack equipped with the mounting 99370617 under the axle.

Unscrew the nuts (7) of the brackets (8) securing the axle to the leaf spring (11).


Lower the hydraulic jack and extract the axle.

Refitting

For refitting, carry out the operations described for removal in reverse order, observing the required tightening torques for the screws and/or nuts.

Afterwards, check that:

- Check the thread of the brackets joining the leaf springs to the axle. If there are any irregularities, rectify the thread (operation 500412) or replace the brackets.
- Bleed the air from the brake hydraulic system as described under the relevant heading (operation 784010).
- Adjust the handbrake control ties as described under the relevant heading (operation 502710).
- Lock the nuts or screws to the required tightening torque.
- The self-locking nuts must not be reused.
- Check the state of the flexible pads (12) and replace them if they have deteriorated (operation 500417).
- The lubricating oil in the axle housing should be at the right level.

Figure 1

DESCRIPTION

The rear axle is the load-bearing type with a single reduction using a hypoid crown wheel and pinion.

The axle housing is made of pressed sheet steel with hot pressed arms.

The central portion, seat of the differential unit, is equipped with cooling fins.

The bevel pinion is supported by two pre-lapped tapered roller bearings to hold the bearing pre-load better.

The rolling torque of the bearings of the bevel pinion is adjusted by changing the thickness of the adjustment ring between the two tapered roller bearings.

In addition, it is possible to adjust the position of the bevel pinion with respect to the ring bevel gear by changing the thickness of the ring between the axle housing and the bevel pinion rear bearing external ring.

The gear housing is supported by two tapered roller bearings.

The rolling torque of the bearings is adjusted with adjustment rings between the spacer rings and the external rings of the bearings.

The clearance between pinion and crown wheel is adjusted by changing the thickness and/or position of the adjustment rings, though the total thickness must be the same as that of the adjustment rings removed.

The gear housing is composed of two half-housings.

It may be of two different sizes depending on the ratio of the crown wheel and pinion.

The gearing of the differential is composed of four planetary gears and two crown wheels.

The wheel hubs are keyed, with UNIT BEARINGS lubricated for life, onto the arms of the axle housing.

The bearings need no adjustment.


The brakes are disc brakes with floating brake calipers.

The disc brakes are keyed onto the wheel hubs.

The brake calipers are secured with flanges fixed onto the arms of the axle housing.

















The parking brake is the drum type, built into the brake disc.

Figure 2



51858

SPECIFICATIONS AND DATA

|  | Type of rear axle: Simple reduction type | 450311/1 | 450511 |
|---|--|--|---|
| Electric control mechanical differential locking | | on request | |
|  | DIFFERENTIAL UNIT Reduction bevel gear pair ratio (No. of teeth: pinion/crown) | 15/44(1/2.93) - 14/43 (1/3.07) - 13/41 (1/3.15) - 13/43 (1/3.30) - 14/47 (1/3.35) - 13/47 (1/3.61) - 12/47 (1/3.91) - 11/46(1/4.18) - 9/40(1/4.44) - 9/44(1/4.88) - 9/46(1/5.11) - 9/47(1/5.22) - 8/45(1/5.62) - 7/41(1/5.85) | 13/43(1/3.30) - 14/47(1/3.35) - 13/47(1/3.61) - 12/47(1/3.91) - 11/46(1/4.18) - 9/40(1/4.44) - 9/44(1/4.88) - 9/47(1/5.22) - 8/45(1/5.62) |
|  | Bevel pinion bearings | 2 with taper rollers | |
|  | Bevel pinion bearings rolling torque (lubricated bearings and gaskets) Nm New bearings kgm | 1.2 ÷ 2.4 0.12 ÷ 0.24 | |
|  | Adjustment of pre-load of bevel pinion bearings | By means of adjustment rings | |
|  | Bevel pinion bearing preload adjusting ring thickness | 1 ÷ 1.975 mm with progression of 0.025 mm. | |
|  | Temperature of assembly of inner bearing ring on bevel pinion | 80 °C ÷ 90 °C | |
|  | Position of bevel pinion with respect to differential casing | By means of adjustment rings | |
|  | Thickness of adjusting ring placed between bevel pinion bearing and differential carrier. | 1 ÷ 1.975 mm with progression of 0.025 mm. | |
|  | Bearings for gear housing | 2 with taper rollers | |
|  | Differential casing bearings rolling torque Nm kgm | 2 ÷ 2.8 0.20 ÷ 0.28 | |
|  | Adjustment of differential casing bearings rolling torque | By means of adjustment rings | |
|  | Differential carrier bearing rolling torque adjusting ring thickness | 1 ÷ 1.95 mm with progression of 0.05 mm. | |
|  | Clearance between pinion and ring bevel gear | 0.15 ÷ 0.20 mm | |
|  | Adjustment of clearance between pinion and ring bevel gear | By means of adjustment rings | |
|  | Clearance between planetary and crown wheels | 0.12 ÷ 0.18 mm | |









| | | | | |
|--|---|--|---------------|------|
|  | Type of rear axle: Simple reduction type | 450311/1 | 450511 | |
|  | WHEEL HUBS | | | |
|  | Wheel hub bearings | Unit-Bearing | | |
|  | Wheel hub bearings end play | - | | |
|  | Wheel hub bearings rolling torque Nm kgm | - - | | |
|  | Adjustment of wheel hub bearings end play | Non-adjustable Tightening to fixing ring nut torque | | |
|  | Rear axle oil Quantity Litres | TUTELA WI40/M-DA 1.9 | | |
| Dry rear axle weight : <input type="checkbox"/> With ABS kg <input type="checkbox"/> Without ABS kg <input type="checkbox"/> Max capacity (GRW) kg | | 3100 | 154.6 153 | 3700 |

Figure 3




SECTIONAL VIEW OF DIFFERENTIAL

51862

TIGHTENING TORQUES

Figure 4




44588

SECTIONAL VIEW OF REAR AXLE DIFFERENTIAL WITH DIFFERENTIAL LOCKING

| COMPONENT | TORQUE | |
|-----------|-----------|------------|
| | Nm | kgm |
| 1 | 400 ÷ 500 | 40 ÷ 50 |
| 2 | 200 ÷ 210 | 20 ÷ 21 |
| 3 | 21 ÷ 25 | 2.1 ÷ 2.5 |
| 4 | 21 ÷ 26 | 2.1 ÷ 2.6 |
| 5 | 96 ÷ 117 | 9.6 ÷ 1.17 |

Figure 5



SECTIONAL VIEW OF HUB







87907

| COMPONENT | TORQUE | |
|-----------|-----------|-------------|
| | Nm | kgm |
| 1 | 290 ÷ 349 | 29 ÷ 34.9 |
| 2 | 63 ÷ 76 | 6.3 ÷ 7.6 |
| 3 | 618 ÷ 667 | 61.8 ÷ 66.7 |
| 4 | 69 ÷ 76 | 6.9 ÷ 7.6 |
| 5 | 180 ÷ 220 | 18 ÷ 22 |
| 6 | 85 ÷ 97 | 8.5 ÷ 9.7 |
| 7 | 8 | 0.8 |
| ** | 5 ÷ 7 | 0.5 ÷ 0.7 |







* Spread the surface of the drive shaft - wheel hub union with B-type sealant.

** When assembling the screws securing the timing sensor mounting, apply a few drops of LOCTITE 245 thread-lock onto the thread of the corresponding holes of the bracket welded onto the axle arm.

TOOLS

| TOOL NO. | DESCRIPTION |
|-----------------|--|
| 99305121 | Hot air drier  |
| 99321024 | Hydraulic trolley for removing and refitting wheels  |
| 99322215 | Driving and steering axle overhaul stand  |
| 99341001 | Double effect bridge  |
| 99341005 | Reaction bridge  |
| 99341010 | Pair of retainers  |

TOOLS

| TOOL NO. | DESCRIPTION |
|-----------------|---|
| 99345056 | Counter block for pullers  |
| 99355087 | 65 mm. diam. box wrench for disassembly - assembly wheel hub locking ring  |
| 99370006 | Handle, interchangeable drift  |
| 99370309 | Tool for measuring thickness of bevel pinion adjustment rings (to be used with 99395728)  |
| 99370317 | Lever and relevant extension bar to retain flanges  |
| 99370497 | Tool for assembly of wheel hub  |


TOOLS

| TOOL NO. | DESCRIPTION |
|-----------------|---|
| 99370498 | Tool for assembly of wheel hub bearing and phonic wheel |
| 99370617 | Axle universal support during removal/installation |
| 99374022 | Keying tool for assembly of differential bevel pinion gasket (to be used with 99370006) |
| 99389819 | Torque wrench (0 to 10 mm) with 1/4" square attachment |
| 99395728 | Dial gauge with support to be used with the tools to determine the adjustment thickness of the bevel pinion |
| 99348001 | Extractor with locking device |

525010 OVERHAULING THE REAR AXLE ASSEMBLY

This chapter deals with overhaul operations different from those described for rear axle 450210. Adjustment data, tightening torque and tools are those specified in this chapter.

Figure 6




44609

Set the entire rear axle assembly on stand 99322215.

! The identification data of the rear axle unit are given on the plate (1) fixed near to the leaf spring attachment support.

525030 Wheel hub overhaul

Figure 7




101965

Disconnect the pipe (2) from the support bracket (1). Remove caps (3), take off screws (4), then remove brake caliper (5) from support (6).

NOTE The thread of the screws securing the brake caliper is treated with adhesive. Therefore, they must not be reused, but replaced with new ones every time they are removed.


Figure 8



44611

Take off the brake linings (1). Take out the screws (⇒) and remove the mounting (2).


Figure 9



44612

Take out the screws (⇒) and remove the drive shaft (1).

Figure 10




44613

Lift up the notch (⇒) of the ring nut (1). Using the wrench 99355087 (2) remove the ring nut (1), take out the washer and extract the wheel hubs (3).


525031 Replacing the wheel hub bearing

Figure 11




If the hub is fitted with a phonic wheel (2), take it out with the extractor (1) 99341001 as shown in the figure. Otherwise, take out the bearing guard ring.

Figure 12



Take out the screws (⇒) and remove the brake disc (1) from the wheel hub. Check the brake disc as described under the Brakes heading.


Figure 13



The bearing (1) is removed from the wheel hub with the aid of an ordinary punch.


NOTE Bearing (1) driving load is 2100 ÷ 5000 kg.

Figure 14




The new bearing should be mounted in the wheel hub with a press and tool 99370498.

Figure 15



Mount the brake disc (1) on the wheel hub (2) and tighten the fixing screws (⇒) to the required torque.

Figure 16




If it is necessary to replace the pins of the wheel hub (1), before mounting the new ones, check that the mating surface of the pin head is free from burrs, dross and blisters.

The pins should be driven in by applying a load on their head no greater than 2000 kg.

After driving them home, check that the pins are perfectly in touch with the hub: maximum orthogonal tolerance 0.2 mm.

Figure 17




44619

Stand the bearing of the wheel hub (2) on a special mounting that permits rotation. With a magnetic dial gauge (1) check the off-centring of the brake disc on both sides.

Off-centring must not exceed 0.1 mm.


Figure 18



45165

The phonic wheel (2) should be mounted in the hub with the punch 99370498 (1), checking after assembly that the "phonic" wheel rests perfectly in its seat in the hub.

Figure 19




44620

Check the orthogonality of the phonic wheel (2), proceeding as follows:

Position the feeler of the magnetic dial gauge (1) on the phonic wheel.

Making the wheel hub (3) turn, check that the maximum error of orthogonality of the phonic wheel (2) is no greater than 0.1 mm.

Figure 20




44621

NOTE Check and, if necessary, adjust the clearance between the parking brake drum and shoes as described in the Brakes section.

Mount the inserter 99370497 (2) on the sleeve.

Lubricate the sleeve with TUTELA WI 40/M-DA oil and key the wheel hub (1).


Figure 21



44622

Mount the washer (1) and a new ring nut (2). Using the wrench 99355087 (3), tighten the ring nut (2) to the required torque. Notch the fixing ring nut (2) on the milling of the axle housing arm.


Figure 22



44623

Mount the support (2) and tighten the fixing screws (1) to the required torque.

Figure 23




44611

Mount the brake linings (1).



The brake lining with the wear indicator must be mounted from the piston side of the brake caliper.

Figure 24



101971

Fit brake caliper (3) to support (2), then use torque wrench (4) to tighten fastening screws (1) to a torque of 32 to 36 Nm.


Having to move the brake caliper piston back, keep to the instructions given in the BRAKES section.



Mount only new screws (2, Figure 24).

Every time they are removed, they must be replaced.


Figure 25



101962

Fit new protection caps (3).
Connect the pipe (2) to the support bracket (1).

Figure 26



44626

Apply IVECO 1905685 sealant on the contact surfaces of the drive shaft (2) with the wheel hub (1).


Mount the drive shaft (2) in the sleeve.

Tighten the screws (3) securing the drive shaft (2) to the hub (1) to the required torque.

526210 DIFFERENTIAL REPAIR OPERATIONS

526260 Disassembly of differential locking


Figure 27



Remove the spring (1).
Unscrew and remove the 4 screws (2) including washers and then disconnect the differential locking device (3).
If required, remove the unit as described in the following paragraphs.

Differential locking removal

Figure 28




Remove gasket (4).
By means of a normal beater knock out the elastic pin (2), remove the lever (1) complete with ring and washer.
Finally, remove the control lever (3) from the support (5).

Assembling the differential locking device

Assemble the differential locking device by following the removal operations in the reverse order.
Re-attach the differential locking device to the rear axle casing as follows:


Differential locking refitting

Figure 29



Mount a new O-ring on the differential locking attachment plane.
Position the previously assembled support (3) so as to insert the control lever in the spline on the sliding sleeve.
Insert the 4 screws (2) complete with washers and spring washers and tighten the screws to the driving torque of 23 Nm (2.35 kgm).
Assemble the spring (1).
Adjust the differential locking device by following the procedures below.

Figure 30



61871

DIFFERENTIAL LOCKING DEVICE COMPONENTS

1. Flexible tie rod bracket (Bowden) - 2. Rear axle casing - 3. Spring - 4. Gasket - 5. Sealing ring - 6. Gasket - 7. Sleeve control lever (9) - 8. Elastic pin to fix lever (7) to lever (12) - 9. Differential locking sliding sleeve - 10. Spring coupling plate (11) - 11. Lever return spring (12) - 12. Transmission lever - 13. Adjusting screw nut - 14. Adjusting screw - 15. Differential locking device body.


Adjusting the differential locking device

Engage the sliding sleeve (9). Once this has been done, loosen the nut (13), move the adjustment screw (14) so that it is in contact with the control lever (7). After this, unscrew the adjustment screw by 9.5 turns (corresponding to 9.5 mm. travel of the screw) and lock it with the fastening nut (13).

Disassembling the differential unit

NOTE Before carrying out repair operations on the differential unit you must drain off the oil and disassemble the drive shafts. For the rear axle, you must disassemble the differential locking as described in the relevant paragraphs.


Figure 31



18216


Unscrew the screws (1) complete with tab washers and spring washers and remove the gear housing inspection cover (2) complete with gasket.

Figure 32



Mark the position of the caps (1 and 2) and remove them.

Figure 33




Take out the gear housing (1).

Note the assembly position of the adjustment rings (3) and take them out of the housing together with the spacer rings (2).

NOTE In the case of reuse, do not swap over the assembly positions of the external rings (4) of the tapered roller bearings.

Disassembly of gear housing


Figure 34



Extract the support bearing inner rings (3 and 5) and shoulder ring (2) from the gear housing and, by means of the puller tool 99348001 (4), extract the counter block (1).

NOTE The thrust ring (2) is only present with rear axles fitted with differential locking.


Figure 35



NOTE Mark the cover (1) and the gear housing (4).

Unscrew the screws (2), remove the ring bevel gear (3) and the gear housing (4) cover (1).


Figure 36



Remove the crown wheel (2) on the cover side with its thrust washer (3) from the gear housing (1).


Using a generic beater to remove the long pin (4) and the two short pins (5) from the gearing case (1).

Figure 37




Remove the spider (1) and the four planetary gears (2) with their shoulder washers (3) from the gear housing.

Figure 38



Remove the crown wheel (1) on the gear housing side with the thrust washers.

Figure 39




51863

PARTS COMPRISING THE DIFFERENTIAL UNIT

- 1. Nut - 2. Transmission connection coupling - 3. Seal - 4. Front bearing - 5. Pinion shim ring - 6. Fixed spacer - 7. Spacer ring - 8. Adjustment ring - 9. Rear bearing - 10. Bevel pinion - 11. Ring bevel gear - 12. Fixed ring - 13. Adjustment ring - 14. Bearing - 15. Thrust ring (axle with differential locking) - 16. Gear housing - 17. Crown wheel thrust washer - 18. Spider - 19. Crown wheel - 20. Gear housing cover - 21. Screw - 22. Planetary gear thrust washer - 23. Planetary gear - 24. Short pin - 25. Long pin.


Assembly of gear housing

Figure 40




Position the crown wheel (1), gear housing side, complete with thrust washer, into its own housing.

Figure 41




Position the two planetary gears (1) complete with thrust washers, spider (2) and then insert the long pin (3).

Figure 42




Position the other two planetary gears (1) complete with thrust washers and then insert the two short pins (2). Rotate the planetary gears-crown wheel unit and check that it is free without stiffness. Assemble the other crown wheel complete with thrust washer.

Figure 43



Assemble the cover and make the marks made during disassembly coincide. Assemble the ring bevel gear and fasten this to the half-casing by means of the fixing screws. By means of a torque wrench (1) tighten the fixing screws (2) to the required tightening torque.

Figure 44




Only for axles with differential lock. Using tool 99305121, heat thrust ring (1) to a temperature of $120^{\circ}\text{C} \pm 150^{\circ}\text{C}$ for 15' and fit on the gear casing (2) from the side with the differential lock.

Assembling bevel pinion unit

This differs from assembling of bevel pinion unit of rear axle 450210 differential in the following.


Figure 44/I



Fit tapered-roller bearing internal ring (2) onto false pinion 99370309 (1) with the washer supplied (3).

Differential unit refitting

Figure 45



62100

Using a suitable punch, with a grip, drive the external ring (4) for the front bearing into the axle housing (1).

Position the spacer ring (2), thickness 2 mm, and using a suitable punch drive in the external ring (3) of the rear bearing.


Determine the adjustment thickness and position of the bevel pinion as described for axle 450210.

Remove the external ring (3) of the tapered roller bearing.

Position the adjusting ring (5) of the calculated thickness on the spacer ring (2).

Refit the external ring (3) of the tapered roller bearing.

Figure 46



51865


Lubricate the internal ring of the front bearing and position it in the housing.

Using the key 99374022 (1) and grip 99370006 (2), mount the pre-lubricated seal.

Determine the bevel pinion rolling torque adjustment ring as described for axle 450210.

NOTE The rolling torque of the bevel pinion must be measured with lubricated bearings and seals.

Figure 47




18252

Heat the internal ring (4) of the tapered roller bearing to 80°C ± 90°C for approximately 15 min. and drive it, with a suitable punch, onto the bevel pinion (1).

Position the spacer ring (3) and adjustment ring (2), calculated beforehand to obtain the required rolling torque, on the bevel pinion (1).

Figure 48




51866

Position the axle housing as shown in the figure.

On the stand, set a pipe (3) of such diameter and length as to provide a solid supporting surface for the flange (2) and the internal ring (1) of the front bearing above, already mounted in the axle housing.

Figure 49



Insert the bevel pinion (1), assembled as shown in the figure, in the internal ring of the front bearing (2) and in the flange (3).


NOTE Strike the top of the bevel pinion until it is possible to fit the nut (1, Figure 50) securing the flange (3).
Take out the support pipe (4).
Complete assembling the pinion by fully tightening the nut.

Block rotation of the transmission flange with the retainer tool 99370317.

Using a suitable Allen wrench and the torque wrench, tighten the bevel pinion retainer nut (1, Figure 50) to the required torque.


To be on the safe side, check the rolling torque of the bevel pinion with the dynamometer 99389819.

Figure 50




Make a cut in the collar of the nut (1) by the milling of the bevel pinion (2) as shown in the figure.

Figure 51




Position the sliding sleeve in the rear axle housing for differential locking (if present). Mount the external rings (1) for the gear housing support bearings and then position the previously mounted gear housing in the rear axle housing.

Figure 52



Mount the spacers and adjustment rings in the same number, thickness and position found during disassembly, in the following order: spacer (1), adjustment ring (2), adjustment ring (3) and spacer (4).

Figure 53



18262

Complete assembly by checking the total rolling torque and the bevel pinion coupling clearance as described for axle 450210.

Position a new seal ring over the gear housing inspection attachment surface.

Mount the cover (3), insert the fixing screws (2) complete with tab washers and spring washers.

Tighten the screws (2) with the torque wrench (1) to the required tightening torque.

NOTE Do not tighten the screws to a torque greater than the value indicated since this would impair the sealing effect of the gasket placed between the coupling plane and the gear housing inspection cover.

Mount the differential locking device (if present) and adjust it as described under the relevant heading.

Mount the drive shafts as described under heading: "525030 Overhauling the Hubs".

Screw on the oil drainage plug and tighten it to the required torque.

Add lubricating oil in the required quantity and grade through the hole.

Screw on the oil filler plug and tighten it to the required torque.

Take the assembly off the stand.

NOTE The assembly should be put back on its mounting to prevent the dust guards and/or brake discs from getting damaged.

Rear axle 450517/2

| | Page |
|--|------|
| REAR AXLE REMOVAL – REFITTING | 63 |
| <input type="checkbox"/> Removal | 63 |
| <input type="checkbox"/> Refitting | 63 |
| DESCRIPTION | 65 |
| SPECIFICATIONS AND DATA | 66 |
| TIGHTENING TORQUES | 68 |
| TOOLS | 70 |
| OVERHAULING THE REAR AXLE ASSEMBLY | 74 |
| <input type="checkbox"/> Air breather disassembly – assembly | 74 |
| <input type="checkbox"/> Overhaul of wheel hubs | 74 |
| <input type="checkbox"/> Removal | 74 |
| <input type="checkbox"/> Stud replacement | 76 |
| <input type="checkbox"/> Refitting | 76 |
| <input type="checkbox"/> Refitting | 77 |
| DIFFERENTIAL REPAIR OPERATIONS | 79 |
| <input type="checkbox"/> Differential locking | 79 |
| DIFFERENTIAL REPAIR OPERATIONS | 80 |
| <input type="checkbox"/> Differential unit removal | 80 |
| <input type="checkbox"/> Gearing case removal | 80 |
| <input type="checkbox"/> Differential components check | 82 |
| <input type="checkbox"/> Rear axle casing check | 82 |
| <input type="checkbox"/> Gearing case refitting | 82 |
| <input type="checkbox"/> Differential unit refitting | 86 |

REAR AXLE REMOVAL - REFITTING

Removal

Position the vehicle on level ground and lock the front wheels.

Loosen rear wheel fastening nuts.

Lift the rear part of the vehicle and position it on proper stands.

Fit hydraulic truck 99321024 under the rear wheels, remove wheel fastening nuts and then remove wheels.

Loosen handbrake lever adjustment nut (4). Release cables (2) from vehicle cross member by releasing the retaining clips (5), and from the side member brackets by loosening clamp fastening screws (3).

Loosen propeller shaft fastening screws (6).

Release cables from clamps and disconnect the brake lining (1) and (7) wear indication electrical cables of ABS sensors, if any.

Loosen shock absorber (14) fastening nuts (16).

Loosen the screws (17) fastening the stabilizer bar (10) to the rear axle.

Disconnect brake oil pipes from connection (13) and secure them to the chassis to prevent oil draining from system.

Disconnect pipe (15) from rear axle casing oil vapour bleed.

Position the hydraulic jack fitted with support 99370617 under the rear axle.

Loosen the nuts (8) of the brackets (9) fastening the rear axle to the leaf spring (10).

Lower the hydraulic jack and remove the rear axle.


Refitting

For refitting, carry out the operations described for removal in reverse order, observing the required tightening torques for the screws and/or nuts.

Afterwards, check that:

- Check the thread of the brackets joining the leaf springs to the axle. If there are any irregularities, rectify the thread (operation 500412) or replace the brackets.
- Bleed the air from the brake hydraulic system as described under the relevant heading (operation 784010).
- Adjust the handbrake control ties as described under the relevant heading (operation 502710).
- Lock the nuts or screws to the required tightening torque.
- The self-locking nuts must not be reused.
- Check the state of the flexible pads (12) and replace them if they have deteriorated (operation 500417).
- The lubricating oil in the axle housing should be at the right level.

Figure 1



DESCRIPTION

The rear axle is the load-bearing type with a single reduction using a hypoid crown wheel and pinion.

The axle housing is made of pressed sheet steel with hot pressed arms.

The central portion, seat of the differential unit, is equipped with cooling fins.

The bevel pinion is supported by two pre-lapped tapered roller bearings to hold the bearing pre-load better.

The rolling torque of the bearings of the bevel pinion is adjusted by changing the thickness of the adjustment ring between the two tapered roller bearings.

In addition, it is possible to adjust the position of the bevel pinion with respect to the ring bevel gear by changing the thickness of the ring between the axle housing and the bevel pinion rear bearing external ring.

The gear housing is supported by two tapered roller bearings.

The rolling torque of the bearings is adjusted with adjustment rings between the spacer rings and the external rings of the bearings.

The clearance between pinion and crown wheel is adjusted by changing the thickness and/or position of the adjustment rings, though the total thickness must be the same as that of the adjustment rings removed.

The gear housing is composed of two half-housings.

It may be of two different sizes depending on the ratio of the crown wheel and pinion.

The gearing of the differential is composed of four planetary gears and two crown wheels.

Wheel hubs are supported by two "SET RIGHT" type bearings set on the sleeve.

The bearings need no adjustment.


The brakes are disc brakes with floating brake calipers.

The disc brakes are keyed onto the wheel hubs.

Perrot type brake callipers are supported by flanges welded to rear axle casing arms.
















The parking brake is the drum type, built into the brake disc.








Figure 2



62983


SPECIFICATIONS AND DATA

| | | |
|---|---|---|
|  | Type of axle: Bearing with single reduction and mechanical control differential locking | 450517/2 |
|  | DIFFERENTIAL UNIT Reduction bevel gear pair ratio (tooth no.: pinion/crown wheel), on request | 1/3.91 (11/43) - 1/4.30 (10/43)* - 1/4.56 (9/41)* - 1/5.13 (8/41)* |
|  | Bearings for bevel pinion | 2 taper rollers |
|  | Bevel pinion bearing rolling torque (lubricated gaskets and bearings) Nm New bearings kgm | 2 ÷ 3 0.20 ÷ 0.30 |
|  | Bevel pinion bearing preload adjustment | through adjustment rings |
|  | Bevel pinion bearing preload adjustment ring thickness | 1* - 2 mm * with 0.025 mm progression |
|  | Temperature for fitting inner bearing ring on bevel pinion | 80 °C ÷ 90 °C |
|  | Bevel pinion position with reference to differential casing | By means of shims |
|  | Thickness of adjustment rings between bevel pinion and differential casing | 3.45 ÷ 4.35 mm with 0.025 mm progression |
|  | Bearings for gearing case | 2 taper rollers |
|  | Differential case bearing rolling torque Nm kgm | 2.6 ÷ 3.9 0.26 ÷ 0.39 |
|  | Adjustment of differential case bearing rolling torque | Through adjustment rings |
|  | Thickness of adjustment rings for differential case bearing rolling torque | 2.65 ÷ 3.20 mm with 0.05 mm progression |
|  | Backlash between pinion and crown wheel | 0.15 ÷ 0.20 mm |
|  | Adjustment of backlash between pinion and crown wheel | Through adjustment rings |

| | | |
|---|---|---------------------------------------|
|  | Type of axle: | 450517/2 |
|  | WHEEL HUBS | |
|  | Wheel hub bearings | Two "SET-RIGHT" type taper rollers |
|  | Hub bearing end play | 0.16 max. |
|  | Wheel hub bearing rolling torque Nm kgm | 0 ÷ 4 0 ÷ 0.4 |
|  | Wheel hub bearing end play adjustment | Fastening nut tightening to torque |
|  | Rear axle oil | Tutela WI40/M-DA (SAE 85 WI40) |
| | Amount | 3 |
| | | kg |
| | Max. capacity GAW | 5000 |

TIGHTENING TORQUES

Figure 3



450517/2 (R0537) REAR AXLE DIFFERENTIAL SECTION

62879

| PART | TORQUE | |
|------|---------------|-------------|
| | Nm | kgm |
| 1 | 533 ÷ 589 | 53.3 ÷ 58.9 |
| 2 | 26 ÷ 21 | 2.6 ÷ 2.1 |
| 3 | 309.5 ÷ 342.5 | 30.9 ÷ 34.2 |
| | 266 ÷ 294 | 26.6 ÷ 29.4 |
| 4 | 61 ÷ 74 | 6.1 ÷ 7.4 |
| 5 | 23 | 2.3 |
| 6 | 102 ÷ 113 | 10.2 ÷ 11.3 |

* Before tightening the screws, smear their threaded holes with IVECO sealant I905683.

Figure 4





Figure 5



ABS VERSION

74729

62878

| PART | TORQUE | |
|------|---------------|-------------|
| | Nm | kgm |
| 1 | 283.8 ÷ 342.6 | 28.3 ÷ 34.2 |
| 2** | 56 ÷ 69 | 5.6 ÷ 6.9 |
| 3 | 441 ÷ 540 | 44.1 ÷ 54 |
| 4 | 9.5 ÷ 11.5 | 0.9 ÷ 1.1 |
| 5 | 54 ÷ 59 | 5.4 ÷ 5.9 |
| 6 | 150 ÷ 177 | 15 ÷ 17.7 |
| 7 | 52 ÷ 57 | 5.2 ÷ 5.7 |
| 8*** | 5 ÷ 7 | 0.5 ÷ 0.7 |

* Smear axle shaft-wheel hub connecting surface with IVECO sealant 1905685.
 ** Smear the threads of the screws acting as plugs with IVECO sealant 1905683.
 *** Apply LOCTITE 243 on hole threads.







TOOLS

| TOOL No. | DESCRIPTION |
|-----------------|---|
| 99305121 | Hot air operated equipment |
| 99306004 | 300 kg hydraulic crane |
| 99306010 | Equipment for bleeding air from brake and clutch system |
| 99321024 | Hydraulic truck for removing - refitting wheels |
| 99322215 | Stand to overhaul axles |
| 99345056 | Counter block for pullers |

TOOLS

| TOOL No. | DESCRIPTION |
|-----------------|--|
| 99348001 | Puller with locking device |
| 99357080 | Wrench (91.5 mm) for wheel hub bearing adjustment nut |
| 99370006 | Handle for interchangeable beaters |
| 99370007 | Handle for interchangeable beaters |
| 99370296 | Tool to find bevel pinion shims (to be used with 99395728) |
| 99370317 | Counter lever and relevant extension to retain flanges |


TOOLS

| TOOL No. | DESCRIPTION |
|-----------------|--|
| 99370617 |  Universal support to hold axles during removal/refitting |
| 99374093 |  Beater to fit in place bearing outer races (91-134) (to be used with 99370007) |
| 99374132 |  Element to fit in place wheel hub internal gasket (to be used with 99370006) |
| 99374201 |  Element to fit in place differential bevel pinion gasket |
| 99389819 |  Dynamometric wrench (0-10 Nm) connection 1/4" |
| 99395026 |  Tool to check hub rolling torque (to be used with dynamometric wrench) |


TOOLS

TOOL No.

DESCRIPTION

99395684

Dial gauge with magnetic base

99395728


Dial gauge with support to be used with the tools for finding proper bevel pinion shims

525010 OVERHAULING THE REAR AXLE ASSEMBLY



The drive shafts, brake disc and calipers, air breather and differential can all be removed and refitted even with the unit mounted on the vehicle.


Figure 6



62880

Before positioning the rear axle assembly on the stand for overhauling, drain oil by loosening rear axle casing plug. Disconnect brake fluid pipes (2) from brake callipers (1) and from rear axle casing and pipes (3) from rear axle casing.

Figure 7




62881

Set the entire rear axle assembly on stand 99322215.

NOTE The identification data of the rear axle unit are given on the plate (1) fixed near to the leaf spring attachment support.

525013 Air breather disassembly - assembly

Figure 8




62882

Take out the screws (1) and remove the brake caliper with its brake linings from the mounting.

525030 Overhaul of wheel hubs

Removal

Figure 9



62883

Take out the screws (1) and remove the brake caliper (2) with its brake linings from the mounting.



The caliper must not be violently knocked or dropped.


Prevent the rubber caps coming into contact with sharp metal tools.

Do not dirty or wet the rubber caps with mineral grease or oil.

Do not dirty the pads with liquids or grease.

Check proper brake calliper and brake lining conditions as described in "Brake" section.


Figure 10



62889

Rotate the wheel hub (1) to set downward one of the two screws (2) located between hub reliefs; remove the screws and drain oil completely from wheel side. Remove the other screws fastening the axle shaft (3) to the wheel hub (1).


Figure 11



62890

Remove the axle shaft (2) from the wheel hub (1).


Figure 12



62891

Remove ring nut (1) safety screw (2).


Figure 13



62892

Loosen bearing retaining ring nut (1, Figure 12) using wrench 99357080 (1).


Figure 14



62893

Remove the safety washer (1).


Figure 15



62894

Sling the brake disc (1) with rope and hoist, remove the wheel hub (2) including: brake disc (1), front (3) and rear bearings, sealing ring and spacer.


Figure 16



Remove front bearing (1) inner ring and spacer (2). Remove screws (4) and disconnect the brake disc (5) from the wheel hub (3).


NOTE Check the brake disc as described in the "Brake" section.

Figure 17



Remove phonic wheel (1), if any, using suitable equipment. Remove sealing ring (2) and the rear bearing inner ring (4) set below from the wheel hub (3).


Figure 18



Use a suitable punch to remove the rear taper roller bearing outer ring (1). Repeat this operation to remove the front taper roller bearing outer ring.

Stud replacement

Figure 19




If it is necessary to replace the pins of the wheel hub (1), before mounting the new ones, check that the mating surface of the pin head is free from burrs, dross and blisters.

The pins should be driven in by applying a load on their head no greater than 2000 kg.

After driving them home, check that the pins are perfectly in touch with the hub: maximum orthogonal tolerance 0.2 mm.

Refitting


Figure 20



Use handle 99370007 (1) and beater 99374093 (2) to fit taper roller bearing outer rings into the wheel hub.

NOTE This operation shall be performed using a press until positioning the rings at 5 mm from their abutting end, their fitting shall be then completed by hand.

Figure 21



62932


Lubricate rear taper roller bearing inner ring (4) with SAE W 140 M-DA oil and fit it to wheel hub (5). Use tool 99374132 (2) provided with proper handle 99370006 (1) to fit sealing ring (3).

NOTE Use tool 99374132 (2) side to position the sealing ring (3) at 1.5 mm from wheel hub side surface.

Fit the phonic wheel, if any, on the wheel hub.

NOTE Phonic wheel fitting shall be performed after heating it at 150°C. When fitting is over, check whether the phonic wheel is resting perfectly on the hub seat. Check whether phonic wheel squareness and oscillation is lower than 0.2 mm.

Figure 22




62896

Fit the brake disc (3) on the wheel hub (1) and tighten the fastening screws (2) to the specified torque.

Refitting

Figure 23




62938

NOTE Check and, if necessary, adjust the clearance between the parking brake drum and shoes as described in the Brakes section.

Lubricate the sleeve and the sealing ring supporting ring (1) with TUTELA W140/M-DA (SAE 85W140) oil.


Figure 24



62897

Use suitable rope and hoist to fit wheel hub (1) on sleeve (4). Lubricate spacer (2) and outer bearing inner ring (3) with Tutela W140/M-DA and fit them on sleeve (4).


Figure 25



62898

Fit the safety washer (3) so that the clip is guided properly into rear axle casing sleeve groove. Tighten ring nut (4) with wrench 99357080 (1) and dynamometric wrench (2), tighten the new ring nut (4) to the specified torque.

Figure 26




62899

Position the dial gauge 99395684 (1) with a magnetic base on the wheel hub (3) and rest the rod on the sleeve (2).

Check whether wheel hub end play is falling between 0 and 0.16 mm.


Figure 27



62900

Use tool 99395026 (2) and the dynamometric wrench 99389819 (1) to check whether the wheel hub rolling torque is falling between 0 and 4 Nm (0 - 0.4 kgm).


Figure 28



62891

After checking the end play and the rolling torque, check whether one of the adjustment nut (1) holes is coinciding with one of the safety washer holes otherwise loosen the adjustment nut (1) until it is possible to fit the fastening screw (2). Tighten the fastening screw (2) and the adjustment nut to the specified torque.

Figure 29




62902

Smear the contact surface between axle shaft (3) and wheel hub (1) with IVECO sealing compound 1905685.

Fit axle shaft (3), tighten the fastening screws (2), excluding those set between the two wheel hub marks (see Figure 30) with tool 99370317 (4) lock wheel hub (1) rotation.

Figure 30




62903

Set horizontally to ground the two holes (1) located between the wheel hub marks and pour through 0.2 l of W140 M-DA oil on each wheel side.

Smear the threaded section of the screws acting as plug with IVECO sealant 1905683 and tighten to the specified torque.

Figure 31




62904

Position brake calliper (1) including the brake lining on the supporting flange (2).
Tighten the fastening screws to the specified torque.

NOTE The brake lining with the wear sensor shall be fitted on brake calliper piston side.
Comply with BRAKE section requirements to move back the brake calliper piston.

Figure 32




62880

Remove the rear axle assembly from the overhaul stand. Refit brake fluid pipes (2 and 3) to rear axle casing and brake callipers (1).
Fill rear axle casing with oil in the specified amount and quality.

526210 DIFFERENTIAL REPAIR OPERATIONS

526260 Differential locking


Figure 33



62906

Remove the 4 screws (1) including washers and disconnect the differential locking device (2).
When refitting, replace the gasket located between differential locking device and rear axle casing.
Tighten screws (1) to the specified torque.

Figure 34



62907

DIFFERENTIAL LOCKING DEVICE SECTION


Differential locking device engagement/disengagement lever stroke shall be equal to 5 mm.

526210 DIFFERENTIAL REPAIR OPERATIONS

Differential unit removal

NOTE Before performing differential repair, drain oil and remove axle shafts as described previously.


Figure 35



33077

Remove gearing (1) inspection cover including the gasket.


Figure 36



33078

Remove caps (1) after marking them.

Figure 37




33079

Remove the spacer (1) and remove the gearing case (3) including the crown wheel (4) and the outer rings (2) for supporting bearings. Remove the other spacer and the adjustment rings. Do not reverse the outer races of the gearing case supporting bearings.

Gearing case removal


Figure 38



33081

Remove gearing case supporting bearings (1 and 2) using puller 99348001 (3) and counter block 99345056 (4).


Figure 39



33082

Clamp the gearing case (2) in a vice and remove the ring bevel gear (1) from the gearing case (2).


Figure 40



33083

Mark gearing half-boxes (1 and 2), loosen the fastening screws, position the gearing case on a bench and remove the two half-boxes.


Figure 41



33084

Remove sun gears (5) and planetary gears (2) including the spider (6) from the gearing half-box (4). Recover the shoulder washers (1 and 3).


Figure 42



33086

Remove bevel pinion retaining nut safety crimp and loosen the nut using the counter lever 99370317 (1).


Figure 43



33087

Remove transmission connection flange (1).


Figure 44



33088

Use a bronze beater in arrow direction to remove the bevel pinion (1) including the rear bearing, the fixed spacer and the adjustment rings from the rear axle casing (2).


Figure 45



33089

Remove the sealing ring (1) and the front taper roller bearing from the rear axle casing (2). Use a bronze beater to remove the front taper roller bearing outer ring.


Figure 46



33090

Use a bronze beater to remove the rear taper roller bearing outer ring (1) from the rear axle casing (2).

Figure 47



33091

Use puller 99348001 (3) to remove the rear taper roller bearing (2) from the bevel pinion (1).

Differential components check

Carefully clean each differential component. Lubricate the bearings and rotate the roller cage freely. The rotation must be even and without sign of stiffness. Check the ring bevel gear contact surfaces and the half-box striker plate to ensure that the crown wheel adheres perfectly. Deformations on these surfaces cause the crown wheel fastening screws to vibrate, thus jeopardizing the correct operation of the unit.

NOTE Carefully clean all threads in order to obtain exact adjustments and accurate tightening torque.

Check that the splined section for flange-pinion connection is not badly worn, otherwise replace the pinion.

NOTE When replacing the crown wheel or pinion it is necessary to replace both parts since they are supplied in pairs.

Check the planetary gears and the relevant shoulder washers, the spider and the crown wheels with the relevant shoulder washers.


Replace all sealing elements, the bevel pinion retaining nut and gearing case bearing adjustment nut with new parts.

Rear axle casing check

Check whether rear axle casing is not deformed.

Gearing case refitting


Figure 48



33092

Fit in place the sun gear (2) with the shoulder washer set below in gearing half-box (1).


Figure 49



33084

Fit in place the planetary gears (2) with shoulder washers (3), the spider (6) and the sun gear (5) with shoulder washer (1) in the gearing half-box (4).


Figure 50



33094

Fit between them the half-boxes (1 and 2) and tighten the fastening screws to the specified torque.


Figure 51



33095

Heat in air-circulation furnace at 100°C for approx. 15' the tapered roller supporting bearing (1) on tooting side and fit it down onto the gearing case (2) completely.


Figure 52



33096

Heat in air-circulation furnace at 100°C for approx. 15' the tapered roller supporting bearing (1) on tooting opposite side and fit it down onto the gearing case (2) completely.


Figure 53



33097

Pour few drops of LOCTITE 270 into crown wheel (1) holes, fit the crown wheel (1) on the gearing case (2) and tighten the fastening screws to the specified torque.


Figure 54



33098

Use beater 99374093 (1) to fit in place front tapered roller bearing outer ring on rear axle casing. (See Figure 17 for ring adjustment on beater 99374093).


Figure 55



33099

Use beater 99374093 (1) to fit in place rear tapered roller bearing outer ring on rear axle casing (2) without adjustment ring.


Figure 56



33100

On surface plate (2), set to zero dial gauge 99395728 (1) on support (3) and slightly preload it.


Figure 57



33101

Fit the rear bearing (2) on the false pinion 99370296 (1).

Figure 58




33102

Position the false pinion 99370296 (1) including the rear bearing (2) into its seat on rear axle casing (3).

Fit the front bearing, the transmission connecting flange and the bevel pinion retaining nut and tighten so as to remove end play and to enable false pinion rotation.

Figure 59



33103

Set dial gauge 99395728 (1) including support (3) on false pinion 99370296 (2). Direct suitably the dial gauge previously set to zero (see Figure 51) to position the rod to the bottom of the gearing case supporting bearing housing.

Repeat this operation for the other bearing and take note of both found values.

Pinion adjustment ring thickness is obtained through the following formula:

$$S = \frac{A_1 + A_2}{2} - (+ B)$$

"S" = thickness of the adjustment rings to be positioned between bevel pinion rear bearing outer ring and rear axle casing.

"A1" = value found on right housing

"A2" = value found on left housing

"B" = reference value marked on bevel pinion (see Figure 60)

Example:

$$S = \frac{3.90 + 4.10}{2} - (\pm 0.05)$$


$$S = \frac{8.00}{2} - 0.05$$

$$S = 4.00 - 0.05$$

$$S = 3.95$$

Adjustment ring thickness shall therefore be: 3.95 mm.


Figure 60



33104

NOTE If the value marked on the pinion is preceded by positive sign (+), it shall be subtracted from the value obtained by the sum divided by two of the housings, whereas it shall be added if preceded by negative sign (-).


Figure 61



33099

Choose an adjustment ring having the same thickness obtained by using the formula shown in Figure 59 and fit it into the rear axle casing after removing rear taper roller bearing outer ring previously mounted.
Use beater 99374093 (1) to fit definitely the rear taper roller bearing outer ring into rear axle casing (2).


Figure 62



32481

Heat the rear bearing (1) to 100°C for approx. 15' into an air-circulation furnace and then fit it down onto the bevel pinion (2).


Figure 63



32482

Position the fixed spacer (2) and the adjustment ring (3), previously used to obtain the specified rolling torque, on the bevel pinion (1).


Figure 64



33111

Position the complete bevel pinion into the rear axle casing. Heat the front bearing (1) to 100°C for approx. 15' into an air-circulation furnace and then fit it down onto the bevel pinion (2).


Figure 65



74730

Fit the seal ring (2) in the axle casing with tool 99374201 (1).


Figure 66



33113

Fit the transmission connecting flange (1) and the bevel pinion retaining nut (2).

Figure 67




74731

Assemble the flange (3) and prevent rotation with tool 99370317 (1).

Using the torque wrench (2), tighten the bevel pinion flange (3) retaining nut to the correct torque value.

Figure 68



32480

Using the torque wrench 99389819 (1), measure the rolling torque of the bevel pinion.


NOTE The rolling torque must be measured at an ambient temperature of 25°C, making the pinion turn at a speed of 50 rpm after it has made 10 turns.

If the value is incorrect disassemble the pinion (2, Figure 64), and replace the adjuster ring (3, Figure 63) with a suitable ring.

Refit the pinion and repeat the rolling torque check.

Differential unit refitting


Figure 69



33116

Fit gearing case supporting bearing outer rings (2) and then position the gearing case (1), previously fitted, in the rear axle casing.


Figure 70



33117

Insert the spacer (2), adjuster ring (1), adjuster ring (4) and then spacer (3).

Figure 71




33119

Refit caps (1) taking into account the marks made at removal. Use dynamometric wrench 99389827 (2) to tighten the fastening screws to the specified torque. Set gearing case supporting bearings and check total rolling torque.

NOTE The rolling torque must be measured at an ambient temperature of 25°C, making the pinion turn at a speed of 50 rpm after it has made 10 turns.

Figure 72



33107

Use dynamometric wrench 99389819 (1) to check total rolling torque:

$$Ct = Cp + \left(\frac{Cd}{R} \times 0.99 \right)$$

Ct = total rolling torque

Cp = bevel pinion bearing rolling torque

$$Cd = 2 \div 2.8 \text{ Nm (0.2} \div 0.29 \text{ kgm)}$$

R = Rear axle reduction ratio

Example:


$$Ct = 2.5 + \left(\frac{2.8}{3.91} \times 0.99 \right)$$

$$Ct = 2.5 + 0.71$$

$$Ct = 3.21 \text{ Nm (0.33 kgm)}$$

If the value is incorrect, replace the adjuster rings (1 and 4, Figure 70) with rings of the correct thickness.

Figure 73



33121


Position magnetic dial gauge 99395684 (1) and check the clearance between the pinion and crown on four equidistant teeth on the crown. The average of the measurements must equal the required value. If a different clearance is found, remove the caps (3) again and swap over the assembly position of the adjustment rings (1 and 4, Figure 70).

If this is not sufficient, replace the adjustment rings with ones of a different thickness, but the total thickness must still be the same as that of the adjustment rings removed. This is so as not to change the total rolling torque.

Apply a thin layer of Prussian blue on ring gear teeth by brush. Turn the pinion and measure the impression of the contact of the pinion tooting on the crown wheel tooting.

Here we illustrate the possible contacts with the corrections to obtain precise coupling of the crown wheel and pinion.

Figure 74




44603

A = Coupling depth
 B = Crest
 C = Side
 D = Play

E = Greater base
 F = Heel
 G = Top land
 H = Contact surface
 I = Lateral surface


Figure 75



Correct contact

44604


Figure 76



Excessive contact on side of tooth.
 Move the pinion away from the ring bevel gear and then move the ring bevel gear towards the pinion to adjust clearance.

44605


Figure 77



Excessive contact on heel of tooth.
 Move the ring bevel gear towards the pinion and then move the pinion away from the ring bevel gear to adjust clearance.

44606


Figure 78



Excessive contact in the upper part or crest of the tooth.
 Move the pinion towards the ring bevel gear and then move the ring bevel gear away from the pinion to adjust clearance.

44607


Figure 79



Excessive contact on the top land of the tooth.
 Move the ring bevel gear away from the pinion then move the pinion towards the ring bevel gear to adjust clearance.

44608


Figure 80



Fit a new sealing gasket on gearing inspection cover connection surface. Apply Loctite 270 on the thread of the holes for screws to secure cover (1). Fit cover (1) and use dynamometric wrench to tighten the fastening screws to the specified torque.

NOTE Do not tighten screws at higher torque value since this shall jeopardize the effect of the sealing gasket located between the connection surface and the gearing inspection cover.


Figure 81



* NUT ROTATION DIRECTION

Crimp nut (1) collar on bevel pinion (2) milling as shown in the figure.

Figure 82



Fit oil drain plug (2). Pour 3 litres of W140MDA oil through the proper hole and fit inspection and filling plug (1).

Rear axles 450310

| | Page |
|---|------|
| DESCRIPTION | 93 |
| SPECIFICATIONS AND DATA | 94 |
| TIGHTENING TORQUES | 96 |
| TOOLS | 99 |
| OVERHAULING THE REAR AXLE ASSEMBLY . | 103 |
| <input type="checkbox"/> Air breather disassembly - assembly | 103 |
| <input type="checkbox"/> Wheel hub overhaul | 103 |
| <input type="checkbox"/> Replacing the wheel hub bearing | 104 |
| REPAIRING THE DIFFERENTIAL | 107 |
| <input type="checkbox"/> Disassembling the differential unit | 107 |
| <input type="checkbox"/> Gear housing removal | 107 |
| <input type="checkbox"/> Checking the parts comprising the differential | 109 |
| <input type="checkbox"/> Assembly | 109 |
| <input type="checkbox"/> Assembly of gear housing | 111 |
| <input type="checkbox"/> Assembling the bevel pinion assembly | 112 |
| <input type="checkbox"/> Assembly of differential unit | 115 |

DESCRIPTION

The rear axle is the load-bearing type with a single reduction using a hypoid crown wheel and pinion.

The axle housing is made of pressed sheet steel with hot pressed arms.

The central portion, seat of the differential unit, is equipped with cooling fins.

The bevel pinion is supported by two pre-lapped tapered roller bearings to hold the bearing pre-load better.

The rolling torque of the bearings of the bevel pinion is adjusted by changing the thickness of the adjustment ring between the two tapered roller bearings.

In addition, it is possible to adjust the position of the bevel pinion with respect to the ring bevel gear by changing the thickness of the ring between the axle housing and the bevel pinion rear bearing external ring.

The gear housing is supported by two tapered roller bearings.

The rolling torque of the bearings is adjusted with adjustment rings between the spacer rings and the external rings of the bearings.

The clearance between pinion and crown wheel is adjusted by changing the thickness and/or position of the adjustment rings, though the total thickness must be the same as that of the adjustment rings removed.

The gear housing is composed of two half-housings.

It may be of two different sizes depending on the ratio of the crown wheel and pinion.

The gearing of the differential is composed of two planetary gears and two crown wheels.

The wheel hubs are keyed, with UNIT BEARINGS lubricated for life, onto the arms of the axle housing.

The bearings need no adjustment.


The brakes are disc brakes with floating brake calipers.

The disc brakes are keyed onto the wheel hubs.

The brake calipers are secured with flanges fixed onto the arms of the axle housing.















The parking brake is the drum type, built into the brake disc.










Figure 1



102133


SPECIFICATIONS AND DATA

| | | |
|---|---|---|
|  | Type of rear axle: Simple reduction type with mechanical control differential locking | 450310 |
|  | DIFFERENTIAL UNIT Reduction bevel gear pair ratio (No. of teeth: pinion/crown) | 12/45 (1/3.75) - 12/47 (1/3.92) |
|  | Bevel pinion bearings | 2 with taper rollers |
|  | Bevel pinion bearings rolling torque (without seal ring) daNm kgm | 0.23 ÷ 0.33 0.23 ÷ 0.33 |
|  | Adjustment of pre-load of bevel pinion bearings | By means of adjustment rings |
|  | Bevel pinion bearings pre-load adjustment rings | 5.175 ÷ 6.150 mm with progression of 0.025 mm. |
|  | Temperature at assembly of inner bearing ring on bevel pinion | - |
|  | Position of bevel pinion with respect to differential casing | By means of adjustment spacers |
|  | Thickness of adjustment rings placed between bevel pinion and differential casing | 3.2 ÷ 4.1 mm with progression of 0.025 mm. |
|  | Bearings for gear housing | 2 with taper rollers |
|  | Differential casing bearings rolling torque daNm kgm | 0.271 ÷ 0.39 0.271 ÷ 0.39 |
|  | Adjustment of differential casing bearings rolling torque | By means of adjustment rings |
|  | Thickness of adjustment rings of differential casing bearings rolling torque | 4.075 ÷ 4.850 mm with progression of 0.05 mm. |
|  | Clearance between pinion and ring bevel gear | 0.13 ÷ 0.18 |

| | | |
|---|--|--|
|  | Type of rear axle: Simple reduction type | 450310 |
|  | Adjustment of clearance between pinion and ring bevel gear | By means of adjustment rings |
|  | Clearance between planetary and crown wheels | 0.12 ÷ 0.18 mm |
|  | WHEEL HUBS | |
|  | Wheel hub bearings | UNIT-BEARING |
|  | Wheel hub bearings end play | - |
|  | Wheel hub bearings rolling torque Nm kgm | - - |
|  | Adjustment of wheel hub bearings end play | By means of nut Torquing the securing nut |
|  | Rear axle oil | TUTELA W90/M-DA (SAE 80 W 90) |
| | Quantity Litres | 1,85 |
| | Max capacity (GAW) kg | 2600 |

TIGHTENING TORQUES

Figure 2



101961

SECTIONAL VIEW OF 450310 REAR AXLE DIFFERENTIAL


| COMPONENT | | TORQUE | |
|-----------|--|-------------|-------------|
| | | Nm | kgm |
| 1 | Bevel pinion retaining nut | 400 ÷ 500 | 40 ÷ 50 |
| 2 | Screw securing gear housing to ring bevel gear | 89 ÷ 108 | 8.9 ÷ 10.8 |
| 3** | Oil filler plug | 49 ÷ 62 | 4.9 ÷ 6.2 |
| 4 | Screw securing caps to differential housing | 100 ÷ 120 | 10 ÷ 12 |
| 5 | Screw securing gearing inspection cover to the axle housing | 80 ÷ 95 | 8 ÷ 9.5 |
| 6 | Screw securing gearing inspection cover to the axle housing (alternative mounting) | 31.5 ÷ 38.5 | 3.15 ÷ 3.85 |
| - | Oil drainage plug ** | 49 ÷ 62 | 4.9 ÷ 6.2 |

* Apply Loctite 5910 on the housing

** Apply Loctite 577 on the plug thread

*** Apply Loctite 573 on both sides of the gasket


Figure 3



SECTIONAL VIEW OF DIFFERENTIAL 450310

49359

Figure 4









SECTIONAL VIEW OF HUB

87907

| COMPONENT | TORQUE | |
|-----------|-----------|-------------|
| | Nm | kgm |
| 1 | 290 ÷ 349 | 29 ÷ 34.9 |
| 2 | 63 ÷ 76 | 6.3 ÷ 7.6 |
| 3 | 618 ÷ 667 | 61.8 ÷ 66.7 |
| 4 | 69 ÷ 76 | 6.9 ÷ 7.6 |
| 5 | 180 ÷ 220 | 18 ÷ 22 |
| 6 | 85 ÷ 97 | 8.5 ÷ 9.7 |
| 7 | 8 | 0.8 |
| ** | 5 ÷ 7 | 0.5 ÷ 0.7 |

* Spread the surface of the drive shaft - wheel hub union with B-type sealant.

** When assembling the screws securing the timing sensor mounting, apply a few drops of LOCTITE 245 thread-lock onto the thread of the corresponding holes of the bracket welded onto the axle arm.

| TOOLS | |
|-----------------|--|
| TOOL NO. | DESCRIPTION |
| 99305121 |  <p>Hot air drier</p> |
| 99321024 |  <p>Hydraulic trolley for removing and refitting wheels</p> |
| 99322215 |  <p>Driving and steering axle overhaul stand</p> |
| 99341003 |  <p>Single-acting rear axle</p> |
| 99341005 |  <p>Reaction bridge</p> |
| 99341009 |  <p>Pair of retainers</p> |






TOOLS

| TOOL NO. | DESCRIPTION |
|-----------------|---|
| 99341010 | Pair of retainers |
| 99341011 | Pair of retainers |
| 99341015 | Clamp |
| 99345057 | Extractor reaction block |
| 99355087 | 65 mm. diam. box wrench for disassembly - assembly wheel hub locking ring |
| 99370006 | Handle, interchangeable drift |

TOOLS

| TOOL NO. | DESCRIPTION |
|-----------------|--|
| 99370007 | Grip for interchangeable punches |
| 99370286 | Tool for measuring thickness of bevel pinion adjustment rings (to be used with 99395728) |
| 99370317 | Lever and relevant extension bar to retain flanges |
| 99370497 | Tool for assembly of wheel hub |
| 99370498 | Tool for assembly of wheel hub bearing and phonic wheel |
| 99370617 | Axle universal support during removal/installation |


TOOLS

| TOOL NO. | DESCRIPTION | |
|-----------------|--|---|
| 99374091 |  A cylindrical metal punch with a central hole and a slightly wider base. | Punch to fit external races of bearings (diameter 55 + 69 mm use with 99370007) |
| 99374092 |  A cylindrical metal punch with a central hole and a slightly wider base, similar to 99374091 but larger. | Punch to fit external races of bearings (diameter 69 + 91 mm use with 99370007) |
| 99374456 |  A circular metal key with a central hole and a raised outer rim. | Key to fit differential bevel pinion gasket (use with 99370006) |
| 99389819 |  A torque wrench with a handle and a square attachment. | Torque wrench (0 to 10 mm) with 1/4" square attachment |
| 99395728 |  A dial gauge with a circular dial and a support base. | Dial gauge with support to be used with the tools to determine the adjustment thickness of the bevel pinion |

525010 OVERHAULING THE REAR AXLE ASSEMBLY

NOTE The drive shafts, brake disc and calipers, air breather and differential can all be removed and refitted even with the unit mounted on the vehicle.

Figure 5




Before positioning the rear axle assembly on the stand for overhauling, drain oil by loosening rear axle casing plug (2).

Set the entire rear axle assembly on stand 99322215.

NOTE The identification data of the rear axle unit are given on the plate (1) fixed near to the leaf spring attachment support.

525013 Air breather disassembly - assembly


Figure 6



Take out the screws (1) and remove the brake caliper with its brake linings from the mounting.

525030 Wheel hub overhaul


Figure 7



Disconnect the pipe (2) from the support bracket (1). Remove caps (3), take off screws (4), then remove brake caliper (5) from support (6).

NOTE The thread of the screws (4) securing the brake caliper is treated with adhesive. Therefore, they must not be reused, but replaced with new ones every time they are removed.

Figure 8



Remove braking gaskets (1). Remove screws (2), then take support (3) off the rear axle case flange.

NOTE The caliper must not be violently knocked or dropped.


Prevent the rubber caps coming into contact with sharp metal tools.

Do not dirty or wet the rubber caps with mineral grease or oil.

Do not dirty the pads with liquids or grease.

Check the conditions of brake caliper and relating braking shoes as described in brake section.


Figure 9



101967

Take out the screws (1) and remove the drive shaft (2).

Figure 10




44613

Lift up the notch (⇒) of the ring nut (1). Using the wrench 99355087 (2) remove the ring nut (1), take out the washer and extract the wheel hubs (3).

525031 Replacing the wheel hub bearing


Figure 11



101968

In case of a hub equipped with phonic wheel (4), remove the latter by means of extractor made up of rear axle 99341003 (1), brackets 99341010 (2), and reaction axle 99341005 (3). Otherwise, remove the bearing guard ring.


Figure 12



101969

Take out the screws (2) and remove the brake disc (1) from the wheel hub. Check the brake disc as described under the Brakes heading.

Figure 13




44616

The bearing (1) is removed from the wheel hub with the aid of an ordinary punch.

NOTE Bearing (1) driving load is 2100 ÷ 5000 kg.


Figure 14



45164

The new bearing should be mounted in the wheel hub with a press and tool 99370498.


Figure 15



101970

Mount the brake disc (1) on the wheel hub (2) and tighten the fixing screws (3) to the required torque.

Figure 16




44618

If it is necessary to replace the pins of the wheel hub (1), before mounting the new ones, check that the mating surface of the pin head is free from burrs, dross and blisters.

The pins should be driven in by applying a load on their head no greater than 2000 kg.

After driving them home, check that the pins are perfectly in touch with the hub: maximum orthogonal tolerance 0.2 mm.

Figure 17




44619

Stand the bearing of the wheel hub (2) on a special mounting that permits rotation. With a magnetic dial gauge (1) check the off-centring of the brake disc on both sides.

Off-centring must not exceed 0.1 mm.


Figure 18



45165

The phonic wheel (2) should be mounted in the hub with the punch 99370498 (1), checking after assembly that the "phonic" wheel rests perfectly in its seat in the hub.

Figure 19




44620

Check the orthogonality of the phonic wheel (2), proceeding as follows:

Position the feeler of the magnetic dial gauge (1) on the phonic wheel.

Making the wheel hub (3) turn, check that the maximum error of orthogonality of the phonic wheel (2) is no greater than 0.1 mm.

Figure 20




44621

NOTE Check and, if necessary, adjust the clearance between the parking brake drum and shoes as described in the Brakes section.

Mount the inserter 99370497 (2) on the sleeve. Lubricate the sleeve with TUTELA W140/M-DA oil and key the wheel hub (1).


Figure 21



44622

Mount the washer (1) and a new ring nut (2). Using the wrench 99355087 (3), tighten the ring nut (2) to the required torque.
Notch the fixing ring nut (2) on the milling of the axle housing arm.


Figure 22



44623

Mount the support (2) and tighten the fixing screws (1) to the required torque.

Figure 23




44611

Mount the brake linings (1).

NOTE The brake lining with the wear indicator must be mounted from the piston side of the brake caliper.

Figure 24




101971

Fit brake caliper (3) to support (2), then use torque wrench (4) to tighten fastening screws (1) to the torque of 32 to 36 Nm. Having to move the brake caliper piston back, keep to the instructions given in the BRAKES section.

NOTE Mount only new screws (1, Figure 24). Every time they are removed, they must be replaced.


Figure 25



102962

Fit new protection caps (3).
Connect the pipe (2) to the support bracket (1).

Figure 26



44626


Apply IVECO 1905685 sealant on the contact surfaces of the drive shaft (2) with the wheel hub (1).
Mount the drive shaft (2) in the sleeve.
Tighten the screws (3) securing the drive shaft (2) to the hub (1) to the required torque.
After the assembling operation has been completed, fill the rear axle case with TUTELA W90/M - DA oil to the prescribed amount and grade.

526210 REPAIRING THE DIFFERENTIAL

Disassembling the differential unit


NOTE Before repairing the differential it is necessary to drain off the oil and dismantle the drive shafts, as described under the heading of overhauling the wheel hub (operation 525030).

Figure 27




Unscrew the screws (1) with their lock washers and spring washers (if any) and take off the gearing inspection cover (2) with its gasket (if present).

Figure 28



Mark the position of the caps (1 and 2), take out the screws (3) and remove them.

Figure 29




Extract the differential unit (1) from the axle housing.

NOTE Note the assembly position of the adjustment rings (2-4) of the spacers (3-5) and of the external rings (6) of the tapered roller bearings to position them for assembly in the same position. In case of re-utilization, do not reverse the assembling position of tapered-roller bearing external rings (6).


Gear housing removal

Figure 30



Use tool 99341003 (1), brackets 99341009 (2), clamp 99341015 (3) and reaction block 99345057 (4) to remove taper roller bearing inner rings (5 - 7) from gear housing (6).

Figure 31




18222

NOTE Mark cover (1) and gear housing (4).

Loosen screws (2), remove ring bevel gear (3) and gear housing (4) cover (1).


Figure 32



62099

Remove from gear housing (1) the sun gear (2) on cover side including shoulder washer (3).


Figure 33



101974

Take pin (2) out of wheel-case (1), then remove the two planetary gears (3), complete with shoulder washers (4), from the wheel-case.


Figure 34



18226

Take planetary gear (1), complete with shoulder washer, out of the wheel-case.

Figure 35




51824

Raise the securing ring (⇒) on the flange (1) nut (3).

Using tool 99370317 (2), block rotation of the coupling (1).

Remove the nut (3).


Figure 36



51825

Take flange (1) off bevel pinion (2).


Figure 37



51826

Using a bronze punch, strike in the direction shown by the arrow to eject the bevel pinion (1), with the rear bearing, the fixed spacer and adjustment ring from the axle housing (2).


Figure 38



61866

Remove the seal (1) and the internal ring (2) of the front bearing.


Figure 39



51828

Use a punch to remove the external rings (3 - 4) of the tapered roller bearings from the axle housing (1) and take out the adjustment shim (2).

Figure 40



74727

With axle 99341003 (2), brackets 99341011 (1), press 99341015 (5) extract the internal ring (3) on the bevel pinion (4).

Checking the parts comprising the differential

Carefully clean the single components of the differential locking.

Lubricate the bearings and rotate the roller cage freely; rotation must be even and without signs of stiffness. Check the support surfaces of the ring bevel gear and the striking surface of the half-casing so that the ring bevel gear fits perfectly. Deformations of such parts, could determine vibration of the ring bevel gear fastening screws, thus compromising the perfect operation of the unit.

NOTE Carefully clean all the threads in order to obtain exact adjustments and accurate tightening torque.

Check that the splined section for the flange-pinion connection is not badly worn, if it is, replace the pinion.

NOTE If it is necessary to replace the ring bevel gear or pinion, replace both parts since they are supplied in pairs.

Check the planetary gears with their shoulder washers, the pin and the crown wheels with their shoulder washers.

Replace all the sealing elements, the bevel pinion retaining nut and the gear housing bearing adjustment ring nut with new parts.


Assembly

NOTE The tapered roller bearings are supplied as spare parts, lubricated with rustproof oil.

They must not be washed or heated for assembly.

The differential housing support bearings must both be from the same supplier.

Figure 41




101975

DIFFERENTIAL UNIT COMPONENTS

1. Nut - 2. Transmission coupling sleeve - 3. Seal ring - 4. Front bearing - 5. Pinion shim ring - 6. Fixed spacer - 7. Adjuster ring - 8. Rear bearing - 9. Bevel pinion - 10. Bevel ring - 11. Adjuster ring - 12. Fixed ring - 13. Bearing - 14. Gear casing - 15. Crown wheel thrust washer - 16. Crown wheel - 17. Planetary gear thrust washer - 18. Planetary gear - 19. Short pin - 20. Gear casing - 21. Screw.

Assembly of gear housing


Figure 42



18226

Position the crown wheel (1), gear housing side, complete with shoulder washer, into its own housing.


Figure 43



101974

Position the two planetary gears (1), complete with shoulder washers, into the wheel-case, then insert pin (3).


Figure 44



62099

Rotate the planetary gears-crown wheel unit and check that it is free without stiffness.
Fit the other planetary gear (2), complete with shoulder washer (3), into the wheel-case (1).


Figure 45



18237

Assemble the cover and make the marks made during disassembly coincide. Assemble the ring bevel gear and fasten this to the half-casing by means of the fixing screws. By means of a dynamometric wrench (1) tighten the fixing screws (2) to the required tightening torque.


Figure 46



18240

Only for axles with differential lock.
Using tool 99305121, heat thrust ring (1) to a temperature of 120°C ± 150°C for 15' and fit on the gear casing (2) from the side with the differential lock.


Figure 47



Using the punch 99374091 (3) and grip 99370006 (4), mount the external ring (2) of the tapered roller bearing in the axle housing (1).

NOTE New bearings are lubricated with rustproof oil and must therefore not be washed or heated for assembly.

Figure 48




Set adjusting ring (4), removed at disassembling, into rear axle casing (5).

Using the punch 99374092 (2) and grip 99370007 (1), mount the external ring (3) of the tapered roller bearing.


Assembling the bevel pinion assembly

Figure 49




On a surface plate (2), zero a dial gauge (1) set on the mounting 99395728 (3) and pre-load it slightly.

Figure 50



Fit tapered-roller bearing internal ring (2) onto false pinion 99370286 (1) with the washer supplied (3).

Figure 51




Position the dummy pinion 99370286 (1), assembled as shown in Figure 50, on the external ring (2) of the tapered roller bearing.

On the opposite side, fit the taper bearing internal ring (3) on the dummy pinion (1) and the transmission shaft flange (4).

Screw on the nut (5) so that the dummy pinion turns freely with no end float.

Figure 52



51840

Fit the mounting 99395728 (2) with the dial gauge (1) on the dummy pinion 99370286 (3).

Orientate the, previously zeroed, dial gauge so as to position the rod on the lowest portion of the seat of the bearing supporting the gear housing and note the difference **A1**.

Repeat the same operation on the seat of the other bearing and note the difference **A2**.

Thickness **S** to be added to adjusting ring thickness (4, Figure 54) used for measuring, for pinion positioning is obtained by the following formula:

$$S = \frac{A1 + A2}{2} - (\pm B)$$

A1 indicates the value measured on the right-hand seat.

A2 indicates the value measured on the left-hand seat.

B indicates the value marked on the bevel pinion (see Figure 53).


For example:

$$S = \frac{1.05 + 1.10}{2} - (-0.05) = \frac{2.15}{2} + 0.05 = 1.125$$

The result of the formula must be added algebraically to the value of the adjusting ring used to make the measurements. Example:

if the value of the adjusting ring used is 3.00 mm, replace with one measuring 4.125 mm (3.00 + 1.125).

Figure 53




18246

NOTE If the value marked on the pinion is preceded by a positive sign (+), it must be subtracted from the value of the sum divided by two for both seats, whereas it has to be added if it is preceded by a negative sign (-).

Unscrew the retaining nut, the transmission connection flange and remove it and the bearing from the dummy pinion.

Remove the dummy pinion with the mounting 99395728, dial gauge and rear bearing from the axle housing.

Figure 54




51838

If required, replace adjusting ring (4) with a new one having the calculated thickness, after removing bearing outer ring (3) from rear axle casing (5) by beater.

Then fit the new adjusting ring (4) into rear axle casing (5).

Using the punch 99374092 (2) and grip 99370007 (1), mount the external ring (3) of the tapered roller bearing.


Figure 55



18251

Using a suitable punch (1) and a hydraulic press, mount the internal ring (2) of the tapered roller bearing on the bevel pinion (3).


Figure 56



18252

Position the fixed spacer (3) and the adjustment ring (2), used previously to obtain the required rolling torque, on the bevel pinion (1).


Figure 57



62097

Position the axle casing as indicated in the figure. Fit the taper bearing internal ring (1) and the transmission shaft flange (2). Position a suitable pipe (3) on the stand so that the flange (2) and the taper bearing internal ring (1) are correctly supported.

Figure 58




51845

Mount the bevel pinion (1) in the axle housing so as to enter the internal ring (2) of the tapered roller bearing.

Tap on the end of the pinion (1) so that the transmission shaft flange retaining nut (3) can be fitted.

Figure 59




51846

Use tool 99370317 (2) to prevent the flange (1) from rotating.

Tighten the bevel pinion retainer nut to the required torque with a torque wrench (3).

Figure 60



74728

Using the torque wrench 99389819 (1), measure the rolling torque of the bevel pinion.

NOTE The rolling torque must be measured at an ambient temperature of 25°C, making the pinion turn at a speed of 50 rpm after it has made 10 turns.


If the reading differs from the prescribed value, disassemble the pinion (1, Figure 58), replace the adjuster ring (2, Figure 56) with a ring of the correct thickness.

Refit the pinion and repeat the rolling torque check.

Assembly of differential unit

NOTE When fitting the differential unit, carefully comply with the tightening torque values specified, and make use of a torque wrench.

Figure 61




102972

Fit the differential (1) unit and support (6) bearings in the axle casing.

Refit the spacers and adjuster rings in exactly the original positions and in the following order: adjuster ring (2), spacer (3 and 5) and adjuster ring (4).

Figure 62




51849

NOTE Position the caps (2) making the marks made during disassembly coincide.

Screw on the screws (1) and tighten them to the required torque with the dynamometric wrench (3).

Figure 63




74728

Check the total rolling torque with the torque wrench 99389819 (1).

NOTE The rolling torque must be measured at an ambient temperature of 25°C, making the pinion turn at a speed of 50 rpm after it has made 10 turns.

If the value of the measurement is not as required, replace the adjustment rings (2 and 4, Figure 61) with another one of a suitable thickness.

Figure 64



Position the dial gauge 99395684 (1) with a magnetic base and measure the clearance between the pinion and crown wheel on four opposite teeth of the crown wheel (2).

The average of the measurements must equal the required value.

If a different clearance is found, remove the caps (3) again and swap over the assembly position of the adjustment rings (2 and 4, Figure 61).

If this is not sufficient, replace the adjustment rings with ones of a different thickness, but the total thickness must still be the same as that of the adjustment rings removed.


This is so as not to change the total rolling torque.

Apply a thin layer of Prussian blue on ring gear teeth by brush.

Turn the pinion and measure the impression of the contact of the pinion tooting on the crown wheel tooting.

Here we illustrate the possible contacts with the corrections to obtain precise coupling of the crown wheel and pinion.


Figure 65



A = Coupling depth
 B = Crest
 C = Side
 D = Play


E = Greater base
 F = Heel
 G = Top land
 H = Contact surface
 I = Lateral surface

Figure 66



Correct contact


Figure 67



Excessive contact on tooth bottom or flank.

Move away pinion and put ring gear to pinion to adjust clearance.



Figure 68



Excessive contact on heel of tooth.

Move the ring bevel gear towards the pinion and then move the pinion away from the ring bevel gear to adjust clearance.

Figure 69





Excessive contact in the upper part or crest of the tooth.

Move the pinion towards the ring bevel gear and then move the ring bevel gear away from the pinion to adjust clearance.

44607

Figure 70




Excessive contact on the top land of the tooth.

Move the ring bevel gear away from the pinion then move the pinion towards the ring bevel gear to adjust clearance.

44608

Figure 71




51851

After having determined the prescribed coupling clearance, tool 99370317 (2) prevents the flange (1) from rotating.

Unscrew the retaining nut and extract the flange (1) from the bevel pinion.

Figure 72




51852

Lubricate the internal lip of the seal (1).

With the key 99374456 (2) and grip 99370006 (3), mount the seal in the axle housing.

Figure 73




51846

Mount the coupling (1) and with the tool 99370317 (2) block its rotation with the torque wrench (3).

Tighten the bevel pinion retaining nut to the required torque.


Figure 74



51853

Deform the collar of the nut (1) as shown in the figure at the milling of the bevel pinion (2).

Figure 75



51854

Thoroughly clean the flange of the axle housing.

Apply LOCTITE 5910 sealant on the flange of the axle housing to form a bead of approx. 5 mm diameter.

It must be uniform (no lumps), without any air bubbles, thin areas or gaps.

Any flaws must be corrected in as short a time as possible.

Avoid using too much material to seal the joint.


Too much sealant would tend to come out on both sides of the joint.

After applying the sealant, the joints need to be assembled immediately (10 - 20 minutes).

To seal at a later date, there is product 21623 capable of softening or liquefying the above-mentioned sealant.

It is essential to clean the surface to be sealed in order to achieve good future sealing.

Figure 76




51855

Mount the cover (1) and screw on the screws (2).

- Flanged screws (for solution without gasket).
- Screws with washer (for solution with gasket).

Figure 77



62098

Following the order shown in the figure, tighten the screws to the torque of:

- flanged screws (for solution without gasket) 80 ÷ 95 Nm;
- screws with washer (for solution with gasket) 31.5 ÷ 38.5 Nm.

Complete assembly taking the following precautions:

Mount the drive shafts as described under the heading: "525030 overhauling hubs".

Apply LOCTITE 577 thread-locking oil on the oil drain plug thread, screw it into the axle housing, tightening it to the required torque.

Add lubricating oil in the required quantity and grade through the hole.

Apply LOCTITE 577 thread-locking oil on the inspection plug thread, screw it into the axle housing, tightening it to the required torque.

Take the assembly off the stand.

NOTE The assembly should be put back on its mounting to prevent the dust guards and/or brake discs from getting damaged.

SECTION 7

5206 Axles

Page


This section contains:

| | |
|----------------------|----|
| DIAGNOSTICS | 3 |
| AXLE 5817 | 7 |
| AXLE 5818 | 21 |
| AXLE 5819 | 29 |
| AXLE 5823 | 37 |
| WHEEL GEOMETRY | 49 |

DIAGNOSTICS


Front axle main working faults:

- 1 - Stiff steering;
- 2 - Wobble;
- 3 - Noise.



2

WOBBLE



Irregular wheel camber.

- YES →

Check the tie rod assembly, adjust or repair the deformed parts.

NO



Front wheels not aligned.

- YES →

Align front wheels.

NO



Irregular wheel toe-in.

- YES →

Correctly adjust toe-in.

NO



Steering gear tie rod king-pins inefficient.

- YES →

Replace defective parts.

NO



Irregular play of wheel hub bearings.

- YES →

Replace the wheel hubs.

NO



Eccentric wheels:
eccentric, deformed rim
tyre assembled on wrong rim.

- YES →

Replace the wrong rim.
Deflate and centre the tyre on the rim.


NO



Unbalanced wheels.

- YES →

Balance the wheels.



Axle 5817

| | Page |
|--|------|
| DESCRIPTION | 9 |
| SPECIFICATIONS AND DATA | 10 |
| TIGHTENING TORQUES | 11 |
| TOOLS | 12 |
| REMOVING AND REFITTING AXLE 5817 | 13 |
| <input type="checkbox"/> Removal | 13 |
| <input type="checkbox"/> Refitting | 13 |
| REPAIRS | 15 |
| OVERHAULING AXLE 5817 | 15 |
| <input type="checkbox"/> Wheel hub removal and refitting | 15 |
| <input type="checkbox"/> Removal | 15 |
| <input type="checkbox"/> Replacing phonic wheel | 16 |
| <input type="checkbox"/> Refitting | 16 |
| STUB AXLE REMOVAL-REFITTING | 17 |
| <input type="checkbox"/> Removal | 17 |
| <input type="checkbox"/> Refitting | 19 |

DESCRIPTION

The front axle 5817 is composed of a load-bearing cross member on which are mounted the suspensions and power steering.


The stub axles turn, by means of swivel heads, on the ends of the suspensions.

The steering levers are cast on the king-pin of the stub axles to which are secured the brake calipers.

The wheel hubs are supported on the pins of the stub axles by UNIT - BEARINGS that need neither lubrication nor adjustment.










The wheel rims are secured onto the wheel hubs by five screws.

Figure 1




52247

SPECIFICATIONS AND DATA

| | | |
|---|--|--|
|  | Axle type | 5817 |
|  | WHEEL HUBS | |
|  | Wheel hubs bearings | UNIT BEARING |
|  | Hub bearings end play | - |
|  | Wheel hub bearings play adjustment | Not Adjustable Fixing nut torque tightening |
|  | WHEEL GEOMETRY | |
|  | Wheel camber angle (vehicle at static load) | 0° ± 20' |
|  | Wheel caster angle (vehicle at static load) | 3° ± 20' |
|  | Wheel toe-in (vehicle at static load) | 2 ± 1 mm |

TIGHTENING TORQUES

Figure 2



49355

AXLE 5817

| PART | TORQUE | |
|------|-----------|-------------|
| | Nm | kgm |
| 1 | 170 ÷ 196 | 17 ÷ 19.6 |
| 2 | 19.5 ÷ 24 | 1.9 ÷ 2.4 |
| 3 | 256 ÷ 314 | 25.6 ÷ 31.4 |
| 4 | 160 | 16 |
| 5 | 6 ÷ 7.5 | 0.6 ÷ 0.7 |
| - | 176 ÷ 217 | 17.6 ÷ 21.7 |

TOOLS

| TOOL NO. | DESCRIPTION |
|-----------------|---|
| 99305354 | Portable optical reading tool for checking wheel trim |
| 99306010 | Apparatus to purge air from brakes and clutch |
| 99321024 | Hydraulic trolley for removing/refitting wheels |
| 99322215 | Guide to wheel hub assembly |
| 99347074 | Puller for steering tie rod king-pins |

REMOVING AND REFITTING AXLE 5817**Removal**

Set the vehicle on solid, level ground.

Lock the rear wheels with scotches, remove the wheel rim guards and loosen the screws or nuts fixing the wheel.

Lift the front of the vehicle and rest the chassis frame on supports.

Take out the screws or nuts fixing the wheel and remove them with tool 99321024.

From underneath the vehicle:

- remove the central guard (15) under the engine by taking out the screws securing it to the side guards and to the front cross member of the chassis frame;
- remove the engine side guards (6) and (19) by taking out the screws securing them to the chassis frame;
- remove the gearbox side guards (5) and (20) by taking out the screws securing them to the chassis frame and the nuts securing them to the cross member under the gearbox (23);
- disconnect the brake fluid pipe (21) from the retaining blocks on the axle (22);
- drain off the power-steering fluid and disconnect the pipes (11) and (12) in correspondence with the fittings on the hydraulic power steering (13);
- disconnect the power steering column in correspondence with the coupling (14).

If it is decided to leave the brake callipers on the axle, proceed to:

- disconnect the electrical connection (1) signalling brake lining wear and the ABS sensor (4) if there is one;
- disconnect the brake fluid pipes in correspondence with the fittings (7) and (18) after draining the system.

If it is decided to leave the brake callipers on the vehicle, proceed to:

- disconnect the brake fluid pipes from the axle (22) in correspondence with the brackets (8, 10, 16, 17);
- then disconnect the brake callipers (3) from their respective stub axles by taking out the screws (2) and supporting the callipers to prevent any strain on the pipes.

To complete removing the axle:

- unscrew five of the six fixing screws (9) on both sides of the chassis frame;
- put a hydraulic lift under the axle and take out the last two screws;
- lower the hydraulic jack and extract the axle.

Refitting

Reverse the steps described for removal tightening the screws or nuts to the prescribed torque.



Adjust the load of the torsion bar as illustrated under the specific heading.


Top up the power-steering fluid.

If the brake callipers have been left on the axle, restore the brake fluid level and bleed off any air.

Check and adjust the front wheel geometry.

Figure 3




REPAIRS**520610 OVERHAULING AXLE 5817****Figure 4**

Remove the wheel rim cup.

Free the screws (1) securing the wheel rim.


Lift the vehicle and put the stands (2) under the structural members in a forward position.

Unscrew the screws (1) and remove the entire wheel.

520620 Wheel hub removal and refitting**Removal****Figure 5**

Take out the screws (1) and remove the mounting with the brake caliper (2) from the stub axle.


Support the brake caliper suitably to prevent strain on the oil pipe.

Figure 6

Remove the two centring pins (2) and detach the brake disc (1) from the wheel hub (4).


Remove the cup (3) from the wheel hub (4).

NOTE Check the state of the brake disc and linings as described in the BRAKE SYSTEM section.

Figure 7

Lift the deformation (⇒) of the nut (1) and unscrew this with a suitable wrench.

Figure 8




Extract the wheel hub (1) from the pin of the stub axle (2).

NOTE If any trouble is found with the wheel hub or bearing, the assembly needs to be replaced since the parts are not supplied as single spares.

When repairing the wheel hub (1), take care not to damage the phonic wheel (3).

526712 Replacing phonic wheel

Figure 9



The phonic wheel (2) is extracted from the wheel hub (1) with general tools: minimum extraction load 300 kg.


The phonic wheel should be mounted on the wheel hub after heating it to a temperature of 150°C.

On completing assembly, make sure the phonic wheel sits in its seat in the hub properly.

Check that the orthogonality and oscillation of the phonic wheel is no greater than 0.3 mm.

Refitting


Figure 10



Lubricate the surface of the stub axle pin (2) with TUTELA MR3 grease and key the wheel hub (1).

NOTE The wheel hub must be keyed without forcing.. If there are difficulties, do not assemble since the bearing may be damaged. Extract the wheel hub, check the cause of the difficulties and eliminate them.


Figure 11



After keying the hub (1), position the washer (2) and screw on the nut (3).

Tighten the nut (3) to the required torque with the Allen wrench (4).


Figure 12



52255

Deform the collar of the nut (1) by the milling (⇒) of the pin (2).

Figure 13




52250

Mount the cup (3) in the wheel hub (4).

Mount the brake disc (1) and secure it to the wheel hub (4) with the two centring pins (2).

Figure 14



52257


Rest the brake caliper (2) with the brake linings on the stub axle (1).

NOTE The brake lining with its wear indicator must be mounted from the piston side of the brake caliper.

If it is necessary to move the brake caliper piston back, use tool 99372236, taking the precautions given in the BRAKES section.

Tighten brake calliper (2) fixing screws to the prescribed torque.

Figure 15



62101


Fit the wheel on the brake plate as shown in the figure and tighten wheel fixing screws to the prescribed torque.

Fit wheel rim cup.

522820 STUB AXLE REMOVAL-REFITTING

Removal

Figure 16




61672

Remove the wheel hubs as described under the relevant heading (operation 520620).

Remove nut (1) and withdraw crankpin (2) from stabiliser bar (3).

Figure 17




52259

Remove screws (5) and remove protection (4) from stub axle (6).

Remove nut (2) fixing kingpin (1) to lever (3).

NOTE Fit the proper setscrew wrench into kingpin (1) to stop its rotation, if required.


Figure 18



52260

Using the extractor 99347074 (1), remove the pin (2) of the swivel head from the steering lever of the stub axle (3).

Figure 19




61670

With the hydraulic jack under the bottom suspension arm (3) oppose the action of the transverse leaf spring.

Remove the nuts (2 - 6) securing the swivel head pin (1 - 5) to the stub axle (4).

NOTE To block rotation of the swivel head pins (1 - 5), insert a suitable Allen wrench into the hexagon sunk into them.

Figure 20




61669

Using the extractor 99347074 (2), remove the link pins (1 - 3) of the stub axle (4) and put this aside.

Refitting

Figure 21




Insert the pins of the swivel heads (1 - 2) of the top and bottom suspension arms into the seats of the stub axle (3). Then screw on the self-locking nuts (5) and lock them at the required torque.

NOTE Once removed, self-locking nuts (5) must not be reused.

To block rotation of the swivel head pins (1 - 2), insert a suitable Allen wrench (4) into the hexagon sunk into them.

Figure 22



Connect the pin of the swivel head (1) of the power steering tie to the lever (3) of the stub axle (6) and tighten the fixing nut (2) to the required torque.


NOTE Once removed, self-locking nuts (2) must not be reused.

To block rotation of the swivel head pin (1), insert a suitable Allen wrench into the hexagon sunk into them.

Mount the guard (4) on the stub axle and secure it, tightening the screws (5) to the required torque.

Refit the wheel hub as described in the relevant chapter (operation 520620).

Figure 23



Connect stabiliser bar (3) to crankpin (2), screw new nut (1) and tighten it to the prescribed torque.










Axle 5818

| | Page |
|---|------|
| DESCRIPTION | 23 |
| SPECIFICATION AND DATA | 23 |
| TIGHTENING TORQUES | 24 |
| TOOLS | 25 |
| OVERHAULING AXLE 5818 | 26 |
| <input type="checkbox"/> Replacing phonic wheel | 26 |
| <input type="checkbox"/> Refitting | 27 |
| STUB AXLE REMOVAL AND REFITTING | 27 |

DESCRIPTION


Axle 5818 differs from axle 5817 for wheel hub, brake disc and wheel rim fixing to brake disc that is implemented by nut studs without stabiliser bar.

SPECIFICATION AND DATA

| | | |
|---|--|--|
|  | Axle type | 5818 |
|  | WHEEL HUBS | |
|  | Wheel hubs bearings | UNIT BEARING |
|  | Hub bearings end play | - |
|  | Wheel hub bearings play adjustment | Not Adjustable Fixing nut torque tightening |
|  | WHEEL GEOMETRY | |
|  | Wheel camber angle (vehicle at static load) | $0^\circ \pm 20'$ |
|  | Wheel caster angle (vehicle at static load) | $3^\circ \pm 20'$ |
|  | Wheel toe-in (vehicle at static load) | $2 \pm 1 \text{ mm}$ |

TIGHTENING TORQUES

Figure 1



FRONT AXLE 5818


49354

| PART | TORQUE | |
|------|--------------|-------------|
| | Nm | kgm |
| 1 | 170 ÷ 196 | 17 ÷ 19.6 |
| 2 | 257 ÷ 314 | 25.7 ÷ 31.4 |
| 3 | 20 ÷ 24 | 2 ÷ 2.4 |
| 4 | 98.1 ÷ 107.9 | 9.8 ÷ 10.7 |
| 5 | 284 ÷ 342 | 28.4 ÷ 34.2 |
| 6 | 6 ÷ 7.5 | 0.6 ÷ 0.7 |
| 7 | 85 ÷ 104 | 8.5 ÷ 10.4 |
| — | 154 ÷ 170 | 15.4 ÷ 17 |


TOOLS

TOOL NO.


DESCRIPTION

99305354


Portable optical reading tool for checking wheel trim

99306010


Apparatus to purge air from brakes and clutch

99321024


Hydraulic trolley for removing/refitting wheels

99322215

Guide to wheel hub assembly

99347074

Puller for steering tie rod king-pins

99370496

Wheel hub fitting guide


520610 OVERHAULING AXLE 5818

The overhauling operation different from the ones concerning the axle 5817 are described below.

To remove and refit axle 5818, proceed in a similar manner as for axle 5817.

Adjustment values, tightening torque values and equipment are those specified in this chapter.

Figure 2



19603


Free the screws (1) securing the wheel rim.

Lift the vehicle and put the stands (3) under the structural members in a forward position.

Unscrew the nuts (1), take off the protection (2) and remove the entire wheel.

Remove the mounting with the brake caliper as described for axle 5817.

Figure 3




52264

Take out the screws (2), take off the cover (1) and remove the brake disc (3) from the wheel hub (4).

NOTE Check the state of the brake disc, wheel pins and linings as described in the BRAKE SYSTEM section.

Figure 4



52265

Loosen the screw (3).

With the socket wrench (4), remove the nut (2) securing the wheel hub (1) to the pin of the stub axle.


Extract the wheel hub (1) from the pin of the stub axle.

NOTE If any trouble is found with the wheel hub or bearing, the assembly needs to be replaced since the parts are not supplied as single spares.

When putting aside the wheel hub, take care not to damage the phonic wheel.

526712 Replacing phonic wheel

Figure 5



44647

The phonic wheel (2) should be extracted from the wheel hub (1) with general tools.


The phonic wheel should be mounted on the wheel hub after heating it to a temperature of 150°C.

On completing assembly, make sure the "phonic" wheel sits in its seat in the hub properly and is positioned at the distance shown in the figure.

Check the oscillation of the phonic wheel (2). Tolerance must be no greater than 0.1 mm.

Refitting


Figure 6



52266

Assemble the tool 99370496 (2) on the stub axle pin, lubricate the external surface of the tool (2) using TUTELA MR3 grease and assemble the wheel hub (1).

Figure 7




52267

NOTE The wheel hub must be keyed without forcing. If there are difficulties, do not assemble since the bearing may be damaged. Extract the wheel hub, check the cause of the difficulties and eliminate them.

When the wheel hub has been keyed (1), position the washer, screw the nut (2) and using the socket wrench (4) tighten the nut (2) to the prescribed torque.

Tighten the check screw (3) of the nut to the prescribed torque.

Figure 8




52268

Assemble the brake drum (1) on the wheel hub. Position the cover (2), lock the wheel hub rotation with the lever (3) and tighten the fixing screws to the prescribed torque.

Using a magnetic dial gauge, check the eccentricity of the brake disc: it must not exceed 0.125 mm.

Refit the mounting with the brake caliper to the stub axle, tightening the fixing screws to the required torque.

Figure 9



Assemble:

- the wheel on the brake drum;
- the nut protection and screw the fixing nuts.

Tighten the nuts fixing the wheel to the prescribed torque according to the diagram shown in figure.

522820 STUB AXLE REMOVAL AND REFITTING

Perform stub axle removal and refitting as described for axle 5817, without considering the points concerning the stabiliser bar since the latter is lacking on axle 5818.

Axle 5819

| | Page |
|--|------|
| DESCRIPTION | 31 |
| SPECIFICATION AND DATA | 32 |
| TIGHTENING TORQUES | 33 |
| TOOLS | 34 |
| REPAIR OPERATIONS | 36 |
| AXLE 5819 OVERHAUL | 36 |
| <input type="checkbox"/> Stub axle removal and refitting | 36 |
| <input type="checkbox"/> Removal | 36 |
| <input type="checkbox"/> Refitting | 36 |

DESCRIPTION

The front axle 5819 has independent wheels.

It is basically composed of:

- stub axles;
- wheel hubs;
- suspension arms.


The stub axles are also the end elements of the suspension.

They are connected to the top and bottom suspension arms by swivel heads that allow turning the stub axle.

The brake calipers and steering levers are secured on the king-pin of the stub axles.










The hubs are supported on the stub axle pins by Unit-Bearings, which need no adjustment or lubrication.

Figure 1




30772

SPECIFICATION AND DATA

| | | |
|---|--|--|
|  | Axle type | 5819 |
|  | WHEEL HUBS | |
|  | Wheel hubs bearings | UNIT BEARING |
|  | Hub bearings end play | - |
|  | Wheel hub bearings play adjustment | Not Adjustable Fixing nut torque tightening |
|  | WHEEL GEOMETRY | |
|  | Wheel camber angle (vehicle at static load) | 0° 30' ± 20' |
|  | Wheel caster angle (vehicle at static load) | 1° 35' ± 20' |
|  | Wheel toe-in (vehicle at static load) | 2.5 ± 1 |

TIGHTENING TORQUES

Figure 2









52256

FRONT AXLE 5819

| PART | TORQUE | |
|------|---------------|-------------|
| | Nm | kgm |
| 1 | 154 ÷ 170 | 15.4 ÷ 17 |
| 2 | 15 ÷ 22 | 1.5 ÷ 2.2 |
| 3 | 154 ÷ 170 | 15.4 ÷ 17 |
| 4 | 85 ÷ 104 | 8.5 ÷ 10.4 |
| 5 | 94 ÷ 115 | 9.4 ÷ 11.5 |
| 6 | 257 ÷ 314 | 25.7 ÷ 31.4 |
| 7 | 20 ÷ 24 | 2 ÷ 2.4 |
| 8 | 284.5 ÷ 343.3 | 28.4 ÷ 34.3 |

TOOLS


| TOOL NO. | DESCRIPTION |
|---|---|
| 99305354  | Portable optical reading tool for checking wheel trim |
| 99306010  | Apparatus to purge air from brakes and clutch |
| 99321024  | Hydraulic trolley for removing/refitting wheels |
| 99322215  | Driving and steering axle overhaul stand |
| 99347074  | Tool for extracting steering tie rod king-pins |
| 99357144  | Wrench for spindle pin ring nut |

TOOLS

TOOL NO.

DESCRIPTION

99370496



Tool for wheel hub assembly

REPAIR OPERATIONS

520610 AXLE 5819 OVERHAUL

The following paragraphs describe the overhaul operations that differ from axle 5818 operations.


To remove and refit axle 5819, proceed in a similar manner as for axle 5823.

Adjustment values, tightening torque values and equipment are those specified in this chapter.

520611 Stub axle removal and refitting

Removal

Figure 3



19026


Remove wheel hub as described in the relevant chapter (operation 520620) concerning axle 5817.

Remove from stub axle (5):

- dust cover (2) by loosening screw (7);
- steering lever (3) by loosening screw (8);

Loosen kingpin (1 and 6) fixing nuts from stub axle (5).

Figure 4




19027

Use tool 99347074 (3) to remove kingpin (1) from stub axle (2) then remove the latter.

Refitting

Figure 5



19028

Set upper and lower lever kingpins (6 and 8) into stub axle seat (4) then tighten self-locking nuts (1 and 5) to the prescribed torque.

Refit steering lever (3) on stub axle by tightening the relevant fixing screw and nut (7) to the prescribed torque.

Refit dust cover (2) to stub axle by means of the proper screws indicated with arrows.

NOTE Self-locking nuts (1 and 5) cannot be reused after removing.

Refit wheel hub as described in the relevant chapter (operation 520620) concerning axle 5818.

5206 Axle 5823

| | Page |
|--|------|
| DESCRIPTION | 39 |
| SPECIFICATION AND DATA | 40 |
| TIGHTENING TORQUES | 41 |
| TOOLS | 42 |
| REMOVING AND REFITTING AXLE 5823 | 43 |
| <input type="checkbox"/> Removal | 43 |
| <input type="checkbox"/> Refitting | 44 |
| AXLE 5823 OVERHAUL | 45 |
| <input type="checkbox"/> Wheel hub removal and refitting | 45 |
| <input type="checkbox"/> Removal | 45 |
| <input type="checkbox"/> Replacing phonic wheel | 46 |
| <input type="checkbox"/> Re-fitting | 46 |

DESCRIPTION

The front axle 5823 has independent wheels.

It is basically composed of:

- stub axles;
- wheel hubs;
- suspension arms.


The stub axles are also the end elements of the suspension.

They are connected to the top and bottom suspension arms by swivel heads that allow turning the stub axle.

The brake calipers and steering levers are secured on the king-pin of the stub axles.










The hubs are supported on the stub axle pins by Unit-Bearings, which need no adjustment or lubrication.

Figure 1




62909

SPECIFICATION AND DATA

| | | |
|---|--|--|
|  | Axle type | 5823 |
|  | <p align="center">WHEEL HUBS</p> | |
|  | Wheel hubs bearings | UNIT BEARING |
|  | Hub bearings end play | 0.11 ± 0.14 |
|  | Wheel hub bearings play adjustment | Not Adjustable Fixing nut torque tightening |
|  | <p align="center">WHEEL GEOMETRY</p> | |
|  | Wheel camber angle (vehicle at static load) | $1^\circ \pm 20'$ |
|  | Wheel caster angle (vehicle at static load) | $2^\circ 30' \pm 20'$ |
|  | Wheel toe-in (vehicle at static load) | $2.5 \pm 1 \text{ mm}$ |

TIGHTENING TORQUES

Figure 2



FRONT AXLE 5823


74742

| COMPONENT | TORQUE | |
|-----------|---------------|-------------|
| | Nm | kgm |
| 1 | 176 ÷ 217 | 17.6 ÷ 21.7 |
| 2 | 6 ÷ 7.5 | 0.6 ÷ 0.7 |
| 3 | 52 ÷ 64 | 5.2 ÷ 6.4 |
| 4 | 284.5 ÷ 343.3 | 28.4 ÷ 34.3 |
| 5 | 98 ÷ 108 | 9.8 ÷ 10.8 |
| 6 | 363 ÷ 441 | 36.3 ÷ 44.1 |
| 7 | 19.6 ÷ 23.5 | 1.9 ÷ 2.3 |
| 8 | 98 ÷ 108 | 9.8 ÷ 10.8 |


TOOLS

TOOL No.


DESCRIPTION

99305354


Portable optical reading tool for checking wheel trim

99321024


Hydraulic truck for removing - refitting operations

99322215

Stand to overhaul axles

99347074

Tool to remove drag link joints and wishbones

99370713

Guide to wheel hub assembly

REMOVING AND REFITTING AXLE 5823**Removal**

Set the vehicle on solid, level ground.

Lock the rear wheels with scotches, remove the wheel rim guards and loosen the screws or nuts fixing the wheel.

Lift the front of the vehicle and rest the chassis frame on supports.

Take out the screws or nuts fixing the wheel and remove them with tool 99321024.

Remove the front right and left mudguard (1).

Remove the right and left mudguards under the bumpers (17).

To help remove the front suspension mounting (2), free the top screw stay (14) in correspondence with the screw (15) fixing to the suspension arm (13).

Remove the front suspension mounting (2) by taking out the chassis frame fasteners (16).

Fit the top screw stay (14) back onto the suspension arm (13).

The same steps must be performed on both left and right.

Adjust the load on the right and left torsion bars (9).

Undo the nut (11) and unscrew the threaded pin (12) until the torsion bar (9) is entirely "discharged".


Remove the fasteners (10) fixing the mounting (8) to the chassis frame.

Extract the mounting (8) from the torsion bar (9).

If it is decided to leave the brake callipers on the axle, proceed to:

- disconnect the electrical connection (3) signalling brake lining wear and the ABS sensor (5) if there is one;
- disconnect the brake fluid pipes in correspondence with the fittings (7) after draining the system;
- if it is decided to leave the brake callipers on the vehicle, proceed to:
- disconnect the brake callipers (4) from their respective stub axles by taking out the screws (6) and supporting the callipers to prevent any strain on the pipes.

Figure 3



From underneath the vehicle:

- remove the central guard (7) under the engine by taking out the screws securing it to the side guards (8) and to the front cross member of the chassis frame;
- remove the right and left side guards (8) of the engine by taking out the screws securing them to the chassis frame;
- remove the right and left side guards (9) of the gearbox by taking out the screws securing them to the axle (11) and to the cross member (12) under the gearbox;
- disconnect the brake fluid pipe (10) from the retaining blocks on the axle;
- drain off the power-steering fluid and disconnect the pipes (4) and (5);
- disconnect the power steering column (3) in correspondence with the coupling (6);
- place the removal bracket on the hydraulic jack and put it all under the axle;
- undo the chassis frame bottom fixing screws (2) and the top fixing nuts (1);
- lower the hydraulic jack and extract the axle (11).

Refitting

Reverse the steps described for removal tightening the screws or nuts to the prescribed torque.



Adjust the load of the torsion bar as illustrated under the specific heading.

Top up the power-steering fluid.

If the brake callipers have been left on the axle, restore the brake fluid level and bleed off any air.

Check and adjust the front wheel geometry.


Figure 4



520610 AXLE 5823 OVERHAUL

Overhaul operations described in this sections are those differing from axle 5817.

Figure 5



62911

Loosen wheel rim fastening nuts (1).


Lift the vehicle and set the supporting stands under the side members in forward position.

Loosen nuts (1), remove protection (2) and remove the entire wheel.

520620 Wheel hub removal and refitting

Removal

Figure 6




62912

Remove the screws (1) and remove the support including the brake calliper (2) from the stub axle.



Suitably support the brake calliper to prevent oil pipe tensioning.

Figure 7




62913

Stop wheel hub (1) rotation.

Remove the screws (2) and remove the cover (3).


Figure 8



62914

Remove the screws (2) and remove wheel hub (1) from hub (3).

Figure 9




62915

Remove the brake disc (1) from the wheel hub (2).

NOTE Check brake disc and lining conditions as described in the BRAKE SYSTEM section.

Figure 10



Loosen the screw (3).

With the socket wrench (4), remove the nut (2) securing the wheel hub (1) to the pin of the stub axle.


Extract the wheel hub (1) from the pin of the stub axle.

NOTE If any trouble is found with the wheel hub or bearing, the assembly needs to be replaced since the parts are not supplied as single spares.

When repairing the wheel hub (1), take care not to damage the phonic wheel (3).

526712 Replacing phonic wheel

Figure 11



The possible extraction of the phonic wheel (2) from the wheel hub (1) is made using normal tools.


The phonic wheel must be heated up to a temperature of 150°C before the assembly on the wheel hub.

When the assembly is ended, make sure that the “phonic” wheel perfectly rests on the hub housing and that is positioned at the dimension shown in figure.

Check that the orthogonality and oscillation of the phonic (2) wheel is no greater than 0.1 mm.


Re-fitting

Figure 12



Screw tool 99370496 (2) on kingpin (1), grease tool external surface (2) with Tutela MR3.

Figure 13




Refit the wheel hub (1).

NOTE The wheel hub must be keyed without forcing. If there are difficulties, do not assemble since the bearing may be damaged. Extract the wheel hub, check the cause of the difficulties and eliminate them.

When the wheel hub has been keyed (1), position the washer, screw the nut (2) and using the socket wrench (4) tighten the nut (2) to the prescribed torque. Tighten the check screw (3) of the nut to the prescribed torque.


Figure 14



62915

Fit brake disc (1) on wheel hub (2).

Figure 15



62921

Fit flange (1) on wheel hub. Stop wheel hub rotation using the proper lever (3) and tighten the fastening screws (2) to the specified torque.

Use the gauge with magnetic base to check brake disc mismatching: it must be lower than 0.125 mm.


Wheel stud replacement

Replace wheel studs if found damaged by removing them from the wheel hub.

Smear new stud threads with Loctite 270 and tighten to the specified torque.

Once refitting is over, check stud squareness, max. error is 0.2 mm.


Figure 16



52268

Refit cover (1). Stop wheel hub rotation using the proper lever (3) and tighten the fastening screws (1) to the specified torque.

Figure 17



62912


Rest brake calliper (2) and brake linings on stub axle (1).

NOTE The brake lining with the wear sensor shall be fitted on brake calliper piston side.

Comply with BRAKE section requirements to move back the brake calliper piston using tool 99372236.

Tighten brake calliper (2) fastening screws (1) to the specified torque.

Figure 18



89007

Fit the wheel on the flange and tighten the fastening screws to the specified torque according to the sequence shown in the figure.

Refit wheel rim cap.

Wheel geometry

| | Page |
|---|------|
| DESCRIPTION | 51 |
| WHEEL GEOMETRY | 53 |
| SPECIFICATIONS AND DATA | 53 |
| TIGHTENING TORQUES | 53 |
| TOOLS | 54 |
| CHECKING CHARACTERISTIC ANGLES | 55 |
| <input type="checkbox"/> Positioning jaws and projectors | 55 |
| <input type="checkbox"/> Electronic balancing of rim eccentricity | 56 |
| <input type="checkbox"/> Wheel alignment | 56 |
| <input type="checkbox"/> Checking toe-in | 57 |
| <input type="checkbox"/> Front wheel deviation test (vehicle wheelbase check) | 57 |
| <input type="checkbox"/> Checking camber | 58 |
| <input type="checkbox"/> Checking king-pin angle and caster angle | 58 |
| <input type="checkbox"/> Checking steering angles | 59 |
| <input type="checkbox"/> Checking rear axle alignment | 59 |
| <input type="checkbox"/> Calculating thickness of spacers to be fitted between tie rod mountings and chassis side members (with the exception of vehicles equipped with 5-mm thick chassis or with transverse leaf-spring suspension) | 60 |

DESCRIPTION


In order to have a good vehicle ground holding, a low consumption of tyre and to enable the driving wheels to return to straight running after steering, the front wheels are adjusted at defined assembly angles:

- wheel camber angle;
- king-pin camber angle;
- caster angle;
- wheel toe-in.

These angles, accurately calculated, enable the correct balancing of the forces created when the vehicle is moving, in the different load conditions, tending to change the position of the wheels on the ground.

Wheel camber angle

Figure 1




32956

The camber angle (α) is the angle formed by the axis passing through the wheel centre line and the vertical to the ground, looking at the vehicle from the front.

The camber angle is positive (A) when the upper part of the wheel tends toward the outside; it is negative (B) when the wheel upper part tend toward the inside.

Camber angle

Figure 2



32957

The king-pin camber angle (β) is the angle formed by the axis passing through the king-pin and the vertical to the ground, looking at the vehicle from the front.


When the projection of the king-pin axis is near to the contact point of the wheel with the ground (opposite tendency to the wheel camber) the angle is positive, it is difficult to say that it is impossible to have the king-pin camber angle negative.

The wheel camber angle (α) and the king-pin camber angle (β) enable wheel axis and the king-pin axis to come nearer as much as possible to the contact centre of the tyre on the ground.

In this way, reduced tyre wear and lower steering torque are obtained.

Caster angle

Figure 3



32958


The caster angle (γ) is the angle formed by the king-pin axis with the vertical to the ground, looking at the vehicle from one side.

If the projection formed by the king-pin axis falls in front of the wheel contact point with the ground, in the direction of travel of the vehicle, the caster angle is by convention positive (A); it is negative (B) if it falls behind the wheel contact point with the ground; it is equal to zero if it is perfectly vertical to the contact point.

This angle makes it possible to keep the front wheels straight when the vehicle is running straight and allows the wheels to return spontaneously to running straight from the position taken in the bend, as soon as the steering wheel is released by the driver.

Wheel toe-in

Figure 4




32359

The wheel toe-in results from the difference between the distances A and B (value expressed in mm) measured on the horizontal axis of the rims, looking at the vehicle from the top. In this way a light drive and a low tyre consumption is obtained.

The toe-in is positive if B is higher than A.


Figure 5



32960

The toe-in is negative if B is lower than A.







Figure 6



32961

The toe-in is equal to zero if B is equal to A.

WHEEL GEOMETRY SPECIFICATIONS AND DATA

| | MODELS | | | |
|--|--|--------|------------------------------|--------------------------------|
| | 29L - 35S | 35 (1) | 35 (2), 40 - 45. - 50. | 60C - 65C |
|  WHEEL GEOMETRY | - | - | - | - |
|  Wheel camber angle (vehicle at static load) ($\pm 20'$) | $0^\circ \pm 20'$ | | $0^\circ 30' \pm 20'$ | $1^\circ \pm 20'$ |
|  Wheel caster angle (vehicle at static load) | $3^\circ \pm 20'$ | | $1^\circ 35' \pm 20'$ | $2^\circ 30' \pm 20'$ |
|  Wheel toe-in (vehicle at static load) mm | 2 ± 1 | | 2.5 ± 1 | |
|  Steering angle: Internal a External b | $47^\circ 30' \pm 30'$ $39^\circ \pm 30'$ | | 43° $36^\circ 30'$ | $37^\circ 7'$ $45^\circ 6'$ |
|  Stub axle king-pin camber α | 13.38° | | 7° | |

(1) Front suspension with transverse leaf spring

(2) Front suspension with torsion bar


TIGHTENING TORQUES

| PART | TORQUE | |
|---|--------------|--------------|
| | Nm | kgm |
| Nut fixing king-pin to the side tie rod of the steering box | $15 \div 20$ | $1.5 \div 2$ |


TOOLS

TOOL NO.

DESCRIPTION

99305354

Tool for checking wheel geometry

99347074

Puller for king-pins


CHECKING CHARACTERISTIC ANGLES

Before proceeding with the checks, it is necessary to perform a preliminary inspection at some of the vehicle members, which can affect the geometry: if malfunctions are found, it is necessary to eliminate them in order to avoid wrong detection.

The check to be performed are the following:

- tyre pressure;
- wheel hub bearing play
- play between steering tie rod pins and stub axle levers;
- shock absorber efficiency;
- unallowed deformation of the wheel rims.

Figure 7



- Ensure the presence of spacers (1) between side members (2) and tie rod (4) attachment mountings (3) (with the exception of vehicles equipped with 5 mm thick side members). If not, proceed as described on page 60.

NOTE The checks and possible operations on the wheel geometry must be carried out with the vehicle at static load. Make sure, periodically, that the optical unit are perfectly calibrated.




In case of modifications of the wheel's characteristic angles in vehicles equipped with ESP, you will have to perform the calibration procedure for the steering angle sensor fitted into the steering wheel, as described on page 63 of the "Brakes" section.

Perform the geometry check using the tool 99305354.


Positioning jaws and projectors

Figure 8




Place the vehicle with the wheel in straight running position on a level surface. Lift the rear of the vehicle and position the board (3). Lower the vehicle, brake the rear wheels and apply the hook (1) with the slide rule (2).

Figure 9




Lift the vehicle front part and position the floating wheels (1) locking them with the locks (2).

Figure 10



Position the clutch jaw (1) fitted with fixing pins (2). Operating the handgrip (3), lock the jaw on the wheel, making sure that it is perfectly secured.


Figure 11



Assemble the detecting unit (1) on the jaws (3) and constrain it with the screw (2). Repeat the operation on the other wheel.

Electronic balancing of rim eccentricity

Figure 12



32819

Connect the detectors plugs (7) to the transformer (6) and switch on the switch (8); loosen the locking screw (2) of the detector and lift the detector lens guard (7).



Make sure that the laser beam does not hit the eyes of people, it will severely damage their sight.

Press the push-button "out of centre" (1) for at least two seconds, the display (3) shows nine lines.

Manually rotate the wheel slowly in the running direction and project the light signal on the slide rule scale (5).

Stop the wheel when the signal read on the slide rule (5) has reached the maximum value and note down the value (e.g. 12).

Rotate the wheel again until the minimum value is reached and note it down (e.g. 8).

Calculate the mean value of the amplitude: $12 + 8 = 20 : 2 = 10$ and position the wheel on the mean value calculated marking its position.


Press the push-button "out of centre" again (1) until the LED (4) of the wheel camber is lighted and on the display (3) a fictitious value is shown.

Repeat the operations on the other wheel.

Lower the vehicle so that the wheels, in the position previously marked, completely rest at the centre of the floating discs (9).

Loosen the floating discs (9) from their bases extracting the pins (10).

Figure 13




25120

Press the brake pedal locking it with the suitable tool (1) positioned against the seat.

NOTE The wheels must be braked during the whole measuring cycle.

Wheel alignment

Figure 14




52269

Using the level (4) arrange horizontally the detectors (3) and fix them to their position with the screw (2).

Move the slide rules (1) until they are centred by the light signal transmitted by the detector (3) and note down the values.

Figure 15




13952

If the values are different, steer the wheels until the light signal indexes are set to two values equal (A) and exactly the mean value of the two previous readings.

In this way a perfect wheel alignment is obtained.

Checking toe-in

Figure 16




25122

Keeping the detectors in horizontal position and the wheels perfectly aligned, move the lens guard (2) using the lever (1)

Operate the lever (3) and direct the light signal index on the slide rule scale (4) corresponding to the rim diameter.


Figure 17



52270

Repeat the same operations on the opposite detector and read the toe-in value on the scales (in millimetres): the result of the algebraic sum of the two values must be the prescribed value.

Figure 18



32295

The positive or negative toe-in adjustment is carried out as follows:

Loosen the nuts (3) on the joint heads (2, right and left).

Turn tie rods (1) up to obtain the toe-in of each wheel equal to half of the prescribed value.

Then tighten the nuts (3) to the prescribed torque.

Front wheel deviation test (vehicle wheelbase check)

The front wheel deviation test and toe-in reading are carried out at the same time.

The partial toe-in values, to be detected on the proper straightedges divided into millimetres, must have the same value and their sum must correspond to the whole toe-in value.

If between the readings there is a difference (e.g.: -2 and + 3), it means that there is a deviation between the two wheels: a wheel onward as to the other wheel, equal to 5 lines of the toe-in scale.

The number of lines is calculated by the algebraic sum [+3-2(-1)=5] or counting the lines included between the two values.

Each line corresponds to a deviation of 2 mm, so the deviation between the two wheels is equal to 10 mm (5 x2).

For vehicles with torsion bar suspension:

After determining which is the defective wheel, check its conditions and the exact assembly dimension of the upper and lower tie rods of the wheel suspension.

If the tie rods have been subject to deformations, replace them; if the assembly dimension is wrong, screw or unscrew the tie rod on the king-pin so that the vehicle wheel base is adjusted and the wheel are on the same axis.


NOTE In order not to change wheel caster angle, a lengthening or shortening of the lower tie rod must correspond to a lengthening or shortening of the upper tie rod.

For vehicles with transverse leaf spring suspension:

The deviation error may be due to deformation of the frame or of the assemblies connected to the wheels.

Checking camber


Figure 19



When the front wheels are aligned to the rear ones and the detectors are on an horizontal plane, press the key wheel camber (2) the LED lights up and the display (1) shows the camber angle value.


Checking king-pin angle and caster angle

Figure 20




When the front wheels are aligned to the rear ones, loosen the knurled knobs (3) and zero the graduated sector (2) on the index (1) of the floating disc.

Figure 21




Steer the wheel 20° toward the inside; press twice the king-pin camber push-button (2), the LED lights up and the display (1) shows 9 horizontal lines.

Figure 22



Steer the wheels 20° toward the outside, press the king-pin camber push-button (2) and the display (1) shows the king-pin camber angle.

Figure 23



Without moving the wheel, press the caster angle push-button (2), the LED lights up and the display (1) shows the caster angle value.

Repeat these operations on the other wheel.


NOTE The king-pin camber angle and the wheel caster angle are stored, after detection, by the instrument and can be recalled when necessary pressing the push-button relevant to the concerned angle.

For regulating the caster angle proceed as follows:

- set wheels in a straight running condition;
- press the kingpin angle button until its relevant LED starts blinking;
- screw and unscrew, as required, lower tie rod joint head, considering that the joint head can't carry out more than one turn.

Checking steering angles

Figure 24



This check is carried out during the king-pin camber check of during the caster angle check, making the following operations:

- if the prescribed steering angles exceed 30°, the mark 20°(1) on the floating disc (2) and the mark 30° (3) on the graduated selector (4) must be considered as initial reference values.

- Steer the wheels until the floating disc index of the wheel inside the bend in correspondence with the prescribed steering angle.

NOTE For steering angles higher than 30°, it is necessary to consider as reference index the mark 20° (1).


- under the above conditions, check on the other wheel that the steering angle value is as expected;
- reverse steering and check again.

If different values are found, possible causes can be:

- wrong centering of the steering box;
- deformations caused by impacts;
- deviation error between axles (front and rear axles) higher than 20 mm.

Checking rear axle alignment


Figure 25



Apply the slide rule (1) to the front wheels checking that the cursor (2) is exactly in the middle of the two ring splines of the shaft (3)

Apply the detectors to the rear wheels and proceed as already described for the front axle wheels.

Figure 26



44934


Project the light signal on the slide rule (I) and mark the value shown.

Repeat the measure on the other wheel and check that the value is equal to the noted down value, otherwise carefully check the vehicle rear axle assembly

If no malfunctions are detected, check that the frame is not deformed, sticking to the procedures described in the section "Body and frame".

Calculating thickness of spacers to be fitted between tie rod mountings and chassis side members (with the exception of vehicles equipped with 5-mm thick chassis or with transverse leaf-spring suspension)

Figure 27



46951

Introduction

The external width of the chassis with reference to tie rod mountings attachment point can vary from vehicle to vehicle depending on chassis assembling tolerances and side member thickness.

Therefore, width A (864 mm) is considered as an acceptable reference value on which to base correct wheel geometry.

The above value results from the sum of chassis internal width B (854 ± 2 mm) plus thickness $D_1 - D_2$ of a 4 mm thick chassis.

Proceed as follows.

Measure external chassis width A_1 at the axle.


If chassis width is not 864 mm (reference value A), subtract your reading (for example, $A_1 = 859$ mm) from the reference value: $864 - 859 = 5$ mm.

Divide this figure by 2 ($5 : 2 = 2.5$ mm).

2.5 mm is therefore the thickness of the compensating spacers that should be fitted to each side member.

Spacers are supplied as spare parts in the following thicknesses: 1 - 1.5 - 2 mm.

Figure 28



46952

Proceed as follows to install compensating spacers (1).

Dismantle:

- Rh and lh front engine guard (5 and 6).
- Engine oil sump guard (3).
- Rh and lh wheel guard (4 and 7).
- Rh and lh side engine guard (2 and 8).

Position spacers (1) of the thickness calculated before, fit mounting (10), screw in screws (11) and lock them to a torque of 14.25 kgm (142.5 Nm).

Reassemble all previously dismantled guards.

When assembly is completed, check and adjust wheel geometry as required following directions provided in the relevant chapters.

SECTION 8

Suspensions

| | Page |
|--|------|
| FRONT AND REAR MECHANICAL SUSPENSIONS | 3 |
| REAR AIR SUSPENSIONS | 83 |


**Front and rear
mechanical suspensions**

| | Page |
|------------------------------------|------|
| DIAGNOSTICS | 5 |
| FRONT MECHANICAL SUSPENSIONS | 9 |
| REAR MECHANICAL SUSPENSIONS | 53 |


DIAGNOSTICS

Main possible suspension defects


- 1 - noisy suspension;
- 2 - the vehicle tends to drift to one side;
- 3 - excessive suspension flexibility;
- 4 - excessive suspension stiffness.




(Continues)



(Continues)



(Continues)



| Front mechanical suspensions | |
|--|------|
| | Page |
| DESCRIPTION | 11 |
| ARTICULATED QUADRILATERAL SUSPENSION WITH TRANSVERSE LEAF SPRING | 11 |
| SPECIFICATIONS AND DATA | 12 |
| <input type="checkbox"/> Front leaf spring | 12 |
| <input type="checkbox"/> Front suspension stabilizer bar (axle 5817) ... | 13 |
| <input type="checkbox"/> Front shock absorbers | 14 |
| TOOLS | 14 |
| VEHICLE SUSPENSIONS 29 L - 35 S WITHOUT SWAY BAR | 15 |
| <input type="checkbox"/> Shock absorber data | 15 |
| TIGHTENING TORQUES | 16 |
| <input type="checkbox"/> Vehicles 29 L - 35 S (without sway bar) | 16 |
| TIGHTENING TORQUES | 17 |
| <input type="checkbox"/> Vehicles 29 L - 35 S | 17 |
| TIGHTENING TORQUES | 18 |
| <input type="checkbox"/> Vehicles 35 C | 18 |
| TIGHTENING TORQUES | 19 |
| <input type="checkbox"/> Vehicles 29 L - 35 S - 35C | 19 |
| REPAIRS | 20 |
| <input type="checkbox"/> Check the clearance of upper swinging arm articulated head | 20 |
| <input type="checkbox"/> Check the clearance of lower swinging arm articulated head | 21 |
| OVERHAULING THE SUSPENSION | 21 |
| <input type="checkbox"/> Suspension arms | 21 |
| <input type="checkbox"/> Removal | 21 |
| <input type="checkbox"/> Replacing suspension arm bushings | 21 |
| <input type="checkbox"/> Disassembly | 21 |
| <input type="checkbox"/> Assembly | 22 |
| <input type="checkbox"/> Refitting | 22 |
| STABILIZER BAR | 23 |
| <input type="checkbox"/> Removal | 23 |
| <input type="checkbox"/> Refitting | 23 |
| FRONT SHOCK ABSORBERS | 23 |
| <input type="checkbox"/> Removal | 23 |
| <input type="checkbox"/> Refitting | 23 |

| | Page |
|---|------|
| LEAF SPRING | 25 |
| <input type="checkbox"/> Removal | 25 |
| <input type="checkbox"/> Refitting | 26 |
| TORSION BAR SUSPENSION | 27 |
| <input type="checkbox"/> Axle 5819 - vehicles 35C - 40C - 45C - 50C .. | 27 |
| <input type="checkbox"/> Description | 27 |
| SPECIFICATIONS AND DATA | 28 |
| <input type="checkbox"/> Front shock absorbers | 28 |
| <input type="checkbox"/> Stabilizer bar diameter | 28 |
| TOOLS | 29 |
| TIGHTENING TORQUES | 31 |
| <input type="checkbox"/> Vehicles 35 C - 40 C - 45 C - 50 C | 31 |
| REPAIRS | 33 |
| <input type="checkbox"/> Check the clearance of upper swinging arm articulated head | 33 |
| <input type="checkbox"/> Check the clearance of lower swinging arm articulated head | 34 |
| OVERHAULING THE SUSPENSION | 35 |
| TIE RODS | 35 |
| <input type="checkbox"/> Removal | 35 |
| <input type="checkbox"/> Replacing swivel heads | 35 |
| <input type="checkbox"/> Refitting | 36 |
| TORSION BARS | 36 |
| <input type="checkbox"/> Removal | 36 |
| <input type="checkbox"/> Replacing silentbloc and limit stops | 37 |
| <input type="checkbox"/> Replacing link pins | 37 |
| <input type="checkbox"/> Refitting | 38 |
| <input type="checkbox"/> Adjusting torsion bar pre-load | 40 |
| STABILIZER BAR | 41 |

| | Page |
|---|------|
| <input type="checkbox"/> Removal | 41 |
| <input type="checkbox"/> Refitting | 41 |
| FRONT SHOCK ABSORBERS | 41 |
| <input type="checkbox"/> Removal | 41 |
| <input type="checkbox"/> Refitting | 41 |
| TORSION BAR SUSPENSION | 43 |
| <input type="checkbox"/> Axle 5823 - vehicles 60C - 65C | 43 |
| <input type="checkbox"/> Description | 43 |
| SPECIFICATIONS AND DATA | 44 |
| <input type="checkbox"/> Front shock absorbers | 44 |
| <input type="checkbox"/> Stabilizer bar | 44 |
| TIGHTENING TORQUES | 45 |
| EQUIPMENT | 47 |
| REPAIR OPERATIONS | 48 |
| SUSPENSION OVERHAUL | 48 |
| <input type="checkbox"/> Lower tie rod articulated heads replacement .. | 48 |
| TORSION BARS | 48 |
| <input type="checkbox"/> Removal | 48 |
| <input type="checkbox"/> Rubber bush replacement | 49 |
| <input type="checkbox"/> Removal | 49 |
| <input type="checkbox"/> Refitting | 49 |
| <input type="checkbox"/> Torsion bar preload adjustment | 52 |

MECHANICAL FRONT SUSPENSIONS

DESCRIPTION

The front suspension has independent wheels of the type:


- with an articulated quadrilateral with a transverse leaf spring for axles 5817 and 5818;
- with longitudinal torsion bars for axle 5819 and 5823.

ARTICULATED QUADRILATERAL SUSPENSION WITH TRANSVERSE LEAF SPRING (vehicles 29I - 35s - 35c)

The suspension comprises:


- two top triangular suspension arms, composed of a sheet-metal shell, connected by elastic bushings to the crosspiece by pins articulated to the stub axle;
- two bottom triangular suspension arms, composed of two sheet-metal half-shells welded together, connected by elastic bushings with metal reinforcement to the crosspiece and pins articulated to the stub axle.
The bottom suspension arms have reaction points for the leaf spring and the bottom mountings of the shock absorbers;
- a single-blade leaf spring, made of composite material for axles 5817 mounted on vehicles 29 L and 35 S, steel for axles 5818 mounted on vehicles 35 C; the spring is kept inside the crosspiece by two top reaction plugs fitted on the ends of the spring housed in the seats in the bottom suspension arms.
The steel leaf spring, due to the resistance it provides for the rolling movements of the vehicle, makes mounting the front stabilizer bar superfluous;
- two double-acting hydraulic shock absorbers with integrated limit stops;
- stabilizer bar on vehicles 29 L - 35 S.

Figure 1



SPECIFICATIONS AND DATA**Front leaf spring**

| Models: 29 L - 35 S | | | |
|--------------------------------|------|----------|--------------|
| Transverse | | | N° 1 |
| Spring length | (mm) | | 1313.2 |
| Sheet thickness measured at | (mm) | A | 39.92 ± 0.50 |
| Sheet width measured at | (mm) | { B C | 56.0 ± 0.5 |
| | | | 81.0 ± 0.5 |

Figure 2


52322

COMPOSITE LEAF SPRING

| NEW LEAF SPRING CHECK DATA | | | |
|-----------------------------------|---------|-------|-------|
| | | 29 L | 35 S |
| STATIC LOAD | (N) | 19865 | 21040 |
| SAG WITH STATIC LOAD | (mm) | 71.7 | 68.4 |
| DYNAMIC LOAD | (N) | 34270 | 37005 |
| SAG WITH DYNAMIC LOAD | (mm) | 123.7 | 120.4 |
| FLEXIBILITY ± 5%I | (mm/kN) | 277 | 307.0 |
| DISTANCE BETWEEN SUPPORT PLUGS | (mm) | 540 | 600 |

Front leaf spring**Models: 35 C**

| | | |
|-----------------|------|----------|
| Transverse | | N° 1 |
| Spring length | (mm) | 1365 ± 3 |
| Sheet thickness | (mm) | 20 ± 0.2 |
| Sheet width | (mm) | 80 ± 0.5 |

Figure 3

50824


STEEL LEAF SPRING

| NEW LEAF SPRING CHECK DATA | | | | | |
|----------------------------|--------|--------|----------------|-------------|-----------|
| POSITION | LOAD | | CAMBER (mm) | FLEXIBILITY | |
| | daN | kg | | mm/100 daN | mm/100 kg |
| STATIC LOAD | 845.1 | 861.5 | 70.25 | 8.31 | 8.15 |
| DYNAMIC LOAD | 1453.3 | 1481.4 | 120.8 | | |




Front suspension stabilizer bar (axle 5817)**Models: 29 L - 35 C**

| | | |
|-------------------------|------|----|
| Stabilizer bar diameter | (mm) | 18 |
|-------------------------|------|----|

Front shock absorbers


| Models: | 29 L - 35 S - 35 C | | |
|---|----------------------------------|---------------------------|----------------------|
|  | | Mannesmann - Sachs | Arvin Meritor |
| | Distance between centre of eyes: | | |
| | Open (mm) | 405 ± 3 | |
| | Closed (mm) | 320 ± 3 | |
| Stroke (mm) | 85 | | |

TOOLS

| TOOL NO. | DESCRIPTION |
|-----------------|---|
| 99321024 |  <p>Hydraulic trolley for wheel removal and refitting</p> |
| 99347074 |  <p>Extractor to take out link pins</p> |
| 99374179 |  <p>Tool for disassembling and reassembling suspension arm flexible bushings</p> |

VEHICLE SUSPENSIONS 29 L - 35 S WITHOUT SWAY BAR (recent production with rebound pad integrated in shock absorbers).


Figure 4



85872

1. Built-in rebound - 2. Reaction pad.


Shock absorber data

| Models: | 29 L - 35 S | |
|---|---------------------------------|----------------------|
|  | | Alvin Meritor |
| | Length between eyebolt centres: | |
| | Open (mm) | 405 ± 3 |
| | Closed (start of damping) (mm) | 380 ± 3 |
| | Closed (pad squeezed) (mm) | 340 ± 3 |
| | Stroke (mm) | 65 |

TIGHTENING TORQUES

Vehicles 29 L - 35 S (without sway bar)

Figure 5




85873

| COMPONENT | TORQUE | | |
|-----------|---|-----------|-------------|
| | Nm | kgm | |
| 1 | Screw for nut securing steering gear housing | 50 ÷ 61 | 5 ÷ 6.1 |
| 2 | M12 screw for nut securing leaf spring mounting to the cross member | 100 ÷ 124 | 10 ÷ 12.4 |
| 3 | M10 screw for nut securing leaf spring mounting to the cross member | 39 ÷ 48 | 3.9 ÷ 4.8 |
| 4 | Nut for screw securing shock absorber top and bottom | 124 ÷ 152 | 12.4 ÷ 15.2 |
| 5 | Screw for nut securing shock absorber mounting to bottom suspension arm | 39 ÷ 48 | 3.9 ÷ 4.8 |
| 6 | Nut securing bottom suspension arm ball joint to the stub axle | 160 ÷ 180 | 16 ÷ 18 |
| 7 | Nut securing steering gear housing tie rod ball joint to the stub axle | 68 ÷ 83 | 6.8 ÷ 8.3 |
| 8 | Screw securing wheel | 160 | 16 |
| 9 | Nut securing hub to stub axle | 256 ÷ 314 | 25.6 ÷ 31.4 |
| 10 | Screw securing brake disc to wheel hub | 19.5 ÷ 24 | 1.9 ÷ 2.4 |
| 11 | Nut securing top suspension arm ball joint to the stub axle | 125 ÷ 140 | 12.5 ÷ 14 |
| 12 | Nut securing ball joint to the steering gear housing tie rod | 70 ÷ 100 | 7 ÷ 10 |
| - | Nut fixing stabilizer bar reaction link rod | 35 ÷ 53 | 3.5 ÷ 5.4 |

TIGHTENING TORQUES

Vehicles 29 L - 35 S

Figure 6




49353

| COMPONENT | | TORQUE | |
|-----------|---|-----------|-------------|
| | | Nm | kgm |
| 1 | Screw for nut securing steering gear housing | 50 ÷ 61 | 5 ÷ 6.1 |
| 2 | M12 screw for nut securing leaf spring mounting to the cross member | 100 ÷ 124 | 10 ÷ 12.4 |
| 3 | M10 screw for nut securing leaf spring mounting to the cross member | 39 ÷ 48 | 3.9 ÷ 4.8 |
| 4 | Nut for screw securing shock absorber top and bottom | 124 ÷ 152 | 12.4 ÷ 15.2 |
| 5 | Screw for nut securing shock absorber mounting to bottom suspension arm | 39 ÷ 48 | 3.9 ÷ 4.8 |
| 6 | Nut securing bottom suspension arm ball joint to the stub axle | 160 ÷ 180 | 16 ÷ 18 |
| 7 | Nut securing steering gear housing tie rod ball joint to the stub axle | 68 ÷ 83 | 6.8 ÷ 8.3 |
| 8 | Screw securing wheel | 160 | 16 |
| 9 | Nut securing hub to stub axle | 256 ÷ 314 | 25.6 ÷ 31.4 |
| 10 | Screw securing brake disc to wheel hub | 19.5 ÷ 24 | 1.9 ÷ 2.4 |
| 11 | Nut securing top suspension arm ball joint to the stub axle | 125 ÷ 140 | 12.5 ÷ 14 |
| 12 | Nut securing ball joint to the steering gear housing tie rod | 70 ÷ 100 | 7 ÷ 10 |
| - | Nut fixing stabilizer bar reaction link rod | 35 ÷ 53 | 3.5 ÷ 5.4 |

TIGHTENING TORQUES

Vehicles 35 C

Figure 7




49351

| COMPONENT | TORQUE | |
|-----------|--------------|-------------|
| | Nm | kgm |
| 1 | 50 ÷ 61 | 5 ÷ 6.1 |
| 2 | 100 ÷ 124 | 10 ÷ 12.4 |
| 3 | 39 ÷ 48 | 3.9 ÷ 4.8 |
| 4 | 124 ÷ 152 | 12.4 ÷ 15.2 |
| 5 | 39 ÷ 48 | 3.9 ÷ 4.8 |
| 6 | 160 ÷ 180 | 16 ÷ 18 |
| 7 | 68 ÷ 83 | 6.8 ÷ 8.3 |
| 8 | 284 ÷ 342 | 28.4 ÷ 34.2 |
| 9 | 98.1 ÷ 107.9 | 9.8 ÷ 10.7 |
| 10 | 20 ÷ 24 | 2 ÷ 2.4 |
| 11 | 257 ÷ 314 | 25.7 ÷ 31.4 |
| 12 | 85 ÷ 104 | 8.5 ÷ 10.4 |
| 13 | 70 ÷ 100 | 7 ÷ 10 |
| 14 | 125 ÷ 140 | 12.5 ÷ 14 |

TIGHTENING TORQUES

Vehicles 29 L - 35 S - 35C

Figure 8




49352

| COMPONENT | | TORQUE | |
|-----------|--|-----------|-------------|
| | | Nm | kgm |
| 1 - 2 | Screw for nut securing suspension arm to the top cross member and bottom to the cross member | 170 ÷ 280 | 17 ÷ 28 |
| 3 | Screw securing disc guard to the axle stub | 6 ÷ 7.5 | 0.6 ÷ 0.7 |
| 4 | Nut for screw securing cross member to chassis frame | 83 ÷ 101 | 8.3 ÷ 10.1 |
| 5 | Nut for screw securing cross member to chassis frame | 83 ÷ 101 | 8.4 ÷ 10.1 |
| 6 | Screw securing caliper mounting to the axle stub | 170 ÷ 196 | 17.0 ÷ 19.6 |
| 7 | M14 screw securing covers to the cross member | 151 ÷ 184 | 15.1 ÷ 18.4 |

REPAIRS**Check the clearance of upper swinging arm articulated head**


Figure 9



88671

Adjust vehicle on flat ground and lock rear wheels.
 Unloosen rear wheels securing nuts.
 By a hydraulic jack, lift the vehicle on front side and rest it on two supporting stands.
 Unscrew wheels securing nuts and detach wheels again by hydraulic truck 99321024.
 Check that protection cowlings (1 and 2) of articulated heads are not damaged.


Figure 10



88672

Apply the magnetic base of comparator 99395684 (1) to brake disk (4) and position comparator tracer point on the top of the articulated head (2) of upper swinging arm (3).
 Pre-load comparator by approximately 4 mm.

Figure 11




88673

By suitable lever (3) resting on articulated spindle (4), lift swinging arm (2) as much as possible and reset comparator (1).



In operation, take care not to damage the protection cowling of articulated head .

Figure 12




88674

By suitable pliers (2) applied on articulated head (1) and on articulated spindle (4), apply strong pressure on head and spindle and check comparator (3) hand displacement corresponding to articulated head clearance.
 If detected value is between 1.5 and 2.0 mm, the swinging arm needs to be replaced, as described in relating chapter.

Check the clearance of lower swinging arm articulated head

Figure 13



88692


The check of the clearance of the articulated head (2) of lower swinging arm (1) is similar to the one of upper swinging arm.

If detected value is between 1.5 and 2.0 mm, the swinging arm needs to be replaced, as described in relating chapter.

500760 OVERHAULING THE SUSPENSION

Suspension arms Removal

Figure 14




61664

Remove the stub axle as described under the relevant heading (operation 520611 including removal of the wheel hubs operation 520620).

Take out the nuts (2), extract the screws (3) and remove the top suspension arm (4) from the mountings of the cross member (1).

Figure 15




61665

Take out the nut (6) and remove the shock absorber (5) from the mounting (8) of the bottom suspension arm, extracting the screw (7).

Take out the nuts (2), extract the screws (3) and remove the bottom suspension arm (4) from the mountings of the cross member (1).

Replacing suspension arm bushings Disassembly

Figure 16



52325




If there is damage to the caps (3) protecting the link pins (2) or if these have too much play, replace the suspension arm (1).

Using general tools, extract the flexible bushings (4) from the suspension arms (1).

Assembly


NOTE The flexible bushings of the bottom suspension arms are equipped with metal reinforcement.

Figure 17




Insert the bushing (2) into the suspension arm (1).
 Apply the parts (3 - 4 - 5 - 6) of the tool 99374179, as shown in the figure.
 Screw on the nut (6) to make the bushing (2) flush with the suspension arm (1).
 Remove the parts of tool 99374179.

Figure 18



Insert the bushing (7) into the suspension arm (1).
 Apply the parts (2 - 3 - 5 - 6) of the tool 99374179, as shown in the figure.
 Screw on the nut (6) to make the bushing (7) flush with the suspension arm (1).
 Remove the parts of tool 99374179.


Figure 19



Insert the spacer (2) into the bushing (1).
 Apply the parts (3 - 4 - 5) of the tool 99374179, as shown in the figure.
 Screw on the nut (5) to fully insert the spacer (2) into the flexible bushings (1).

Refitting

Figure 20




To refit the bottom (5) and top (1) suspension arms to the crosspiece (2), reverse the steps described for removal tightening the nuts (6 - 3) for the fixing screws (4 - 7) to the prescribed torque.



Self-locking nuts, once removed, must be replaced with new ones.

528030 STABILIZER BAR**Removal**

Figure 21

FRONT STABILIZER BAR
VEHICLES 29 L - 35S

Unscrew the nuts (3) fixing the link rods to the stabilizer bar (1).
Unscrew the screws (4) fixing the stabilizer bar (1).
If necessary, unscrew the fixing nuts and remove the reaction link rods (2).




Check that the bushings and/or elastic elements are not worn or deteriorated; if they are, replace the relevant part.

Refitting

For refitting, carry out the removal operations in reverse order and keep to the required tightening torques.

**500910 FRONT SHOCK ABSORBERS****Removal**

Figure 22

FRONT SHOCK ABSORBER
VEHICLES 29 L - 35S

Set the vehicle on level ground. Lock the rear wheels with a scotch, remove the wheel rim guards and loosen the screws or nuts fixing the wheel.
Lift the front of the vehicle and rest the chassis frame on supports.
Take out the screws or nuts fixing the wheel and remove them with tool 99321024.
Unscrew the top and bottom bolts (2) and remove the shock absorbers (1) from the vehicle.



Check that the bushings and/or elastic elements are not worn or deteriorated; if they are, replace the relevant part.

Check the efficiency of the shock absorbers with a suitable instrument.

Refitting

For refitting, carry out the removal operations in reverse order and keep to the required tightening torques.

LEAF SPRING

Removal


Set the vehicle on level ground.


Lock the rear wheels with chocks. Take off the wheel rim guards and loosen the screws or nuts securing the wheel. Lift the front of the vehicle and rest the chassis frame on stands.


Take out the screws or nuts securing the wheel with tool 99321024.

On the right-hand side:

- using a hydraulic jack, slightly lift the stub axle so as to limit the load of the leaf spring;
- disconnect the electrical connection (1) for indicating brake lining wear;
- disconnect the ABS speed sensor (4) (if there is one);
- take out the screws (2) securing the brake caliper to the axle stub and remove it. Remove the brake linings from the brake caliper (3) and support this adequately to prevent strain on the brake pipes;

Figure 23




 Check the state of the brake linings and brake disc as described in the BRAKES section.


- take out the nut locking the link pin of the tie rod (20) and, with tool 99347074 (19), remove the link pin (20) of the steering tie rod from the stub axle;
- take out the nut (21) and, with tool 99347074 (19), remove the link pin (22) of the top suspension arm from the stub axle;
- take out the nuts (16) and screws (18) securing the shock absorber mounting (15) to the bottom suspension arm;
- lower the hydraulic jack;

Repeat the similar operations on the left-hand side;


- take out the nuts (6 and 5) and screws (10 and 11) and remove the covers (8, 9 and 12) from the cross member (7).

 Note the assembly position of the bottom flexible plugs (13) on the cover (8).

Remove the leaf spring (17).

 Note the assembly position of the top flexible plugs (14) in the cross member (7).


 For axle 5817 (vehicles 29L - 35S), remove nut (24) and disconnect crankpin (25) from stabiliser bar (23).



Refitting

Carry out the operations described for removal in reverse order, but you must take the following precautions:

- ❑ fit the top flexible plugs (2) in the cross member (1) at the position found during disassembly;
- ❑ fit the flexible plugs (4) onto the ends of the new leaf spring (3);
- ❑ fit the leaf spring (3) into the cross member and support it with a hydraulic lift;
- ❑ with two lifts arranged under the stub axles, lift them together, checking that the flexible plugs (4) of the leaf spring (3) get correctly positioned in the honeycomb of the bottom suspension arms (5 and 8) and the centre line (⇒) of the leaf spring is aligned with the central holes (⇒) della traversa (1), of the cross member (1), max. error ± 2 mm;
- ❑ then complete refitting by tightening the screws or nuts to the required torque;
- ❑ position the bottom flexible plugs (6) on the cover (7) at the position found during disassembly;
- ❑ mount the cover (7) and tighten the screws and nuts to the required torque.

 The nylon self-locking nuts must be replaced with new ones every time they are taken down.

NOTE To block rotation of the pins of the swivel heads (9 - 10), insert a suitable Allen wrench into the hexagon sunk in it.



 For axle 5817 tighten the nut (24) (Figure 23) fixing the link rod to a torque of 44 ± 9 Nm.

Figure 24

TORSION BAR SUSPENSION (Axle 5819 - vehicles 35C - 40C - 45C - 50C)

Description

The torsion bar suspension is composed of:

- two bottom suspension arms;
- two top suspension arms;
- two longitudinal torsion bars;
- two hydraulic shock absorbers;
- two bottom reaction tie rods;
- two top reaction tie rods;
- a stabilizer bar;
- two rubber pads.

The longitudinal torsion bars are anchored at the front to the top suspension arms and at the rear to a mounting secured to the chassis frame.


The hydraulic shock absorbers are the double-acting telescopic type.

The side tie rods are mounted at the front to the chassis frame mounting by means of adjustable link pins, and at the rear to the transverse levers.

The purpose of the stabilizer bar, mounted on the bottom reaction screw stays, is to maintain the parallelism between the axis of the wheels and the chassis frame, cancelling any load unbalance on the wheels mounted on the same axle.

The purpose of the rubber pads fixed on the top mounting of the shock absorbers is to limit the upward movement of the suspension.

Figure 25




ASSEMBLY DRAWING OF FRONT TORSION BAR SUSPENSION

SPECIFICATIONS AND DATA






| Torsion bar suspension with independent wheels, stabilizer bar and hydraulic shock absorbers | Models | | | |
|---|------------------------------------|-------------|-------------|-------------|
| | 35 C | 40 C | 45 C | 50 C |
| Torsion bar diameter mm | 29 | | | |
| Top tie rod adjustment distance | 378 ± 0.15 mm 220.4 ± 0.15 mm | | | |
| Bottom tie rod adjustment distance | 364.5 ± 0.15 mm 300.4 ± 0.15 mm | | | |

Front shock absorbers

| Models: | 35 C - 40 C - 45 C - 50 C | | | |
|--|----------------------------------|---------------------------|----------------------|--|
|  | | Mannesmann - Sachs | Arvin Meritor | |
| | Distance between centre of eyes: | | | |
| | Open mm | 430 ± 3 | 444 ± 3 mm | |
| | Closed mm | 280 ± 3 | 286 ± 3 mm | |
| Stroke mm | 150 | 158 mm | | |


Stabilizer bar diameter

| Models: | 35 C - 40 C - 45 C - 50 C | |
|----------------------------|----------------------------------|----|
| Stabilizer bar diameter mm | 16 | 20 |

| TOOLS | |
|-----------------|---|
| TOOL NO. | DESCRIPTION |
| 99321024 |  <p>Hydraulic trolley for wheel removal - refitting</p> |
| 99347060 |  <p>Extractor to take out tie rod link pins</p> |
| 99347074 |  <p>Extractor to take out steering tie rod link pins and suspension arms</p> |
| 99357144 |  <p>Wrench for ring nut securing link pins</p> |
| 99374241 |  <p>Tool for disassembling and reassembling front suspension flexible bushings</p> |

TIGHTENING TORQUES
Vehicles 35 C - 40 C - 45 C - 50 C

Figure 26



| | DESCRIPTION | TORQUE | |
|----|---|-----------|-------------|
| | | Nm | kgm |
| 1 | Nut, reaction rod mounting upper fastening to chassis fixing screw | 126 ÷ 154 | 12.8 ÷ 15.7 |
| 2 | Nut, reaction rod ball joint to mounting | 98 ÷ 137 | 10 ÷ 14 |
| 3 | Nut, reaction rod and knuckle joint stiffener to chassis fixing screw | 33 ÷ 49 | 3.4 ÷ 5.0 |
| 4 | Nut for screw fixing cross member to reaction rod support | 126 ÷ 154 | 12.8 ÷ 15.7 |
| 5 | Nut, ball joint to upper tie rod | 98 ÷ 137 | 10 ÷ 14 |
| 6 | Nut, upper tie rod to upper arm fastening screw | 150 ÷ 183 | 15.3 ÷ 18.7 |
| 7 | Nut, shock absorber upper and lower fastening screw | 116 ÷ 142 | 11.8 ÷ 14.5 |
| 8 | Nut, lower bracket fastening screw suspension adjustment unit | 151 ÷ 184 | 15.4 ÷ 18.8 |
| 9 | Nut, torsion bar adjusting lever pin | 254 ÷ 311 | 25.9 ÷ 31.7 |
| 10 | Nut, cross member to chassis side member lower wing fixing screw | 72 ÷ 88 | 7.3 ÷ 9 |
| 11 | Nut for steering box fixing screw | 50 ÷ 61 | 5 ÷ 6.1 |
| 12 | Nut, lower arms to cross member anchoring screw | 206 ÷ 252 | 21.0 ÷ 25.7 |


| | DESCRIPTION | TORQUE | |
|----|---|-----------|------------|
| | | Nm | kgm |
| 13 | Ring nut, ball joint to upper/lower arms | 83 ÷ 152 | 8.5 ÷ 15.5 |
| 14 | Nut, ball joint to steering knuckle | 157 ÷ 177 | 16 ÷ 18 |
| 15 | Nut, fixing will | 335 ÷ 410 | 34 ÷ 41.8 |
| 16 | Nut fixing steering box rod ball joint to stub axle lever | 68 ÷ 83 | 6.8 ÷ 8.3 |
| 17 | Hexagonal-head slotted nut, torsion bar to suspension arm | 84 ÷ 103 | 8.5 ÷ 10.5 |
| 18 | Nut, cross member upper fastening to bracket on chassis side member upper wing fixing screw | 47 ÷ 58 | 4.8 ÷ 5.9 |
| 19 | Nut, cross member upper anchoring bracket to chassis side member upper wing fixing screw | 18 ÷ 22 | 1.8 ÷ 2.2 |
| 20 | Nut, upper and intermediate bracket fastening screw (suspension adjustment unit) | 94 ÷ 115 | 9.6 ÷ 11.7 |
| - | Screw for nut fixing front tubular cross member to side members | 42 ÷ 51 | 4.2 ÷ 5.2 |
| - | Nut, stabilizer bar clamps fixing screw | 18 ÷ 22 | 1.8 ÷ 2.2 |
| - | Rubber plug nut | 68 ÷ 83 | 6.9 ÷ 8.5 |

62103

REPAIRS

Check the clearance of upper swinging arm articulated head


Figure 27



88675

Adjust vehicle on flat ground and lock rear wheels.
Unloosen rear wheels securing nuts.
By a hydraulic jack, lift the vehicle on front side and rest it on two supporting stands.
Unscrew wheels securing nuts and detach wheels again by hydraulic truck 99321024.
Check that protection cowlings (1) of articulated heads are not damaged.


Figure 28



88676

Remove nut (5) and dismount shock absorber (1) from lower swinging arm (2).
Unloosen nut (4) for the screw to secure lower swinging arm (2) to cross member (3).


Figure 29



88677

Remove screw (3) and detach tie rod (2) from lower swinging arm (1).


Figure 30



88678

By suitable jack (2), positioned under wheel hub (1), load suspension.


Figure 31



88679


Apply the magnetic base of comparator 99395684 (1) to brake disk (2) and position comparator tracer point on the top of the articulated head (4) of upper swinging arm (3).

Figure 32



Pre-load comparator (1) by approximately 4 mm and reset it by suitable lever (4), lift upper swinging arm (3) as much as possible and detect the displacement of comparator (1) hand corresponding to the clearance of articulated head (2). If detected value is between 1.5 and 2.0 mm, the articulated head (2) needs to be replaced, as described in relating chapter.


Figure 34



By suitable pliers (2) applied on articulated head (3) and on lower swinging arm (1), apply strong pressure on head and arm and write down comparator (4) hand displacement corresponding to articulated head clearance. If detected value is between 1.5 and 2.0 mm, the swinging arm needs to be replaced, as described in relating chapter. Remount dismantled parts in order to make checks.

Check the clearance of lower swinging arm articulated head

Figure 33



Position comparator (1) tracer point with magnetic base 99395684 on the top of the articulated head of lower swinging arm (2).

By suitable lever, lower swinging arm (2) and reset comparator (1).




See Figure 29: the nut for screw (3) to secure tie rod (2) to lower swinging arm (1) and see Figure 28: the nut (4) for the screw to secure lower swinging arm (2) to cross member (3): they must be tightened at prescribed torque with the vehicle lowered and vehicle empty weight weighing down on suspension.

500760 OVERHAULING THE SUSPENSION

TIE RODS

Removal

Figure 35




44664

Remove the stabilizer bar as described under the relevant heading (operation 528030).

Take out the nut for the screw (2) securing the tie rod (3) to the bottom suspension arm (1) and remove the screw (2) from this.

Take out the nut securing the link pin (5) to the mounting (4). Using the extractor 99347060, remove the swivel head (5) from the mounting (4).

Figure 36




75359

Using the extractor 99347060 (1), detach the stub axle (2) from the mounting (4) Figure 25.

Remove the screw stay (3) from the vehicle.

Figure 37



75360


Take out the nut (3) for the screw (4) securing the tie rod (1) to the top suspension arm (2) and remove the screw (4) from this. Take out the nut securing the link pin (5) to the mounting (7). Using the extractor 99347074 (6), remove the swivel head (5) from the mounting (7). Remove the screw stay (1) from the vehicle.



If removing the mounting (7), so as not to change the wheel geometry, not the number and thickness of the spacers (if there are any) under the mounting to mount them in the same way when refitting the mounting (7).

500764 Replacing swivel heads

Figure 38




44666

Loosen the nut (2) and unscrew the swivel head (1) from the top tie rod (3).

Screw the new swivel head (1) onto the tie rod (3) positioning it at the values shown in the figure.

Figure 39




19056

Loosen the nut (2) and unscrew the swivel head (1) from the bottom tie rod (3).

Screw the new swivel head (1) onto the tie rod (3) positioning it at the values shown in the figure.

Tighten the nut (2) to the prescribed torque.

Refitting**Figure 40**

Refit the top tie rod (5) to the top suspension arm (3) and to the mounting (6).

Tighten the nut securing the link pin (1) to the required torque.




 The nut (4) for the screw securing the tie rod (5) to the lever (3) must be tightened when the load of the empty vehicle weighs on the suspension.


Figure 41

Refit the bottom tie rod (3) to the bottom suspension arm (1) and to the mounting (4).

Tighten the nut securing the link pin (5) to the required torque.

 The nut (2) for the screw securing the tie rod (3) to the bottom lever must be tightened when the load of the empty vehicle weighs on the suspension.


Re-fit the stabilizer bar.

 At the end of the re-fitting check the wheels geometry as described in the relevant paragraph.


Then tighten the nuts, which fasten the articulated head to the relevant tie-rods, to the prescribed torque.

500666 TORSION BARS**Removal**

Remove the lower and upper tie-rods as described in the relevant paragraph (operation 500761) and go on as follows:

Figure 42


Remove the nut which fastens the articulated head (2) of the gearbox tie-rod to the steering knuckle; with the puller No. 99347074 (1) remove the articulated head (2).

Figure 43

Loosen the nut (2) and unscrew the threaded pin (1) until the torsion bar (3) is fully "unloaded".

Take out the nuts (4) for the screws securing the mounting (5) to the chassis frame.

Remove the mounting (5) from the torsion bar (3).


Figure 44

Remove the nuts securing the link pins (1) from the top (4) and bottom (6) suspension arms to the stub axle (5).

Support in an appropriate way the steering knuckle (5) together with brake caliper and wheel hub and with the tool No. 99347074 (2) remove the steering knuckle (5) from the levers (4 and 6).

Place the steering knuckle (5) on a support without straining the brake fluid hose and the electrical wires.


Figure 45



Take out the nut (5), remove the screw (4) and recover the two washers.

Disconnect the bottom suspension arm (3) from the cross member (1) extracting the bushing (2).


Figure 46



Remove the split pin (6), the nut (5) and the washer (4). Disconnect the top suspension arm (2) from the cross member (3) extracting the torsion bar (1).

Replacing silentbloc and limit stops


Figure 47



Silentbloc is replaced using tool 99374241 (1); the limit stops (2) are replaced with general tools.


Replacing link pins

Figure 48




Straighten the safety lock (1) of the ring nut (2).

Figure 49




Using tool 99357144 (1) loosen the ring nut and extract the link pin (2) from the suspension arm.

Figure 50



Mount the new link pin (4) on the top and bottom suspension arm (1). Loosen the ring nut (3) with its safety lock (2).


Figure 51



19604

With the tool No. 99357144 (1) fasten the ring nut (3, Figure 50) to the prescribed torque.

Figure 52




19605


Bend a tongue of the safety lock (1) in the slot of the ring nut (2).

Refitting

Figure 53




19046

 The letters AD - AS, printed in the back of torsion bars, indicate respectively the right bar and the left one.

Moreover the splined part has a double tooth (1) which, at the reassembly, must correspond to the double spline (2) of the upper lever.


Figure 54



52370

Position the top suspension arm (2) in the cross member. Then insert the torsion bar (1), with the washer (3), in the cross member and in the suspension arm.


Figure 55



44674

Place the washer (1) and screw the nut (2) without tightening it.


Figure 56



19052

Position the bottom suspension arm in the cross member and insert the bushing (1). Insert the screw with its washers and screw the nut without tightening it.


Figure 57



44675

Connect the stub axle (3) to the link pins of the top (1) and bottom (4) suspension arms. Tighten the fixing nuts (2) to the required torque.


Figure 58



74998

Lubricate the grooved portion of the torsion bar (3). Assemble the torsion bar (3) and the support (1) so that the splines (2) of the toothed bush and of the torsion bar coincide. Fix the support (1) to the chassis tightening the fastening screw nuts to the prescribed torque.


Figure 59



44676

Refit the tie rods (4 and 7) to the suspension arms (1 and 6) without tightening the nuts for the screws (3 and 5) to their torque; connect the link pin (2) of the steering gear housing tie rod to the lever of the stub axle and tighten the nut to the required torque.


Figure 60



44697

Fit the stabilizer bar (1) back onto the bottom screw stays (2) with the clamps (3), taking care that the screws (4) go into the slots in the stabilizer bar. Complete fitting the suspension back on by mounting the shock absorber.

Figure 61



7768

Refit the wheels, mount the nut guard and screw on the fixing nuts; lower the vehicle, removing the stands.


Following the order shown in the figure, tighten the fixing nuts to the required torque.

Then tighten the torsion bar fixing nuts to the required torque and mount the safety split pins on them.

Tighten the nuts for the screws securing the top and bottom tie rods to their respective levers to the required torque.

Adjusting torsion bar pre-load

Figure 62




TORSION BAR PRE-LOADING CONTROL DIAGRAM
 H = mm, distance from ground of the side frame upper thread, measured as near as possible the suspension connecting area
 RSC = mm, loaded wheel radius

Ensure that the wheel pressure complies with the prescribed one and check, with the suitable gauge, that the thread depth of tyres is more or less the same on both wheels.

Measure on both sides of the vehicle, the distance from ground (H) of the side frame upper thread, measured as near as possible the suspension connecting area.

The height H must correspond to the value given in the table below.

Figure 63



If the value is different, act on the adjusting screw (1) as much as you need it, but remember that, before acting on the screw, it is necessary, to lift the vehicle with the hydraulic jack, so that the wheels are lifted from the ground. This is necessary if you do not want to damage the screw.


Once the vehicle has reached the right position, lock the screw with the lock nut (2).

HEIGHT OFF GROUND (H in millimetres) OF THE TOP EDGE OF THE CHASSIS FRAME IN RELATION TO THE WEIGHT FOR MODELS 35C/40C/45C/50C WITH TORSION BAR DIAMETER 29 mm.

| Weight on the front wheels (Kg) | Tyres | |
|---------------------------------|-------------|-----------|
| | 195/75 R 16 | 6.50 R 16 |
| 1200 | 610 | 629 |
| 1220 | 608 | 627 |
| 1240 | 606 | 625 |
| 1260 | 604 | 623 |
| 1280 | 603 | 622 |
| 1300 | 601 | 620 |
| 1320 | 599 | 618 |
| 1340 | 597 | 616 |
| 1360 | 596 | 615 |
| 1380 | 594 | 613 |
| 1400 | 592 | 611 |
| 1450 | 588 | 607 |
| 1500 | 584 | 602 |
| 1550 | 579 | 598 |
| 1600 | 575 | 593 |
| 1650 | 571 | 589 |
| 1700 | 566 | 585 |
| 1750 | 562 | 580 |
| 1800 | 558 | 576 |
| 1850 | 553 | 571 |
| 1900 | 549 | 567 |

528030 STABILIZER BAR**Removal**

Figure 64



75000

FRONT STABILISER BAR
Vehicles 35C - 40C - 45C - 50C

Unscrew the screws (2) fixing the half-brackets (3) and remove the stabilizer bar (1) from the vehicle, recovering the rubber plugs (4).




Check that the bushings and/or elastic elements are not worn or deteriorated; if they are, replace the relevant part.

Refitting

To fit it back on, perform the steps carried out for removal in reverse order, keeping to the prescribed tightening torques.

**500910 FRONT SHOCK ABSORBERS****Removal**

Figure 65



75001

FRONT SHOCK ABSORBER
Vehicles 35C - 40C - 45C - 50C

Set the vehicle on level ground.

Lock the rear wheels with scotches, remove the wheel rim guards and loosen the screws or nuts fixing the wheel.

Lift the front of the vehicle and rest the chassis frame on supports.

Take out the screws or nuts fixing the wheel and remove them with tool 99321024.

Unscrew the top and bottom bolts (2), then remove the shock absorbers (1) from the vehicle.



Check that the bushings and/or elastic elements are not worn or deteriorated; if they are, replace the relevant part.

Using a suitable instrument, check the efficiency of the shock absorbers.

Refitting

To fit it back on, perform the steps carried out for removal in reverse order, keeping to the prescribed tightening torques.



TORSION BAR SUSPENSION (Axle 5823 - vehicles 60C - 65C)

Description

The torsion bar suspension is composed of:

- two bottom suspension arms;
- two top suspension arms;
- two longitudinal torsion bars;
- two hydraulic shock absorbers;
- two bottom reaction tie rods;
- two top reaction tie rods;
- a stabilizer bar;
- two rubber pads.

The longitudinal torsion bars are anchored at the front to the top suspension arms and at the rear to a mounting secured to the chassis frame.


The hydraulic shock absorbers are the double-acting telescopic type.

The side tie rods are mounted at the front to the chassis frame mounting by means of adjustable link pins, and at the rear to the transverse levers.

The purpose of the stabilizer bar, mounted on the bottom reaction screw stays, is to maintain the parallelism between the axis of the wheels and the chassis frame, cancelling any load unbalance on the wheels mounted on the same axle.

The purpose of the rubber pads fixed on the top mounting of the shock absorbers is to limit the upward movement of the suspension.

Figure 66




ASSEMBLY DRAWING OF FRONT TORSION BAR SUSPENSION

SPECIFICATIONS AND DATA

| Torsion bar suspension with independent wheels, stabilizer bar and hydraulic shock absorbers | Models |
|---|----------------------|
| | 60 C - 65 C |
| Torsion bar diameter mm | 33 |
| Top tie rod adjustment distance | 378 ± 0.8 mm |
| | 220 ± 0.5 mm |
| Bottom tie rod adjustment distance | 369 ± 0.5 mm |
| | 300.4 ± 0.5 mm |
| Lower linkage adjustment (for recently manufactured vehicles) | 363.5 ± 0.5 mm |
| | 299 ± $^{+0.3}_0$ mm |
| | 377 ± 0.15 mm |
| | 219 ± 0.15 mm |

Front shock absorbers


| Models: | 60 C - 65 C | | | |
|---|----------------------------------|---------------------------|--------------|---------|
|  | | Mannesmann - Sachs | ARVIN | |
| | Distance between centre of eyes: | | | |
| | Open | mm | 430 ± 3 | 400 ± 3 |
| | Closed | mm | 280 ± 3 | 280 ± 3 |
| Stroke | mm | 150 | 120 | |

Stabilizer bar

| Models: | 60 C - 65 C | | | | | |
|----------------------------|--------------------|--------------------|----------|------|--------------|-------------|
| | Twin cab | Truck Chassis Cabs | Cut Away | Vans | Chassis Cowl | Semi-Glazed |
| Stabilizer bar diameter mm | 20 | | | 22 | | |

TIGHTENING TORQUES







Figure 67



62103

| DESCRIPTION | TORQUE | |
|---|-----------|-------------|
| | Nm | kgm |
| 1 Nut, reaction rod mounting upper fastening to chassis fixing screw | 140 | 14 |
| 2 Nut, reaction rod ball joint to mounting | 98 ÷ 137 | 10 ÷ 14 |
| 3 Nut, reaction rod and knuckle joint stiffener to chassis fixing screw | 41 | 4.1 |
| 4 Nut for screw fixing cross member to reaction rod support | 140 | 14 |
| 5 Nut, ball joint to upper tie rod | 98 ÷ 137 | 10 ÷ 14 |
| 6 Nut, upper tie rod to upper arm fastening screw | 150 ÷ 183 | 15.3 ÷ 18.7 |
| 7 Nut, shock absorber upper and lower fastening screw | 116 ÷ 142 | 11.8 ÷ 14.5 |
| 8 Nut, lower bracket fastening screw suspension adjustment unit | 151 ÷ 184 | 15.4 ÷ 18.8 |
| 9 Nut, torsion bar adjusting lever pin | 197 ÷ 241 | 20 ÷ 24 |
| 10 Nut, cross member to chassis side member lower wing fixing screw | 80 | 8 |
| 11 Nut for steering box fixing screw | 50 ÷ 61 | 5.1 ÷ 6.2 |
| 12 Nut, lower arms to cross member anchoring screw | 206 ÷ 252 | 21.0 ÷ 25.7 |

| DESCRIPTION | TORQUE | |
|--|---------------|-------------|
| | Nm | kgm |
| 13 Ring nut, ball joint to upper/lower arms | 83 ÷ 152 | 8.5 ÷ 15.5 |
| 14 Nut, ball joint to steering knuckle | 157 ÷ 177 | 16 ÷ 18 |
| 15 Nut, fixing will | 284.5 ÷ 343.3 | 28.4 ÷ 34.3 |
| 16 Nut fixing steering box rod ball joint to stub axle lever | 83 ÷ 68 | 8.4 ÷ 6.9 |
| 17 Hexagonal-head slotted nut, torsion bar to suspension arm | 84 ÷ 103 | 8.6 ÷ 10.5 |
| 18 Nut, cross member upper fastening to bracket on chassis side member upper wing fixing screw | 52.5 | 5.2 |
| 19 Nut, cross member upper anchoring bracket to chassis side member upper wing fixing screw | 20 | 2 |
| 20 Nut, upper and intermediate bracket fastening screw (suspension adjustment unit) | 104 | 10.4 |
| - Screw for nut fixing front tubular cross member to side members | 42 ÷ 51 | 4.2 ÷ 5.2 |
| - Nut, stabilizer bar clamps fixing screw | 24.5 | 2.4 |
| - Rubber plug nut | 68 ÷ 83 | 6.9 ÷ 8.5 |

| EQUIPMENT | |
|-----------------|--|
| TOOL No. | DESCRIPTION |
| 99321024 |  <p>Hydraulic trolley for wheel removal and refitting</p> |
| 99347027 |  <p>Tool for removing front suspension rubber bushes</p> |
| 99347060 |  <p>Extractor to take out link pins</p> |
| 99347074 |  <p>Extractor to take out link pins and suspension arms</p> |
| 99357144 |  <p>Tool for link pins fixing screw</p> |
| 99374166 |  <p>Tool for refitting front suspension rubber bushes</p> |


REPAIR OPERATIONS

500760 SUSPENSION OVERHAUL

NOTE It differs from suspension overhaul with torsion bars for vehicles: 35C, 40C, 45C, 50C for the following points.

500764 Lower tie rod articulated heads replacement


Figure 68



Loosen the nut (2) and unscrew the articulated head (1) from the upper tie rod (3).
Screw the new articulated head (1) on the tie rod (3).
Position it according to the values show in the above figure.


500666 TORSION BARS Removal

Figure 69



Remove the nut fastening the steering box tie rod kingpin (4) from stub axle lever; use puller 99347074 (2) to remove the kingpin (4).
Remove suspension lever (1) upper tie rod (3).

Figure 70




61984

Loosen the nut (3) and loosen the threaded pin (2) until the torsion bar (1) is completely "released".

NOTE Take note of the number of pin (2) threads above nut (3); these data shall provide the starting point to adjust the torsion bar after assembling..

NOTE For left torsion bar disconnect the fuel tank.

Figure 71



62925


Remove the nut (2), withdraw the screw (3) and disconnect the shock absorber (4) from the upper support (1).

Remove the nut (7) fastening the articulated head (6) from the upper lever (5) to stub axle (8).

Suitably support the stub axle (8) including the brake calliper and the wheel hub and using tool 99347074 remove the lever (5) from the stub axle (8).

Rest the stub axle (8) on a proper stand to prevent brake fluid pipes and electric cables tensioning.


Figure 72



62931

Remove the circlip (1) from the sleeve (2) and remove it.


Figure 73



62927

Remove the lock nut (6), the nut (7) and withdraw the washer (5).
Remove the torsion bar (2) with the washer (1) from the upper lever (3) and remove it from the bracket (4).

Figure 74




62928

Remove the torsion bar (2) including the circlip (3) and the washer (4) from the adjustment lever (5) and remove it from the bracket (1).

Rubber bush replacement

Removal

Figure 75



62929


Apply tool 99347027 (5) as shown in the figure.

Hold the screw (6), tighten the nut (4) and remove the rubber bushes (3 and 7) from the cross member (1).

NOTE The rubber stop plug (2) is pressure-fitted to cross member (1) and no tool is required for its replacement.

Refitting

Figure 76




62930

Position rubber bushes (2-5) in cross member (1).

Apply tool 99374166 (4) to bushes (2-5) as shown in the figure.

Hold the screw (6) and tighten the nut (3) until fitting in place the rubber bushes (2-5).


Figure 77




62928

Set the adjustment lever (5) in the bracket (1) and insert the torsion bar (2) including the washer (4) and the circlip (3).

Figure 78




19046

 The rear part of the torsion bars is marked with AD-AS to identify respectively the right bar and the left bar.

The splined part is provided with a double tooth (1), that shall coincide at refitting with the double space (2) of the upper lever.


Figure 79



52370

Set the upper lever (2) in the cross member, then insert the torsion bar (1), including the washer (3), into cross member and lever, making the double tooth coinciding with the double space of the lever.


Figure 80



44674

Set the washer (1) and screw the nut (2) without locking it.


Figure 81



44675

Connect the stub axle (3) to the upper lever (1) ball joint; tighten the fastening nut (2) to the specified torque.



Figure 82




62931

Fit the sleeve (3) on the torsion bar (1) and in the adjustment lever (2) so that the marks on these components coincide as shown in the following figure.

Figure 83



AD. Right torsion bar




AS. Left torsion bar

62934

- 1. Bracket - 2. Adjustment lever - 3. Sleeve - 4. Torsion bar - 5. Washer - 6. Circlip - A. Front reference mark on sleeve (3)
- B. Front reference mark on adjustment lever (2) - C. Rear reference mark on sleeve (3) - D. Reference mark on torsion bar (4) - E. Reference mark on left torsion bar - F. Reference mark on right torsion bar.

After refitting torsion bar (4)/ sleeve (3)/ adjustment lever (2), secure the sleeve (3) to the bracket with the circlip (6). Refit the fuel tank (if removed).

Figure 84



62935

Refit the tie rod (6) to the lever (3) without tightening to torque the nut for screw (7); connect the articulated head (4) of the steering box tie rod to the stub axle lever and tighten the nut to the specified torque.

Connect the shock absorber with the screw (5) and the nut (1) and tighten the latter to the specified torque.

Refit wheels, fit nut protection and tighten the fastening nuts; remove stands and lower the vehicle.


Then tighten to the specified torque the following components:

- wheel fastening nuts;
- nut and lock nut fastening the torsion bars to the relevant levers;
- nuts for screws fastening the upper tie rods to the relevant levers.

Adjust torsion bar preload as described in the following paragraph.

Torsion bar preload adjustment

Figure 85



20986

TORSION BAR PRELOAD CHECK DIAGRAM

H = mm, height from ground of side member upper edge measured as close as possible to suspension connection area

RSC (Loaded radius):


- with 225/75R16 tyres, 345 mm with 2500 kg load
- with 7.00R16 tyres, 364 mm with 2000 kg load

Check whether tyre pressure is the specified one and then using the proper gauge, check whether tyre tread depth is almost the same on both wheels.

Measure on both vehicle sides the height (H) from ground of side member upper edge - measured as close as possible to suspension connection area

Height (H) shall correspond to the value specified in the following table.

Figure 86



62936

If a different value is found, operate on the adjustment screw (1) as required, taking into account that before performing this operation the vehicle shall always be lifted from ground with hydraulic jack to prevent screw damaging.

Once proper vehicle setup is obtained, lock the screw with the lock nut (2).

| Load on front wheels (Kg) | Tyres | |
|---------------------------|-------------|-----------|
| | 225/75 R 16 | 7.00 R 16 |
| 1400 | 672 | 691 |
| 1500 | 665.6 | 684.6 |
| 1700 | 652.6 | 671.6 |
| 1800 | 646 | 665 |
| 1900 | 639.4 | 658.4 |
| 2100 | 626.1 | 645.1 |
| 2300 | 612.8 | 631.8 |
| 2400 | 606.1 | 625.1 |
| 2500 | 599.5 | 618.5 |

Rear mechanical suspensions

| | Page |
|---|------|
| DESCRIPTION | 55 |
| CHARACTERISTICS AND DATA | 56 |
| <input type="checkbox"/> Rear leaf spring | 56 |
| <input type="checkbox"/> Rear shock absorbers | 73 |
| TOOLS | 74 |
| TIGHTENING TORQUES | 75 |
| <input type="checkbox"/> Vehicles 29 L - 35 S | 75 |
| <input type="checkbox"/> Vehicles 35 C - 40 C - 45 C - 50 C | 76 |
| <input type="checkbox"/> Vehicles 60 C - 65 C | 77 |
| REAR LEAF SPRING | 78 |
| <input type="checkbox"/> Vehicles: 29 L - 35 S | 78 |
| <input type="checkbox"/> Removal | 78 |
| <input type="checkbox"/> Refitting | 78 |
| <input type="checkbox"/> Vehicles: 35 C - 40 C - 45 C - 50 C - 60 C - 65 C | 79 |
| <input type="checkbox"/> Removal | 79 |
| <input type="checkbox"/> Refitting | 79 |
| REPAIRS | 80 |
| <input type="checkbox"/> Disassembling the leaf spring | 80 |
| <input type="checkbox"/> Checks | 80 |
| <input type="checkbox"/> Assembling the leaf spring | 80 |
| <input type="checkbox"/> Replacing the bushings | 80 |
| REAR SHOCK ABSORBERS | 81 |
| <input type="checkbox"/> Removal | 81 |
| <input type="checkbox"/> Refitting | 81 |
| STABILIZER BAR | 82 |
| <input type="checkbox"/> Removal | 82 |
| <input type="checkbox"/> Refitting | 82 |

DESCRIPTION

The rear suspension is composed of:

- two leaf springs which, according to the vehicle, can be of a semi-elliptic type with double flexibility or of a parabolic type with simple flexibility.;
- two stop bumpers;
- two hydraulic double acting shock absorbers;
- stabilizer bar.

The semi-elliptic leaf spring is very stiff because all leaves forming the leaf spring have the same thickness from one end to the other.

Moreover, leaves are placed one against the other and this causes a great internal friction which limits the movements of the leaf spring.

The parabolic leaf spring is formed by leaves which have a greater thickness in the middle than at the two ends.


Leaves are spaced by means of shims and this reduces much of the internal friction.

The low internal friction and the particular form of the leaves make the parabolic leaf spring more "soft", this makes driving easier.

Hydraulic double-acting telescopic shock absorbers, hinder the wheel movement both upwards and downwards, allowing a great driving stability.

The stabilizer bar must keep the geometry between the wheel axle and the chassis and arrange the load evenly over the wheels on the same axle.

Figure 87











52371

REAR SUSPENSION

CHARACTERISTICS AND DATA**Rear leaf spring**









Vehicles: 29 L - 35 S

| | | mm |
|---|--|--|
|  | Parabolic springs | N° 2 |
|  | Spring length (measured at eye centres) | 1500 ± 3 |
|  | Leaf thickness (measured at centre) | 24 (22)* |
|  | Gap between leaves | - |
|  | Leaf width | 80 ± 0.5 |
|  | CONTROL DATA WITH NEW SPRING: Spring flexibility with static load | 8.6 mm/kN |
|  | Main leaf eye inner diameter (Bush seat) | 40 ± 0.5 |
|  | D = bush outer diameter d = bush inner diameter | $40^{+0}_{-0.1}$ $16.5^{+0.2}_{-0}$ |

(*) Alternatively









Rear leaf spring

Vehicles: 35 C - Camper version

| | | |
|---|--|--|
| | | mm |
|  | Parabolic springs | Nº 2 |
|  | Spring length (measured at eye centres) | 1415 ± 3 |
|  | Leaf thickness (measured at centre) | - |
|  | Gap between leaves | 15 |
|  | Leaf width | 60 ± 0.5 |
|  | CONTROL DATA WITH NEW SPRING: Spring flexibility with static load | 6.4 mm/kN |
|  | Main leaf eye inner diameter (Bush seat) | 40 ± 0.5 |
|  | D = bush outer diameter d = bush inner diameter | 40 ⁺⁰ _{-0.1} 16.5 ^{+0.2} ₋₀ |

Rear leaf spring









Vehicles: 35 C

| | | |
|---|--|--|
| | | mm |
|  | Parabolic springs | Nº 2 |
|  | Spring length (measured at eye centres) | 1415 ± 3 |
|  | Leaf thickness (measured at centre) | 19 |
|  | Gap between leaves | 3 (1 × 3 + 1 × 25)* |
|  | Leaf width | 60 ± 0.5 |
|  | CONTROL DATA WITH NEW SPRING: Spring flexibility with static load | 10.5 mm/kN |
|  | Main leaf eye inner diameter (Bush seat) | 40 ± 0.5 |
|  | D = bush outer diameter d = bush inner diameter | 40 ⁺⁰ _{-0.1} 16.5 ^{+0.2} ₋₀ |

(*) For versions with maximum front load = 1900 kg









Rear leaf spring

Vehicles: 40 C chassis cowl

| | | |
|---|---|--|
| | | mm |
|  | Parabolic springs | Nº 2 |
|  | Spring length (measured at eye centres) | 1415 ± 3 |
|  | Leaf thickness (measured at centre) | 22 |
|  | Gap between leaves | 3 |
|  | Leaf width | 60 ± 0.5 |
|  | CONTROL DATA WITH NEW SPRING: Main spring flexibility with static load | 7.6 mm/kN |
|  | Main leaf eye inner diameter (Bush seat) | 40 ± 0.5 |
|  | D = bush outer diameter d = bush inner diameter | 40 ⁺⁰ _{-0.1} 16.5 ^{+0.2} ₋₀ |









Rear leaf spring

Vehicles: 40 C

| | | mm |
|---|---|--|
|  | Parabolic springs | Nº 2 |
|  | Spring length (measured at eye centres) | 1415 ± 3 |
|  | Leaf thickness (measured at the centre) thickness of the auxiliary leaf (measured at the centre) | 18 18 |
|  | Gap between leaves | 3 |
|  | Leaf width | 60 ± 0.5 |
|  | CONTROL DATA WITH NEW SPRING: Main spring flexibility with static load | 7.6 mm/kN |
|  | Main leaf eye inner diameter (Bush seat) | 40 ± 0.5 |
|  | D = bush outer diameter d = bush inner diameter | 40 ⁺⁰ _{-0.1} 16.5 ^{+0.2} ₋₀ |

Rear leaf spring









Vehicles: 45 C

| | | |
|---|--|--|
| | | mm |
|  | Parabolic springs | Nº 2 |
|  | Spring length (measured at eye centres) | 1415 ± 3 |
|  | Leaf thickness (measured at centre) | 22 (23)* |
|  | Gap between leaves | 3 |
|  | Leaf width | 60 ± 0.5 |
|  | CONTROL DATA WITH NEW SPRING: Spring flexibility with static load | 6.9 mm/kN |
|  | Main leaf eye inner diameter (Bush seat) | 40 ± 0.5 |
|  | D = bush outer diameter d = bush inner diameter | 40 ⁺⁰ _{-0.1} 16.5 ^{+0.2} ₋₀ |

(*) Alternatively









Rear leaf spring

Vehicles: 50 C

| | | mm |
|---|--|---|
|  | Parabolic springs | N° 2 |
|  | Spring length (measured at eye centres) | 1415 ± 3 |
|  | Leaf thickness (measured at centre) | 19 |
|  | Gap between leaves | 3 |
|  | Leaf width | 60 ± 0.5 |
|  | CONTROL DATA WITH NEW SPRING: Main spring deflection with static load Auxiliary spring deflection with static load Main spring flexibility with static load | 5.6 mm/kN |
|  | Main leaf eye inner diameter (Bush seat) | 40 ± 0.5 |
|  | D = bush outer diameter d = bush inner diameter | 40 ⁺⁰ _{-0.1} 16.5 ^{+0.02} ₋₀ |

Rear leaf spring









Vehicles: 60 C - 65 C

| | | |
|---|---|--|
| | | mm |
|  | Parabolic springs | Nº 2 |
|  | Spring length (measured at eye centres) | 1415 ± 3 |
|  | Thickness of the main leaves (measured at the centre) thickness of the auxiliary leaf (measured at the centre) | 18 (19)* 28 |
|  | Gap between leaves | 3 |
|  | Leaf width | 70 ± 0.5 |
|  | CONTROL DATA WITH NEW SPRING: Main spring deflection with static load Flexibility with static load after aux. spring action | 9.3 mm/kN 3.4 mm/kN |
|  | Main leaf eye inner diameter (Bush seat) | $40^{+0.5}_{-0.2}$ |
|  | D = bush outer diameter d = bush inner diameter | $40^{+0.02}_{-0.07}$ $16.5^{+0.2}_{-0}$ |

(*) Alternatively









Rear leaf spring

Vehicles: 35 C

| | | mm |
|---|--|---|
|  | Semi-elliptical springs | N° 2 |
|  | Spring length (measured at centre of eyes) | 1415 ± 4 |
|  | Leaf thickness (measured at the centre), main leaf (1st - 4th) auxiliary leaf (1st - 2nd) | 9 15 |
|  | Gap between leaves | -- |
|  | Leaf width | 60 ± 0.5 |
|  | CONTROL DATA WITH NEW SPRING: Main spring flexibility with static load Flexibility with static load after aux. spring action | 20.2 mm/kN 10.4 mm/kN |
|  | Main leaf eye inner diameter (Bush seat) | 40 ± 0.5 |
|  | D = bush outer diameter d = bush inner diameter | 40 ⁺⁰ _{-0.1} 16.5 ^{+0.02} ₋₀ |









Rear leaf spring

Vehicles: 35 C - 40 C

| | | mm |
|---|--|--|
|  | Semi-elliptical springs | N° 2 |
|  | Spring length (measured at centre of eyes) | 1415 ± 4 |
|  | Leaf thickness (measured at the centre), main leaf (1st - 4th) auxiliary leaf (1st - 3rd) | 9 15 |
|  | Gap between leaves | -- |
|  | Leaf width | 60 ± 0.5 |
|  | CONTROL DATA WITH NEW SPRING: Main spring flexibility with static load Flexibility with static load after aux. spring action | 19.7 mm/kN 6.4 mm/kN |
|  | Main leaf eye inner diameter (Bush seat) | 40 ± 0.5 |
|  | D = bush outer diameter d = bush inner diameter | 40 ⁺⁰ _{-0.1} 16.5 ^{+0.2} ₋₀ |









Rear leaf spring

Vehicles: 45 C - 50 C (semi-elliptical with leaf spring)

| | | |
|---|--|---|
| | | mm |
|  | Semi-elliptical springs | N° 2 |
|  | Spring length (measured at centre of eyes) | 1415 ± 4 |
|  | Leaf thickness (measured at the centre), master leaf (1st - 7th) additional leaf (1st - 6th) | 9 8 |
|  | Gap between leaves | 7 |
|  | Leaf width | 60 ± 0.5 |
|  | CONTROL DATA WITH NEW SPRING: Main spring flexibility with static load Flexibility with static load after aux. spring action | 15 mm/kN 3.6 mm/kN |
|  | Main leaf eye inner diameter (Bush seat) | 40 ± 0.5 |
|  | D = bush outer diameter d = bush inner diameter | 40 ⁺⁰ _{-0.1} 16.5 ^{+0.02} ₋₀ |









Rear leaf spring

Vehicles: 45 C

| | | mm |
|---|--|--|
|  | Semi-elliptical springs | N° 2 |
|  | Spring length (measured at centre of eyes) | 1415 ± 4 |
|  | Leaf thickness (measured at the centre), master leaf (1st - 4th) additional leaf (5th - 7th) | 9 15 |
|  | Gap between leaves | - |
|  | Leaf width | 60 ± 0.5 |
|  | CONTROL DATA WITH NEW SPRING: Main spring flexibility with static load Flexibility with static load after aux. spring action | 19.7 mm/kN 5.8 mm/kN |
|  | Main leaf eye inner diameter (Bush seat) | 40 ± 0.5 |
|  | D = bush outer diameter d = bush inner diameter | 40 ⁺⁰ _{-0.1} 16.5 ^{+0.2} ₋₀ |









Rear leaf spring

Vehicles: 45 C - 50 C (semi-elliptical with leaf spring)

| | | |
|---|--|--|
| | | mm |
|  | Semi-elliptical springs | N° 2 |
|  | Spring length (measured at centre of eyes) | 1415 ± 4 |
|  | Leaf thickness (measured at the centre), master leaf (1st - 7th) additional leaf (1st - 6th) | 9 8 |
|  | Gap between leaves | 10 |
|  | Leaf width | 60 ± 0.5 |
|  | CONTROL DATA WITH NEW SPRING: Main spring flexibility with static load Flexibility with static load after aux. spring action | 14.5 mm/kN 3.4 mm/kN |
|  | Main leaf eye inner diameter (Bush seat) | 40 ± 0.5 |
|  | D = bush outer diameter d = bush inner diameter | 40 ⁺⁰ _{-0.1} 16.5 ^{+0.2} ₋₀ |









Rear leaf spring

Vehicles: 50 C

| | | mm |
|---|--|--|
|  | Semi-elliptical springs | N° 2 |
|  | Spring length (measured at centre of eyes) | 1415 ± 4 |
|  | Leaf thickness (measured at the centre), master leaf (1st - 4th) additional leaf (1st - 3th) | 9 16 |
|  | Gap between leaves | 10 |
|  | Leaf width | 60 ± 0.5 |
|  | CONTROL DATA WITH NEW SPRING: Main spring flexibility with static load Flexibility with static load after aux. spring action | 19.7 mm/kN 4.9 mm/kN |
|  | Main leaf eye inner diameter (Bush seat) | 40 ± 0.5 |
|  | D = bush outer diameter d = bush inner diameter | 40 ⁺⁰ _{-0.1} 16.5 ^{+0.2} ₋₀ |

Rear leaf spring









Vehicles: 50 C

| | | mm |
|---|---|--|
|  | Parabolic springs | Nº 2 |
|  | Spring length (measured at eye centres) | 1415 ± 3 |
|  | Leaf thickness (measured at the centre) master leaf | 22 (24)* |
|  | Gap between leaves | 3 (10)* |
|  | Leaf width | 60 ± 0.5 |
|  | CONTROL DATA WITH NEW SPRING: Main spring flexibility with static load | 5.6 mm/kN |
|  | Main leaf eye inner diameter (Bush seat) | 40 ± 0.5 |
|  | D = bush outer diameter d = bush inner diameter | 40 ⁺⁰ _{-0.1} 16.5 ^{+0.2} ₋₀ |

(*) Alternatively









Rear leaf spring

Vehicles: 60 C - 65 C

| | | mm |
|---|--|--|
|  | Semi-elliptical springs | Nº 2 |
|  | Spring length (measured at centre of eyes) | 1415 ± 4 |
|  | Leaf thickness (measured at the centre), master leaf (1st - 4th) additional leaf (1st - 2nd) | 11 22 |
|  | Gap between leaves | -- |
|  | Leaf width | 70 ± 0.5 |
|  | CONTROL DATA WITH NEW SPRING: Main spring flexibility with static load Flexibility with static load after aux. spring action | 9.3 mm/kN 3.1 mm/kN |
|  | Main leaf eye inner diameter (Bush seat) | 40 ^{+0.5} _{-0.2} |
|  | D = bush outer diameter d = bush inner diameter | 40 ^{+0.02} _{-0.07} 16.5 ^{+0.2} ₋₀ |




Rear leaf spring

Vehicles: 60 C - 65 C (semi-elliptical with leaf spring)

| | | |
|---|--|---|
| | | mm |
|  | Semi-elliptical springs | N° 2 |
|  | Spring length (measured at centre of eyes) | 1415 |
|  | Leaf thickness (measured at the centre), master leaf (1st - 10th) auxiliary leaf thickness (1st - 10th) | 9 7 |
|  | Gap between leaves | 9 |
|  | Leaf width | 70 ± 0.5 |
|  | CONTROL DATA WITH NEW SPRING: Main spring flexibility with static load Flexibility with static load after aux. spring action | 8.5 mm/kN 2.4 mm/kN |
|  | Main leaf eye inner diameter (Bush seat) | 40 ^{+0.5} _{-0.2} |
|  | D = bush outer diameter d = bush inner diameter | 40 ^{+0.02} _{-0.07} 16.5 ^{+0.02} ₋₀ |

(*) Alternatively

Rear shock absorbers

| Models: | 29 L - 35 S | | |
|---|----------------------------------|---------------|------------|
|  | | Arvin Meritor | Sachs |
| | Distance between centre of eyes: | | |
| | Open | 475 ± 3 mm | 480 ± 3 mm |
| | Closed | 302 ± 3 mm | 300 ± 3 mm |
| | Stroke | 173 mm | 180 mm |
| Models: | 35 C - 40 C - 45 C - 50 C | | |
|  | | Arvin Meritor | Sachs |
| | Distance between centre of eyes: | | |
| | Open | 571 ± 3 mm | 565 ± 3 mm |
| | Closed | 350 ± 3 mm | 345 ± 3 mm |
| | Stroke | 221 mm | 220 mm |
| Models: | 60 C - 65 C | | |
|  | | Arvin Meritor | Sachs |
| | Distance between centre of eyes: | | |
| | Open | 564 ± 3 mm | 565 ± 3 mm |
| | Closed | 347 ± 3 mm | 345 ± 3 mm |
| | Stroke | 217 mm | 220 mm |


Rear stabilizer bar

| Models: | 29 L - 35 S - 35 C - 40 C | 45 C - 50 C Vans | 45 C - 50 C Truck Chassis Cabs | 60 C - 65 C |
|------------------------------|---------------------------|---------------------|--------------------------------------|-------------|
| Stabilizer bar diameter (mm) | 18 | 20 | 22 | 28 |


TOOLS

TOOL NO.


DESCRIPTION

99306064

Hydraulic trolley to support leaf spring during removal and refitting

99321024


Hydraulic trolley for wheel removal and refitting

99370617

Bracket for removal - refitting and/or support of rear axle

TIGHTENING TORQUES
Vehicles 29 L - 35 S

Figure 88




NOTE The diagram refers to vans with wheelbase 3000 - 3300 mm.

| COMPONENT | | TORQUE | |
|-----------|---|-------------|-------------|
| | | Nm | kgm |
| 1 | M16 nut for screw securing front leaf spring | 139 ÷ 170 | 13.9 ÷ 17 |
| 2 | M10 screw for nut securing stabilizer bar support cap | 26.4 ÷ 35.3 | 2.6 ÷ 3.5 |
| 3 | M10 nut for screw securing stabilizer bar support | 26.4 ÷ 35.3 | 2.6 ÷ 3.5 |
| 4 | M16 nut for screw securing top and bottom shock absorber | 124 ÷ 152 | 12.4 ÷ 15.2 |
| 5 | M16 screw for nut securing rear leaf spring | 139 ÷ 170 | 13.9 ÷ 17 |
| 6 | M16 screw for nut securing shackle to rear mounting | 130 ÷ 170 | 13 ÷ 17 |
| 7 | M10 screw for nut securing stabilizer bar anchoring connecting rod to the rear axle | 26.4 ÷ 35.3 | 2.6 ÷ 3.5 |
| 8 | Nut for screw securing shock absorber top mounting to the chassis frame | 47 ÷ 58 | 4.7 ÷ 5.8 |
| 9 | M12 nuts for stands securing leaf spring to the rear axle | 98 ÷ 120 | 9.8 ÷ 12 |
| 10 | M10 nuts for screws securing leaf spring rear mounting | 43 ÷ 53 | 4.3 ÷ 5.3 |

TIGHTENING TORQUES

Vehicles 35 C - 40 C - 45 C - 50 C

Figure 89




50814

| COMPONENT | | TORQUE | |
|-----------|---|---------------------|-------------|
| | | Nm | kgm |
| 1 | M16 nut for screw securing front leaf spring | 139 ÷ 170 | 13.9 ÷ 17 |
| 2 | Nuts for stands securing leaf spring to the rear axle | M 14 74.5 ÷ 91.2 | 7.4 ÷ 9.1 |
| | | M16 113 ÷ 170 | 11.3 ÷ 17 |
| 3 | M16 nut for screw securing top and bottom shock absorber | 124 ÷ 152 | 12.4 ÷ 15.2 |
| 4 | M10 nut for screw securing stabilizer bar support cap | 26.4 ÷ 35.3 | 2.6 ÷ 3.5 |
| 5 | M10 nut for screw joining stabilizer bar anchoring connecting rods | 26.4 ÷ 35.3 | 2.6 ÷ 3.5 |
| 6 | M16 screw for nut securing connecting rod to mounting | 179.4 ÷ 220.6 | 17.9 ÷ 22 |
| 7 | M16 screw for nut securing rear leaf spring | 139 ÷ 170 | 13.9 ÷ 17 |
| 8 | M16 screw for nut securing shackle to rear mounting | 139 ÷ 170 | 13.9 ÷ 17 |
| 9 | M10 screw for nut securing connecting rod mounting to the chassis frame | 43 ÷ 53 | 4.3 ÷ 5.3 |
| 10 | M8 screw for nut securing buffer to the chassis frame | 26.4 ÷ 35.3 | 2.6 ÷ 3.5 |

TIGHTENING TORQUES

Vehicles 60C - 65C

Figure 90




62937

| COMPONENT | | TORQUE | |
|-----------|---|---------------|-------------|
| | | Nm | kgm |
| 1 | Screw for front leaf spring fastening nut | 186 ÷ 152 | 18.6 ÷ 15.2 |
| 2 | M16 nut for upper and lower shock absorber fastening screw | 92 ÷ 74 | 9.2 ÷ 7.4 |
| 3 | Nut for stands fastening leaf spring to rear axle | 150 ÷ 190 | 15.3 ÷ 19.3 |
| 4 | Nut for screw fastening brackets and spacers to stabilizer bar supporting rod | | |
| 5 | Screw for rear leaf spring fastening nut | 186 ÷ 152 | 18.6 ÷ 15.2 |
| 6 | Screw for nut fastening connecting rods to support | 186 ÷ 152 | 18.6 ÷ 15.2 |
| 7 | Nut for screw fastening stabilizer bar spacer and rod to support | 109.9 ÷ 137.7 | 11.2 ÷ 14 |
| 8 | M10 screw for nut fastening support to chassis | 26.4 ÷ 32.3 | 2.7 ÷ 3.3 |
| 9 | Screw for nut fastening cross member to chassis | 71.7 ÷ 87.7 | 7.3 ÷ 8.9 |
| 10 | Nut fastening bumper to chassis | 49 ÷ 40 | 4.9 ÷ 4 |

REAR LEAF SPRING

Vehicles: 29 L - 35 S

Figure 91



50972A

REAR SUSPENSION WITH SINGLE-BLADE PARABOLIC LEAF SPRING



Removal

Set the vehicle on level ground. Lock the front wheels with chocks. Loosen the screws securing the rear wheels.

Put the bracket 99370617 on a hydraulic lift, position it under the rear axle and lift the vehicle.

Rest the chassis frame on stands, keeping the bracket in contact with the rear axle.

Take out the nuts securing the wheels with tool 99321024.

Take out the nuts (4) and remove the brackets (5) joining the leaf springs (2) to the rear axle.

Position the trolley 99306064 under the leaf spring (2) and fasten this to the trolley support with the brackets.

Take out the nuts and remove the screw (3) securing the leaf spring (2) to the front mounting (1).

Take out the nut and remove the screw (7) securing the leaf spring (2) to the shackle (8) of the rear mounting (9).

Lower the trolley 99306064 and extract the leaf spring.



Refitting

To re-fit, carry out the removal operations in reverse, taking the following precautions.




Check the threads of brackets which fasten the leaf springs to the axle; if they are damaged, re-machine the threads (operation 500412) or replace the brackets.

Check the conditions of bumpers (6), if they are damaged, replace them (operation 500417).



Tighten the nuts to the prescribed driving torque. Following the order shown in the figure.

After replacing the leaf springs and the hydraulic shock absorbers, it is necessary to check the efficiency of the braking control and, if necessary, carry out its adjustment (operation 796910. See Braking System Section).

Vehicles: 35 C - 40 C - 45 C - 50 C - 60 C - 65 C**Figure 92**

50973

REAR SUSPENSION WITH SEMI-ELLIPTICAL LEAF SPRING**Removal**

Set the vehicle on level ground. Lock the front wheels with chocks. Loosen the screws securing the rear wheels.

Put the bracket 99370617 on a hydraulic lift, position it under the rear axle and lift the vehicle rest the chassis frame on stands, keeping the bracket in contact with the rear axle.

Take out the nuts securing the wheels with tool 99321024.


Take out the nuts (5) and remove the brackets (4) joining the leaf springs (3) to the rear axle.

Position the trolley 99306064 under the leaf spring and fasten this to the trolley support with the brackets.

Take out the nut and remove the screw (2) securing the leaf spring (3) to the front mounting (1).

Take out the nut and remove the screw (8) securing the leaf spring (3) to the shackle (7) of the rear mounting (6).

Operating the hydraulic lift, lower the rear axle to be able to remove the centring setscrew of the leaf spring from it and extract the leaf spring.

 When lowering the rear axle, make sure the brake system pipes are not put under strain.

Refitting

To re-fit, carry out the removal operations in reverse, taking the following precautions.



Check the threads of brackets which fasten the leaf springs to the axle; if they are damaged, re-machine the threads (operation 500412) or replace the brackets.



Check the conditions of bumpers (9), if they are damaged, replace them.



Tighten the nuts to the prescribed driving torque. Following the order shown in the figure.

After replacing the leaf springs and the hydraulic shock absorbers, it is necessary to check the efficiency of the braking control and, if necessary, carry out its adjustment (operation 796910. See Braking System Section).

REPAIRS


Disassembling the leaf spring



Leaf springs must be disassembled only Figure 93 if it is necessary to replace the main leaf (1) or the first leaf (4), in this case go on as follows.

In case other leaves are broken or yielded, replace the whole leaf spring.

Figure 93



19074

Place the leaf spring in the vice of the suitable bench, clamping it near the central pin; remove the relevant nut and extract the central coupling pin.

Unscrew the fastening nut (2) of the central pin (7) and extract the pin. Open the pack side clips (5), lifting the two ends that are bent on the main leaf. Open the vice and disassemble the leaf spring.



Side clips (5) fastened with a rivet (6) to the leaf, can be re-used, provided that they do not show signs of breakage when they are re-bent to hold the pack. In this case, it is necessary to replace them with new ones to be fixed to the leaf with new rivets.

Checks



Carefully clean, with diesel oil or solvent, all components; ensure that the bushes are firmly driven in the spring eyes and shackles.



Check that the internal surface is not ovalized and that the pins are not worn or strained, in case they are, replace them.

Assembling the leaf spring


Ensure that the leaf contact surfaces are perfectly smooth and clean.

Before re-assembling the leaves, grease contact surfaces with a little of CA IG Grease.

Re-assemble the pack as follows (see Figure 93):

- place the main leaf (1) with the end eyes in the end pin of the 1st leaf (4);
- place the other leaves, included the one with the clip (5), near the former ones, rest them on one side and align them in the bench vice;
- insert through the central hole of the leaves, the central pin (7), then lock the pack in the vice;
- insert the nut (2) on the central pin (7) and lock;

Figure 94



19075

- close the two side retaining clamps (5) by folding the ends back as shown in the figure.

500454 Replacing the bushings

The leaf spring bushings (3) are replaced with the hydraulic press and a suitable punch.


500940 REAR SHOCK ABSORBERS**Removal**

Remove the shock absorber (1) extracting the upper and lower fastening nuts or bolts (\Leftrightarrow) of the shock absorber.

**Refitting**

To re-fit shock absorbers carry out the removal operations in reverse and comply with the prescribed torques.


Figure 95



50975

REAR AXLE SHOCK ABSORBERS VEHICLES 29 L - 35 S

Figure 96



50977

REAR AXLE SHOCK ABSORBERS VEHICLES 35 C - 65 C

528960 STABILIZER BAR**Removal**

Remove the shock absorber bar (1) from its points of connection by taking out the fixing nuts and bolts (⇐).




Check that the bushings and/or flexible parts are not worn or deteriorated, if they are, replace them.

**Refitting**


For refitting, carry out the removal operations in reverse and comply with the prescribed torques.

Figure 97



REAR STABILIZER BAR VEHICLES 29 L - 35 S

Figure 98



REAR STABILIZER BAR VEHICLES 35 C - 65 C

| | Page |
|--|------|
| DIAGNOSTIC | 85 |
| REAR PNEUMATIC SUSPENSIONS - VB-TECHNIEK TYPE | 86 |
| <input type="checkbox"/> Blink - code | 86 |
| REAR PNEUMATIC SUSPENSIONS - WABCO TYPE | 86 |
| <input type="checkbox"/> Blink-code | 86 |
| <input type="checkbox"/> Failure code table | 87 |
| GENERAL | 88 |
| PNEUMATIC SUSPENSIONS - WABCO TYPE (for R 29L - 35S vehicles) | 88 |
| SPECIFICATIONS AND DATA | 89 |
| <input type="checkbox"/> Air system components | 89 |
| <input type="checkbox"/> Rear leaf spring | 90 |
| <input type="checkbox"/> Rear shock absorbers | 90 |
| <input type="checkbox"/> Stabilizer bar | 90 |
| <input type="checkbox"/> Levelling and height values | 90 |
| ELECTRIC SYSTEM WABCO (ECAS) | 91 |
| PNEUMATIC SYSTEM WABCO (ECAS) | 92 |
| PNEUMATIC SYSTEM ON VEHICLE | 93 |
| <input type="checkbox"/> Vehicles without ABS | 93 |
| <input type="checkbox"/> Vehicles with ABS | 94 |
| CHASSIS SELF-LEVELLING, LIFTING AND LOWERING | 95 |
| <input type="checkbox"/> Operation | 95 |
| MAIN SYSTEM COMPONENTS | 95 |
| PNEUMATIC SUPPLY UNIT | 95 |
| <input type="checkbox"/> Specifications and data | 95 |
| ELECTRONIC CONTROL UNIT | 95 |
| <input type="checkbox"/> ECU programming/setting | 96 |
| LEVEL SENSOR | 96 |
| <input type="checkbox"/> Level sensor replacement | 96 |

Rear air suspensions

| | Page |
|--|------|
| <input type="checkbox"/> Removal | 96 |
| <input type="checkbox"/> Refitting | 96 |
| <input type="checkbox"/> Level sensor adjustment | 96 |
| AIR SPRING | 97 |
| <input type="checkbox"/> Air spring replacement | 97 |
| <input type="checkbox"/> Removal | 97 |
| <input type="checkbox"/> Refitting | 97 |
| LOAD SENSING VALVE | 97 |
| <input type="checkbox"/> Load sensing valve replacement | 98 |
| <input type="checkbox"/> Removal | 98 |
| <input type="checkbox"/> Refitting | 98 |
| <input type="checkbox"/> Load sensing valve adjustment on vehicle | 98 |
| REAR SUSPENSION OVERHAUL | 99 |
| LEAF SPRING | 99 |
| <input type="checkbox"/> Removal | 99 |
| <input type="checkbox"/> Refitting | 99 |
| REAR SHOCK ABSORBERS | 99 |
| <input type="checkbox"/> Removal | 99 |
| <input type="checkbox"/> Refitting | 99 |
| REAR STABILIZER BAR | 99 |
| <input type="checkbox"/> Removal | 99 |
| <input type="checkbox"/> Refitting | 99 |
| PANHARD REACTION BAR | 100 |
| <input type="checkbox"/> Removal | 100 |
| <input type="checkbox"/> Refitting | 100 |
| AIR SUSPENSIONS TYPE VB-TECHNIEK (FOR VEHICLES 35C - 40C - 45C - 50C - 60C - 65C) | 101 |
| GENERAL INFORMATION | 101 |
| SPECIFICATIONS AND DATA | 102 |
| <input type="checkbox"/> Pneumatic system (for vehicles 35 C - 40 C) . | 102 |
| <input type="checkbox"/> Rear leaf spring (vehicles 35 C - 40 C) | 102 |


| | Page |
|--|------|
| <input type="checkbox"/> Rear leaf spring (vehicles 45 C - 50 C) | 103 |
| <input type="checkbox"/> Rear shock absorbers | 103 |
| <input type="checkbox"/> Levelling and height values | 103 |
| VB TECHNIEK ELECTRIC SYSTEM | 104 |
| PNEUMATIC SYSTEM | 105 |
| VB-TECHNIEK ELECTRICAL SYSTEM (60 C - 65 C VEHICLES) | 106 |
| PNEUMATIC SYSTEM (VEHICLES: 60 C - 65 C) | 107 |
| PNEUMATIC SYSTEM ON VEHICLE | 108 |
| <input type="checkbox"/> Vehicles without ABS (35C - 40C - 45 C - 50 C) | 108 |
| <input type="checkbox"/> Vehicles with ABS (35C - 40C - 45 C - 50 C) . | 109 |
| <input type="checkbox"/> 60 C - 65 C vehicles without ABS | 110 |
| <input type="checkbox"/> 60 C - 65 C vehicles with ABS | 111 |
| CHASSIS SELF-LEVELLING, LIFTING AND LOWERING | 112 |
| <input type="checkbox"/> Operation | 112 |
| MAIN SYSTEM COMPONENTS | 112 |
| ELECTROCOMPRESSOR | 112 |
| ELECTRONIC CONTROL UNIT | 112 |
| <input type="checkbox"/> ECU programming/setting | 112 |
| LEVEL SENSOR | 113 |
| <input type="checkbox"/> Level sensor replacement | 113 |
| <input type="checkbox"/> Removal | 113 |
| <input type="checkbox"/> Refitting | 113 |
| <input type="checkbox"/> Level sensor adjustment | 113 |
| AIR SPRING | 113 |
| <input type="checkbox"/> Air spring replacement | 114 |
| <input type="checkbox"/> Removal | 114 |
| <input type="checkbox"/> Refitting | 114 |
| LOAD SENSING VALVE | 114 |
| <input type="checkbox"/> Load sensing valve replacement | 114 |
| <input type="checkbox"/> Removal | 114 |
| <input type="checkbox"/> Refitting | 114 |
| <input type="checkbox"/> Load sensing valve adjustment on vehicle | 114 |

| | Page |
|--|------|
| REAR SUSPENSION OVERHAUL (vehicles 30 C - 35C - 40C - 45 C) | 115 |
| LEAF SPRING | 115 |
| <input type="checkbox"/> Removal | 115 |
| <input type="checkbox"/> Refitting | 115 |
| REAR SHOCK ABSORBERS | 116 |
| <input type="checkbox"/> Removal | 116 |
| <input type="checkbox"/> Refitting | 116 |
| PANHARD REACTION BAR | 116 |
| <input type="checkbox"/> Removal | 116 |
| <input type="checkbox"/> Refitting | 116 |
| REAR STABILIZER BAR | 116 |
| <input type="checkbox"/> Removal | 116 |
| <input type="checkbox"/> Refitting | 116 |

DIAGNOSTIC

Pneumatic suspension main failures:

- 1 - Poor or irregular pneumatic system supply;
- 2 - Vehicle irregular conditions.



REAR PNEUMATIC SUSPENSIONS - VB-TECHNIEK TYPE**Blink - code**

Blink-code led is set between the rear part of the ECU and the electrocompressor box to which it is secured.

Each time the ignition key is turned to "MAR", the led goes on and then goes off after five seconds. The following situations can then take place:

| Led blinking | Failure | Check |
|---------------------|--|--|
| Always OFF | Power | Fuses, power cable |
| Always ON | Level sensor | Sensor, levers and power cable operation |
| Fast blinking | Electrocompressor overload (if five minutes later the electrocompressor restarts, failure can be due to air leak or vehicle use under overload conditions) | Air springs, compressor, pneumatic circuit |
| Slow blinking | Electrocompressor overload (manual lifting push button have been depressed for more than two minutes) | Never depress lifting push button for more than two minutes |
| Dimmed light | Light dims out if levelling push buttons are depressed at the same time or if one push button is faulty | Push buttons and wiring, never depress the push buttons at the same time |

REAR PNEUMATIC SUSPENSIONS - WABCO TYPE

Certain electric or pneumatic failures can be detected through Modus, IT 2000 or E.A.SY..

In case of component assembling or replacement it shall be necessary to perform system setting to guarantee proper operation of the entire system.

Diagnostic connector is set on the right side of the engine compartment. Use adapter 99331043 to connect with diagnostic equipment.

According to detected failures, the red warning light set on the dashboard goes on as follows:

- FIXED LIGHT: indicates failures;
- BLINKING LIGHT: indicates electrocompressor excessive temperature

Blink-code

The Blink-Code system "displays" one failure at a time. To identify every failure stored in the ECU it is therefore necessary to repeat the code activation procedure several times.

The Blink-Code can be activated by grounding the Diagnostic socket line L (pin 2) for 2 seconds at least with ignition key set to "MAR".

Should line L be grounded for more than 5 seconds, the Blink-Code shall not be activated and ECU is reset for standard operation.

The Blink-Code consists of two figures (Tens and Units):

- Tens blinking 2 sec. (Slow)
- Units blinking 0.5 sec. (Fast)

Failure code table

| FAILURE TYPE | FAILURE CODE |
|--|---------------------|
| ECU | |
| Checksum errors | |
| Parameter error | 01 |
| Level sensor setting data error | 02 |
| ROM internal memory fault | 03 |
| WABCO data error | 04 |
| Level sensor value error | 05 |
| Pressure sensor setting data error | 07 |
| RAM memory fault | 06 |
| PIN 1 cut-off (battery power) | 08 |
| WABCO specific data | 80 |
| Internal relay valve fault | 09 |
| Vehicle speed signal (cut-off/short circuit to +Vbatt) | 81 |
| Level sensor failure: cut-off/short circuit to +Vbatt | |
| RH rear level sensor | 10 |
| LH rear level sensor | 11 |
| Level sensor failure: short circuit to ground | |
| RH rear level sensor | 20 |
| LH rear level sensor | 21 |
| Solenoid valve/relay failure: cut-off/short circuit to +Vbatt | |
| Compressor relay | 30 |
| LH rear compressor solenoid valve | 31 |
| RH rear compressor solenoid valve | 32 |
| Intake/exhaust solenoid valve | 35 |
| Solenoid valve/relay failure: short circuit to +Vbatt | |
| Compressor relay | 40 |
| LH rear compressor solenoid valve | 41 |
| RH rear compressor solenoid valve | 42 |
| Intake/exhaust solenoid valve | 45 |
| Plausibility during air bellows lifting/inflating | |
| RH rear level sensor | 50 |
| LH rear level sensor | 51 |
| Plausibility during air bellows lowering/deflating | |
| RH rear level sensor | 60 |
| LH rear level sensor | 61 |

GENERAL

These pneumatic suspensions show high flexibility and significant vibration damping. Their main characteristic is that the distance between chassis and road level, irrespectively of vehicle load, remains constant due to the effect of the automatic adjustment of the system.

Electronic-control pneumatic suspensions are activated automatically when starting the vehicle.

Electronic-control pneumatic suspensions enable, through the proper push buttons located in the cab, to change manually the distance between chassis and road level and therefore the height of the vehicle load bed.

The following two types of pneumatic suspensions are currently adopted:

- WABCO pneumatic suspensions for 29L - 35S vehicles
- VB - Techniek pneumatic suspensions for 35C - 40C - 45C - 50C - 60C - 65C vehicles.

PNEUMATIC SUSPENSIONS - WABCO TYPE (for 29L - 35S vehicles)

WABCO system in addition to known advantages offered by pneumatic suspension, enables the following:

- significant air consumption reduction;
- ready response to the different adjustment processes;
- friendly systems;
- high safety performance;
- complete system diagnostic.


The WABCO system controls automatically the rated level of vehicle pneumatic suspensions.

The above mentioned operations are bound to preset operating conditions and to the relevant system safety requirements.

The ECU controls automatically the chassis level (distance from road level), through the real values provided by sensors and compares these values to the rated ones stored in its memory.


If the driving position is changed, the electronic control unit governs the electro-pneumatic assemblies, by means of which the actual level is corrected in relation to the nominal level set or saved by the driver.

Figure 1



62350

Figure 2









62349

SPECIFICATIONS AND DATA


Air system components

| COMPONENT | |
|---|--|
| Pneumatic supply unit <input type="checkbox"/> Type: WABCO 415 403 402 0 Operating temperature Max. operating pressure Rated voltage Pressure control | - 30°C to 65°C 12.7 bar 12V DC 14 to 17.1 bar |
| Level sensors <input type="checkbox"/> Type: WABCO 441 050 012 0 | |
| ECU <input type="checkbox"/> Type: WABCO 446 055 450 0 Rated voltage | 12V |
| Double circuit load sensing valve (vehicles without ABS) <input type="checkbox"/> Type : BOSCH NM/FV/98-347 (ref. 796803) Ratio | 0.15 |
| Pneumatic actuator <input type="checkbox"/> Type : ELLENA EE6492 Operating temperature Operating pressure | - 20°C to 80°C max 8 bar |
| Air tank (litres) | 3l |
| Rear air spring (Mod. 29 L - 35 S) Max. diameter Min. length Max. length | 171 mm 350 mm 150 mm |

Rear leaf spring

| | | |
|--|--|---|
| | | mm |
|  | | N° 2 |
|  | Spring length (measured between eye centre and air spring connection) | 1073 ± 6 |
|  | Leaf thickness (measured at the securing point to rear axle) | 24 ± 0.3 |
|  | Leaf width | 80 ± 0.5 |
|  | Bush seat inner diameter | 40 ^{-0,05} _{-0,2} |
|  | D = bush outer diameter d = bush inner diameter | 40.2 ⁰ _{-0,15} 16.5 ^{+0,2} ₀ |

Rear shock absorbers

|  | | | Mannesmann Sachs | ARVIN MERITOR | |
|---|-----------------------------|---------|-----------------------------|--------------------------|--|
| | Length between eye centres: | | | | |
| Open | mm | 460 ± 3 | 460 ± 3 | 480 ± 3 | |
| Closed | mm | 315 ± 3 | 315 ± 3 | 315 ± 3 | |
| Stroke | mm | 145 | 145 | 165 | |

Stabilizer bar


| | |
|------------------------------|--------------------|
| Models: | 29 L - 35 S |
| Stabilizer bar diameter (mm) | 20 |

Levelling and height values

| Suspension condition | Distance between upper chassis edge and road level (mm) | Max. distance (mm) |
|----------------------|--|--------------------|
| Max. height | 620 | + 40 |
| Self-levelling | 580 | - |
| Min. height | 520 | - 60 |

ELECTRIC SYSTEM WABCO (ECAS)

Figure 3



Legend

- | | | | |
|-------|--|-------|--|
| 20000 | Battery | 52502 | Key switch |
| 25926 | Relay for enabling suspension lifting and stopping the lowering function | 53051 | Suspension lifting control switch |
| 25927 | Relay for enabling suspension lowering and stopping the lifting function | 53052 | Suspension lowering control switch |
| 42354 | Pneumatic suspension system failure switch | 58713 | Failure warning led |
| 52090 | Suspension levelling switch | 58918 | Board with 32 optical indications plus instruments |
| | | 78233 | Vehicle lifting solenoid valve unit |
| | | 86023 | Vehicle lifting/lowering control unit |


61069

PNEUMATIC SYSTEM WABCO (ECAS)

Electronic-control

Vehicles: 29 L - 35 S

Figure 4



Legend

- 1 - ECU (ECAS).
- 2 - Manual chassis levelling control switch.
- 3 - Chassis lifting control switch.
- 4 - Chassis lowering control switch.
- 5 - Warning light ECAS.
- 6 - Stop light switch.
- 7 - Speedometer - tachograph.
- 8 - Right air spring.
- 9 - Right level sensor.
- 10 - Hydraulic load sensing valve*.
- 11 - Load sensing valve control pneumatic cylinder*.
- 12 - Left level sensor.
- 13 - Left air spring.
- 14 - Electrocompressor and distribution valve unit.
- 15 - Right chassis control solenoid valve.
- 16 - Left chassis control solenoid valve.
- 17 - Choke valve.
- 18 - Drier filter
- 19 - Air spring discharge solenoid valve.
- 20 - One-way valve.
- 21 - Compressor.
- 22 - One-way valve
- 23 - Intake filter.
- 24 - Compressor motor
- 25 - Motor control relay
- 26 - Diagnosis socket


- 15 - Right chassis control solenoid valve.
 - 16 - Left chassis control solenoid valve.
 - 17 - Choke valve.
 - 18 - Drier filter
 - 19 - Air spring discharge solenoid valve.
 - 20 - One-way valve.
 - 21 - Compressor.
 - 22 - One-way valve
 - 23 - Intake filter.
 - 24 - Compressor motor
 - 25 - Motor control relay
 - 26 - Diagnosis socket
- * For vehicles without ABS only.

000216T

PNEUMATIC SYSTEM ON VEHICLE

Vehicles without ABS

Figure 5




62353

Legend

- 1 - Warning light.
- 2 - Right level sensor.
- 3 - Right air spring.
- 4 - Chassis lifting control push button.
- 5 - Chassis lowering control push button.
- 6 - ECU.
- 7 - Manual chassis levelling control push button.
- 8 - Hydraulic load sensing valve.
- 9 - Load sensing valve control pneumatic cylinder.
- 10 - Left air spring.
- 11 - Pneumatic supply unit.
- 12 - Left level sensor.
- 13 - Centralised diagnostic socket.

Vehicles with ABS

Figure 6




62354

Legend

- I - Warning light.
- 2 - Right level sensor.
- 3 - Right air spring.
- 4 - Chassis lifting control push button.
- 5 - Chassis lowering control push button.
- 6 - ECU.
- 7 - Manual chassis levelling control push button.
- 8 - Left air spring.
- 9 - Pneumatic supply unit.
- 10 - Left level sensor.
- II - Centralised diagnostic socket.

CHASSIS SELF-LEVELLING, LIFTING AND LOWERING

Figure 7



62355

Operation

The system consists of the following:

- Pneumatic supply unit (electrocompressor, solenoid valve unit);
- One ECU;
- Two level sensors;
- Two air springs;
- Three levelling push buttons (1, 2, 3);
- One warning light (4).

Level sensors send to ECU the signals corresponding to chassis-road distance. The ECU processes these signals, generates accordingly activation signals and sends them to the electrocompressor.

Turn the ignition key to "MAR" and depress push buttons (1, 2, 3) for lifting, lowering or activating the self-levelling function of the chassis.

This system enables vehicle running up to 20 km/h under whatever height and level condition. When this speed is exceeded, chassis automatic levelling is activated.

Variation operations are indicated by warning light (4) blinking.


MAIN SYSTEM COMPONENTS

790560 PNEUMATIC SUPPLY UNIT

Specifications and data

| | |
|-------------------------|-----------------|
| Type | Wabco |
| Lubrication | Dry operation |
| Max. operating pressure | 12.7 bar |
| Operating temperature | -30 C° to 65° C |
| Rated voltage | 12V DC |

Figure 8




62356

This unit produces the compressed air required to supply the pneumatic system and enables to bleed air from the pneumatic system to lower the load bed.

766175 ELECTRONIC CONTROL UNIT

Figure 9



62357

The ECU is the mastermind of the system.

It controls every logic function of suspensions under both static and dynamic stage.

ECU receives signals from the control switches set in the cab and lifts and lowers the load bed accordingly. It also receives signals from the level sensors and controls the electrocompressor and the air spring to keep the vehicle in the self-levelling condition.

ECU indicates any system failure through the dedicated warning light set on the instrument panel.

ECU programming/setting

WABCO ECU is not requiring programming since it is supplied already programmed.

Setting can be performed by MODUS, E.A.S.Y. and IT2000 diagnostic systems and shall be performed when replacing the following:


- ECU;
- level sensor;
- level sensor levers.

Connect the diagnostic tool to the 38-pin socket and proceed as follows to obtain correct setting:

- check and adjust to 110 mm the level sensor lever length, if required;
- lift the chassis by depressing the proper video push button (max. lifting);
- Insert the special spacers provided (99346151) between the chassis and the rear axle measuring 65 mm;
- lower the chassis completely by depressing the proper video push button (max.lowering);
- set ECU by depressing the proper video push button.

768822 LEVEL SENSOR

Figure 10



62358

Level sensors inform constantly the ECU on distance changes between chassis and road level.


Level sensors consists of a coil secured to the chassis and a small piston.

When chassis height changes, a cam and a lever linked to the axle make the piston move inside the coil, thus modifying its inductance.

These changes will be used by the ECU in the different stages of the system.

Level sensor replacement Removal

Figure 11



Disconnect the electrical connection (2), loosen the screw (⇒) and disconnect the levers. Loosen the fastening screws and remove the level sensor (1).

Refitting




Reverse removal operations to perform refitting.

Perform level sensor and ECU setting as shown in the relevant paragraphs "ECU programming/setting" and "Level sensor adjustment".

Level sensor adjustment

Figure 12




Operate on adjustment screws and set relay lever X value to 110 mm.

Perform ECU setting as shown in the relevant paragraphs "ECU programming/setting".

500731 AIR SPRING

Figure 13




62359

Air spring is an elastic element dedicated to contain pressure air and to change its extension irrespectively of the applied load.

Air spring replacement

Removal


Figure 14



62360

- Position the vehicle on level ground.
- Lift the rear part of the vehicle and rest the chassis on the proper stands.
- Use the hydraulic jack to support the rear axle.
- Bleed the system and disconnect the air spring (3) supply pipe (2).
- Loosen upper (1) and lower fastening nuts.
- Lower the rear axle and remove the air spring (3).


Refitting



Reverse removal operations to perform refitting.

784310 LOAD SENSING VALVE

Figure 15



62361


Vehicles not fitted with ABS/EBS/ABD systems have been provided with the following components to obtain brakeforce distribution:

- double circuit load sensing valve;
- load sensing valve pneumatic actuator.

The load sensing valve controls automatically the braking torque produced by brakes on the rear axle, according to the load applied on the rear axle, measured and transferred to the load sensing valve of the pneumatic actuator.

The following diagram shows the brakeforce distribution ratio corresponding to 0.15 as a function of pneumatic pressure change inside air springs.

Figure 16




62362

Legend

- A Hydraulic output pressure in bar;
- B Hydraulic control pressure in bar;
- C Pneumatic control pressure in bar;
- D Characteristic curves, 0.15 ratio (without load);
- E 1:1 ratio (with load);
- F Pneumatic pressure/load characteristic curves.

Load sensing valve replacement Removal

Figure 17



Bleed the system, loosen the screws (3) and disconnect the pneumatic actuator (2).

Loosen the fastening screws of the load sensing valve (1) and remove it including the pneumatic actuator (2).

Refitting

- Reverse removal operations to perform refitting.
- Perform load sensing valve adjustment as shown in the relevant paragraphs "Load sensing valve adjustment on vehicle".

Load sensing valve adjustment on vehicle

This device shall be checked and adjusted, if required, at regular intervals by checking the values indicated on the plate (Figure 18) located on the internal part of the engine hood.

Should the plate or the relevant technical data be missing, ask the manufacturer for a duplicate specifying the following:

- Vehicle type and wheelbase
- Rear axle weight
- Load sensing valve No.

Figure 18

| TARGHETTA / SCHILLO / PLATE / PANNEAU / PLACA | PER / FUR / FOR / POUR / PARA | TIPO / TYP. / TYPE / TYPE | 29L - 35S |
|---|-------------------------------|---------------------------|-----------|
| | | | |
| | | | |
| Kg | bar | bar | bar |
| 750 | 15 | | 1,8 |
| 1050 | 15 | | 2,6 |
| 1300 | 34 | | 3,8 |
| 1500 | 50 | | 3,8 |
| 1700 | 66 | | 4,3 |
| 1900 | 82 | | 4,8 |
| 2120 | 100 | | 5,3 |
| | | | 0,15 |
| CORRETTORE DI FREINATA / NERKSPÄT / TRIGER / LOAD SENSING VALVE / CORRECTEUR DE FREINA / VALVULA REGULADORA | | | |
| MOLLA VUOTO / CARICO / POST. / ZEEP / VENTIL. / VALVE CHARGE / VIDE / VALVULA EN CARGA / VACIO | | | |
| MOLLA POSTERIORE / HINTERFEDE / REAR SPRING / RESSORT ARRIERE / BALLESTA TRASERA | | | |
| 500312049 | | | |
| 500385854 | | IVECO | |


62577

LOAD SENSING VALVE PLATE

Perform required operations in the following sequence:

- position the vehicle with the rear wheels set on the brake test bed 99336914;
- connect gauges 99372269 or Modus to pressure control intakes set upstream and downstream connector;
- should gauges not be fitted with valves for automatic bleeding, bleed air by loosening the suitable ring nuts

Figure 19



- Loosen nut (1);
- apply 5 kg to plate (3) in point (2);
- start engine;
- disconnect the pneumatic actuator (4);
- with engine running at idle, depress the brake pedal gradually until obtaining 100 bar pressure read on the gauge set upstream connector. This value shall be constant and shall be read on vehicle with load and without load;
- simulate the fully laden condition by lifting completely the relay lever (3) and the unloaded condition by lowering the lever completely;
- read output pressure value under both vehicle conditions (laden and unloaded); obtained values shall comply with those indicated on the plate, otherwise replace the load sensing valve;
- operate the relay lever (3) to check whether the load sensing valve piston is sliding smoothly into its seat, otherwise replace the load sensing valve;
- reconnect the pneumatic actuator (4);
- load the vehicle to obtain 1500 kg weight on the rear axle evenly distributed on the right and left side of the vehicle with ± 5 kg tolerance;
- with engine running at idle and 100 bar pressure read on the gauge set upstream the connector, check whether the output pressure value read on the gauge set downstream the connector is corresponding to the values indicated on the plate, otherwise replace the load sensing valve;
- stop the vehicle, tighten nut (1) to the specified torque and remove applied loads.

Perform this check with gradually increasing pressure.

To check the load sensing valve, every braking system component shall be in perfect operating conditions. When replacing the leaf spring for special set-up, a new plate is required with properly corrected values.


- when tests are over, check brake performance.

500730 REAR SUSPENSION OVERHAUL

500450 LEAF SPRING

Removal

Figure 20



Position the vehicle on level ground. Lift the rear part of the vehicle and rest the chassis on the proper stands. Use the hydraulic jack to support the rear axle.

Bleed the system, remove the wheel, loosen the air spring lower fastening screw (1). Loosen shock absorber lower fastening nut (3) and disconnect it.

Loosen nuts (2) and remove the U bolts (4) and the elements securing the leaf spring to the rear axle.

Loosen and remove the pin (6) and remove the leaf spring (5).

Refitting




Reverse removal operations to perform refitting.



500940 REAR SHOCK ABSORBERS

Removal

Figure 21



Lift the rear part of the vehicle and use the jack to support the rear axle. Loosen the upper (3) and the lower (1) fastening nuts and remove the shock absorber (2).

Refitting




Reverse removal operations to perform refitting.



528960 REAR STABILIZER BAR

Removal

Figure 22



Operate on both vehicle sides.

Loosen the screws (1) and the nut (3). Remove the stabilizer bar (4) including the joints (2).

Refitting




Reverse removal operations to perform refitting.



PANHARD REACTION BAR Removal

Figure 23



Loosen the "Panhard" reaction bar (4) fastening screws (3 and 5) and remove it.

Loosen the relay rod (2) fastening screws (1 and 6) and remove it.

Refitting



Reverse removal operations to perform refitting.

AIR SUSPENSIONS TYPE VB-TECHNIEK (for vehicles 35C - 40C - 45C - 50C - 60C - 65C) GENERAL INFORMATION

The VB - TECHNIEK system is controlled by an electronic control unit that keeps the settings, depending on the signals sent by the level sensors, in all working conditions.

A supply unit, which includes all the appliances, distributes and discharges the air from the springs.


For vehicles with no ABS, there is a braking load apportioning valve, governed by an air-operated actuator.

With each start, the control unit runs a test on all the system components and when the handbrake is released it restores the set driving position.

It is possible, with the vehicle stationary and the handbrake engaged, to lift or lower the chassis frame. During these operations, a red light on the dashboard warns of not being in the driving position.


Suspension assembly diagram (for vehicles 35C - 40C - 45C - 50C)

Figure 24



62351

Figure 25








62435






SPECIFICATIONS AND DATA**Pneumatic system (for vehicles 35 C - 50 C)**

| COMPONENT | | |
|--|--|--------------------------|
| Air supply unit | | |
| <input type="checkbox"/> Type: VB TECHNIEK | | 1252131010 |
| Level sensor | | |
| <input type="checkbox"/> Type: VB TECHNIEK | | 1252091020 |
| ECU | | |
| <input type="checkbox"/> Type: VB TECHNIEK | | 125212050 |
| Hydraulic load sensing valve (vehicles without ABS) | | |
| <input type="checkbox"/> Type: VB TECHNIEK | (for vehicles 35 C - 40 C) (for vehicles 45 C - 50 C) | 1252081065 1252081070 |
| Rear air spring | | |
| <input type="checkbox"/> Type: VB TECHNIEK | | 1252030070 |
| Max. diameter | | 240 mm |
| Min. length | | - mm |
| Max. length | | - mm |
| Air tank | | |
| | | - |


Rear leaf spring (vehicles 35 C - 40 C)

| | | mm |
|---|--|------|
|  | Single blade <input type="checkbox"/> Type: VB TECHNIEK 1252011575 | N° 2 |
|  | Leaf length (measured between eye centre and air spring connection) | 1080 |
|  | Leaf thickness (measured at the securing point to rear axle) | 35 |
|  | Leaf width | 60 |
|  | Bush seat inner diameter | 39 |

Rear leaf spring (vehicles 45 C - 50 C)

| | | |
|---|--|------|
| | | mm |
|  | Twin blade □ Type: VB TECHNIEK I2520 I1585 | Nº 2 |
|  | Leaf length (measured between eye centre and air spring connection) | 1080 |
|  | Leaf thickness (measured at the securing point to rear axle) | - |
|  | Leaf width | 60 |
|  | Bush seat inner diameter | 39 |

Rear shock absorbers

| | | |
|---|-----------------------------|---------|
|  | Length between eye centres: | |
| | Open | 471 ± 3 |
| | Closed | 313 ± 3 |
| | Stroke | 158 |

Stabilizer bar


| | |
|------------------------------|---------------------------|
| Models: | 35 C - 40 C - 45 C - 50 C |
| Stabilizer bar diameter (mm) | 18 |

Levelling and height values

| Suspension condition | Distance between upper chassis edge and road level (mm) | Max. distance (mm) |
|----------------------|---|--------------------|
| Max. height | 640 | + 60 |
| Self-levelling | 580 | - |
| Min. height | 550 | - 30 |

VB TECHNIK ELECTRIC SYSTEM

Figure 26




Legend

- | | | | |
|-------|-----------------------------------|-------|--|
| 20000 | Battery | 53052 | Suspension lowering control switch |
| 40046 | Inductive type level sensor | 58713 | Failure warning led |
| 42102 | Hand brake ON switch | 58719 | Hand brake ON warning led |
| 52052 | Key switch | 58918 | Board with 32 optical indications plus instruments |
| 53051 | Suspension lifting control switch | 85160 | Chasis setup change control device |

62448

PNEUMATIC SYSTEM
VB TECHNIK Electronic-control pneumatic suspensions
Vehicles: 35 C - 40 C - 45 C - 50 C

Figure 27



Legend

- 1 - ECU
- 2 - Hand brake ON switch
- 3 - Warning light
- 4 - Chassis lifting control switch
- 5 - Chassis lowering control switch
- 6 - Air spring bleeding solenoid valve
- 7 - Throttling valve
- 8 - Single-acting exhaust valve
- 9 - Single-acting delivery valve
- 10 - Drier filter
- 11 - Right air spring
- 12 - Pneumatic control load sensing valve*

- 13 - Air duct connection
- 14 - Pneumatic bleeding valve
- 15 - Level sensor
- 16 - Left air spring
- 17 - Compressor
- 18 - Supply filter
- 19 - Compressor motor
- 20 - Motor thermal sensor
- 21 - Exhaust silencer
- 22 - Motor control relay


* Only for vehicles without ABS.attery

73732

VB-TECHNIEK ELECTRICAL SYSTEM (60 C - 65 C VEHICLES)

Vehicles: 60 C - 65 C

Figure 28




86166

Legend

- | | | | |
|-------|--|-------|---|
| 20000 | Battery | 53052 | Suspension lowering control switch |
| 40046 | Chassis height sensor, inductive type, rear axle | 58713 | VTB failure warning led |
| 42102 | Handbrake engaged indication switch | 58719 | Handbrake engaged led |
| 52502 | Key switch | 58918 | Instrument panel with 32 optical indications plus instruments |
| 53051 | Suspension raising control switch | 85160 | Chassis position variation control device |

PNEUMATIC SYSTEM (vehicles: 60 C - 65 C)
VB TECHNIK Electronic-control pneumatic suspensions

Figure 29



Legend

- 1 - electronic control unit
- 2 - manual mode activation button
- 3 - raising button
- 4 - lowering button
- 5 - VBT warning light
- 6 - tachograph
- 7 - electric motor relay
- 8 - exhaust solenoid valve (for washing)
- 9 - throttle valve
- 10 - single-acting exhaust valve
- 11 - single-acting feed valve
- 12 - drier filter

- 13 - RH air spring
- 14 - air exhaust valve
- 15 - compressor
- 16 - compressor electric motor
- 17 - filter
- 18 - brakeforce distributor
- 19 - silencer
- 20 - exhaust solenoid valve
- 21 - LH air spring
- 22 - level sensor


* Only for vehicles without ABS

86154

PNEUMATIC SYSTEM ON VEHICLE

Vehicles without ABS (35C - 40C - 45 C - 50 C)

Figure 30




000364T

Legend

- 1 - VBT warning light
- 2 - Suspension control unit (ECU, pneumatic supply unit)
- 3 - Chassis lifting control switch
- 4 - Chassis lowering control switch
- 5 - Right air spring
- 6 - Level sensor
- 7 - Load sensing valve pneumatic actuator
- 8 - Load sensing valve
- 9 - Left air spring

Vehicles with ABS (35C - 40C - 45 C - 50 C)

Figure 31




000365T

Legend

- 1 - VBT warning light
- 2 - Suspension control unit (ECU, pneumatic supply unit)
- 3 - Chassis lifting control switch
- 4 - Chassis lowering control switch
- 5 - Right air spring
- 6 - Level sensor
- 7 - Left air spring

60 C - 65 C vehicles without ABS

Figure 32




86155

Legend

- | | |
|---|-----------------------------|
| 1 - VBT warning light | 9 - Brakeforce distributor |
| 2 - Suspension control unit | 10 - LH air spring |
| 3 - Chassis raising control button | 11 - Exhaust solenoid valve |
| 4 - Chassis lowering control button | 12 - Filter |
| 5 - Manual control button | 13 - Relay |
| 6 - RH air spring | 14 - Electric compressor |
| 7 - Level sensor | 15 - Control unit |
| 8 - Brakeforce distributor air actuator | |

60 C - 65 C vehicles with ABS

Figure 33




86156

Legend

- | | |
|-------------------------------------|----------------------------|
| 1 - VBT warning light | 8 - LH air spring |
| 2 - Suspension control unit | 9 - Exhaust solenoid valve |
| 3 - Chassis raising control button | 10 - Filter |
| 4 - Chassis lowering control button | 11 - Relay |
| 5 - Manual control button | 12 - Electric compressor |
| 6 - RH air spring | 13 - Control unit |
| 7 - Level sensor | |

CHASSIS SELF-LEVELLING, LIFTING AND LOWERING

Figure 34



62355

Operation

The system consists of the following:

- Electrocompressor (two models 60 C - 65 C);
- One ECU;
- One level sensor;
- Two air springs;
- Two levelling buttons (1 and 2) in 30 C - 35 C - 40 C - 50 C models;
- Three buttons (1, 2, 3) in 60 C - 65 C models;
- One warning light (4).

The level sensor sends signals which are proportional to the chassis-road clearance to the ECU. The ECU processes these signals and consequently operates the electrical compressor (or compressors) for raising or lowering the chassis.

The chassis is automatically levelled when the engine is running and the handbrake is lowered (35 C - 40 C - 45 C - 50 C vehicles). In 60 C - 65 C vehicles, button (3) must not be pressed in addition to handbrake operation.


To change load bed height depress push buttons (1 and 2) for lifting or lowering the chassis.

Chassis lifting or lowering can be performed just with stopped vehicle and hand brake ON.

In 60 C - 65 C vehicles, this operation can be activated also when the vehicle is moving (up to 20 km/h) with handbrake off and levelling button pressed.

MAIN SYSTEM COMPONENTS 790560 ELECTROCOMPRESSOR

Figure 35




62440

This unit produces the compressed air required to supply the pneumatic system and enables to bleed air from the pneumatic system to lower the load bed.

766175 ELECTRONIC CONTROL UNIT

Figure 36



62441

The ECU is the mastermind of the system.

It controls every logic function of suspensions under both static and dynamic stage.

ECU receives signals from the control switch set in the cab and lifts and lowers the load bed accordingly. It also receives signals from the level sensor and controls the electrocompressor and the air spring to keep the vehicle in the self-levelling condition.


ECU indicates any system failure through the blinking of the dedicated led.

ECU programming/setting

No ECU programming/setting is required; only the level sensor adjustment according to the specified adjustment value shall therefore be performed.

768822 LEVEL SENSOR

Figure 37




50870

The level sensor sends to ECU variable signals according to chassis-road level distance.

Level sensor replacement

Removal

Figure 38



62442

Disconnect the electrical connection, disconnect the levers (⇒), loosen the fastening screws (2) and remove the level sensor (1).


Refitting



Reverse removal operations to perform refitting.
Perform level sensor adjustment as shown in the relevant paragraph "Level sensor adjustment".

Level sensor adjustment

Figure 39



62585

Level sensor (1) adjustment shall be performed each time this sensor or the adjustment tie rod (2) are removed or replaced.

Apply the handbrake, raise the chassis by means of the button in the cab and insert the following shims between chassis and axle:

- 90 mm for 30 C - 35 C - 40 C vehicles;
- 110 mm for 45 C - 50 C - 60 C - 65 C vehicles.


Lower down the chassis completely by depressing the proper push button located in the cab.

Check and adjust control lever X value to 11 mm if required.

Adjust level sensor (1) position by operating on the fastening screws (3) to obtain reaction lever verticality. Secure the level sensor.

500731 AIR SPRING

Figure 40




62443

Air spring is an elastic element dedicated to contain pressure air and to change its extension irrespectively of the applied load.


Air spring replacement Removal

Figure 41




Position the vehicle on level ground.
Lift the rear part of the vehicle and rest the chassis on the proper stands.
Use the hydraulic jack to support the rear axle.
Bleed the system and disconnect the air spring (2) supply pipe (1).
Loosen upper and lower fastening screws (⇒).
Lower the rear axle and remove the air spring (2).

Refitting



784310 LOAD SENSING VALVE

Figure 42



Vehicles not fitted with ABS system have been provided with the following components to obtain brakeforce distribution:


- single-circuit load sensing valve;
- load sensing valve pneumatic actuator.

The load sensing valve controls automatically the braking torque produced by brakes on the rear axle, according to the load applied on the rear axle, measured and transferred to the load sensing valve of the pneumatic actuator.

The load sensing valve used on vehicles with this type of suspension is set to 0.25 ratio.

Load sensing valve replacement Removal


Figure 43



Bleed the system.

Disconnect pneumatic and hydraulic pipes, loosen the fastening screws and remove the load sensing valve (2) including the pneumatic actuator (1).


Refitting



Load sensing valve adjustment on vehicle

This device shall be checked and adjusted, if required, at regular intervals.

Figure 44



Remove the load sensing valve and the cover.


Refit the load sensing valve and operate on screw (1) to set dimension X, between load sensing valve push rod (2) and pneumatic actuator screw (1), to the value shown in table

Remove the load sensing valve and refit it with its cover.

| VEHICLE | X |
|------------|--------------|
| 35C - 40 C | 2.9 ÷ 3.3 mm |
| 45C - 50 C | 2 ÷ 2.5 mm |

500730 REAR SUSPENSION OVERHAUL (vehicles 30 C - 35C - 40C - 45 C)**500450 LEAF SPRING****Removal**

Figure 45



62459

Position the vehicle on level ground.

Lift the rear part of the vehicle and rest the chassis on the proper stands.

Use the hydraulic jack to support the rear axle.

Bleed the system and remove the wheels.

Only for right leaf spring: loosen the screws (1) fastening the "Panhard" bar support (2) and disconnect it.

Loosen the air spring lower fastening screw (⇒).

Loosen the fastening nuts and remove the U bolts (4).

Loosen the screw (3) fastening the leaf spring (5) to the rear axle.

Loosen and remove the pin (6).

Remove the leaf spring (5).


Refitting

Reverse removal operations to perform refitting.



500940 REAR SHOCK ABSORBERS Removal

Figure 46



62446

Lift the rear part of the vehicle and use the jack to support the rear axle.

Loosen the upper (3) and the lower (1) fastening nuts and remove the shock absorber (2).


Refitting



Reverse removal operations to perform refitting.

528960 REAR STABILIZER BAR Removal

Figure 48



62447

Operate on both vehicle sides and loosen the screws (⇒) fastening the stabilizer bar to the chassis. Loosen the nut and remove the pin (3).

Remove the stabilizer bar (1) including the joints (2).


Refitting



Reverse removal operations to perform refitting.

PANHARD REACTION BAR Removal

Figure 47



62434

Refitting



Reverse removal operations to perform refitting.

Loosen the fastening screws (1 and 3), withdraw the relevant pins and remove the "Panhard" reaction bar (2).

SECTION 9

5025 Wheel and Tyres

| | Page |
|---|------|
| DESCRIPTION | 3 |
| <input type="checkbox"/> Tyre pressure | 4 |
| TOOLS | 5 |
| DIAGNOSTICS | 5 |
| STATIC WHEEL BALANCING | 8 |
| TYRE PRESSURE | 9 |
| HOW TYRE BEHAVIOUR DEPENDS ON PRESSURE | 9 |

DESCRIPTION


The wheel rim represents the rigid structure of the wheel and is identified by the following dimensions:

- diameter of the rim, measured at the base of the circumferential groove (i.e., on the surface on which the air chamber rests);
- width of the circumferential groove in the wheel rim (i.e., the distance between the surfaces on which the cover rests).

The tyre has the following functions:

- to absorb the greater part of the jolts caused by roughness of the road surface by utilising the elasticity of air;
- to generate on the ground the motive force supplied by the engine necessary for the vehicle to move;
- to ensure the maximum grip and stability of contact between the tyre and the road, with satisfactory tyre life;
- to withstand the forces generated by sudden braking, hard acceleration and by the thrust of centrifugal force on bends;
- to ensure the stability of the vehicle even at high speeds; to ensure the steerability of the vehicle.

Figure 1



1. Tyre section rated width (mm)
2. Tyre height-width ratio percentage e.g., $H/S = 0.75$
3. Tyre structure (R = Radial)
4. Wheel rim diameter in inches
5. Load and speed index symbols
113: tyre load index on simple axis: 1150 kg
111: tyre load index on paired axis: 1090 kg
Speed category (N= 140 km/h)
6. Designation of the manufacturer's tyre:
XC A Tubeless (TL): tyre to be used with no inner tube.

Figure 2

44929

- S = Tyre section rated width (mm)
- H = Tyre height
- D = Max. utilisation diameter (Rx2)
- R = Radius under load (static)
- Ø = Fitting diameter
- E = Min. distance between centres in case of paired tyres
- e = Tyre deflection
- CdR = Rolling circumference

Tyre pressure

| bar (kg/cm ²) | | | 3,0 | 3,25 | 3,5 | 3,75 | 4,0 | | 4,5 | 4,75 | 5,0 | 5,25 | 5,5 | 6,0 |
|---------------------------|----|-------|------|------|------|------|------|------|------|------|------|------|------|------|
| 205/70 R15 | kg | front | 1350 | - | 1500 | - | - | | - | - | - | - | - | - |
| 106/104Q | | rear | - | - | 1500 | 1650 | 1740 | | 1900 | - | - | - | - | - |
| 215/70 R15 | kg | front | 1460 | - | 1600 | - | - | | - | - | - | - | - | - |
| 109/107Q | | rear | - | - | 1600 | 1700 | 1830 | | 2060 | - | - | - | - | - |
| 225/70 R15 | kg | front | 1550 | 1650 | - | - | - | | - | - | - | - | - | - |
| 112/110Q | | rear | - | 1740 | 1860 | 1960 | 2020 | | 2240 | - | - | - | - | - |
| bar (kg/cm ²) | | | 3,0 | 3,25 | 3,5 | 3,75 | 4,0 | 4,25 | 4,5 | 4,75 | 5,0 | 5,25 | 5,5 | 6,0 |
| 195/65 R16 | kg | front | - | - | 1400 | 1450 | 1550 | 1650 | 1700 | 1800 | - | - | - | - |
| 104/102Q | | rear | 2230 | - | 2600 | - | - | - | - | - | - | - | - | - |
| 185/75 R16 | kg | front | 1300 | - | 1480 | - | 1590 | - | - | 1800 | - | - | - | - |
| 104/102Q | | rear | 2440 | 2600 | 2760 | - | 2990 | - | - | 3400 | - | - | - | - |
| 195/75 R16 | kg | front | 1350 | - | 1520 | 1600 | 1700 | 1750 | 1850 | 1900 | - | - | - | - |
| 107/105P | | rear | 2560 | - | 2890 | 3100 | 3200 | 3400 | 3550 | 3700 | - | - | - | - |
| 225/75 R16 | kg | front | 1950 | - | 2100 | - | 2260 | - | - | - | - | 2640 | - | - |
| 118/116 | | rear | 3630 | - | 3930 | - | 4240 | - | - | - | - | 5000 | - | - |
| +6.50 R16 | kg | front | - | - | 1370 | 1570 | 1680 | 1750 | 1840 | 1940 | 2000 | - | - | - |
| 106/107L | | rear | - | - | 2600 | 3050 | 3240 | 3400 | 3560 | 3720 | 3900 | - | - | - |
| +7.00 R16 | kg | front | - | - | - | - | 1840 | - | 2000 | 2120 | 2200 | - | 2380 | 2570 |
| 117/116L | | rear | - | - | - | - | 3600 | - | 3890 | 4150 | 4260 | - | 4360 | 5000 |


NOTE The pressures indicated refer to cold tyres and an outside temperature of 20°C.

TOOLS

TOOL NO.

DESCRIPTION

99305037





Electronic equipment for front wheel balancing on the vehicle

DIAGNOSTICS


Main tyres malfunctions:

- 1 - excessive wear;
- 2 - irregular wear;
- 3 - vehicle pulls to one side.






(continues)



502511 STATIC WHEEL BALANCING

Figure 3




The front wheels can be balanced on the vehicle using the electronic unit 99305037; this has the advantage of balancing the wheel together with the other rotating masses.

The operation must be carried out as follows:

- raise the front of the vehicle and make sure that the wheels are free to rotate;
- position the imbalance detector (1) under the axle close to the wheel being examined, arranging the height so that the spin-up wheel of unit 99305037 (2) is in contact with the tyre; position a support stand under the opposite side of the axle and lower the hydraulic jack;

Figure 4



16997

- connect the cable (3) of the imbalance detector to unit 99305037;
- make a reference mark on the tyre by drawing a radial mark with chalk or using a strip of gummed paper;
- turn switch (2) to the static balancing position and sensitivity switch (4) to notch no. 5 on the graduated scale;
- turn on switch (5) for instrument light (1) and strobe lamp switch (8);
- turn the spin-up switch (6) of unit 99305037 to the first speed position so as to make the wheel rotate.

Turn up the spin switch (6) to the second speed and place the balancing machine against the tyre.


While the wheel is being spun, it will be found that the stroboscopic effect on the wheel will make the reference mark appear stationary; the pointer of the instrument (1), moving from the value zero, reaches a maximum value on the scale and then returns to zero.

When the pointer has begun to fall back, withdraw the balancing machine, turn off the spin-up switch (6) completely and brake the motor by means of the brake lever (7).

The wheel continues to revolve due to inertia and the reference mark made on the tyre moves; the point to which the reference mark has moved should therefore be noted.

Read off from the instrument (1) the value shown by the pointer; multiply it by 10, giving the value of the balance weight to be fitted to the rim.

Figure 5




16998

Fit the balance weight calculated in this way as shown in the figure.

If during the test, the pointer of the instrument (1, Figure 4) remains in the green area of the box, the wheel is balanced.

NOTE If the weight required to balance the wheel is more than 60 ÷ 80 grams, divide the weight in half and position the two parts so formed with one half on the inside and one half on the outside of the rim, making sure that they are in the same position.

Figure 6



23885

To correct the residual imbalance, repeat the operations already carried out as above; depending on the new reading of the instrument (1, Figure 4), refer to the diagram in the figure and proceed as follows to adjust:

- If the weight is in the zone marked with the letter A, this means that it is too light, and in that case weight must be added as indicated by the instrument (I, Figure 4).
- If the weight is in the bottom zone marked with the letter C, this means that it is too heavy and in that case the weight must be reduced as shown by the measuring instrument.
- If the weight is found to be in the zones marked with the letters B or D, do not remove or add any weight but instead move it 5 cm upwards in the direction of the arrows, see Figure 6.

502510 TYRE PRESSURE

The tyre pressures must be checked with the tyres cold.

Take great care that the pressure is correct since, if it is higher than required, a harsh ride and excessive wear of the centre of the tread will result, while if it is lower, the load is not distributed over the whole tread but is concentrated at either side, causing premature wear of these areas and also damaging the internal structure of the tyre.

Unequal pressures between tyres affects the driving stability of the vehicle and impairs operating safety.


Tyre abnormal wear can occur in different areas of tread.

HOW TYRE BEHAVIOUR DEPENDS ON PRESSURE

Schematic views to demonstrate how tyre behaviour and performance depend on pressure.


NOTE The value shown inside each tyre indicates the level of pressure of the tyre, while the efficiency relates to the life of the tyre.

Figure 7




EFFICIENCY 40%

Figure 8



EFFICIENCY 90%

Figure 9



EFFICIENCY 100%

SECTION 10**5014 Steering gear**

| | Page |
|--|------|
| STEERING GEAR | 3 |
| <input type="checkbox"/> General | 3 |
| POWER STEERING SPECIFICATIONS AND DATA | 4 |
| <input type="checkbox"/> Steering gear | 4 |
| TIGHTENING TORQUES | 5 |
| SPECIFIC TOOLS | 5 |
| DIAGNOSTICS | 6 |
| POWER STEERING | 11 |
| <input type="checkbox"/> Description | 11 |
| POWER STEERING TYPE TRW | 12 |
| <input type="checkbox"/> Operation | 12 |
| POWER STEERING TYPE ZF | 14 |
| <input type="checkbox"/> Operation | 14 |
| CHECKS AND OPERATIONS ON THE VEHICLE | 16 |
| <input type="checkbox"/> Checking maximum pressure | 16 |
| <input type="checkbox"/> Checking hydraulic steering centre (for "ZF" power steering only) | 16 |
| <input type="checkbox"/> Bleeding the air from the hydraulic system | 16 |
| SWIVEL HEADS | 16 |
| PROTECTION CASINGS | 16 |
| STEERING GEAR CONTROL | 16 |
| <input type="checkbox"/> Vehicles equipped with an Air-Bag | 16 |
| SAFETY STANDARDS TO BE OBSERVED DURING REPAIR OR MAINTENANCE OPERATIONS ON VEHICLES EQUIPPED WITH AIR-BAG SYSTEM PROVIDED BY SUPPLIER | 17 |
| <input type="checkbox"/> Preliminary Standards | 17 |
| <input type="checkbox"/> Repairs and inspections required after an accident | 17 |
| <input type="checkbox"/> Accidents with or without Air-Bag module activation | 17 |

Page

| | | |
|--------------------------|---|----|
| <input type="checkbox"/> | Accidents with Air-Bag module activation | 17 |
| <input type="checkbox"/> | Painting | 18 |
| <input type="checkbox"/> | Risks for health | 18 |
| <input type="checkbox"/> | Overexposure effects | 18 |
| <input type="checkbox"/> | Safety Standards to observe when handling Air-Bag modules | 18 |
| <input type="checkbox"/> | Air-Bag module scrapping | 19 |
| <input type="checkbox"/> | Safety Standards to observe when handling pretensioners | 19 |
| <input type="checkbox"/> | Pretensioners scrapping | 20 |
| <input type="checkbox"/> | Operations on system components | 20 |
| <input type="checkbox"/> | Removing and scrapping activated Air-Bag module and pretensioner from vehicle | 20 |
| <input type="checkbox"/> | Removing and scrapping non-activated Air-Bag module from a repairable vehicle | 20 |
| <input type="checkbox"/> | Air-Bag module deployment Remote activation | 21 |
| <input type="checkbox"/> | Activating Air-Bag modules and electronic pretensioners installed on unrecoverable vehicles | 21 |
| <input type="checkbox"/> | Upper steering gear shaft removal | 23 |
| <input type="checkbox"/> | For vehicles equipped with Air-Bag | 23 |
| <input type="checkbox"/> | For all vehicles | 23 |
| <input type="checkbox"/> | Refitting | 24 |
| <input type="checkbox"/> | Lower steering gear shaft removal | 24 |
| <input type="checkbox"/> | Refitting | 25 |
| | HYDRAULIC POWER STEERING | 25 |
| <input type="checkbox"/> | Hydraulic power steering removal | 25 |
| <input type="checkbox"/> | Refitting | 25 |
| <input type="checkbox"/> | Steering linkage replacement | 26 |
| <input type="checkbox"/> | Removal | 26 |
| <input type="checkbox"/> | Refitting | 26 |
| <input type="checkbox"/> | Rubber bushing replacement procedure | 26 |
| | POWER STEERING PUMP | 27 |
| <input type="checkbox"/> | Power steering pump overhaul procedure | 28 |

STEERING GEAR

General

Generally, the steering gear members consist of: a full steering gear control, a steering box, the linkage joining the driving wheels and, for the hydraulic-type steering box of: an hydraulic pump, an oil tank and oil piping.

In vehicle system 35C-65C with FIC engine, there is installed a pipe coil (A) to cool oil.

The rotary movement given to the steering wheel by the driver is transmitted to the steering box by three shafts joined one another by universal joints.

The universal joints allow the transmission of the rotary movement on different planes.

The upper shaft, on which the steering wheel is keyed, is housed and supported in the upper support by elastic bushes. In addition, the indicator automatic switch-off and the antitheft steering lock are keyed to the support.

The steering box is of the type: pinion - rack rod with hydraulic power.

It has two functions:


- angle driving between spin axis of the steering control and the wheels' steering axis.
- gear down through the coupling ratio the resistant moment opposing the wheels under the steering effect.

The value of this ratio and the wheel geometry characteristics (toe-in - camber - caster), determine the stress and the type of steering, more or less direct; this increases or decreases the driver sensitivity of the vehicle attitude on road; besides, it determines the steering caster action degree, that is, the spontaneous return to straight normal running when the steering wheel is released after steering.

The tie rods joining the steering levers mounted on stub axles using knuckle heads are joined by ball joints at the end of the rack rod. Operating the tie rod the wheel camber is adjusted.

The hydraulic pump is of the blade type and is flanged to the engine auxiliary member unit, it has the overpressure valve incorporated.





Figure 1



STEERING GEAR DIAGRAM

88735

POWER STEERING SPECIFICATIONS AND DATA**Steering gear**

| | | | | | | |
|---|--|----------------------|--|----------------|--------------------|----------------|
|  | Steering gear | Hydraulic | | | | |
|  | Power steering | Pinion and rack type | | | | |
| | Type | ZF* | | TRW | | |
| | Operating pressure X | 100 bar | | | | |
| | Maximum delivery volume | - | | | | |
| | No. of steering wheel turns | 3.8 | | | | |
| | Rack travel in both steering directions: | 180 ± 1.5 mm | | | | |
|  | Type | | TEXAND F020 | | SHELL-ALVANIA LS00 | |
| | pinion side | kg | - | | 0.060 | |
| | pipe end side | kg | - | | 0.030 | |
|  | Power steering pump | | blade type with pressure relief valve incorporated | | | |
| | Motor | | 8140 | | FIA | FIC |
| | Type | | ZF 7684 955124 | ZF 7684 955138 | ZF 7612 955117 | ZF 7682 955133 |
| | Minimum RGM | RPM | 500 | 460 | 500 | 750 |
| | Maximum RGM | RPM | 3500 | 2980 | 8500 | 3500 |
| | Maximum pressure | bar | 80 + 10 | | 100 + 10 | 115 + 10 |
| | Minimum delivery | dm ³ /min | - | - | | |
| Adjusted delivery | dm ³ /min | 7 | 8 | 9 ± 0,75 | 9 ± 0,8 | |
| Turning circle (theoretical value) [m] | | | | | | |
| Wheelbase [mm] | MODELS | | | | | |
| | 29 L - 35 S | 35 C ⁽¹⁾ | 35 C ⁽²⁾ - 40 C - 45 C - 50 C | | 60 C - 65 C | |
| Tyres | 205 - 225/70 R 15 | 195/65 R 16 | 195/75 R 16 | | 225/75 R 16 | |
| 3000 | 10.37 | 10.34 | 11.04 | | - | |
| 3300 | 11.25 | 11.22 | 11.98 | | 11.79 | |
| 3450 | 11.69 | 11.66 | 12.46 | | 12.25 | |
| 3750 | 12.57 | 12.54 | 13.40 | | 13.17 | |
| 3950 | 13.15 | 13.12 | 14.03 | | 13.78 | |
| 4100 | - | 13.56 | 14.50 (3) | | 14.24 | |
| 4350 | - | - | 15.29 (4) | | 15.01 | |
| 4750 | - | - | 16.55 (4) | | 16.24 | |


(1) Front suspension with trasverse leaf spring.

(2) Front suspension with torsion bar.

(3) Models 35C-40C only

(4) Models 45C-50C only


TIGHTENING TORQUES



52376

| | DESCRIPTION | TORQUE | |
|---|-----------------------------------|----------|-----------|
| | | Nm | kgm |
| 1 | Screw, steering box fastening nut | 50 ÷ 61 | 5 ÷ 6.1 |
| 2 | Nut, ball joint to steering arm | 68 ÷ 83 | 6.8 ÷ 8.3 |
| 3 | Nut, ball joint to track arm | 70 ÷ 100 | 7 ÷ 10 |


SPECIFIC TOOLS

| TOOL NO. | DESCRIPTION |
|-----------------|---|
| 99347074 |  Knuckle pivot extractor (4x2 vehicles) |

DIAGNOSTICS

Main hydraulic power steering operating faults:

- | | |
|---|--|
| <ul style="list-style-type: none"> 1 - Steering stiff when turning right and left; 2 - Steering stiff only when turning left or right; 3 - Steering stiff when the wheel is turned quickly; 4 - When steering, heavy jolts are felt at the wheel; 5 - Torsional vibration of the steering wheel; | <ul style="list-style-type: none"> 6 - Excessive play at the steering wheel; 7 - Loss of oil; 8 - Insufficient pressure in the circuit; 9 - The vehicle tends to move sideways; 10 - Hydraulic power steering pilot light always lighted. |
|---|--|



2 STEERING STIFF ONLY WHEN TURNING LEFT OR RIGHT



Incorrect position of hydraulic centre (when wheel is released, the steering returns to one end of travel by itself): (ZF steering case only)..

- YES ->

Replace the power steering unit

3 STEERING STIFF WHEN THE WHEEL IS TURNED QUICKLY



Regulating valve in pump blocked.

- YES ->

Replace the power steering pump

NO



Insufficient pump delivery (gears worn).

- YES ->

Replace the hydraulic pump

NO



Air in steering system.

- YES ->

Check suction tube and pump shaft seal for leaks. Bleed system and top up the oil.

4 WHEN STEERING, HEAVY JOLTS ARE FELT AT THE WHEEL



Play in universal joint.

- YES ->

Fit a new seal.

NO



Internal failure of hydraulic power steering.

- YES ->

Replace the power steering unit

NO




Insufficient oil in system.


- YES ->

Top up oil and bleed system.

(Continue)



5 TORSIONAL VIBRATION OF THE STEERING WHEEL



6 EXCESSIVE PLAY AT THE STEERING WHEEL



Play in ball joints and/or elastic supports loosen.

- YES →

Secure the supports
Replace the ball joints.

NO
↓

Play in universal joint.

- YES →

Replace universal joint.

NO
↓

Internal failure of hydraulic power steering.

- YES →

Replace the power steering unit

7 LOSS OF OIL



Tank cover not secured.

- YES →

Secure cover.

NO
↓

Seal gaskets worn.

- YES →

Replace the power steering unit

In any case it is necessary to determine the place and the reason why there is oil leakage, eliminate the cause, top up oil in the tank with the engine started up to the upper mark of the dipstick.

8 INSUFFICIENT PRESSURE IN THE CIRCUIT




Hydraulic pump not operating correctly.

- YES →

Replace the power steering pump


(Continue)



POWER STEERING

Description

Figure 2



24103

HYDRAULIC POWER STEERING SYSTEM DIAGRAM

■ HIGH PRESSURE

□ LOW PRESSURE

The power steering system consists of:

- a tank (A);
- a blade pump (B) with delivery regulating valves (C);
- a series of connecting pipings (D);
- an hydraulic power steering (E).

The oil tank, in the engine compartment, feeds the blade pump. This pump is able to provide a feeding pressure ranging from a minimum of approx. 4 bar to a maximum of approx. 80 + 10. The oil come to the steering box, which is similar to a mechanical steering as for general building features, from the pump.

In fact, its operation is mechanical for pinion to rack coupling. The rack rod is joined to the wheels with two side tie rods. The system is self-bleeding; bleeding is performed by completely steering to the right or to the left with the engine started and the vehicle stopped.

The oil level check must be performed with the engine started.


NOTE The description below concerns the TRW hydraulic power steering and due to their similarity, it also applies to the ZF hydraulic power steering.

The hydraulic part of the steering box consist of:

- a distributor (3);
- an hydraulic cylinder (1);
- a double-acting piston (4) integral with the rack rod.

The hydraulic connection between distributor and hydraulic cylinder is achieved using two stiff pipes (2). The distributor (3) is integral with the hydraulic power steering pinion.

Figure 3



24104

The distributor consists of:


- a drive shaft (1) (joined to the steering column);
- a distributing valve (4);
- a wrench bar (3);
- a pinion (6).

The drive shaft is elastically joined by the wrench bar to the pinion by means of the pin (2). The distributing valve, triggered on the drive shaft is integral with the pinion by means of a pin (5); it has holes and splines in order to receive and distribute the oil flow to the hydraulic cylinder. Besides, a stiff joint (A) ensures the mechanical working of the hydraulic power steering in case of failure of the hydraulic system, through a bayonet joint.

POWER STEERING TYPE TRW

Operation

Figure 4




24105

The hydraulic cylinder (1) is integral part of the hydraulic power steering. The double-acting piston (2) (integral with the rack rod) slides in the hydraulic cylinder and divides it into two separate chambers A and B.

The power steering is obtained by sending oil under pressure into one of the hydraulic cylinder chambers and discharging it into the other one. The power generated by the oil pressure on the side surface of the piston causes the movement of the piston and, as a result, of the rack. The feeding of one of the two hydraulic cylinder chambers occurs when the torque applied to the steering wheel causes the wrench of the bar; in this condition, the port of the drive shaft and the relevant ports of the distributing valve are joined depending on the rotary direction of the steering wheel. If the amount of torque applied to the steering wheel does not cause the wrench of the bar (low wheel resistance), the power steering does not intervene and the steering operates as a mechanical one.

Figure 5



24106


HYDRAULIC POWER STEERING OPERATION DIAGRAM: NEUTRAL POSITION

■ HIGH PRESSURE □ LOW PRESSURE

The oil coming from the pump through the joint (3) goes into the distributing valve, circulates in it and returns in the tank through the joint (4), simultaneously passing through the chambers (2) and (1).

The drive shaft (A), since it is not subject to wrench, is centred with respect to the distributing valve (B) and drives the oil coming from the pump directly into the tank through the ports (C). The chokes caused by the shaft (A) position with respect to the distributing valve (B) cause a pressure of ~ 3.5 bar in the right and left chamber through the ports (D) and (E).

Figure 6



24108

HYDRAULIC POWER STEERING OPERATION DIAGRAM: RIGHT STEERING

■ HIGH PRESSURE


□ LOW PRESSURE

The oil coming from the pump through the joint (3) goes into the distributing valve and it is sent to the hydraulic cylinder chamber (1) causing the movement of the piston.

This movement pushes the oil contained into the chamber (2), through the joint (4), into the tank, passing again in the distributing valve. The movement of the piston in the direction of the arrow shows a right steering.

The drive shaft (A), rotating clockwise with respect to the distributing valve (B), drives the oil under pressure coming from the pump through the ports (C), to the left chamber along the ports (E) and joins the discharge and the right chamber circuit by means of the ports (D).

Figure 7



HYDRAULIC POWER STEERING OPERATION DIAGRAM: LEFT STEERING

■ HIGH PRESSURE □ LOW PRESSURE


The oil coming from the pump through the joint (3) goes into the distributing valve and it is sent to the hydraulic cylinder chamber (2) causing the movement of the piston. This movement pushes the oil contained into the chamber (1), through the joint (4), into the tank passing again in the distributing valve.

The movement of the piston in the direction of the arrow shows a left steering.

The drive shaft (A), rotating clockwise with respect to the distributing valve (B), drives the oil under pressure coming from the pump through the ports (C), to the left chamber along the ports (D) and joins the discharge and the right chamber circuit by means of the ports (E).

POWER STEERING TYPE ZF
Operation

Figure 8



HYDRAULIC POWER STEERING OPERATION DIAGRAM: NEUTRAL POSITION

■ HIGH PRESSURE □ LOW PRESSURE


With the steering wheel positioned to straight running, the bush (2) is arranged so that the passage of both feeding and discharge oil of the operating cylinder is closed.

The oil pressures in the right and left chamber of the operating cylinder are balanced.

The oil under pressure coming from the power steering pump (4) through the piping (5) feeds the distributor (1) central groove, flows in the bush (2) splines, goes out from it and, through the piping (6) returns in the tank (3).

The neutral position of the hydraulic power steering is obtained and, therefore, the vehicle straight ride.

Figure 9



19595

HYDRAULIC POWER STEERING OPERATION DIAGRAM: RIGHT STEERING


■ HIGH PRESSURE

□ LOW PRESSURE

The oil under pressure coming from the power steering (4) pump, through the piping (5), feeds the distributor (1) passing in the central groove.

The rotation of the steering wheel causes a semi-rotation of the bush (2), this one is positioned so that the oil flows in its three splines and is sent to: the distributor upper groove, in case of right steering (Figure 9), or in the distributor lower groove, in case of left steering (Figure 10). The latter sends it to the relevant feeding piping (depending on the steering direction) of the operating cylinder chambers. Meanwhile, the oil contained in the chamber opposite to the fed one returns in the distributor. From the latter one, it flows in the discharge grooves of the bush (2) then, through the piping (6), returns in the tank (3). In this way the hydraulic interlocking is obtained.

Figure 10



19596

HYDRAULIC POWER STEERING OPERATION DIAGRAM: LEFT STEERING

■ HIGH PRESSURE

□ LOW PRESSURE




The only possible interventions on the power steering and mechanical steering systems are: replacement of ball joints, replacement of protective rubber boots, linkages and rubber bushings. Follow the instructions provided in the specific paragraphs. Replace the power steering system if problems referred to this system only are found.

CHECKS AND OPERATIONS ON THE VEHICLE

Checking maximum pressure

Figure 11



19598

Join a pressure gauge (2) on the oil delivery piping on the power steering pump (1). Rotate the steering wheel up to the limit stop, speed up the engine and read on the pressure gauge the maximum pressure value, which must be of 80 bar.

Checking hydraulic steering centre (for "ZF" power steering only)

Lift the front of the vehicle and put the wheels in the straight ride position.

Start the engine and fully speed up; if the steering gear put itself in steering position, the hydraulic steering centre is wrong and the hydraulic power steering must be changed.

501430 Bleeding the air from the hydraulic system

Check the oil level in the tank, if necessary top up. Lift the front part of the vehicle, start the engine and make it idle for a certain period.


Check that there is no oil leakage from the hydraulic circuit and check the tank level.

Slowly rotate the steering wheel in the two steering directions so that the air contained in the hydraulic system goes out. Check again the oil level in the tank and, in case top up.

520636 SWIVEL HEADS

501438 PROTECTION CASINGS

Figure 12



32875

Check that the protection casings of the knuckle heads are in perfect condition and that their pivots do not present play, otherwise replace them as described below.

Loosen the nut (3) securing the knuckle head (2) to the tie rod (4).

Remove the nut fixing the knuckle head to the steering gear lever and using the extractor (1) 99347074 remove the knuckle head.

Unscrew knuckle head from the tie rod of the steering box noting down the number of turns needed to disassemble. Remove the fixing brackets (5) and extract the protection casing (6).

In order to re-fit the assembly, perform the above operation in reversed order, sticking to the following instructions:

- carefully clean the steering gear tie rod knuckle;
- lubricate the protective boot seats on the power steering box to facilitate assembly;
- screw up the knuckle head with the same number of turns used to disassemble it;
- fit a new o-ring on the power steering box;
- tighten the nuts of the prescribed torque;
- Adjust toe-in as shown in the respective section.

501410 STEERING GEAR CONTROL

Vehicles equipped with an Air-Bag



Before doing any work on steering gear control components:

- steering wheel;
- steering control lever system;
- steering gear shaft

Strictly observe the safety standards described in the following paragraphs for Air-Bag system components.

SAFETY STANDARDS TO BE OBSERVED DURING REPAIR OR MAINTENANCE OPERATIONS ON VEHICLES EQUIPPED WITH AIR-BAG SYSTEM PROVIDED BY SUPPLIER



The following Standards shall be strictly observed when performing any type of repair or maintenance operations on vehicles equipped with Air-Bag safety system.

Preliminary Standards



Air-Bag modules shall be handled with the utmost care. Use, transport and storage of these components are governed by the handling procedures described in the following paragraphs.

Before starting any bodywork repair operation, welding or whatever work requiring to remove the Air-Bags or the control unit, proceed as follows:

- set ignition key to "STOP" and take it out;
- always disconnect the battery, i.e.: disconnect the two terminals from the relevant pole and insulate them properly by tape;
- wait for at least 10 minutes before proceeding;
- disconnect control unit connector.

Store modules with the cover set upwards, inside a metallic key-locked cabinet that must be used just with this purpose and that must not contain other type of materials, especially if flammables.

Adopted connectors wired to Air-Bag modules are provided with short-circuit clip. It is impossible to activate units accidentally until Air-Bag modules are connected to a power source with suitable properties.

A system component not activated in case of collision is to be considered still "live" (active).

Live components that shall be removed from vehicles (due to defects, warranty expiry or other reasons) shall be returned to the suitable Centre using the following procedure.



Component removal and refitting shall be performed EXCLUSIVELY by skilled and authorised personnel. Failure to comply with the following procedure can result in unintentional activation of the system, severe injury or repairs not required. IT IS ABSOLUTELY FORBIDDEN TO DISASSEMBLE Air-Bag MODULE COMPONENTS.

System components are designed to operate just on vehicles of the specified make and type. Air-Bags must therefore not be adapted, reused or installed on other vehicles.

Mount and use them only on the vehicles for which they have been designed and produced.



Any reuse, adaptation or installation on a different type of vehicle can result in severe injury or death for passengers in case of collision.

Repairs and inspections required after an accident



Any safety system component damaged after an accident must be replaced. Do not attempt to repair the control unit, the coil cable or the Air-Bag modules.

Accidents with or without Air-Bag module activation

Certain system components must be inspected after any crash, whether the Air-Bag deployed or not. These components are the following:

- steering column;
- steering column support;
- electronic control unit anchoring area and modules;
- coil cable;
- dashboard (in the area of the passenger Air-Bag).

If any faulty condition is found, replace the faulty component.

Accidents with Air-Bag module activation

In case of front impact with total system activation, the following components must be replaced:

- Air-Bag modules;
- pretensioners;
- electronic control unit;
- coil cable.

Inspect cables and connectors to find any burning, external insulation melting or damages due to excessive heat.

If any faulty condition is found on coil cable, electronic control unit anchoring area and modules, replace the faulty component.

Painting

Since modules and pretensioners are designed to withstand the temperatures developed during standard baking operation on bodywork, no special safety requirement shall be observed during painting or baking.

Do not use open flames when working near the modules. Electronic control units (including the Air-Bag one) shall always be removed when temperature in certain rooms is equal to or exceeds 85°C.

Risks for health

Precautions to be observed when handling live Air-Bag are the following:

- wear protective polyethylene gloves and goggles;
- wash hands and any exposed body part with water and soap after handling live modules.

Overexposure effects

Since system is completely sealed there is no potential danger of exposure to propelling gas.

Propelling gas mixture is at solid state, it is therefore impossible to inhale gas even in case of gas generator cartridge breakage. There is no risk for health in case of gas leakage.

Avoid in any case contact with the skin and do not swallow the propelling gas.

In case of:

- contact with the skin: rinse immediately with water and soap;
- contact with eyes: rinse immediately with fresh water for 15 minutes at least;
- inhalation: bring immediately the injured person to open air;
- swallow: make the injured person vomit if conscious.



Always call the doctor in any of the above cases.

Safety Standards to observe when handling Air-Bag modules

Driver and passenger Air-Bags usually activate in case of collision through the action of the electronic activation control. Gas (mainly nitrogen) produced under these conditions are not toxic.

Personnel operating on safety system shall strictly observe the following safety standards.

Personnel operating on these devices shall be suitably trained and must observe the following precautions:

- when removing or replacing activated Air-Bags, wear protective polyethylene gloves and goggles and handle just one module at a time;
- always place the Air-Bag module with the cover and exhaust hole upwards. Never put something on Air-Bag cover;
- once servicing is over rinse hands with water and neutral soap, in case of eyes contact with residual powders rinse immediately with fresh water;
- before starting servicing, disconnect both battery cables (first the negative one), insulate terminals by tape and wait at least 10 minutes before proceeding;
- metal components of the Air-Bag are hot after explosion, avoid to touch these components for at least 20 minutes from module activation;
- do not repair Air-Bags but send faulty modules to supplier. Do not heat the Air-Bag module by welding, percussion, drilling, mechanical machining, etc.;
- never install on vehicle a damaged or fall Air-Bag module;
- it is prohibited to store Air-Bag modules together with flammable material or fuels;
- gas generators must not come into contact with acids, greases or heavy metals since contact can result in formation of poisonous, noxious gas or explosive compounds;
- never use open flames when working near Air-Bag modules or system components.

Spare parts shall be stored in their original package and temporary storing shall follow the same procedure as for live modules disconnected from vehicle, i.e. storage into dedicated metallic key-locked cabinet (resistant to shocks and provided with grids to enable natural ventilation). Cabinet shall be provided with proper warning plates (RISK OF EXPLOSION - NO OPEN FLAMES - NO OPENING BY UNAUTHORISED PEOPLE).

Air-Bag module scrapping

Air-Bag modules must not be scrapped together with the vehicle, but must be previously removed and activated as described in the following pages.

Air-Bag units must always be activated before scrapping.

An Air-Bag module not exploded during an accident is to be considered still "live".

Live materials MUST NOT BE ACTIVATED but must be sent to a specialised centre (in Italy to GECMA in Chivasso) specifying on the freight note:

- Air-Bag DEVICE CONTAINING PYROTECHNIC CHARGE TO BE DEACTIVATED.**

Devices must be sent using their original packages only. Should the original package be not available, a new one shall be requested to SPARE PARTS.

In case of Air-Bag device replacement, the original package shall obviously be kept in good conditions to send the non-activated device.

FOREIGN MARKETS shall observe local current laws and regulations.



Failure to observe these procedures can result in unintentional Air-Bag module activation and severe injury. Live Air-Bag units must NOT be disposed of using the common disposal procedure. Live Air-Bag units contain substances dangerous for health that can cause severe injury if the sealed container is damaged during disposal.



Live Air-Bag units contain substances dangerous for health that can cause severe injury if the sealed container is damaged during disposal.

Safety Standards to observe when handling pretensioners

In case of front impact, driver and passenger pretensioners usually activate just a minute before Air-Bag modules

Personnel operating on these devices shall be suitably trained and must observe the following precautions:

- when handling activated pretensioners, i.e. with activated propelling gas, wear protective gloves and goggles;
- once servicing is over rinse hands with water and neutral soap, in case of eyes contact with residual powders rinse immediately with fresh water;
- disconnect both battery cables (first the negative one), insulate terminals by tape and wait at least 10 minutes before proceeding;
- pretensioner produce heat during activation, it is therefore necessary to wait at least 10 minutes before operating;
- protect pretensioners against fall or shock during handling or transport; damaged or fallen pretensioners must not be used and must be returned to supplier communicating the reason for;
- never carry pretensioners by the seat belt;
- pretensioners must be protected against sparks and open flames and must not stay in contact with surfaces with temperatures exceeding 100°C for more than 6 hours;
- propelling gas not burnt is flammable, therefore generator components must never be disassembled, damaged or tampered;
- it is prohibited to store pretensioners together with flammable material or fuels;
- gas generators must not come into contact with acids, greases or heavy metals since contact can result in formation of poisonous, noxious gas or explosive compounds;
- seat belts with pretensioners shall be stored in proper key-locked compartments or cabinets, suitably aerated and away from open flames and heat sources.



After any impact involving pretensioner activation, the seat belt is unserviceable and must be replaced.

Pretensioners scrapping

Non-activated pretensioners (not installed on vehicle) must always be activated before scrapping. Non-activated pretensioners installed on vehicle must not be scrapped together with the vehicle, but must be previously removed. Pretensioner not activated during an accident is to be considered still "live" and therefore it is necessary to follow the procedure described in this manual.

Operations on system components

Once servicing operations are completed, the system shall be tested by Modus, I.W.T. or equivalent diagnostic equipment. Air-Bag components are provided at installation with a label with a removable part showing system and components date of installation.

The removable part is detached and data are stored together with the test report provided by Modus, by the workshop that has installed the components.

After 10 years from installation, unless prior replacement, a new Air-Bag system (cable and components) shall be installed. As said above components technical data and the date of installation will be filed.

Removing and scrapping activated Air-Bag module and pretensioner from vehicle

Always wear gloves and goggles when handling activated Air-Bag or pretensioner. Wash hands and exposed skin with water and neutral soap after handling activated Air-Bag or pretensioner. In case of exposure to secondary products, rinse eyes immediately with fresh water. Failure to observe these indications can result in severe injury.

To remove and scrap activated Air-Bag module and pretensioner proceed as follows:

- follow instructions contained in this manual to remove activated Air-Bag module and pretensioner;
- disconnect Air-Bag module and pretensioner mechanical fixings;
- disconnect component connector form Air-Bag wiring;
- put Air-Bag module and pretensioner in the proper sealed nylon bag;
- send to authorised collection/disposal centre;
- dispose of, recycle or scrap deployed Air-Bag module and pretensioner using the suitable procedure.

Propelling gas residues shall be considered with attention. These residues that are mostly concentrated on the generator body or in small amount in the bag can contain copper or chlorides (e.g. potassium chloride). Combustion residues are very alkaline and corrosive.

Always wear skin protections and goggles. Activated Air-Bags must always be stored in dry and well ventilated places.

Removing and scrapping non-activated Air-Bag module from a repairable vehicle



Never cut the cables or tamper the connector between vehicle wiring and Air-Bag module. Connector contains a safety clip.

If connector is cut or removed from Air-Bag unit, the safety clip is disabled and this can result in unintentional activation and severe injury.

Air-Bag systems have a backup power supply located in the control unit. This power supply shall be deactivated by disconnecting the two battery terminals and waiting for at least 10 minutes before starting any operation on whatever Air-Bag component.

Keep the bag and the external bag cover in opposite direction to body when handling a live Air-Bag module. When placing a live Air-Bag on the bench or some surface like that, set the bag and the cover facing upwards and far from people. Never place objects near a live Air-Bag, since in case of module deployment objects will be thrown away like shells.



Always store live Air-Bag modules and pretensioners in fresh, dry, close and safe place. Do not expose to open flames or temperatures exceeding 150°C.




Never cut, drill, solder or weld an Air-Bag module or its components. Failure to observe these indications can result in unit damages, fire, unintentional deployment and severe injury.

Damaged live Air-Bag modules and pretensioners (e.g. electric connection breakage), shall be store far from corrosive or oxidising substances. Failure to observe these indications can result in fire and/or severe injury.



Air-Bag modules and pretensioners are provided with backup power supply giving the electrical pulse required to bag deployment when the accident damages the battery or the cables before the sensor activates the gas generator.

Figure 13



8663

AIR-BAG MODULE REMOTE ACTIVATION DIAGRAM

- C1 = Air-Bag module connector
 C2 = remote activation device connector (Air-Bag connector with safety clip, counterparts with male pins on Air-Bag side)
 Lb = braid length = approx. 1 m
 L = main cable, safety distance 10 m
 A fenced area
 B Remote activation device

Air-Bag module deployment

Remote activation

General instructions:

- activation procedure can be performed in open area, suitably defined and fenced, far from flammable materials, liquids or other substances and far from people. Set the Air-Bag module on a firm surface and lock it;
- clean this area from any material (glass, instruments, parts, etc.) which could become like shells during deployment;
- check whether connector C2 is disconnected from remote activation device (10 m).
- connect electric connector C1, specified by vehicle manufacturer, to remote activation Air-Bag module;
- connect connector C2 to remote activation device;
- connect remote activation device to 12V circuit or equivalent device;
- stand protected;
- wear goggles and protective clothes;
- depress double activation push-button;
- wait for approx. 20 minutes before touching the activated Air-Bag module since it is hot;
- dispose of, recycle or scrap, as required, activated Air-Bag modules as described in the relevant chapters.

Activating Air-Bag modules and electronic pretensioners installed on unrecoverable vehicles

This procedure is to be used when scrapping a vehicle with one or more live Air-Bag modules. This procedure is valid whether Air-Bag system and/or electronic pretensioners are sound or not.


It is recommended to activate pyrotechnic charges on vehicles by directly connecting the electric connector of each module to remote activation device.



Deployment procedure shall be performed outdoor, away from people and in a well defined area. Check for absence of objects and flammable fluids near modules and pretensioners. Do not remain on the vehicle during activation and remember to close the doors. Stand protected (e.g. behind a wall, a vehicle, etc.) against thrown-away objects, if any. Let generators and modules cool down after deployment (20 min. at least before proceeding). Failure to observe these indications can result in severe injury.

General instructions:

- follow all WARNINGS, PRECAUTIONS and safety instructions reported in this manual;
- bring the vehicle outside in the provided area;
- remove from the area around the Air-Bag covering all materials and slugs (glasses, tools, components etc.) and make sure that no inflammable liquids are nearby;
- disconnect the two battery cables (first the negative cable) and wait for at least 10 minutes before proceeding;
- use a connecting braid (L= about 1 m) with specific terminal connector for the electric connection with the module to activate;
- reach the electric module connection (Air-Bag or electronic pretensioner), following the instructions of this manual;
- disconnect connector C1 of the pretensioner or Air-Bag module;
- check whether connector C2 is disconnected from remote activation device;
- connect the electric connector C1 of the pretensioner or Air-Bag module to the connecting braid of the remote activation device;
- connect connector C2 to remote activation device;
- place people in a safe place;
- connect the remote control device to a 12 Volts circuit or equivalent device;
- press the double activation push-button to activate all pretensioners and Air-Bag modules at the same time;
- after activating the Air-Bag modules and pretensioners, leave them cooling before touching them (about 20 minutes);
- after activating the Air-Bag modules and pretensioners, the vehicle can be scrapped - by squashing or crushing - and/or recycled, depending on the cases.

Figure 14


8664

VEHICLE PYROTECHNIC CHARGES ACTIVATION DIAGRAM, SINGLE ACTIVATION

- ABG = driver Air-Bag
- ABP = passenger Air-Bag
- C2 = remote activation device connector
- C1 = specific pyrotechnic charge connector
- L = main cable, safety distance 10 m
- Lb = braid length
- PTG = driver pretensioner
- A. Remote activation device

541415 Upper steering gear shaft removal

Figure 15




62107

Disconnect the battery (2) cables (1-3) first the negative cable (1) then the positive one (3) and insulate them taping the terminals.

For vehicles equipped with Air-Bag

Follow the safety standards given in the relevant chapter and wait for 10 minutes before proceeding.


Figure 16



62108

For vehicles without Air-Bag, remove the pressure-fit cover (2) on the steering wheel.
For vehicles with Air-Bag, turn the steering wheel and position it as shown in the figure, in order to easily reach the screws (1 and 3) and remove them.

Figure 17



62108

- Lift the Air-Bag module (1) in order to disconnect connector (2);
- Remove the Air-Bag module (1) from the steering wheel (3).




After removal, non-activated Air-Bag modules must be stored with plate laying on the surface in a suitable key-locked cabinet.

For all vehicles

Remove fixing nut (4).

Figure 18




62109

Set front wheels in straight running and mark (→) steering wheel assembly position (1) on upper steering gear shaft (2).
Remove the steering wheel (1) from the shaft (2).
For vehicles with Air-Bag, make sure not to extract or damage coil device cable (3).


! Make sure that steering wheel removal has lifted the top cap of the coil device. If the top cap turns, it will be necessary to block it by bringing it to the outside. If you hear a "click", it means that the cap is blocked. For any removals of the winding device, meticulously observe what specified in "Electric System" section.

Figure 19



Remove the two screws (2) and remove the upper protection (1). Remove the three screws (4) and remove the lower protection (3).

Figure 20



Cut electric cable fixing clamps and disconnect connectors (9-10-13). On vehicles equipped with ESP, take off connector (14) of steering angle sensor (15) incorporated into the steering column stalk. Loosen screw (3) locking indicator switch retaining clamp to gear shaft (1). Remove the indicator switch (2) from the gear shaft (1). To remove steering angle sensor (15), you just need to take off cover (16) and unscrew the three screws (17) that secure it to the steering column stalk.

Mark universal joint (6) assembly position on lower shaft (8) and loosen the fixing screw (7). Remove the screws (4-5) and disconnect the upper steering gear shaft (1) from the lower steering gear shaft (8). To replace or disassemble switch (12) it is necessary to unscrew screws (11) using a proper punch or drill them in order to eliminate the most of material to remove them. Make sure not to damage switch thread in case of reuse. At refitting, the new screws (11) must be tightened till the hexagonal head is sheared from its rod.



Refitting


For refitting reverse removal operations and observe the following recommendations:

- reconnect shafts and refit steering wheel matching the marks made during removal operations;
- at refitting, the self-braking nuts and the steering wheel fixing nut must always be replaced;
- tighten nuts and screws to the prescribed torque;
- after tightening steering wheel fixing nut to upper shaft, it is necessary to crimp the nut;
- when refitting is completed, carry out operation test on indicator switch and horn.

NOTE On vehicles equipped with ESP, the steering angle sensor is fitted inside the steering column stalk. In this case, you will have to carry out the functional checks as well as the calibration procedure described in the relevant chapter of the "Brakes" section (page 63).


541413 Lower steering gear shaft removal

Figure 21



Remove the upper steering gear shaft as described in the relevant chapter (operation 541415). Lift cover (1) from floor. Unscrew the three fixing screws (2) of lower shaft (3) support (4).

Figure 22



Mark universal joint (6) assembly position on hydraulic power steering (3) shaft.
Loosen screw (7) and remove hydraulic power steering lower shaft.



Refitting

For refitting reverse removal operations, complying with upper steering gear shaft refitting operations.

5014 HYDRAULIC POWER STEERING 541413 Hydraulic power steering removal

Proceed as follows to remove the hydraulic power steering:
Loosen front wheel fixing screws or nuts.
Lift the front part of the vehicle, support it by proper stands and brake rear wheels.
Position tool 99321024 near the wheels, remove wheel fixing screws or nuts. Remove the wheels.
Remove cap (1) from hydraulic power steering oil tank.
Disconnect pipes (4-5) from hydraulic power steering (3) and drain system oil into a suitable container.
Steer wheel hubs in both directions to drain out oil from the system.
Remove nuts (8) fixing kingpins (10) to steering levers (9) and remove the latter using extractor 99347074.
Loosen the screw (7) fixing the universal joint (6) to the hydraulic power steering shaft (3).
Remove the fixing screws (2) and remove the hydraulic power steering (3).



Refitting

For refitting reverse removal operations and observe the following recommendations:

- after refitting the hydraulic power steering to the front cross member or to the driving axle, turn the pinion up to bring the rack to the end of the stroke. Turn again the pinion to the opposite direction for a number of turns equal to half of the turns required to the rack to complete the whole stroke (approx. 2 turns);
- in this position, set steering wheel in straight running condition and connect the elastic joint to hydraulic power steering pinion fork or the universal joint to the hydraulic power steering.
- At refitting, the self-braking nuts must not be reused but replaced with new ones.
- tighten screws and nuts to the prescribed torque;
- fill hydraulic power steering system tank in and carry out the drainage as described in the relevant section;
- check and adjust toe-in as described in the relevant section.




The only repair operations to carry out on hydraulic power steering and mechanical steering are the following: joint head replacement and rubber boots replacement. In these cases, follow the operations described in the relevant section.
If defects depending only on the hydraulic power steering are found, replace it.

Steering linkage replacement

Removal


Figure 23



86010

Use suitable pliers to loosen the retainer clamps (2 and 4), remove the protective boot (3) from the power steering box (1) and move it aside to access the steering linkage connection (5) to the rack rod.

Figure 24



86011


Tighten the rack rod (2) in a vice with lead covered jaws, loosen the joint (3) and remove the steering linkage (4). Remove the o-ring (1). Repeat the operations to remove the opposite steering linkage. Follow the removal/refitting operations described in the respective sections to reuse ball joints.



Do not take the rack rod (2) to end of stroke after removing the linkage (4) to avoid damaging the power steering o-rings.

Refitting

Figure 25



86012

POWER STEERING SYSTEM SPARE PARTS

- 1. O-ring - 2. Clamp - 3. Protective boot - 4. Clamp - 5. Steering linkage - 6. Nut - 7. Head - 8. Tube - 9. Tube - 10. Power steering unit - 11. Rubber bushing.

Reassemble by reversing the disassembly sequence; observe the following precautions:

- replace o-rings (1) and clamps (2 and 4) with new parts;
- lubricate (→) protective boot (3) seats on power steering unit (10) to facilitate assembly of the boots;
- tighten steering linkage joints (5) at 100 ± 10 Nm (10 ± 1 kgm).


Rubber bushing replacement procedure

Use a suitable ram to remove/refit rubber bushings (11).

501450 POWER STEERING PUMP

8140 engine power steering pump

Figure 26



19597

8140 ENGINE POWER STEERING PUMP OPERATION

■ HIGH PRESSURE

□ LOW PRESSURE

Operation

Rotating the shaft (5) and the rotor (8) joined to it and the blades (6) able of a radial motion, are pressed by their centrifugal force and by the oil pressure against the guide track of the stator (7).

Each couple of near blades forms a chamber, which has as side limits thrust plates (9 and 10).

The suction and delivery chambers are arranged so that the radial hydraulic stresses exerted on the rotor (8) balance one another.

Four splines both made on the front plate cover side (10) and in the internal plate (9), make the oil under pressure reach the surfaces of the blades directed to the rotation centre, helping in this way the centrifugal force.

The oil coming from pressure chambers comes to the delivery relief valve through holes and then, through a choke (2) at the delivery joint (1)

The oil under pressure downstream the choke is sent, through suitable holes, to the side fitted with spring of the delivery relief piston (4).

Increasing the number of turns, and therefore the pump delivery, an increasingly higher difference in pressure between the chambers upstream and downstream the choke is caused on the side fitted with spring of the piston (4).

As soon as the hydraulic force (pressure difference multiplied by the piston surface (4)) exceeds the spring force, the piston moves leftward so that the exceeding oil returns in the suction channel (11) of the pump, through the free hole. In this way the steering gear is fed by a delivery of hydraulic oil almost constant at any speed of the pump (and therefore of the engine).


An overpressure valve (3) is fitted in the delivery relief piston (4).

When an overpressure occurs in the hydraulic circuit, the oil pressing on the valve (3) increasing the pressure, overcomes the spring resistance and through an hole, discharge in the suction channel (11) of the pump.

In this way, the oil pressure adjustment is obtained.

FIA engine power steering pump


Figure 27



86013

FIC engine power steering pump

Figure 28



89008

Operation of the power steering pumps for FIA/FIC engines is similar to that of 8140 engines.

Power steering pump overhaul procedure

Replace the power steering pump if poor operation is found.

SECTION II**78 Hydro-pneumatic system****52 Brakes**























| | Page |
|--|------|
| GRAPHIC SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (MISCELLANEOUS AND GENERATORS) . . | 3 |
| GRAPHIC SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (VALVES) . . . | 4 |
| GRAPHIC SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (TANKS AND ACCUMULATORS) | 10 |
| GRAPHIC SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (CONVERTERS, CYLINDERS AND CALIPERS) | 11 |
| GRAPHIC SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (CALIPERS AND CYLINDERS) | 12 |
| GRAPHIC SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (SEMI-COUPPLINGS AND COUPLING HEADS) | 13 |
| GRAPHIC SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (INDICATORS AND SWITCHES) | 15 |
| GRAPHIC SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (BRAKES) . . . | 16 |
| PIPES AND COUPLINGS | 17 |
| <input type="checkbox"/> General | 17 |
| <input type="checkbox"/> Re-flanging rigid pipes | 17 |
| <input type="checkbox"/> Bending rigid pipes | 18 |
| <input type="checkbox"/> Cutting rigid pipes | 18 |
| <input type="checkbox"/> Replacing flexible hoses with threaded couplings | 19 |
| <input type="checkbox"/> Replacing flexible hoses with quick release couplings | 20 |
| BRAKING SYSTEM | 22 |
| <input type="checkbox"/> Outline diagram for vehicles 29L - 35S | 22 |
| <input type="checkbox"/> Outline diagram for vehicles 35C - 40C - 45C - 50C - 60C - 65C | 23 |
| <input type="checkbox"/> Outline diagram for vehicles 29L - 35S with ABS | 24 |
| <input type="checkbox"/> Outline diagram for vehicles 35C - 40C - 45C - 50C - 60C - 65C with ABS | 25 |

| | Page |
|---|------|
| <input type="checkbox"/> Outline diagram for vehicles 29L - 35S with ESP | 25/1 |
| <input type="checkbox"/> Outline diagram for vehicles 35C with ESP . . . | 25/2 |
| <input type="checkbox"/> Braking system main components layout | 26 |
| <input type="checkbox"/> Location of the main brake system components on vehicles with ABS | 28 |
| <input type="checkbox"/> Location of the main brake system components on vehicles with ESP | 29/1 |
| DESCRIPTION | 29/2 |
| <input type="checkbox"/> Service brake | 29/2 |
| BRAKES | 29/2 |
| <input type="checkbox"/> Front and Rear disc brakes | 29/2 |
| <input type="checkbox"/> Emergency brake | 29/2 |
| <input type="checkbox"/> Parking brake | 29/2 |
| <input type="checkbox"/> Diagnosis Instruments | 30 |
| FAULT DIAGNOSIS | 30 |
| TIGHTENING TORQUES | 38 |
| TOOLS | 40 |
| SPECIFICATIONS AND DATA - HYDRAULIC SYSTEM | 43 |
| SPECIFICATIONS AND DATA - BRAKES | 44 |
| <input type="checkbox"/> Functional check of vacuum brake system | 46 |
| CHECKS | 46 |
| BRAKING SYSTEM MAIN COMPONENTS | 47 |
| <input type="checkbox"/> Vacuum pump | 47 |
| <input type="checkbox"/> Vacuum servo brake | 47 |
| <input type="checkbox"/> Bleeding air from the hydraulic circuit (vehicles not equipped with ABS) | 48 |
| <input type="checkbox"/> Bleeding air from the hydraulic circuit with deaerator device (vehicles not equipped with ABS) | 48 |
| <input type="checkbox"/> Air bleeding from the ABS/ESP system hydraulic circuit | 48/1 |































| | Page |
|--|-------|
| <input type="checkbox"/> Regulation of load proportioning valve on vehicle | 49 |
| <input type="checkbox"/> Mechanically controlled load sensing valve (vehicles 35C - 40C - 45C - 50C - 60C - 65C) | 49 |
| <input type="checkbox"/> Dual mechanically controlled load sensing valve (vehicles 29L - 35S) | 50 |
| <input type="checkbox"/> Adjusting the load sensing valve | 50 |
| STABILITY CONTROL AND ANTI-SKID DEVICES | 51 |
| ABS SYSTEM FUNCTIONS | 51 |
| <input type="checkbox"/> Antilock braking system (ABS) | 51 |
| <input type="checkbox"/> Electronic braking distribution device (EBD) | 51 |
| <input type="checkbox"/> Anti-skid braking device (ABD) | 51 |
| <input type="checkbox"/> Electronic Stability Program (ESP) - Option | 51 |
| FUNCTIONS INCLUDED IN THE ESP SYSTEM ONLY | 51 |
| <input type="checkbox"/> Acceleration drive control device (ASR) | 51 |
| <input type="checkbox"/> Engine braking torque control (MSR) | 51 |
| <input type="checkbox"/> Hill holder control (HHC) | 51 |
| <input type="checkbox"/> Hydraulic Brake Assistant (HBA) | 51 |
| <input type="checkbox"/> Electro-hydraulic modulator/control unit for 29L - 35S vehicles | 51/1 |
| <input type="checkbox"/> Electro-hydraulic modulator/control unit for 35C - 65C vehicles | 51/2 |
| ABS 8/ESP 8 ELECTROHYDRAULIC MODULATOR DIAGRAMS | 51/3 |
| <input type="checkbox"/> Hydraulic diagrams of ABS 8 modulator – 4-channel (X) | 51/4 |
| <input type="checkbox"/> Hydraulic diagrams of ABS 8 modulator – 3-channel (II) | 51/8 |
| <input type="checkbox"/> Hydraulic diagrams of ESP 8 modulator – 4-channel (X) | 51/12 |
| <input type="checkbox"/> Hydraulic diagrams of ESP 8 modulator – 4-channel (II) | 51/21 |

| | Page | | Page |
|--|------|--|------|
| <input type="checkbox"/> Rev sensor | 52 | YAW SENSOR | 65 |
| <input type="checkbox"/> Phonic wheels | 52 | <input type="checkbox"/> Removal | 65 |
| ESP SYSTEM SENSORS | 52 | <input type="checkbox"/> Refitting | 65 |
| <input type="checkbox"/> Yaw sensor with built-in side acceleration sensor | 52 | <input type="checkbox"/> Calibration | 65 |
| <input type="checkbox"/> Longitudinal acceleration sensor | 52 | ELECTROHYDRAULIC MODULATOR/CONTROL UNIT | 66 |
| <input type="checkbox"/> Steering angle sensor | 52 | <input type="checkbox"/> Removal | 66 |
| BRAKE REPAIRS | 53 | <input type="checkbox"/> Refitting | 66 |
| <input type="checkbox"/> Front brakes | 53 | <input type="checkbox"/> Programming | 66 |
| <input type="checkbox"/> Replacing brake linings | 53 | <input type="checkbox"/> Calibration | 66 |
| <input type="checkbox"/> Brake caliper removal and refitting | 54 | <input type="checkbox"/> Bench overhauling | 67 |
| REAR BRAKES | 55 | <input type="checkbox"/> Disassembly | 67 |
| <input type="checkbox"/> Replacing brake linings | 55 | <input type="checkbox"/> Assembly | 67 |
| <input type="checkbox"/> Brake caliper removal and refitting | 57 | | |
| OVERHAUL OF BRAKE CALIPERS | 57 | | |
| <input type="checkbox"/> 2x42 - 2x44 - 2x46 - 2x52 Brembo brake calipers | 57 | | |
| <input type="checkbox"/> 1x52 Brembo brake calipers | 58 | | |
| OVERHAULING BRAKE DISCS | 59 | | |
| MACHINING AND GRINDING OF DISC BRAKES | 59 | | |
| WHEEL NUT TIGHTENING SEQUENCE | 60 | | |
| OVERHAULING PARKING BRAKE | 60 | | |
| <input type="checkbox"/> Assembly | 62 | | |
| <input type="checkbox"/> Adjusting parking brake | 62 | | |
| REPLACING THE ESP COMPONENTS | 63 | | |
| STEERING ANGLE SENSOR | 63 | | |
| <input type="checkbox"/> Replacing | 63 | | |
| <input type="checkbox"/> Calibration | 63 | | |
| LONGITUDINAL ACCELERATION SENSOR .. | 64 | | |
| <input type="checkbox"/> Removal | 64 | | |
| <input type="checkbox"/> Refitting | 64 | | |
| <input type="checkbox"/> Calibration | 64 | | |

GRAPHIC SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (MISCELLANEOUS AND GENERATORS)

| DESCRIPTION | SYMBOL | |
|------------------------------|---|---|
| HYDRAULIC FLOW |  | |
| AIR FLOW |  | |
| ELECTRICAL LINE |  | |
| ABLE TO ROTATE |  | |
| CROSSOVER OF CONNECTED LINES |  | |
| PRESSURE TEST POINT |  | |
| QUICK-RELEASE COUPLING |  | |
| COCK |  |  |
| COCK WITH OUTLET |  |  |
| SILENCER |  | |
| COMPRESSOR |  |  |
| ENERGY SAVING COMPRESSOR |  |  |
| VACUUM PUMP |  |  |
| HYDRAULIC PUMP |  |  |
| HYDRAULIC HAND PUMP |  |  |






















GRAPHIC SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (VALVES)

| DESCRIPTION | SYMBOL | |
|---|---|---|
| CONDENSATE SEPARATOR |  |  |
| FILTER |  |  |
| DEHUMIDIFIER |  |  |
| DEHUMIDIFIER |  |  |
| DEHUMIDIFIER WITH BUILT-IN REGULATOR |  |  |
| AUTOMATIC CONDENSATION DRAIN VALVE |  |  |
| CONTROLLED CONDENSATION DRAIN VALVE |  |  |
| HAND CONDENSATE DRAIN VALVE |  |  |
| CONTROLLED ANTI-ICING UNIT |  |  |
| AUTOMATIC ANTI-ICING UNIT |  |  |
| PRESSURE REGULATOR WITH INDEPENDENT CIRCUIT |  |  |
| PRESSURE CONTROLLER |  |  |
| PRESSURE CONTROLLER |  |  |
| PRESSURE CONTROLLER (GOVERNOR) |  |  |
| PRESSURE LIMITING VALVE |  |  |



















GRAPHIC SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (VALVES)

| DESCRIPTION | SYMBOL | |
|------------------------------------|--------|--|
| PROPORTIONAL REDUCING VALVE | | |
| MATCHING VALVE | | |
| FOUR CIRCUIT PROTECTION VALVE | | |
| THREE CIRCUIT PROTECTION VALVE | | |
| TWO CIRCUIT PROTECTION VALVE | | |
| NON-RETURN AIR INLET VALVE | | |
| NON-RETURN AIR INLET VALVE | | |
| SAFETY VALVE | | |
| CHECK VALVE | | |
| CHECK VALVE | | |
| DOUBLE SHUT-OFF VALVE | | |
| DIFFERENTIAL DOUBLE SHUT-OFF VALVE | | |
| THROTTLE VALVE WITH QUICK RETURN | | |
| THROTTLE VALVE | | |
| CONTROL VALVE | | |



















GRAPHIC SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (VALVES)

| DESCRIPTION | SYMBOL | |
|-----------------------------|---|---|
| DUMP VALVE |  |  |
| BRAKE CONTROL VALVE |  |  |
| BRAKE CONTROL VALVE |  |  |
| BRAKE CONTROL VALVE |  |  |
| PARKING BRAKE CONTROL VALVE |  |  |
| PARKING BRAKE CONTROL VALVE |  |  |
| BRAKE VALVE |  |  |
| CONTROL VALVE |  |  |
| CONTROL VALVE |  |  |
| RETARDER CONTROL VALVE |  | |
| SERVO CONTROL VALVE |  |  |















GRAPHIC SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (VALVES)

| DESCRIPTION | SYMBOL | |
|---|---|---|
| SERVO CONTROL VALVE |  |  |
| SERVO CONTROL VALVE FOR SINGLE LINE |  |  |
| TRAILER BREAKING TRIPLE CONTROL VALVE |  |  |
| TRAILER BREAKING TRIPLE CONTROL VALVE WITH BUILT-IN SERVO SWITCHING |  |  |
| LOAD PROPORTIONING VALVE |  |  |
| DUAL LOAD PROPORTIONING VALVE |  |  |
| LOAD PROPORTIONING VALVE WITH BY-PASS |  |  |
| LOAD PROPORTIONING VALVE WITH BUILT-IN RELAY |  |  |
| LOAD PROPORTIONING VALVE WITH BUILT-IN RELAY WITH AIR CONTROL |  |  |







GRAPHIC SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (VALVES)

| DESCRIPTION | SYMBOL | |
|--|---|---|
| LOAD PROPORTIONING VALVE WITH AIR CONTROL |  |  |
| LOAD PROPORTIONING VALVE WITH AIR CONTROL |  |  |
| PROPORTIONAL REDUCING VALVE |  |  |
| SLAVED PROPORTIONAL REDUCING VALVE |  |  |
| SLAVED LIMITING VALVE |  |  |
| LEVELLING VALVE |  |  |
| LEVELLING VALVE |  |  |
| HAND OPERATED SUSPENSION RAISING CONTROL VALVE |  |  |
| LEVELLING VALVE WITH BUILT-IN TRAVEL LIMITER |  |  |

























GRAPHIC SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (VALVES)

| DESCRIPTION | SYMBOL | |
|---|---|---|
| PROPORTIONAL CONTROL VALVE |  |  |
| HAND OPERATED SUSPENSION CONTROL VALVE WITH ELECTRICAL MONITORING |  |  |
| ELECTROPNEUMATIC VALVE |  |  |
| ELECTROPNEUMATIC VALVE |  |  |
| ELECTROPNEUMATIC VALVE |  |  |
| HYDRAULIC MODULATOR FOR ABS |  |  |
| AUGMENTER VALVE |  |  |











**GRAPHIC SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS
(TANKS AND ACCUMULATORS)**

| DESCRIPTION | SYMBOL | |
|-----------------------|---|---|
| COMPRESSED AIR TANK |  |  |
| BRAKE FLUID RESERVOIR |  |  |
| AIR SPRING |  |  |






**GRAPHIC SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS
(CONVERTERS, CYLINDERS AND CALIPERS)**






| DESCRIPTION | SYMBOL | |
|--------------------------------|---|---|
| VACUUM SERVO BRAKE |  |  |
| VACUUM SERVO BRAKE |  |  |
| DUAL CIRCUIT MASTER CYLINDER |  |  |
| SINGLE CIRCUIT MASTER CYLINDER |  |  |
| AIR/HYDRAULIC CONVERTER |  |  |
| AIR/HYDRAULIC CONVERTER |  |  |
| HYDRAULIC BRAKE CYLINDER |  |  |
| SLAVE CYLINDER |  |  |
| BRAKE CYLINDER |  |  |
| SPRING CYLINDER |  |  |
| COMBINED BRAKE CYLINDER |  |  |
| FIXED DISK BRAKE CALIPER |  |  |

**GRAPHIC SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS
(CALIPERS AND CYLINDERS)**









| DESCRIPTION | SYMBOL | |
|--|---|---|
| FLOATING DISK BRAKE CALIPER |  |  |
| FLOATING DISK BRAKE CALIPER WITH PARKING |  |  |
| MECHANICAL FLOATING DISK BRAKE CALIPER |  |  |
| SERVO CLUTCH |  |  |
| SERVO CLUTCH |  |  |

**GRAPHIC SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS
(SEMI-COUPLINGS AND COUPLING HEADS)**












| DESCRIPTION | SYMBOL | |
|---------------------|---|--|
| "ISO" SEMICOUPLING |  <p>ISO VERSION</p> | |
| "ISO" SEMICOUPLING |  <p>ISO JOINT VERSION</p> | |
| "CUNA" SEMICOUPLING |  <p>ITALY VERSION</p> | |
| "CUNA" SEMICOUPLING |  | |
| "NATO" SEMICOUPLING |  <p>NATO VERSION</p> | |















**GRAPHIC SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS
(SEMI-COUPPLINGS AND COUPLING HEADS)**

| DESCRIPTION | SYMBOL | |
|---------------|--|---|
| SEMI-COUPLING |  <p>VERSION WITH SINGLE DUCT</p> |  |
| SEMI-COUPLING |  <p>VERSION WITH SINGLE DUCT</p> |  |
| SEMI-COUPLING |  <p>VERSION WITH SINGLE DUCT</p> |  |
| SEMI-COUPLING |  <p>VERSION WITH SINGLE DUCT</p> |  |

**GRAPHIC SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS
(INDICATORS AND SWITCHES)**

| DESCRIPTION | SYMBOL | |
|----------------------------|---|---|
| PRESSURE GAUGE |  | |
| PRESSURE GAUGE |  | |
| PRESSURE TRANSMITTER |  | |
| LAMP |  | |
| MECHANICAL OPERATED SWITCH |  | |
| PRESSURE SWITCH |  | |
| LOW PRESSURE SWITCH |  |  |
| AUDIBLE WARNING |  | |
| SENSOR |  |  |

GRAPHIC SYMBOLS FOR AIR/HYDRAULIC SYSTEM CIRCUIT DIAGRAMS (BRAKES)

| DESCRIPTION | SYMBOL | |
|---|---|---|
| SINGLE CYLINDER HYDRAULIC BRAKE |  |  |
| TWIN CYLINDER HYDRAULIC BRAKE |  |  |
| DUAL SERVO HYDRAULIC BRAKE |  |  |
| DUAL SERVO HYDRAULIC BRAKE WITH PARKING BRAKE |  |  |
| SINGLE CAM OPERATED BRAKE |  |  |
| TWIN DUAL CAM OPERATED BRAKE |  |  |

799512 PIPES AND COUPLINGS


General

The pipes in the braking systems of commercial vehicles are currently of two types:

- ❑ flexible nylon hose with single or two-ply structure and in the following diameters 6-8-10-12-16 mm supplied as spares in metre lengths;
- ❑ rigid metal pipes of the following diameters: 4.75-6.35-8-10-12 mm. Pipes from Ø 4.75 to Ø 10 mm are supplied as spares in straight lengths of 4, 5 and 6 m, while those which are over 10 mm diam. are supplied as spares ready cut, bent and flared.

Re-flanging rigid pipes

Figure 1




31971

TYPES OF RE-FLANGING OF RIGID PIPES

A type re-flanging


Figure 2



31972

Position of press 99386523 (3) the blocks (1) so that the stamped numbers indicating the diameter of the pipes to be worked are facing towards the die (2). The choice of the matrix die (2) depends on the diameter of the pipe to be re-flanged. Additionally, the diameter of the pipe that can be re-flanged is stamped on the matrix die.


Figure 3



31973

Deburr pipe (1), insert union fitting (2) on this and position it between blocks (3) bearing against pin (5). Lock pipe (1) with screw (4).

Figure 4




31974

Move pin (4) to neutral position. Tighten screw (1) until matrix die (2) comes up against blocks (3), thus forming the end of the pipe (5).

B type re-flanging

Figure 5




31975

Fix matrix die (2) to press 99386523 (1). For re-flanging follow the instructions given above for A type re-flanging.

C type re-flanging


Figure 6



31976

Fit nut (2) and ring (3) over the pipe (1).

Figure 7




31977

Fit union fitting (2) and tighten so that ring (3, Figure 6) is locked over the pipe (1).

Bending rigid pipes


Figure 8



31978

Fit tool (1) 99386523 and select components (2) and (3) according to the diameter of the pipe to be bent.


Figure 9



31979

Position pipe (1) in tool (3) and bend the pipe by acting on lever (2).

Figure 10




31980

To remove the pipe (2) from the tool (3) use lever (1).

Cutting rigid pipes

Figure 11



31981

Position pipe (2) in tool (3) 99386523 and tighten screw (1). By holding the pipe (2) still, rotate the tool (3) until the pipe has been completely cut.


After having cut the pipe, deburr and shape the ends as described previously.

NOTE By turning tool (3) around the pipe (2), screw (1) becomes loose. To completely cut the pipe, you must tighten the screw (1) as soon as it becomes loose.

Replacing flexible hoses with threaded couplings

Carefully follow the instructions below:

Figure 12




- only use type approved hoses;
- check the condition of the new hose, that must be free from cracks, cuts or scores;
- cut the hose at 90°, with respect the to axis, to the required length by means of pipe-cutter pliers 99387050;

Fit the following in the specified order over the hose:

- nut (3), pressure ring (2) (the thickest part should be facing the nut (3)) and the reinforcement bush (1);
- the bush must be in perfect condition (it must be free from deformation or hammer dents).

Figure 13



ASSEMBLY OF REINFORCEMENT BUSH
 A = CORRECT ASSEMBLY
 B = INCORRECT ASSEMBLY

- Fit the reinforcement bush with tool 99372219 ensuring contact between its flange and end of the hose.
- Make sure that the end of the hose penetrates into the rake throat of the flange.


- Re-flange the support ring when fitted on the vehicle or at the test bench on a union fitting.
- The pressure and the final distance of the pressure ring front edge from the reinforcement bush should be in accordance with those shown in the table below.

NOTE When the hose is incorrectly fitted, do not reuse the hose once the bush and support ring have been removed.

| | Hose mm | Distance between bush edge and ring edge mm (*) | Fitting pressure (N/mm ²) |
|--------------|-----------|---|---------------------------------------|
| Twin-layer | 6 x 1 | da 1 a 1.5 | 0.040 |
| | 8 x 1 | da 2 a 2.5 | 0.050 |
| Single layer | 10 x 1.5 | da 2 a 2.5 | 0.050 |
| | 12 x 1.6 | da 2 a 2.5 | 0.060 |
| | 16 x 2.34 | da 3 a 3.5 | 0.060 |

(*) See reference h, Figure 14.

Figure 14



1. Reinforcement bush - 2. Pressure ring - 3. Nut - 4. Union fitting - 5. Hose - h. Distance between bush edge and ring edge (see table)


Introduce the end of the prepared hose into the union fitting until the reinforcement bush flange rests in the appropriate seat:

- to lock the nut on the union fitting, tighten this up by hand and then by means of a box wrench and dynamometric wrench; this must be tightened up to the required driving torque.

When fitting the hose to the vehicle, some important points should be borne in mind:


- bends must comply with minimum radii, so as to avoid constrictions;

| Diameter of pipe mm | Minimum radius of curvature mm |
|---------------------|--------------------------------|
| 6 x 1 | ~ 40 |
| 8 x 1 | ~ 50 |
| 10 x 1.5 | ~ 60 |
| 12 x 1.6 | ~ 75 |
| 16 x 2.34 | ~ 100 |

 Make sure that the hoses are not in contact with sharp edges or with sharp metal parts or sources of heat, but are at a minimum safe distance of 15mm from these.


- when hoses run through chassis members or metal parts, make sure that the holes through which they pass are fitted with rubber grommets, and that these are in good condition;
- avoid sliding the hose along sharp edges which might cause cuts;
- when the hose has to be attached to existing pipe work, take into account of the additional heat to which it may be subjected (power steering pipe work). In this case the hose must be protected with shields;
- when the hose has been connected, check that it is not under tension between the attachment points, instead leaving it slightly slack to take up the more substantial variations in temperature, especially for short lengths;
- before fitting, thoroughly clean the hoses by blowing compressed air through them to safeguard operation of the system.

Figure 15



13132

- Protect the hoses if grinding or welding operations are carried out on the vehicle; a notice is fitted in the cabin indicating the precautions to be observed to avoid damage.


 For greater safety and convenience in working, it is advisable to remove the hoses during these operations.

When fitting is finished, check that all seals (unions, couplings, etc.) are completely free from leaks.

Replacing flexible hoses with quick release couplings

Swivel couplings:

Figure 16




39306

screw the coupling into the threaded seating provided on the air valve, and tighten it to the driving torque indicated in the table.

Banjo couplings:

Figure 17




39307

- check that the seal ring (1) is in its seal;
- tighten the coupling until the seal gasket is in contact with the valve;
- direct the valve correctly and, by keeping the moveable part still, lock the hexagonal nut to the driving torque indicated in the table.

Swivel and banjo couplings:

| COUPLING THREAD | DRIVING TORQUE (Nm + 10%) |
|-----------------|---------------------------|
| M 10 x 1.0 mm | 22 |
| M 12 x 1.5 mm | 24 |
| M 14 x 1.5 mm | 28 |
| M 16 x 1.5 mm | 35 |
| M 22 x 1.5 mm | 40 |


Figure 18



33977

- only use type approved hoses;
- check the condition of the new hose, that must be free from cracks, cuts or scores;
- cut the hose at 90°, maximum error 15°, with reference to the axis. Use pipe-cutter pliers 99387050 to cut to the required length;

Figure 19



33976


A = Mark to identify end of tube travel

- use indelible ink to clearly mark two reference notches on both diametrically opposite faces of the pipe at an angle of $\geq 75^\circ$, set to distances L_1 and L_2 , to ensure correct fitting in place.

NOTE L_1 and L_2 vary according to the diameter of the hose and are to be measured at the longer part of the hose (see Figure 18).

| D (mm) | L ⁰ _{+0,5} (mm) | L ₁ ^{-0,5} ₊₁ (mm) | L ₂ ^{-0,5} ₊₁ (mm) |
|-----------|--|--|--|
| 6 | 19.8 | 17 | 22 |
| 8 | 20.5 | 18 | 23 |
| 12 | 25 | 22 | 28 |
| 16 | 27.1 | 24 | 30 |


Figure 20



39308

- Insert the hose (2) by hand into the coupling (1), with a force between 30 and 120 N according to the diameter of the hose, so that reference mark L_1 is inside the hose while mark L_2 remains visible.

Figure 21



33978

When removing couplings (1) on pneumatic components, check the condition of the seal ring (2) and, if necessary, replace.

| COUPLING THREAD | SEAL RING DIMENSIONS |
|-----------------|----------------------|
| M 10 x 1.0 | 10.1 x 1.6 |
| M 12 x 1.5 | 11.0 x 2.0 |
| M 14 x 1.5 | - |
| M 16 x 1.5 | 15.0 x 2.0 |
| M 22 x 1.5 | - |



Whenever a hose is removed from a quick release coupling, the coupling itself must be replaced. Spare quick release couplings are supplied complete.




Quick release and threaded couplings are not interchangeable. This also applies to flexible hoses used with quick release couplings and flexible hoses used with threaded couplings.

BRAKING SYSTEM

Outline diagram for vehicles 29L - 35S

Figure 22




52378

1. Pressure reducer - 2. Vacuum tank (2 litres) - 3. Servo brake - 4. Hydraulic pressure test point - 5. Dual mechanical operated load proportioning valve (for vehicles with mechanical suspensions) - 6. Parking brake lever - 7. Rear brake caliper - 8. Rear brake disc - 9. Dual pneumatic operated load proportioning valve (for vehicles with pneumatic suspensions) - 10. Front brake disc - 11. Front brake caliper - A. From pneumatic suspension circuit.

Outline diagram for vehicles 35C - 40C - 45C - 50C - 60C - 65C


Figure 23



1. Pressure reducer - 2. Vacuum tank (2 litres for 35C, 40C vehicles, 5 litres for 45C / 50C / 60C / 65C vehicles) -
 3. Servo brake - 4. Hydraulic pressure test point - 5. Dual mechanical operated load proportioning valve (for vehicles with mechanical suspensions) - 6. Parking brake lever - 7. Rear brake caliper - 8. Rear brake disc - 9. Parking drum brake - 10. Dual pneumatic operated load proportioning valve (for vehicles with pneumatic suspensions) - 11. Front disc brake - 12. Front brake caliper - A. From the pneumatic suspension circuit.

Outline diagram for vehicles 29L - 35S with ABS

Figure 24




74938

1. Electro-hydraulic modulator - 2. Vacuum pump - 3. Vacuum tank - 4. Servo brake - 5. Hydraulic pressure test point -
 6. Parking brake lever - 7. Rear brake caliper - 8. Rear brake disc - 9. Electronic control unit -
 10. Wheel revolutions sensor - 11. Phonic wheel - 12. Front brake disc - 13. Front brake caliper.

Outline diagram for vehicles 35C - 40C - 45C - 50C - 60C - 65C with ABS

Figure 25




102103

1 Electro-hydraulic modulator - 2. Vacuum pump - 3. Vacuum tank - 4. Servo brake - 5. Hydraulic pressure test point - 6. Parking brake lever - 7. Parking drum brake - 8. Rear brake disc - 9. Rear brake caliper - 10. Electronic control unit - 11. Wheel revolutions sensor - 12. Phonic wheel - 13. Front brake disc - 14. Front brake caliper.

* For vehicles equipped with the ABS 8 system, connections "F" and "R" shall become "MCI" and "MC2", respectively.

Outline diagram for vehicles 29L - 35S with ESP

Figure 25/1




102104

1. Electro-hydraulic modulator - 2. Vacuum pump - 3. Vacuum tank - 4. Servo brake - 5. Hydraulic pressure test point - 6. Parking brake lever - 7. Rear brake caliper - 8. Rear brake disc - 9. Yaw sensor - 10. Longitudinal acceleration sensor - 11. Electronic control unit - 12. Wheel revolutions sensor - 13. Phonic wheel - 14. Front brake disc - 15. Front brake caliper - 16. Steering angle sensor

Outline diagram for vehicles 35C with ESP

Figure 25/2




102105

- 1 Electro-hydraulic modulator - 2. Vacuum pump - 3. Vacuum tank - 4. Servo brake - 5. Hydraulic pressure test point - 6. Parking brake lever - 7. Parking drum brake - 8. Yaw sensor - 9. Longitudinal acceleration sensor - 10. Rear brake disc - 11. Rear brake caliper - 12. Electronic control unit - 13. Wheel revolutions sensor - 14. Phonic wheel - 15. Front brake disc - 16. Front brake caliper. - 17. Steering angle sensor

Braking system main components layout

Vehicles 29L - 35S

Figure 26




52382

- 1. Servo brake - 2. Front brake caliper - 3. Front brake disc - 4. Vacuum pump - 5. Vacuum tank - 6. Pressure test points - 7. Brake-force corrector - 8. Rear brake disc - 9. Rear brake caliper.

Vehicles 35C - 40C - 45C - 50C - 60C - 65C

Figure 27



52383


1. Servo brake - 2. Front brake caliper - 3. Front brake disc - 4. Vacuum pump - 5. Vacuum pump - 6. Pressure test point - 7. Proportional load valve - 8. Rear brake disc - 9. Rear brake caliper

Location of the main brake system components on vehicles with ABS

Vehicles 29L - 35S

102106


Figure 28



- 1. Vacuum brake - 2. Electrohydraulic modulator - 3. Front brake disk - 4. Phonic wheel - 5. Wheel revs sensor - 6. Vacuum device - 7. Vacuum chamber - 8. Electronic control unit - 9. Front brake caliper - 10. Hydraulic pressure check sockets - 11. Rear brake disk - 12. Rear brake caliper - 13. Brake lights indicator switch (on vehicles with EDC there are two switches), inform the ABS - EDC control unit that the vehicle is braking - 14. Hydraulic accumulator - 15. Electrohydraulic modulator - 16. Electronic control unit. - A. Fitting the electro-hydraulic modulator/control unit for ABS 8 systems.

Vehicles 35C - 40C - 45C - 50C - 60C - 65C

Figure 29




- 1. Vacuum brake - 2. Electrohydraulic modulator - 3. Front brake disk - 4. Phonic wheel - 5. Wheel revs sensor - 6. Vacuum device - 7. Vacuum chamber - 8. Electronic control unit - 9. Front brake caliper - 10. Hydraulic pressure check sockets - 11. Rear brake disk - 12. Rear brake caliper - 13. Brake lights indicator switch (on vehicles with EDC there are two switches), inform the ABS - EDC control unit that the vehicle is braking - 14. Hydraulic accumulator - 15. Electrohydraulic modulator - 16. Electronic control unit. - A. Fitting the electro-hydraulic modulator/control unit for ABS 8 systems.

Location of the main brake system components on vehicles with ESP

Vehicles < 3,5 ton.

Figure 29/1



102107

1. Acceleration sensor - 2. Yaw sensor - 3. Steering angle sensor - 4. Electro-hydraulic modulator/control unit

DESCRIPTION

Service brake

The service brake is of the pedal type with two independent hydraulic circuits. Both circuits are served from the vacuum-type servo brake.

The load proportioning valve is inserted in the hydraulic circuit of the rear brakes so as to compensate the braking action of the rear wheels as a function of the load being carried.

By means of a servo brake the pedal acts on the twin section master cylinder that puts the brake liquid under pressure.

Movement of the pistons in the caliper casing, as a consequence of the hydraulic pressure, causes the brake linings to be compressed on both surfaces of the brake disc and therefore brings the vehicle to a standstill.

Emergency brake

Incorporated in the service brake, the twin circuit system allows a single axle to brake even when the other brake is faulty, by acting on the service brake pedal.

Parking brake

Mechanical design consisting of a hand lever and associated linkages and wires that act on the rear wheel bakes.

BRAKES

Front and Rear disc brakes

- Front BREMBO 2x42 - 2x44 (model 29L - 35S);
- Front BREMBO 2x44 (model 35C - 40C - 45C - 50C);
- Front BREMBO 2x52 (model 60C - 65C);
- Rear BREMBO 1x52 (model 29L - 35S);
- Rear BREMBO 2x44 (model 35C - 40C - 45C - 50C).
- Rear BREMBO 2x46 (model 60C - 65C).

An electric wire is embedded in the brake linings which is connected to a tell-tale light on the driving panel to indicate the lining wear.

FAULT DIAGNOSIS

SECTION I

Faults affecting the ABS/ESP systems can be found by means of the Modus, E.A.SY. and IT 2000 diagnosis instruments.

These instruments are necessary to perform exhaustive diagnosis and take appropriate measures as regards every single fault.

Each single instrument displays the diagnosis and repair help.

Diagnosis Instruments

MODUS (Maintenance and Diagnostic System)

A computerized fault-diagnosis station dedicated to diagnosing the brake systems, air suspensions, engines and systems controlled electronically.

The station is equipped with auxiliary functions, such as: programming electronic control units, consulting the spare parts catalogue and service time schedules.

The vehicle has a 30-pin diagnosis socket to interface with the instrument.

E.A.SY. (Electronic Advance System)

The E.A.SY. system allows you to easily diagnose and program the various electronic control units fitted to the vehicle. It is made up of an ECI module for communication with the electronic control units and a Panasonic PC.

The ECI module allows you, by taking advantage of the Panasonic PC, to easily carry out work on the road; in particular, diagnostic work can be assisted by a specialized remote centre, thanks to the wireless technology incorporated into the Panasonic PC (e.g. GPRS).

IT 2000 (IVECO Electronic Tester)

This makes it possible to take immediate action on the vehicle, identifying it with the chassis number.

It saves the results of diagnostics actions performed.

It can be used as a portable Personal Computer, too, being fitted for remote diagnosis.

By using MODUS as the mother station it is possible to update and configure the IT 2000.


IT 2000 interfaces with the vehicle via a 30-pin diagnosis socket.

SECTION 2


Main operating faults in the brake system:

- 1 - Rear axle service brake is inefficient or irregular
- 2 - Front axle service brake is inefficient or irregular
- 3 - Inefficient or no parking brake


- 4 - Delayed action of parking brake
- 5 - Vehicle skids when braking
- 6 - Rapid brake lining wear
- 7 - Too long or abnormal travel of brake pedal
- 8 - Noisy brakes




(Continue)




2 FRONT AXLE SERVICE BRAKE IS INEFFICIENT OR IRREGULAR



(Continue)



4 DELAYED ACTION OF PARKING BRAKE



Tie-rods are faulty.

- YES →

Overhaul tie-rods and replace any worn parts.

NO



Shoe return springs are faulty.

- YES →

Replace shoe return springs.

NO



Rear calipers are faulty (calipers 1x52).

- YES →

Overhaul calipers and replace any worn parts.

NO




Parking drum brake is faulty (2x44 calipers).

- YES →

Adjust or overhaul the parking drum brake and replace any worn parts.

5 VEHICLE SKIDS WHEN BRAKING



Leaks or breakage in hydraulic system pipes.

- YES →

Tighten or replace loose or damaged fittings. Replace broken or damaged pipes.

NO





Load proportioning valve is faulty (vehicles without ABS).


- YES →

Adjust and, if necessary, replace load proportioning valve.

(Continue)







TIGHTENING TORQUES

| COMPONENT | TORQUE | |
|--|---------------|-------------|
| | Nm | kgm |
| Screw securing cover and brake disc to wheel hub (Front axle 5818 - 5823) | 98.1 ÷ 107.9 | 9.8 ÷ 10.7 |
| Screw securing brake disc to wheel hub (Front axle 5817) | 19.5 ÷ 24 | 1.9 ÷ 2.4 |
| Screws to fasten wheel (Front axle 5817 - Rear axle 450210) | 160 | 16 |
| Screws to fasten wheel (Front axle 5818) | 284 ÷ 342 | 28.4 ÷ 34.2 |
| Screws to fasten brake caliper support to stub axle (Axle 5818 - 5817) | 176 ÷ 217 | 17.6 ÷ 21.7 |
| Screws to fasten cover to stub axle (Front axle 5818 - 5817 - 5823) | 6 ÷ 7.5 | 0.6 ÷ 0.7 |
| Ring nut securing brake disc to wheel hub (Front axle 5817 - 5823) | 256 ÷ 314 | 25.6 ÷ 31.4 |
| Ring nut securing wheel hub (Front axle 5818 - 5819) | 257 ÷ 314 | 25.7 ÷ 31.4 |
| Screw securing ring nut (Front axle 5818 - 5819 - 5823) | 20 ÷ 24 | 2 ÷ 2.4 |
| Screw securing caliper to caliper mounting (Front axle 5818 - 5819 - 5823) | 176 ÷ 217 | 17.6 ÷ 21.7 |
| Nut securing wheel (Rear axle 450311/1 - 450511) | 290 ÷ 349 | 29 ÷ 34.9 |
| Screw securing disc and drive shaft (Rear axle 450210) | 13 ÷ 21 | 1.3 ÷ 2.1 |
| Screw securing drive shaft to wheel hub (Rear axle 450311/1 - 450511) | 63 ÷ 76 | 6.3 ÷ 7.6 |
| Screw securing brake caliper (Rear axle 450210) | 176 ÷ 217 | 17.6 ÷ 21.7 |
| Ring nut retaining wheel hub bearing (Rear axle 450311/1 - 450511) | 618 ÷ 667 | 61.8 ÷ 66.7 |
| Screws securing brake disc to wheel hub (Rear axle 450311/1 - 450511) | 69 ÷ 76 | 6.9 ÷ 7.6 |
| Screws securing caliper mounting to shoe mounting (Rear axle 450311/1 - 450511) | 180 ÷ 220 | 18 ÷ 22 |
| Fixing stud to brake disc (spread IVECO 1905683 sealant on the thread) (Front axle 5818 - 5819) | 85 ÷ 104 | 8.5 ÷ 10.4 |
| Screw to fasten brake caliper support to stub axle (Front axle 5819) | 154 ÷ 170 | 15.4 ÷ 17 |
| Screw securing plate and brake disc to wheel hub (Front axle 5819) | 94 ÷ 115 | 9.4 ÷ 11.5 |
| Nut securing wheel (Front axle 5819 - 5823 - Rear axle 450517/2) | 284.5 ÷ 343.3 | 28.5 ÷ 34.3 |
| Screw to fasten cover and sheet metal guard to rear axle box (Rear axle 450210) | 81 ÷ 100 | 8.1 ÷ 10 |
| Screw to fasten cover and sheet metal guard (Rear axle 450210) | 10 ÷ 16 | 1 ÷ 1.6 |
| Ring nut securing drive shaft (Rear axle 450210) | 300 ÷ 350 | 30 ÷ 35 |
| Screw securing shoe mounting to rear axle box (Rear axle 450311/1 - 450511) | 85 ÷ 97 | 8.5 ÷ 9.7 |
| Screws securing sheet metal guard (Rear axle 450311/1 - 450511) | 8 | 0.8 |
| Screw securing caliper to caliper mounting (Front axle 5817) | 176 ÷ 217 | 17.6 ÷ 21.7 |
| Sensor support retaining screw (Rear axle 450311/1 - 450511 - 450517/2) | 5 ÷ 7 | 0.5 ÷ 0.7 |

TIGHTENING TORQUES

| COMPONENT | TORQUE | |
|---|-----------|-------------|
| | Nm | kgm |
| Screw securing brake disc to wheel hub (Front axle 5823) | 98 ÷ 108 | 9.8 ÷ 10.8 |
| Screws to fasten brake caliper support to stub axle (Axle 5823) | 176 ÷ 217 | 17.6 ÷ 21.7 |
| Ring nut securing wheel hub (Front axle 5823) | 363 ÷ 441 | 36.3 ÷ 44.1 |
| Screw securing drive shaft to wheel hub (Rear axle 450517/2) | 56 ÷ 69 | 5.6 ÷ 6.9 |
| Screw securing brake caliper (Rear axle 450517/2) | 150 ÷ 177 | 15 ÷ 17.7 |
| Ring nut retaining wheel hub bearing (Rear axle 450517/2) | 441 ÷ 540 | 44.1 ÷ 54 |
| Screws securing brake disc to wheel hub (Rear axle 450517/2) | 54 ÷ 59 | 5.4 ÷ 5.9 |
| Fixing stud to brake disc (spread IVECO 1905683 sealant on the thread) (Front axle 5823) | 52 ÷ 64 | 5.2 ÷ 6.4 |
| Screw securing shoe mounting to rear axle box (Rear axle 450517/2) | 70 | 7 |
| Brake shoe/axle casing retaining screw (Rear axle 450517/2) | 52 ÷ 57 | 5.2 ÷ 5.7 |
| Calliper guide bushing socket head screw | 28 ÷ 32 | 2.8 ÷ 3.2 |

TOOLS

| TOOL NO. | DESCRIPTION |
|-----------------|---|
| 99301005 | Brake disc assembly |
| 99306010 | Appliance to bleed air from brake and clutch systems |
| 99321024 | Hydraulic trolley for removing/refitting wheels |
| 99355087 | Wrench (65 mm) for wheel hub nut (450311/1 - 450511) |
| 99355176 | Wrench for ring nut retaining drive shaft bearing (rear axle 450210) |
| 99357080 | Spanner (91.5 mm) for adjusting wheel hub bearings nut (Rear axle 450517/2) |

| TOOL NO. | DESCRIPTION |
|-----------------|---|
| 99370241 | Tool for mounting drive shaft bearing (rear axle 450210). |
| 99370496 | Guide for mounting wheel hub (front axle 5819 - 5818) |
| 99370497 | Guide for mounting wheel hub (rear axle 450311/1 - 450511) |
| 99370498 | Tool for driving bearing and phonic wheel onto wheel hub (rear axles 450311/1 - 450511) |
| 99370713 | Guide for mounting wheel hub (front axle 5823) |
| 99372236 | Tool to retract brake caliper piston (rear axle 450210) |

| TOOL NO. | DESCRIPTION |
|-----------------|---|
| 99372249 | Parking brake shoes adjusting tool |
| 99372269 | Pair of gauges to check pressure and to adjust hydraulic brakeforce distributor |
| 99374132 | Tool for fitting wheel hub internal seal (use with 99370006) (Axle 450517/2) |
| 99386523 | Flanging tool for brake system pipes |
| 99389819 | Torque wrench (0 ÷ 10 Nm) with square 1/4" connection. |

SPECIFICATIONS AND DATA - HYDRAULIC SYSTEM**DESIGNATION****Vacuum pump**

| | | | |
|---|--|---------|--------|
| <input type="checkbox"/> BOSCH D.151-B (8140 engines) - BOSCH ES F009 D00 165 (FIA engines) - BOSCH ES F009 D00 886 (FIC engines) | Emptying time (4.5 litre tank) at a pressure of: | 0.5 bar | 4.5 S |
| | | 0.8 bar | 12.5 S |

Vacuum servo brake

| | | |
|---|---|----------------|
| <input type="checkbox"/> Type 11": BOSCH 0204051186 (tip: 157 mm) - 0204051187 (tip: 180 mm) (combi vehicles) | Pneumatic cylinder diameter | 279.4 mm |
| | Hydraulic (or master) cylinder diameter | 23.81 mm |
| | Stroke | 21 + 21 mm |
| <input type="checkbox"/> BOSCH 136.895 (single-chamber) | Pneumatic cylinder diameter | 279.4 mm |
| | Hydraulic (or master) cylinder diameter | 25.4 mm |
| | Stroke | 20.5 + 20.5 mm |
| <input type="checkbox"/> Type 11": BOSCH 136.761 (single-chamber) | Pneumatic cylinder diameter | 288.9 mm |
| | Hydraulic (or master) cylinder diameter | 25.4 mm |
| | Stroke | 21 + 21 mm |
| <input type="checkbox"/> Type 10" T: BOSCH 0204021854 (dual) | Pneumatic cylinder diameter | 279.4 mm |
| | Hydraulic (or master) cylinder diameter | 26.99 mm |
| | Stroke | 20.5 + 20.5 mm |
| <input type="checkbox"/> Type 10" T: BOSCH 0204021934 (dual) | Pneumatic cylinder diameter | 254 mm |
| | Hydraulic (or master) cylinder diameter | 28.57 mm |
| | Stroke | 23.5 + 17.5 mm |

Pneumatic operated load proportioning valve

| | | |
|--|-------|------|
| <input type="checkbox"/> BOSCH 26/08094 - BOSCH 796801 | Ratio | 0.25 |
| <input type="checkbox"/> BOSCH 796803 | Ratio | 0.15 |

Braking calibrator for pneumatic suspensions

| | | |
|---|-------|------|
| <input type="checkbox"/> BOSCH 0204031150 | Ratio | 0,25 |
|---|-------|------|

ABS 5.3 system electro-hydraulic modulator/control unit (*)











- BOSCH 0 265 219 442 (vehicles 65C)
- BOSCH 0 265 219 427 (vehicles 35C - 50C)
- BOSCH 0 265 220 501 (vehicles 29L - 35S)

















ABS8/ESP8 system electro-hydraulic modulator/control unit (*)

- BOSCH 0 265 231 451 (vehicles 29L - 35S; ABS8) - (PN IVECO spare parts 504075552 - EZ)
- BOSCH 0 265 234 131 (vehicles 29L - 35S; ESP8) - (PN IVECO spare parts 504065620 - EZ)
- BOSCH 0 265 231 453 (vehicles 35C - 50C; ABS8) - (PN IVECO spare parts 504075554 - EZ)
- BOSCH 0 265 231 455 (vehicles 60C - 65C; ABS8) - (PN IVECO spare parts 504075556 - EZ)
- BOSCH 0 265 234 133 (vehicles 35C; ESP8) - (PN IVECO spare parts 504075550 - EZ)






* The component shall be supplied filled with brake fluid for storing.

SPECIFICATIONS AND DATA - BRAKES

|  FRONT AXLE DISC BRAKES | | 5817 | 5818 | 5819 | 5823 |
|---|---|--|-------------|---------------------|------------------------|
|  | Brake caliper cylinders: - quantity - diameter | 2 42 44 | 2 44 | | 2 52 |
|  | Brake lining thickness: - normal - min. allowed | S mm S mm | 12 | 15 2.9 ÷ 3.4 (*) | |
|  | Disc brake diameter | Ø mm | 276±0.2 | 290±0.2 | 276±0.2 290±0.2 |
|  | Disc brake thickness: - normal - min. allowed | S mm S mm | | 22±0.2 19 | 22±0.2 26±0.1 |
| (*) Remaining thickness of friction material to have the light on (cutting cable) | | | | | |
|  AXLE WHEEL HUBS | | 5817 | 5818 | 5819 | 5823 |
|  | Type of front axle | | | | |
|  | Wheel hub bearings | UNIT-BEARING | | | |
|  | Wheel hub bearings end play | mm | - | - | 0.110 min 0.140 max |
|  | Wheel hub bearing axial clearance adjustment | Not adjustable Retaining nut torque | | | |

|  | REAR AXLE DISC BRAKES | 450210 | 450511 450311/1 450310 | 450517/2 | |
|---|--|---------------------------|--|--|---|
|  | Brake caliper cylinders: - quantity - diameter | 1 52 mm | 2 44 | 2 46 | |
|  | Brake lining thickness: - min. allowed | S mm | 15 2.9 ÷ 3.4 (*) | | |
|  | Disc brake diameter | mm | 276 ±0.2 | 289 ^{+0.2} ₋₀ | 306 ±0.2 |
|  | Disc brake thickness: - normal - min. allowed | S mm S mm | 16 ±0.1 13 | 22 ±0.1 19 | 22 ±0.1 19 |
| Parking drum brake | | | | | |
|  | Drum diameter: - Nominal | Ø mm | | 172 ^{+0.15} ₋₀ Max 173 mm | 190 ^{+0.15} ₋₀ Max 191 |
|  | Brake lining thickness: - Nominal - Min. allowed | S mm S ₁ mm | | 4.25 mm Min. 1.5 mm | 6.2 Min. 3.5 |
|  | Brake lining diameter: - Nominal | Ø mm | | 71.2 ÷ 171.5 | 189.2 ÷ 189.5 |
|  | Brake lining width | L mm | | ~42 | |
|  | Clearance between brake linings and drum | G mm | | 0.2 ÷ 0.5 | 0.3 ÷ 0.4 |
| (*) Remaining thickness of friction material to have the light on (cutting cable) | | | | | |
|  | AXLE WHEEL HUBS | 450210 | 450511 450311/1 | 450517/2 | |
|  | Wheel hub bearings | | UNIT-BEARING | | SET-RUGHT |
|  | Wheel hub bearings end play | mm | - | 0.16 | |
|  | Wheel hub bearings rolling torque | Nm kgm | - - | 0 ÷ 4 0 ÷ 0.4 | |
|  | Adjustment of wheel hub bearings end play | | Not adjustable Retaining nut torque | | |
|  | Rear axle oil Quantity | Litres | TUTELA W140/M-DA (SAE 85 W 140) | | |
| | | | 1.85 | 1.90 | 3 |

CHECKS

| Device | Designation | Checks |
|---|---------------------------------------|---|
|  | Pressure Reducer | <p>Connect a vacuum meter to the intake line.</p> <p>At full operation the pressure reduction must reach the value of $0.80 \div 0.85$ bar. If this value is not obtained, check if there are any leaks in the pressure piping and servo brake components.</p> <p>Check that the distance between the top of the rotor and cover (with unit fitted) is comprised in the range $0.07 \div 0.14$mm.</p> |
|  | Vacuum servo brake | <p>Check the functionality and that there are no leaks. With the vacuum meter fitted on the piping between the pressure reducer and servo brake with engine at full speed, check that the pressure reduction values are in the range $0.80 \div 0.85$ bar with the pedal both released and pressed fully down for a period of 1 minute of rotation of the engine.</p> |
| | Brake liquid compensation tank | <p>Check the level of the brake liquid and eventually top up with Tutela DOT SPECIAL to the specified level. Change the brake liquid once per year.</p> |
|  | Load proportioning valve | <p>Check that the values measured with special manometers, via the test points, correspond to those indicated on the self-adhesive plate applied to the inside of the vehicle.</p> |
|  | Disk brake caliper | <p>Check the condition of the brake linings; check for scratches on the discs and the efficiency of the pistons.</p> |
|  | Pipes and fittings | <p>Ensure that metal pipes are in perfect condition, with no dents or cracks. Also make sure that they are not near sharp edges of the body work or chassis that could damage them.</p> <p>Check that the rubber and cloth flexible hoses are not in contact with oil or mineral grease, or rubber solvents. Press hard on the brake pedal and check that the pipes are not blown, and check that there are no leaks.</p> <p>Check that all brackets fastening the pipes are securely fixed - loose fastenings cause vibrations that could give rise to breakage.</p> <p>Check that there are no leaks from fittings, otherwise tighten them fully, taking care when tightening not to cause irregular pipe torsion.</p> <p>In all the above cases the parts are to be replaced if there is a minimum of doubt as to their efficiency.</p> <p>Apart from their condition, it is recommended to replace hoses after considerable mileage, or after a period of long vehicle use. This will avoid sudden breakage due to age and fatigue.</p> |

Functional check of vacuum brake system


With the engine stopped, press the brake pedal a few times in order to annul the vacuum in the servo brake. Press the pedal once again and keep it pressed, in the brake position, by putting a certain pressure on it. Start the engine and check the pedal stroke:

- if the stroke of the pedal increases, this implies that the servo brake and pipes are satisfactory;
- if the pedal remains still, this implies that the outside has penetrated into the vacuum plant that is not perfectly sealed, or the servo brake is faulty.

BRAKING SYSTEM MAIN COMPONENTS

790530 Vacuum pump

Figure 30



32277

This is the component which generates a reduction in pressure for operation of the servo brake.


Diagnostics

The figure shows the version for vehicles with engine 8140. As regards the vehicles with engine F1A/F1C, the vacuum device is incorporated into the vacuum oil pump unit.

| TROUBLE | POSSIBLE CAUSES | CURE |
|------------------------|--|--|
| Oil leakage from cover | <p>Incorrect driving torque between power reducer and engine.</p> <p>Cover seal surface not completely flat.</p> <p>Broken seal between pump and engine.</p> | <p>Lock screws to correct driving torque indicated in appropriate table.</p> <p>Check the seal surfaces, replace any defective parts or place them on a flat surface.</p> <p>Replace seal.</p> |
| Poor efficiency | <p>Excessive backlash between the blades and sliding surfaces.</p> <p>Bad sealing of connecting pipes or uni-directional valve.</p> <p>Insufficient lubrication.</p> | <p>Replace blades, or the entire pressure reducer.</p> <p>Check the seal and eventually replace the connecting pipes or replace the uni-directional valve.</p> <p>Carefully clean the oil pipes.</p> |

794101 Vacuum servo brake

Figure 31



32279

This is a device which increases the force applied by the pedal and consists of two main components:


- a power reducer pneumatic section;
- an hydraulic section (master cylinder and brake liquid tank).

The servo brake is manufactured in such a way that in case the pneumatic section fails, the brakes can still work. In this case the braking action is obtained by one master cylinder.

784010 Bleeding air from the hydraulic circuit (vehicles not equipped with ABS)

Front brake circuit

Figure 32



One end of a transparent plastic pipe (2) should be fitted to the bleeder screw (1) with the end placed into a container (3) that has been partially filled with brake liquid.

Repeatedly press the brake pedal

By maintaining the brake pedal in the down position unscrew the bleeder screw (1) one full turn.

Tighten the bleeder screw, repeatedly press the brake pedal.


Repeat the above operation until the brake liquid comes out in a uniform manner.

Bleed off the air from the opposite brake assembly. Check that the level of brake liquid in the relevant tank is always sufficient.

This operation will allow the air in the hydraulic circuit liquid piping to be expelled.

Rear brake circuit

Figure 33



Disconnect the load proportioning valve control rod and lock it at the top so as to set the proportioning valve in the fully open position.

Bleed off the air from the hydraulic circuit as described for the front brake circuit.

Having terminated this operation connect the load proportioning valve control rod.




Finish bleeding-off air from the brake circuit, top up to the maximum level with Tutela DOT SPECIAL brake liquid.

784010 Bleeding air from the hydraulic circuit with deaerator device (vehicles not equipped with ABS)

Front brake circuit

Figure 34



As an alternative you can bleed-off air from the brake circuit with the deaerator device 99306010 by following the procedures below:

1. load the air tank (4);
2. fill the tank with brake liquid (5);
3. one end of a transparent plastic pipe (6) should be fitted to the bleeder screw with the end placed into a container that has been partially filled with brake liquid;
4. replace the brake liquid tank cover with one (7) taken from the box supplied with the deaerator;
5. insert the deaerator 99306010 pipe (1) on the cover of the brake liquid tank;
6. unscrew the bleeder screw one full turn, open the cock valve (3) until there is a reading of $1 \div 1.2$ bar on the manometer (2).

When the brake liquid comes out in a uniform manner from the circuit, close the bleeder screw and discharge air from the aerator tank (4). Repeat this operation for all wheels.

Air bleeding from the ABS/ESP system hydraulic circuit

The procedure must be performed with the engine stopped and the key turned to running (Key ON). Get connected to the diagnosis take-off located in the cabin, on the passenger's side, by means of a suitable instrument. Follow the "BLEEDING" procedure described by the instrument.

NOTE Press the brake pedal over and over again during the process. The correct blow-off sequence for the four wheels is as follows:

- rear left wheel (RL)
- front left wheel (FL)
- front right wheel (FR)
- rear right wheel (RR)

As regards the systems of the ABS 8/ESP 8 type, no other sequence is permitted. As far as ABS 5.3 systems are concerned, on the contrary, you may act on the single wheels without having to perform the entire procedure.


After every single wheel has been bled, visually inspect the brake fluid level and top up, if necessary. Do not fill with fluid that has already been used.

In the event that either one single phase or the entire blow-off process is repeated, you will have to wait at least 5 minutes in order to let the system solenoid valve cool. Otherwise, the valves themselves may be damaged due to overheating.


Prior to tightening the drain screws, make sure that the corresponding routine has been completed, and the brake fluid flows out smoothly (no air bubbles should appear).

In order to ensure correct bleeding, the vehicle is to be set in a proper way. You will have to clean the drain screws and procure a transparent tube and a container partially filled with brake fluid, to be connected to the screw of the wheel being bled.

ABS 5.3 system bleeding procedure sequence




NOTE After air bleeding from the braking circuit has been completed, fill with brake fluid up to the top level (do not fill with oil that has already been used).

ABS 8/ESP 8 system bleeding procedure sequence

NOTE After air bleeding from the braking circuit has been completed, fill with brake fluid up to the top level (do not fill with oil that has already been used).


784310 Mechanically controlled load sensing valve (vehicles 35C - 40C - 45C - 50C - 60C - 65C)

Figure 35



The load proportioning valve automatically adjusts, as a function of the load acting on the rear axle, the braking torque produced by the brakes of the axle itself. This valve has the important job, especially when the vehicle is light without any load, to limit the braking torque that would otherwise block the rear wheels with a consequent skidding and jerking of the vehicle.

Figure 36



A. Inlet pressure (Bar) - B. Outlet pressure (bar)
Ratio = 0.25

Regulation of load proportioning valve on vehicle

To stop the vehicle from skidding or the wheels from being locked when braking, you must check the device at regular intervals and eventually adjust if necessary. This consists in verifying the values indicated on the plate (Figure 37) applied on the inside of the bonnet.



If there is no plate or if the data is missing, ask the manufacturer for a duplicate by indicating:



- Vehicle type
- Number of leaf springs
- Vehicle pitch
- Weight of rear axle
- Number of load proportioning valve

Figure 37


| | | | | | | |
|------------|----------|----------|-------|-------|-----|---|
| T. ARCHET? | PR | TPO | 35 | | | |
| SCILLO | LUX | TYF | | | | |
| P. APT. | FOR | TYFF | | | | |
| P. B. NEAU | POUR | TYFE | | | | |
| P. A. CA | P. A. CA | T. A. C. | | | | |
| 100 bar | | | | | | CORRE LORE DI FREINATA RIFASCIATA TRG-FP LOAD SENSING VALVE CORRECTEUR DE FREINATA VALVULA REGULADORA |
| | | | | | | 0.25 |
| Kg | bar | bar | f= mm | f= mm | bar | |
| 1000 | | 28 | | 0 | | |
| 1100 | | 33 | | 8 | | |
| 1300 | | 41 | | 18 | | |
| 1500 | | 48 | | 29 | | |
| 1700 | | 56 | | 39 | | |
| 1900 | | 64 | | 49 | | |
| 2100 | | 71 | | 59 | | |
| 2300 | | 79 | | 70 | | |
| 2600 | | 90 | | 85 | | |
| 2900 | | 100 | | 100 | | |
| | | | | | | VALVOLA VENTIL/CARICO ACT/LEER VENTIL LOAD LIFTING VALV VALVE CHARGE/AIDE VALVULA EN CARGA/AJUDA |
| | | | | | | |
| | | | | | | VALVOLA POSTERIORE REAR SPRING REAR SPRING VALVOLA POSTERIORE REAR SPRING |
| | | | | | | 93815209 93809566 |
| 500348109 | | | | | | IVECO |

LOAD PROPORTIONING VALVE PLATE

The operations are to be carried out in the following order:

- set the vehicle with its rear wheel on a weighing machine 99336914 or on the brake test bench;
- connect the pressure gauges 99372269 or Modus to the pressure test points upstream from the load proportioning valve;
- if the pressure gauges are not equipped with a valve for automatic bleeding, bleed off the air through the pressure gauges by unscrewing the appropriate ring nuts;
- load the vehicle so as to have a load (B) on the rear axle divided equally between the right- and left-hand sides of the vehicle with a tolerance of ± 5 kg;


Figure 38




- loosen the nut (1);
- connect a weight (A, page 50) to the plate (5) at point (2);
- tighten the nut (1) at the specified torque and remove the loads (A and B).
- start up the engine;

- ❑ Load the vehicle to obtain the loading sequence shown in the table in fig. 37, equally shared on the rear axle on the left and right sides of the vehicle with a tolerance of ± 5 kg.

Figure 39



- ❑ with the engine idling and a pressure of 100 bar, shown on the pressure gauge (3) upstream from the sensing valve, check that the outlet pressure shown on the pressure gauge (2) downstream from the sensing valve corresponds to the values given on the rating plate, otherwise replace the sensing valve;
- ❑ Proceed as follows if the pressure read downstream of the corrector do not correspond to the values shown in Figure 37.
- ❑ Disconnect the bar (4, Figure 38) from the axle.
- ❑ in addition, use the transmission lever (3, Figure 38) to check that the load sensing valve stem runs smoothly in its seat, otherwise replace the sensing valve;
- ❑ reconnect the adjustment rod (4, Figure 38) to the rear axle;

 Perform the check by gradually increasing the pressure.

To check the load sensing valve, all the components of the braking system must be in full working order. In addition, in the case of replacing the leaf springs for special versions it is necessary to install a new rating plate whose values are correct.


- ❑ Once the checks have been completed, verify the operation of the brakes by testing them.

TABLE OF LOADS FOR ADJUSTING THE LOAD SENSING VALVE

| Model | Load (A) kg | Load (B) kg |
|---|----------------|----------------|
| 35C | 3.5 | 1500 |
| 40C | 3 | 1500 |
| 45C | 4 | 1800 |
| 50C semi-elliptic and double flex. parabolic leaf springs | 9 | 1800 |
| 50C single flex. parabolic leaf springs. | 4.5 | 1800 |


784310 Dual mechanically controlled load sensing valve (vehicles 29L - 35S)

Figure 40



The load sensing valve automatically regulates the braking torque generated by the brakes of the rear axle according to the load weighing on the rear axle. It has the important function, especially when the vehicle has no load, of limiting the braking torque that would lock the rear wheels causing the vehicle to skid.

Figure 41



A. Inlet pressure (in bar) - B. Outlet pressure (in bar)
Ratio = 0.15

Adjusting the load sensing valve



This adjustment is similar to that described above, using the following loads.

TABLE OF LOADS FOR ADJUSTING THE LOAD SENSING VALVE

| Model | Load (A) kg | Load (B) kg |
|-------|----------------|----------------|
| 29L | 9 | 1500 |
| 35S | 6,5 | 1500 |

STABILITY CONTROL AND ANTI-SKID DEVICES

The devices described below are integrated into three different types of systems:

- ABS 5.3 system, which integrates the *ABS/ABD* and *EBD* functions on vehicles equipped with F1A (no automatic transmission), F1C and 8140 engines.
- ABS 8 system, which integrates the *ABS* and *EBD* functions on vehicles equipped with F1A engine and 6 AS 300 VD automatic transmission.
- ESP8 system (OPTION), which includes the *ESP/ABS/EBD/ASR/MSR/HBA/HCC* functions on vans up to 3.5 t. with F1A/F1C engines.

ABS SYSTEM FUNCTIONS

Antilock braking system (ABS)

This system comprises an electro-hydraulic modulator and an electronic control unit mounted on the modulator, located in the engine bay, four sensors and four phonic wheels that measure the number of turns of the wheels.

The tendency for one or more wheels, whether front or rear, to lock, which is detected by the sensors through the pulses of the phonic wheels, is communicated to the electronic control unit that, by means of the electro-hydraulic modulator, independently or simultaneously regulates the pressure in the hydraulic circuit of the front and rear axles.

Electronic braking distribution device (EBD)

This system acts at a level prior to ABS operation. It ensures a sensitive control over the tendency of the rear wheels to lock with respect to the front ones, when braking, by optimizing the braking force in the different conditions of load, travel and state of use of the vehicle.

This device substitutes the function of the mechanically operated load sensing valve. If this device fails, braking takes place with the same pressure on front and rear brakes.

Anti-skid braking device (ABD)

This system acts by automatically braking the wheels that on starting tend to skid.

It operates with speeds up to 40 km/h.

NOTE This function is available in ABS 5.3 systems only.

Electronic Stability Program (ESP) - Option

It monitors the vehicle's behaviour steadily (both on straight stretches and bends, when braking or accelerating).

It also monitors the driver's actions: steering the wheel, pressing the brake pedal, accelerator position, speed.

It is always active in the background, i.e. the ESP system compares the actual vehicle ride with the driver's desired ride 50 times a second. It recognizes dangerous situations before the driver does.

The system considers the different possibilities of coming into operation. It brakes on every single wheel separately.

It operates on the engine control system.

FUNCTIONS INCLUDED IN THE ESP SYSTEM ONLY

Acceleration drive control device (ASR)

This system prevents driving wheel skid through quick action on the engine and brakes. It allows the vehicle to set off safely and fast even on slippery roads or when one driving wheel is skidding. It also reduces the risk of understeering when you accelerate too much when cornering.

Engine braking torque control (MSR)

This system avoids driving wheel drag due to the exhaust brake. It ensures vehicle stability when releasing on slippery roads (e.g. snow, ice), and assists in keeping the path when cornering and shifting down, especially on slippery roads. It requires a slight increase of revs number, through the CAN line.

Hill holder control (HHC)

This function allows the vehicle to be kept automatically locked (braked) until the clutch is closet and the driver subsequently presses the accelerator pedal, thus preventing undesired vehicle motion.

The function is actuated automatically: the braking situation is detected by the sensor inside the modulator. When the brake pedal is released, the vehicle will be kept braked for 2.5 seconds, thus allowing the driver/system to put the gear (and the vehicle to be started). This ensures safe, easy start with any incline, regardless of the weight carried.

Hydraulic Brake Assistant (HBA)

The main feature of the HBA function is to recognize an emergency braking situation followed by "automatic" increase of vehicle deceleration.

Vehicle deceleration is only restricted to actuation of ABS control, thus taking the greatest advantage of the grip between the tyre and the roadbed currently available. Therefore, ordinary drivers can now achieve braking distances which only experienced drivers could achieve in the past.

If the driver reduces the braking intensity, vehicle deceleration is reduced depending on the reduction of the force applied onto the pedal.


Therefore, the driver can control deceleration accurately after overcoming the emergency situation.

The extent of the braking request from the driver corresponds to the force applied onto the pedal. The force applied onto the pedal is derived from measuring the pressure in the brake pump.

526716 Electro-hydraulic modulator/control unit for 29L - 35S vehicles

ABS 5.3 systems

Figure 42



The electronic control unit has the task of controlling the electro-hydraulic modulator solenoid valves according to the signals from the wheel speed sensors. The electro-hydraulic modulator modulates the pressure of the brake fluid in both front and rear circuits according to the control signals from the control unit.


NOTE The devices comprising the control unit and electro-hydraulic modulator of the various models are not interchangeable.



The parts inside the hydraulic unit are not compatible with mineral oil and unsuitable fluids. In case of contamination by such fluids, the unit shall be replaced and properly disposed of.

ABS8/ESP8 systems

Figure 43




1. Hydraulic accumulator - 2. Electro-hydraulic modulator - 3. Electronic control unit - A. ABS8 connector - B. ESP8 connector - F/MCI. Front axle power supply - R/MC2. Rear axle power supply - LF (or FL for ABS8/ESP8 systems). Left front axle output - RR. Right rear axle output - RF (or FR for ABS8/ESP8 systems). Right front axle output - LR (or RL for ABS8/ESP8 systems) . Left rear axle output

526716 Electro-hydraulic modulator/control unit for 35C - 65C vehicles


ABS 5.3 systems

Figure 44




The electronic control unit has the task of controlling the electro-hydraulic modulator solenoid valves according to the signals from the wheel speed sensors. The electro-hydraulic modulator modulates the pressure of the brake fluid in both front and rear circuits according to the control signals from the control unit.

NOTE The devices comprising the control unit and electro-hydraulic modulator of the various models are not interchangeable.

 The parts inside the hydraulic unit are not compatible with mineral oil and unsuitable fluids. In case of contamination by such fluids, the unit shall be replaced and properly disposed of.

ABS8 systems (vehicles 35C - 65C) / ESP8 (vehicles 35C only)

Figure 45



1. Hydraulic accumulator - 2. Electro-hydraulic modulator - 3. Electronic control unit - A. ABS8 connector - B. ESP8 connector - F/MC1. Front axle power supply - R/MC2. Rear axle power supply - LF (or FL for ABS8/ESP8 systems). Left front axle output - RR. Right rear axle output - RF (or FR for ABS8/ESP8 systems). Right front axle output - LR (or RL for ABS8/ESP8 systems) . Left rear axle output

ABS 8/ESP 8 ELECTROHYDRAULIC MODULATOR DIAGRAMS

The next pages illustrate the connections of ABS 8/ESP 8 modulators and all their internal components in case of intervention of the functions integrated into the braking system.

As far as **ABS 8** systems are concerned, the functions described are as follows:

- ABS, pressure increase
- ABS, pressure decrease
- ABS, pressure maintenance
- EBD, electronic braking corrector

As far as **ESP8** systems are concerned, the functions described are as follows:

- ABS, pressure increase
- ABS, pressure decrease
- ABS, pressure maintenance
- EBD, electronic braking corrector
- ESP, electronic stability program
- MSR, engine braking torque control
- ASR, acceleration traction control device
- HHC, start assist on slopes
- HBA, emergency braking hydraulic assist

DIAGRAM COLOUR LEGEND

Black - high-pressure circuit


Dark grey - intermediate-pressure circuit

Light grey - low-pressure circuit

Hydraulic diagrams of ABS 8 modulator – 4-channel (X)

Pressure increase

Figure 46




1. Vacuum servobrake - 2. Scavenge pump control motor - 3. Scavenge pumps - 4. Low pressure accumulators - 5. Power supply solenoid valves - 6. Quick pressure decrease single-acting valves - 7. Discharge solenoid valves - 8. Electronic control unit - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor - DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor

102267

By pressing down the brake pedal, the oil under pressure can reach the brake calipers since power supply solenoid valves "5" are open.

Pressure decrease

Figura 46/1



102268


1. Vacuum servobrake - 2. Scavenge pump control motor - 3. Scavenge pumps - 4. Low pressure accumulators - 5. Power supply solenoid valves - 6. Quick pressure decrease single-acting valves - 7. Discharge solenoid valves - 8. Electronic control unit - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor - DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor

If the sensors find that the wheel(s) tends to get locked, they will inform the control unit: the latter will reduce the braking power by actuating power supply solenoid valves "5" and discharge solenoid valves "7".

At the same time, the excess oil in low pressure accumulators can be recovered by powering motor "2" which drives pumps "3".

Pressure maintenance

Figura 46/2




1. Vacuum servobrake - 2. Scavenge pump control motor - 3. Scavenge pumps - 4. Low pressure accumulators -
5. Power supply solenoid valves - 6. Quick pressure decrease single-acting valves - 7. Discharge solenoid valves -
8. Electronic control unit - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor - DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor

102269

When the optimum braking force has been obtained, the control unit will be able to keep such force steady by de-energizing discharge solenoid valves "7", motor "2" and its respective scavenge pumps "3", whereas power supply solenoid valves "5" will be powered on.

EBD Device intervention

Figura 46/3



1. Vacuum servobrake - 2. Scavenge pump control motor - 3. Scavenge pumps - 4. Low pressure accumulators - 5. Power supply solenoid valves - 6. Quick pressure decrease single-acting valves - 7. Discharge solenoid valves - 8. Electronic control unit - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor - DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor


Fp. Rear axle braking force - Fa. Front axle braking force - A. Servobrake distribution curve - B. Ideal distribution curve - C. Distribution curve of corrector (if any) - D. EBD system distribution curve

If the sensors find that one or both of the rear wheels tend to get locked compared with the front wheels, they will inform the control unit: the latter will, as a result, power rear axle power supply solenoid valve "5", so as to optimize the braking force. Any anomaly of some components of the system will cause the ABS system to be cut off (this condition will be displayed by the lighting of the respective warning light). Yet, the EBD system operation will be ensured. Simultaneous lighting of both failure warning lights (ABS and EBD) will indicate a fault in the EBD system; under these conditions, great care shall therefore be taken while driving, since braking will not be optimized.

Hydraulic diagrams of ABS 8 modulator – 3-channel (II)

Pressure increase

Figura 46/4




1. Vacuum servobrake - 2. Electronic control unit - 3. Scavenge pumps - 4. Scavenge pump control motor - 5. Low pressure accumulators - 6. Power supply solenoid valves - 7. Quick pressure decrease single-acting valves - 8. Discharge solenoid valves - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor - DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor

102271

By pressing down the brake pedal, the oil under pressure can reach the brake calipers since power supply solenoid valves "6" are open.

Pressure decrease

Figura 46/5



102272


1. Vacuum servobrake - 2. Electronic control unit - 3. Scavenge pumps - 4. Scavenge pump control motor - 5. Low pressure accumulators - 6. Power supply solenoid valves - 7. Quick pressure decrease single-acting valves - 8. Discharge solenoid valves - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor - DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor

If the sensors find that the wheel(s) tends to get locked, they will inform the control unit: the latter will reduce the braking power by actuating power supply solenoid valves "6" and discharge solenoid valves "8".

At the same time, the excess oil in low pressure accumulators "5" can be recovered by powering motor "4" which drives pumps "3".

Pressure maintenance

Figura 46/6




1. Vacuum servobrake - 2. Electronic control unit - 3. Scavenge pumps - 4. Scavenge pump control motor -
 5. Low pressure accumulators - 6. Power supply solenoid valves - 7. Quick pressure decrease single-acting valves -
 8. Discharge solenoid valves - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor -
 DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor

102273

When the optimum braking force has been obtained, the control unit will be able to keep such force steady by de-energizing discharge solenoid valves "8", motor "4" and its respective scavenge pumps "3", whereas power supply solenoid valves "6" will be powered on.

EBD Device intervention

Figura 46/7



102274

1. Vacuum servobrake - 2. Electronic control unit - 3. Scavenge pumps - 4. Scavenge pump control motor -
 5. Low pressure accumulators - 6. Power supply solenoid valves - 7. Quick pressure decrease single-acting valves -
 8. Discharge solenoid valves - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor -
 DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor


Fp. Rear axle braking force - Fa. Front axle braking force - A. Servobrake distribution curve -
 B. Ideal distribution curve - C. Distribution curve of corrector (if any) - D. EBD system distribution curve

If the sensors find that one or both of the rear wheels tend to get locked compared with the front wheels, they will inform the control unit: the latter will, as a result, power rear axle power supply solenoid valve "6", so as to optimize the braking force. Any anomaly of some components of the system will cause the ABS system to be cut off (this condition will be displayed by the lighting of the respective warning light). Yet, the EBD system operation will be ensured. Simultaneous lighting of both failure warning lights (ABS and EBD) will indicate a fault in the EBD system; under these conditions, great care shall therefore be taken while driving, since braking will not be optimized.

Hydraulic diagrams of ESP 8 modulator – 4-channel (X)

Pressure increase

Figura 46/8




1. Vacuum servobrake - 2. Yaw sensor - 3. Steering angle sensor - 4. Longitudinal acceleration sensor -
 5. EDC motor control unit - 6. ESP electronic control unit - 7. Intake solenoid valves - 8. Driving solenoid valves -
 9. Scavenge pump control motor - 10. Scavenge pumps - 11. Single-acting safety valves - 12. Low pressure accumulators -
 13. Quick pressure decrease single-acting valves - 14. Power supply solenoid valves - 15. Discharge solenoid valves -
 16. Pressure sensor - 17. Single-acting valves - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor -
 DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor

102275

By pressing down the brake pedal, the oil under pressure can reach the brake calipers since both driving solenoid valves "8" and power supply solenoid valves "14" are open.

Pressure decrease

Figura 46/9



102276


1. Vacuum servobrake - 2. Yaw sensor - 3. Steering angle sensor - 4. Longitudinal acceleration sensor - 5. EDC motor control unit - 6. ESP electronic control unit - 7. Intake solenoid valves - 8. Driving solenoid valves - 9. Scavenge pump control motor - 10. Scavenge pumps - 11. Single-acting safety valves - 12. Low pressure accumulators - 13. Quick pressure decrease single-acting valves - 14. Power supply solenoid valves - 15. Discharge solenoid valves - 16. Pressure sensor - 17. Single-acting valves - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor - DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor

If the sensors find that the wheel(s) tends to get locked, they will inform the control unit: the latter will reduce the braking power by actuating power supply solenoid valves "14" and discharge solenoid valves "15".

At the same time, the excess oil in low pressure accumulators "12" can be recovered by powering motor "9" which drives pumps "10".

Pressure maintenance

Figura 46/10




1. Vacuum servobrake - 2. Yaw sensor - 3. Steering angle sensor - 4. Longitudinal acceleration sensor -
 5. EDC motor control unit - 6. ESP electronic control unit - 7. Intake solenoid valves - 8. Driving solenoid valves -
 9. Scavenge pump control motor - 10. Scavenge pumps - 11. Single-acting safety valves - 12. Low pressure accumulators -
 13. Quick pressure decrease single-acting valves - 14. Power supply solenoid valves - 15. Discharge solenoid valves -
 16. Pressure sensor - 17. Single-acting valves - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor -
 DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor

When the optimum braking force has been obtained, the control unit will be able to keep such force steady by de-energizing discharge solenoid valves "15", motor "9" and its respective scavenge pumps "10", whereas power supply solenoid valves "14" will be powered on.

102277

EBD device intervention

Figura 46/11




1. Vacuum servobrake - 2. Yaw sensor - 3. Steering angle sensor - 4. Longitudinal acceleration sensor -
 5. EDC motor control unit - 6. ESP electronic control unit - 7. Intake solenoid valves - 8. Driving solenoid valves -
 9. Scavenge pump control motor - 10. Scavenge pumps - 11. Single-acting safety valves - 12. Low pressure accumulators -
 13. Quick pressure decrease single-acting valves - 14. Power supply solenoid valves - 15. Discharge solenoid valves -
 16. Pressure sensor - 17. Single-acting valves - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor -
 DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor

Fp. Rear axle braking force - Fa. Front axle braking force - A. Servobrake distribution curve -
 B. Ideal distribution curve - C. Distribution curve of corrector (if any) - D. EBD system distribution curve

If the sensors find that one or both of the rear wheels tend to get locked compared with the front wheels, they will inform the control unit: the latter will, as a result, power rear axle power supply solenoid valve "14", so as to optimize the braking force. Any anomaly of some components of the system will cause the ABS system to be cut off (this condition will be displayed by the lighting of the respective warning light). Yet, the EBD system operation will be ensured. Simultaneous lighting of both failure warning lights (ABS and EBD) will indicate a fault in the EBD system; under these conditions, great care shall therefore be taken while driving, since braking will not be optimized.

ESP device intervention

Figura 46/12




1. Vacuum servobrake - 2. Yaw sensor - 3. Steering angle sensor - 4. Longitudinal acceleration sensor - 5. EDC motor control unit - 6. ESP electronic control unit - 7. Intake solenoid valves - 8. Driving solenoid valves - 9. Scavenge pump control motor - 10. Scavenge pumps - 11. Single-acting safety valves - 12. Low pressure accumulators - 13. Quick pressure decrease single-acting valves - 14. Power supply solenoid valves - 15. Discharge solenoid valves - 16. Pressure sensor - 17. Single-acting valves - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor - DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor

102281

Control unit "6" can brake the single wheels to ensure vehicle stability under dangerous driving conditions. The signals from yaw sensor "2", steering angle sensor "3", and longitudinal acceleration sensor "4", as well as the speed signals and the accelerator pedal position, provide information that allows the system to come into operation under vehicle understeering or oversteering conditions. Intake solenoid valves "7" and driving solenoid valves "8" will be actuated. At the same time, motor "9" will be actuated, which controls pumps "10" so that the wheel(s) will be braked in order to correct the path. Thanks to the CAN line communication with EDC motor control unit "5", ESP control unit "6" will be able to act on engine control, too.

MSR device intervention

Figura 46/13




1. Vacuum servobrake - 2. Yaw sensor - 3. Steering angle sensor - 4. Longitudinal acceleration sensor - 5. EDC motor control unit - 6. ESP electronic control unit - 7. Intake solenoid valves - 8. Driving solenoid valves - 9. Scavenge pump control motor - 10. Scavenge pumps - 11. Single-acting safety valves - 12. Low pressure accumulators - 13. Quick pressure decrease single-acting valves - 14. Power supply solenoid valves - 15. Discharge solenoid valves - 16. Pressure sensor - 17. Single-acting valves - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor - DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor

If the sensors find that the driving wheels tend to drag due to the exhaust brake, control unit "6" will request a slight increase of engine revs through the CAN line. This device ensures stability when releasing the clutch pedal on slippery roads (e.g. snow, ice) and helps keep the path when taking a bend and shifting down, especially on slippery roads.

ASR device intervention

Figura 46/14



1. Vacuum servobrake - 2. Yaw sensor - 3. Steering angle sensor - 4. Longitudinal acceleration sensor - 5. EDC motor control unit - 6. ESP electronic control unit - 7. Intake solenoid valves - 8. Driving solenoid valves - 9. Scavenge pump control motor - 10. Scavenge pumps - 11. Single-acting safety valves - 12. Low pressure accumulators - 13. Quick pressure decrease single-acting valves - 14. Power supply solenoid valves - 15. Discharge solenoid valves - 16. Pressure sensor - 17. Single-acting valves - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor - DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor


102280

If the sensors find that one or both of the rear axle wheels tend to skid (at a speed of 6 to 10 k.p.h.), they will inform the control unit: the latter will power intake solenoid valves "7", driving solenoid valves "8", and power supply solenoid valves "14".

At the same time, the pressure to be conveyed to the brake calipers affected can be generated by powering motor "9" which drives pumps "10".

HBA device intervention

Figura 46/15



102282


1. Vacuum servobrake - 2. Yaw sensor - 3. Steering angle sensor - 4. Longitudinal acceleration sensor - 5. EDC motor control unit - 6. ESP electronic control unit - 7. Intake solenoid valves - 8. Driving solenoid valves - 9. Scavenge pump control motor - 10. Scavenge pumps - 11. Single-acting safety valves - 12. Low pressure accumulators - 13. Quick pressure decrease single-acting valves - 14. Power supply solenoid valves - 15. Discharge solenoid valves - 16. Pressure sensor - 17. Single-acting valves - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor - DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor

If the system recognizes, through pressure sensor "16", an emergency braking condition, i.e. it detects a pressure increase " $\Delta p / \Delta t$ " higher than normal braking, the control unit will power both intake solenoid valves "7" and driving solenoid valves "8".

At the same time, the pressure to be conveyed to the brake calipers affected can be generated by powering motor "9" which drives pumps "6". Pressure shall be such that further reduction of the braking distance will be ensured.

HHC device intervention

Figura 46/16



1. Vacuum servobrake - 2. Yaw sensor - 3. Steering angle sensor - 4. Longitudinal acceleration sensor - 5. EDC motor control unit - 6. ESP electronic control unit - 7. Intake solenoid valves - 8. Driving solenoid valves - 9. Scavenge pump control motor - 10. Scavenge pumps - 11. Single-acting safety valves - 12. Low pressure accumulators - 13. Quick pressure decrease single-acting valves - 14. Power supply solenoid valves - 15. Discharge solenoid valves - 16. Pressure sensor - 17. Single-acting valves - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor - DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor

102283

If longitudinal acceleration sensor "4" finds that the vehicle is on a slope, if the brake pedal is pressed down, and if either the first gear or the reverse gear is engaged, the control unit will power both intake solenoid valves "7" and driving solenoid valves "8". At the same time, the pressure to be conveyed to the brake calipers affected can be generated by powering motor "9" which drives pumps "10".


This function will automatically keep the vehicle braked over 2.5 seconds until the clutch is closed and the driver presses the accelerator pedal again, thus avoiding uncontrolled motion of the vehicle.

It allows the driver to easily and safely start the vehicle on all slopes, regardless of the load carried.

Hydraulic diagrams of ESP 8 modulator – 4-channel (II)

Pressure increase

Figura 46/17




1. Vacuum servobrake - 2. Yaw sensor - 3. Steering angle sensor - 4. Longitudinal acceleration sensor -
 5. EDC motor control unit - 6. ESP electronic control unit - 7. Intake solenoid valves - 8. Driving solenoid valves -
 9. Scavenge pump control motor - 10. Scavenge pumps - 11. Single-acting safety valves - 12. Low pressure accumulators -
 13. Quick pressure decrease single-acting valves - 14. Power supply solenoid valves - 15. Discharge solenoid valves -
 16. Pressure sensor - 17. Single-acting valves - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor -
 DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor

By pressing down the brake pedal, the oil under pressure can reach the brake calipers since both driving solenoid valves "8" and power supply solenoid valves "14" are open.

Pressure decrease

Figura 46/18




1. Vacuum servobrake - 2. Yaw sensor - 3. Steering angle sensor - 4. Longitudinal acceleration sensor - 5. EDC motor control unit - 6. ESP electronic control unit - 7. Intake solenoid valves - 8. Driving solenoid valves - 9. Scavenge pump control motor - 10. Scavenge pumps - 11. Single-acting safety valves - 12. Low pressure accumulators - 13. Quick pressure decrease single-acting valves - 14. Power supply solenoid valves - 15. Discharge solenoid valves - 16. Pressure sensor - 17. Single-acting valves - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor - DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor

If the sensors find that the wheel(s) tends to get locked, they will inform the control unit: the latter will reduce the braking power by actuating power supply solenoid valves "14" and discharge solenoid valves "15".

At the same time, the excess oil in low pressure accumulators "12" can be recovered by powering motor "9" which drives pumps "10".

Pressure maintenance

Figura 46/19




102286

1. Vacuum servobrake - 2. Yaw sensor - 3. Steering angle sensor - 4. Longitudinal acceleration sensor -
 5. EDC motor control unit - 6. ESP electronic control unit - 7. Intake solenoid valves - 8. Driving solenoid valves -
 9. Scavenge pump control motor - 10. Scavenge pumps - 11. Single-acting safety valves - 12. Low pressure accumulators -
 13. Quick pressure decrease single-acting valves - 14. Power supply solenoid valves - 15. Discharge solenoid valves -
 16. Pressure sensor - 17. Single-acting valves - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor -
 DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor

When the optimum braking force has been obtained, the control unit will be able to keep such force steady by de-energizing discharge solenoid valves "15", motor "9" and its respective scavenge pumps "10", whereas power supply solenoid valves "14" will be powered on.

EBD device intervention

Figura 46/20



1. Vacuum servobrake - 2. Yaw sensor - 3. Steering angle sensor - 4. Longitudinal acceleration sensor - 5. EDC motor control unit - 6. ESP electronic control unit - 7. Intake solenoid valves - 8. Driving solenoid valves - 9. Scavenge pump control motor - 10. Scavenge pumps - 11. Single-acting safety valves - 12. Low pressure accumulators - 13. Quick pressure decrease single-acting valves - 14. Power supply solenoid valves - 15. Discharge solenoid valves - 16. Pressure sensor - 17. Single-acting valves - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor - DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor


Fp. Rear axle braking force - Fa. Front axle braking force - A. Servobrake distribution curve - B. Ideal distribution curve - C. Distribution curve of corrector (if any) - D. EBD system distribution curve

If the sensors find that one or both of the rear wheels tend to get locked compared with the front wheels, they will inform the control unit: the latter will, as a result, power rear axle power supply solenoid valve "14", so as to optimize the braking force. Any anomaly of some components of the system will cause the ABS system to be cut off (this condition will be displayed by the lighting of the respective warning light). Yet, the EBD system operation will be ensured. Simultaneous lighting of both failure warning lights (ABS and EBD) will indicate a fault in the EBD system; under these conditions, great care shall therefore be taken while driving, since braking will not be optimized.

102287

ESP device intervention

Figura 46/21



102290

1. Vacuum servobrake - 2. Yaw sensor - 3. Steering angle sensor - 4. Longitudinal acceleration sensor - 5. EDC motor control unit - 6. ESP electronic control unit - 7. Intake solenoid valves - 8. Driving solenoid valves - 9. Scavenge pump control motor - 10. Scavenge pumps - 11. Single-acting safety valves - 12. Low pressure accumulators - 13. Quick pressure decrease single-acting valves - 14. Power supply solenoid valves - 15. Discharge solenoid valves - 16. Pressure sensor - 17. Single-acting valves - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor - DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor

Control unit "6" can brake the single wheels to ensure vehicle stability under dangerous driving conditions.


The signals from yaw sensor "2", steering angle sensor "3", and longitudinal acceleration sensor "4", as well as the speed signals and the accelerator pedal position, provide information that allows the system to come into operation under vehicle understeering or oversteering conditions.

Intake solenoid valves "7" and driving solenoid valves "8" will be actuated. At the same time, motor "9" will be actuated, which controls pumps "10" so that the wheel(s) will be braked in order to correct the path.

Thanks to the CAN line communication with EDC motor control unit "5", ESP control unit "6" will be able to act on engine control, too.

MSR device intervention

Figura 46/22




1. Vacuum servobrake - 2. Yaw sensor - 3. Steering angle sensor - 4. Longitudinal acceleration sensor - 5. EDC motor control unit - 6. ESP electronic control unit - 7. Intake solenoid valves - 8. Driving solenoid valves - 9. Scavenge pump control motor - 10. Scavenge pumps - 11. Single-acting safety valves - 12. Low pressure accumulators - 13. Quick pressure decrease single-acting valves - 14. Power supply solenoid valves - 15. Discharge solenoid valves - 16. Pressure sensor - 17. Single-acting valves - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor - DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor

102288

If the sensors find that the driving wheels tend to drag due to the exhaust brake, control unit "6" will request a slight increase of engine revs through the CAN line. This device ensures stability when releasing the clutch pedal on slippery roads (e.g. snow, ice) and helps keep the path when taking a bend and shifting down, especially on slippery roads.

ASR device intervention

Figura 46/23



102289


1. Vacuum servobrake - 2. Yaw sensor - 3. Steering angle sensor - 4. Longitudinal acceleration sensor - 5. EDC motor control unit - 6. ESP electronic control unit - 7. Intake solenoid valves - 8. Driving solenoid valves - 9. Scavenge pump control motor - 10. Scavenge pumps - 11. Single-acting safety valves - 12. Low pressure accumulators - 13. Quick pressure decrease single-acting valves - 14. Power supply solenoid valves - 15. Discharge solenoid valves - 16. Pressure sensor - 17. Single-acting valves - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor - DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor

If the sensors find that one or both of the rear axle wheels tend to skid (at a speed of 6 to 10 k.p.h.), they will inform the control unit: the latter will power intake solenoid valves "7", driving solenoid valves "8", and power supply solenoid valves "14".

At the same time, the pressure to be conveyed to the brake calipers affected can be generated by powering motor "9" which drives pumps "10".

HBA device intervention

Figura 46/24



1. Vacuum servobrake - 2. Yaw sensor - 3. Steering angle sensor - 4. Longitudinal acceleration sensor - 5. EDC motor control unit - 6. ESP electronic control unit - 7. Intake solenoid valves - 8. Driving solenoid valves - 9. Scavenge pump control motor - 10. Scavenge pumps - 11. Single-acting safety valves - 12. Low pressure accumulators - 13. Quick pressure decrease single-acting valves - 14. Power supply solenoid valves - 15. Discharge solenoid valves - 16. Pressure sensor - 17. Single-acting valves - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor - DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor


102291

If the system recognizes, through pressure sensor "16", an emergency braking condition, i.e. it detects a pressure increase " $\Delta p / \Delta t$ " higher than normal braking, the control unit will power both intake solenoid valves "7" and driving solenoid valves "8".

At the same time, the pressure to be conveyed to the brake calipers affected can be generated by powering motor "9" which drives pumps "10". Pressure shall be such that further reduction of the braking distance will be ensured.

HHC device intervention

Figura 46/25



102292

1. Vacuum servobrake - 2. Yaw sensor - 3. Steering angle sensor - 4. Longitudinal acceleration sensor - 5. EDC motor control unit - 6. ESP electronic control unit - 7. Intake solenoid valves - 8. Driving solenoid valves - 9. Scavenge pump control motor - 10. Scavenge pumps - 11. Single-acting safety valves - 12. Low pressure accumulators - 13. Quick pressure decrease single-acting valves - 14. Power supply solenoid valves - 15. Discharge solenoid valves - 16. Pressure sensor - 17. Single-acting valves - DX/A. Front axle right wheel sensor - SX/A. Front axle left wheel sensor - DX/P. Rear axle right wheel sensor - SX/P. Rear axle left wheel sensor


If longitudinal acceleration sensor "4" finds that the vehicle is on a slope, if the brake pedal is pressed down, and if either the first gear or the reverse gear is engaged, the control unit will power both intake solenoid valves "7" and driving solenoid valves "8". At the same time, the pressure to be conveyed to the brake calipers affected can be generated by powering motor "9" which drives pumps "10".

This function will automatically keep the vehicle braked over 2.5 seconds until the clutch is closed and the driver presses the accelerator pedal again, thus avoiding uncontrolled motion of the vehicle.

It allows the driver to easily and safely start the vehicle on all slopes, regardless of the load carried.

526713 Rev sensor
566712 Phonic wheels

Figure 46/26




The system for measuring the speed of rotation of the wheels is composed of the wheel speed sensor and the phonic wheel. The phonic wheel is housed or incorporated in the brake disc of the wheel and turns at the same speed as the wheel. By induction in the sensors it generates alternating voltages whose frequency is in proportion to the speed of rotation of the respective wheel. These voltage signals are transmitted to the control unit for processing.

ESP SYSTEM SENSORS

Yaw sensor with built-in side acceleration sensor

Figure 46/27



It measures the motion of the vehicle around its own vertical axis (yaw) as well as the vehicle's side acceleration.


These signals continuously inform the control unit about the vehicle's behaviour.

The comparison between these signals and those from the driver (steering-wheel position, wheel spin number/speed and pressure on the brake pedal/accelerator position) allows the ESP control unit to define the actions to be taken. The hydraulic unit controls brake pressure as quickly as possible, separately for every single wheel.

Moreover, the ESP system may decrease the engine revs number by means of the engine control feature.

Longitudinal acceleration sensor

Figure 46/28



It measures the vehicle's acceleration and deceleration changes.


These signals continuously inform the control unit about the vehicle's behaviour.

The comparison between these signals and those from the driver (steering-wheel position, wheel spin number/speed and pressure on the brake pedal/accelerator position) allows the ESP control unit to define the actions to be taken. The hydraulic unit controls brake pressure as quickly as possible, separately for every single wheel.

Moreover, the ESP system may decrease the engine revs number by means of the engine control feature.

Steering angle sensor

Figure 46/29



It measures the steering angle required by the driver.

The comparison between this signal and those from all the other sensors allows the ESP control unit to define the actions to be taken. The hydraulic unit controls brake pressure as quickly as possible, separately for every single wheel.

Moreover, the ESP system may decrease the engine revs number by means of the engine control feature.

5274 BRAKE REPAIRS

Front brakes

The following operations have been carried out on vehicles with 2x44 Brembo front calipers.

They should be considered similar also for 2x42 - 2x52 Brembo front calipers unless stated otherwise.

527417 Replacing brake linings




The braking system effects safety. All repairs and servicing operations must be exclusively carried out by skilled, qualified personnel.



The oil inlet hose to the calliper must not be disconnected during the operations that follow.

Figure 47




455026

Set the vehicle on level ground and lock the rear wheels. Loosen the nuts (1) securing the front wheels. Lift the front of the vehicle with a hydraulic lift and rest it on two stands (3).

Unscrew the nuts (1), take off the cover (2) and remove the wheel.

For 2x42 calipers


Figure 48



52272

Remove the protective rubber plug (1).


Figure 49



79524

Disconnect the wear sensor connection (2). Loosen the screw (1). Remove the bushing (4) by using a screwdriver as a lever. Remove the caliper body (3) from the support by making it turn on the other bushing to extract the brake pads.


Figure 50



45845

Remove the brake linings (1).

Figure 51



79253



Retracting the pistons will increase the level of brake fluid in the reservoir. For this reason, check the fluid does not spill out of the reservoir and damage vehicle paintwork during the operation.

Use a retractor or other suitable device (2) to retract the pistons (1).



Be careful not to damage the surface of the pistons and the protective boots in contact with the tool.

Clean the pad resting surface with suitable materials and products (e.g. with a damp cloth). Avoid using nitro thinner or petrol, etc., which could damage protective boots.


Inspect the state of the dust caps. If they are out of shape or broken, it is necessary to replace them. Remove the dirt from the brake caliper with a wire brush, without damaging the dust caps. Check the surfaces of the brake disc and make sure there is no corrosion or scoring. Small surface cracks are acceptable, but it is then necessary to grind the brake disc as described under the relevant heading. Replace worn brake discs.



We suggest that both brake discs be renewed also in case one of them only needs to be replaced. As regards brake lining pairs, always replace a complete series for each axle.

Always overhaul both brake calipers also in case one of them only seems to be damaged.


Figure 52



79526

Insert new brake liners (1) in the brake calliper mount and check that they slide in their seats.

Figure 53



46487

Use a torque wrench (3) to tighten the screws (1) at the specific torque.


Connect the wear sensor connection (2).



The screw (1) is treated with threading locking adhesive, therefore every time the screw (3) is removed it must be changed.

For 2x42 calipers

Figure 54




52272

Fit on the protective rubber plug (1).

527413 Brake caliper removal and refitting
Removal

For 2x42 calipers

Figure 55




52273

Remove the protective rubber plugs (1 and 2).

For all brake calipers

Figure 56





52274


Disconnect the lining wear sensor electrical connection (2). Disconnect the pipe (3) from the caliper (4) and drain off the brake fluid.


Unscrew the screws (1 and 5) and remove the brake caliper (4).

Refitting

 Check the pistons are fully retracted inside the caliper body.

 Refit by carrying out the operations described for removal in reverse order, observing the required tightening torques.

 Every time the screws (1 and 5, Figure 56) are removed, they must be replaced.

 Drive slowly without prolonged, sudden brake application during the first period of use of new brake pads because braking efficiency is reduced.

Press the brake pedal repeatedly to restore pressure in the system and correct brake pedal stroke.


527440 REAR BRAKES

The following operations have been carried out on vehicles with 2x44 and 2x46 Brembo rear calipers.

They should be considered similar also for 1x52 Brembo rear calipers unless stated otherwise.

527447 Replacing brake linings

Figure 57



45045


Set the vehicle on level ground, loosen the nuts (1) securing the wheels.

Lift the front of the vehicle with a hydraulic lift and rest it on two stands (2).

Unscrew the nuts (1) and remove the wheels.

For 1x52 calipers

Figure 58




50734

Remove the protective rubber plug (1).

For all brake calipers

Figure 59




46287

Disconnect the wear sensor connection (2). Unscrew the screws (1) and turn the brake caliper (3) over.

If the liners are replaced in vehicles with leaf spring suspensions, extract both bushings and entirely separate the caliper body from the mount.

Figure 60



46849

Remove the brake linings (1).

Retract the pistons as shown in Figure 51.

Inspect the state of the dust caps. If they are out of shape or broken, it is necessary to replace them.

Remove the dirt from the brake caliper with a wire brush, without damaging the dust caps.

Clean the pad resting surface with suitable materials and products (e.g. with a damp cloth). Avoid using nitro thinner or petrol, etc., which could damage protective boots.


Check the surfaces of the brake disc and make sure there is no corrosion or scoring. Small surface cracks are acceptable, but it is then necessary to grind the brake disc as described under the relevant heading. Replace worn brake discs.



We suggest that both brake discs be renewed also in case one of them only needs to be replaced. As regards brake lining pairs, always replace a complete series for each axle.

Always overhaul both brake calipers also in case one of them only seems to be damaged.

Figure 61




Fit the new linings (1) to the brake caliper mounting. Ensure linings are free to slide in their seats.

Push brake caliper pistons (2) as far as they can go. Then position the caliper on the brake linings.

For 1x52 calipers

Figure 62



Using tool 99372236 (1) retract the piston (3) by pushing constantly in line with the piston axis with a force of approx. 300 ± 400 N while turning the tool clockwise until the piston (3) is fully retracted.




During this operation, take care not to twist the protective cap (2) or let it swell out.

Let the air out of the cap by moving it away from the brake caliper.

For all brake callipers

Figure 63



Tighten the screw (3) to the required torque with a torque wrench (1).


Connect the wear sensor connection (2).



The screw (1) is treated with threading locking adhesive, therefore every time the screw (3) is removed it must be changed.

For 1x52 calipers

Figure 64



Fit on the protective rubber plug (1).

For all brake callipers



Drive slowly without prolonged, sudden brake application during the first period of use of new brake pads because braking efficiency is reduced.


Press the brake pedal repeatedly to restore pressure in the system and correct brake pedal stroke.

527443 Brake caliper removal and refitting

Removal

For 1x52 calipers

Figure 65




51753

Remove the protective rubber plugs (1 and 2).

For all brake calipers

Figure 66




46046

Disconnect brake shoe wear sensor electrical connection (3). Disconnect the calliper (5) hose (2) from the pipe with a suitable tool (cap the pipe to prevent leakage of brake fluid). Loosen the screws (1 and 4) and remove the brake calliper (5).

NOTE Remove the hose at the bench.

For 1x52 calipers

Figure 67



50735

Remove the retaining clip (1) and unhook the parking brake rope.

Removal



Refit by carrying out the operations described for removal in reverse order, observing the required tightening torques.



Replace the hose if anomalies are found.




Every time the screws (1 and 4, Figure 66) are removed, they must be replaced.

527413 OVERHAUL OF BRAKE CALIPERS
2x42 - 2x44 - 2x46 - 2x52 Brembo brake calipers

Disassembly

Figure 68




45033

Place the caliper on a work bench. Insert a block of wood (2) so that the pistons can be removed without damaging them, and to make the operations safe for the technician.

By means of a gun (3), introduce air into the brake caliper the pistons (1) are extracted.

Remove the dust boots from the respective seats.


Figure 69



45034

Remove the dust covers (1 and 2) and keep the sliding bushes (3).

Figure 70



45035

Remove the seal rings (1) from the brake caliper cylinder seats.

Cleaning and checking of main components For all types of brake calipers



When washing the metal components use hot water with Fiat LCD type detergent.



By means of a metal brush, remove any dirt from the brake caliper, then eliminate any residual dirt with the use of a brush. Carefully clean the seats of the guide pins, sliding bushes, pistons and the pistons themselves.

By means of a suitably sized synthetic brush, remove all traces of grease from the seats of the sliding bushes. Open the bleeder valves, then carefully blow compressed air into the brake caliper casing.

By means of a piece of canvas soaked in methylated spirits or similar, carefully clean the sliding surfaces.

Check the wear on the sliding bushes, pistons and relevant seats on the brake caliper casing. Make sure that the sliding surfaces are neither damaged or worn.

Insert the bushes and pistons into the seats and check that they are free to slide, otherwise restore or replace as necessary.



A regular braking effect depends a great deal on the condition of the sliding surfaces.

Check wear of brake liners and safety springs. Replace the parts which are either deformed or worn.


It is recommended to replace the piston dust covers and seal rings even if they do not show any signs of deformations or defects.

Re-assembly



Lubricate the pistons and seal rings with brake liquid Tutela DOT SPECIAL.


Figure 71



45035

Insert the seal rings (1) into the relevant seats of the caliper casing.

Figure 72



45036

Insert the dust boots (4 and 5) in their seat on the brake caliper (1). Fit the cylinders (2) and the sliding bushes (3) and make sure they slide freely.

Correct sliding if required by lubricating the bushings with Klueber glkl pf grease.

Insert the dust covers into the relevant seats on the pistons (2) and on the sliding bushes (3).

1x52 Brembo brake calipers




The 1x52 callipers (rear, 29 L - 35 S vehicles) are equipped with an automatic brake liner wear tensioner device and the components cannot be removed.

Consequently, replacement/overhauling operations on the piston, dust boot and internal components must only be carried out by specialised personnel. Only the sliding bushings can be overhauled. The removal/refitting procedure is the same as that described for the other callipers.

52741 I OVERHAULING BRAKE DISCS

Figure 73



45038


To take down and fit back the brake disk (1) follow the procedures described in the "axles" section.

Check the wear on the surfaces of the drum brakes.

When values different from those indicated in the specifications and data table are found, machine and grind the disk brakes and, if necessary, replace them.

52741 I MACHINING AND GRINDING OF DISC BRAKES


Figure 74



45039


- Fit the disk brake (1) complete with the wheel-hub to the late arbor 99301005 (2);
- fit a set of spacers on the shaft to remove unit end play, tighten the lock nut and apply the lathe support;
- place the tool-holder (3) along the axis of the drum brake (1) then adjust the work depth of the tools;
- turn down the drum brake (1) by passing over the surface a few times depending on the condition of the surface itself.

Figure 75




45040

By means of the lathe 99301001 (1), machine both working surfaces of the drum brake.

 During this grinding operation, gradually move the sequential wheel towards the working surface in order to completely remove the swarf left over from turning.

WHEEL NUT TIGHTENING SEQUENCE

Figure 76




52746

5817 - 450210 AXLE TIGHTENING ORDER

Tighten the screws at the specified torque in the order shown.

Figure 77



52747


AXLE TIGHTENING ORDER
(EXCEPT FOR 5817 AND 450210)

Tighten the screws at the specified torque in the order shown.

OVERHAULING PARKING BRAKE

Dismantling parking drum brake

Figure 78




45048

Release shoe (1) return springs (2 and 5). Save the adjusting device (3).

Remove retaining brackets (4 and 6) and detach shoes (1).

Figure 79



45049


Remove shoe retaining pins (3) and parking brake wire hitching device (4).

NOTE Disjoin support (1) and withdraw sensor (2) to remove ABS sensor (2).

To reassemble the sensor (2), push it as far as it will go inside support (1) and fasten the latter to the rear axle.

For models 35C - 40C - 45C - 50C

Figure 80




45047

VIEW OF THE PARKING DRUM BRAKE

For models 60C - 65C

Figure 81



62674

VIEW OF THE PARKING DRUM BRAKE



Check inner disc diameter to establish whether it can be reused.



Measure the inner disc diameter with a sliding gauge without moving the arms to an angle.



Measure the drum diameter in several spots to determine ovality and wear. Also examine depth of scoring on the braking surface.

Max permitted ovality and/or eccentricity tolerance is 0.1 mm.

Replace the disc if wear or evident signs of overheating are found (see specifications and data table).

Check brake jaw conditions and replace if anomalies are found.

If the brake lining surface is oily, trace the cause and repair the fault.


The minimum brake seal thickness is 3.5 mm for models 60C - 65C, and 1.5 mm for models 35C - 40C - 45C - 50C.

If this is not so, even if only slightly above or below the specified value, replace them.

Check serviceability of shoe return springs.

Assembly

Figure 82




Loosen the tensioner under the chassis in the middle of the vehicle.

Reverse disassembly operations to reassemble.

Using a sliding gauge, measure the diameter of the brake seal (2), check that the values correspond with those indicated on the specifications and data tables, if not, adjust the device (1) until the correct values and data are obtained.

5027 Adjusting parking brake (vehicles with parking drum brake)

Figure 83



A. Play recovery is not automatic. Minor lever stroke extension (corresponding to approximately 2 notches in addition to the normal lever stroke which is 7 notches) by means of the tensioner (1) as shown below:

- lift the rear of the vehicle, resting the chassis frame on the stands;
- loosen the lock nut (3);
- take the parking brake lever, in the cab, onto its third catch;
- screw down the tightener screw (2) until the rear wheels are hard to turn by hand;
- operate 3-4 times the lever in the cab to set parts, then check whether the stroke is of approx. 6 steps;
- lock the lock nut (3);
- lower the vehicle.

B. For further adjustments, it is necessary to proceed as follows:


Case 1 – With disk removal

- lift the rear of the vehicle, resting the chassis frame on the stands;
- loosen the screw (2) completely;
- remove the disc as described in the "REAR AXLES" section;
- run the checks described on page 61;
- use the adjustment device (1, Figure 82) to obtain the distances given in the "Specifications and Data" table;
- mount the disc and wheels. Firmly apply the parking brake a few times to settle the sheaths of the ropes;
- take the parking brake lever, in the cab, onto its third catch;
- screw down the tightener until the rear wheels are hard to turn by hand;
- lock the tightener lock nut;
- lower the vehicle.

Case 2 – Without removing disks

- lift the rear part of the vehicle resting the chassis on the supporting stands provided for the purpose and remove wheels;
- loosen the lock nut (3);

Figure 84



- remove the brake upper slot rubber plug (3);
- use tool 99372249 (1) to operate the manual adjuster internal ring nut (2) and widen the shoes until the disk can no longer be turned using just the hands;
- always with tool 99372249 (1), loosen the above mentioned adjusting ring nut (2) by 3 notches and check whether the disk is free to turn;
- refit the rubber plug into the slot;
- refit rear wheels;
- set the lever in the cab to the third position;
- screw the tightener screw (2, Figure 81) until wheels can no longer be turned using just the hands;
- operate 3-4 times the lever in the cab to set parts, then check whether the stroke is of approx. 6 steps;
- lock tightener lock nut;
- lower the vehicle.



Should new brakes/disks be replaced at the same time, drum brakes are not to be adjusted. Only adjust the main cable tightener since brakes are adjusted yet to the rated installation value.

Vehicles with parking brake on brake disc

Clearance recovery is automatic, but if the ropes are removed or replaced it is necessary to adjust their length in accordance with points A and B.

REPLACING THE ESP COMPONENTS

Some modifications or repairs affecting the ESP system components require a specific calibration procedure.

The repairs that require such procedure are detailed as follows:



- replacing the electronic control unit (integrated into the electrohydraulic modulator) of the system's braking apparatus;
- replacing the steering angle sensor fitted inside the steering wheel;
- replacing the longitudinal acceleration sensor.

NOTE Replacing the yaw sensor requires no calibration.

STEERING ANGLE SENSOR

Replacing

Figure 85



102110

Below is the description of sensor calibration only. As far as steering angle sensor replacement is concerned, refer to the description on page 24 of the "Steering" section.

Calibration


With both the steering-wheel and the wheels in straight position (after checking toe-in), you will obtain the sensor "zero" condition through the diagnosis instrument, i.e. you will assign its absolute zero position.

Use a diagnosis instrument to clear the errors.

Carry out a road test, to make the control unit verify whether errors are still found. Drive along a straight road at a constant speed. Steer to the right and then to the left several times, after making sure you do not endanger other drivers.

NOTE Drive back to the service centre, then use a diagnosis instrument to verify that the anomaly is no longer found.


Drive back to the service centre, then use a diagnosis instrument to verify that the anomaly is no longer found.

526741104 LONGITUDINAL ACCELERATION SENSOR**Figure 86**

102315

**Removal**

Disconnect the battery cables in the engine compartment.
Take off the instrument board covering.

Figure 87

102316

Disconnect electric connection (3).
Unscrew the two sensor (2) fastening screws (1).
Remove sensor (2).

**Refitting**

Re-attachment is carried out by reversing the order of detachment operations. Also follow the advice below:

- never change the sensor position and fastening points. The sensor features an offset position compared with the vehicle centre line, which must not be modified.
- After re-attachment has been completed, follow the calibration procedure described below.

Calibration

Calibration must be carried out with the vehicle on a flat ground.

Assign the sensor "zero" position by means of the diagnosis instrument.

Always clear the errors (if any) found in the control unit memory by means of the diagnosis instrument.


Carry out a functional road test to verify whether errors are still found.

This consists of driving the vehicle to a slight slope and subsequently verifying whether the vehicle is kept braked over 2.5 seconds.

Drive back to the service centre, then use a diagnosis instrument to verify that no anomaly is found any longer.

526742104 YAW SENSOR

Figure 88




102317

Removal

Disconnect the battery cables in the engine compartment. Take off the instrument board covering.

Figure 89




102318

Disconnect electric connection (2).



Take off glove compartment (1) on the passenger's side. If the vehicle is equipped with passenger's airbag, follow the safety rules indicated in the relevant chapter of the "Steering" section.

Figure 90



102319

Unscrew the two sensor (2) fastening screws (1) by using a suitable wrench to remove the side right screw, considering that the latter cannot be accessed easily. Then, remove sensor (2).

Refitting



Re-attachment is carried out by reversing the order of detachment operations. Also follow the advice below:



- never change the sensor position and fastening points. The sensor features an offset position compared with the vehicle centre line, which must not be modified.

Calibration

NOTE Replacing the yaw sensor requires no calibration procedure.

526741 I04 ELECTROHYDRAULIC MODULATOR/CONTROL UNIT

Figure 91




102109

**Removal**

Disconnect the battery cables in the engine compartment. Take off the hydraulic braking system fluid cap, then remove the filter.

Suck the braking system fluid by means of a syringe.

Figure 92



102320

Disconnect the six oil ducts from modulator (1). Clear the modulator parts of the oil escaped when disconnecting the ducts.

Disconnect the electric connection.

Loosen the screws securing the modulator to the support bracket.

Remove the modulator/control unit (1).

**Refitting**

Re-attachment is carried out by reversing the order of detachment operations. Also follow the advice below:

- connect the connector with great attention, taking care to insert it perpendicularly to the seat to avoid damaging the pins;
- after re-attachment has been completed, perform the programming and calibration procedures described below.

Programming

Programming requires entering the following variant codes (by means of the diagnosis instrument): type of drive, engine, MTT, wheelbase, type of front and rear suspensions, height.

Easy compares the type of vehicle (PIC reading) with the control unit code to avoid installation errors (single wheels instead of dual wheels), and downloads the variant codes into the control unit.


Calibration

Replacing the modulator/control unit requires calibration of the longitudinal acceleration sensor (described on page 64). In this case, the steering angle sensor shall not be calibrated since it features its own internal memory.

Bench overhauling

Disassembly

Figure 93



Loosen the four screws (1) securing control unit (2) to electrohydraulic modulator (3).
Take control unit (2) out of the modulator.

Assembly

Re-attachment is carried out by reversing the order of detachment operations.

SECTION 12

| | |
|-------------|-----------------------------|
| 5501 | Bodywork |
| 5001 | Chassis Frame |
| 5532 | Cab air-conditioning |

NOTE For bodywork and chassis frame see publication No. 603.43.606.

| | Page |
|---|------|
| SAFETY STANDARDS TO OBSERVE WHEN WORKING ON VEHICLES EQUIPPED WITH THE AIR-BAG SYSTEM | 5 |
| CAB AIR-CONDITIONING | 5 |
| <input type="checkbox"/> General | 5 |
| VENTILATION | 5 |
| <input type="checkbox"/> Description | 5 |
| AIR-CONDITIONING SYSTEM MAIN COMPONENTS AND FUNCTIONAL DIAGRAM | 6 |
| AIR-CONDITIONING AND HEATING | 6 |
| <input type="checkbox"/> Description | 6 |
| <input type="checkbox"/> Air-conditioning | 6 |
| <input type="checkbox"/> Heating | 6 |
| AUTOMATIC AIR-CONDITIONING/HEATING . | 7 |
| <input type="checkbox"/> Description | 7 |
| MAIN COMPONENTS | 8 |
| <input type="checkbox"/> Compressor | 8 |
| <input type="checkbox"/> Condenser | 8 |
| <input type="checkbox"/> Drier filter | 8 |
| <input type="checkbox"/> Expansion valve | 9 |
| <input type="checkbox"/> Evaporator | 9 |
| CONTROL AND SAFETY DEVICES | 10 |
| <input type="checkbox"/> Description | 10 |
| <input type="checkbox"/> Three-level pressure switch | 10 |
| <input type="checkbox"/> Outside air temperature sensor | 10 |
| AIR-CONDITIONING UNIT ("M. MARELLI" OR "DENSO" TYPE) | 11 |

Page

| | |
|--|----|
| <input type="checkbox"/> General | 11 |
| <input type="checkbox"/> Electronic control unit | 11 |
| AIR-CONDITIONING SYSTEM CONTROLS AND LOCATION OF VENTS | 12 |
| HEATER/AIR-CONDITIONER UNIT | 13 |
| <input type="checkbox"/> Removal and Refitting | 13 |
| <input type="checkbox"/> Removal | 13 |
| <input type="checkbox"/> Refitting | 14 |
| "M. MARELLI" TYPE HEATER/AIR-CONDITIONER UNIT | 15 |
| <input type="checkbox"/> Components | 15 |
| PROCEDURE FOR EMPTYING AND REFILLING THE AIR-CONDITIONING SYSTEMS WITH R134A REFRIGERANT | 17 |
| <input type="checkbox"/> R134A refrigerant recovery and refilling station (99305146) | 17 |
| CONTROL FASCIA | 18 |
| SAFETY STANDARDS | 20 |
| OPERATION FLOW CHART | 21 |
| RECOVERING REFRIGERANT FROM THE VEHICLE SYSTEM | 22 |
| CREATING A VACUUM IN THE SYSTEM | 24 |
| RESTORING OIL IN THE SYSTEM | 26 |
| FILLING THE SYSTEM WITH REFRIGERANT | 27 |
| CHECKING THE PRESSURES IN THE SYSTEM .. | 29 |
| OPERATIONS PRIOR TO DISCONNECTING THE STATION FROM THE SYSTEM | 29 |
| LEAK FINDER FOR AIR-CONDITIONING SYSTEMS WITH HFC R134A (9905147) | 29 |
| REPAIRS | 30 |
| <input type="checkbox"/> Air-conditioner unit control unit | 30 |
| <input type="checkbox"/> Removal - Refitting | 30 |
| <input type="checkbox"/> Removal | 30 |
| <input type="checkbox"/> Refitting | 30 |
| ELECTRONIC CONTROLLER | 30 |
| <input type="checkbox"/> Removal - Refitting | 30 |
| <input type="checkbox"/> Removal | 30 |
| <input type="checkbox"/> Refitting | 30 |

Page

| | |
|---|----|
| ANTI-FROST SENSOR | 30 |
| <input type="checkbox"/> Removal - Refitting | 30 |
| <input type="checkbox"/> Removal | 30 |
| <input type="checkbox"/> Refitting | 30 |
| ELECTRIC FAN | 31 |
| <input type="checkbox"/> Removal - Refitting | 31 |
| <input type="checkbox"/> Removal | 31 |
| <input type="checkbox"/> Refitting | 31 |
| HEATER RADIATOR | 31 |
| <input type="checkbox"/> Removal - Refitting | 31 |
| <input type="checkbox"/> Removal | 31 |
| <input type="checkbox"/> Refitting | 31 |
| MIXING ACTIVATOR | 31 |
| <input type="checkbox"/> Removal - Refitting | 31 |
| <input type="checkbox"/> Removal | 31 |
| <input type="checkbox"/> Refitting | 31 |
| AIR INTAKE ACTUATOR | 32 |
| <input type="checkbox"/> Removal - Refitting | 32 |
| <input type="checkbox"/> Removal | 32 |
| <input type="checkbox"/> Refitting | 32 |
| TREATED AIR SENSOR | 32 |
| <input type="checkbox"/> Removal - Refitting | 32 |
| <input type="checkbox"/> Removal | 32 |
| <input type="checkbox"/> Refitting | 32 |
| EVAPORATOR UNIT | 33 |
| <input type="checkbox"/> Removal - Refitting | 33 |
| <input type="checkbox"/> Removal | 33 |
| <input type="checkbox"/> Refitting | 33 |
| EXPANSION VALVE AND EVAPORATOR PIPE | 34 |
| <input type="checkbox"/> Removal - Refitting | 34 |
| <input type="checkbox"/> Removal | 34 |
| <input type="checkbox"/> Refitting | 34 |
| COMPRESSOR | 34 |
| <input type="checkbox"/> Compressor Removal - Refitting | 34 |

| | Page |
|--|------|
| <input type="checkbox"/> Removal | 34 |
| <input type="checkbox"/> Refitting | 34 |
| POLLEN FILTER | 35 |
| <input type="checkbox"/> Removal - Refitting | 35 |
| <input type="checkbox"/> Removal | 35 |
| <input type="checkbox"/> Refitting | 35 |
| THREE-LEVEL PRESSURE SWITCH AND DRIER FILTER | 35 |
| <input type="checkbox"/> Removal - Refitting | 35 |
| <input type="checkbox"/> Removal | 35 |
| <input type="checkbox"/> Refitting | 35 |
| CONDENSER | 35 |
| <input type="checkbox"/> Removal - Refitting | 35 |
| <input type="checkbox"/> Removal | 35 |
| <input type="checkbox"/> Refitting | 35 |
| DIAGNOSTIC | 36 |
| FAILURES OF THE ELECTRIC TYPE (MARELLI AIR-CONDITIONER) | 36 |
| <input type="checkbox"/> Self-diagnosis | 36 |
| <input type="checkbox"/> Diagnosis by error codes | 36 |
| <input type="checkbox"/> Error codes | 38 |
| <input type="checkbox"/> Diagnosis by IWT, MODUS and UNITESTER | 39 |
| <input type="checkbox"/> Diagnosis by IWT | 40 |
| FAILURE OF THE MECHANICAL TYPE | 44 |
| "MARELLI" TYPE HEATER | 47 |
| <input type="checkbox"/> Removal - Refitting | 47 |
| <input type="checkbox"/> Removal | 47 |
| <input type="checkbox"/> Refitting | 47 |
| ELECTRIC FAN | 48 |
| <input type="checkbox"/> Removal - Refitting | 48 |
| <input type="checkbox"/> Removal | 48 |
| <input type="checkbox"/> Refitting | 48 |
| HEATER CONTROL CABLES | 49 |
| <input type="checkbox"/> Removal - Refitting | 49 |
| <input type="checkbox"/> Removal | 49 |
| <input type="checkbox"/> Refitting | 49 |

| | Page |
|---|------|
| HEATER UNIT | 50 |
| <input type="checkbox"/> Components | 50 |

SAFETY STANDARDS TO OBSERVE WHEN WORKING ON VEHICLES EQUIPPED WITH THE AIR-BAG SYSTEM



Before doing any work, you MUST observe the SAFETY rules given in section I0 "Steering system"

CAB AIR-CONDITIONING

General

The purpose of the air-conditioning system is to make the cab comfortable as regards the following parameters:

- temperature and relative humidity of outside air;
- temperature and relative humidity in the cab.

The system subjects the air to thermodynamic transformations that affect its temperature, relative humidity and purity. This is accomplished by:


- Ventilation**, or introducing air taken from the outside (therefore with the temperature and humidity of the surrounding environment) into the cab.
- Air-conditioning**, or cooling and de-humidifying the air, with the possibility of heating it afterwards as preferred so as to change the temperature and humidity in the cab.

VENTILATION Description

Ventilation is the function of drawing in fresh air from the outside, cleaned of pollen and dust by a special filter, or recycling the air in the cab.

This system is composed of a shell, designed to house the electric fan unit, air ducts, fresh air intake and recycled air intake. The electric fan has several speeds to draw in and circulate large masses of air.

Figure I




35858

CAB VENTILATION DIAGRAM

AIR-CONDITIONING SYSTEM MAIN COMPONENTS AND FUNCTIONAL DIAGRAM

Figure 2



52279

A. Refrigerant liquid inlet - B. Refrigerant liquid outlet - H. High-pressure circuit - L. Low-pressure circuit.

1. Condenser - 2. Three-level pressure switch - 3. Drier filter - 4. Compressors - 5. Heater/fan unit - 6. Evaporator - 7. Expansion valve - 8. Pollen filter.

AIR-CONDITIONING AND HEATING Description

This is accomplished by integrating an air-conditioning and a heating system.

This integration makes it possible to change the temperature and humidity in the cab.

Air-conditioning

Air-conditioning is accomplished by taking advantage of the high capacity of some gases to lower temperature considerably in their phase of expansion, thereby making it possible to absorb heat from the cab.

This condition is obtained by two different levels of pressure (high, when the refrigerant fluid is in its liquid state, and low, when the fluid is in its gaseous state) that are established and maintained during operation of the system.

Heating

Heating is accomplished by a radiator, in the heater unit, in which the engine coolant circulates.

Special doors allow air to pass through the radiator only when the heating function is activated.

The main components of the air-conditioning and heating system comprise:

- compressor (4);
- condenser (1);
- drier filter (2);
- three-level pressure switch (3);
- expansion valve (7);
- evaporator (6);
- heater/fan unit (5);
- pollen filter (8).


AUTOMATIC AIR-CONDITIONING/HEATING

Description

The automatic air-conditioning/heating system is controlled by an electronic control unit that governs the air-conditioning and heating functions so as to obtain and maintain the required conditions in as stable a manner as possible.

The following figure illustrates the vehicle layout of the main components of the automatic air-conditioning/heating system and the layout of the contactors and fuses on the fuse/contactor-holder unit.

Figure 3




1. Air-conditioning system filler coupling (high pressure) - 2. Pollen filter - 3. Air-conditioning system drainage coupling (low pressure) - 4. Low-pressure pipe - 5. High-pressure pipe - 6. High-pressure pipe - 7. Condenser - 8. High-pressure pipe - 9. Drier filter - 10. Three-level pressure switch - 11. Compressor - 12. 5A fuse (air-conditioner/heater) - 13. 5A fuse (engine electronic control unit) - 14. 5A fuse (miscellaneous lighting) - 15. 30A fuse (cab heater) - 16. 10A fuse (engine electronic control unit) - 17. 3A fuse (air-conditioner) - 18. 3A fuse (panel) - 19. Contactor turning off air-conditioner compressor - 20. Contactor turning on air-conditioner compressor - 21. Contactor controlling electromagnetic coupling - 22. 25A fuse (engine electronic control unit) - 23. Fuse/contactor-holder unit - 24. Heater/air-conditioner unit.

52280

MAIN COMPONENTS

553239 Compressor

Figure 4




52281

The compressor is located between the evaporator and the condenser. Its function is to:

- draw refrigerant fluid in the form of vapour at low pressure and low temperature from the evaporator through the inlet (2);
- compress the refrigerant fluid drawn up and introduce it at high temperature and high pressure into the condenser through the outlet (1).

The compressor is driven by the electromagnetic friction device mounted on the compressor shaft.

Figure 5



52282


The electromagnetic friction device is composed of an electromagnetic coil (2), a pulley (1) and a front disc (3).

When the system is not running, the pulley (1) turns idle on the bearing (4) since it is driven by the engine via the V-belt.

On switching on the air-conditioning system, the electromagnetic coil (2) attracts the front disc (3) on the pulley (1) that comes to be virtually keyed onto the compressor shaft and makes it rotate.

553232 Condenser

Figure 6



52283


The condenser is a heat exchanger located between the compressor and the drier filter. Its function is to transform the refrigerant fluid from its gaseous to its liquid state.

This transformation is made by the refrigerant fluid releasing heat to the outside air. This is why the condenser is installed on the vehicle so as, in the best conditions, to take advantage of the air stream produced by the forward motion of the vehicle.

When the vehicle is stationary or in a traffic jam, the flow of air needed to transform the refrigerant fluid is produced, under the control of the three-level pressure switch, by the fan for cooling the engine coolant.

553234 Drier filter

Figure 7




52284

The drier filter is located between the condenser and the expansion valve. It has the following functions:

- reserve tank for excess refrigerant fluid during variable filling phases;
- filtering element for the solid particles generated by compressor wear;
- eliminating the moisture formed in the system.

553233 Expansion valve

Figure 8



52285

The expansion (block) valve is located between the drier filter and the evaporator.


Its function is to control and proportion the flow of refrigerant fluid to get the highest refrigerating capacity out of the system and to lower the pressure of the refrigerant (at the filter outlet) to a pre-set value so that the fluid, circulating in the evaporator, can be drawn up by the compressor in a completely gaseous form.

This valve has two passages for the refrigerating fluid:

- the bottom one enabling the refrigerant to pass (5) from the drier filter to the evaporator (2). Along this route there is a spring (4) that, appropriately set, makes it possible to obtain such a leap in temperature (overheating) as to make sure that the refrigerant, at the evaporator inlet, is entirely in its gaseous state. In addition, there is also a modulating element, in this case a ball (3) housed in the gauged pipe that controls the flow rate of refrigerant to the evaporator;
- the top one enabling the refrigerant to pass (1) from the evaporator to the compressor (6). Along this route there is a temperature sensor (7) that, depending on the temperature at the evaporator outlet, makes it possible to control the flow rate of refrigerant, by means of the modulating element (3), and control the overheating, by means of the spring (4).

553231 Evaporator

Figure 9



52286

The evaporator is a heat exchanger located between the expansion valve and the compressor.

Its function is to:

- change the state of the refrigerant from a liquid, at the inlet, to a gas, at the outlet;
- absorb the heat in the cab and thereby produce the required refrigerating effect.

To be able to perform these functions, an electric fan draws warm, moist air from the cab and conveys it onto the evaporator.

Since this air is at a higher temperature than the refrigerant, it gives some of its heat to the refrigerant and cools down, while the moisture it contains condenses on the evaporator fins in the form of droplets.

This produces cold, dehumidified air.

This change takes place with considerable heat absorption. A special channel collects the condensation formed and discharges it outside.

The considerable cooling of the radiating pack is due to the change in state, from liquid to gas, of the refrigerant.


CONTROL AND SAFETY DEVICES

Description

The system is equipped with specific devices that, by checking the pressure and temperature, make it possible to protect the system from possible trouble and provide optimal operation.

553235 Three-level pressure switch

Figure 10




52287

The three-level pressure switch is mounted on the pipe connecting the drier filter to the expansion valves. It has the task of operating the electric fan for the condenser and radiator when the vehicle is stationary or running at low speed, so there is no air stream caused by the forward motion of the vehicle, and it is therefore necessary to activate refrigerant condensation by forced ventilation.

In addition, it has the task of disconnecting the electromagnetic coupling of the compressor pulley when the pressure of the fluid (high pressure side), in spite of the action of the condenser and radiator fan, reaches dangerous limits or when the heating load conditions are not sufficient to make the refrigerant evaporate.

553242 Outside air temperature sensor

Figure 11




52288

This is mounted on the left-hand external rear-view mirror in the position shown in the figure.

553230 AIR-CONDITIONING UNIT (“M. MARELLI” OR “DENSO” TYPE)

Figure 12



52289

General

A special casing, configured so as to permit insulation, houses the radiator-heater, evaporator, fan unit, internal air (recirculation air) and external air (fresh air) intakes, direction flaps, ducts and vents for the flow of treated air.

This unit has to control the following parameters and functions automatically under the control of the control unit: air temperature at vents, fan speed, air distribution, recirculation, and compressor activation.

The system needs to make provision for the possibility of adjusting the following parameters and functions manually: fan speed on 5 positions, air distributor on 4 positions (5 in automatic mode), recirculation, and compressor activation.


The manual controls have priority over automatic mode and are kept in memory until the user deliberately cancels the command, returning control of the relative function to automatic mode.

If one of the parameters is changed manually, the others remain under automatic control.

The air temperature at the vents is always controlled automatically to produce the temperature shown on the display in the cab (unless the system is not in operation).

553248 Electronic control unit

Figure 13



52290

The automatic air-conditioning/heating system is controlled by an electronic control unit that governs both systems (air-conditioning and heating) and determines the mixture and quantity of air to be introduced into the cab to provide the required conditions.

To obtain the required temperature in the cab, the control unit also takes into account the data from the sensor that measures the outside air temperature.


The control unit therefore governs the following functions:

- switching the air-conditioning system on and off;
- using external or recycled air; the hot/cold air mixture;
- the amount of air to introduce into the cab (with the different fan speeds).

Every time the battery is disconnected, when it is reconnected the control unit automatically zeroes the positions.

AIR-CONDITIONING SYSTEM CONTROLS AND LOCATION OF VENTS

Figure 14




52291

1. Central vents - 2. Demisting vents - 3. Side vents - 4. Air-conditioning system warning light - 5. Switch to activate the function of recycling air inside the cab - 6. Switch to turn off the air-conditioner - 7. Air distribution knob: A. air towards face / B. air towards face and feet / C. air towards feet / D. air towards feet and windscreen / E. air towards windscreen / F. MAX/DEF position: the system prepares for demisting - 8. Knob for air temperature control with end positions to activate HI and LO functions (max and min air temperature) - 9. Fan knob with relative operating speed manual/automatic/off - 10. Vent for driver's feet - 11. Vent for passenger's feet.

HEATER/AIR-CONDITIONER UNIT**Removal and Refitting****Removal**

- First of all, disconnect the battery cables, drain off the engine coolant and discharge the gas in the air-conditioning system following the procedures described under the relevant headings.
- Remove the steering column from the fascia following the procedure described under the relevant heading.
- Remove the bottom covering of the fascia on the passenger's side (25) lifting it off the dual locks.
- Remove the covering of the instrument panel (31) lifting it off the dual locks after unscrewing the fixing screws (26).
- Remove the central bottom covering (18) lifting it off the dual locks after unscrewing the fixing screws (15).
- Remove the glove compartment (30) after unscrewing the fixing screws (28).
- Remove the upright covering (27) after unscrewing the fixing screws (29) on both sides of the vehicle.
- Remove the fascia side covering (10) after unscrewing the fixing screws (9) on both sides of the fascia.
- Remove the door to the fuses (11).
- Remove the bonnet opening knob (1) after unscrewing the retaining screw (2).
- Remove the instrument fascia (32) after unscrewing the fixing screws (14) and disconnecting the electrical connections (6).
- Remove the switch panel (17) after unscrewing the fixing screws (19) and disconnecting the electrical connections (16).
- Lift off the heater control knob (22).
- Remove the air-conditioning/heating controls mask (21) lifting it off the dual locks and disconnect the electrical connection (23).
- Unscrew the screws (20) securing the control unit to the fascia covering.
- Remove any loudspeakers (13) on both sides of the fascia after unscrewing the fixing screws (12) and disconnecting the electrical connection.
- Remove the fuse and contactor holder mounting (8) after unscrewing the fixing screws.
- Lift off any controls on the covering (e.g., the headlamp height adjustment control (7) and disconnect the relevant electrical connections.
- Unscrew the screws (24) securing the fascia covering to the framework and remove the covering (5) from the vehicle.
- Unscrew the nut (4) holding the bonnet opening rod (3).



- Disconnect the ventilation duct (1) unscrewing the fixing screws (12).
- Disconnect the demisting duct (2) unscrewing the fixing screws (11).
- Remove the radio mounting box (8) unscrewing the fixing screws (9).
- Disconnect the duct distributing air towards the feet (6) unscrewing the fixing screws (5) and (7). Remove the bonnet opening cable from the framework.

Operations from the bonnet side (Detail B).

- Unscrew the fixing nuts (21). Remove and shift the expansion liquid reservoirs (22).
- Remove the seal clamps (19) and disconnect the delivery and return pipes (17) and (18) for the heater water.
- Unscrew the screws (14) and disconnect the pipes (13) and (16) supplying the evaporator.
- Unscrew the nuts (15) securing the flange.
- Unscrew the nuts (20) securing the heater on the union side.

Operations in the cab.

- Unscrew the nuts (4) and screws (10) and move the framework back together with the heater unit.
- Disconnect the electrical connections from the heater unit and cut the cabling retainer clamps.
- Unscrew the screws (24) securing the heater unit (23) to the cross member (3) (detail C).




Refitting

For refitting, position the fascia covering and retain it at the point shown in detail D. Then continue by carrying out the operations described for removal in reverse order, observing the required tightening torques for the screws and/or nuts. Afterwards, check that:

- the engine coolant is at the right level;
- the gas in the air-conditioning system is at the right pressure;
- the system and components involved in the above procedure work properly.

Figure 16




**553230 "M. MARELLI" TYPE HEATER/
AIR-CONDITIONER UNIT**

Components

1. Strip on A.I. flange - 2. Treated air sensor - 3. Front door hatch - 4. Distribution bushing - 5. Recirculation door - 6. LH air intake box - 7. Cond. drain pipe retaining bracket - 8. Mixing actuator - 9. Rear box - 10. Distribution bushing - 11. Complete distribution door - 12. Strip - 13. Strip - 14. Radiating mass - 15. Wiring harness - 16. Tie rod - 17. Distribution lever - 18. MAX DEF cam - 19. Fan potentiometer - 20. Mixing potentiometer - 21. Control mounting - 22. Knob adapter ring - 23. Prism - 24. Complete microswitch - 25. Control pin - 26. Knob - 27. Cap spring - 28. Cap - 29. Condensation drain pipe - 30. Strip - 31. Condensation drain tub - 32. Control unit - 33. Condensation drain tub strip - 34. Front box - 35. Self-tapping insert - 36. Mixing/foot door lever - 37. Bushing - 38. Transmission - 39. Vent./demist. door lever - 40. Water pipe fixing U-bolt - 41. Distribution cam - 42. Control mounting bracket - 43. Anti-frost sensor - 44. Wiring retainer clamp - 45. Fan strip - 46. Electric fan - 47. Connection cover - 48. Motor mounting - 49. Spacer - 50. Connector bracket - 51. Electronic control - 52. Evaporator - 53. Distribution bushing - 54. Complete distribution door - 55. Evaporator strip - 56. Pipe - 57. OUT O-ring - 58. Expansion valve - 59. OUT O-ring - 60. Fixing screw - 61. IN O-ring - 62. IN O-ring - 63. Pipe passage strip - 64. Pipe strips - 65. A.I. actuator - 66. A.I. door lever - 67. RH air intake box - 68. Tie rod

Figure 17



PROCEDURE FOR EMPTYING AND REFILLING THE AIR-CONDITIONING SYSTEMS WITH R134A REFRIGERANT
R134A refrigerant recovery and refilling station (99305146)

This station has been made to be used on all air-conditioning/heating systems for motor vehicles using R134A gas.

By connecting the station to a refrigerating system the gas it contains can be recovered, cleaned and made ready to be reloaded into the system or be transferred to an external container. In addition, it is possible to see the amount of oil taken from the system, restore it and "empty" the system.

To be operative, the station needs to absorb approximately 3 kg of refrigerant.


For prompt use it is advised to have at least 2 kg of refrigerant in the filler cylinders and to keep the station as level as possible.

NOTE This procedure does not describe the phases of loading and unloading refrigerant to and from external and internal containers or maintenance. Therefore, please refer to the operating and maintenance manual of the appliance.

The station is composed of:

- 1 control panel;
- 2 container to restore any oil recovered when unloading;
- 3 flexible hoses;
- 4 container to collect any oil recovered from the system;
- 5 filler cylinder with graduated scale revolving.


Figure 18



50631

CONTROL FASCIA


Figure 19




50634

Figure 20

FILLER CYLINDER



OIL TANK



50632

Control fascia diagram legend

| | |
|------|--|
| M1 | Low pressure gauge |
| M2 | High pressure gauge |
| M3 | Filler cylinder pressure gauge |
| LOW | Low-pressure valve |
| HIGH | High-pressure valve |
| REF | Refrigerant filler and drain valve |
| V1 | Valve on low-pressure pipe |
| V2 | Valve on high-pressure pipe |
| V3 | Oil injection valve for A/C system |
| V5 | Oil drainage valve |
| V9 | A/C system washing refrigerant service valve |
| I0 | Moisture indicator |
| VS | Safety and drainage valve |
| L3 | Alarm warning light |
| L4 | Maximum level warning light |
| L5 | Minimum level warning light |
| A | Unit process / bottle heater switch |
| LA1 | Unit process indicator light |
| LA2 | Bottle heater indicator light |
| B | Refrigerant process / vacuum process switch |
| LB1 | Refrigerant process indicator light |
| LB2 | Vacuum process indicator light |
| C | Recovery recycle cycle / Filling switch |
| LC1 | Recovery recycle cycle indicator light |
| LC2 | Filling indicator light |
| D | Vacuum / vacuum test switch |
| LD1 | Vacuum indicator light |
| LD2 | Vacuum test indicator light |

Filler cylinder legend

- 1 Pressure values in bar (vertical lines, revolving top cylinder).
- 2 Weight of load in grams (oblique lines, revolving top cylinder) 50 g division between lines.
- 3 Tank level viewer (internal cylinder).

SAFETY STANDARDS



This station is exclusively for professionally trained operators who must be familiar with refrigerating systems, refrigerant gases and the damage pressurized equipment can cause, therefore:




- always wear gloves and goggles when working with refrigerant gases. Contact of refrigerant liquid with the eyes can cause blindness;
- avoid all contact with skin (low boiling point -30°C can cause frostbite);
- never inhale the vapours of refrigerant gases;
- before connecting the station with a system or external container, check that all the valves are closed;
- before disconnecting the station, check that the cycle is over and all the valves are closed. This will prevent dispersing refrigerant gas into the atmosphere;

- never expose the unit or operate it in acidic or wet environments or close to open containers of inflammable substances;
- the unit must operate in places with good ventilation;
- never alter the settings of the safety valves and control systems;
- never use bottles or other storage containers that are not approved and are not fitted with safety valves;
- never load any container over 80% of its maximum capacity;
- never leave the unit powered if it is not to be used immediately. Cut off the mains power supply when it is not planned to use the equipment.

The station is equipped with special fittings to avoid contamination with systems using R12. Do not attempt to adapt this unit for use with R12.

OPERATION FLOW CHART



RECOVERING REFRIGERANT FROM THE VEHICLE SYSTEM

Before starting to disconnect the pipes from the air-conditioner, check whether it is possible to do the repairs without discharging the gas.


If this is not possible, the following operations must be carried out:

- connect the pipe marked **HIGH** under the pressure gauge to the evaporator inlet (the inlet is the one on the

pipe with a smaller diameter (H) connecting the drier filter with the evaporator);

- connect the pipe marked **LOW** under the pressure gauge to the evaporator outlet (the outlet is the one on the pipe with a larger diameter (L) connecting the evaporator with the drier);
- open the valves **V1** and **V2**;
- open the **LOW** and **HIGH** cocks.

Figure 21



52295


- connect the station to the electricity mains (220 V - 50 Hz);
- press the switch **A** (Process Unit) onto position 1
The respective indicator light **LA1** will come on;
- press the switch **B** (Refrigerant Process) onto position 1;
- the respective indicator light **LBI** will come on;
- press the switch **C** (Recovery Recycle) onto position 1.
The recovery and recycling operation will start automatically. The respective indicator light **LCI** will come on to signal the operation in progress.
On completing this operation the unit will automatically stop and the indicator light **LCI** go out. Wait for a few minutes so that any pockets of refrigerant at low pressure remaining in the system can increase their pressure, by absorbing heat, and be able to be recovered. The station will automatically repeat the recovery cycle if the above conditions occur;

- put the switches A, B and C back onto position 0;
- close the **V1**, **V2**, **LOW** and **HIGH** valves.

NOTE If the refrigerant reaches the maximum level (maximum level indicator light L4 on), the recovery cycle must be stopped immediately by pressing switch C onto position 0 and transferring the refrigerant from the filler cylinder to a suitable external bottle.

- Continue the operations following the instructions given on the following pages.

Figure 22



50636

CREATING A VACUUM IN THE SYSTEM

This operation should be carried out if all the repairs have been performed and the system components have been properly refitted. This operation is the phase prior to refilling, therefore proceed as follows:

NOTE Do not run the vacuum cycle when there is even minimal pressure in the station or system.

- Connect the pipes to the specific system connections and open the **V1-V2/LOW** and **HIGH** valves.
- Press the switch **A** (Process Unit) onto position 1. The respective indicator light **LA1** will come on.
- Press the switch **B** (Vacuum Process) onto position 2. The respective indicator light **LB2** will come on.
- Press the switch **D** (Vacuum) onto position 1. The system will automatically start being evacuated and the respective indicator light **LD1** will come on to signal the operation in progress.


After a few minutes of operation (10 at most) if the system has no leaks the indicator light **LD2 VACUUM TEST** will also come on. From this time on, evacuation should be continued for at least two hours to obtain a good evacuation.



The indicator light **LD2 vacuum test** fails to come on if there is a leak. Stop evacuation, eliminate the leak and repeat the evacuation procedure.

- At the end of the time programmed for evacuation, press the switch **D** (vacuum test) onto position 2 and leave the system in this state for 3-5 minutes. The indicator light **LD2 VACUUM TEST** is on if the system has a good seal. The indicator light **LD2 VACUUM TEST** goes out if there is a leak. Eliminate the leak and repeat the evacuation cycle.
- Put the switches **D** and **B** back onto position 0 and proceed with the following phase.

Figure 23




50637

It is possible that at the end of each recovery cycle the station may have recovered lubrication oil from the compressor, which should be drained off into a specific graduated container (1).

- 1 Slowly open the valve **V5** (Oil Discharge).
- 2 When all the oil has been discharged into the container (1) close the valve **V5**.

- 3 Quantify and **record** the amount of oil discharged.
- 4 Eliminate the recovered oil correctly.
This oil cannot be reused.
The same amount of new oil as has been removed must be added to the system.

Figure 24



50638

RESTORING OIL IN THE SYSTEM

If during the recovery and recycle phase, oil from the system has been removed, it must now be replenished:


- take the metering device supplied with the right amount of lubricant for the system concerned, or previously measured;
- connect the metering device (I) to the lubricant injection valve **V3**;
- open the valve **V3** and then carry out the system vacuum phase for a few moments;
- open the valve mounted on the metering device container (I). The oil will be drawn into the system;
- close the valve **V3** and the valve on the metering device container when the required quantity of lubricant has been drawn in;

- disconnect the metering device (I) from the injection valve **V3** and fit the protective cap back on.

NOTE Keep the oil containers well sealed in order to avoid contamination. In particular, remember that oil is extremely hygroscopic.

- never open the oil injection valve **V3** if the system has positive pressure;
- oil should only be injected with a vacuum in the system;
- the oil level must never fall under the suction pipe (air would get into the system).

Figure 25



50639


FILLING THE SYSTEM WITH REFRIGERANT

Before refilling, it is wise to be aware of some important rules:

- know the quantity of refrigerant to use (it is normally written on an adhesive plate affixed on the vehicle);
- the filler cylinder is equipped with a minimum level check that prevents introducing incondensable gas into the system.
This is why the last approx. 600 g of refrigerant it contains cannot be used;
- therefore, before filling, check that the cylinder contains a sufficient quantity for filling (maximum quantity that can be used 3800 g);
- if the pressure inside the filler cylinder indicated on the pressure gauge (2) is greater than as required, which can be seen on the filler cylinder window approx. 10 bar max, discharge the excess pressure through the valve (1) on the pressure gauge assembly to bring it down to the right level, reading the value on the pressure gauge.

NOTE To transfer refrigerant from an external bottle to the filler cylinder and vice versa, refer to the equipment manual.
Considering that the amount of refrigerant depends on its pressure, to know the actual weight it is necessary to turn the outside of the filler cylinder so the line of the diagram matches the level viewer. In this way we can know the exact quantity of refrigerant in the cylinder (starting weight).
When calculating the weight of the refrigerant, in addition to the 600 g that cannot be used, remember to increase the load by approximately 100 g (this is the weight of refrigerant contained in the station-system connecting pipes). The right quantity of refrigerant to introduce into the system will therefore be given by: 600 g + 100 g + (quantity referred to the system capacity).
Always check before filling that the indicator on the "console" shows the refrigerant contains no moisture, in which case the indicator will be bright green. If this is not so, replace the filters in the station as instructed in the equipment manual.

Figure 26



50640

| VEHICLE | COMPRESSOR | R134 COULANT QUANTITY PROVIDED FOR IN SYSTEM | COULANT QUANTITY CONTAINED IN THE PIPINGS (150 cm length) THAT ARE USED FOR RECHARGING | COULANT TOTAL QUANTITY TO BE SET ON CHARGING TOOL | OIL QUANTITY TO BE ADDED INTO SYSTEM AT EACH ND 8 TYPE CHARGING |
|--|----------------------------|--|--|---|---|
| DAILY (8140 engine): WITH CAB, VAN, SPECIAL ITEMS, 6+1 | SC 08 OPT 6650 | 720 g | 100 [g] for low pressure pipe, 100 [g] for high pressure pipe | 1020 g | 30 g |
| DAILY (8140 engine): WITH CAB, VAN, SPECIAL ITEMS, 6+1 | DENSO 10 PA 17 OPT 6652 | 720 g | 100 [g] for low pressure pipe, 100 [g] for high pressure pipe | 1020 g | 40 g |
| DAILY (FIA engine): WITH CAB, VAN, SPECIAL ITEMS, 6+1 | DENSO 10 PA 17 OPT 6652 | 720 g | 100 [g] for low pressure pipe, 100 [g] for high pressure pipe | 1020 g | 40 g |
| DAILY (FIA engine): COMBI | DENSO 10 PA 17 OPT 6652 | 1200 g | 100 [g] for low pressure pipe, 100 [g] for high pressure pipe | 1500 g | 40 g |
| DAILY (FIC engine): WITH CAB, VAN, SPECIAL ITEMS, 6+1 | DENSO 10 PA 17 OPT 6652 | 440 g | 100 [g] for low pressure pipe, 100 [g] for high pressure pipe | 750 g | 40 g |


When the cylinder contains the necessary quantity for filling (both pipes must already be connected to the system connectors since the vacuum operation has already been performed), proceed as follows:

- close the **LOW** valve, keep the **HIGH** and **VI - V2** valves open;
- press the switch **B** (Refrigerant process) onto position 1, the indicator light **LBI** will come on;
- press the switch **C** (Charge) onto position 2, the respective indicator light **LC2** will come on and refrigerant will flow from the station into the system;

NOTE When filling, if the level of refrigerant in the cylinder falls under the required quantity the system will stop and the Minimum Level indicator light (L5) will come on.

- having loaded 200 ÷ 500 g of refrigerant, depending on the size of the system, stop filling by moving the switch **C** (Charge) onto position 0;
- check the system is properly sealed with the electronic leak finder;
- complete filling the system until the **pre-calculated residual weight** in the cylinder is reached; (Residual weight = Total weight - System capacity weight)
- complete filling, move the switches **C - B** and **A** onto position 0 (A had been moved for the vacuum). Check again there is no leakage;
- close the **HIGH** valve.

Figure 27



50641

CHECKING THE PRESSURES IN THE SYSTEM

After filling, leave the pipes connected and carry out the following check:

- close the **HIGH** and **LOW** valves, **V1** and **V2** open;
- turn on the engine, switch on the air-conditioner and check on the pressure gauges **M1** and **M2** that the pressures correspond, normally: low pressure no less than 1 bar, high pressure 15 ÷ 18 bar, depending on the system specifications.


OPERATIONS PRIOR TO DISCONNECTING THE STATION FROM THE SYSTEM

Always observing the above safety rules, carry out the following operations:

- check that all the valves are closed: **LOW - HIGH, V1 - V2**;
- disconnect the pipes of valves **V1 - V2** and put the caps back onto the system valves;
- Check the system again with the leak finder.

NOTE Normally, with the air-conditioner switched on, air should come out of the vents at a temperature lower than 5°C and after a period of operation to stabilize the temperature of the ducts.

Figure 28



50642

LEAK FINDER FOR AIR-CONDITIONING SYSTEMS WITH HFC R134A (9905147)

Tool L-780A makes it possible to identify leakage of HFC 134A gas from the system extremely accurately in the order of 3.3 g a year with the switch on maximum sensitivity.

This instrument requires no settings, the operator only needs to select the desired sensitivity.

The instrument warns the operator of any gas leakage with a buzzer and a LED that flashes in proportion to the concentration of gas.

In addition, the LED indicates the battery is flat if it goes out.

Operating temperature is between 0°C and 50°C.


The instrument is equipped with a flexible probe to reach particularly difficult fittings or parts.

The two levels of sensitivity are:

- low sensitivity = 16.5 g/year;
- high sensitivity = 3.3 g/year.

NOTE Before checking vehicles, wait for the engine to cool, the hot parts can falsify the test.

Figure 29




50643

REPAIRS

**553248 Air-conditioner unit control unit
Removal - Refitting
Removal**

Figure 30




52296

- Turn over the bottom door on the passenger side (1).
- Disconnect the electrical connections (2) and (3).
- Unscrew the fixing screws (4) and remove the control unit (5).

Refitting
Refit the control unit by carrying out the operations described for removal in reverse order.

**ELECTRONIC CONTROLLER
Removal - Refitting
Removal**

Figure 31




52297

- Turn over the bottom door on the passenger side.
- Disconnect the electrical connections (1) and (2).
- Unscrew the fixing screws (3) and remove the electronic control (4).

Refitting
Refit the control unit by carrying out the operations described for removal in reverse order.

**ANTI-FROST SENSOR
Removal - Refitting
Removal**

Figure 32




52298

- Remove the glove compartment by following the procedure described above.
- Disconnect the electrical connection (1), remove the anti-frost sensor (2) through the slot A illustrated in the detail after turning over the bottom door on the passenger side.

Refitting
Refit the anti-frost sensor by carrying out the operations described for removal in reverse order.

553237 ELECTRIC FAN**Removal - Refitting****Removal**

Figure 33



52299


- Turn over the bottom door on the passenger side, following the procedure described above.
- Disconnect the electrical connections (1), (2) and (3).
- Unscrew the screw (7) and remove the connector bracket (8) to access the fixing screw (4).
- Unscrew the fixing screw (4), remove the electric fan (5) and the gasket (6).

**Refitting**

Refit the electric fan by carrying out the operations for removal in reverse order, taking care to replace the gasket (6) if it is damaged.

553215 HEATER RADIATOR**Removal - Refitting****Removal**

Figure 34



52300

- Drain off the engine coolant.
- Unscrew the fixing screws and move the expansion tub to one side so as to be able to access the heater coolant inlet/outlet couplings.



- Remove the seal clamp.
- Disconnect the pipes from the heater.
- Remove the fascia covering, following the procedure described above, so as to access the radiator fixing points.
- Unscrew the screw (2) securing the stand anchoring the pipe (3), unscrew the screw (4) securing the pipes to the heater.
- Extract the radiator (5) from the heater and remove the seals (1) and (6).

**Refitting**

Refit the radiator by carrying out the operations for removal in reverse order, taking care to replace the seals (1) and (6) if they are damaged.

553252 MIXING ACTIVATOR**Removal - Refitting****Removal**

Figure 35



52301


- Remove the fascia covering, following the procedure described above.
- Disconnect the electrical connection (3) from the activator, (2) located at the point shown in the figure.
- Unscrew the fixing screws (1) and remove the activator (2) from its seat.

**Refitting**

For refitting, carry out the procedure described for removal in reverse order.

553253 AIR INTAKE ACTUATOR**Removal - Refitting****Removal**

Figure 36




- Remove the glove compartment, following the procedure described above.
- Disconnect the electrical connection (1) from the actuator, located at the point shown.
- Unscrew the fixing screws (3) and remove the actuator (2) from the heater unit.

Refitting

Refit the unit by carrying out the procedure described for removal in reverse order, checking the cogged sector couples correctly.

553241 TREATED AIR SENSOR**Removal - Refitting****Removal**

Figure 37



- Remove the fascia covering and partially remove the heater unit, without taking it out of the vehicle, following the procedure described above, to access the sensor.
- Disconnect the electrical connection (2), lift up and remove the sensor (1) from the heater unit.


Refitting

For refitting, carry out the procedure described for removal in reverse order.

55323 I EVAPORATOR UNIT

Removal - Refitting Removal

Figure 38



- Remove the heater/air-conditioner unit, following the procedure described in the above figures.
- Disconnect the electrical connections from the actuators and sensors.
- Lift up and remove the temperature sensors (1) and (11).
- Remove the adhesive strip from the duct connection bay, unscrew the fixing screws (10) and take out the moulding (9) complete with drain pipe and control unit.
- Unscrew the screws securing the pipe (6), the screw (8) securing the bolt (7) and carefully remove the radiator (5) from the heater.
- Unscrew the fixing screws (4) and separate the front (3) and rear (2) boxes.
- Remove the air duct gasket (13).
- Take out the evaporator unit (12) with the expansion valve and pipe.




Refitting

For refitting, carry out the procedure described for removal in reverse order, taking care to replace the radiator and evaporator gaskets if they are damaged.

553233 EXPANSION VALVE AND EVAPORATOR PIPE

Removal - Refitting

Figure 39



52305

- Remove the evaporator unit, following the procedure described above.
- Remove the seals (1) and (4) from the evaporator (2) from the pipe (3), if they are damaged replace them when refitting.
- Unscrew the fixing screws (10) and remove the expansion valve (7), O-rings (5), (6), (8), (9) and the pipe (3).

Refitting



For refitting, carry out the procedure described for removal in reverse order, taking care to replace the radiator and evaporator gaskets if they are damaged. Check the state of wear of the seals. They need to be replaced if they are damaged or worn.

553239 COMPRESSOR


Specifications and data

| COMPRESSOR | | |
|--------------------------|-----------------|-------------------------|
| Type | | SCO 8 C |
| Displacement | cm ³ | 80 |
| Stroke | mm | 33 |
| Rev. No.: | | |
| Max | RPM | 7800 |
| Refrigerant | | R 134 a (ecological) |
| Oil type | | ND - OIL 8 |
| Refrigerant amount | kg | 0.72 |
| Oil amount | | 80 ± 20 cm ³ |
| Airtightness test | | 3.14 MPa |
| Pressure test | High | 530 MPa |
| | Low | 250 MPa |
| ELECTROMAGNETIC FRICTION | | |
| Torque | min | 26 Nm |
| Voltage rating | V | 12 |
| Absorbed pressure | W | max 35 |
| Weight | kg | 1.5 |
| Belt | | 4k-type |
| Pulley actual diameter | mm | 105 |

Compressor Removal - Refitting

Removal

Figure 40



52306

- Drain the air-conditioning system, following the procedure described under the relevant heading.
- Unscrew the fixing screws (3) and (5) and remove the inlet (2) and outlet (1) pipes from the compressor.
- Slacken the drive belt, following the instructions given under the relevant heading.
- Disconnect the electrical connection (4), unscrew the fixing screws (6) and remove the compressor (7) from the vehicle.

Refitting




For refitting, carry out the procedure described for removal in reverse order. Check the state of wear of the seals. They need to be replaced if they are damaged or worn.

553261 POLLEN FILTER

Removal - Refitting

Removal

Figure 41



52307

- From inside the engine bay, lift up the protective cover (1) and remove the pollen filter (2).

Refitting


For refitting, carry out the procedure described for removal in reverse order.

553235 THREE-LEVEL PRESSURE SWITCH AND DRIER FILTER

Removal - Refitting

Removal

Figure 42



52308

- Drain the air-conditioning system, following the procedure described above.

- Disconnect the electrical connection (1) of the three-level pressure switch (3).
- Unscrew the fixing screw (2) and remove the pipe (4), unscrew the fixing screw (5) and remove the pipe (6).
- Unscrew the screw (7) and loosen the bracket (8).
- Take the drier filter (9) out of its seat.

Refitting


For refitting, carry out the procedure described for removal in reverse order, checking the soundness and correct position of the seals on the pipes. They need to be replaced if they are damaged or worn.

553232 CONDENSER

Removal - Refitting

Removal

Figure 43



52309

- Partially carry out the procedure for removing the engine until you can access the condenser, which is located in front of the radiator.
- Drain the air-conditioning system, following the procedure described above.
- Unscrew the screw (2) and remove the pipe (1), unscrew the screw (6) and remove the pipe (5).
- Unscrew the fixing screws (3) and remove the condenser (4).

Refitting

For refitting, carry out the procedure described for removal in reverse order, checking the soundness and correct position of the seals on the pipes. They need to be replaced if they are damaged or worn.

DIAGNOSTIC

FAILURES OF THE ELECTRIC TYPE (Marelli air-conditioner)

Self-diagnosis

Suitable control logics enable the control unit to memorise and to display certain system failures (constant and/or intermittent). In response to these failures, the control unit controls system operation by replacing the detected anomalous values with proper recovery values which guarantee minimum system operation.

When failure is detected, the control unit displays the message "Error Cli" on the instrument panel.

- To have a preliminary information, it is possible to display any detected failure on the instrument panel by following a special procedure.
- For a more complete and in-depth diagnosis it is however indispensable to use the service network testers, i.e.: MODUS (release 2.1) and IWT (Release 1.4).


NOTE Fan electric module control is not provided in self-diagnosis, it can therefore be detected with the available release only.

Diagnosis by error codes

To find the failing component proceed as follows:

- set temperature setting knob to "HI";
- set fan speed control knob to "0";
- set air distribution knob to "MAX DEF".


Figure 44



75450

1 Required temperature setting knob - 2 Fan speed control knob - 3 Air distribution knob - 4 "ECON" switch - 5 Air recycling switch


Figure 45



- Set key switch to service position (+15)

0002774


Figure 46



- Operate within 10 seconds, the fan speed control knob with the following sequence: "0" ⇒ "AUTO" ⇒ "0" ⇒ "AUTO" ⇒ "0".

0002784

Figure 47




- Error code is now displayed on instrument panel. Other errors, if any, are displayed every 3 seconds.

0002794

Error codes

Figure 48




0002794

These are the error codes that can appear on the display of the panels during diagnosis in place of "Cli" .

| | |
|----|---|
| 12 | Blown air sensor circuit short to ground |
| 14 | Blown air sensor circuit open or short |
| 32 | Outside air temperature sensor positive short to ground |
| 34 | Outside air temperature sensor circuit open or short |
| 42 | Inside air temperature sensor positive short to ground |
| 44 | Inside air temperature sensor circuit open or short |
| 52 | Evaporator temperature sensor positive short to ground |
| 54 | Evaporator temperature sensor circuit open or short |
| 65 | Air mixing ratio-motor malfunctioning |
| 82 | Required temperature potentiometer positive short to ground |
| 84 | Required temperature potentiometer circuit open or short |
| 92 | Ventilation control potentiometer positive short to ground |
| 94 | Ventilation control potentiometer circuit open or short |
| B2 | Air mixing potentiometer signal positive short to ground |
| B4 | Air mixing potentiometer signal circuit open or short |
| D5 | Fan control electronic module malfunctioning |
| E2 | Potentiometer powering 10 ECU pin positive short to ground |
| E3 | Potentiometer powering 10 ECU pin short to positive |
| F6 | Supply voltage higher than max. limit |
| F7 | Supply voltage lower than min. limit |

Diagnosis by IWT, MODUS and UNITESTER

Figure 49



61545

The above figure shows 99331048 ER1 + ER2 tool connection to ventilation and heating system ECU and to IWT. Detail (A) shows IVECO TESTER connection.

NOTE IWT can measure lines on control unit wiring and pin-out.
With MODUS, this measurement can only be performed using UNITESTER.

Diagnosis by IWT

Preliminary operations

IWT software memorises the list of components and the relevant failures and enables their reading on the particular screen displays. It also enables to analyse for every type of failure the measurement in Kohm or Mohm for every component circuit and it displays in any case the optimum operation parameters.

It also displays operation procedure by the **REPAIR** function.

Repair manual using IWT will be added in next edition.

It is however important to remind that before proceeding with troubleshooting diagnosis, the following three main factors shall be checked:

I. Identification:

Check and prove control unit identity consistency between vehicle and IWT data.

If the control unit is not of the preset type, "**not compatible control unit**" message is displayed.

Therefore, diagnosis cannot be correct.

Figure 50

| IDENTIFICATION | | PARAMETERS | FAILURES |
|---|--------------|-------------------------|-----------------|
| 35C13/P | | MARELLI AIR-CONDITIONER | AIR-CONDITIONER |
| MARELLI SOFTWARE | 509300500000 | | ↑ |
| MARELLI SOFTWARE DATE | 04-12-97 | | |
| IVECO H.W. | 0500326588 | | |
| IVECO H.W. DATE | 02-05-97 | | |
| <div style="text-align: right;">↓</div> | | | |


61546

2. Failures:

If failures are found, follow repair procedure shown on the screen display using the proper icons.

If no failure is found, perform check by screen display "PARAMETERS" (see point 3).

Figure 51




61547

3. Parameters:

Check for system response by operating vehicle controls until finding the control which gives no signal on IVWT screen display. The following parameters are also checked:


COMPRESSOR, RECYCLE, MAX DEF

Figure 52




61548


Figure 53



61549

FAILURE OF THE MECHANICAL TYPE





(continued)

4.2 STRANGE NOISE WITH FRICTION CONNECTED



Compressor fixing elements are in good conditions.

- NO →

Check and tighten compressor screws and bolts to the prescribed torque.

YES
↓

Serviceable electromagnetic friction.

- NO →

Check whether failure is due to mechanical or electrical troubles and operate accordingly.

YES
↓

Regular compressor oil level.

- NO →

Check oil level and refill if required.

YES
↓

Serviceable compressor.

- NO →

Drain out system and replace compressor.

4.3 STRANGE NOISE WITH FRICTION DISCONNECTED OR VIBRATIONS



Proper clearance between front plate and electromagnetic friction pulley.

- NO →

Check clearance, disconnect compressor if required and adjust clearance

YES
↓

Serviceable electromagnetic friction power system.

- NO →

Check electric system.

553210 "MARELLI" TYPE HEATER**Removal - Refitting****Removal**

For removing/refitting the heater unit, carry out the procedure described on pages 13 and 14 concerning heater/fan unit removal and refitting, taking into consideration just the common parts: dashboard covering, instrument panel, control, air outlets, refrigerant tank and pipes, radio mounting box and cross member.

Remove the control panel shown in the figure before performing the following removals:



- withdraw air recycle control selector (2);
- take off the heater control panel knob (3);
- unscrew screw (4) set behind the panel;
- disconnect connection (6) and remove mask (5) by removing it from velcro (⇒) fixing;

- remove the two screws (1) fixing controls to dashboard;
- then remove the complete unit (7) including controls (6) from the passenger compartment.

**Refitting**

For refitting, carry out the procedure described for removal in reverse order and observing the prescribed tightening torque for screws and/or nuts. When refitting procedure is over, check the following:

- proper engine coolant level;
- regular operation of system and components involved in the described procedure.

Figure 54

60727

553213 ELECTRIC FAN**Removal - Refitting****Removal**


- Remove lower covering (1) on passenger side from velcro fixings;
- unscrew the three M4x12 fan fixing screws (3);
- disconnect electrical connections (2);
- remove motor support (4) including the fan;

- remove frame (7) and connector (8) bracket fixings (6);
- remove fan (5) after removing both M5x16 motor fixings (9).

**Refitting**

For fan refitting, carry out the procedure described for removal in reverse order. Replace seal if damaged.

Figure 55



60726

553218 HEATER CONTROL CABLES


Removal - Refitting



Removal

- First of all disconnect battery cables;
- remove dashboard lower covering (14) on passenger side from velcro fixings (↔) and release it from hinges;
- remove dashboard (2) covering from velcro fixings after unscrewing fixing screws (1);
- remove switch panel (8) after unscrewing fixing screws (7) and disconnecting electrical connections (4);
- lift off heater control knob (11);
- unscrew screw (10) set behind knob (11);
- detach air recycle cursor (9);
- remove control mask (12) from velcro fixings after disconnecting electrical connection (13).
- To facilitate control unit removal from compartment proceed as follows:
- unscrew the two screws (19) fixing the unit to the dashboard;
- remove control unit from compartment (3) set neat multiple meter;
- remove the three cables from control unit by releasing them from clamps (15) and pins (16). (Detail A);
- remove cables from heater unit (Details B-C-D) by releasing them from clamps (5) (17) and pins (6) and (18).


Figure 56



Refitting

For refitting, carry out the procedure described for removal in reverse order. Check for matching between doors and control knobs.

Figure 57



553210 HEATER UNIT Components

1. Complete distribution door - 2. Rear box - 3. Pipe strip - 4. RH air intake box - 5. Tie rod - 6. Distribution bushing - 7. Strip on A.I. flange - 8. Doors - 9. LH air intake box - 10. Recycle air intake control transmission - 11. Bowden clip - 12. A.I. door lever - 13. Wiring - 14. Mixing flexible transmission - 15. Mixing control lever - 16. Recycle air intake lever - 17. Control pin - 18. Spring - 19. Cap - 20. Cap, cap spring - 21. Complete distribution - temperature knob - 22. Knob prism - 23. Recycle air intake cursor - 24. Clamp - 25. Control mounting - 26. Light guide cable - 27. Connecting rod - 28. I.A.- REC flexible transmission - 29. Distribution control lever - 30. Switch - 31. Distribution flexible transmission - 32. Connection cover - 33. Motor mounting - 34. Connector bracket - 35. Frame bracket - 36. Electric fan - 37. Self-tapping insert - 38. Mixing/foot door lever - 39. Transmission - 40. Distribution cam - 41. Mixing bowden clamp - 42. Control fixing bracket - 43. Mixing/foot door lever - 44. Vent/def door lever - 45. Wiring retainer clamp - 46. Fan strip - 47. Water pipe fixing U-bolt - 48. 4-speed resistor - 49. Bushing - 50. Front box - 51. Complete distribution door - 52. Distribution bushing - 53. Radiating mass - 54. Side gasket - 55. Gasket on tub - 56. Water pipe assembly. - A. Flexible transmission.

60920

Passenger's compartment heating and ventilation system

| | Page |
|---|------|
| SAFETY STANDARDS TO OBSERVE WHEN WORKING ON VEHICLES EQUIPPED WITH THE AIR-BAG SYSTEM | 53 |
| PASSENGER'S COMPARTMENT HEATING AND VENTILATION SYSTEM | 53 |
| <input type="checkbox"/> General | 53 |
| VENTILATION | 53 |
| <input type="checkbox"/> Description | 53 |
| FUNCTIONAL DIAGRAM AND MAIN HEATING AND VENTILATION SYSTEM COMPONENTS | 54 |
| HEATING AND VENTILATION SYSTEM | 54 |
| <input type="checkbox"/> Description | 54 |
| <input type="checkbox"/> Air-conditioning | 54 |
| <input type="checkbox"/> Heating | 54 |
| ADDITIONAL COOLING SYSTEM CONTROLS AND AIR VENTS LAYOUT | 55 |
| DESCRIPTION | 55 |
| ADDITIONAL HEATING SYSTEM CONTROLS | 56 |
| DESCRIPTION | 56 |
| ADDITIONAL COOLING UNIT | 57 |
| <input type="checkbox"/> Removal - Refitting | 57 |
| <input type="checkbox"/> Removal | 57 |
| <input type="checkbox"/> Refitting | 57 |
| ADDITIONAL HEATER UNIT | 58 |
| <input type="checkbox"/> Removal - Refitting | 58 |
| <input type="checkbox"/> Removal | 58 |
| <input type="checkbox"/> Refitting | 58 |
| ADDITIONAL HEATER CIRCUIT ENABLING SOLENOID VALVE | 59 |
| <input type="checkbox"/> Removal - Refitting | 59 |
| <input type="checkbox"/> Removal | 59 |
| <input type="checkbox"/> Refitting | 59 |

SAFETY STANDARDS TO OBSERVE WHEN WORKING ON VEHICLES EQUIPPED WITH THE AIR-BAG SYSTEM



Before doing any work, you MUST observe the SAFETY rules given in section 10 "Steering system"

PASSENGER'S COMPARTMENT HEATING AND VENTILATION SYSTEM

NOTE The following pages describe the heating and ventilation system variations for COMBI versions with OPT. 6652 - 6658.

General

Purpose of the heating and ventilation system is to enhance comfort inside the cab as regards the following parameters:

- temperature and relative humidity of outside air;
- temperature and relative humidity in the cab.

The system subjects the air to thermodynamic transformations that affect its temperature, relative humidity and purity. This is accomplished through the following functions:

- ventilation, i.e.: air taken from the outside (therefore with temperature and humidity of the surrounding environment) is blown into the cab;
- air-conditioning, i.e.: air cooling and dehumidification, with the possibility of heating it afterwards as preferred in order to change temperature and humidity in the cab.






VENTILATION Description


The ventilation function provides the intake of outside air, purified from pollen and dust through a proper filter provided for the purpose, or air recirculation inside the passenger's compartment.

The system consists of the following:

- heater / heater fan unit, set under the driver's panel covering that also includes a part of the heating and ventilation system components.
- additional heater fan, adjustable at different speeds to provide air flowing inside the passenger's compartment under whatever conditions of use.
- air ducts (fresh air intake and air recirculation).
- additional air heater, set at the base of the last rear seat row.

Figure 58

-  Inlet air
-  Cool air
-  Warm air
-  Conditioned air
-  Air flowing out the vehicle



PASSENGER'S COMPARTMENT VENTILATION DIAGRAM

HEATING AND VENTILATION SYSTEM

Description

This is accomplished by combining an air-conditioning system with a heating system.

This integration enables to change temperature and relative humidity inside the passenger's compartment.

Air-conditioning

Air-conditioning is accomplished by taking advantage of the power of certain "cooling" gases to lower temperature considerably at their expansion stage, thereby enabling to absorb heat from the passenger's compartment.

This condition is obtained by two different pressure levels (high pressure when coolant is at liquid state and low pressure when coolant is at gaseous state) that are established and maintained during system operation.

Heating

Heating is implemented through a radiator, located in the heater unit, where engine coolant flows.


Special doors let air flow through the radiator only when the heating function is activated.

The main heating and ventilation system components are the following:

- compressor (4);
- condenser (1);
- drier filter (2);
- three-level pressure switch (3);
- expansion valve (13);
- evaporator (12);
- heater/heater fan unit (5);
- pollen filter (14);
- cooler/heater fan unit (8-9) set in the rear area of the passenger's compartment;
- passenger's compartment conditioning circuit enabling solenoid valve (6);
- additional cooler expansion valve;
- heater/additional heater fan unit (10-11), set in the rear area of the passenger's compartment;
- additional heater circuit enabling solenoid valve (15);


FUNCTIONAL DIAGRAM AND MAIN HEATING AND VENTILATION SYSTEM COMPONENTS

Figure 59



A. Coolant inlet to heater - B. Coolant outlet from heater - C. Coolant delivery to additional heater - D. Coolant return from additional heater - E. Coolant return to engine - H. Heating and ventilation system high pressure circuit - L. Heating and ventilation system low pressure circuit - W. Engine coolant circuit for passenger's compartment heating - V. Ventilation flow.
 1. Condenser - 2. Drier filter - 3. Three-level pressure switch - 4. Compressor - 5. Heater/heater fan unit - 6. Solenoid valve - 7. Expansion valve - 8. Additional cooler fan - 9. Additional heater fan - 10. Additional heater - 11. Additional heater fan - 12. Cooler - 13. Expansion valve - 14. Pollen filter - 15. Solenoid valve.

86414

ADDITIONAL COOLING SYSTEM CONTROLS AND AIR VENTS LAYOUT**Figure 60**

1. Passenger's compartment air intake - 2. Adjustable air vents - 3. Additional cooling system control selector

DESCRIPTION


The additional cooling system integrates the basic air conditioning system and implements air cooling and distribution to the passenger's compartment area.

This system can therefore be activated just when the main air conditioning system is working yet. To start cool air distribution to the passenger's compartment, use selector (3) set at the end of the upper duct.

Selector controls additional cooling circuit enabling valve opening and heater fan speed.

Passenger's compartment air recovered through air intake (1) is conveyed by the heater fan through the additional cooler, it is then cooled, forced into ducts and distributed through the adjustable air vents (2).

86415

ADDITIONAL HEATING SYSTEM CONTROLS**Figure 6I**

86416

I. Additional heater on button - 2. Additional heater circuit enabling solenoid valve - 3. Additional heater unit - 4. Heater fan - 5. Coolant return pipe - 6. Coolant delivery pipe.

DESCRIPTION

The passenger's compartment additional heater unit (3) is located under the last passenger seat row and can be turned on just with engine running and cab heater operating in "heating" mode.

The additional heater is activated through button (1) set on the instrument panel.

This button controls solenoid valve (2), that deviates the return pipe flow from cab heater to additional heater (3) and heater fan (4) that warms and drives air from the passenger's compartment through the radiator. Heater fan revs cannot be adjusted.


ADDITIONAL COOLING UNIT Removal - Refitting



Removal


Place the vehicle on pit or lift taking the required safety precautions.
Disconnect battery negative and positive terminals.
Drain out coolant from the cooling system as described in the relevant section of this Manual.

Figure 62




- Loosen the fastening screws (1) and remove the additional cooling unit protection cover (2).

Figure 63



- Loosen connections and disconnect delivery (1) and return (2) pipes.
- Loosen the fastening screws (3) and remove the flange (4), withdrawing it from pipes.

Figure 64



- Disconnect the electrical connection (2) and release cables from anchoring clip (1).
- Disconnect power cable electrical connection (4) and release cables from anchoring clips.
- Remove the sealant bead (6), loosen the fastening screws and remove cool air distribution duct cover (7).
- Loosen the fastening screws (3), and remove the cooling unit (5) from the wall.
- Turn with extreme care the whole cooling unit to make the delivery and return pipes come out of the slot on the floor. Then, remove the unit from the vehicle.




Refitting

For refitting, reverse the removal procedure and top up coolant as described in the relevant section of this Manual. Check for regular operation of the components involved in the above described procedure.

ADDITIONAL HEATER UNIT Removal - Refitting


Figure 65



Removal

- Release the anchoring clips (1) and remove rear seat lower side upholstery (2).
- Loosen the fastening screws (3) and remove the additional heater rear protection (4).

Figure 66



Set the container for collecting engine coolant near the additional heater delivery and return pipes.

- Disconnect the heater fan power cable electrical connection (3) and release it from the anchoring clips, if any;
- Loosen clamp (7) and disconnect the additional heater engine coolant delivery pipe (6). Plug the pipe end properly to prevent leaks;
- Loosen clamp (5) and disconnect the additional heater engine coolant delivery pipe (4). Plug the pipe end properly to prevent leaks;
- Loosen the fastening screws (1) and remove the additional heater (2) from the vehicle.



Refitting


For refitting, reverse the removal procedure and top up engine coolant as described in the relevant Section.

ADDITIONAL HEATER CIRCUIT ENABLING SOLENOID VALVE

Removal - Refitting

Set the vehicle on level ground taking the required safety precautions.
Disconnect battery negative and positive terminals.
Prepare a proper container to collect engine coolant.

Figure 67



86422

Set the container for collecting engine coolant near the additional heater delivery and return pipes.



Removal

- Release the anchoring clips and move aside the expansion tank breather pipe (2) to clear the work area.
- Disconnect the additional heater circuit enabling solenoid valve (9) power cable electrical connection (1);
- Loosen clamp (11) and disconnect coolant return pipe (10) to engine;
Plug the pipe end properly to prevent leaks;
- Loosen clamp (8) and disconnect coolant return pipe (7) from cab heater;
Plug the pipe end properly to prevent leaks;

- Loosen clamp (6) and disconnect coolant delivery pipe (5) to additional heater;
Plug the pipe end properly to prevent leaks;
- Loosen clamp (3) and disconnect coolant return pipe (4) from additional heater;
Plug the pipe end properly to prevent leaks;



Refitting

For refitting, reverse the removal procedure and top up engine coolant as described in the relevant Section.

SECTION 13

Scheduled maintenance

| | Page |
|---|------|
| MAINTENANCE | 3 |
| <input type="checkbox"/> Table of maintenance services | 3 |
| 8140 ENGINE VEHICLES | 3 |
| <input type="checkbox"/> Inspection and/or maintenance interventions .. | 4 |
| <input type="checkbox"/> Extra plan operations | 4 |
| FIA ENGINE VEHICLES | 5 |
| <input type="checkbox"/> Inspection and/or maintenance interventions .. | 5 |
| <input type="checkbox"/> Extra plan operations | 6 |
| FIC ENGINE VEHICLES | 7 |
| <input type="checkbox"/> Inspection and/or maintenance interventions .. | 8 |
| <input type="checkbox"/> Extra plan operations | 8 |
| DIAGRAM OF CHECK AND/OR MAINTENANCE POINTS | 9 |
| MAINTENANCE OPERATIONS | 10 |

MAINTENANCE

Table of maintenance services

The Extra Plan operations (designated with the letters EP) are complementary to standard services (designated with letter M for Maintenance).

They are maintenance operations to be carried out at regular time or mileage intervals and concern optional components that are not present on all models.

Important! The correlation between kilometres and months only applies in cases where the distance travelled by the vehicle corresponds roughly to the specified average annual mileage. This is indicated only in order to suggest a hypothetical maintenance programme. Note that the time intervals specified for Extra Plan operations (designated by letter T for Time) are to be adhered to regardless of the actual mileage covered.



The kilometre frequency for engine lubrication is in relation to a percentage of sulphur in diesel of under 0.5%.

NOTE: If using diesel with a percentage of sulphur above 0.5%, the oil-change frequency has to be halved.

Use engine oil: **ACEA B5 (Urania Daily)**
ACEA E3/E5 (Urania LD5)

To schedule the work, keep to the following chart:

8140 ENGINE VEHICLES

| Engine Oil | Engines Type | Type of Usage | Standard Services | | | Extra Plan | Time Operations | | | |
|--|---|-------------------------------------|---------------------------------------|---------------------------------------|---|--|--|--|------------------|------------------|
| | | | EO | M1 | M2 | EPI | T1 | T2 | T3 | T4 |
| ACEA B5 Urania Daily ⁽¹⁾ ACEA E3/E5 Urania Turbo LD5 | Engine 8140.63 PC/NA (Pre-combustion chamber) | Mileage less than 40,000 km/year | Every 10,000 km or 200 hours | Every 30,000 km or 600 hours | Every 90,000 km or 1,800 hours | Every 120,000 km or 2,400 hours | Every year at the start of spring | Every year at the start of winter | Every 2 years | Every 3 years |
| | | Mileage more than 40,000 km/year | Every 7,500 km or 150 hours | | | | | | | |
| | Engines 8140.43C ID/TCA 8140.43S ID/TCA | | | | | | | | | |

⁽¹⁾ IVECO recommend **Urania Daily** for benefits in terms of "fuel economy". IVECO have already introduced this lubricant with new vehicles



- Average speed calculated at 50 km/h
- The fuel filter of the 8140.43R/B/S/N engines (common rail) must be replaced when the warning light on the instrument panel comes on. Every 30,000 km if there is no signal.
- If fuel containing a percentage of sulphur higher than 0.5% is used, the mileage for changing the engine oil must be halved.
- In the case of very low mileage or anyhow under 30,000 km/year, the engine oil and filter must be changed every 12 months.
- In the case of mileage under 40,000 km/year, the gearbox and axle oil must be changed at least every three years.

Inspection and/or maintenance interventions (8140 engine vehicles)

| Type of intervention | EO | Engine 8140.63 PC/NA (Pre-combustion chamber) | M1 | M2 |
|---|---|--|---------------------------------|-----------------------------------|
| | Mileage less than 40,000 km/year | Every 10,000 km or 200 hours | Every 30,000 km or 600 hours | Every 90,000 km or 1,800 hours |
| | Mileage more than 40,000 km/year | Every 7,500 km or 150 hours | | |
| LUBRICATION, CHANGING OIL, FILTERS AND CHECKING FLUIDS | | | | |
| 1 | Changing engine oil | • | • | • |
| 1 | Changing engine oil filter | | • | • |
| 2 | Changing fuel filter | | • | • |
| 3 | Checking hydraulic brake system fluid level | | • | • |
| 4 | Changing fuel pre-filter | | | • |
| CHECKS IN THE ENGINE BAY | | | | |
| • | Checking state of auxiliary drive belts | | • | |
| • | Changing auxiliary drive belts ⁽¹⁾ | | | • |
| • | Changing timing belt ⁽¹⁾ | | | • |
| • | Changing pre-combustion chamber glow plugs | | | • |
| CHECKS UNDER THE VEHICLE | | | | |
| 7 | Checking steering box rack covers | | • | • |
| 8 | Checking wear of brake discs and shoes | | • | • |
| 6 | Cleaning rear axle oil breather | | | • |
| 7 | Checking steering column, articulation and linkage | | | • |
| 9 | Checking steering box fixing | | | • |
| 10 | Checking universal joints and propeller shaft fixing | | | • |
| CHECKS IN THE CAB | | | | |
| • | Checking parking brake travel | | • | • |
| EXTERNAL CHECKS | | | | |
| 11 | Checking headlight adjustment | | | • |
| DIAGNOSTICS | | | | |
| • | Check-up engine EDC system with MODUS-IT 2000 (vehicles with common rail injection system) | | | • |
| ON-ROAD TESTS | | | | |
| • | Functional testing on the road | | • | • |

Extra plan operations (to be carried out possibly in combination with maintenance service)**EPI EVERY 120,000 km**

- Change engine oil
- Rear axle differential oil changing procedure

TI EACH YEAR - especially in early springtime

- Check state of pollen filters.
In the case of low mileage, change the filters once a year, early each spring.

T2 EACH YEAR - before the winter season

- Check coolant density.
- Check pre-combustion chamber glow plug operation.
- Change supplementary heater fuel filter.

T3 EVERY TWO YEARS

- Change brake fluid and bleed brake fluid system.

T4 EVERY THREE YEARS - even if there is no indication of the air filter clogging

- Change cartridge and clean air filter container.
- Change engine coolant.

The timing system, alternator and air-conditioning compressor driving belts must be changed on reaching the first time/mileage limit of the following: 90,000 km-1800 hours-4 years.

In harsh conditions of use (dusty and/or hot), the timing system driving belt must be changed every 60,000 km.

(1) Replace every four years. Replace every 60,000 km under harsh conditions of use (dust and/or heat).

(*) If the "clogged filter" warning lamp lights up on the instrument panel, the filter must be replaced before the programmed replacement interval

FIA ENGINE VEHICLES

| Engine-oil | Engine | Standard Services | | Extra plan | | Time Operations | | | |
|--|------------|---------------------------------------|--|--|--|---|---|------------------|------------------|
| | | M1 | M2 | EPI | EP2 | T1 | T2 | T3 | T4 |
| ACEA B5 Urania Daily ⁽¹⁾ ACEA E3/E5 Urania Turbo LD5 | Engine FIA | Every 40,000 km or 800 hours | Every 120,000 km or 2,400 hours | Every 240,000 km or 4,800 hours | Every 240,000 km or 4,800 hours | Every year at the start of spring | Every year at the start of winter | Every 2 years | Every 3 years |

⁽¹⁾ IVECO recommend **Urania Daily** for benefits in terms of "fuel economy". IVECO have already introduced this lubricant with new vehicles



- Average speed calculated at 50 km/h
- If using oils according to specification, the replacement interval for engine oil and filter must be reduced to 30,000 km
- If fuel containing a percentage of sulphur higher than 0.5% is used, the mileage for changing the engine oil must be halved.
- In the case of very low mileage or anyhow under 40,000 km/year, the engine oil and filter must be changed every 12 months.
- In the case of mileage under 40,000 km/year, the gearbox and axle oil must be changed at least every three years.

Inspection and/or maintenance interventions (FIA engine vehicles)

| Type of intervention | | M1 | M2 |
|---|--|---------------------------------|------------------------------------|
| | | Every 40,000 km or 800 hours | Every 120,000 km or 2,400 hours |
| LUBRICATION, CHANGING OIL, FILTERS AND CHECKING FLUIDS | | | |
| 1 | Changing engine oil | • | • |
| 1 | Changing engine oil filter | • | • |
| 2 | Changing fuel filter * | • | • |
| 3 | Checking hydraulic brake system fluid level | • | • |
| 4 | Visually checking fuel pre-filter clogging | • | |
| 4 | Changing fuel pre-filter | | • |
| 5 | Changing mechanical gearbox oil | | • |
| 6 | Changing rear axle oil | | • |
| CHECKS IN THE ENGINE BAY | | | |
| • | Checking state of auxiliary drive belts | • | |
| • | Changing auxiliary drive belts ⁽¹⁾ | | • |
| CHECKS UNDER THE VEHICLE | | | |
| 7 | Checking steering box rack covers | • | • |
| 8 | Checking wear of brake discs and shoes | • | • |
| 6 | Cleaning rear axle oil breather | | • |
| 7 | Checking steering column, articulation and linkage | | • |
| 9 | Checking steering box fixing | | • |
| 10 | Checking universal joints and propeller shaft fixing | | • |
| CHECKS IN THE CAB | | | |
| • | Checking parking brake travel | • | • |
| EXTERNAL CHECKS | | | |
| 11 | Checking headlight adjustment | | • |
| DIAGNOSTICS | | | |
| • | Check-up engine EDC system with MODUS-IT 2000 | | • |
| ON-ROAD TESTS | | | |
| • | Functional testing on the road | • | • |

⁽¹⁾ Replace every four years. Replace every 60,000 km under harsh conditions of use (dust and/or heat).

^(*) If the "clogged filter" warning lamp lights up on the instrument panel, the filter must be replaced before the programmed replacement interval

Extra plan operations (to be carried out possibly in combination with maintenance service)**EPI EVERY 80,000 km or 1600 hours (.12 and EGR engine vehicles only)**

- Check air flow meter with MODUS - IWT IT 2000 devices
- Air flow meter replacement ⁽¹⁾

EP2 EVERY 240,000 km or, anyhow, every 5 years (or 4,800 hours)

- Changing the timing system driving belt ⁽²⁾.
- Changing the automatic tensioner of the timing system driving belt.
- Changing the automatic tensioner of the belt driving the alternator and hydraulic pump
- Changing the pre-heating glow plugs.

TI EACH YEAR - especially in early springtime

- Check state of pollen filters.
In the case of low mileage, change the filters once a year, early each spring.

T2 EACH YEAR - before the winter season

- Check coolant density.
- Check pre-combustion chamber glow plug operation.

T3 EVERY TWO YEARS

- Change brake fluid and bleed brake fluid system.

T4 EVERY THREE YEARS - even if there is no indication of the air filter clogging

- Change cartridge and clean air filter container ⁽³⁾.
- Change engine coolant.

(1) Replacement is mandatory also if the flow meter does not appear faulty following the test.

(2) The timing belt must be replaced in any case every 5 years.

(3) Early air cleaner obstruction is generally due to particular environmental conditions. For this reason it may need to be replaced when indicated by the sensor regardless of the replacement interval also if not specifically stated.

FIC ENGINE VEHICLES

| Engine-oil | Engine | Standard Services | | Extra plan | Time Operations | | | |
|--|------------|---------------------------------------|--|--|---|---|------------------|------------------|
| | | M1 | M2 | EPI | T1 | T2 | T3 | T4 |
| ACEA B5 Urania Daily ⁽¹⁾ | Engine FIC | Every 40,000 km or 800 hours | Every 120,000 km or 2,400 hours | Every 240,000 km or 4,800 hours | Every year at the start of spring | Every year at the start of winter | Every 2 years | Every 3 years |

⁽¹⁾ IVECO recommend **Urania Daily** for benefits in terms of "fuel economy". IVECO have already introduced this lubricant with new vehicles



- Average speed calculated at 50 km/h
- If using oils according to specification, the replacement interval for engine oil and filter must be reduced to 30,000 km
- If fuel containing a percentage of sulphur higher than 0.5% is used, the mileage for changing the engine oil must be halved.
- In the case of very low mileage or anyhow under 40,000 km/year, the engine oil and filter must be changed every 12 months.
- In the case of mileage under 40,000 km/year, the gearbox and axle oil must be changed at least every three years.

Inspection and/or maintenance interventions (FIC engine vehicles)

| Type of intervention | | M1 | M2 |
|---|--|---------------------------------|------------------------------------|
| | | Every 40,000 km or 800 hours | Every 120,000 km or 2,400 hours |
| LUBRICATION, CHANGING OIL, FILTERS AND CHECKING FLUIDS | | | |
| 1 | Changing engine oil | • | • |
| 1 | Changing engine oil filter | • | • |
| 2 | Changing fuel filter * | • | • |
| 3 | Checking hydraulic brake system fluid level | • | • |
| 4 | Visually checking fuel pre-filter clogging | • | |
| 4 | Changing fuel pre-filter | | • |
| 5 | Changing mechanical gearbox oil | | • |
| 6 | Changing rear axle oil | | • |
| CHECKS IN THE ENGINE BAY | | | |
| • | Checking state of auxiliary drive belts | • | |
| • | Changing auxiliary drive belts (1) | | • |
| CHECKS UNDER THE VEHICLE | | | |
| 7 | Checking steering box rack covers | • | • |
| 8 | Checking wear of brake discs and shoes | • | • |
| 6 | Cleaning rear axle oil breather | | • |
| 7 | Checking steering column, articulation and linkage | | • |
| 9 | Checking steering box fixing | | • |
| 10 | Checking universal joints and propeller shaft fixing | | • |
| CHECKS IN THE CAB | | | |
| • | Checking parking brake travel | • | • |
| EXTERNAL CHECKS | | | |
| 11 | Checking headlight adjustment | | • |
| DIAGNOSTICS | | | |
| • | Check-up engine EDC system with MODUS-IT 2000 | | • |
| ON-ROAD TESTS | | | |
| • | Functional testing on the road | • | • |

⁽¹⁾ Replace every four years. Replace every 60.000 km under harsh conditions of use (dust and/or heat).

^(*) If the "clogged filter" warning lamp lights up on the instrument panel, the filter must be replaced before the programmed replacement interval

Extra plan operations (to be carried out possibly in combination with maintenance service)**EPI EVERY 240,000 km or, anyhow, every 5 years (or 4,800 hours)**

- Changing the automatic tensioner of the belt driving the alternator.
- Changing the pre-heating glow plugs.

TI EACH YEAR - especially in early springtime

- Check state of pollen filters.
In the case of low mileage, change the filters once a year, early each spring.

T2 EACH YEAR - before the winter season

- Check coolant density.
- Check pre-combustion chamber glow plug operation.

T3 EVERY TWO YEARS

- Change brake fluid and bleed brake fluid system.

T4 EVERY THREE YEARS - even if there is no indication of the air filter clogging


- Change cartridge and clean air filter container. ⁽¹⁾
- Change engine coolant ⁽²⁾.

⁽¹⁾ Early air cleaner obstruction is generally due to particular environmental conditions. For this reason it may need to be replaced when indicated by the sensor regardless of the replacement interval also if not specifically stated.

⁽²⁾ Parafllu¹¹ needs to be diluted at 50% with water, while Parafllu FE is already diluted at 50% with water.

DIAGRAM OF CHECK AND/OR MAINTENANCE POINTS

Figure 1



60391

MAINTENANCE OPERATIONS




The figures given below are for the maintenance work on the engines (8140..).

NOTE After checking or changing parts, test the operation of the vehicle.

EO SERVICE (8140.63 engine with pre-chamber vehicles only)

1. Changing engine oil

Figure 2




Take out the dipstick (2). From underneath the vehicle, remove the soundproofing guard, and fit it back on after completing the operation. Remove the plug from the oil sump and drain the engine oil off into a special container. Pour oil into the engine through the filling-pipe (1) of the required grade and quantity (see fluids table in the GENERAL section).

MI SERVICE

NOTE MI service is replaced by the "engine oil changing" procedure described in the EO service section with the addition of the following operations.

1. Changing engine oil filter

Figure 3



Take out the dipstick (2). From underneath the vehicle, remove the soundproofing guard, and fit it back on after completing the operation. Remove the plug from the oil sump and drain the engine oil off into a special container.

NOTE For the engines (8140..) use tool 99360091 and remove the oil filter (1), for engines (FIA) use tool 99360076.




Before refitting the new cartridges, moisten the seal with engine oil.

Screw the oil filter (1) on by hand until it is in contact with the mounting and then tighten by 3/4 of a turn (tightening torque 25 Nm). Screw the plug back on under the sump. Pour oil into the engine through the filling-pipe (1) of the required grade and quantity (see fluids table in the GENERAL section).

2. Changing the fuel filter

Figure 4




NOTE For the engines (8140..) use tool 99360091 and remove the fuel filter (1), for engines (FIA) use tool 99360076.

Screw the new one on by hand (tightening torque 18 ± 2 Nm) taking care to check that the rubber gasket and seal surface are clean and in a perfect state of repair.

For 8140.63 and 8140.43C engines

Bleed the air from the supply as described hereunder.

Figure 5




Loosen the air bleeder screw (2) and operate the priming pump piston (1) until all the air in the system has been ejected then close the bleeder screw (2).

NOTE If the engine stops due to running out of fuel, with air consequently getting into the system, it is necessary (if bleeding as described above is not sufficient) to loosen the fittings of at least two injectors, turn the engine by starting and after bleeding the air close the fittings again.

3. Checking hydraulic brake system fluid level

Figure 6



Check the level of brake fluid. If it is low, top it up (see fluids table in the GENERAL section).



4. Visually checking fuel pre-filter clogging (FIA-FIC engines)

Visually check that the fuel pre-filter is not clogged; if it is, change it as described in the M2 Service "Changing fuel pre-filter (on chassis frame)".



• Checking state of auxiliary drive belts

Visually check that the belts are not worn or deteriorated, in which case replace them as described in the "ENGINE" section.



7. Checking steering box rack covers

Remove the soundproofing guard from underneath the vehicle. If the covers are damaged at all, replace them as described in the "STEERING GEAR" section.



8. Checking wear of brake discs and shoes

If the wear is found to be too great, replace the brake discs or shoes as described in the "BRAKES" section.



• Checking parking brake travel

Check that the vehicle stays braked with a lever travel of:

- five catches.


If it does not, adjust it as described in the "BRAKES" section.

M2 SERVICE

NOTE The M2 service comprises some of the operations in the M1 service as well as the following operations.

4. Changing the fuel pre-filter (on the chassis frame)

Figure 7




Disconnect the pre-filter retaining clamp (1) and the clamps (2) connecting the fuel pipes. Remove and replace the fuel pre-filter (3).

5. Replacing the mechanic and automatic transmission gearbox oil

NOTE For vehicles with 8140 engine. This operation is described in EP1 service section.

Figure 8



A. Automatic transmission - B. Mechanic transmission

The lubrication oil should be drained off when it is warm. Place a special container under the plug (1). Take out the plug and drain off the oil.

Screw the plug back on. Unscrew the filler plug and pour in lubricating oil of the required grade and quantity (see fluids table in the GENERAL section).


Fit the plug (2) back on.

Remove the oil vapour vent and clean it thoroughly.

6. Changing rear axle oil

NOTE For vehicles with 8140 engine.
This operation is described in EPI service section.

Figure 9




NOTE The oil change described refers to the Rear Axles 4050210 - 450311/1 - 450511.

The lubricating oil has to be drained off while it is hot. Place a container under the plug near the arrow; remove the plug and drain off the oil.

Screw the plug back on. Unscrew the plug (2) and pour in the prescribed quantity of lubricating oil (see fluids table under the GENERAL INFORMATION heading).

To get off I leak it some vapors oil (1) and to carefully clean it.

Figure 10



NOTE The oil change described refers to the Rear Axles 450517/2.

The lubrication oil should be drained off when it is warm. Place a special container under the plug (2). Take out the plug and drain off the oil.

Screw the plug (2) back on. Unscrew the plug (1) and pour in lubricating oil of the required grade and quantity (see fluids table in the GENERAL section).

Remove the oil vapour vent and clean it thoroughly. (Shown in Figure 11).

• Changing auxiliary drive belts

This should be done as described in the "ENGINE" section.

• Changing timing belts (Engines: 8140-F1A)

This should be done as described in the "ENGINE" section.

For vehicles with 8140 engine.

This operation is described in EPI service section.


• Changing pre-combustion chamber glow plugs

This should be done as described in the "ENGINE" section.

NOTE For vehicles with 8140 engine.
This operation is described in EPI service section.

6. Cleaning rear axle oil breather

Figure 11



Take out the screws (1) and remove the brake caliper with its brake linings from the mounting.

NOTE Cleaning the oil breather pipe as described here, refers to the rear axle 450517/2, for rear axles 4050210 - 450311/1 - 450511 refer to Figure 9.

7. Checking steering column, articulation and linkage

Steering linkage

- Check that the nuts and screws securing the clamps to the tie rods have not deteriorated and are tightened to the required torque.
- The tie rods must not be damaged, likewise the threaded portion must be sound.

Swivel heads

- Clean the swivel heads of the tie rods.
- This must be done with dry canvas or raw cotton. Use no solvents.
- Check that the swivel heads, in their components, have no points of corrosion, with sections affected to a depth greater than 1 mm. In particular, check the sheet metal cover close to the rolled section.
- Check the protecting casing: it must be secured to the body and to the pin of the joint with a retaining ring and must not rotate.
- The casing must be neither damaged nor deteriorated.
- Crush the protective casings by hand and check that lubrication grease comes out.
- Check that the nuts and split pins have not deteriorated.



9. Checking steering box fixing


Remove the soundproofing guard from underneath the vehicle.

If there is any damage, refer to the "STEERING GEAR" section.

After making the check, fit the soundproofing guard back on.

10. Checking universal joints and propeller shaft flange fixing

Figure 12



52124

The plates welded onto the propeller shafts are there for balancing.


If there are no plates, it is necessary to balance the shaft again. Turning the propeller shaft and at the same time the sliding sleeve in the opposite direction, check there is not too much clearance between the splines.

Acting on the forks of the couplings (in the direction of the arrows shown in the figure), check that the spiders are not worn. Replace them if they are.

If there is any damage, refer to the "PROPELLER SHAFTS" section.

11. Checking headlight adjustment

Figure 13



46311

Set the unloaded vehicle on level ground, with the tyres at the required pressure, opposite a light-coloured wall.

Draw two crosses on the wall corresponding to the centres of the two headlights.

Position the switch (for vehicles fitted with one) onto "0".

Set the vehicle at a distance of 10 metres and switch on the low beam. The distance between the crosses and the points P, corresponding to the angle of the headlamps, must be 10 cm (1% as indicated on the plate).

- **Check-up engine EDC system with MODUS-IT2000 (UNIJET injection system)**

SECTION 14**7600 Electric/Electronic system**

| | Page |
|---|------|
| ABBREVIATIONS AND GRAPHIC SYMBOLS . . . | 7 |
| GENERAL CONDITIONS FOR LAYING ELECTRIC CIRCUITS | 8 |
| GENERAL WARNINGS | 8 |
| TECHNICAL CODES | 9 |
| POWER NETWORK | 13 |
| <input type="checkbox"/> General | 13 |
| <input type="checkbox"/> Power network assembly | 14 |
| <input type="checkbox"/> Positive network | 15 |
| <input type="checkbox"/> Negative network | 17 |
| <input type="checkbox"/> Earth points on the vehicle | 19 |
| CONCEPT OF EARTH AND ELECTROMAGNETIC COMPATIBILITY | 20 |
| <input type="checkbox"/> Practical advice | 21 |
| <input type="checkbox"/> Ultrasonic cable welding | 22 |
| MAIN COMPONENTS OF POWER NETWORK | 23 |
| <input type="checkbox"/> BOSCH KCBI 14V 110A Alternator | 23 |
| <input type="checkbox"/> EV 12V - 2.3 kW Starter motor | 24 |
| <input type="checkbox"/> Battery | 25 |
| <input type="checkbox"/> Ignition switch | 26 |
| <input type="checkbox"/> Interconnection center | 27 |
| <input type="checkbox"/> General remote control switch (T.G.C.) | 28 |
| ONBOARD CABLES | 29 |
| <input type="checkbox"/> Components of the injection system (E. 8140) | 29 |
| <input type="checkbox"/> Engine cable | 29 |
| 8140.43C ID/TCA (.11) ENGINE HARNESS | 30 |
| 8140.43S UNIJET (.13) ENGINE HARNESS | 32 |
| INJECTION CABLE - V.G.T (.15) | 34 |

| | Page |
|---|------|
| FIA UNIJET (.10 - .12) ENGINE HARNESS | 36 |
| FIA UNIJET WITH EDC16 (.10 - .12 - .14) ENGINE HARNESS | 37/1 |
| F1C UNIJET WITH EDC16 (.10 - .12 - .14) ENGINE HARNESS | 37/3 |
| INJECTION CABLE - FIA (.10 - .12) WITH AND WITHOUT EGR | 38 |
| TRUCK CHASSIS CABLE | 40 |
| A.B.S. PARALLEL CABLE | 42 |
| AIR-BAG CABLE WITH ONE-CONNECTOR CONTROL UNIT | 44 |
| AIR-BAG CABLE WITH TWO-CONNECTOR CONTROL UNIT | 46 |
| VAN INTERIOR DOME LAMP CABLES 1/2 | 48 |
| VAN INTERIOR DOME LAMP CABLES 2/2 | 50 |
| TRUCK INTERIOR DOME LAMP CABLES | 52 |
| JUNCTION CONNECTORS | 53 |
| <input type="checkbox"/> Connection between cab/bonnet cable and injection cable (Unijet) | 53 |
| <input type="checkbox"/> Connection between cab/bonnet cable and air bag cable | 54 |
| <input type="checkbox"/> Connection between cab/bonnet cable and rear differential lock cable | 55 |
| <input type="checkbox"/> Connection between cab/bonnet cable and cable for tachometer | 56 |
| <input type="checkbox"/> Connection between frame cable and right tail lamp cable | 57 |
| <input type="checkbox"/> Connection between frame cable and right tail lamp cable | 58 |
| <input type="checkbox"/> Connection between frame cable and left tail lamp cable | 59 |
| <input type="checkbox"/> Connection between frame cable and left tail lamp cable | 60 |
| <input type="checkbox"/> Connection between cab/bonnet cable and roof lamp cable inside cab | 61 |
| <input type="checkbox"/> Connection between cab/bonnet cable and 13 pin current socket cable or rear door opening/closing cable (van) | 62 |
| <input type="checkbox"/> Connection between cab/bonnet cable and brake wear/air cleaner clogged cable | 63 |

| | Page |
|--|------|
| <input type="checkbox"/> Connection between cab/bonnet cable and self-levelling suspension cable | 64 |
| <input type="checkbox"/> Connection between cab/bonnet cable and self-levelling suspension cable | 65 |
| <input type="checkbox"/> Connection between cab/bonnet cable and total power takeoff cable | 66 |
| <input type="checkbox"/> Connection between cab/bonnet cable and total power takeoff cable | 67 |
| <input type="checkbox"/> Connection between cab/bonnet cable and antitheft cable | 68 |
| <input type="checkbox"/> Connection between cab/bonnet cable and antitheft cable with central door locking | 69 |
| <input type="checkbox"/> Connection between cab/bonnet cable and right door cable | 70 |
| <input type="checkbox"/> Connection between cab/bonnet cable and left door cable | 71 |
| <input type="checkbox"/> Connection between cab roof lamp and left front clearance light cable | 72 |
| <input type="checkbox"/> Connection between cab roof lamp and right front clearance light cable | 73 |
| <input type="checkbox"/> Connection between cab/bonnet cable and fog lamp cable | 74 |
| <input type="checkbox"/> Connection between right tail light cable and rear roof lamp cable | 75 |
| <input type="checkbox"/> Connection between frame cable and side clearance lights cable | 76 |
| <input type="checkbox"/> Connection between cab/bonnet cable and ABS cable | 77 |
| <input type="checkbox"/> Connection between cab/bonnet cable and ABS cable | 78 |
| <input type="checkbox"/> Connection between cab/bonnet cable and climate control system cable | 79 |
| <input type="checkbox"/> Connection between cab/bonnet cable and climate control system cable | 80 |
| <input type="checkbox"/> Connection between cab/bonnet cable and climate control system cable | 81 |
| VENDOR-DERIVED BUS VERSION | 82 |
| <input type="checkbox"/> General Information | 82 |
| <input type="checkbox"/> Perspective view of Vendor-derived Bus version interior lighting harness | 83 |
| <input type="checkbox"/> Diagnostic connector | 84 |

| | Page | | Page |
|---|-------|--|--------|
| RELAY AND FUSE HOLDER SUPPORT | 86 | <input type="checkbox"/> Four crossed channel system (x) | 132/3 |
| <input type="checkbox"/> Identification of fuses | 87 | <input type="checkbox"/> Electro-hydraulic modulator/control unit | 132/3 |
| <input type="checkbox"/> Identification of relays/diode holders | 88 | <input type="checkbox"/> Four parallel channel system (II) | 132/4 |
| OPTICAL INDICATORS | 89 | <input type="checkbox"/> Electro-hydraulic modulator/control unit | 132/4 |
| <input type="checkbox"/> Interface bride with the new tool with 32-way connectors | 90 | <input type="checkbox"/> ABS 8 control unit pin out | 132/5 |
| INSTRUMENT CLUSTER | 91 | <input type="checkbox"/> ESP 8 control unit pin out | 132/6 |
| <input type="checkbox"/> Warning lights assembly | 91 | <input type="checkbox"/> ESP operation | 132/7 |
| <input type="checkbox"/> Instrument assembly | 92 | <input type="checkbox"/> Control strategy | 132/7 |
| <input type="checkbox"/> Connector assembly (cable input side view) . | 94 | <input type="checkbox"/> ASR deactivation strategies | 132/9 |
| SWITCH ASSEMBLY | 98 | <input type="checkbox"/> Recovery strategy in case of component failure | 132/9 |
| STALK UNIT | 100 | <input type="checkbox"/> Warning light legend | 132/10 |
| <input type="checkbox"/> Functions | 102 | <input type="checkbox"/> Installing the ESP components | 132/10 |
| <input type="checkbox"/> Cruise Control | 104 | <input type="checkbox"/> ESP system components and calibration | 132/11 |
| ELECTRONIC SYSTEMS | 105 | <input type="checkbox"/> Yaw sensor with built-in side acceleration sensor | 132/11 |
| <input type="checkbox"/> Immobilizer | 105 | <input type="checkbox"/> Steering angle sensor | 132/13 |
| <input type="checkbox"/> System components | 106 | <input type="checkbox"/> ESP control unit programming | 132/14 |
| <input type="checkbox"/> Key teaching procedure | 109 | 6AS 300 VD AUTOMATIC TRANSMISSION ... | 132/15 |
| ABS/EBD/ABD | 112 | <input type="checkbox"/> Description of operation | 132/15 |
| <input type="checkbox"/> General | 112 | <input type="checkbox"/> Electronic control | 132/16 |
| SYSTEM WITH 4 CROSSED CHANNELS (X) .. | 116 | COMPOSITION OF THE SYSTEM | 132/17 |
| <input type="checkbox"/> Location of components | 117 | <input type="checkbox"/> System control unit | 132/17 |
| <input type="checkbox"/> Sensor on phonic wheel | 118 | <input type="checkbox"/> Connector control unit pin-out – gearbox side (A) | 132/18 |
| <input type="checkbox"/> Electrohydraulic control unit/modulator | 119 | <input type="checkbox"/> Connector control unit pin-out – vehicle side (B) | 132/19 |
| <input type="checkbox"/> Electrohydraulic modulator | 120 | <input type="checkbox"/> Gearbox actuator | 132/20 |
| SYSTEM WITH 4 PARALLEL CHANNELS (II) . | 125 | <input type="checkbox"/> Clutch actuator | 132/22 |
| <input type="checkbox"/> Electrohydraulic control unit/modulator | 126 | <input type="checkbox"/> Display | 132/24 |
| <input type="checkbox"/> Electrohydraulic modulator | 127 | <input type="checkbox"/> Accelerator pedal | 132/26 |
| <input type="checkbox"/> Pressure increase | 127 | <input type="checkbox"/> PTO | 132/27 |
| <input type="checkbox"/> Electronic control unit | 132 | <input type="checkbox"/> Diagnosis instruments | 132/30 |
| ABS 8/ESP 8 | 132/1 | | |

| | Page | | Page |
|--|--------|---|-------|
| <input type="checkbox"/> MODUS - IT 2000 - E.A.S.Y. connection . . . | 132/31 | <input type="checkbox"/> Clutch pedal switch | 155 |
| <input type="checkbox"/> Troubleshooting | 132/32 | <input type="checkbox"/> Electromagnetic junction fan | 156 |
| ELECTRONIC INJECTION SYSTEM | 133 | <input type="checkbox"/> Preheat plug electronic centre (FIA/FIC engine) | 157 |
| <input type="checkbox"/> Common rail | 133 | <input type="checkbox"/> Preheat plugs | 157 |
| <input type="checkbox"/> Common rail (FIA) | 135 | EDC MS6.3 / EDC16 | 158 |
| <input type="checkbox"/> Hydraulic system (Common Rail - FIA) | 136 | <input type="checkbox"/> Electronic injection control | 158 |
| SYSTEM COMPONENTS | 137 | <input type="checkbox"/> Bosch MS6.3 control unit | 162 |
| <input type="checkbox"/> Camshaft pulley and timing sensor | 137 | <input type="checkbox"/> Control unit connection to the injection cable on engine side (housing A) | 163 |
| <input type="checkbox"/> Flywheel and rpm sensor | 138 | <input type="checkbox"/> Control unit connection to cab-bonnet cable (housing B) | 164 |
| <input type="checkbox"/> Flywheel and camshaft sensor specifications . . | 139 | <input type="checkbox"/> EDC system components | 165 |
| <input type="checkbox"/> Pre-filter | 140 | <input type="checkbox"/> Blink Code (up to chassis no. 5383302/ D187233) | 167 |
| <input type="checkbox"/> Electric pump | 140 | <input type="checkbox"/> Common Rail 8140.43B - 8140.43S - 8140.43N - EDC MS6.3 | 167 |
| <input type="checkbox"/> Fuel filter | 141 | <input type="checkbox"/> FIA Common Rail | 168 |
| <input type="checkbox"/> High pressure pump | 142 | <input type="checkbox"/> EDC16 | 169 |
| <input type="checkbox"/> High-pressure pump (FIA engine) | 143 | <input type="checkbox"/> Bosch EDC16 control unit | 170 |
| <input type="checkbox"/> Pressure regulator | 144 | <input type="checkbox"/> Control unit connection to the injection cable on engine side (housing A) | 171 |
| <input type="checkbox"/> Pressure regulator (FIA) | 145 | <input type="checkbox"/> Control unit connection to cab-bonnet cable (housing K) | 173 |
| <input type="checkbox"/> Rail (pressure accumulator) | 146 | <input type="checkbox"/> Accelerator pedal sensor | 175 |
| <input type="checkbox"/> Rail (pressure accumulator - FIA) | 147 | <input type="checkbox"/> Camshaft sensor (FIA) | 176 |
| <input type="checkbox"/> Flow limiters | 148 | <input type="checkbox"/> Injection cable FIA (.10 - .12) | 177 |
| <input type="checkbox"/> Pressure limiter | 148 | <input type="checkbox"/> Injection cable FIA (.14) | 177/1 |
| <input type="checkbox"/> Fuel pressure sensor | 148 | <input type="checkbox"/> Joint connector | 178 |
| <input type="checkbox"/> Injectors | 149 | <input type="checkbox"/> Diagnostic connector | 179 |
| <input type="checkbox"/> Fuel outlets unit | 150 | <input type="checkbox"/> Diagnostic connector pin description table . . | 180 |
| <input type="checkbox"/> Air flow meter | 151 | <input type="checkbox"/> High-pressure pump (FIA engine) | 181 |
| <input type="checkbox"/> Atmospheric pressure sensor | 153 | FIC ENGINE | 182 |
| <input type="checkbox"/> Engine coolant temperature sensor | 153 | <input type="checkbox"/> Injection cable FIC (.14 - .17) | 183 |
| <input type="checkbox"/> Fuel temperature sensor | 153 | | |
| <input type="checkbox"/> Brake pedal switches | 155 | | |

| | Page |
|--|------|
| <input type="checkbox"/> Connection between cab/bonnet cable and injection cable | 184 |
| <input type="checkbox"/> R.p.m. / timing sensors | 185 |
| <input type="checkbox"/> Timing sensor (stroke) | 186 |
| <input type="checkbox"/> RPM sensor | 187 |
| <input type="checkbox"/> Timing sensor | 188 |
| <input type="checkbox"/> High-pressure pump | 189 |
| <input type="checkbox"/> Pressure regulator | 190 |
| <input type="checkbox"/> Rail (pressure accumulator) FIC | 191 |
| <input type="checkbox"/> Pressure sensor | 191 |
| <input type="checkbox"/> Air temperature/pressure sensor (without EGR) | 193 |
| <input type="checkbox"/> Atmospheric pressure sensor | 194 |
| <input type="checkbox"/> Engine coolant temperature sensor | 194 |
| <input type="checkbox"/> Fuel temperature sensor | 194 |
| <input type="checkbox"/> Fuel filter | 195 |
| <input type="checkbox"/> Brake pedal switches | 196 |
| <input type="checkbox"/> Clutch pedal switch | 196 |
| <input type="checkbox"/> Injectors | 197 |
| <input type="checkbox"/> Electromagnetic junction fan | 198 |
| CLIMATE CONTROL | 199 |
| <input type="checkbox"/> General | 199 |
| <input type="checkbox"/> Operating logic | 200 |
| <input type="checkbox"/> Electronic control unit | 205 |
| <input type="checkbox"/> Outside air temperature sensor | 206 |
| <input type="checkbox"/> Inside temperature sensor | 207 |
| <input type="checkbox"/> Blown air temperature sensor | 208 |
| <input type="checkbox"/> Evaporator temperature sensor | 208 |
| <input type="checkbox"/> Required temperature potentiometer | 208 |
| <input type="checkbox"/> Ventilation control potentiometer | 209 |
| <input type="checkbox"/> Electronic fan control module | 210 |

| | Page |
|--|------|
| <input type="checkbox"/> Air mixing gear motor | 211 |
| <input type="checkbox"/> Re-circulation gear motor | 212 |
| <input type="checkbox"/> Compressor | 213 |
| <input type="checkbox"/> Safety pressure switches | 213 |
| SYSTEM SELF-DIAGNOSTICS | 214 |
| <input type="checkbox"/> Diagnostics through blink code | 214 |
| <input type="checkbox"/> Blink codes | 215 |
| AIR BAG | 216 |
| <input type="checkbox"/> General | 216 |
| <input type="checkbox"/> Operation | 217 |
| <input type="checkbox"/> Preliminary rules | 218 |
| <input type="checkbox"/> Operations after an accident | 219 |
| <input type="checkbox"/> Painting work | 219 |
| <input type="checkbox"/> Health hazards | 219 |
| <input type="checkbox"/> Effects of over-exposure | 219 |
| <input type="checkbox"/> Rules of safety in handling air bag modules | 220 |
| <input type="checkbox"/> Air bag module scrapping | 220 |
| <input type="checkbox"/> Rules of safety in handling pretensioners | 221 |
| <input type="checkbox"/> Scrapping pretensioners | 221 |
| <input type="checkbox"/> Operations on system components | 222 |
| <input type="checkbox"/> Removing and scrapping an activated air bag module and pretensioner from a vehicle | 222 |
| <input type="checkbox"/> Removing or scrapping an air bag module that has not been deployed from a repairable vehicle | 222 |
| <input type="checkbox"/> Deployment of an air bag | 223 |
| <input type="checkbox"/> Deployment of air bag modules and electronic pretensioners still on board of irreparable vehicles | 224 |
| <input type="checkbox"/> Electronic control unit | 225 |
| <input type="checkbox"/> One-connector electronic control unit pin-out | 226 |
| <input type="checkbox"/> ECU pin-out to the two connectors | 229 |

Page

| | | |
|--------------------------|--|-----|
| <input type="checkbox"/> | Drivers air bag module | 230 |
| <input type="checkbox"/> | Clock spring | 231 |
| <input type="checkbox"/> | Passenger's air bag module | 233 |
| <input type="checkbox"/> | Pretensioners | 234 |
| <input type="checkbox"/> | Driver's/passenger's pretensioner | 235 |
| <input type="checkbox"/> | Centre passenger's pretensioner | 236 |
| | DOOR-BLOCKER WITH ANTI-THEFT PROTECTION | 237 |
| <input type="checkbox"/> | General information | 237 |
| <input type="checkbox"/> | System components | 238 |
| <input type="checkbox"/> | Operation | 239 |
| <input type="checkbox"/> | Arrangement of components | 240 |
| | MAIN COMPONENTS OF THE SYSTEM | 241 |
| <input type="checkbox"/> | Remote-control key | 241 |
| <input type="checkbox"/> | Electronic central control unit (ECU) | 243 |
| <input type="checkbox"/> | Arrangement of the switches | 245 |
| <input type="checkbox"/> | Electronic volumetric-detection module | 248 |
| <input type="checkbox"/> | Siren | 249 |
| | ERROR CODES | 251 |
| <input type="checkbox"/> | Error code table | 252 |
| | AIR SUSPENSIONS ECAS | 253 |
| <input type="checkbox"/> | WABCO electronically controlled air suspensions (ECAS) | 254 |
| <input type="checkbox"/> | Vehicles with braking system without ABS | 256 |
| <input type="checkbox"/> | Vehicles with ABS system | 257 |
| <input type="checkbox"/> | Electronic Control Unit | 258 |
| <input type="checkbox"/> | Level sensor | 260 |
| <input type="checkbox"/> | Pneumatic supply unit | 261 |
| <input type="checkbox"/> | Brake action compensator | 262 |
| <input type="checkbox"/> | Chassis lifting | 264 |
| <input type="checkbox"/> | Chassis lowering | 265 |
| <input type="checkbox"/> | Chassis leveling | 266 |

Page

| | | |
|--------------------------|---|-----|
| | VB TECHNIEK PNEUMATIC SUSPENSIONS | 267 |
| <input type="checkbox"/> | Vehicles with braking system without ABS | 269 |
| <input type="checkbox"/> | Vehicles with ABS system | 270 |
| | SYSTEM COMPONENTS | 271 |
| <input type="checkbox"/> | Electronic Control Unit (35C - 40C - 45C) | 271 |
| <input type="checkbox"/> | Electronic control unit (60C - 65C - 50C) | 272 |
| <input type="checkbox"/> | Level sensor | 273 |
| <input type="checkbox"/> | Brake action compensator | 274 |
| | ROTATING SLIDING DOOR | 275 |
| <input type="checkbox"/> | Description | 275 |
| | SYSTEM COMPONENTS | 276 |
| <input type="checkbox"/> | Electronic center | 276 |
| <input type="checkbox"/> | Optical and sound warnings | 278 |
| <input type="checkbox"/> | Sound device | 278 |
| <input type="checkbox"/> | Description and operation | 279 |
| <input type="checkbox"/> | Emergency operation | 280 |
| <input type="checkbox"/> | Diagnosis | 280 |
| <input type="checkbox"/> | Description of opening | 281 |
| <input type="checkbox"/> | Description of closing cycle | 282 |
| <input type="checkbox"/> | Operating diagram | 283 |
| | ELECTRONIC TACHOGRAPH | 284 |
| <input type="checkbox"/> | Removing the lower dashboard cover | 284 |
| <input type="checkbox"/> | Electronic tachograph control unit housing assembly | 284 |
| <input type="checkbox"/> | Assembling the tachograph control unit support on the dashboard | 285 |
| <input type="checkbox"/> | Removing the instrument cluster module | 286 |
| <input type="checkbox"/> | Operations on gearbox | 288 |
| <input type="checkbox"/> | Operation in bonnet | 289 |
| | CIRCUIT CHARTS | 291 |

ABBREVIATIONS AND GRAPHIC SYMBOLS



Indicates a general warning

A Ampere

kW KiloWatt

NB Note Well

m2 Identification of an earth point

IWT IVECO Wiring Tester

V Volt

Ω Ohm




Connection to a power earth point




Connection to a signal earth point


72030_{3C} Code of connector between cables:
72030 = connector code
3C = cell identification co-ordinates



Base equipment



Base electrical connection



Connection to earth by cable

||₆

Connector between cables:
|| = connector number
6 = cell number

7777

Cable colour code



Consult



Reed fuse on control box
4 = fuse number
5A = capacity
59-60 = terminal identification



Electronic component or control unit



Optional equipment



Optional electrical connection in a base circuit chart




Connection to earth through metal agglomerate


Cables symbol



No protection



Protection with continuous PVC tape



Protection with 30 mm spiral PVC tape



The symbol identifies a knot

GENERAL CONDITIONS FOR LAYING ELECTRIC CIRCUITS

- Engine off
- Ignition switch off
- Handbrake engaged
- Neutral gear
- Fluids at normal level

GENERAL WARNINGS



Do not ever disconnect the system batteries and do not open the general current switch with the i.c. engine running. Do not start the engine without first connecting the batteries in a permanent manner.

- Before doing any work on the vehicle chock the wheels appropriately.
- Do not use quick chargers to start the engine. Starting must only be carried out with separate batteries or with the special trolley.
- Make sure that the polarity on the battery terminals is correct when starting from an auxiliary trolley.
- The incorrect polarisation of the power voltage of electronic control units (for example incorrect polarisation of the batteries) may lead to their destruction.
- When needing to disconnect the battery from the system, firstly always disconnect the battery negative cable that goes to the engine from the negative terminal of the battery itself.
- Before connecting the battery to the system, make sure that it is well insulated.
- When seeking faults, insert a wander fuse between the battery negative terminal and the engine earth cable.
- Before removing any electrical and/or electronic components, disconnect the ground cable from the negative terminal of the battery.
- Disconnect the battery from the system when charging it with external equipment.
- Disconnect the external charging equipment from the mains before removing its grippers from the terminals of the battery.
- Do not insert or remove the connector of electronic control units with the power on.
- With temperatures above 80 °C (drying ovens) remove the electronic control units
- During electric welding work disconnect the connectors of electronic control units.
- During connection, tighten the nuts of the connectors (temperature, pressure sensors, etc.) only with the specified tightening torque.



Key storing procedures are affected by electromagnetic noise (mobile phones, etc.). Therefore, during key storing:

1. Pay attention that there are no noise sources in the cab or near keys.
2. Keys not inserted in panel must be at least at 1 metre distance.



Measurements in electronic control units, plug connections and electric connections to components may be carried out only on appropriate testing lines, with special plugs and sockets. Never use improper means such as metal wires, screwdrivers, clips or the like. In addition to the danger of a short circuit, damage to the plug connectors may also result and this would subsequently cause contact problems.

TECHNICAL CODES

| | |
|-------|---|
| 03000 | Self-rectifying alternator with built in voltage regulator |
| 08000 | Starter motor |
| 12006 | Motor for adjustable mirrors |
| 12010 | Motor for locking right door |
| 12011 | Motor for locking left door |
| 12012 | Compressor for air conditioning system |
| 12025 | Power takeoff motor |
| 12026 | Motor, winch control |
| 12027 | Motor for opening or closing left side door lock |
| 19005 | Thermal starter |
| 19010 | Heater plug |
| 20000 | Starter battery |
| 22001 | Horn |
| 22039 | Bell for parking lights on signal |
| 25003 | Relay for switching on fog lights |
| 25006 | Brake lights relay |
| 25014 | Relay for enablement of parking lights with engine off |
| 25023 | Relay for disconnection of low beam lights with parking lights on |
| 25104 | Relay for switching off Retarder with ABS engaged |
| 25209 | Relay for switching off services during starting |
| 25222 | Relay for allowing connection of thermal starter |
| 25223 | Relay for allowing connection of thermal starter fuel tank with atmosphere |
| 25307 | Relay for controlling air conditioning compressor |
| 25336 | Relay for engine cooling electromagnetic joint |
| 25337 | Relay for disconnecting air-conditioning system compressor |
| 25340 | Relay, compressor operation, signal to EDC |
| 25620 | Relay for fuel filter clogged signal |
| 25704 | Relay for switching NC/NO signal for third steering axle |
| 25705 | Relay for enabling point switching on |
| 25810 | Relay for controlling diesel heating circuit |
| 25811 | Ignition timer relay (KSB) |
| 25818 | Relay for switching on heated windscreen |
| 25837 | Relay for connection of fuel pump |
| 25858 | Relay for EDC connection |
| 25926 | Relay for enablement of suspension lifting and stopping of suspension lowering function |
| 25927 | Relay for enablement of suspension lowering and stopping of suspension lifting function |
| 25928 | Relay, rear window heating |
| 28002 | Engine stopping electromagnet |
| 30003 | Multifunctional side headlight |
| 30011 | Fog light |
| 32002 | Front direction indicator |
| 33001 | Side direction indicator |
| 33004 | Side marker lamp |
| 34000 | Multifunctional rear light |
| 34007 | Stop light |
| 34009 | Rear fog lamp |
| 35000 | Number plate light |
| 37001 | Front dimensions light |
| 39020 | Ashtray light |
| 39022 | Courtesy light for cabin interior with adjustable spot light |

| | |
|-------|--|
| 39025 | Lamp for lighting rear hatch |
| 39026 | Lamp for lighting side hatch |
| 40011 | Electronic tachograph |
| 40030 | Sender unit for electronic tachometer |
| 40031 | Sender unit for electronic tachograph |
| 40046 | Inductive type chassis height sensor (rear axle) |
| 42035 | Absolute pressure sensor |
| 42102 | Switch signalling handbrake applied |
| 42350 | Switch signalling body tilted |
| 42351 | Switch signalling air filter blocked |
| 42354 | Switch for air suspension system failure |
| 42374 | EDC clutch switch |
| 42550 | Switch signalling engine oil pressure |
| 42552 | Fuel filter clogged indicator switch |
| 42608 | Coolant pressure signalling 3-switch assembly |
| 44031 | Sender unit, fuel level indicator with w/lamp contact |
| 44033 | Insufficient brake fluid level gauge control |
| 44036 | Insufficient radiator coolant level gauge control |
| 44037 | Insufficient power assisted steering fluid level gauge control |
| 44044 | Engine oil low level indicator control |
| 47034 | Engine coolant temperature sensor (EGR) |
| 47035 | Engine coolant temperature sensor |
| 47104 | Switch for engaging engine cooling electromagnet coupling |
| 47106 | Switch for engaging diesel fuel heating |
| 47109 | Switch for connection of ignition timer (KSB) |
| 47207 | Switch/sender unit, engine water temperature indicator |
| 48035 | Engine rpm sensor |
| 48042 | Engine rpm sensor (on timing gear) |
| 52005 | Switch with built in w/l for heated rear view mirrors |
| 52036 | Switch with built in w/l for engaging windscreen heater |
| 52082 | Switch with built-in w/lamp, fog lights |
| 52083 | Switch with built-in w/lamp, hazard lights |
| 52084 | Switch with incorporated warning light for switching on rear differential lock |
| 52090 | Suspension levelling switch (ECAS) |
| 52091 | Switch with incorporated warning light for switching on rearscreen heating |
| 52093 | Switch for tail hatch locking safety |
| 52310 | Switch for adjustable mirrors |
| 52312 | Switch controlling headlamp alignment adjustment |
| 52502 | Ignition switch for services with starting |
| 53004 | Switch for headlamp washer |
| 53041 | Switch for checking EDC system |
| 53051 | Suspension lifting switch |
| 53052 | Suspension lowering switch |
| 53300 | Switch for driver's side electric window |
| 53302 | Switch for passenger side electric window |
| 53501 | Switch signalling vehicle stopped |
| 53503 | Switch signalling reversing lights |
| 53505 | Rear differential lock engaged indicator switch |
| 53509 | Switch for switching on interior lights |
| 53565 | Switch for signalling brake pedal fully pressed |
| 53590 | Switch for bonnet open signal |

| | |
|-------|---|
| 54032 | 8 function steering column switch unit |
| 58700 | Led, battery charging failure |
| 58701 | Led, EDC failure |
| 58702 | Led, preheating on |
| 58703 | Led, ABS failure |
| 58709 | Trailer direction indicators ON LED |
| 58710 | Water in fuel pre-filter indicator LED |
| 58713 | Led, ECAS system failure |
| 58715 | Total power take off (PTO) ON indicator LED |
| 58717 | Led, Immobilizer on |
| 58718 | Brake system failure warning led |
| 58719 | Led per segnalazione freno a mano inserito |
| 58720 | Led, radiator water level |
| 58722 | Led, engine oil pressure (low) |
| 58725 | Led, air cleaner restriction |
| 58728 | Power steering fluid level w/lamp |
| 58730 | Engine oil level w/lamp |
| 58735 | Led for indicating rear differential lock on |
| 58918 | 32-optical indicator panel |
| 61002 | 3 diode holder container 3A (with + common) |
| 61101 | Diesel fuel heater resistor |
| 61102 | Rheostat for antipollution device (EGR) |
| 61103 | Variable resistance for ignition timer control (KSB) |
| 61106 | Windscreen heater resistor |
| 61124 | Resistance for rearscreen heating |
| 64000 | Electric windscreen washer pump |
| 65000 | Windscreen wiper unit |
| 66005 | Headlamp washer pump |
| 66010 | Headlamp washer timer |
| 68000 | Radio equipment |
| 68001 | Speaker |
| 72016 | 13-pole coupling for 12V connection to trailer |
| 72027 | 38-pole coupling for connection with IVECO |
| 78000 | Solenoid valve for connection with atmosphere from fuel tank for thermal starters |
| 78013 | Pressure regulator solenoid valve |
| 78015 | Solenoid valve to cut out third pumping element |
| 78208 | Transmission total power take-off solenoid valve |
| 78209 | Solenoid valve for antipollution devices (EGR) |
| 78233 | Vehicle raising solenoid valve assembly |
| 78247 | Solenoid valve for electronic injection |
| 78248 | Solenoid valve for variable geometry turbine order |
| 80000 | Motor for right electric window |
| 80001 | Motor for left electric window |
| 82000 | Windscreen defrosting control unit |
| 82010 | Joint between cab-bonnet cable and climate control cable |
| 84020 | Outdoor temperature sensor |
| 85000 | Cigar lighter |
| 85005 | Electrically adjustable heated rear view mirror |
| 85022 | Engine cooling electromagnet coupling |
| 85028 | Locking device for rear differential |
| 85036 | Heated air-suspended seat (driver's side) |
| 85038 | Heated air-suspended seat (driver's opposite side) |

| | |
|-------|--|
| 85130 | Immobilizer |
| 85131 | Volumetric sensor |
| 85132 | Antitheft device self-supplying syren |
| 85150 | 4-channel methane control unit |
| 85151 | EDC injection pump |
| 85152 | Accelerator load sensor (EDC) |
| 85156 | Turbofan air pressure temperature sensor, (EDC) |
| 85157 | Pressure adjustment sensor |
| 86002 | Sensors for front brake shoe wear |
| 86003 | Sensors for rear brake shoe wear |
| 86011 | Electronic control unit, pre/after-heating system |
| 86012 | Electronic control unit for signalling water in fuel filter |
| 86013 | Sensor, water in fuel filter |
| 86020 | Antipollution device control unit (EGR) |
| 86023 | Vehicle raising/lowering control unit |
| 86029 | Electronic control unit for central door locking |
| 86046 | Electronic control unit for trailer lights control |
| 86047 | Electronic control unit for switching on total power takeoff |
| 86060 | Airbag control unit |
| 86061 | Air bag |
| 86062 | Pretightener |
| 88000 | ABS system electronic control unit |
| 88001 | ABS system sensor |

POWER NETWORK

General



Never disconnect the battery from the system with the engine running.

When needing to disconnect the battery from the system, always firstly disconnect the earth cable on the engine from the battery negative terminal.

Before connecting the battery to the system, make sure that the system is well insulated.

Disconnect the battery from the system when charging it.


The purpose of the electric system is to generate, regulate, store and distribute the energy needed to make the vehicle components work.

For this reason the supply of the base electric system is ensured by a generator (14V, 50 – 110A alternator) and a 12 V, 110 Ah battery.

The battery is located in a special compartment on the left front side of the bonnet.

Figure 1

Earth points




7389

EARTH POINTS

m1. Engine earth – m2. Frame earth – m3. Bonnet power earth – ms3. Bonnet signal earth – m4. Bonnet right side earth
m5. Bonnet left side earth – m6. m7. Cab inside earths – ms7. Cab inside signal earth – ms8. Air bag signal earth

Power network assembly

Figure 2




8633

POWER NETWORK ASSEMBLY

- A. Control box – B. Instrument cluster with warning lights – C. Ignition switch – D. Stalk unit – E. Relay/fuse holder Support – F. Starter motor – G. Earth cables of frame and tail lighting components – H. Battery – I. Alternator

Figure 3



73720

POWER NETWORK ASSEMBLY WITH TELMA SPEED LIMITER

- A. Control box – B. Instrument cluster with warning lights – C. Ignition switch – D. Stalk unit – E. Relay/fuse holder Support – F. Starter motor – G. Earth cables of frame and tail lighting components – H. Battery – I. Alternator – L. Relays – M. Electromagnets – N. Ground point – O. Ground cable for Telma speed limiter


Positive network

The battery positive terminal is connected through a 50 mm² cable to terminal 30 of the starter motor. Two 16 mm² and one 6 mm² cables are also connected to the battery positive terminal cable. The first two cables are connected to alternator and interconnection central unit, while the other cable feeds 60A fuse for pre-heating glow plugs central unit.

At the terminal of the battery positive cable in vehicles with ABS a 6 mm² cable connects the 40A fuse that supplies the ABS electronic control unit.

In the vehicles that are provided with a cab/bonnet cable preset for various options, a 4 mm² cable is also connected to battery positive cable pin; via ultrasound weld, it feeds key switch, 38-pole diagnosis connector and instrument panel with warning indicators.


Figure 4



8627

CONNECTIONS TO BATTERY POSITIVE TERMINAL


Figure 5



8628

CONNECTION OF STARTER MOTOR TERMINAL 30 TO BATTERY POSITIVE TERMINAL

Figure 6



8629

POSITIVE NETWORK CONNECTION TO ALTERNATOR

Figure 7




Figure 8





Figure 9



In the immediate vicinity of the battery, there is the control box; this has the task of providing the battery + supply, through internal bridges to the different electric functions of the vehicle.

A 6 mm² cable and a 10 mm² cable are connected to it; through ultrasonic welds they supply certain components and part of the fuses and relays located on the support on the lower left part of the dashboard.

In particular, the components and electric functions supplied by the 6 mm² cable are:

- interior lighting, radio-receiver, cigar lighter
- services cut-off relay during starting
- headlamp washer
- 13-pin current socket
- socket for converter

The 10 mm² cable supplies:

- ignition switch (base vehicle)
- stalk unit (exterior lights and hazard warning)
- stop lights
- horns
- EDC switching on relay
- instrument cluster with warning lights
- modus diagnostics enable relay
- heated fuel filter
- climate control system
- door locking


Lastly, a 2.5 mm² cable can be connected to the control box which supplies fuse 33 (20A), where applicable, of the relay/fuse holder support relating to the additional heater control unit.

Negative network

The battery negative terminal is connected to with a brown 50 mm² cable to the earth point **m1** to be found on the left-hand side of the crankcase, next to the starter motor. From this point, two copper braids are connected to earth points **m2** on the front of the left sidemember and **m3**, on the bonnet under the vacuum servobrake. At **m3** the wirings concerning the frame and engine are connected. Near **m3**, there is another earth point, called **ms3** which, through a 2.5 mm² cable performs the signal earth function for the ABS electronic control unit.

A 6 mm² cable also connects the battery cable pin to the ultrasound weld on which the earth cables of immobilizer electronic central unit, EDC system function control switch, EDC electronic central unit and diagnosis connector converge.


Figure 10



8623

EARTH POINT ON FRAME


Figure 11



8622

EARTH POINT ON ENGINE


Figure 12



8624

EARTH POINT ON LOWER BONNET (m3–ms3)


Figure 13



8625

EARTH POINT ON BONNET RIGHT-HAND SIDE


Figure 14



8626

EARTH POINT ON BONNET LEFT-HAND SIDE


Figure 15



7379

EARTH POINT ON CAB RIGHT-HAND SIDE

Figure 16



7380

EARTH POINT ON CAB LEFT-HAND SIDE

Earth point **m4** to which the components concerning the front and right side lighting, windscreen wiper, windscreen washer, windscreen washer pump and air cleaner clogged signal switch are connected, is located in the bonnet near the right front direction indicator.

Earth point **m5** to which the components concerning the left front lighting and the fuel oil heating device are connected, is located near the left front direction indicator.


Earth points **m6** and **m7** are respectively located on the right and left of the cab, near the upper hinges of the doors. To these are connected the components in the dashboard (stalk unit, instruments, warning lights, switches), in the doors, where applicable (power window switches, motors for power window/door locking, rear-view mirror aiming) and in the upper part of the cab (roof lamp, front clearance lights).

Near **m7** earth point, there is the **ms7** signal earth; from here, a 1.5 mm² cable is connected to an ultrasound weld towards which the signal earth cables of cab/bonnet cable electronic components like steering column stalk and instrument panel with warning indicators for diagnosis converge.









Lastly on the floor panel, next to the handbrake lever, there is an earth point (**ms8**) specific for the air bag electronic control unit.

Earth points on the vehicle

Figure 17



7390

| Earth connection | Location | Components concerned |
|---|--|---|
|  <p>m1</p> | Left crankcase | Battery negative terminal–connection to earth points m2 and m3 |
|  <p>m2</p> | Front part of left sidemember | Connection to earth point m1 |
|  <p>m3 ms3</p> | Lower bonnet (under vacuum power steering) | Connection to earth point m1 – components on frame and engine – electronic ABS control unit |
|  <p>m4 m5</p> | Bonnet (near right and left side direction indicator) | Fuel oil heating resistance – air cleaner clogged signal switch – front and side lights – windscreen washer pump |
|  <p>m6</p> | Cab inner right side | Stalk unit – windscreen electric demister control unit – cigar lighter– ashtray light – hazard warning light switch – radio–receiver unit |
|  <p>m7</p> | Cab inner left side | Instrument cluster with warning lights – front clearance lights – headlamp aiming control – relays on relay/fuse holder support – interior lighting |
|  <p>ms7</p> | Cab inner left side | Instrument cluster with warning lights – stalk unit – low engine coolant fluid level indicator control – transmitter for electronic tachograph |
|  <p>ms8</p> | Centre floor | Air bag electronic control unit |

CONCEPT OF EARTH AND ELECTROMAGNETIC COMPATIBILITY

The electric system is traditionally a single-pole system. The body, the frame, the metal container of electromechanical components act as equipotential return conductor to the generator, as any point of their metal structure or any negative terminal not isolated is at the same reference potential or EARTH. This is why the earth has been chosen as reference to the whole system, conventionally giving it the value of zero.

Due to obvious reasons of construction, in the negative network of the system there are various earth points located on the vehicle in relation to the location of the components on the frame, engine and body.

On the other hand, ideally, all the equipment should be connected to **only** one earth point in order to provide them, particularly for electronic devices, a clearly defined earth reference.


For the above-mentioned reasons it is necessary to distinguish the **supply earth** or system earth, characterised by strong direct current intensity (> 1 A for electromechanical components), from the **analogue earth**, characterised by wave shapes at determinate frequencies and very low current intensity (mA, μ A) of electronic systems.

The definition of signal earth or analogue earth depends on the sensitivity of the electronic systems to EMC (electromagnetic compatibility), as parasite signals emitted by the systems on board or outside the vehicle, induce failures and/or deterioration of the systems themselves. The best solution for a signal earth is connection with the battery negative terminal.

In order to minimise both continuous and transient disturbance or interference generated by parasite radiation, **it is of the utmost importance** to always bear in mind that the satisfactory efficiency of the reference plane or system earth depends on the excellent conductivity characteristics (contact resistance tending towards zero) in each of its connection points.

Briefly, we can say that the earth understood as equipotential electrical conductor, i.e. as potential reference for all the electric/electronic components on board, is subdivided into system earth and analogue earth.

Figure 18



6616

IDEAL EQUIPOTENTIAL EARTH NETWORK
Ba. Battery – R. Loads – Rz. Frame impedance – M_1, M_2, M_3 . Earth


Practical advice

The negative cables connected to an earth point must be as short as possible and connected to one another in a "star" connection, trying to tighten them neatly and adequately.

Additionally, for electronic components the following instructions should absolutely be followed:

- Electronic control units must be connected to the system earth when they have a metal container.
- The negative cables of electronic control units must be connected to both a system earth point, for example the dashboard earth (avoiding "serial" or "chain" connections), and to the negative terminal of the battery/ies.
- Though they are not connected to the system earth/battery negative terminal, analogue earths (sensors) must be perfectly insulated. Therefore, particular care should be given to the parasite resistances of the terminals: oxidation, clinching defects, etc.
- In the presence of jointing connectors the unscreened section **d**, near them, should be as short as possible.
- The cables should be laid on parallel with the reference plane, i.e. as near as possible to the frame/body structure.
- Additional electromechanical systems should be carefully connected to the system earth and must not be set at the side of the cables of electronic components.

Figure 19



SCREENING BY METAL BRAID OF A CABLE TO AN ELECTRONIC COMPONENT
C. Connector – d. Distance → 0

88039

Ultrasonic cable welding

In order to eliminate earth, supply, outer/inner lighting bridges between components, ultrasonic welding points have been used. These are not easily identifiable as they appear along the cables inside the corrugated tube of the various harnesses and they are isolated from the cables through heat-shrinking sheaths or insulating plastic.


Generally, the cables of the components converge on one side in the different welding points, while on the other only one cable connects them with the earth or supply.

It is also possible to have several welding points connected to one another in which several cables converge on both sides of the welding. In this case, the earth or supply cable will be connected to the last weld of the series.


Ultrasonic welding brings considerable advantages, including:

- reduction of electromagnetic interference outside the vehicle
- the almost total reliability of the electric system, due to elimination of the bridges, with lower possibility of faults.

Figure 20





4886



8576

ULTRASONIC WELDING
A. Wiring diagram – B. Technical layout



8577


CONNECTION BETWEEN COMPONENTS
A. Connection through bridges – B. Connection through ultrasonic welding point

MAIN COMPONENTS OF POWER NETWORK

BOSCH KCBI 14V 110A Alternator

03000

Figure 21



WIRING DIAGRAM

8649

Specifications for use



Vehicle electric system rated voltage: 12 V
 Suitable for coupling with battery of any capacity
 It must work with the battery connected.

Connection with inverted polarity is not allowed.

Operating specifications

Rated voltage 14 V
 Rated current delivery 110A
 Drive side direction of rotation clockwise
 Maximum continuous speed $\leq 12.000 \text{ min}^{-1}$
 Storage temperature $-40 \text{ }^\circ\text{C} / +110 \text{ }^\circ\text{C}$

Figure 22




TECHNICAL VIEW

8656

EV 12V – 2.3 kW Starter motor


Figure 23



WIRING DIAGRAM

74023

Figure 24




PERSPECTIVE VIEW

08000

8642

Figure 25



PERSPECTIVE BLOWN-UP VIEW

1. Support – 2. Pinion engagement control electromagnet – 3. Pinion – 4. Pinion engagement fork – 5. Rotor – 6. Frame – 7. Inductors – 8. Brush holder support – 9. Cover – 10. Screw

5260

Fast diagnosis

| Defect | Possible causes | Remedy |
|--|--|---|
| Low drawing torque | 1. Low battery | Recover |
| | 2. Oxidized or loose circuit connections | Check starter motor and battery connections |
| | 3. Faulty brushes | Check brush slide length and pressure |
| | 4. Field coils short circuited | Replace coils |
| | 5. Rotor cut out or short circuited | Replace rotor |
| | 6. Oval collector | Grind correct or replace |
| Low drawing torque but engine does not start | 1. Defective free wheel or electromagnet | Replace |
| Pinion disconnected | 1. Worn toothed crown | Recover |


Battery

The battery shown below has a 12Vdc 110Ah 460 A power supply voltage and is installed on the left side of the engine compartment near the EDC control unit (Ref. A of figure).

Requirements

- Case and cover in polypropylene plastics PR. 50.100. Matt white case.
- C.S. plugs, black. Grids: positive and negative made of Pb Ca.
- Cover integral polypropylene
- Separator: envelope-type polyethylene
- Battery for "tropical duty" marked with red color.
- "Environmental precautions" plate according to Law no. 126 of 10/04/91 "Standards for user information".
- Adhesive label with "Selective disposal" acc. to EEC Directive no. 93/86.

Figure 26



73721


Fast diagnosis

| Defect | Possible causes | Remedy |
|--------------------------------|--|---|
| Start defect | 1. Low battery | Check battery charge; if regular check recharge circuit |
| | 2. Loose, oxidized or burnt out contacts | Recover |
| | 3. Starter circuit defective | Cf. start section |
| Low voltage at component leads | 1. Battery at half power | Check battery charge; if regular check recharge circuit |
| | 2. Oxidized connections | Sand and replace |
| Electrolyte level often low | 1. Over voltage | Check recharge circuit and/or connection tightness |

Ignition switch

52502


Figure 27



WIRING DIAGRAM

1171


Figure 28



SWITCHING SEQUENCE
0. Stop – I. Drive – II. Starting

1125

Figure 29



8654


PERSPECTIVE VIEW WITH ASSOCIATED CONNECTIONS AND KEY ROTATION TECHNICAL LAYOUT

| Position | Under current | Live circuit | Terminal | Function | Cable colour code |
|----------|----------------------|----------------------|------------|--|-------------------|
| 0 | 30 | – | 30 | Supply | 7777 |
| I | 30 – 15 30 – 15/A | Services Users | 15 15/A | Services User cut-off relay during starting | 8887 8850 |
| II | 30 – 15 30 – 50 | Services Starting | 50 | Starting | 8888 |

Interconnection center

This is a shunt center distributing battery positive power via internal jumpers.


Figure 30



8630

PERSPECTIVE VIEW OF THE JUNCTION BOX AND ASSOCIATED CONNECTORS AND THEIR SURFACE WITH CONTACT BLADES

Figure 31




73722

VIEW OF THE ENGINE COMPARTMENT LOCATION

General remote control switch (T.G.C.)

The general remote control switch is installed in vertical position to the vehicle chassis near the battery using special mounting brackets. The remote control switch closing is controlled by switch 53008 and the associated relay to energize TGC from inside cab 25226.

Figure 32



73717

GENERAL REMOTE CONTROL SWITCH

ONBOARD CABLES

Components of the injection system (E. 8140)

1. Injector
2. Injector retainer screw and bracket
3. Injector retainer screw and bracket
4. Rail sound-absorbing protection (pressure accumulator)
5. High pressure pipe
6. Pump backflow pipe
7. High pressure pump
8. Thermal starter supply pipe
9. Fuel outlets unit

Components of the injection system


1. Thermal starter supply pipe
2. Brackets
3. Brackets
4. Connection pipe with intercooler
5. Thermal starter
6. Piping
7. After warming solenoid valve
8. Intake manifold
9. Boosting air pressure sensor

Engine cable

All engine cabling is in one bundle assembly.


In case of need replace the entire bundle assembly and not individual cables or cable sections.

Figure 33




COMPONENTS OF THE INJECTION SYSTEM

Figure 34



COMPONENTS OF THE FUEL SUPPLY SYSTEM –
INJECTION


Figure 35



CABLE ON ENGINE

8140.43C ID/TCA (.11) ENGINE HARNESS


Figure 36



74002

Figure 37

WELDING 8140.43C




74003

| Component code | Description |
|----------------|--|
| 00000 | Ground |
| 03000 | Self-rectifying alternator with incorporated voltage regulator |
| 08000 | Starter motor |
| 12012 | A/C compressor |
| 19005 | Thermostarter |
| 20000 | Starter battery |
| 28002 | Engine shutdown solenoid |
| 42550 | Engine oil low pressure indicator switch |
| 44044 | Low engine oil level indicator control |
| 47030 | Transmitter for engine water temperature thermometer |
| 47104 | Engine cooling electromagnetic coupling |
| 47105 | Diesel oil heating switch |
| 47109 | Spark advance variator switch (KSB) |
| 48035 | RPM sensor |
| 61103 | Variable resistance for spark advance variator (KSB) |
| 70066 | 40A one-way fuse holder |
| 72030 | Engine service harness connector to cab/hood harness |
| 78000 | Solenoid valve for fuel tank connection to atmosphere |
| 85022 | Electromagnetic coupling for engine cooling |
| 86011 | Pre-post-heating electronic control unit |

8140.43S UNIJET (.13) ENGINE HARNESS

Figure 38




74008

| Component code | Description |
|----------------|--|
| 00000 | Ground |
| 03000 | Self-rectifying alternator with integrated voltage regulator |
| 08000 | Starter motor |
| 12012 | A/C compressor |
| 20000 | Starter battery |
| 42550 | Engine oil low pressure indicator switch |
| 44044 | Low engine oil level indicator control |
| 47030 | Transmitter for engine water temperature thermometer |
| 72030 | Engine service harness connector to cab/hood harness |
| 78000 | Solenoid valve for fuel tank connection to atmosphere |
| 85022 | Electromagnetic coupling for engine cooling |

| Component code | Description |
|----------------|--------------------------------------|
| 85150 | EDC center |
| I | Connection to hood cab cable |
| 47035 | Coolant temperature sensor |
| 78015 | Radialjet pump control electro valve |
| 85157 | Fuel pressure sensor |
| 78247 | Electrical injection electro valve |
| 48042 | rpm sensor on distributor |
| 48035 | Engine rpm sensor |
| 78013 | Pressure adjustment electro valve |
| 47106 | Fuel heat on switch |
| 85156 | EDC blower air pressure sensor |
| 61101 | Fuel heat resistor |

FIA UNIJET (.10 - .12) ENGINE HARNESS


Figure 40



| Component code | Description |
|----------------|--|
| 00000 | Ground |
| 03000 | Self-rectifying alternator with integrated voltage regulator |
| 08000 | Starter motor |
| 12012 | A/C compressor |
| 20000 | Starter battery |
| 42550 | Engine oil low pressure indicator switch |
| 44044 | Low engine oil level indicator control |
| 47030 | Transmitter for engine water temperature thermometer |
| 85022 | Electromagnetic coupling for engine cooling |
| CI | Engine service harness connector to cab/hood harness |

FIA UNIJET WITH EDC16 (.10 -.12 -.14) ENGINE HARNESS

Figure 40/1




101861

| Component code | Description |
|----------------|--|
| 03000 | Self-rectifying alternator with integrated voltage regulator |
| 08000 | Starter motor |
| 12012 | A/C compressor |
| 42550 | Engine oil low pressure indicator switch |
| 44044 | Low engine oil level indicator control |
| 47030 | Transmitter for engine water temperature thermometer |
| 85022 | Electromagnetic coupling for engine cooling |
| CI | Engine service harness connector to cab/hood harness |

FIC UNIJET WITH EDC16 (.10 -.12 -.14) ENGINE HARNESS

Figure 40/2




101862

| Component code | Description |
|----------------|--|
| 03000 | Self-rectifying alternator with integrated voltage regulator |
| 08000 | Starter motor |
| 12012 | A/C compressor |
| 42550 | Engine oil low pressure indicator switch |
| 42608 | Three-level pressure switches |
| 44044 | Low engine oil level indicator control |
| 47030 | Transmitter for engine water temperature thermometer |
| 85022 | Electromagnetic coupling for engine cooling |
| C1 | Engine service harness connector to cab/hood harness |
| C60 | Three-level pressure switch cable joint with cabin/hood cables |

INJECTION CABLE - FIA (.10 - .12) WITH AND WITHOUT EGR

Figure 41



74268

| Component code | Description |
|----------------|---|
| 85150 | EDC center |
| 1 | Connection to hood cab cable |
| 47035 | Coolant temperature sensor |
| 85157 | Fuel pressure sensor |
| 78247 | Electrical injection electro valve |
| 48042 | rpm sensor on distributor |
| 48035 | Engine rpm sensor |
| 78013 | Pressure adjustment electro valve |
| 47106 | Fuel heat on switch |
| ● 85156 | EDC blower air pressure sensor |
| 61101 | Fuel heat resistor |
| 19010 | Preheat plug |
| 25231 | Plug insert centre |
| 70064 | 1-way fuse holder |
| * 85159 | Environment air temperature and pressure sensor for EDC |
| * 78209 | EGR electro valve |

- Without EGR
- * With EGR

TRUCK CHASSIS CABLE

Figure 42





Figure 43




74018

| Component code | Description |
|----------------|--|
| 22000 | Horn |
| 34000 | Multifunctional rear floodlight |
| 35000 | License plate light |
| 40032 | Transmitter for tachometer and tachograph |
| 42351 | Air filter clogged sensor |
| 44031 | Fuel oil level indicator transmitter with contact for min. level indicator |
| 44033 | Brake fluid low indicator control |
| 47106 | Diesel oil heating switch |
| 53503 | Backup light switch |
| 61101 | Diesel oil preheating resistor |
| 85151 | EDC injection pump |
| 86002 | Front wheel pad wear indicator sensors |
| 86003 | Rear wheel pad wear indicator sensors |
| 86012 | Water-in-fuel-filter indicator sensor |
| C2-C4 | Chassis harness connector to cab/hood cables |
| C3 | Chassis harness connector to side clearance lights |
| M2 | Ground |

A.B.S. PARALLEL CABLE


Figure 44



74015

Figure 45

WELDING




74016

| Component code | Description |
|----------------|---|
| 20000 | Starter battery |
| 70060 | 40A one-way fuse holder |
| 72048 | Cab-hood harness to ABS harness connector |
| 88000 | ABS electronic control unit |
| 88001 | ABS sensor |

AIR-BAG CABLE WITH ONE-CONNECTOR CONTROL UNIT


Figure 46



| Component code | Description |
|----------------|---|
| 86060 | AIRBAG control unit |
| 86061 | Passenger airbag – Driver airbag |
| 86062 | Passenger pretensioner – Central pretensioner – Driver pretensioner |
| II | Dashboard harness connector |

AIR-BAG CABLE WITH TWO-CONNECTOR CONTROL UNIT

Figure 47




74022

| Component code | Description |
|----------------|---|
| 86060 | AIRBAG control unit |
| 86061 | Passenger airbag – Driver airbag |
| 86062 | Passenger pretensioner – Central pretensioner – Driver pretensioner |
| II | Dashboard harness connector |


VAN INTERIOR DOME LAMP CABLES I/2

Figure 48



74012

Figure 49



| Component code | Description |
|----------------|--|
| C12 | Cab-hood harness to dome lamp harness connector |
| C15 | Dome lamp connectors to slide door bridle |
| C16 | Dome lamp connectors to electrical lock contacts |
| 37001 | Front clearance lamp |
| 39022 | Interior door lamp with adjustable spot |
| 39026 | Side door lighting dome lamp |
| 42102 | Parking brake on indicator switch |
| 53509 | Interior lighting switch |

VAN INTERIOR DOME LAMP CABLES 2/2

Figure 50





Figure 51




74014

| Component code | Description |
|----------------|---|
| 37002 | Rear clearance lamp |
| 39025 | Liftgate lighting dome lamp |
| C11 | Chassis harness connector to rear dome lamp harness |

TRUCK INTERIOR DOME LAMP CABLES


Figure 52



JUNCTION CONNECTORS

Connection between cab/bonnet cable and injection cable (Unijet)



Figure 53



| Ref. | Ref. (FIA) | Cable colour code | Function |
|------|------------|-------------------|---|
| I 1 | | 5000 | To pin 36 of EDC electronic control unit |
| 2 | 3 | 8150 | Fuel pump engagement relay |
| 3 | 4 | 7740 | Relay engagement for engine cooling electromagnetic joint control |
| 4 | 5 | 9990 | Air conditioning compressor switching off |
| 5 | 6 | 8159 | Fuel oil heating circuit switching on |
| 6 | 8 | 0000 | Earth |
| 7 | 1 | 5577 | Fuel oil heating resistance supply |
| 8 | 16 | 0077 | Fuel oil heating resistance earth |
| | 10 | 8150 | Preheat plug centre positive (pin-86) |
| | 11 | 1310 | Preheat plug centre control (pin-D1), (EDC pin-B37) |
| | 12 | 1311 | Preheat plug centre control (pin-ST), (EDC pin-B42) |
| | 13 | 0000 | Preheat plug centre mass (pin-31) |
| | 2 | 8847 | Speed adjustment sensor positive |
| | 7 | - | Free |
| | 9 | - | Free |
| | 14 | - | Free |
| | 15 | - | Free |



Connection between cab/bonnet cable and air bag cable

Figure 54



8587

8590




8591


| Ref. | Cable colour code | Function |
|------|-------------------|--|
| II | 1 6722-AR | Supply (+15) |
| | 2 6750-AR | Supply (+15) |
| | 3 8087-S | Supply (+15) for air bag electronic control unit |
| | 4 2292-BR | To diagnostic connector |
| | 5 0000-HN | Earth |
| | 6 6711-G | To air bag failure warning light |

Connection between cab/bonnet cable and rear differential lock cable



Figure 55



8587



8592




8593

| Ref. | Cable colour code | Function |
|------|-------------------|--|
| III | 1 2222 | Tachometric signal |
| | 2 8879 | Supply (+15) |
| | 3 7777 | Supply (+30) |
| | 4 - | Spare |
| | 5 3400 | Rear differential lock engagement |
| | 6 6660 | To rear differential lock on warning light |

Connection between cab/bonnet cable and cable for tachometer



Figure 56





| Ref. | Cable colour code | Function |
|--------------------|-------------------|---|
| 4001IA (white) | 1 7772 | Supply (+30) |
| | 2 - | Spare |
| | 3 5156 | Supply (+15) |
| | 4 - | Spare |
| | 5 0000 | Earth |
| | 6 0000 | Earth |
| | 7 - | Spare |
| | 8 - | Spare |
| 4001IB (yellow) | 1 5517 | Supply (+15) |
| | 2 0058 | Earth |
| | 3 5517 | Tachometric signal |
| | 4 5516 | To transmitter for tachometer |
| | 5 - | Spare |
| | 6 - | Spare |
| | 7 - | Spare |
| | 8 - | Spare |
| 4001ID (brown) | 1 - | Spare |
| | 2 - | Spare |
| | 3 - | Spare |
| | 4 2400 | To instrument cluster with warning lights |
| | 5 - | Spare |
| | 6 5517 | Tachometric signal |
| | 7 2300 | To instrument cluster with warning lights |
| | 8 - | Spare |

Connection between frame cable and right tail lamp cable

Figure 57



8597




8598

8599


| Ref. | Cable colour code | Function |
|--------|-------------------|------------------------------|
| 72025A | 1 2283 | Rear fog guard |
| | 2 0000 | Earth |
| | 3 4418 | Rear roof lamp supply |
| | 4 0003 | Switching on interior lights |

Connection between frame cable and right tail lamp cable



Figure 58



8597



8600







8601

| Ref. | Cable colour code | Function |
|---------------|-------------------|---------------------|
| 72025B | 1 1125 | Direction indicator |
| | 2 1172 | Stop light |
| | 3 3335 | Side light |
| | 4 2227 | Reversing light |

Connection between frame cable and left tail lamp cable

Figure 59



8597


8602

8603

| Ref. | Cable colour code | Function |
|--------|-------------------|-----------------|
| 72026A | 1 2227 | Reversing light |
| | 2 2283 | Rear fog guard |
| | 3 0000 | Earth |

Connection between frame cable and left tail lamp cable



Figure 60





| Ref. | Cable colour code | Function |
|----------|-------------------|---------------------|
| 1 | 1120 | Direction indicator |
| 72026B 2 | 1177 | Stop light |
| 3 | 3334 | Side light |

Connection between cab/bonnet cable and roof lamp cable inside cab

Figure 61



72031



8587


8608

8609

| Ref. | Cable colour code | Function |
|--------------|-------------------|---|
| 72031 | 1 | 4418 Supply (+30) |
| | 2 | 3330 Left front clearance light |
| | 3 | 3339 Right front clearance light |
| | 4 | - Spare |
| | 5 | 6662 Handbrake on signal |
| | 6 | 0000 Earth |
| | 7 | 8904 To motor for side door closing control (van) |
| | 8 | 8903 To motor for side door closing control (van) |
| | 9 | 9074-0204 To switch for turning on interior lights (van) |
| | 10 | 9074-0205 To switch for turning on interior lights (van) |
| | 11 | - Spare |
| | 12 | 0000-0003 Turning on roof lamp |

Connection between cab/bonnet cable and 13 pin current socket cable or rear door opening/closing cable (van)





Figure 62



| Ref. | Cable colour code | Function |
|--------|-------------------|--|
| 72032A | 1 8901 | To pin 8 connector A of electronic control unit for central door locking |
| | 2 8902 | To pin 7 connector A of electronic control unit for central door locking |
| | 3 7777 | Supply (+30) |
| | 4 7777 | Supply (+30) |
| | 5 1386-6120 | Trailer direction indicator on signal |
| | 6 8881 | Supply (+15) |

Connection between cab/bonnet cable and brake wear/air cleaner clogged cable

Figure 63



8587

8598


8601

8599


| Ref. | Cable colour code | Function |
|-------|-------------------|----------------------------|
| 72036 | 1 8016 | Brake wear signal |
| | 2 8016 | Brake wear signal |
| | 3 0000 | Earth |
| | 4 6663 | Air cleaner clogged signal |

Connection between cab/bonnet cable and self-levelling suspension cable



Figure 64



8587



8592




8593


| Ref. | Cable colour code | Function |
|---------------|-------------------|---|
| 72037A | 1 | 8090 Supply (+15) |
| | 2 | 8091 To pin 26 of electronic control unit for vehicle raising/lowering control |
| | 3 | 1194 To 38-pin diagnostic connector (cell 15) |
| | 4 | 7772 Supply (+30) |
| | 5 | 8420 Suspension levelling control |
| | 6 | 2294 To 38-pin diagnostic connector (cell 16) |

Connection between cab/bonnet cable and self-levelling suspension cable

Figure 65





8587



72037B

8612




8613

| Ref. | Cable colour code | Function |
|-----------------|-------------------|--|
| 1 | 6008 | Self-levelling suspension system failure signal |
| 72037B 2 | 5411 | Tachometric signal |
| 3 | 1363 | Positive with vehicle stop signal switch engaged |

Connection between cab/bonnet cable and total power takeoff cable


Figure 66



| Ref. | Cable colour code | Function |
|---------------|----------------------|---|
| 72038A | 1 9133 | To electronic control unit for switching on total power takeoff (connector P2 cell 3) |
| | 2 9134 | To electronic control unit for switching on total power takeoff (connector P2 cell 4) |
| | 3 9135 | To electronic control unit for switching on total power takeoff (connector P2 cell 5) |
| | 4 9136 | To electronic control unit for switching on total power takeoff (connector P2 cell 6) |
| | 5 0056 | To electronic control unit for switching on total power takeoff (connector P2 cell 7) |
| | 6 0057 | To electronic control unit for switching on total power takeoff (connector P2 cell 8) |

Connection between cab/bonnet cable and total power takeoff cable

Figure 67



8587


8612

8613


| Ref. | Cable colour code | Function |
|-----------------|-------------------|--|
| 1 | 9131 | To switch for total power takeoff engaged signal |
| 72038B 2 | 0000 | Earth |
| 3 | - | Spare |

Connection between cab/bonnet cable and antitheft cable

Figure 68





8587



72039A

8608




8609

| Ref. | Cable colour code | Function |
|--------|-------------------|---------------------------------------|
| 72039A | 1 7741-8911 | Supply (+30) |
| | 2 - | Spare |
| | 3 8879-4442 | Supply (+15) |
| | 4 9070-0200 | To switch for locking rear door (van) |
| | 5 1545-8914 | To volumetric sensor |
| | 6 8912 | To volumetric sensor |
| | 7 8913 | To volumetric sensor |
| | 8 8915 | To volumetric sensor |
| | 9 8916 | To volumetric sensor |
| | 10 0000 | Earth |
| | 11 - | Spare |
| | 12 - | Spare |

Connection between cab/bonnet cable and antitheft cable with central door locking

Figure 69



8587


8592

8593

| Ref. | Cable colour code | Function |
|--------|-------------------|---------------------------------|
| 72039B | 1 8909-9140 | Supply (+15) |
| | 2 0000 | Earth |
| | 3 8910-9141 | Supply (+30) |
| | 4 - | Spare |
| | 5 - | Spare |
| | 6 9073-9142 | To self-powered siren for alarm |

Connection between cab/bonnet cable and right door cable


Figure 70




| Ref. | Cable colour code | Function |
|-------|-------------------|---|
| 72040 | 1 | 8861 Supply (+15/A) |
| | 2 | 0000 Earth |
| | 3 | 8862-0000 Connection between switches for passenger's door power window |
| | 4 | 8002-0026 Connection between switches for passenger's door power window |
| | 5 | 8830 Heated rear-view mirror |
| | 6 | - Spare |
| | 7 | 8859-8809 Electrically-operated aimable mirror |
| | 8 | 8857-8806 Electrically-operated aimable mirror |
| | 9 | 8858-8808 Electrically-operated aimable mirror |
| | 10 | - Spare |
| | 11 | 1111 To connection between cab/bonnet cable and left door cable |
| | 12 | 0000 Earth |
| | 13 | - Spare |
| | 14 | - Spare |
| | 15 | 8905 To door closing control motor |
| | 16 | 8906 To door closing control motor |
| | 17 | - Spare |
| | 18 | - Spare |
| | 19 | - Spare |
| | 20 | - Spare |

Connection between cab/bonnet cable and left door cable

Figure 71





8587



72041

8614




8615


| Ref. | Cable colour code | Function | |
|-------|-------------------|-----------|---|
| 72041 | 1 | 8829 | Supply (+15) |
| | 2 | 8861 | Supply (+15/A) |
| | 3 | 8862 | Connection between switches for passenger's door power window |
| | 4 | 8002 | Connection between switches for passenger's door power window |
| | 5 | 8830 | Heated rear-view mirror |
| | 6 | 0000 | Earth |
| | 7 | 8859-8809 | Electrically-operated aimable mirror |
| | 8 | 8857 | Electrically-operated aimable mirror |
| | 9 | 8858 | Electrically-operated aimable mirror |
| | 10 | 0026 | Earth |
| | 11 | 1111 | To connection between cab/bonnet cable and left door cable |
| | 12 | 0000 | Earth |
| | 13 | 5532 | To outside temperature sensor |
| | 14 | 5532 | To outside temperature sensor |
| | 15 | 8905 | To door closing control motor |
| | 16 | 8906 | To door closing control motor |
| | 17 | - | Spare |
| | 18 | - | Spare |
| | 19 | - | Spare |
| | 20 | - | Spare |

Connection between cab roof lamp and left front clearance light cable



Figure 72



8587



8616




8617


| Ref. | Cable colour code | Function |
|--------|-------------------|-----------------------|
| 72042A | 1 0000 | Earth |
| | 2 3330 | Front clearance light |

Connection between cab roof lamp and right front clearance light cable



Figure 73



8587



8616




8617

| Ref. | Cable colour code | Function |
|--------|-------------------|-----------------------|
| 72042B | 1 0000 | Earth |
| | 2 3330 | Front clearance light |

Connection between cab/bonnet cable and fog lamp cable


Figure 74




| Ref. | Cable colour code | Function |
|-------|-------------------|-----------|
| 72043 | 1 0000 | Earth |
| | 2 2228 | Fog lamps |

Connection between right tail light cable and rear roof lamp cable

Figure 75





8587



72046

8590




8591


| Ref. | Cable colour code | Function |
|-------|-------------------|---|
| 72046 | 1 0003 | Switching on roof lamp |
| | 2 4418 | Supply (+30) |
| | 3 0000 | Earth |
| | 4 1125 | Positive with direction indicators/hazard warning lights on |
| | 5 1172 | Additional stop light |
| | 6 0000 | Earth |

Connection between frame cable and side clearance lights cable

Figure 76





8597



72047

8602




8603


| Ref. | Cable colour code | Function |
|-------|-------------------|-------------------------------------|
| 72047 | 1 0000 | Earth |
| | 2 3334 | Vehicle right side clearance lights |
| | 3 3335 | Vehicle left side clearance lights |

Connection between cab/bonnet cable and ABS cable



Figure 77



8587



8612




8613


| Ref. | Cable colour code | Function |
|--------|-------------------|---|
| 72048A | 1 2888-8817 | To 38-pin diagnostic connector (cell 4) |
| | 2 - | Spare |
| | 3 1888-8818 | To 38-pin diagnostic connector (cell 3) |

Connection between cab/bonnet cable and ABS cable

Figure 78





8587



72048B

8592




8593

| Ref. | Cable colour code | Function |
|---------------|--------------------|--|
| 72048B | 1 8847 | Supply (+15) |
| | 2 1173 | Positive with switch for vehicle stop engaged signal |
| | 3 0315 | Switching off retarder |
| | 4 6005-6674 | ABD device on signal |
| | 5 6673 | EBD device failure signal |
| | 6 6670 | ABS device failure signal |

Connection between cab/bonnet cable and climate control system cable

Figure 79




8587

8592

| Ref. | Cable colour code | Function |
|---------------|-------------------|-------------------------------|
| 82010A | 1 7551-R | Supply (+30) |
| | 2 4411-H | Positive with side lights on |
| | 3 0000-M | Earth |
| | 4 7711-R | Supply (+15/A) |
| | 5 5532-C | Outside temperature detection |
| | 6 5532-CN | Outside temperature detection |

Connection between cab/bonnet cable and climate control system cable


Figure 80




| Ref. | Cable colour code | Function |
|--------|-------------------|--|
| 82010B | 1 8163-L | To set of 3 switches for coolant fluid pressure signal |
| | 2 - | Spare |
| | 3 5532-G | To instrument cluster with warning lights (connector B pin 11) |

Connection between cab/bonnet cable and climate control system cable

Figure 81





8587



82010C

8604



8605

| Ref. | Cable colour code | Function |
|--------|-------------------|--|
| 82010C | 1 1196 | To 38-pin diagnostic connector (cell 13) |
| | 2 — | Spare |
| | 3 2296 | To 38-pin diagnostic connector (cell 14) |

VENDOR-DERIVED BUS VERSION

General Information


Within this handbook, school-buses are included in the Bus version. If compared to other vehicles, Buses are provided with different interior lighting harness.

The TGC switch position on dashboard panel is shown in the Push-button location Figure 82 while the main switch is located in the engine compartment near the oil filter (Figure 83). To turn the TGC off, turn the ignition key-switch to STOP and turn off the general safety switch 52029 Figure 84 ref. 1, on the left of the steering wheel.

A perspective view of the interior lighting harness is provided in Figure 85.

Figure 84 ref. 2 shows the fan control switch.


Figure 82



73728

TGC CONTROL SWITCH


Figure 83



73717

VOLTAGE MAINS REMOTE SWITCH

Figure 84




73712

1. General safety switch – 2. Fan control switch

Perspective view of Vendor-derived Bus version interior lighting harness

Figure 85



73716

1. Interior lighting – 2. Driver loudspeaker provisions – 3. Fan

Diagnostic connector



Near the positive terminal of the battery there is a diagnostic connector. It is fastened by 2 screws to a special bracket fitted on the body and access to it is gained by unscrewing the protective cap; suitably connected to the diagnostic system (IWT, MODUS), it allows quick identification of the cause of faults in the various electronic devices.

The diagnosis connector on FI engine vehicles is located on the conveyor unit lower part on the passenger side.

The table on the following page shows the correspondence between the various electronic systems and the connector pins referring to them.

NOTE The connector shown is seen from the pin side.


Figure 86



8620

38-PIN DIAGNOSTIC CONNECTOR

Figure 87



8621

IDENTIFICATION OF THE PINS OF THE 38-PIN DIAGNOSTIC CONNECTOR

| System | Pin | Function |
|---|-----|------------|
| EDC/EGR/Methane | 1 | L |
| | 2 | K |
| ABS/EBD/ABD | 3 | L |
| | 4 | K |
| Air Bag/Retarder | 6 | K |
| Tachometer (connector A cell 2 instrument cluster) | 8 | K |
| Supply +15/A services | 11 | Input |
| Immobilizer/Central door locking/Alarm | 12 | K |
| Climate control system | 13 | L |
| | 14 | K |
| Self-levelling suspension | 15 | L |
| | 16 | K |
| Engine timing signal (connector B pin 28 EDC control unit) Engine timing earth (battery -) | 23 | - |
| | 24 | Screening |
| Supply +30 | 27 | Battery +V |
| Engine rpm | 28 | RPM |
| Vehicle speed | 29 | - |
| Earth | 30 | - |


With EDC16: pins 1/23 are not connected.

Can Line pin 21/22.


The unused pins are not indicated.

RELAY AND FUSE HOLDER SUPPORT

Figure 88



8631



Identification of fuses

| N. | Functions | |
|-----|---|-----------|
| 1. | Additional heater | 30 |
| 2. | Immobilizer/Warming/EDC | 5 |
| 3. | – | – |
| 4. | Instrument cluster (+30) | 5 |
| 5. | Instrument cluster (+15) | 5 |
| 6. | Stalk unit (rear fog guard, flasher) | 5 |
| 7. | Stalk unit (low beams) | 10 |
| 8. | Stalk unit (high beams) | 15 |
| 9. | Stalk unit (side lights) | 15 |
| 10. | Windscreen wiper | 15 |
| 11. | Stalk unit (direction indicators/hazard warning lights) | 15 |
| 12. | Stalk unit (horns) | 15 |
| 13. | Reversing light | 5 |
| 14. | Side light, clearance, no. plate light | 5 |
| 15. | Side light cluster lighting | 5 |
| 16. | Left low beam headlamp | 10 |
| 17. | Right low beam headlamp | 10 |
| 18. | Left high beam headlamp | 10 |
| 19. | Right high beam headlamp/headlamp aiming | 10 |
| 20. | Interior lighting/radio/cigar lighter | 10 |
| 20. | Interior lighting/radio | 10 |
| 21. | Electric windscreen defrosting unit | 30 |
| 21. | Cigar lighter | 15 |
| 22. | Heated fuel filter | 15 |
| 23. | EDC electronic control unit | 25 |
| 24. | EDC | 10 |
| 25. | Stop lights | 5 |
| 26. | 13-pin current socket | 15 |
| 27. | 13-pin current socket | 15 |
| 28. | 13-pin current socket | 10 |
| 29. | 38-pin diagnostic connector | 5 |
| 30. | Fog lamps | 10 |
| 31. | Climate control, additional heater, engine cooling | 5 |
| 31. | Compressor, timer, engine fan | 10 |
| 32. | Climate control | 5 |
| 33. | Additional heater | 20 |
| 34. | Headlamp washer | 20 |
| 35. | Rear differential lock | 5 |
| 36. | ABS, EBD, ABD failure warning light | 5 |
| 37. | ABS | 5 |
| 39. | Heated mirrors | 10 |
| 39. | Heated mirrors, heated rear-screen, heated windscreen | 15 |
| 40. | Power windows | 30 |
| 40. | Power windows (left) | 20 |
| 41. | Heated rear-screen, heated windscreen | 10/ 20 |
| 42. | Self-levelling suspensions | 5 |
| 43. | Air bag failure warning light | 5 |
| 44. | Self-levelling suspensions (Wabco) | 40 |
| 45. | Air-bag | 5 |
| 46. | – | – |
| 46. | Power windows (right) | 20 |
| 47. | Electric fuel pump | 10 |
| 48. | Door locking/alarm | 30 |
| 49. | Door locking/alarm | 5 |
| 50. | Rear differential lock | 30 |
| 51. | Total power takeoff | 10 |
| 52. | Front differential lock (4x4) | 30 |
| 53. | Self-levelling suspensions Technik | 30 |
| 54. | Electric hatch (van and 6+1) | 15 |
| 55. | Rototranslating door | 15 |

Identification of relays/diode holders

| Code | Function |
|--------|--|
| 25035 | Switching on external lights |
| 25003 | Switching on fog lamps |
| 25006 | Switching on stop lights |
| 25704 | Total power takeoff engagement control |
| 25104 | Switching off Retarder with ABS on |
| 25209 | Loads cut-off during starting |
| 25222 | Thermal starter engagement enable |
| 25223 | Thermal starter fan control |
| 25307 | Climate control compressor engagement |
| 25336 | Engine cooling |
| 25337 | Climate control compressor disengagement |
| 25340 | Compressor on signal |
| 25620 | Fuel filter clogged signal |
| 25705 | Diagnostics enable |
| 25810 | Heated fuel filter circuit control |
| 25811 | Advance variator control (KSB) |
| 25818 | Heated windscreen switching on |
| 25837 | Electric fuel pump switching on |
| 25858 | EDC switching on |
| 25926 | Suspension raising enable |
| 25927 | Suspension lowering enable |
| 25928 | Rear-screen heating switching on |
| 61002A | Anti-return from Trinary |
| 61002B | Anti-return from TGC (bus) |
| 66010 | Timer for headlamp washer |



Fuse 39 must be replaced with a 10A fuse if the following optionals are present on the vehicle at the same time:

- heated wing mirrors with heated driver's seat;
- heated wing mirrors with heated driver's and passenger's seat;
- heated wing mirrors with electric aiming with heated driver's seat;
- heated wing mirrors with electric aiming with heated driver's and passenger's seat.

Fuse 41 (39 for F1A) must be replaced with a 15A fuse if the following optionals are present on the vehicle at the same time:

- heated windscreen with heated rear-screen.

Fuse 55 must be replaced with a 15A fuse if both the seats are heated.

Fuse 70060 (40A) relating to the ABS, device is located in the engine compartment, near the control box.

For the F1A, plug preheat centre 25231 is located on the engine compartment to the right of the EDC centre and is powered by 60A fuse 70064.


The previous indications (fuses/remote control switches) can be changed. Should it occur, make reference to the indications on the sticker label next to the fuses.

OPTICAL INDICATORS

A table is shown below with pin out 58918 in 4–connector version, as well as a 2–connector version one.

| 1 | 2 | 1 | 2 | 1 | 2 |
|-----|-----|-------|-----|-------------------------------------|------|
| D6 | B5 | * B15 | A2 | B3 | B156 |
| C20 | A5 | B2 | A17 | B1 | A22 |
| B17 | A29 | B12 | A18 | B10 | A21 |
| B16 | A14 | C8 | A4 | C5 | B26 |
| B6 | A30 | * B4 | A3 | A1 | A23 |
| B8 | A32 | * B14 | A19 | C4 | B24 |
| B9 | A16 | A2 | A6 | A3 | A7 |
| B20 | A15 | C18 | B14 | C13 | B27 |
| C19 | B13 | A8 | A11 | C3 | B25 |
| C10 | B15 | D3 | B29 | B11 | B2 |
| A4 | A8 | B19 | A13 | C14 | B1 |
| A10 | A9 | D9 | B30 | C9 | B23 |
| A9 | A10 | D12 | B9 | | |
| A11 | A24 | B18 | A12 | | |
| A12 | A25 | C11 | B11 | | |
| A5 | A26 | C15 | B22 | 1 | 2 |
| D8 | B3 | C12 | B21 | * B4 | A19 |
| D4 | B4 | D1 | B6 | * B14 | A2 |
| C1 | B12 | A6 | A27 | * B15 | A3 |
| D11 | B10 | D10 | B8 | * Variant for versions .11/.13/.15. | |
| B5 | A20 | D2 | B7 | | |
| B13 | A1 | D5 | B31 | | |
| C6 | B18 | C2 | B32 | | |
| C7 | B20 | A7 | A28 | | |
| C16 | B19 | B7 | A31 | | |
| C17 | B17 | D7 | B28 | | |

Figure 89




058918 PIN OUT OF THE PREVIOUS VERSION


74024

Interface bride with the new tool with 32-way connectors

Figure 90



77025



0742528t


REAR VIEW OF 32-WAY CONNECTOR UNIT

1. Blue colour seat "A" for 32-way female holder connector complete with terminals
2. Blue colour seat "B" for 32-way female holder connector complete with terminals

INSTRUMENT CLUSTER**Warning lights assembly**

Figure 91

58918




8655

| Ref. | Component code | Description |
|------|----------------|--|
| 1 | 58706 | Rear fog guard |
| 2 | 58002 | High beam headlamps |
| 3 | 58732 | Side lights |
| 4 | 58708 | Hazard warning lights |
| 5 | 58707 | Tractor direction indicators |
| 6 | 58709 | Trailer direction indicators |
| 7 | 58700 | No battery charge |
| 8 | 58718 | Brake system failure (under TEST) |
| 9 | 58722 | Low engine oil pressure |
| 10 | 58730 | Low engine oil pressure (under TEST) |
| 11 | 58719 | Handbrake on (under TEST) |
| 12 | 58728 | Low power steering fluid level (under TEST) |
| 13 | 58710 | Water in fuel filter (under TEST) |
| 14 | 58725 | Air cleaner clogged (under TEST) |
| 15 | 58701 | EDC failure |
| 16 | 58702 | Engine warming |
| 17 | 58734 | EBD failure |
| 18 | 58703 | ABS failure |
| 19 | 58713 | ECAS failure |
| 20 | 58735 | Rear transversal differential lock |
| 21 | 58720 | Low engine coolant fluid level (under TEST) |
| 22 | 58704 | ABD on |
| 23 | 58721 | High gearbox oil temperature (under TEST) |
| 24 | 58723 | Emergency handle lock (under TEST) |
| 25 | 58733 | EGR failure |
| 26 | 58717 | Immobilizer engaged |
| 27 | 58731 | Seat heating |
| 28 | 58724 | Door open indicator |
| 29 | 58705 | Airbag failure |
| 30 | 58715 | Total power takeoff (PTO) on |
| 31 | 58714 | Emergency handle activated (under TEST) |
| 32 | 58711 | Retarder on |
| 33 | 44031 | Low fuel level (under TEST) |
| 34 | 47207 | High engine coolant fluid temperature (under TEST) |

Instrument assembly

Figure 92




8655

| Ref. | Description |
|------|---|
| 1 | Electronic tachometer |
| 2 | Electronic gyrometer |
| 3 | Engine coolant fluid temperature gauge with incorporated warning light |
| 4 | Instrument lighting adjustment button |
| 5 | Trip meter reset button |
| 6 | Display for: clock, outside temperature (only with climate control), total odometer (km), trip meter (km) |
| 7 | Clock adjustment button (minutes) |
| 8 | Clock adjustment button (hours) |
| 9 | Fuel level gauge with reserve warning light |

Rear view

Figure 93




8643

| Ref. | Description |
|------|--|
| 1 | Seat "A" for 12-way, blue, female holder connector complete with terminal |
| 2 | Seat "B" for 20-way, blue, female holder connector complete with terminal |
| 3 | Seat "C" for 20-way, black, female holder connector complete with terminal |
| 4 | Seat "D" for 12-way, black, female holder connector complete with terminal |

Connector assembly (cable input side view)

Connector A

Figure 94




8643

8644


| Ref. | Cable colour code | Function |
|------|-------------------|---|
| A 1 | 2400 | Tachograph failure warning light |
| A 2 | 5595 | To cell 8 of diagnostic connector (serial line K) |
| A 3 | 2300 | Speed indication from tachograph |
| A 4 | 4411 | Side lights on warning light |
| A 5 | 1114 | Hazard warning lights on warning light |
| A 6 | 5520 | Low engine coolant fluid level warning light |
| A 7 | 6663 | Air cleaner clogged warning light |
| A 8 | 5530 | Water in fuel oil filter warning light |
| A 9 | 2287 | Rear fog guard on warning light |
| A 10 | 2285 | High beam headlamps on warning light |
| A 11 | 1123 | Direction indicators on warning light |
| A 12 | 1129 | Direction indicators on warning light |

Connector B

Figure 95



8643




8645


| Ref. | Cable colour code | Function | |
|------|-------------------|-------------------|--|
| B | 1 | 5517 | Tachometric signal |
| | 2 | 5614 | Rev counter signal |
| | 3 | - | - |
| | 4 | 5584 | To cell 28 of diagnostic connector (engine rpm repeater) |
| | 5 | 0000 | To pin 14 of connector B of electronic control unit for EDC |
| | 6 | 0000 | Earth for warning on warning light |
| | 7 | 6673 | EBD Failure warning light |
| | 8 | 6670 | ABS failure warning light |
| | 9 | 6659 | Supply (+15) for ABD, ABS and EBD failure warning lights |
| | 10 | 0058 | To electronic tachometer transmitter |
| | 11 | 5532 | To pin 2 of connector B of air conditioning system electronic control unit |
| | 12 | - | - |
| | 13 | 5155 | To pin 4 of connector B of EDC electronic control unit (tachometric signal repeater) |
| | 14 | 2222 | Tachometric signal repeater for rear differential lock |
| | 15 | 2222 | Tachometric signal repeater |
| | 16 | 8150 | Positive for EDC failure and warning on warning lights (Unijet) |
| | | 5553 | Positive for warning on warning light |
| | 17 | 5156 | EDC failure warning light |
| | 18 | 6660 | Rear differential lock warning light |
| | 19 | 6008 | Self-levelling suspension system failure warning light |
| 20 | 6674 | A.S.R. pilot lamp | |

Connector C

Figure 96



8643




8646

C


| Ref. | Cable colour code | Function |
|------|-------------------|---|
| 1 | - | Retarder on warning light (bus) |
| 2 | 9075 | Door open warning light |
| 3 | 5528 | Engine coolant fluid temperature gauge |
| 4 | 5557 | Fuel level gauge |
| 5 | 5555 | Fuel reserve warning light |
| 6 | 8888 | Supply (+50) |
| 7 | 4411 | Positive with exterior light switch on |
| 8 | - | To pin A1 of radio receiver set |
| 9 | 0000 | Connection to signal earth ms7 |
| 10 | - | Fog lamp pilot lamp |
| C 11 | 6770 | Sensor for immobilizer on signal |
| 12 | 5506 | Low engine oil level sensor |
| 13 | 5552 | Engine coolant fluid high temperature warning light |
| 14 | 0000 | Earth |
| 15 | 5556 | Low engine oil level sensor |
| 16 | 7772 | Supply (+30) |
| 17 | 8879 | Supply (+15) |
| 18 | 6711 | Air bag failure warning light |
| 19 | 6722 | Supply (+15) for air bag failure signal |
| 20 | 7778 | Supply (+15) for battery charge failure warning light |

Connector D

Figure 97



8643



8647



D

| Ref. | Cable colour code | Function | |
|------|-------------------|----------|--|
| D | 1 | 5503 | Low engine oil pressure warning light |
| | 2 | 6662 | Handbrake engaged warning light |
| | 3 | 5525 | Low power steering fluid level warning light |
| | 4 | - | - |
| | 5 | - | Rotary translating door failure warning lamp (bus) |
| | 6 | 7778 | Battery charge failure warning light |
| | 7 | 8016 | Brake failure warning light |
| | 8 | 1386 | Trailer direction indicators on warning light |
| | 9 | - | Handle lock pilot lamp |
| | 10 | - | - |
| | 11 | 5583 | EGR failure warning light |
| | 12 | 6660 | Total power takeoff (PTO) on warning light |

SWITCH ASSEMBLY

All the switches and push buttons of this module incorporate a warning led.

Figure 98



74271


Legend

| Position | Function | Vehicles | |
|----------|---------------------------------|--------------------------------------|----------|
| | | CARRIAGE – VAN – MIXED | |
| | | Standard | Optional |
| 1 | Emergency lights | X | |
| 2 | Fog lights | | X |
| 3 | Heated rearview mirrors | | X |
| 4 | Rear glass | | X |
| 5 | Rear differential lock | | X |
| 6 | Level compressed air suspension | | X |
| 7 | Lower compressed air suspension | | X |
| 8 | Lift compressed air suspension | | X |
| 9 | Electrical manhole opens | | X |
| 10 | Electrical manhole closes | | X |
| 11 | Heated windshield | | X |
| 12 | Light washer | | X |
| 13 | Cap | | |
| 14 | Rear door lock | | X |
| 15 | Speed limiter adjustment | | X |
| 16 | Cap | | |
| | | VENDOR PERSONS–VENDOR GOODS–SHIELDED | |
| 1 | Emergency lights | X | |
| 2 | Fog lights | | X |
| 3 | Heated rearview mirrors | | X |
| 4 | Rear glass | | X |
| 5 | Air heating | | X |
| 6 | Level compressed air suspension | | X |
| 7 | Lower compressed air suspension | | X |
| 8 | Lift compressed air suspension | | X |
| 9 | Electrical manhole opens | | X |
| 10 | Electrical manhole closes | | X |
| 11 | Heated windshield | | X |
| 12 | Light washer | | X |
| 13 | Rotary travel holder | X | |
| 14 | Rear door lock | | X |
| 15 | Speed limiter adjustment | | X |
| 16 | Battery sectioner reset | X | |
| | | COMBI | |
| 1 | Emergency lights | X | |
| 2 | Fog lights | | X |
| 3 | Heated rearview mirrors | | X |
| 4 | Rear glass | | X |
| 5 | Air heating | | X |
| 6 | Level compressed air suspension | | X |
| 7 | Lower compressed air suspension | | X |
| 8 | Lift compressed air suspension | | X |
| 9 | Electrical manhole opens | | X |
| 10 | Electrical manhole closes | | X |
| 11 | Heated windshield | | X |
| 12 | Light washer | | X |
| 13 | Cap | | |
| 14 | Rear door lock | | X |
| 15 | Speed limiter adjustment | | X |
| 16 | Cap | | |

STALK UNIT

54032

Figure 99




8651


WIRING DIAGRAM

- A. Exterior light switch – B. Rear fog guard button – C. Direction indicator switch –
- D. High beam headlamp/flasher switch – E. Windscreen wiper switch – F. Windscreen washer pump button –
- G. Horn button

Figure 100



8640




8641

TECHNICAL VIEW OF COMPONENT AND CONNECTORS OF CAB/BONNET CABLE TO BE CONNECTED TO STALK UNIT

| Ref. | Function | Cable colour code |
|-----------------------|--|-------------------|
| P1 (Black) | 1 – | – |
| | 2 Input from alarm | 9071 |
| | 3 Input from hazard warning lights | 7728 |
| | 4 Supply (+30) for horn button | 7774 |
| | 5 Horns | 1116 |
| | 6 Left-hand direction indicator | 1129 |
| | 7 Right-hand direction indicator | 1123 |
| | 8 Signal earth | 0000 |
| | 9 Positive with fog lights on | 2284 |
| | 10 Supply (+30) for direction indicators and hazard warning lights | 7728 |
| | 11 Rear fog guard and rear fog guard on warning | 2283 |
| | 12 Supply (+15) | 2283 |
| P2 (Blue) | 1 Windscreen wiper first speed | 8881 |
| | 2 Windscreen wiper second speed | 8882 |
| | 3 Supply (+15/A) for windscreen wiper | 8879 |
| | 4 Windscreen wiper reset input | 8873 |
| | 5 Electric pump for windscreen washer | 8886 |
| | 6 Supply (+30) for side lights switch | 3333 |
| | 7 Side lights | 3333 |
| | 8 Supply (+15/A) for switching on low beam headlamps | 2201 |
| | 9 Power earth | 0000 |
| | 10 Low beam headlamps | 2201 |
| | 11 Supply (+15/A) for switching on high beam headlamps | 2200 |
| | 12 High beam headlamps | 2200 |

Functions


Figure 101



7409



EXTERIOR LIGHTING KNURLED RING ROTATION SECTION F-F

REAR FOG GUARD KNURLED RING ROTATION SECTION G-G



7433

A.–B. Positions of stalks – C. Horn control – D. Exterior lights knurled ring – E. Rear fog guard knurled ring

| Technical view | Position | Electrical function |
|---|--|--|
|  <p>7410</p> | <p>A</p> <p>A1</p> <p>A2</p> <p>A3</p> <p>A4</p> <p>A5</p> <p>A6</p> <p>A7</p> <p>A8</p> <p>A9</p> <p>A10</p> <p>A11</p> <p>A12</p> | <p>Position "0"</p> <p>Right lane change (unstable)</p> <p>Right direction</p> <p>Left lane change (unstable)</p> <p>Left direction</p> <p>Light flashing</p> <p>High beam headlamps</p> <p>Side light switch position "0"</p> <p>Side lights</p> <p>Low beam headlamps plus high beam and fog guard enable</p> <p>Rear fog guard stable position (on or off)</p> <p>Rear fog guard unstable position off</p> <p>Rear fog guard unstable position on only with light switch at position A9 of rear fog guards on</p> <p>Horn</p> |
|  <p>7411</p> | <p>B</p> <p>B1</p> <p>B2</p> <p>B3</p> <p>B4</p> <p>B5</p> | <p>Windscreen wiper reset</p> <p>Intermittent device</p> <p>First Speed</p> <p>Second speed</p> <p>Second speed unstable</p> <p>Windscreen washer</p> |

Cruise Control


The cruise control is operated by push-buttons (Figure 102) installed on the windscreen wiper control lever with following functions:

- adjust engine idle speed;
- read and adjust drive rpm;
- set and store travel speed.

Cruise control is deactivated by pressing the clutch pedal, the brake pedal and keeping the accelerator pedal pressed for over 10 seconds or by turning the switch to "OFF".

Cf. the Use and Maintenance Handbook on board the vehicle for further information on use.


Figure 102



000245t

CRUISE CONTROL

Figure 103




TECHNICAL VIEW OF THE COMPONENT
A. Connector (Cruise control)

ELECTRONIC SYSTEMS

Immobilizer

In order to increase protection against attempted theft, the vehicles have been fitted with an electronic engine block system called "Immobilizer" which is activated automatically removing the ignition key. In fact, the keys are fitted with an electronic "Transponder" that sends a code signal to a special electronic control unit which, only allows the engine to be started if it recognises the code sent. del motore.

Figure 104



WARNING LIGHT MAIN SYSTEM COMPONENTS

- 1. Immobilizer electronic control unit – 2. Electronic key containing the transponder – 3. Aerial used for sending/reading the key code – 4. Code card containing the code for emergency starting

000245t

System components

Electronic control unit


This is located behind the steering wheel column.

It is able to communicate with "EDC" central unit by a "CAN line".

The main functions of the control unit are:

- recognising insertion and rotation of the key in the ignition switch,
- activating and reading the secret code emitted by the Transponder,
- managing control and processing the codes,
- communicating with the "EDC" control unit,
- memorising any faults,
- system diagnostics.

Figure 105



00290t

| Pin | Function |
|-----|--|
| A1 | Aerial |
| A2 | Aerial |
| A3 | — |
| B1 | CAN line L for EDC control unit pin 39 (EDC 16 – pin 61) |
| B2 | Line K for 38-pin diagnostic connector pin 12 |
| B3 | Negative for Immobilizer failure warning lamp |
| B4 | CAN H line for EDC control unit pin 8 (EDC 16 – pin 62) |
| B5 | — |
| B6 | Earth |
| B7 | Key-operated positive supply |
| B8 | — |

Electronic keys

An electronic device called "Transponder" is fitted in the key grip which is not supplied by any battery, it is not removable and contains and transmits the secret code.

Inserting the key, the "Transponder" is activated, then, when it receives the radio waves emitted by the aerial (fitted on the ignition switch block), it automatically answers transmitting the secret code.

If the two codes correspond, the control unit enables starting, otherwise it shuts off the flow of fuel thereby preventing the engine from starting.



The keys provided are two. Each key contains a "Transponder" with the corresponding secret code. It is highly to carry out the correct key teaching procedure.


Aerial

This is fitted coaxially with the ignition switch and it has the task of:

- supplying the energy to the "Transponder" for sending the secret code
- receiving the signal from the Transponder and sending it to the control unit.

It is connected to the control unit on pins A1/A2.


Figure 106




ELECTRONIC KEYS

000291t

Figure 107




8659



000292t

AERIAL


Figure 108



CODE CARD

000293t

Figure 109



000294t

WARNING LIGHT

Code card

Card containing the Electronic code and the Mechanical code.

- Electronic code or PIN code
Code absolutely necessary for the starting procedure in the event of an emergency.
- Mechanical code
Code needed for request to duplicate the mechanical part of the key.

Warning light

This is located on the instrument cluster and informs the driver whether the system is working properly or of any possible faults.

Moving the ignition key to drive the control unit tests the system turning on the warning light for about "4 seconds".

If it goes out after this time, this means that the key has been recognised and the system is working, if it does not it indicates the possible system faults.

Key teaching procedure

In the event of loss or replacement of the keys it will be absolutely necessary to follow a precise procedure solely through the diagnostic tools.

- Connect the diagnostic tool.

Key teaching

- Engage the first key and turn it to drive.
- Wait for the "code" warning light on the cluster to go out and turn the key to stop.
- Engage the new key and turn it to drive, repeat the operations described previously.

If the code warning light does not go out during the teaching procedure, this means that the operation has not been carried out correctly.

Possible causes:

- The same key has been engaged twice.
- The key has not been turned to stop in useful time.
- An attempt has been made to teach more than three keys.
- Keys already used with another control unit have been used.
- Aerial reception problems.

NOTE After following this procedure the control unit memorises the keys and will no longer make this operation possible without entering the PIN code.
The keys enabled for starting will never be more than three.
A previously memorised key but not included in the last teaching process is no longer able to start the vehicle.

Emergency procedure

It is absolutely necessary to enter the "PIN code" given on the "Code Card", only using the accelerator pedal as described below:

- Move the ignition key to Drive.
- After about ~ 2 seconds the EDC warning light starts to flash quickly
- Press the accelerator pedal and keep it pressed for about ~ 15 seconds.
- The EDC warning lamp starts flashing slowly.
- When the number of flashes corresponds to the first digit of the PIN code press the accelerator completely and then release it again. (During this press the EDC warning light stays off).
- Continue with the reading and corresponding pressing on the accelerator pedal for the remaining four numbers of the "PIN code".
- At the end of the sequence if the code entered is correct and there are no system faults, the EDC warning light stops flashing. The operation has been concluded correctly.
- Start the vehicle.

System self–diagnostics

After the initial test, depending on the behaviour of the “code” warning light, the system is capable of informing the operator of possible system faults, as follows:

- Warning light “flashing continuously” with a frequency of “0.3 sec. ON” and “3 sec. OFF” means that there is an error or that the emergency starting procedure has not been carried out correctly.
- Warning light “flashing continuously” with a frequency of “0.3 sec. ON” and “0.3 sec. OFF”, means that no key teaching procedure has been carried out.
- Warning light “always on” means that the key teaching procedure has not been carried out correctly.

For preliminary information, it is possible to display any fault codes on the warning light module of the instrument cluster activating the Blink code.

For complete, more thorough diagnosis it is however indispensable to use the tools available to the service network, such as MODUS.


Diagnostics through the Blink Code

To activate the Blink code it is necessary to earth line K for at least 2 seconds with the ignition key at drive to display the first error.

Repeat this operation (line K at earth) to display any other faults.

The table below shows the various error codes that may appear during diagnostics.

Figure 110



000294t

| Number of blinks | Type of fault |
|------------------|---|
| 1 | Not connected or not configured central unit |
| 2 | Central unit not communicating with EDC Central unit not communicating during installation |
| 3 | Central unit not installed |
| 4 | – Short circuit/disturbance on communication line between control unit and “EDC” |
| 5 | Key with unknown code |
| 6 | Key with code not detected |
| 7 | Aerial not connected |
| 8 | Internal control unit fault |
| 9 | Short circuit on alarm disable line |
| — | “Code” warning light short circuit |
| — | “Code” warning light open circuit |



If after accurate diagnosis it is necessary to replace one or more components, proceed as described below

| PART TO BE REPLACED | PARTS TO BE ORDERED | OPERATIONS AND NOTES |
|---|---|--|
| One or two keys (with one still available) | • Parts Keys | ⇒ Cut the keys according to the mechanical code. ⇒ Perform "Key memorising" in Immobilizer diagnostics (*). NB. In this procedure also enter the remaining working keys otherwise they will NO LONGER be enabled for starting. |
| Addition of a key | | |
| Steering lock and/or ratchets | • KEYS KIT with: 2 cut Parts keys Steering lock + Ratchets | ⇒ Change the steering lock and ratchets. ⇒ Perform "Key memorising" in Immobilizer diagnostics (*). ⇒ State the new mechanical code on the Code Card. |
| ALL the keys | | |
| Ratchets (excluding steering lock) | • KIT with: 2 traditional keys + ratchets | ⇒ Change the ratchets. NB. Traditional keys means keys without Transponder. |
| Code card (due to loss) | • Code Card | ⇒ Complete the "Code Card Duplicate Request Form" printing it from MODUS and send it as mentioned in the ORDER MANAGEMENT form of the IVECO SPARES warehouse concerned. |
| Aerial | • Aerial | ⇒ Replace. |
| ECU Immobilizer | • KIT ECU Including: Immobilizer ECU – 2 keys to be cut New Code Card | ⇒ Cut the keys according to the mechanical code. ⇒ Perform "Key memorising" in Immobilizer diagnostics (*). NB. At the end of this operation, check that the electronic code shown on the screen corresponds to the one printed on the Code Card, if it is different, put the one on the screen on the Code Card. ⇒ In EDC diagnostics perform "new key recognition". ⇒ Put the old mechanical code on the new Code Card. ⇒ Scrap the old keys as it will be NO LONGER possible to use them. ⇒ Complete the "New Immobilizer Installation Form" printing it from MODUS and send it as mentioned in the ORDER MANAGEMENT form of the IVECO SPARES warehouse concerned. |
| EDC control unit | • EDC control unit | ⇒ The system recognises the new actuator automatically the first time the ignition key is moved to Drive. NB. To order the EDC Control Unit complete the specific form printing it from Modus and sending it to the Market Technical help Desk. |



(*). With release MODUS 2.0 (Windows), 1.6C (DOS) or IWT 1.4, before "Storing new keys", it is necessary to disconnect EDC central unit. Once the operation has been completed, clear the fault memory to prevent the error from staying memorised on the actuator.

⇒ For subsequent releases keep to any new instructions given on the screen.

ABS/EBD/ABD

General

The braking of a vehicle in motion and the consequent deceleration and stopping space mainly depend on the grip between the tyre surface and the type of road surface.

With a perfectly efficient braking system, further improvement of braking can be obtained only acting on the tyre friction characteristics or on the quality of the road surface.

Even in these optimum conditions, absolute braking safety is not however guaranteed when needing to cope with particular critical situations, such as low grip due to the conditions of the wet or icy road surface: this compels the driver to moderate the braking action to prevent one or more wheels from partially locking, with the possibility of dangerous skidding.

The friction between the tyre and the road surface does not correspond to the friction between rigid bodies but to the

skidding (or slipping) between the tyre and the road in the contact area.


The figure shows the indicative trend of the longitudinal “ μ_l ” and transversal “ μ_t ” rip coefficients in relation to the percentage of slipping “S”.

The diagram reveals that the maximum value of the longitudinal grip coefficient is not when the wheel is locked, but for a much lower slipping value.

Therefore, the road–tyre grip can be exploited to optimise longitudinal or transversal control of the vehicle. Namely, it is possible to utilise the grip trying to make the braking distance as short as possible or to ensure the best possible handling.

An excellent compromise is obtained using slip rates near the point S^* in which there is a high μ_l value which ensures optimum braking and a μ_t value that offers good lateral roadholding.

Figure 111



TREND OF WHEEL LONGITUDINAL AND TRANSVERSAL GRIP IN RELATION TO SLIPPING

In order to better understand the logic of the system and the parameters that govern it a few basic concepts should be briefly examined.

Due to the effect of the braking action the tyre, that before was rolling freely, undergoes a deformation, called "braking" deformation, in its area of contact with the road and slows down rotation reducing its peripheral speed, to a higher extent than the linear speed of the vehicle.

At the limit, with the wheels completely locked under the braking action, and thus with a wheel peripheral speed of zero, there is the maximum deviation between the wheel rotation speed and the linear speed of the vehicle.

Slipping varies its values within the limits set by the two extreme conditions in which the wheel and vehicle speed may be in.

When the wheel is free, not braked, thus turning at the same speed as the vehicle, the slipping coefficient is 0%.

When the braked wheel is completely locked and the vehicle continues moving forwards due to inertia, the skidding coefficient amounts to 100%.

Experimentation has made it possible to establish that the most effective braking condition is obtained for optimum slipping values contained between about ~ 5% and 20%.

The need to contain the slipping values within precise limits is imposed by the behaviour of the tyres under the braking action, during which the braking friction coefficient comes into play.

The higher this coefficient, the more braking is effective.

If the relation between slipping S and the friction coefficient μ is represented on Cartesian axes, we see how there are the highest friction coefficient values for slipping values between an average of 5% and 20%.

As the friction coefficient is directly proportionate with the applicable braking force, the result is that the "ABS" device acts in such a way as to apply the maximum braking force exactly in correspondence with the best friction coefficient, and this system tends to bring any type of vehicle within this sector.

Figure 112





Figure 113



VEHICLE BRAKING TREND
WITHOUT AND WITH ABS

A. Vehicle without ABS – B. Vehicle with ABS

The locking of one or more wheels, due to excessive pressure on the brake pedal, (anyway higher than allowed by the grip) can cause loss of steering control of the vehicle if both front wheels lock, skidding, resulting in about-facing, if both rear wheels lock.

The need for abrupt braking on a bend, compels the driver to immediate action to avoid losing control of the vehicle, resulting in skidding.

Lastly, the so-called panic braking (caused by a sudden obstacle), compels the driver to press the brake pedal as forcibly as possible in the desperate attempt to stop in time..

So what is the solution even for the most expert drivers?

Being able to avail of a braking system capable of fully exploiting all the grip available without locking the wheels, except at a minimum pre-established speed.

The ABS Antibrake Locking System has been developed exactly to obtain this.

A device inserted in the braking system, with the task of preventing wheel locking when the brake operating pressure is too high in relation to the grip of the tyre on the ground.

Therefore, the purpose of the "ABS" device is to ensure vehicle stability (under all braking conditions) preventing locking of the wheels regardless of the conditions of the road surface, thereby ensuring total use of the grip available.

Also in the vent of emergency braking, the system makes it possible to maintain "steerability" of the vehicle, i.e. acting on the steering to avoid obstacles, without the danger of skidding.

Keeping the rotation and grip of the wheels within the optimum parameters, the system makes it possible to obtain those braking distances that only an expert driver would be able to approach; this way even the less expert driver is able to act like one of the best.

The diagram opposite shows some examples of braking without ABS and with ABS.

In order to be able to intervene effectively the system must not only be precise in response, but also very quick.

This is now possible thanks to electronic information which warrants reliability, precision and rapidity, with a minimal number of components and lower system cost.

In addition to the ABS, the system in question also incorporates the EBD and ABD functions.

EBD – Electronic Brake Force distribution

This device replaces and optimises the function of the present hydraulic braking action proportioning valve, better controlling the braking force on the rear wheels.

It is obtained by adding specific software to the ABS and it acts in a determinate interval before the cutting in of the ABS.

It ensures control on any locking of the rear wheels in relation to the front ones, optimising the braking force in the different load, driving and conditions of use of the vehicle.

ABD – Automatic Brake Differential


This device comes into action automatically braking the driving wheel that has less grip when moving off or travelling the differential to the wheel with higher grip.

It cuts in up to a speed of about 40 km/h and does not interfere with the normal braking system.

It cuts in up to a speed of about 40 km/h and does not interfere with the normal braking system.

The driver is informed when this system is engaged by the flashing of the yellow warning light on the dashboard.

Figure 114




SYSTEM WARNINGS ON DASHBOARD

A. ABS failure warning light 58703 – B. EBD failure warning light 58734 – C. ABD failure warning light 58704

SYSTEM WITH 4 CROSSED CHANNELS (X)

The system shown is used on the following vehicles: 29 L – 35 S


Figure 115



1. Electrohydraulic modulator – 2. Vacuum pump – 3. Vacuum tank – 4. Vacuum servobrake – 5. Hydraulic control sockets
 – 6. Parking brake lever – 7. Rear brake caliper – 8. Rear disk brake – 9. Electronic control unit – 10. Sensor –
 11. Phonic wheel – 12. Front brake disk – 13. Front brake caliper

Location of components

Figure 116



1. Electrohydraulic modulator – 2. Vacuum pump – 3. Vacuum tank – 4. Vacuum servobrake – 5. Hydraulic control sockets – 6. Front brake disk – 7. Rear brake caliper – 8. Rear disk brake – 9. Electronic control unit 88000 – 10. Sensor 88001 – 11. Phonic wheel – 12. Front brake disk – 13. Front brake caliper

Sensor on phonic wheel

The sensors supply the electronic control unit all the useful information, with the necessary continuity, for it to be able to control the solenoid valves.

The signals are obtained by magnetic flux lines which are closed through the teeth of an iron toothed wheel facing the sensor and turned with the wheel.

The passage from solid to hollow, due to the presence or absence of the tooth determines a change of the magnetic flux which is enough to create an electromotive force induced at the terminals of the sensor and thus an alternate electric signal, which is sent to the electronic control unit.

The distance between the sensor and the wheel, called gap, must clearly have a pre-established value so that correct signals are supplied ($0,8 \div 1,6 \text{ mm}$).


The resistance rating of each single sensor detected at the ends of the connector is between $1 \div 2 \text{ k}\Omega$.

The toothed wheel is called phonic wheel because the signal it generates has the frequency of a sound wave.

The frequency of this signal serves to define the wheel rotation speed.

The changes of the frequency, i.e. the rapidity with which the signals follow one another serve to define the acceleration and deceleration values.

Figure 117



SENSOR ON PHONIC WHEEL

A. Phonic wheel

Electrohydraulic control unit/modulator

The component integrates both the electronic part and the hydraulic modulator for system management.

It comprises the following:

A – Electronic control unit

B – Electrohydraulic modulator

C – Accumulator

It is connected to the hydraulic system by the following connections:

MC1 – Diagonal supply LF/RR

MC2 – Diagonal supply RF/LR

LF – Left front axle output


RR – Right rear axle output

RF – Right front axle output

LR – Left rear axle output

It is connected to the electric system through a 31-pin connector.

Figure 118



CONTROL UNIT/ELECTROHYDRAULIC MODULATOR


Electrohydraulic modulator

The figure schematically shows the connection of the modulator and its internal components.

Pressure increase

Operating the brake pedal, the pressurised oil can reach the brake calipers as both the drive solenoid valves "6" and the supply solenoid valve "11" are open.

Figure 119




1. Vacuum servobrake – 2. Electronic control unit – 3. High pressure accumulator – 4. Recovery pumps – 5. Recovery pump drive motor – 6. ABD control solenoid valves (setting 90 bar) – 7. One-way safety valves – 8. ABD intake solenoid valves – 9. ABD one-way valves – 10. Low pressure accumulator – 11. Supply solenoid valves – 12. Discharge solenoid valves – 13. One-way quick pressure reduction valves – 14. Front axle disk brakes – 15. Rear axle disk brakes

Pressure lowering

If the sensors detect the tendency of a wheel or wheels to lock, they inform the control unit which reduces the braking force activating the supply solenoid valves "11" and the discharge solenoid valves "12".

At the same time, supplying the motor "5" that drives the pumps "4" it will be possible to recover the excess oil volume in the high pressure accumulators "3".

Figure 120




SYSTEM OPERATING LAYOUT SHOWING THE PRESSURE MAINTENANCE PHASE

Pressure maintenance

Once the optimum braking force has been reached, the control unit can keep it constant, no longer energising the discharge solenoid valves "12", the motor "5" and the associated recovery pumps "4", while the supply solenoid valves "11" continue being supplied.

Figure 121



SYSTEM OPERATING LAYOUT SHOWING THE PRESSURE MAINTENANCE PHASE

Cutting in of EBD device


If the sensors detect that one or both wheels tend to lock in relation to the front wheels, they inform the control unit which suitably supplies the supply solenoid valves "II" of the rear axle to optimise the braking force.

A fault on certain system components causes the ABS system to be cut off (displayed by turning on the special warning light), still leaving the EBD system operational.

If both failure warning lights turn on (ABS and EBD) this means an EBD system failure.

Under these conditions the braking force will not be distributed between the axles, therefore rear wheel locking may occur with the possibility of skidding.

Figure 122



FP. Rear axle braking force – FA. Front axle braking force – A. Servobrake distribution curve – B. Ideal distribution – C. Curve – distribution curve of any porportioning valve – D. EBD system distribution curve

Cutting in of ABD device

If the sensors detect that one or both rear axle wheels tend to skid, they inform the control unit which supplies the intake solenoid valves "8" and the drive valves "6".

At the same time, supplying the motor "5" which drives the pumps "4" it will be possible to generate the pressure to be sent to the brake calipers concerned.


The braking force generated in this manner is modulated by solenoid valves "11" and "12".

During this phase the maximum pressure is limited by the drive solenoid valves "6" and cannot exceed 90 bar.

The driver is informed of the cutting in of this system by the flashing of the corresponding warning light on the dashboard.

If the warning light turns on and glows steadily, there is an ABD system failure.

Figure 123




ABD DEVICE OPERATING LAYOUT

SYSTEM WITH 4 PARALLEL CHANNELS (II)

The system shown in Figure 124 is used on the following vehicles: 35 C – 40 C – 45 C – 50 C – 65C.

Figure 124



1. Electrohydraulic modulator – 2. Vacuum pump – 3. Vacuum tank – 4. Vacuum servobrake – 5. Hydraulic control sockets – 6. Parking brake lever – 7. Parking drum brake – 8. Rear brake disk – 9. Rear brake caliper – 10. Electronic control unit – 11. Sensor – 12. Phonic wheel – 13. Front brake disk – 14. Front brake caliper

Electrohydraulic control unit/modulator

This component integrates both the electronic part and the electrohydraulic system control modulator.

It comprises the following:

- A – Electronic control unit
- B – Electrohydraulic modulator
- C – Accumulator

It is connected to the hydraulic system by the following connections:

F – Front axle supply

R – Rear axle supply

LF – Left front axle output


RF – Right front axle output

LR – Left rear axle output

RR – Right rear axle output

It is connected to the electric system through a 31-pin connector.

Figure 125



CONTROL UNIT/ELECTROHYDRAULIC MODULATOR



Electrohydraulic modulator

The figure shows the layout of the connection of the modulator and its internal components.

Pressure increase

Operating the brake pedal, the pressurised oil can reach the brake calipers as both the drive solenoid valve "7" and the supply solenoid valves "12" are open.

Figure 126





- 1. Vacuum servobrake – 2. Electronic control unit – 3. High pressure accumulators – 4. Recovery pumps –
- 5. Recover pump drive motor – 6. Accumulator for rear axle system – 7. ABD drive solenoid valve (90 bar setting) –
- 8. One-way abd valve – 9. Intake abd solenoid valve – 10. ABD one-way valve – 11. Low pressure accumulators –
- 12. Supply solenoid valves – 13. Discharge solenoid valve – 14. One-way quick pressure relief valves – 15. Front axle disk brake – 16. Rear axle disk brakes

Pressure reduction

If the sensors detect that a wheel or wheels tend to lock, they inform the control unit which reduces the braking force activating the supply solenoid valves "12" and the discharge solenoid valves "13".

At the same time, supplying the motor "5" which drives the pumps "4", it will be possible to recover the excess oil in the high pressure accumulators "3".

Figure 127





OPERATING LAYOUT OF THE SYSTEM SHOWING THE PRESSURE REDUCTION PHASE

Pressure maintenance

Once the optimum braking force has been reached, the control unit is able to keep it constant by no longer

energising the discharge solenoid valves "13", the motor "5" and the corresponding recovery pumps "4"; while the supply solenoid valves "12" continue being energised.

Figure 128



OPERATING LAYOUT OF THE SYSTEM SHOWING THE PRESSURE MAINTENANCE PHASE

Cutting in of the EBD device


If the sensors detect that one or both rear wheels tend to lock in relation to the front wheels, they inform the control unit which appropriately supplies the supply solenoid valves "12" of the rear axle, in order to optimise the braking force.

A fault on certain system components causes the ABS system to be cut off (displayed by turning on the special warning light), still leaving the EBD system operational.

If both failure warning lights turn on (ABS and EBD) this means an EBD system failure.

Under these conditions the braking force will not be distributed between the axles, therefore rear wheel locking may occur with the possibility of skidding.

Figure 129



FP. Rear axle braking force – FA. Front axle braking force – A. Servobrake distribution curve – B. Ideal distribution curve – C. Any proportioning valve distribution curve – D. EBD system distribution curve

Cutting in of the ABD device

If the sensors detect that one or both rear axle wheels tend to skid, they inform control unit which supplies the intake solenoid valves "9" drive valves "7".

At the same time, supplying the motor "5" which drives the pumps "4" it will be possible to generate the pressure to be sent to the brake calipers concerned.


The braking force generated in this manner is modulated by solenoid valves "12" and "13".

During this phase the maximum pressure is limited by the drive solenoid valves "6" and cannot exceed 90 bar.

The driver is informed of the cutting in of this system by the flashing of the corresponding warning light on the dashboard.

If the warning light turns on and glows steadily, there is an ABD system failure.

Figure 130




ABD DEVICE OPERATING LAYOUT

Electronic control unit

The following table shows the pin out of the control unit in question.

Figure 131



| Pin | Function | Cable colour code |
|-----|---|-------------------|
| 1 | Right rear sensor | — |
| 2 | Right rear sensor | — |
| 3 | Right front sensor (only for 35 C – 40 C – 45 C – 50 C – 65 C vehicles) | — |
| 4 | Right front sensor | — |
| 5 | Right front sensor (only for 29 L – 35 S vehicles) | — |
| 6 | Left front sensor | — |
| 7 | Left front sensor | — |
| 8 | Left rear sensor | — |
| 9 | Left rear sensor | — |
| 10 | — | — |
| 11 | Line K to pin 4 38-pin connector for diagnostics | 8817 |
| 12 | Line L to pin 3 38-pin connector for diagnostics | 8818 |
| 13 | Negative for third brake relay | 0315 |
| 14 | Positive from stop light switch | 1173 |
| 15 | Key-operated positive | 8847 |
| 16 | Earth | 0000 |
| 17 | Direct positive | 7772 |
| 18 | Direct positive | 7772 |
| 19 | Earth | 0000 |
| 20 | Negative for ABS failure warning light | 6670 |
| 21 | Negative for EBD failure warning light | 6673 |
| 22 | — | — |
| 23 | — | — |
| 24 | Negative for ABD operating warning light | 6674 |
| 25 | — | — |
| 26 | — | — |
| 27 | — | — |
| 28 | — | — |
| 29 | — | — |
| 30 | — | — |
| 31 | — | — |

ABS 8/ESP 8**The ABS 8 system integrates the following functions:**

- ABS - Antilock Braking System
It prevents wheels from being locked during braking, thus making it possible to avoid possible obstacles.
It prevents losing control of the vehicle when braking on a slippery surface (even on one side only → mu-split).
It also reduces the braking distance compared with the one with the wheels locked.
- EBD - Electronic Brake Force distribution
It supersedes and optimizes the function of current hydraulic brake correctors, by better controlling the braking force on rear wheels.
It is implemented by adding a special software to the ABS, and comes into action within a given time interval prior to ABS actuation.
It makes it possible to control any locking condition affecting the rear wheels compared with the front wheels, by optimizing the braking force under different load, running and vehicle utilization conditions.

NOTE The ABD (Automatic Brake Differential) function is available only in systems of the ABS 5.3 type.

The ESP 8 system, in addition to the ESP 8 system, incorporates the following functions:

- ESP - Electronic Stability Program
It monitors the vehicle behaviour continuously (both along straight stretches and bends, when braking or accelerating).
It also monitors the driver's actions: steering the wheel, pressing the brake pedal, accelerator position, and speed.
It is always active in the background, i.e. the ESP system compares the actual vehicle ride with the driver's desired ride 50 times a second. It recognizes dangerous situations before the driver does.
The system considers the different possibilities of coming into operation. It brakes on every single wheel separately.
It operates on the engine control system.
- ASR – Acceleration drive control device
This system prevents driving wheel skid through quick action on the engine and brakes. It allows the vehicle to set off safely and fast even on slippery roads or when one driving wheel is skidding. It also reduces the risk of understeering when you accelerate too much when cornering.


- MSR – Engine braking torque control
This system avoids driving wheel drag due to the exhaust brake. It ensures vehicle stability when releasing on slippery roads (e.g. snow, ice), and assists in keeping the path when cornering and shifting down, especially on slippery roads. It requires a slight increase of revs number, through the CAN line.
- HHC – Hill holder control
This function allows the vehicle to be kept automatically locked (braked) until the clutch is closed and the driver subsequently presses the accelerator pedal, thus preventing undesired vehicle motion.
The function is actuated automatically: the braking situation is detected by the sensor inside the modulator. When the brake pedal is released, the vehicle will be kept for 2.5 seconds, thus allowing the driver/system to put the gear (and the vehicle to be started). This ensures safe, easy start with any incline, regardless of the weight carried.
- HBA (Hydraulic Brake Assistant) – Hydraulic assistant in emergency braking
The main feature of the HBA function is to recognize an emergency braking situation followed by “automatic” increase of vehicle deceleration.
Vehicle deceleration is only restricted to actuation of ABS control, thus taking the greatest advantage of the grip between the tyre and the roadbed currently available. Therefore, ordinary drivers can now achieve braking distances which only experienced drivers could achieve in the past.
If the driver reduces the braking intensity, vehicle deceleration is reduced depending on the reduction of the force applied onto the pedal.
Therefore, the driver can control deceleration accurately after overcoming the emergency situation.
The extent of the braking request from the driver corresponds to the force applied onto the pedal. Such force is derived from measuring the pressure in the brake pump.

Application of the ABS 8/ESP8 systems

| SYSTEM | ABS8 | | ESP8 | |
|----------|--|------------|---------------------|------------|
| | X (crossed) | (parallel) | X (crossed) | (parallel) |
| VEHICLES | FIA engine with 6 AS 300 VD automatic gearbox | | FIA and FIC engines | |
| | 29L – 35S | 35C – 65C | 29L – 35S | 35C |

Four crossed channel system (x)**Electro-hydraulic modulator/control unit**

Figure 131/1




102113

1. Hydraulic accumulator - 2. Electro-hydraulic modulator - 3. Electronic control unit - A. ABS8 connector - B. ESP8 connector - MCI. LF/RR diagonal power supply (or FL/RR with ABS8/ESP8 systems) - MC2. RF/LR diagonal power supply (or FR/RL with ABS8/ESP8 systems) - LF (or FL with ABS8/ESP8 systems). Left front axle output - RR. Right rear axle output - RF (or FR with ABS8/ESP8 systems). Right front axle output - LR (or RL with ABS8/ESP8 systems). Left rear axle output

Four parallel channel system (II)
Electro-hydraulic modulator/control unit

Figure 131/2




102114

1. Hydraulic accumulator - 2. Electro-hydraulic modulator - 3. Electronic control unit - A. ABS8 connector - B. ESP8 connector - MCI. Front axle power supply - MC2. Rear axle power supply - LF (or FL with ABS8/ESP8 systems). Left front axle output - RR. Right rear axle output - RF (or FR with ABS8/ESP8 systems). Right front axle output - LR (or RL with ABS8/ESP8 systems). Left rear axle output

ABS 8 control unit PIN OUT (X - crossed channels, II - parallel channels)

Figure I31/3




102245

| Pin (X) | Pin (II) | Function | Cable |
|---------|----------|--|-------|
| 1 | 1 | Earth (pump control motor) | 0000 |
| 2 | 2 | Positive after fuse (pump control motor power supply enable relay) | 7772 |
| 3 | 3 | Positive after fuse (valve lock power supply enable relay) | 7772 |
| 4 | 4 | Signal earth | 0000 |
| 5 | 5 | Front left sensor | 5570 |
| 6 | 16 | - | - |
| 7 | 7 | Rear left sensor | 5572 |
| 8 | 8 | Rear right sensor earth | 5573 |
| 9 | 9 | Front right sensor earth | 5571 |
| 10 | 10 | Front right sensor | 5571 |
| 11 | 11 | Diagnosis K line | 2299 |
| 12 | 12 | EBD failure warning light | 6673 |
| 13 | 13 | Decelerator deactivation with ABS system ON | 0315 |
| 14 | 14 | - | - |
| 15 | 15 | CAN L line | Green |
| 16 | 6 | Front left sensor earth | 5570 |
| 17 | 17 | Rear left sensor earth | 5572 |
| 18 | 18 | Positive after fuse for ABS (KL 15) | 8847 |
| 19 | 19 | Rear right sensor | 5573 |
| 20 | 20 | Stop signalling switch – brake lights | 1173 |
| 21 | 21 | - | - |
| 22 | 22 | ABS failure warning light | 6670 |
| 23 | 23 | - | - |
| 24 | 24 | - | - |
| 25 | 25 | Diagnosis L line | 1199 |
| 26 | 26 | CAN H line | White |

ESP 8 control unit PIN OUT (X - crossed channels, II - parallel channels)

Figure 131/4



| Pin (X) | Pin (II) | Function | Cable |
|----------|----------|--|-------|
| 1 | 1 | Earth (pump control motor) | 0000 |
| 2 | 2 | Positive after fuse (pump control motor power supply enable relay) | 7772 |
| 3 | 3 | Positive after fuse (valve lock power supply enable relay) | 7772 |
| 4 | 4 | Signal earth | 0000 |
| 5 | 5 | Front left sensor | 5570 |
| 6 | 26 | - | - |
| 7 | 7 | Rear left sensor | 5572 |
| 8 | 8 | Rear right sensor earth | 5573 |
| 9 | 9 | Front right sensor earth | 5571 |
| 10 | 10 | Front right sensor | 5571 |
| 11 | 11 | Diagnosis K line | 2299 |
| 12 | 12 | EBD failure warning light | 6673 |
| 13 | 13 | - | - |
| 14 | 14 | CAN L line | Green |
| 15 | 15 | Yaw sensor earth | 9096 |
| 16 | 16 | Yaw sensor signal | 9095 |
| 17 | 17 | Longitudinal acceleration sensor | 9099 |
| 18 | 18 | Yaw sensor reference signal | 9094 |
| 19 | 19 | Voltage stabilization signal to the acceleration sensor | 9091 |
| 20 | 20 | Side acceleration sensor signal | 9092 |
| 21 | 21 | Side acceleration sensor signal earth | 0050 |
| 22 | 22 | Decelerator deactivation with ABS system ON | 0315 |
| 23 | 23 | - | - |
| 24 | 24 | Diagnosis L line | 1199 |
| 25 | 25 | - | - |
| 26 | 6 | Front left sensor earth | 5570 |
| 27 | 27 | Rear left sensor earth | 5572 |
| 28 | 28 | Positive after fuse for ABS (KL 15) | 8847 |
| 29 | 29 | Rear right sensor | 5573 |
| 30 | 30 | Stop signalling switch – brake lights | 1173 |
| 31 | 31 | Exhaust brake actuation enable switch (ASR/ESP passive switch) | 8800 |
| 32 | 32 | ABS failure warning light | 6670 |
| 33/34 | 33/34 | - | - |
| 35 | 35 | CAN H line | White |
| 36 | 36 | Hand brake ON signal | 6662 |
| 37 | 37 | Yaw sensor test signal | 9093 |
| 38/39/40 | 38/39/40 | - | - |
| 41 | 41 | Stop signalling switch | 1173 |
| 42 | 42 | - | - |
| 43 | 43 | Reverse gear signal | 2227 |
| 44/45 | 44/45 | - | - |
| 46 | 46 | Speed limiter or ASR failure warning light | 6672 |

ESP (Electronic Stability Program) operation

The ESP function controls the vehicle's stability and side dynamics.

The main goals of this function are as follows:

- to improve stability, especially in understeering and oversteering conditions;
- to reduce the braking distance in line change conditions and on slippery roads.

The ESP function evaluates the following driver's requests:

- steering-wheel position;
- wheel revs number (speed);
- pressure on the brake pedal or accelerator position.

The ESP control unit microprocessor recognizes the specific manoeuvre and examines the vehicle's behaviour:

- degree of yaw;
- wheel revs number;
- transverse acceleration.

The microprocessor assesses the running behaviour based on the data provided, and the ESP comes into operation by acting on the brakes.

The hydraulic modulator controls brake pressure for every single wheel as quick as possible.


The ESP may, through engine management, reduce the number of revolutions of the engine itself, in order to withstand vehicle deceleration.

The ESP system is always active in the background, i.e. it compares the actual vehicle ride with the driver's desired ride 50 times a second.

Control strategy

Sudden obstacle

Figure 131/5




102246

- 1) Acting on the steering-wheel suddenly: danger of understeering.
- 2) The ESP brakes the rear left wheel \Rightarrow the vehicle follows the steering command.
- 3) The driver countersteers: Danger of oversteering \Rightarrow The ESP brakes the front left wheel.
- 4) The vehicle recovers stability.

Sudden steering

Figure I31/6




101864

- 1) The vehicle risks skidding (oversteering): the ESP brakes the front right wheel.
- 2) The vehicle recovers stability.
- 3) The vehicle risks skidding (oversteering): the ESP brakes the front left wheel.
- 4) The vehicle recovers stability.

Vehicle running on a slippery road

Figure I31/7



101865

- 1) The vehicle risks skidding (understeering): the ESP brakes the rear right wheel and reduces the engine revs number.
- 2) The vehicle recovers stability.

ASR deactivation strategies

- Disabling any engine intervention of the ESP and ASR/MSR (torque increase/decrease) over the entire speed range.
- Traction Control actuation enabled up to the speed of 60 k.p.h. (electronic locking of differential, with no reference to the dragged wheels).
- Stability intervention (ESP) enabled over the entire speed range.
- ABS enabled over the entire speed range.
- EBD enabled over the entire speed range.

NOTE ASR deactivation is recommended when driving with the snow-chains mounted, or when the wheels sink into gravel, sand, etc.

Recovery strategy in case of component failure

| System failure (warning light ON) | ESP/ASR | ABS | EBD |
|---|----------|----------|----------|
| Broken component | | | |
| Steering angle sensor | X | | |
| Yaw sensor | X | | |
| Brake light switch | X | X | |
| 1 or 2 wheel revs sensors | X | X | |
| 3 ou 4 capteurs tours roue 3 or 4 wheel revs sensors | X | X | X |
| Electronic control unit | X | X | X |
| Solenoid valve hydraulic unit | X | X | X |
| Pressure sensor, ABS pump motor | | X | X |

NOTE If the warning lights are OFF, all the systems are working.

Warning light legend

Warning light ON: ESP/ASR/MSR not working. No action taken by the ESP/ASR on the engine or the brakes.

N.B. Warning light blinking = ESP/ASR coming into operation.

ABS not working

The front axle may get locked sooner than the rear axle. EBD recovery reduces the rear axle pressure.


EBD not working

No correction of the rear axle braking pressure: DANGER OF SPINNING THROUGH 180 DEGREES!

The warning light also warns the driver of low brake fluid level, hand brake ON, brake pads worn.

Installing the esp components

Figure 131/8



102108

1. Acceleration sensor - 2. Yaw sensor - 3. Steering angle sensor - 4. Electro-hydraulic modulator/control unit

NOTE Installation of the electro-hydraulic modulator/control unit is similar in ASB 8 systems, too.

ESP system components and calibration


Some modifications or repairs affecting the ESP system components require a calibration procedure.

The repair operations that require the above procedure are detailed as follows:

- Replacing the system's braking apparatus electronic control unit (incorporated into the electro-hydraulic modulator).
- Replacing the steering angle sensor fitted into the steering wheel.
- Replacing the longitudinal acceleration sensor.

Yaw sensor with built-in side acceleration sensor

Figure 131/9



102115

It measures the motion of the vehicle around its own vertical axis (yaw) as well as the vehicle's side acceleration.

These signals continuously inform the control unit about the vehicle's behaviour.


The comparison between these signals and those from the driver (steering-wheel position, wheel spin number/speed and pressure on the brake pedal/accelerator position) allows the ESP control unit to define the actions to be taken. The hydraulic unit controls brake pressure as quickly as possible, separately for every single wheel.

Moreover, the ESP system may decrease the engine revs number by means of the engine control feature.

NOTE Replacing the yaw sensor requires no calibration.

Longitudinal acceleration sensor

Figure 131/10



102116

It measures the vehicle's acceleration and deceleration changes.


These signals continuously inform the control unit about the vehicle's behaviour.

The comparison between these signals and those from the driver (steering-wheel position, wheel spin number/speed and pressure on the brake pedal/accelerator position) allows the ESP control unit to define the actions to be taken. The hydraulic unit controls brake pressure as quickly as possible, separately for every single wheel.

Moreover, the ESP system may decrease the engine revs number by means of the engine control feature.

Longitudinal acceleration sensor calibration

Figure 131/11



102111

In a horizontal position, you will obtain the sensor "zero" condition through the diagnosis instrument, i.e. you will assign its absolute zero position.


Use a diagnosis instrument to clear the errors.

Carry out a road test, to make the control unit verify whether errors are still found. The vehicle is to be taken to a slight slope and checked if it is kept braked for 2.5 seconds.

Drive back to the service centre, then use a diagnosis instrument to verify that the anomaly is no longer found.

Steering angle sensor

Figure 131/12



102116


It measures the steering angle required by the driver.

The comparison between this signal and those from all the other sensors allows the ESP control unit to define the actions to be taken. The hydraulic unit controls brake pressure as quickly as possible, separately for every single wheel.

Moreover, the ESP system may decrease the engine revs number by means of the engine control feature.

Steering angle sensor calibration

Figure 131/13



102110

With both the steering-wheel and the wheels in straight position (after checking toe-in), you will obtain the sensor "zero" condition through the diagnosis instrument, i.e. you will assign its absolute zero position.

Use a diagnosis instrument to clear the errors.


Carry out a road test, to make the control unit verify whether errors are still found. Drive along a straight road at a speed of approximately 50 k.p.h. Steer to the right and then to the left several times, after making sure you do not endanger other drivers.

NOTE You need not oversteer to cause the ESP warning light to come on.

Drive back to the service centre, then use a diagnosis instrument to verify that the anomaly is no longer found.

ESP control unit programming

Figure 131/14



102109

Entering the variant codes: type of drive, engine, MTT, wheelbase, type of front and rear suspensions, height.

Easy compares the type of vehicle (PIC reading) with the control unit code, to avoid installation errors (single wheels instead of dual), and downloads the variant codes into the control unit.

Clear the errors (if any) by means of the diagnosis instrument.

Carry out a road test. Drive along a straight road at a speed of approximately 50 k.p.h. Brake suddenly as if in an emergency, after making sure you do not endanger other drivers: you should feel the system "respond" on the brake pedal. This test makes the control unit verify whether errors are still found.

Drive back to the service centre, then use a diagnosis instrument to verify that the anomaly is no longer found.

Replacing ESP central unit needs the longitudinal acceleration sensor calibration that was already described in previous page.

The steering angle sensor, in this case, is not to be calibrated as it has its own internal memory.

6AS 300 VD AUTOMATIC TRANSMISSION

Description of operation

The gear engaging system of the 6 AS 300 VD gearbox is a combination of a traditional system of the mechanic type and an electric one.

Below are the main components of the system:

- 1) electronic control unit;
- 2) gear selecting/engaging actuator;
- 3) gear shift lever;
- 4) clutch actuator;
- 5) display/buzzer.

In the manual mode, the first gear is used to start the vehicle.

In the automatic mode, you just need to act on the selection lever (A/M): the gear is selected directly by the control unit (1a).

The electronic control unit picks up all the signals required to meet the safety conditions and the parameters programmed in the same. It also drives the electric actuating motor(s) for gear selection/engagement and clutch control.


The information required for driving is in any case made available to the driver by means of the display.

NOTE To ensure correct management of the gearbox and the other auxiliary functions provided for by the system, the control unit is interfaced (CAN line) with the other electric and electronic system fitted to the vehicle, such as:

- EDC
- ABS8/ESP8
- IMMOBILIZER
- PTO (POWER TAKE-OFF, if available).

Electronic control

Figure 131/15



101868

1. Buzzer - 2. Tachograph - 3. Display - 4. IMMOBILIZER control unit - 5. ABS8/ESP8 control unit - 6. EDC control unit -
 7. Gear shift lever - 8. P.T.O. icon - 9. P.T.O. - 10. Gearbox - 11. Gearbox control unit - 12. Reversing light actuation -
 13. Clutch actuator - 14. Gearbox actuator.

COMPOSITION OF THE SYSTEM

System control unit


The electronic control unit receives the signals from the sensors/switches: the management and control of the system under the different operating conditions of the gearbox are based on the above signals.

It is interfaced with other electronic systems available on the vehicle, such as EDC and ABS, through CAN communication lines.

A - Connector on the gearbox side

B - Connector on the vehicle side

Figure 131/16



90135


Through the connection with the EDC I6 system, the gearbox control unit is able to detect the position of the accelerator pedal and also the engine revs number.

Connection with the ABS8/ESP8 control unit is used to prevent the "UP" gear shift at bends and also control driving under poor grip conditions in case of mode "A" driving.

The new ABS system controls "smart" warning lights incorporated into the on-board panel. These warning lights come on to indicate braking system failure.

NOTE The "Brake" signal, upon start-up, comes directly from the EDC control unit. The reverse gear signal is direct.

Figure 131/17




101870

Position of the electronic control unit


Connector control unit PIN-OUT – gearbox side (A)

Figure 131/18



101869

| Pin | Function |
|-----|--|
| 1 | Electric motor positive (gearbox actuator selector pin 6) |
| 2 | Electric motor negative (gearbox actuator selector pin 1) |
| 3 | Electric motor positive (clutch actuator pin 3) |
| 4 | Electric motor negative (clutch actuator pin 4) |
| 5 | Electric motor positive (gear engaging gearshift actuator pin 6) |
| 6 | Electric motor negative (gear engaging gearshift actuator pin 1) |
| 11 | Sensor direction signal (clutch actuator pin 4) |
| 12 | Sensor speed signal (clutch actuator pin 2) |
| 13 | Clutch actuator pin 5 sensor voltage signal (5 V) |
| 15 | Sensor direction signal (gear engaging gearshift actuator pin 4) |
| 16 | Sensor voltage signal, 12 V (gear engaging gearshift actuator pin 3) |
| 17 | Sensor voltage signal, 12 V (gearbox actuator selector pin 3) |
| 18 | Sensor direction signal (gearbox actuator selector pin 4) |
| 33 | Earth (clutch actuator pin 1) |
| 35 | Sensor speed signal (gear engaging gearshift actuator pin 5) |
| 36 | Earth (gear engaging gearshift actuator pin 2) |
| 37 | Earth (gearbox actuator selector pin 2) |
| 38 | Sensor speed signal (gearbox actuator selector pin 5) |

Connector control unit PIN-OUT – vehicle side (B)**Figure 131/19**

101871


| Pin | Function |
|-----|---|
| 1 | Earth |
| 2 | Earth |
| 3 | Earth |
| 4 | Battery positive |
| 5 | Battery positive |
| 6 | Battery positive |
| 7 | Earth |
| 8 | Earth |
| 9 | KL 30 |
| 14 | PTO actuation request signal (option) |
| 17 | CAN H VDB line (female junction) |
| 18 | CAN H VDB line (female junction) |
| 28 | CAN L VDB line (male junction) |
| 29 | CAN L VDB line (female junction) |
| 33 | Free |
| 37 | Free |
| 38 | Free |
| 39 | KL 30 |
| 40 | CAN L --- ZF LINE |
| 41 | CAN H --- ZF LINE |
| 43 | KL 15 |
| 44 | On-board panel signal (doors open) |
| 45 | On-board panel signal (emergency brake) |
| 46 | PTO state signal |
| 47 | PTO ON signal |
| 49 | Power supply from gearbox electronic control unit |
| 51 | Speed signal from on-board panel |
| 52 | Diagnosis K line |

Gearbox actuator

The function of the gear actuator is to continuously exchange information with the electronic control unit for gear selection and engagement.

It is made up of two electric motors, control cylinders, and respective sensors.


Figure 131/20



90139

Position of actuator


Figure 131/21



101872

1. Gear engaging electric motor - 2. Gear selection electric motor

Figure 131/22



101873

Wiring diagram

| Pin | Function |
|-----|-----------------------------|
| 1 | Electric motor negative |
| 2 | Earth |
| 3 | Sensor voltage signal (5 V) |
| 4 | Sensor direction signal |
| 5 | Sensor speed signal |
| 6 | Electric motor positive |

Characteristics of electric motor


| | |
|------------|---------------------|
| Voltage | 12 V |
| Output | 95 W |
| Torque | 0.72 Nm (at 125 °C) |
| n_{\max} | 5400 r.p.m. |

Clutch actuator

It is made up of the following:


- a cylinder acting on the clutch engaging/disengaging lever;
- a position sensor that detects the clutch lever stroke, by informing the electronic control unit of the actuating cylinder position and the clutch plate wear.

Figure 131/23



90137


Figure 131/24



90138

1. Actuating cylinder - 2. Electric motor - 3. Vehicle electric wiring junction block

Figure 131/25



101873

Wiring diagram


| Pin | Function |
|-----|-------------------------------------|
| 1 | Earth |
| 2 | Incremental sensor speed signal |
| 3 | Electric motor positive |
| 4 | Incremental sensor direction signal |
| 5 | Sensor voltage signal (5 V) |
| 6 | Electric motor negative |

Characteristics of electric motor

| | |
|---------------------|------------------------------|
| Max. torque | 0.65 Nm |
| No-load revs number | 5800 r.p.m. |
| Output | 80 W (0.3 Nm - 2,500 r.p.m.) |

Display

Figure 131/26




101875

The display, located on the board, makes it possible to show all the information required for correct use of the system, such as, for instance:

- mode (manual or automatic) and, in both cases, the gear engaged;
- the reverse gear/neutral position (R/N);
- faults/misuse with acoustic signal (e.g. clutch overheating);
- the fault code (troubleshooting) shown on page 47 can be displayed only by means of the diagnosis instrument;
- vehicle state condition: gear engaged.

| Pin | Function |
|-----|-----------------------------|
| 1 | Backlighting ON/OFF control |
| 2 | |
| 3 | Analog backlighting control |
| 4 | - |
| 5 | CAN H |
| 6 | Earth |
| 7 | CAN L |
| 8 | +12 V |


Figure 131/27



90263

Gear selector

Figure 131/28




101876

The gear selector is an electronic component located in the cabin next to the driver.

It is interfaced with the gearbox control unit, by means of the CAN communication line, in order to inform of the driver's intention of selecting and engaging the gears.

| Pin | Function |
|-----|----------|
| 1 | KL 15 |
| 2 | KL 30 |
| 3 | CAN L |
| 4 | CAN H |
| 5 | - |
| 6 | - |

Figure 131/29



90262

I. Gear selector connector

Accelerator pedal

To detect the engine idling position and allow the clutch to be engaged when the vehicle is about to start, the N.O. switch, incorporated into the position sensor, is used, with the pedal released.


This signal reaches the EDC electronic control unit and is sent, through the CAN VDB (Vehicle Data Base) line, to the 6AS 300 VD gearbox control unit.

The "kick-down" function can be actuated during running, in the automatic mode.

When the pedal is pressed down almost fully (98%), e.g. when overtaking, the system will automatically shift down by one speed, thus making it possible to use the deflecting torque at its best.


In practice, if the accelerator pedal is pressed fully down, the vehicle will ride at a running speed with a higher gear shift.

Figure 131/30




101877

Figure 131/31



101878

Figure 131/32



101879

PTO

One single button is used to actuate and deactivate the power take-off (PTO).

Operation under NON-STATIONARY conditions


- The PTO can be engaged only when the gear shift is in neutral and the engine is ON;
- then, the first gear can be engaged, and the vehicle can be started;
- after setting off, the gear cannot be changed any more when the vehicle is running;
- the PTO can be disengaged both with the gears running and the neutral ON.

Operation under STATIONARY conditions

- The PTO can be engaged only when the gear shift is in neutral and the engine is ON.

PTO diagram

Figure 131/33



101880

1. EDC control unit - 2. Gearbox control unit - 3. Clutch actuator electric motor - 4. PTO actuator motor - 5. PTO ON switch - 6. PTO ON warning light - 7. PTO control unit - 8. PTO actuation switch - A. Gearbox side - B. Vehicle side.

PTO engaging procedure

To engage the power take-off, the following operations must be carried out:

- 1) press the PTO button;
- 2) wait at least 0.5 seconds;
- 3) release the PTO button.

-
- NOTE**
- The PTO will be actuated only if the PTO button is kept depressed for more than 0.5 seconds.
 - The PTO button will be ignored until the next 5 seconds have elapsed.
 - After such time, if the button is kept depressed for more than 30 seconds, a quick flash will be displayed, and PTO disengagement and lock will be commanded until the vehicle is switched on again.
-

PTO disengaging procedure


To disengage the power take-off, the following operations must be carried out:

- 1) press the PTO button;
- 2) wait at least 0.5 seconds;
- 3) release the PTO button.

-
- NOTE**
- The operation will be carried out only if the PTO button is kept depressed for more than 0.5 seconds.
 - The PTO button will be ignored until the next 5 seconds have elapsed. • In the event that the power take-off is not disengaged within 5 seconds, the operator may carry out the operation again, by pressing the button again.
 - After such time, if the button is kept depressed for more than 30 seconds, a quick flash will be displayed, and PTO disengagement and lock will be commanded until the vehicle is switched on again.
-

Remote-control switch and fuse assembly

Figure 131/34



90264

The system's power supply is ensured by a set of fuses located in the cabin (see figure) in the marked positions.

64 - control unit power supply

65 - automatic transmission services

66 - start prevent

There are three more 25 A fuses (electric motor power supply) that are connected with control unit pins 4, 5, and 6. In the event that one or two of these fuses blow, the gearbox functions are not affected. If the third fuse is broken, the gearbox is not able to operate (i.e. both the clutch motion and the gear selection/engagement will be disabled).

Accelerator pedal sensor

The accelerator pedal position is provided to the gearbox control unit, through a suitable communication line, by the EDC electronic control unit which is informed about the position by the load transmitter fitted directly to the accelerator pedal.

Engine revs sensor

The sensor is mounted just next to the engine flywheel.

The engine running speed values are sent to the EDC electronic control unit which conveys them to the gearbox control unit by means of a special communication line.

Vehicle speed sensor

This sensor sends the pulses to the tachometer/electronic tachograph.

The signal is duplicated by the ABS/ESP sensors available on the wheels.

DIAGNOSIS INSTRUMENTS

DISPLAY

First-level diagnosis that provides coded displaying of the errors found in the control unit memory. The information is shown on the display only by means of diagnosis instruments.

MODUS

Computer-assisted diagnosis station used for diagnosis of braking systems, pneumatic suspensions, engines and electronically-controlled systems.

The station is equipped with auxiliary functions, such as electronic control unit programming, spare part catalogue referencing, time-charts, etc.

IT 2000

IT 2000 is a diagnosis instrument for all the Electronic Systems fitted to IVECO vehicles. It allows you to promptly operate on a vehicle by recognizing the latter by means of the chassis number.

It stores the results of the diagnostic work carried out.

It can also be used as a laptop PC and is set for remote diagnosis.

Using MODUS as a mother station allows you to update and configure IT 2000.

E.A.SY.

The E.A.SY. system allows you to easily diagnose and program the various electronic control units fitted to the vehicle. It is made up of an ECI module for communication with the electronic control units and a Panasonic PC.


The ECI module allows you, by taking advantage of the Panasonic PC, to easily carry out work on the road; in particular, diagnostic work can be assisted by a specialized remote centre, thanks to the wireless technology incorporated into the Panasonic PC (e.g. GPRS).

MODUS - IT 2000 - E.A.S.Y. CONNECTION

The 38-pole connection makes it possible to perform the following operations:

- Gearbox control unit data reading
- Error (if any) detection and clearing
- Gear shift programming
- Clutch engagement/release control
- Control unit programming and configuring

Figure 131/35



A. IT 2000 - B. E.A.S.Y. - C. MODUS

102266

TROUBLESHOOTING

| DTC DEC | DTC HEX | Description |
|----------------|----------------|--|
| 10 | A | ELECTRONIC CONTROL UNIT / TOO LOW TEMPERATURE |
| 11 | B | ELECTRONIC CONTROL UNIT / TOO HIGH TEMPERATURE |
| 12 | C | VEHICLE CAN LINE / FAULT |
| 13 | D | ZF CAN LINE / FAULT |
| 30 | 1E | VEHICLE CAN LINE / DELAY IN RECEIVING THE EEC1 CAN MESSAGE |
| 31 | 1F | VEHICLE CAN LINE / DELAY IN RECEIVING THE EEC2 CAN MESSAGE |
| 32 | 20 | VEHICLE CAN LINE / DELAY IN RECEIVING THE CCVS CAN MESSAGE |
| 33 | 21 | VEHICLE CAN LINE / DELAY IN RECEIVING THE EEC3 CAN MESSAGE |
| 34 | 22 | VEHICLE CAN LINE / DELAY IN RECEIVING THE EBC1 CAN MESSAGE |
| 35 | 23 | VEHICLE CAN LINE / DELAY IN RECEIVING THE ENGCONFMPM CAN MESSAGE |
| 36 | 24 | VEHICLE CAN LINE / DELAY IN RECEIVING THE HRW CAN MESSAGE |
| 37 | 25 | ZF CAN LINE / DELAY IN RECEIVING THE SL_2_TCU CAN MESSAGE |
| 38 | 26 | VEHICLE CAN LINE / DELAY IN RECEIVING THE VDC1 CAN MESSAGE |
| 39 | 27 | VEHICLE CAN LINE / DELAY IN RECEIVING THE VDC2 CAN MESSAGE |
| 50 | 32 | VEHICLE CAN LINE / ERROR ON ENGINE REVS SIGNAL - EEC1 CAN MESSAGE |
| 52 | 34 | VEHICLE CAN LINE / ERROR ON SIGNAL FOR REQUESTED ENGINE TORQUE - EEC1 CAN MESSAGE |
| 54 | 36 | VEHICLE CAN LINE / ERROR ON ACCELERATOR PEDAL POSITION SIGNAL - EEC2 CAN MESSAGE |
| 56 | 38 | VEHICLE CAN LINE / ERROR ON SIGNAL FROM BRAKE PEDAL - CCVS CAN MESSAGE |
| 57 | 39 | VEHICLE CAN LINE / ERROR ON ENGINE TORQUE AND BRAKING TORQUE CONFIGURATION SIGNAL - EEC1 CAN MESSAGE |
| 58 | 3A | VEHICLE CAN LINE / ERROR ON ACTUAL ENGINE TORQUE SIGNAL - EEC1 CAN MESSAGE |
| 60 | 3C | VEHICLE CAN LINE / ERROR ON ABSORBED ENGINE TORQUE SIGNAL - EEC2 CAN MESSAGE |
| 62 | 3E | VEHICLE CAN LINE / ERROR ON REFERENCE ENGINE TORQUE SIGNAL - ENG_CONF_MPM CAN MESSAGE |
| 66 | 42 | VEHICLE CAN LINE / ERROR ON REAR LEFT WHEEL SPEED SIGNAL - HRW CAN MESSAGE |
| 67 | 43 | VEHICLE CAN LINE / ERROR ON REAR RIGHT WHEEL SPEED SIGNAL - HRW CAN MESSAGE |
| 77 | 4D | VEHICLE CAN LINE / ERROR ON VEHICLE SPEED SIGNAL - CCVS CAN MESSAGE |
| 100 | 64 | SPEED ACTUATOR - SELECT / SHORT-CIRCUIT TO EARTH ON CONTROL MOTOR OUTPUT |
| 101 | 65 | SPEED ACTUATOR - SELECT / SHORT-CIRCUIT TO POSITIVE ON CONTROL MOTOR OUTPUT |
| 102 | 66 | SPEED ACTUATOR - SELECT / INTERRUPTION ON CONTROL MOTOR OUTPUT |
| 103 | 67 | SPEED ACTUATOR - SELECT / SENSOR SUPPLY VOLTAGE - TOO HIGH |
| 104 | 68 | SPEED ACTUATOR - SELECT / SENSOR SUPPLY VOLTAGE - TOO LOW |
| 105 | 69 | SPEED ACTUATOR - SELECT / SENSOR SHORT-CIRCUIT TO EARTH |
| 106 | 6A | SPEED ACTUATOR - SELECT / SENSOR SHORT-CIRCUIT TO POSITIVE OR INTERRUPTION |
| 107 | 6B | SPEED ACTUATOR - SELECT / NON-PLAUSIBLE MOTOR CONTROL SIGNAL |
| 120 | 78 | SPEED ACTUATOR - SELECT / TOO HIGH CURRENT |
| 121 | 79 | SPEED ACTUATOR - SELECT / TOO HIGH TEMPERATURE |

| DTC DEC | DTC HEX | Description |
|---------|---------|---|
| 130 | 82 | SPEED ACTUATOR - SELECT / MECHANIC FAULT |
| 131 | 83 | SPEED ACTUATOR - SELECT / MECHANIC FAULT |
| 132 | 84 | SPEED ACTUATOR - SELECT / POSITION CONTROL ERROR |
| 180 | B4 | SPEED ACTUATOR - SELECT / REFERENCE EOL PARAMETER ERROR (LACKING MEASUREMENT VALUES) |
| 181 | B5 | SPEED ACTUATOR - SELECT / REFERENCE EOL PARAMETER ERROR (OUT-OF-TOLERANCE MEASUREMENT VALUES) |
| 200 | C8 | SPEED ACTUATOR - SHIFT / SHORT-CIRCUIT TO EARTH ON CONTROL MOTOR OUTPUT |
| 201 | C9 | SPEED ACTUATOR - SHIFT / SHIFT / SHORT-CIRCUIT TO POSITIVE ON CONTROL MOTOR OUTPUT |
| 202 | CA | SPEED ACTUATOR - SHIFT / INTERRUPTION ON CONTROL MOTOR OUTPUT |
| 205 | CD | SPEED ACTUATOR - SHIFT / SENSOR SHORT-CIRCUIT TO EARTH |
| 206 | CE | SPEED ACTUATOR - SHIFT / SENSOR SHORT-CIRCUIT TO POSITIVE OR INTERRUPTION |
| 207 | CF | SPEED ACTUATOR - SHIFT / NON-PLAUSIBLE MOTOR CONTROL SIGNAL |
| 220 | DC | SPEED ACTUATOR - SHIFT / TOO HIGH CURRENT |
| 221 | DD | SPEED ACTUATOR - SHIFT / TOO HIGH TEMPERATURE |
| 230 | E6 | SPEED ACTUATOR - SHIFT / MECHANIC FAULT |
| 231 | E7 | SPEED ACTUATOR - SHIFT / MECHANIC FAULT |
| 232 | E8 | SPEED ACTUATOR - SHIFT / POSITION CONTROL ERROR |
| 252 | FC | SPEED ACTUATOR - SHIFT / ENGAGING ERROR - 1 st SPEED |
| 253 | FD | SPEED ACTUATOR - SHIFT / ENGAGING ERROR - 2 nd SPEED |
| 254 | FE | SPEED ACTUATOR - SHIFT / ENGAGING ERROR - 3 rd SPEED |
| 255 | FF | SPEED ACTUATOR - SHIFT / ENGAGING ERROR - 4 th SPEED |
| 256 | 100 | SPEED ACTUATOR - SHIFT / ENGAGING ERROR - 5 th SPEED |
| 257 | 101 | SPEED ACTUATOR - SHIFT / ENGAGING ERROR - 6 th SPEED |
| 258 | 102 | SPEED ACTUATOR - SHIFT / ENGAGING ERROR - REVERSE GEAR |
| 259 | 103 | SPEED ACTUATOR - SHIFT / TEACHING REQUEST GEARBOX BOUNDARY OVERRIDE |
| 260 | 104 | SPEED ACTUATOR - SHIFT / TEACHING REQUEST GEARBOX NEUTRAL POSITION FAILURE |
| 280 | 118 | SPEED ACTUATOR - SHIFT / REFERENCE EOL PARAMETER ERROR (LACKING MEASUREMENT VALUES) |
| 281 | 119 | SPEED ACTUATOR - SHIFT / REFERENCE EOL PARAMETER ERROR (OUT-OF-TOLERANCE MEASUREMENT VALUES) |
| 282 | 11A | SPEED ACTUATOR - SHIFT / SYSTEM GEOMETRY ERROR (ASYMMETRY) |
| 283 | 11B | SPEED ACTUATOR - SHIFT / MECHANIC FAULT |
| 300 | 12C | CLUTCH ACTUATOR / SHORT-CIRCUIT TO EARTH ON CONTROL MOTOR OUTPUT |
| 301 | 12D | CLUTCH ACTUATOR / SHORT-CIRCUIT TO POSITIVE ON CONTROL MOTOR OUTPUT |
| 302 | 12E | CLUTCH ACTUATOR / INTERRUPTION ON CONTROL MOTOR OUTPUT |
| 303 | 12F | CLUTCH ACTUATOR / SENSOR SUPPLY VOLTAGE - TOO LOW |
| 320 | 140 | CLUTCH ACTUATOR / TOO HIGH CURRENT |
| 321 | 141 | CLUTCH ACTUATOR / TOO HIGH TEMPERATURE |
| 330 | 14A | CLUTCH ACTUATOR / MECHANIC FAULT ON CONTROL MOTOR |
| 331 | 14B | CLUTCH ACTUATOR / MECHANIC FAULT - LOCK AT END OF STROKE |
| 350 | 15E | CLUTCH ACTUATOR / POSITION CONTROL ERROR |
| 351 | 15F | CLUTCH ACTUATOR / NON-PLAUSIBLE POSITION SIGNAL AT THE END OF STROKE |
| 352 | 160 | CLUTCH ACTUATOR / NON-PLAUSIBLE POSITION SIGNAL |
| 354 | 162 | CLUTCH ACTUATOR / MULTIPLE INPUT SPEED PLAUSIBILITY ERROR |
| 355 | 163 | CLUTCH ACTUATOR / MULTIPLE CLUTCH TORQUE PLAUSIBILITY ERROR |

| DTC DEC | DTC HEX | Description |
|----------------|----------------|--|
| 356 | 164 | CLUTCH ACTUATOR / NO ENGINE REACTION UPON TORQUE REDUCTION REQUEST |
| 380 | 17C | CLUTCH ACTUATOR / TOO SLOW OR JAMMED CLUTCH MOTION WHEN PERFORMING ACTIVE DIAGNOSIS |
| 381 | 17D | CLUTCH ACTUATOR / OUT-OF-RANGE CLUTCH MOTION WHEN PERFORMING ACTIVE DIAGNOSIS |
| 382 | 17E | CLUTCH ACTUATOR / CLUTCH MOTION BEYOND PERMITTED LIMITS |
| 383 | 17F | ELECTRONIC CONTROL UNIT / DATA MEMORY (EEPROM) ACCESS ERROR WHEN PERFORMING ACTIVE DIAGNOSIS |
| 384 | 180 | CLUTCH ACTUATOR / ERROR DURING CLUTCH CLOSING |
| 385 | 181 | CLUTCH ACTUATOR / ERROR DURING CLUTCH OPENING |
| 386 | 182 | ELECTRONIC CONTROL UNIT / DATA MEMORY (EEPROM) ACCESS ERROR WHEN PERFORMING ACTIVE DIAGNOSIS (TOUCH-POINT) |
| 400 | 190 | DIGITAL OUTPUTS / SHORT-CIRCUIT TO POSITIVE ON ENGINE STARTING ENABLE OUTPUT |
| 401 | 191 | DIGITAL OUTPUTS / SHORT-CIRCUIT TO POSITIVE ON REVERSING LIGHT IGNITION OUTPUT |
| 402 | 192 | DIGITAL OUTPUTS / SHORT-CIRCUIT TO POSITIVE ON PTO ACTUATION ENABLE OUTPUT |
| 403 | 193 | SUPPLY VOLTAGE / SUPPLY VOLTAGE INSIDE THE ECU - TOO HIGH |
| 404 | 194 | SUPPLY VOLTAGE / SUPPLY VOLTAGE INSIDE THE ECU - TOO LOW |
| 405 | 195 | SUPPLY VOLTAGE / ECU SUPPLY VOLTAGE +30 HS - TOO HIGH |
| 406 | 196 | SUPPLY VOLTAGE / ECU SUPPLY VOLTAGE +30 HS - TOO LOW |
| 407 | 197 | SUPPLY VOLTAGE / KEY-CONTROLLED SUPPLY VOLTAGE +15 - TOO HIGH |
| 408 | 198 | SUPPLY VOLTAGE / KEY-CONTROLLED SUPPLY VOLTAGE +15 - TOO LOW |
| 409 | 199 | SUPPLY VOLTAGE / SUPPLY VOLTAGE INSIDE THE ECU - TOO HIGH |
| 410 | 19A | SUPPLY VOLTAGE / SUPPLY VOLTAGE INSIDE THE ECU - TOO LOW |
| 411 | 19B | SUPPLY VOLTAGE / ECU SUPPLY VOLTAGE +30 - TOO LOW |
| 412 | 19C | SUPPLY VOLTAGE / ECU SUPPLY VOLTAGE +30 - TOO LOW |
| 413 | 19D | GEARBOX OUTPUT REVS SENSOR / SHORT-CIRCUIT TO EARTH |
| 414 | 19E | GEARBOX OUTPUT REVS SENSOR / NON-PLAUSIBLE SIGNAL |
| 415 | 19F | GEARBOX OUTPUT REVS SENSOR / WRONG SIGNAL |
| 434 | 1B2 | SUPPLY VOLTAGE / ECU SUPPLY VOLTAGE (+30) DIFFERENT FROM KEY-CONTROLLED VOLTAGE (+15) |
| 435 | 1B3 | GEARBOX OUTPUT REVS SENSOR / NON-PLAUSIBLE SIGNAL |
| 436 | 1B4 | SPEED ACTUATOR - SELECT / NON-PLAUSIBLE SIGNAL FROM THE SENSOR |
| 437 | 1B5 | SPEED ACTUATOR - SHIFT / NON-PLAUSIBLE SIGNAL FROM THE SENSOR |
| 438 | 1B6 | DIGITAL OUTPUTS / SHORT-CIRCUIT TO EARTH ON ENGINE START-PREVENT SIGNAL |
| 439 | 1B7 | DIGITAL OUTPUTS / TOO LOW VOLTAGE ON START-PREVENT SIGNAL |
| 440 | 1B8 | GEAR SELECTOR LEVER / MINOR ANOMALY |
| 441 | 1B9 | GEAR SELECTOR LEVER / SERIOUS ANOMALY - LACKING SIGNAL |
| 442 | 1BA | GEAR SELECTOR LEVER / GEARBOX LEVER POSITION NOT DEFINED |
| 443 | 1BB | DIGITAL OUTPUTS / SHORT-CIRCUIT TO EARTH ON REVERSING LIGHT IGNITION SIGNAL |

| DTC DEC | DTC HEX | Description |
|----------------|----------------|---|
| 444 | IBC | DIGITAL OUTPUTS / SHORT-CIRCUIT TO EARTH ON PTO ACTUATION SIGNAL |
| 450 | IC2 | ELECTRONIC CONTROL UNIT / GENERIC DATA MEMORY (EEPROM) ACCESS ERROR |

ELECTRONIC INJECTION SYSTEM

Common rail

General

In order to reduce the emission of particulate, particularly high injection pressures are required.

The system on the new Daily makes it possible to inject the fuel at pressures reaching 1350 bar, while the pressure obtained with electronic system management optimises the work of the engine limiting emissions and consumption.


In other diesel systems the high pressure is generated only at the moment of injection for each single cylinder (injection pump or injector-pump).

In the common rail a special pump continuously keeps the fuel at high pressure, regardless of the stroke and of the cylinder that is to receive injection, and accumulates it in a common duct for all the injectors.

Therefore, fuel already at the injection pressure is always present at the inlet of the injectors.

When the solenoid valve of an injector is energised by the electronic control unit, injection takes place in the corresponding cylinder.

Figure 132




FUEL FEED AND RECIRCULATION DIAGRAM

1. Heat starter plug – 2. Heat starter electro valve – 3. Electrical injector – 4. Rail hydraulic accumulator – 5. 3rd pump cutout electro valve – 6. High-pressure pump – 7. Fuel filter – 8. Electrically driver pump – 9. Prefilter – 10. Reservoir – 11. Pressure regulator valve – 12. Connection – 13. Pressure limiter valve – 14. Flow limiter

In reality the system is much more complex, as the various control and adjustment components have to be integrated.

The MS6.3 electronic control centre monitors the entire system: it receives data from sensors and activates the actuators as required based on input signal processing.


Figure 133



HYDRAULIC LAYOUT

5. Pre-filter – 6. Electric pump – 7. Filter with overpressure valve – 8. Pressure regulator – 9. Pressure limiter – 10. Fuel outlets unit – 11. Thermal starter

Figure 134




1. 3rd impeller cut-off device – 2. Flywheel rpm sensor – 3. High pressure pump – 4. Pressure regulator – 5. Other actuators (thermal starter, heated filter, fan control, ac control) – 6. Electronic control unit with built-in atmospheric pressure sensor – 7. Other sensors (accelerator, brake, clutch, vehicle speed, water temperature, air temperature) – 8. From rail pressure sensor – 9. Fuel tank – 10. Pre-filter – 11. Electric pump – 12. Fuel filter – 13. Filter overpressure valve – 14. Outlets unit with calibrated hole – 15. Rail pressure limiter – 16. Air flow meter – 17. Common rail – 18. Injectors – 19. Timing sensor on camshaft – A. To thermal starter – B. Electric circuit – C. Low pressure fuel – D. High pressure fuel

Common rail (FIA)

It differs from the Common rail system on previous engines in that injected fuel pressure is 1600 instead of 1350 bars.

Preheat plugs are provided for cold starts.

Figure 135



0003343t

1. High pressure pump – 2. Piping – 3. Pressure regulator – 4. Water in filter sensor – 5. Fuel filter with water separator – 6. Fuel filter clogging sensor – 7. Fuel temperature sensor – 8. Fuel pressure line to filter – 9. Fuel return line to tank – 10. Fuel return line to filter – 11. High pressure piping to common rail – 12. Low pressure return line from rail – 13. Over pressure valve – 14. Common rail – 15. Fuel pressure sensor – 16. High pressure line between rail and electro injectors – 17. Electro injectors – 18. Return line from electro injectors

Hydraulic system (Common Rail – FIA)

The hydraulic system consists of a low and high–pressure circuit, the former consisting of the following piping:

- connecting high–pressure output to the Rail;
- Common Rail;
- connecting the Rail and supplying electro injectors.

The low–pressure circuit consists of the following piping:

- fuel aspiration from tank to prefilter;
- supplying the pump and prefilter;
- supplying the high–pressure pump via the fuel filter.


The Rail exhaust circuit and the electro injectors complete the supply circuit.

The following are mandatory for safety reasons because of high–pressure levels inside this hydraulic system:

- avoid improper connection of high pressure piping junctions;
- avoid connecting high pressure piping with the engine running (useless and hazardous attempts at purging must be avoided!)

Low–pressure circuit integrity is essential to proper system operation, so mishandling and modifications must be avoided, with immediate action required in case of leaks.

Figure 136





0003340t

1. High pressure pump – 2. High pressure line – 3. Electro injector recirculation line – 4. Electro injectors – 5. Common rail – 6. Over pressure valve – 7. Bypass valve – 8. Filter – 9. Priming pump – 10. Tank – 11. Mechanical supply pump – 12. High pressure pump limiter valve – 13. Pressure regulator

Figure 137

Motor 8040



TECHNICAL VIEWS OF PULLEY AND SENSOR
1. Camshaft pulley – 2. Sensor

SYSTEM COMPONENTS

Camshaft pulley and timing sensor

5 teeth (4 + 1 for timing detection) are machined on the pulley opposite an inductive sensor equal to the one on the flywheel.

5 holes (4 + 1 timing recognition hole) are provided on the FIA engine pulley.

The sensor is of the inductive type and is used by the electronic control unit to detect the engine stroke during synchronisation (when starting).


When assembling the sensor:

ensure the dimension illustrated working on the slots of the bracket and measuring with a thickness gauge

- make sure that the sensor is perpendicular in relation to the wheel tightening the nuts.


Figure 138

Motor FIA



0003320t

TIMING RECOGNITION HOLES



0003321t

1. Camshaft pulley – 2. Sensor

Flywheel and rpm sensor

The flywheel has a set of 58 holes (60 – 2), as illustrated, for generating the signal for the inductive sensor.

It is the same as the one on the camshaft and is positioned on the crankcase and detects the passage of the 58 holes on the flywheel.

The change in the signal caused by the lack of 2 holes (synchronism gap) which takes place at each rotation of the crankshaft is the reference signal that allows the control unit to recognise the advance in relation to the TDC of piston pair 1–4.

This signal is also used by the control unit to detect the engine rotation speed, the duration of injection and to control the rev counter.


When assembling the sensor:

- ensure the dimension illustrated working on the slots of the bracket and measuring with a thickness gauge.
- make sure that the sensor is perpendicular in relation to the wheel tightening the nuts.

The FIA engine crankshaft sensor features a slatted sound wheel on the crankshaft front.

This features 58 (60–2) teeth and the sensor detects their passage.

Figure 139




0003319t

TECHNICAL VIEW OF THE SOUND WHEEL AND SENSOR


1. Sound wheel – 2. Crankshaft sensor

Figure 140




HOLES FOR GENERATING SIGNALS ON THE FLYWHEEL

Figure 141



TECHNICAL VIEW OF FLYWHEEL AND SENSOR
1. Flywheel – 2. Sensor

Figure 142




RPM SENSOR ON CRANKCASE

Figure 143



SENSOR AND CONNECTION CABLE

Figure 144



SENSOR CONNECTOR AND WIRING DIRAGRAM

Flywheel and camshaft sensor specifications

These are inductive sensors.

The flywheel sensor (48035) is connected at pins 29 and 37 of connector A of the control unit.

It is also used to control the electronic rev counter on the instrument cluster.

The timing sensor (48042) is connected at pins 4 and 31 of connector A of the control unit.

The resistance at 20 °C is approx. ~ 860 Ohm.

Pre-filter

This is a simple transparent filter like the one in petrol supply systems.

Replace it only when a sight check reveals traces of impurity.

Electric pump

Rotary volumetric pump with integrated by pass (Figure 145) located outside the fuel tank.

It is on the left-hand side of the frame in an accessible area.

There is no need to bleed the fuel supply system.


The pipes are fitted with quick couplings.

It is connected to pins 7 and 8 of connector A of the control unit.

Specifications

| | |
|---------------------------|----------------|
| Delivery pressure: | 2,5 bar |
| Flow rate: | > 155 litres/h |
| Supply: | 13,5 V – < 5 A |
| Coil resistance at 20 °C: | 28.5 Ohm |

Figure 145



TECHNICAL VIEW AND CROSS SECTION OF ELECTRIC FUEL PUMP

Fuel filter

Cartridge degree of filtering: 5 micron

Differential operating pressure (obstruction indicator): 0.6 bar


The fuel temperature sent by the sensor to the electronic injection control unit allows very accurate calculation of the flow rate of the fuel to be injected in the cylinders.

It is located in a fairly accessible position in the left front part of the engine compartment.

1. Actuated by ECU via relay with fuel temperature below 3°C.
2. Filtering element
3. Shows presence of water through a warning lamp on instrument panel.
4. Differential pressure sensor calibrated at 0,6 bar : any clogging is shown by warning lamp
5. It is a NTC sensor connected to EDC for fuel temperature reading enabling electronic control to calculate the amount of diesel oil to be injected into the cylinders.
6. Installed on filter support for excess fuel return to tank.

Figure 146

Engine 8040




73731

FUEL FILTER

1. Heater – 2. Filtering element – 3. Condensation indicator
– 4. Obstruction indicator – 5. Fuel temperature sensor –
6. Discharge

Figure 147

Engine F1A



003312t

1. Clogged filter sensor – 2. Fuel temperature sensor –
3. Water sensor – 4. Heater

High pressure pump

This pump has three radial pistons (total displacement 0,7 cc) controlled by the timing gear belt, with no need for calibration.

Each impeller unit comprises:

- a piston (5) operated by a cam (2) integral with the pump shaft (6)
- a plate inlet valve (3)
- a ball delivery valve (4)

The delivery pressure to the rail is modulated between 250 and 1350 bar by the electronic control unit, acting on the pressure regulator solenoid valve.


The pump is lubricated and cooled by the fuel itself.

The 3rd impeller cut-off solenoid valve (78015) serves to increase the part of fuel oil that lubricates the radialjet pump, it is used above 4200 rpm (when power is no longer needed) and keeps the intake valve open also when the cylinder is compressing. It sends one third of the capacity of the high pressure pump back to low pressure.

The on-off time is considerably lower than conventional injection pumps.

The control solenoid valve is connected to pins 20 and 21 of connector A of the control unit.

Figure I48



TECHNICAL VIEW AND CROSS SECTION OF HIGH PRESSURE PUMP

1. Cylinder – 2. Cam – 3. Plate inlet valve – 4. Ball delivery valve – 5. Piston – 6. Pump shaft – 7. Low pressure fuel inlet – 8. High pressure fuel delivery – 9. Fuel backflow

High-pressure pump (FIA engine)

This pump is similar to the 8140 engine one.

It differs in Rail line pressure, modulated at between 250 and 1600 bars by the electronic centre by acting on the pressure regulator electro valve and is not provided with a 3rd pump cutout electro valve (78015).

Pump (3) is oriented on the pump shaft cam.


During aspiration the pump is powered via supply conduit (5).

The amount of fuel to be sent to the pump is set by pressure regulator (7).

The pressure regulator stops fuel inflow to the pump based on PWM input from the centre.

During pump compression, fuel reaches a pressure level sufficient to open the pressure valve to common rail (2), and supplies it via output (1).

Figure 149



- 1. Output for rail pressure - 2. Rail pressure valve - 3. Pump - 4. Pump shaft - 5. Pump supply conduit - 6. Pressure regulator supply conduit - 7. Pressure regulator - 8. High pressure pump - 9. Fuel input connection from filter – 10. Fuel output connection to filter support – 11. Fuel input connection from centre heat exchanger – 12. Fuel output connection from mechanical pump to filter – 13. Supply mechanical pump

72595

72597

Pressure regulator

This is located on the high pressure pump and modulates the fuel pressure to the rail (and thus to the injectors) on the basis of the commands received from the electronic control unit.

It mainly comprises:

- a ball shutter (1)
- a valve (3) control pin (2)
- a preloading spring (4)
- a coil (5)


When the solenoid is not energised, the delivery pressure depends only on the spring preload.

When, after processing the various engine operating parameters, the electronic control unit determines the need for a different injection pressure, it modulates a command signal in PWM to the regulator solenoid valve which discharges the excess pressure in the pump backflow duct.

The modulated pressure is checked through the pressure sensor on the rail by the control unit, which, if necessary, suitably modifies the intensity of the command signal to reach the required result.

The control solenoid valve (78013) is connected to pins 9 and 20 of connector A of the control unit.

Figure 150



PRESSURE REGULATOR CROSS SECTION

1. Ball shutter – 2. Ppin – 3. Valve – 4. Preloading spring – 5. Coil – 6. Body – 7. Anchor

Pressure regulator (FIA)

Similar to the one installed on the 8140 engine and mounted on the CP3 pump low-pressure circuit.

When the engine control centre pilots the pressure regulator via the PWM signal, solenoid (1) is activated, which in its turn generates movement of magnetic core (2).


Core movement causes cylinder (3) axial displacement by fuel delivery partialization.

When solenoid (1) is not activated, the magnetic core is moved to its rest position by preload spring (6).


In these conditions, cylinder (3) is in a position to offer maximum fuel passage cross-section.

Control electro valve 78013 is connected to centre connector A pins 9 and 20.


Figure 151



003386t



75574



75575

1. Solenoid - 2. Magnetic core - 3. Cylinder - 4. Fuel input - 5. Fuel output - 6. Preload spring - 7. Connector

Rail (pressure accumulator)

The volume of the rail is small in size (29 cc) to allow quick pressurising when starting, at idle speed and in the event of high loads.


It has however sufficient volume to minimise the plenum effect caused by opening and closing of the injectors and operation of the high pressure pump.

Screwed onto the rail there is a fuel pressure sensor. The signal sent by this sensor to the electronic control unit is feedback information on the basis of which correct actuation of the rail pressure is checked.

Common Rail for engines with serial numbers over 3089322

Temporary solution with simulated flow limiters and over pressure valve connected to the fuel discharge unit.

Figure 152




1. Common Rail – 2. Simulated flow limiter – 3. Simulated over pressure valve seat – 4. Pressure sensor –
5. Fuel input from high-pressure pump

Common Rail for engines produced since end-October 2000

Final Common Rail solution without flow limiters and over pressure valve. The new Common Rail features different pressure sensor layout and discharge unit connection predisposition.

Figure 153



1. Common Rail – 2. To electrical injectors – 3. Pressure sensor – 4. Fuel discharge unit attachment –
5. Fuel input from high-pressure pump

Rail (pressure accumulator – FIA)


The hydraulic accumulator is mounted in the cylinder head on the side opposite aspiration.

Its some 22–cm³ volume dampens fuel pressure oscillations due to:

- high–pressure pump operation
- electro injector opening.

The fuel sensor and overpressure valve are positioned on the hydraulic accumulator.

Figure 154



75576


1. Common rail – 2. To electro injectors – 3. Fuel pressure sensor – 4. Overpressure valve – 5. Fuel input from high pressure pump

Over pressure valve


The over pressure valve protects system components in the event that fuel pressure exceeds rated 1750 bars.

- A The piston’s conical end normally keeps discharge to tank open.
- B In the event of fuel pressure being over 1750 bars in the rail, the piston is relocated and excess pressure is discharged into the tank.

Figure 155




70500



70502


- OVER PRESSURE VALVE**
 1. Body – 2. Piston – 3. Stop – 4. Spring – 5. Direct discharge to tank – 6. Seat on the rail

Figure 156



TECHNICAL VIEW OF COMPONENT AND LIMITER CONNECTOR

Figure 157



PRESSURE LIMITER OPERATING GRAPH

Flow limiters

These are located on the rail fuel outlet and their function is to protect the engine or vehicle in the event of internal leaks (for example, atomiser blocked open) and external leaks (example: high pressure pipe damaged).

Under these circumstances they also allow, within certain limits, the system to work through the components that are still intact.

The passage of fuel from the rail to the injectors takes place through the holes machined on the small diameter of the piston.

Under normal conditions, the fuel pressure is exerted on both sides of the piston, held in the open position by the spring.

In the event of a heavy loss of pressure downstream of the limiter, the inlet pressure becomes preponderant and moves the piston from the opposite side, obstructing the fuel outlet.

Pressure limiter

The pressure limiter (1500 bar) screwed in the rail, serves to protect the system components in the event of a failure to the pressure regulator on the pump.

If the pressure of the fuel in the rail exceeds 1500 bar the piston is raised and the excess pressure is eliminated.

Fuel pressure sensor

This is fitted at the centre of the rail and measures the existing fuel pressure in order to determine the injection pressure.

The injection pressure value is used as feedback for closed loop pressure control and to determine the duration of the electric command for injection.

It is connected to pins 6, 13 and 33 of connector A of the control unit.

It is supplied at 5 Volt.

Injectors

The solenoid valve controls the lift of the atomiser needle.

On the fuel inlet union a filter protects the injector for impurities. The injector is constructively the same as conventional ones, except that there is no needle return spring.

Access to the injectors is gained by releasing the side soundproof cover from the cylinder head. The fuel recovery pipe has a quick coupling.

The injector comprises two parts:

- actuator – atomiser composed of pressure rod (1), pin (2) and nozzle (3)
- control solenoid valve comprising a coil (4) and drive valve (5).

1st phase: rest position

The coil (4) is not activated and the shutter (6) is in the closed position.

The same fuel pressure acts in both the control area (7) and in the pressure chamber (8), but as the shutter (6) is closed, the needle (2) cannot be raised.

2nd phase: start of injection

The coil (4) is energised and causes the shutter (6) to move upwards.

The fuel of the control volume (9) flows towards the backflow duct (10) causing a drop in the pressure in the control area (7).

At the same time, the pressure of the fuel in the pressure chamber (8) causes the needle (2) to rise, resulting in fuel injection to the cylinder.

3rd phase: end of injection

The coil (4) is not activated and makes the shutter (6) return to the closed position, which re-creates a balance of forces that makes the needle (2) return to the closed position and consequently end injection.


Injectors (78247)

The solenoid valve is of the N.C. type.

The injectors are connected individually to the control unit at the following pins:


- A12 / A40 cylinder 1 injector
- A10 / A43 cylinder 2 injector
- A23 / A42 cylinder 3 injector
- A24 / A41 cylinder 4 injector

Figure 158



INJECTOR WIRING DIAGRAM AND CROSS SECTION
 1. Pressure rod – 2. Needle – 3. Nozzle – 4. Coil – 5. Pilot valve – 6. Ball shutter – 7. Control area – 8. Pressure chamber – 9. Control volume – 10. Backflow duct – 11. Control duct – 12. Supply duct – 13. Electrical connection – 14. High pressure fuel inlet – 15. Spring

Figure 159



FUEL OUTLET UNIT

1. Fuel outlet to tank – 2. Return from injectors –
3. Delivery to thermal starter – 4. Leading from high
pressure pump – 5. Arrival from filter

Fuel outlets unit

All the outlets, overpressure and backflows of the various hydraulic components converge in this unit.

Part of them is made available to the thermal starter, while the rest returns to the fuel tank.

In the unit there is a 2,3 mm diameter drain hole.

This hole regulates the whole outlet system to maintain a constant counter pressure of 0,5 bar, which is indispensable for correctly supplying the thermal starter and it ensures flow rates which prevent overheating of the fuel.



The calibrated hole is made in a union similar to the other unions. In the event of work on the system, take care not to fit another different union in its place as this would cause serious operating failures.

Air flow meter

This component incorporates a temperature sensor and a pressure sensor.

It is fitted on the engine intake manifold (Figure 162) and measures the maximum flow rate of the intake air which is used to accurately calculate the amount of fuel to be injected at each cycle.

It is connected to the control unit on pins A2 / A3 / A19 / A34.

- Pin 1 sensor – Pin A19 ECU – earth –
- Pin 2 sensor – Pin A2 ECU – temperature signal
- Pin 3 sensor – Pin A3 ECU – 5V – supply
- Pin 4 sensor – Pin A34 ECU – 0 ÷ 5V pressure signal –


Course of sensor in relation to the temperature:

| Temperature | Resistance |
|-------------|------------|
| - 40 °C | 48.50 kOhm |
| - 20 °C | 15.67 kOhm |
| 0 °C | 5.86 kOhm |
| 20 °C | 2.50 kOhm |
| 40 °C | 1.17 kOhm |
| 60 °C | 0.59 kOhm |
| 80 °C | 0.32 kOhm |
| 100 °C | 0.18 kOhm |
| 120 °C | 0.11 kOhm |

Course of sensor in relation to the pressure:


See graph opposite.

Figure 160



AIR FLOW METER OPERATING GRAPH


Figure 161



AIR FLOW METER

8660


Figure 162



I. Air flow meter location


003323t

Figure 163



AIR FLOW METER CONNECTION


Figure I64



003333t

1. Connector – 2. Gauge body – 3. Air input grid

Figure I65



003334t

TECHNICAL VIEW OF GAUGE CONNECTOR

Air delivery gauge

Used in the EGR version to replace the one mounted on the engine aspiration manifold.

The gauge is of the heated film type and is located on their aspiration conduit between the turbine and the air filter.

The gauge contains the aspired air temperature sensor.

It is connected to the centre on pins **A5 / A17 / A18 / A26 / A28**.

- Pin 1 sensor – Pin A5 ECU – temperature signal
- Pin 2 sensor – Pin A17 ECU – 5V power supply
- Pin 3 sensor – Pin A18 ECU – mass
- Pin 4 sensor – Pin A26 ECU – reference voltage
- Pin 5 sensor – Pin A28 ECU – pressure signal


The operating principle is based on a heated membrane inserted in a measurement canal through which air to the engine flows.

The hot film membrane is kept at a constant temperature some 120 °C above incoming air level by the heating resistor.

The air mass traversing the measurement canal tends to subtract heat from the membrane so current must cross the resistor to maintain constant film temperature.


Current absorbed is proportional to the air mass flowing to the engine and is measured with a Wheatstone bridge and the signal is forwarded to the electronic centre.

Figure 166




COURSE OF SENSOR RESISTANCE IN RELATION TO TEMPERATURE

Figure 167



TECHNICAL VIEW OF ENGINE COOLANT TEMPERATURE SENSOR

Figure 168



NTC

WIRING DIAGRAM

Atmospheric pressure sensor

This is integrated inside the control unit.

It measures the atmospheric pressure to correct the flow rate in relation to the altitude.

Engine coolant temperature sensor

This is an NTC sensor located on the thermostat box.

It detects the temperature of the coolant fluid to give the control unit information about the engine temperature conditions.

It is connected to pins 1 and 30 of connector A of the control unit.

Course of the sensor in relation to the temperature:

| Temperature | Resistance |
|-------------|------------|
| - 40°C | 48.30 kOhm |
| - 20°C | 15.46 kOhm |
| 0°C | 5.89 kOhm |
| 20°C | 2.50 kOhm |
| 40°C | 1.17 kOhm |
| 60°C | 0.59 kOhm |
| 80°C | 0.32 kOhm |
| 100°C | 0.19 kOhm |
| 120°C | 0.11 kOhm |

Fuel temperature sensor


This is an NTC sensor located on the fuel filter.

It detects the temperature of the fuel to give the control unit information about the fuel oil temperature conditions.

It is connected to pins 15 and 30 of connector A of the control unit.

It is exactly the same as the engine coolant temperature sensor.

Figure 169



003324t

LOCATION OF FIA ENGINE COOLANT TEMPERATURE SENSOR
1. EDC – 2. Signal instrument panel

The accelerator pedal position sensor is of the potentiometric type with incorporated N.O. minimum switch.


It gives the electronic control unit a value proportionate with the operating angle of the pedal itself determining fuel delivery.

It is supplied at 5 Volt.

The potentiometer resistance is approx. ~ 1 kOhm.


It is connected at pins 2, 13, 27, 29 and 35 of connector B of the control unit.

Figure 170




LOCATION OF SENSOR ON ACCELERATOR PEDAL

Figure 171



SENSOR WIRING DIAGRAM


Figure 172



003326t

I. Brake pedal switches

Figure 173



003327t

I. Clutch pedal switch

Brake pedal switches

Two switches are located on the brake pedal; N.C. 53565 si connected directly to electronic centre pin B31 and 53501 is connected to the centre via remote switch 25006 for stop light actuation and to generate a redundant signal on the centre increasing system reliability degree.

Clutch pedal switch

An N.C. switch connected to electronic centre pin B38 is mounted on the clutch pedal.

The "clutch pedal actuated signal" is used by the centre to identify gear condition selected and gear shifts.

In absence of the pedal pressed switch signal, the centre disengages the Cruise Control function.

Electromagnetic junction fan

The fan is provided with an electromagnetic junction monitored by the electronic centre pin A39 that activated the junction remote control switch, to optimise water cooling.

The electrical fan remote control switch is activated or deactivated by the centre according to the temperature of:

- the coolant
- over supply air
- the fuel

Engine coolant temperature

Activated at over 96 °C and deactivated at under 84 °C


Over supply air temperature

Activated at over 75 °C and deactivated at under 65 °C

Fuel temperature

Activated at over 20 °C and deactivated at under 10 °C

Figure 174



ELECTROMAGNETIC JUNCTION TECHNICAL VIEW0 (F1A)
1. Coil

003328t

Preheat plug electronic centre (FIA/FIC engine)

EDC central unit effects the timing of the functioning of glow plugs pre-heating central unit depending on engine temperature, which, in turn, activates the glow plugs.

The preheat centre contains an "intelligent" remote control switch that sends a feed-back to the control centre for information on any preheat centre defect or plug earth short circuit.

Preheat centre pin-out

- 31 – Mass
- 86 – Start switch (+15)
- ST – EDC electronic centre (pin B42)
- DI – EDC electronic centre (pin B37)
- 30 – Battery positive (+30)
- G1 – Preheat plugs
- G2 – Preheat plugs
- G3 – Preheat plugs
- G4 – Preheat plugs


Preheat plugs

CONTROL VALUES

With constant di 11V power supply:

- maximum current absorbed 18 A
- in 5" $11 \pm 1,5$ A
- in 30" $6 \pm 0,9$ A
- temperature after 7" 850°C
- torque 8–10 Nm


Figure 175



003332t

PREHEAT CENTRE


Figure 176



003331t

ELECTRICAL DIAGRM

Figure 177



75579

PREHEAT PLUS

EDC MS6.3 / EDC I6

Electronic injection control

The system calculates injection on the basis of the processing of the following parameters:

- Engine rpm
- Engine coolant fluid temperature
- Intake air capacity
- Battery voltage
- Fuel pressure
- Accelerator pedal position

Fuel pressure ranges from 400 to 1350 bars (1600 for FI engines), according to engine rpm and load operating conditions.

The lower pressure is compensated by longer injection times and vice versa, always taking account of the loads required.

Up to 2800 rpm pre-injection is also carried out in order to reduce the typical noise of direct injection.

Pre-injection advance angles, the distance between pre-injection and main injection and advance angles of main injection vary according to the instantaneous engine operating conditions.

System diagnosis is performed by means of diagnostic instruments (no Blink Code is used).

Immobilizer recognition

When the control unit receives the signal of the key on "MAR" it communicates with the immobilizer control unit to enable starting.

Checking fuel temperature

With the fuel temperature greater than 75°C, detected by the sensor on the fuel filter, the control unit operates the pressure regulator to decrease the line pressure (injection times are not changed). If the temperature exceeds 90°C, the power is reduced to 60%.

Checking engine coolant temperature

The control unit, depending on the temperature:

- of the engine coolant, turbocharging air and fuel, operates the electromagnetic fan (Baruffaldi) and switches on the coolant temperature warning light.

Checking quantity of fuel injected

According to the signals from the sensors and the mapped values, the control unit:

- operates the pressure regulator;
- varies the "pilot" injection time to 2200 rpm;
- varies the "main" injection time.
- Checking idling adjustment

The control unit processes the signals from the various sensors and regulates the amount of fuel injected:

- it operates the pressure regulator;
- it varies the injection times of the electro-injectors.

Within certain thresholds the speed takes account of the battery voltage.

Fuel cut-off in release phase

In the phase of releasing the throttle pedal the control unit actuates the following logic elements:

- it cuts off supply to the electro-injectors;
- it partially reactivates supply to the electro-injectors before reaching idling speed;
- it operates the fuel pressure regulator.

Checking cylinder balancing on idling

According to the signals received from the sensors, the control unit controls the regularity of the torque at idling speed:

- it varies the amount of fuel injected into the single electro-injectors (injection time).

Checking regular engine rotation (anti-sawing)

It ensures regular engine rotation at a constant rate while increasing revs.

The control unit processes the signals received from the sensors and determines the amount of fuel to be injected via:

- the pressure regulator;
- the electro-injector opening time.

Checking smokiness at exhaust on acceleration

With heavy acceleration, on the basis of the signals received from the air introduction meter and engine speed sensor, the control unit determines the optimum amount of fuel to inject:

- it operates the pressure regulator;
- it varies the electro-injector injection time.

Checking exhaust gas recirculation (E.G.R. if present)

Depending on the engine load and the signal from the accelerator pedal sensor, the control unit limits the amount of air taken in, actuating partial suction of the exhaust gases.

Checking top speed limit

Depending on the number of revs, the control unit actuates two action strategies:

- at 4250 rpm it cuts off the fuel, decreasing the electro-injector opening time. Over 5000 rpm it deactivates the electro-injectors.

Checking regular rotation on acceleration

Regular progression is assured in all conditions by the control of the pressure regulator and the electro-injector opening time.

Preheat plug centre control (FI Engine)

During:

- the start step
- the after start step

the injection centre times the heater starter (or preheat plugs for the FI Engine) according to engine temperature.

Checking activation of air-conditioning system

The control unit operates the air-conditioning compressor:

- switching it on/off when the relative switch is pressed;
- momentarily turning it off (approximately 6 sec.) if the engine coolant reaches the set temperature.

Checking fuel pump

Irrespective of the speed, the control unit:

- supplies the auxiliary fuel pump with the key on MAR;
- cuts off auxiliary pump supply if the engine is not started up within a few seconds.

Checking diesel warming

It times operation of diesel warming in relation to ambient temperature.

Checking cylinder position

During each turn of the engine, the control unit recognizes which cylinder is in the power stroke and operates the injection sequence for the appropriate cylinder.

Checking pilot and main injection timing

According to the signals from the various sensors, including the absolute pressure sensor built into the control unit, the control unit determines the optimum point of injection according to internal mapping.

Checking injection pressure closed cycle

Depending on the engine load, determined by processing the signals from the various sensors, the control unit operates the regulator to obtain optimum line pressure.

Fuel supply

The fuel supply is calculated in relation to:

- accelerator pedal position
- engine speed
- quantity of air introduced.

The outcome may be corrected in relation to:

- the water temperature.

Or to avoid:

- noise
- smoke
- overloading
- overheating
- turbine over-rewinding.

The delivery can be modified in the case of:

- action of external devices (ABS), ABD, EDB
- serious trouble decreasing the load or stopping the engine.

After determining the mass of air introduced by measuring its volume and temperature, the control unit calculates the corresponding mass of fuel to inject into the relevant cylinder (mg per delivery) also taking into account the temperature of the diesel.

The mass of fuel calculated in this way is first converted into volume (mm³ per delivery) and then into degrees of throw, or duration of injection.

Correcting flow rate according to water temperature

A cold engine meets with greater resistance during operation: friction is high, the oil is still very viscous, and the various clearances are not yet optimized.

In addition, the injected fuel tends to condense on the metal surfaces that are still cold.

The fuel supply for a cold engine is therefore greater than for a warm one.

Correcting flow rate to avoid noise, smoke or overloading

The behaviour that could lead to this kind of trouble is well known.

The designer has therefore included special instructions in the control unit to avoid it.

De-rating

In the event of the engine overheating, injection is modified, decreasing the delivery to a varying degree, in proportion to the temperature reached by the coolant.

Turbine rpm setting (.15 – .17) (for the variable geometry turbo-compressor)

By changing its geometry, adjusted turbine speed is monitored by the electronic centre via an electrical signal feeding the compressed air actuator electro valve. Based on signals from the accelerator pedal position and suction manifold air temperature/pressure engine rpm sensors, the electronic centre processes the field-back signal to properly modulate turbine actuator pilot electro valve opening.

Injection timing electronic test

The advance (start of delivery, expressed in degrees) may be different from one injection to the next, also differentiated from one cylinder to another. It is calculated, similarly to the delivery, in relation to the engine load (accelerator position, engine speed and air introduced).

The advance is appropriately corrected:

- in phases of acceleration;
- according to the water temperature.

And also to obtain:

- lower emissions, noise and overloading;
- better vehicle acceleration.

An extremely high advance is set on starting, depending on the water temperature.

Feedback from the start of delivery is supplied by the change in impedance of the injector solenoid valve.

Speed governor

The electronic speed governor has both features of governors:

- idling and top speed
- all speeds

It is stable in ranges where conventional, mechanical governors are imprecise.

Engine starting

During the first few turns of the engine, the timing and cylinder no. 1 recognition signals (flywheel sensor and camshaft sensor) are synchronized.

The accelerator pedal signal is ignored on starting. Starting delivery is set only according to water temperature, by a special map.

When the control unit detects such speed and acceleration of the flywheel as to be able to consider the engine started up and no longer driven by the starter motor, it re-enables the accelerator pedal.

Cold starting

If even just one of the three temperature sensors (water, air or diesel) records a temperature lower than 10°C, pre-post heating is activated.

On inserting the key contact, the pre-heating indicator goes on and remains on for a period varying depending on temperature (air is heated by the pre-heating glow plugs that are located on cylinder head for FI engines), then it blinks. Thereafter, the engine can be started up.

When the motor is running this indicator light goes out, while the glow plugs continue to be powered for a certain length of time (variable) for post-heating.

If, with the indicator light flashing, the engine is not started up within 20–25 seconds (inattention time), the operation is cancelled so as not to run down the batteries pointlessly. The pre-heating curve is also variable in relation to the battery voltage.

Warm starting

If the reference temperatures all exceed 10°C, when the key makes contact the indicator light comes on for approximately 2 sec., for a short test, and then goes out. It is now possible to start up the engine.

Run up

When the key makes contact, the control unit transfers the information stored in memory when the engine was last stopped into the main memory (see After Run) and makes a diagnosis of the system.

After run

Whenever the engine is switched off with the key, the control unit stays powered for a few seconds by the main relay.

This makes it possible for the microprocessor to transfer some data from the main memory (volatile) to a non-volatile memory, which can be erased and written over (EEPROM), so as to make it available at the next start up (see Run Up).

These data basically consist of:

- various settings (engine idling adjustment, etc.);
- settings of some components;
- fault memory.

The process lasts a few seconds, typically from 2 to 7 (depending on the amount of data to save), after which the ECU sends a command to the main relay and makes it disconnect from the battery.



It is extremely important for this procedure not to be broken off, for example by switching off the engine with the battery cut-out, or by disconnecting the battery cut-out before 10 seconds have passed since switching off the engine.

If this happens, the functioning of the system is ensured, but repeated interruptions may damage the control unit.

Cut – off

This function cuts off fuel delivery when the vehicle is decelerating (accelerator pedal released).

Cylinder balancing

Individual cylinder balancing contributes to increasing comfort and handling.

This function permits individual, customized control over the delivery of fuel and the start of delivery for each cylinder, even differently from one cylinder to another, to compensate for the hydraulic tolerances of the injector.

The differences in flow (delivery specifications) between the various injectors cannot be evaluated directly by the control unit. This information is supplied by Modus reading the bar code of each injector at the time of assembly.

Synchronisation search

If there is no signal from the camshaft sensor, the control unit is anyhow able to recognize the cylinders into which the fuel is to be injected.


If this occurs when the engine is already running, the combustion sequence has already been acquired, so the control unit continues with the sequence on which it has already been synchronized.

If this occurs when the machine is at a standstill, the control unit energizes a single solenoid valve. Within at most 2 turns of the crankshaft, injection will take place in that cylinder, so the control unit just needs to get synchronized on the firing sequence and to start up the engine.

Bosch MS6.3 control unit

Figure 178

85150




7420

PERSPECTIVE VIEW

A. Housing for injection cable connector – B. Seat for cabin-bonnet cable (UNIJET motor drive)

Figure 179




7406

LOCATION ON THE VEHICLE

Control unit connection to the injection cable on engine side (housing A)

Figure 180




VIEW OF BOSCH 43-WAY CONNECTOR FROM CABLE INPUT SIDE

7421

| Pin | Function | Cable colour code |
|-----|--|-------------------|
| 1 | To engine coolant temperature sensor | 5154 |
| 2 | To turbo-blower air pressure and temperature sensor for EDC (without EGR) | 5151 |
| 3 | To turbo-blower air pressure and temperature sensor for EDC (without EGR) | 5153 |
| 4 | To engine rpm sensor on camshaft (cams) | White |
| 5 | To temperature sensor and ambient air pressure for EDC (with EGR) | 5151 |
| 6 | Fuel pressure adjustment sensor earth | 0000 |
| 7 | Control to relay for switching on fuel pump | 8150 |
| 8 | Common EDC centre mass – Centre monitored remote control switches – EGR electro valve | 0000 |
| 9 | To solenoid valve for pressure adjustment | 9925 |
| 10 | To solenoid valve for electronic injection (injector 2 – cylinder 3) | — |
| 11 | Spare | — |
| 12 | To solenoid valve for electronic injection (injector 1 – cylinder 1) | — |
| 13 | To solenoid valve for pressure adjustment | 5590 |
| 14 | Spare | — |
| 15 | Sensor (fuel temperature) for switching on fuel warming | 5592 |
| 16 | Spare | — |
| 17 | To ambient air temperature and pressure sensor for EDC (with EGR) | 8150 |
| 18 | To ambient air temperature and pressure sensor for EDC (with EGR) | 8151 |
| 19 | Air temperature and pressure sensor earth (without EGR) | 0165 |
| 20 | Earth shared by control unit and radialjet and pressure solenoid valves (no radialjet for FIA) | 0000 |
| 21 | To solenoid valve for radialjet pump control (not for FIA) | 9917 |
| 22 | Spare | — |
| 23 | To solenoid valve for electronic injection (injector 3 – cylinder 4) | — |
| 24 | To solenoid valve for electronic injection (injector 4 – cylinder 2) | — |
| 25 | To solenoid valve controlling anti-pollution system (EGR) (.13 – FIA) | 5577 |
| 26 | To ambient air temperature and pressure sensor for EDC (with EGR) | 8152 |
| 27 | To speed limiter adjustment sensor | 8847 |
| 28 | To ambient air temperature and pressure sensor for EDC (with EGR) | 8153 |
| 29 | To sensor for engine rpm | White |
| 30 | Earth shared by control unit and temperature sensors | 0150 |
| 31 | To engine rpm sensor on camshaft (cams) | Black |
| 32 | Control to relay for heated fuel oil filter | 8159 |
| 33 | To sensor for fuel pressure adjustment | 5591 |
| 34 | To turbo-blower air pressure and temperature sensor for EDC (without EGR) | 5152 |
| 35 | Control to relay for engaging conditioner compressor | 9990 |
| 36 | To solenoid valve actuator for VGT (.15) or to WASTE GATE solenoid valve (.13) | 5000 |
| 37 | To engine rpm sensor (.13 – .15 – FIA) | Black |
| 38 | Spare | — |
| 39 | Control to relay for engine cooling joint | 7740 |
| 40 | To solenoid valve for electronic injection (injector 1 – cylinder 1) | — |
| 41 | To solenoid valve for electronic injection (injector 4 – cylinder 2) | — |
| 42 | To solenoid valve for electronic injection (injector 3 – cylinder 4) | — |
| 43 | To solenoid valve for electronic injection (injector 2 – cylinder 3) | — |

Control unit connection to cab-bonnet cable (housing B)

Figure 181



VIEW OF BOSCH 43-WAY CONNECTOR FROM CABLE INPUT SIDE


7422

| Pin | Function | Cable colour code |
|-----|---|-------------------|
| 1 | To cruise Control | 8156 |
| 2 | To load sensor on accelerator for EDC | 5157 |
| 3 | Spare | — |
| 4 | To instrument panel module A1 rpm indicator repeater | 5155 |
| 5 | Spare | — |
| 6 | Compressor engaged signal to EDC | 8162 |
| 7 | To diagnostic socket | 2299 |
| 8 | To alarm control unit | Green |
| 9 | EDC control unit supply | 8150 |
| 10 | EDC control unit supply | 8150 |
| 11 | Control to relay for connection with fuel tank for thermal starter (not for FIA) | 0000 |
| 12 | To earth signal (battery negative) | 0000 |
| 13 | To load sensor on accelerator for EDC | 5156 |
| 14 | Instrument panel module A20 rpm indicator repeater mass | 0000 |
| 15 | Spare | — |
| 16 | To instrument panel module A17 rpm signal | 5614 |
| 17 | Spare | — |
| 18 | Spare | — |
| 19 | To diagnostic socket | 1199 |
| 20 | To key-operated fuse 2 | 8051 |
| 21 | To instrument panel module A1 A30 engine preheat warning leds | 0000 |
| 22 | EDC control unit supply | 8150 |
| 23 | To instrument panel module A1 EDC A29 defect warning leds | 5156 |
| 24 | To earth signal (battery negative) | 0000 |
| 25 | To Cruise Control | 8155 |
| 26 | Supply with stop lights on | 8153 |
| 27 | To load sensor on accelerator for EDC | 0150 |
| 28 | To diagnostic socket | 9932 |
| 29 | To load sensor on accelerator for EDC | 0159 |
| 30 | Spare | — |
| 31 | Supply when brake pedal is pressed | 8158 |
| 32 | To cruise Control | 8154 |
| 33 | To cruise Control | 8157 |
| 34 | Spare | — |
| 35 | To load sensor on accelerator for EDC | 5158 |
| 36 | Spare | — |
| 37 | FIA preheat centre control | 1310 |
| 38 | To clutch pressed signal relay for EDC | 0160 |
| 39 | To alarm control unit | White |
| 40 | Control to relay for EDC engagement | 8150 |
| 41 | EDC control unit supply | 8150 |
| 42 | Heater starter insertion remote control switch control/FIA preheat centre control | 0000 / 1311 |
| 43 | To earth signal (battery negative) | 0000 |

EDC system components

| Ref. | Component code | Description |
|------|------------------------|--|
| 1 | 58918 | Instrument panel tachometer |
| 2 | 58918 | Instrument panel rev counter |
| 3 | 42374 | Clutch pedal switch |
| 4 | 53565 | Brake pedal switch |
| 5 | 85152 | Idling switch and accelerator pedal position sensor |
| 6 | 47106 | Fuel temperature sensor (FIA engine) |
| 7 | 47106 | Fuel temperature sensor Fuel filter clogging sensor (8140 engine) |
| 8 | 85157 | Fuel pressure sensor (FIA engine) |
| 9 | 85157 | Fuel pressure sensor (8140 engine) |
| 10 | 47035 | Coolant temperature sensor |
| 11 | 85156 | Air delivery sensor |
| 12 | 48042 | Distribution sensor |
| 13 | 48035 | Crankshaft sensor (FIA engine) |
| 14 | 48035 | Flywheel sensor (8140 engine) |
| 15 | 78247 | Electro injectors |
| 16 | 19005 | Hot starter |
| | 78000 | Hot starter electro valve (8140 engine) |
| 17 | 25231 | Plug preheat centre (FIA engine) |
| 18 | 19010 | Preheat plug (FIA engine) |
| 19 | 85151 | Fuel electro pump |
| 20 | 78015 | 3rd pump cutout electro valve (8140 engine) |
| 21 | 78013 | Pressure regulator (8140 engine) |
| 22 | 78013 | Pressure regulator (8140 engine) |
| 23 | 12012 | AC compressor |
| 24 | 78209 | EGR modulating electro valve |
| 25 | 85159 | Air delivery sensor |
| 26 | 58701 | EDC warning light |
| 27 | 58702 | Preheat warning light |
| 28 | 54032 | Cruise Control/PTO controls |
| 29 | 85130 | Start key with Immobilizer |
| 30 | 72027 | Diagnosis connection |
| 31 | 78248 | VGT control electro valve (for 8140.43N engine) |
| 32 | 85022 | Fan electromagnetic connection |
| (*) | On version without EGR | |
| (**) | On version with EGR | |
| ■ | Only on 8140 engines | |
| ● | Only on FIA engines | |

Figure 182



77024

Blink Code (up to chassis no. 5383302/ DI87233)

With the ignition switch off, press the diagnostic button.

Two series of blinks of the EDC warning light, at intervals with a brief pause, will indicate the code of the first error memorised.

Press the button again to move to the next error.

Each time the last error is reached, the first one will be repeated.

The list of the errors contains all the errors memorised and not only the active ones.

The order in which the errors are shown is the one in which they occurred.

To remove the error list from the memory, proceed as follows:

- With the ignition key off, press the diagnostic button
- keeping the button pressed, switch the ignition on
- keep the button pressed for 5 seconds
- release the button
- Switch the ignition off.

The error codes are given in the following table.

Common Rail 8140.43B – 8140.43S – 8140.43N – EDC MS6.3

(Software version 5.5)

| Blink-Code | Warning light EDC | Warning light | Reduction level (*) |
|-----------------|-------------------|---|---------------------|
| VEHICLE | | | |
| 1.1 | on | Vehicle speed | |
| 1.3 | off | Cruise Control | |
| 1.4 | flashing | Accelerator pedal | X |
| 1.5 | off | Clutch switch | |
| 1.6 | on | Brake switch | |
| 1.7 | off | Brake/accelerator plausibility | Idling setting |
| 1.8 | off | Diagnostic warning light / Main EDC warning | |
| 1.9 | off | Conditioner control relay | |
| ENGINE 1 | | | |
| 2.1 | flashing | H ₂ O temperature sensor | X |
| 2.2 | off | Air temperature sensor | |
| 2.3 | on | Fuel oil temperature sensor | |
| 2.4 | flashing | Boosting pressure sensor | X |
| 2.5 | off | Atmospheric pressure sensor | |
| 2.7 | flashing | Fuel pump | |
| 2.8 | off | Fuel filter heater control relay | |
| 2.9 | on | Fan control relay | |
| ENGINE 2 | | | |
| 3.1 | flashing | Cylinder 1 balancing | |
| 3.2 | flashing | Cylinder 2 balancing | |
| 3.3 | flashing | Cylinder 3 balancing | |
| 3.4 | flashing | Cylinder 4 balancing | |
| 3.5 | off | Battery voltage | |
| 3.6 | off | Thermal starter warning light | |
| 3.7 | off | Thermal starter | |
| 3.8 | off | Thermal starter solenod valve | |
| 3.9 | off | Preheat monitoring | |
| TURBINE | | | |
| 4.4 | flashing | VGT monitoring | |
| 4.5 | on | VGT electro valve | |

| Blink-Code | Warning light EDC | Warning light | Reduction level (*) |
|--------------------------|-------------------|--|---------------------|
| INJECTORS | | | |
| 5.1 | flashing | Cylinder injector 1 | |
| 5.2 | flashing | Cylinder injector 2 | |
| 5.3 | flashing | Cylinder injector 3 | |
| 5.4 | flashing | Cylinder injector 4 | |
| 5.7 | on | Bearing 1 (cylinders 1-4) | |
| 5.8 | on | Bearing 2 (cylinders 2-3) | |
| ENGINE RPM | | | |
| 6.1 | flashing | Engine rpm sensor | X |
| 6.2 | flashing | Camshaft revolution sensor | X |
| 6.4 | flashing | Over-revving | |
| INTERFACE | | | |
| 7.1 | off | PWM signal | |
| 7.2 | off | CAN bus inactive | |
| 7.3 | off | CAN bus control | |
| 7.4 | off | CAN message control | |
| FUEL PRESSURE/EGR | | | |
| 8.1 | flashing | Fuel pressure control | X or Engine cutout |
| 8.2 | flashing | Fuel pressure sensor | X |
| 8.3 | flashing | Pressure regulator | |
| 8.4 | off | 3 rd impeller cut-off solenoid valve | |
| 8.5 | on | EGR control | |
| 8.6 | on | EGR valve | |
| 8.7 | on | Debit meter | X |
| 8.8 | off | EGR atmospheric pressure sensor | |
| CENTER | | | |
| 9.1 | flashing | Control unit error | X or Engine cutout |
| 9.2 | on | Control unit EEPROM fault | |
| 9.3 | flashing | Immobiliser – EDC communication | |
| 9.4 | on | Main relay | |
| 9.5 | off | After run Test | |
| 9.6 | flashing | Engine stop test (ECU) Engine stop test (ECU) | |
| 9.7 | flashing | Sensor supply | X or Engine cutout |
| 9.8 | flashing | Control unit error | Start impossible |
| 9.9 | flashing | ECU operating system | Engine cutout |

FIA Common Rail

Differs for the following codes:

| | | | |
|-----|-----|-----------------------|--|
| 3.6 | off | Preheat warning light | |
| 3.7 | off | Preheat plug centre | |
| 3.8 | off | Preheat plug centre | |
| 3.9 | off | Preheat monitoring | |
| 8.4 | off | (Not used) | |

EDC16

The EDC.16 control unit offers a few innovations compared to the control unit used with system EDC MS6.3.

- latest-generation hardware and software;
- possibility of processing a greater number of signals (both input and output);
- preset for the control of new additional functions and devices, which will be adopted later for technological improvement of the product range or compliance with forthcoming anti-pollution rules.

The variants compared with the MS6.3 system are as follows:

- new sensor on the accelerator pedal;
- new sensor on the distributing shaft (phase);
- engine cable;
- bonnet/cab cable;
- new connectors for control unit connection.


The EDC.16 system replaces the MS6.3 system on engines F1A (.10 – .12). It is present on F1C engines.

Diagnosis is only performed by using the diagnostic instruments available. No Blink Code is provided.

The other features are the same as the 6.3 system.

Bosch EDC16 control unit

Figure 183




85711

PERSPECTIVE VIEW

A. Engine side injection cable connector – K. Bonnet/cab cable connector

Figure 184




7373

LOCATION ON THE VEHICLE

Control unit connection to the injection cable on engine side (housing A)

Figure 185



85708


85710

| Pin | Cable colour code | Function |
|-----|-------------------|--|
| 1 | 0000 | Cylinder injector 3 |
| 2 | 0000 | Cylinder injector 2 |
| 8 | 0000 | Rail pressure sensor negative |
| 11 | 0174 | Distributing shaft sensor negative (phase) |
| 12 | red | Drive shaft sensor |
| 13 | 5153* | Boosting air pressure and temperature sensor power supply |
| 16 | 9924 | Cylinder injector 1 |
| 17 | 9924 | Cylinder injector 4 |
| 19 | 0000 | Pressure regulator negative |
| 20 | 7158 | Distributing shaft sensor positive |
| 21 | – | Drive shaft sensor braided wire |
| 23 | 0165* | Boosting air pressure and temperature sensor negative |
| 27 | white | Drive shaft sensor |
| 28 | 5591 | Rail sensor power supply |
| 29 | 8152 | Air flow meter power supply (available with EGR) |
| 31 | 9924 | Cylinder injector 2 |
| 33 | 0000 | Cylinder injector 4 |
| 37 | 5151 | Air flow meter air temperature signal (available with EGR) |
| 40 | 5152* | Boosting air pressure sensor signal |
| 41 | 0150 | Water temperature sensor negative |
| 42 | 8153 | Air flow meter signal |
| 43 | 5591 | Rail pressure signal |
| 44 | 8151 | Air flow meter negative (available with EGR) |
| 46 | 9924 | Cylinder injector 3 |
| 47 | 0000 | Cylinder injector 1 |
| 49 | 9925 | Pressure regulator |
| 50 | 9160 | Distributing shaft sensor signal (phase) |
| 51 | 0150 | Fuel temperature sensor negative |

| Pin | Cable colour code | Function |
|-----------|--|--|
| 52 | 5592 | Fuel temperature sensor signal |
| 53 | 5151* | Boosting air temperature sensor signal |
| 58 | 5154 | Water temperature sensor signal |
| 60 | 8150 | EGR solenoid valve |
| ● | Power seats | |
| ○ | Signal seats | |
| (*) | Available when the EGR is not provided | |
| – | Pins not highlighted are not used | |

Control unit connection to cab–bonnet cable (housing K)

Figure 186



85708

85709

| Pin | Cable colour code | Function |
|-----|-------------------|--|
| 1 | – | +30 (main relay) |
| 2 | 0000 | Earth |
| 4 | 0000 | Earth |
| 5 | 8150 | +30 (main relay) |
| 6 | 0000 | Earth |
| 8 | 0150 | Accelerator pedal sensor negative (pin 5) |
| 9 | 5157 | Accelerator pedal sensor signal (pin 4) |
| 13 | – | Signal from power takeoff (if any) state selector |
| 16 | – | Negative from power takeoff (if any) state selector |
| 17 | – | Signal from brake pedal pressed for stop light ignition |
| 25 | 2299 | K line |
| 28 | 8051 | +15 |
| 30 | 0159 | Accelerator pedal sensor negative (pin 3) |
| 31 | 5157 | Accelerator pedal sensor signal (pin 6) |
| 38 | 8155 | Cruise Control (resume) |
| 42 | – | Speed limiter button |
| 45 | 5158 | Accelerator pedal sensor power supply (pin 2) |
| 46 | 5158 | Accelerator pedal sensor power supply (pin 1) |
| 48 | 5614 | Engine speed sensor (revs counter) |
| 52 | 1310 | To preheating spark plug actuation remote–control switch pin D1 |
| 54 | 8162 | Signal from air–conditioning ON compressor remote–control switch |
| 56 | 8157 | Cruise Control (set +) |
| 57 | – | Auxiliary speed limiter (where available) |
| 58 | – | Signal from clutch switch |
| 61 | – | CAN L line |
| 62 | – | CAN H line |
| 68 | 8150 | Fuel filter heating remote–control switch positive |

| Pin | Cable colour code | Function |
|-----|-----------------------------------|---|
| 70 | 9990 | Positive to the remote-control switch for engine water recirculation shut-off solenoid valve control with auxiliary heater ON |
| 71 | 5156 | EDC warning light negative |
| 72 | 8150 | Main relay (negative) |
| 75 | 5155 | Vehicle speed signal (tachometer) |
| 77 | 8154 | Cruise Control (off) |
| 78 | 8156 | Cruise Control (set -) |
| 80 | 8158 | Brake pedal signal |
| 90 | 7740 | Positive for engine cooling electromagnetic joint control |
| 91 | - | Fuel electric pump remote-control switch negative |
| 92 | 0000 | Pre-heating warning light negative |
| 93 | 1311 | To pre-heating spark plug actuation remote-control switch pin ST |
| - | Pins not highlighted are not used | |


Accelerator pedal sensor

A new sensor which incorporates two potentiometers (no idling switch is provided) is available on the accelerator pedal. The ratio between the signals from the two potentiometers is 2:1 (one potentiometer exhibits a twofold resistance value compared with the other). Both of these signals (V) are detected by the control unit that processes them according to stored threshold values and manages the


injection system as an accelerator pedal position set by the driver. (At the output of these potentiometers, a variable voltage is available which corresponds to the potentiometer resistance value.)

It is connected to the EDC control unit connector K pins 9–30–45–31–8–46. The potentiometers are powered with 5 V voltage supplied by the control unit itself.

Figure 187




EDC MS6.3



EDC 16

85714


Figure 188



0003320t

I. Phase identification holes


Figure 189




0003321t

I. Distributing shaft pulley – 2. Sensor

Figure 190



85712



85713

PERSPECTIVE VIEW

I. Power supply positive – 2. Signal output – 3. Earth

Camshaft sensor (FIA)

A semiconductor layer, immersed in a magnetic field and through which current flows, generates a potential difference (called Hall voltage) at its ends.

If current intensity remains constant, the generated voltage depends only on the magnetic field strength: periodical variation of field strength is enough to obtain a modulated electric signal.

The smooth portion of the phonic wheel (distributing shaft pulley) covers, while moving, the sensor, thus blocking the magnetic field with resulting low output signal.

On the contrary, the sensor generates a high signal next to the openings and when a magnetic field is available.


Phase sensor signals are acquired, and the engine position is recognized according to the sequence of the phonic wheel notches.

The mounting function makes it possible to identify signal errors and interferences (if any).

The resulting signal is supplied to the processor that controls the injection system.


Injection cable FIA (.10 - .12)

Figure 191



Injection cable FIA (.14)

Figure 191/1




101882

| Component code | Description |
|----------------|------------------------------------|
| 1 | Connection to hood cab cable |
| 19010 | Preheat plug |
| 25231 | Plug insert centre |
| 47035 | Coolant temperature sensor |
| 47106 | Fuel heat on switch |
| 48035 | Engine rpm sensor |
| 48042 | rpm sensor on distributor |
| 61101 | Fuel heat resistor |
| 70064 | 1-way fuse holder |
| 78013 | Pressure adjustment electro valve |
| 78247 | Electrical injection electro valve |
| 85150 | EDC center |
| 85157 | Fuel pressure sensor |
| 85156 | EDC blower air pressure sensor |

Joint connector

Connection between cab/bonnet cable and injection cable (Unijet)

Figure 192



| Ref. | Ref. (FIA) | Ref. (FIA EDCI6) | Cable colour code | Function |
|------|------------|------------------|-------------------|---|
| I 1 | | | 5000 | To pin 36 of EDC electronic control unit |
| I 2 | 3 | | 8150 | Fuel pump engagement relay |
| I 3 | 4 | | 7740 | Relay engagement for engine cooling electromagnetic joint control |
| I 4 | 5 | | 9990 | Air conditioning compressor switching off |
| I 5 | 6 | | 8159 | Fuel oil heating circuit switching on |
| I 6 | 8 | | 0000 | Earth |
| I 7 | 1 | 1 | 5577 | Fuel oil heating resistance supply |
| I 8 | 16 | 8 | 0077 | Fuel oil heating resistance earth |
| I 10 | 2 | | 8150 | Preheat plug centre positive (pin-86) |
| I 11 | 4 | | 1310 | Preheat plug centre control (pin-D1), (EDC pin-B37) |
| I 12 | 5 | | 1311 | Preheat plug centre control (pin-ST), (EDC pin-B42) |
| I 13 | 6 | | 0000 | Preheat plug centre mass (pin-31) |
| I 2 | | | 8847 | Speed adjustment sensor positive |
| I 7 | | | - | Free |
| I 9 | | | - | Free |
| I 14 | | | - | Free |
| I 15 | | | - | Free |
| | | 3 | 8150 | Positive after key for air flow meter |

Diagnostic connector


Near the positive terminal of the battery there is a diagnostic connector. It is fastened by 2 screws to a special bracket fitted on the body and access to it is gained by unscrewing the protective cap; suitably connected to the diagnostic system (IWT, MODUS), it allows quick identification of the cause of faults in the various electronic devices.

The table on the following page shows the correspondence between the various electronic systems and the connector pins referring to them.

NOTE The connector shown is seen from the pin side.



The diagnosis connector on FIA engine vehicles is located on the conveyor unit lower party on the passenger side.

Figure 193



38-POLE DIAGNOSIS TAKEOFF


Figure 194



85620

38-PIN DIAGNOSTIC CONNECTOR

Figure 195



8621

IDENTIFICATION OF THE PINS OF THE 38-PIN DIAGNOSTIC CONNECTOR

Diagnostic connector pin description table

| System | Pin | Function |
|---|-----------|----------------|
| EDC/EGR/Methane | 1* 2 | L K |
| ABS/EBD/ABD | 3 4 | L K |
| Air Bag/Retarder | 6 | K |
| Tachometer (connector A cell 2 instrument cluster) | 8 | K |
| Supply +15/A services | 11 | Input |
| Immobilizer/Central door locking/Alarm | 12 | K |
| Climate control system | 13 14 | L K |
| Self-levelling suspension | 15 16 | L K |
| Engine timing signal (connector B pin 28 EDC control unit) Engine timing earth (battery -) | 23* 24 | - Screening |
| Supply +30 | 27 | Battery +V |
| Engine rpm | 28 | RPM |
| Vehicle speed | 29 | - |
| Earth | 30 | - |

(*) In vehicles equipped with FI engine and EDC 16 electronic control unit, diagnosis connector pins 1 and 23 are free.
Pin 21/22 CAN line

High-pressure pump (FIA engine)

This pump is similar to the 8140 engine one.

It differs in Rail line pressure, modulated at between 250 and 1600 bars by the electronic centre by acting on the pressure regulator electro valve and is not provided with a 3rd pump cutout electro valve (78015).

Pump (3) is oriented on the pump shaft cam.


During aspiration the pump is powered via supply conduit (5).

The amount of fuel to be sent to the pump is set by pressure regulator (7).

The pressure regulator stops fuel inflow to the pump based on PWM input from the centre.

During pump compression, fuel reaches a pressure level sufficient to open the pressure valve to common rail (2), and supplies it via output (1).

Figure 196




- 1. Rail delivery output – 2. Rail delivery valve – 3. Plunger – 4. Pump shaft – 5. Plunger supply duct – 6. Pressure regulator supply duct – 7. Pressure regulator – 8. High-pressure pump – 9. Mechanic feed pump – A. To the tank – B. Return from hydraulic accumulator (rail) – C. Fuel filter return – D. Delivery to hydraulic accumulator (rail) – E. From the tank – F. Return from injectors.

85846

72597

FIC ENGINE

Figure 197




1. Injectors – 2. Common-Rail pressure sensor – 3. Pre-heating glow plugs – 4. Air temperature sensor – 5. Pre-heated diesel oil filter – 6. Diesel oil temperature sensor – 7. High pressure sensor – 8. Pre-heating glow plugs central unit – 9. Sectioning by cab cable – 10. Pre-heating central unit positive – 11. Fuse – 12. Central unit – 13. Engine r.p.m. sensor – 14. Water temperature sensor for EDC – 15. Camshaft r.p.m. sensor – *: Water temperature transmitter for thermometer – **: Oil filter clogged sensor – ***: Engine oil level sensor

87246

Injection cable FIC (.14 - .17)

Figure 198




90164

* with .17 (VGT)

Connection between cab/bonnet cable and injection cable


Figure 199



| Ref. | Cable colour code | Function |
|------|-------------------|---|
| I | 1 5577 | Heated diesel oil filter positive |
| | 2 8150 | Pre-heating central unit (pin 86) |
| | 3 - | - |
| | 4 1310 | Pre-heating central unit (pin-D1) |
| | 5 1311 | Pre-heating central unit (pin-ST) |
| | 6 0000 | Pre-heating central unit earth (pin-31) |
| | 7 - | - |
| | 8 0077 | Heated diesel oil filter earth |

R.p.m. / timing sensors

Figure 200




88056


1. R.p.m. sensor – 2. Phonic wheel on drive shaft – 3. Timing sensor – 4. Phonic wheel on camshaft

Timing sensor (stroke)

Figure 201



88264



88267

1. Phonic wheel on camshaft – 2. Identification slots – 3. Sensor


RPM sensor

A phonic wheel is fitted on the drive shaft. As the sensor detects existing teeth passing, it provides the central unit with the signal that is necessary to determine engine r.p.m.'s.

The variation of the signal generated by the lack of some teeth (synchronisation gap) occurring at each drive shaft turn is the reference signal which enables the central unit to detect the lead of the pair of pistons 1-4 with respect to PMS.

This signal is also used by the control unit to detect the engine rotation speed, the duration of injection and to control the rev counter.


Figure 202



0003319t

TECHNICAL VIEW OF THE SOUND WHEEL AND SENSOR
1. Sound wheel – 2. Sensor


Figure 203



87792

Phonic wheel mounting

Figure 204



87793


1. Phonic wheel

Figure 205




RPM SENSOR AND CONNECTION CABLE

Figure 206



SENSOR CONNECTOR AND WIRING DIRAGRAM

Figure 207



85712

TIMING SENSOR

1. Earth – 2. Signal output – 3. Power supply positive

RPM sensor

These are inductive sensors.

The flywheel sensor (48035) is connected at pins 27 and 12 of connector A of the control unit.

Timing sensor

A semiconductor layer, immersed in a magnetic field and through which current flows, generates a potential difference (called Hall voltage) at its ends.

If current intensity remains constant, the generated voltage depends only on the magnetic field strength: periodical variation of field strength is enough to obtain a modulated electric signal.

The smooth portion of the phonic wheel (distributing shaft pulley) covers, while moving, the sensor, thus blocking the magnetic field with resulting low output signal.

On the contrary, the sensor generates a high signal next to the openings and when a magnetic field is available.

Phase sensor signals are acquired, and the engine position is recognized according to the sequence of the phonic wheel notches.

The mounting function makes it possible to identify signal errors and interferences (if any).

The resulting signal is supplied to the processor that controls the injection system.

The sensor (48042) is connected to the central unit at pins A20/50/11.

High-pressure pump

Pressure delivered to the rail is modulated between 250 and 1600 bars by the electronic central unit by operating on the solenoid valve of pressure regulator.

Pump (3) is oriented on the pump shaft cam.


During aspiration the pump is powered via supply conduit (5).

The amount of fuel to be sent to the pump is set by pressure regulator (7).

The pressure regulator stops fuel inflow to the pump based on PWM input from the centre.

During pump compression, fuel reaches a pressure level sufficient to open the pressure valve to common rail (2), and supplies it via output (1).

Figure 208



1. Output for rail pressure – 2. Rail pressure valve – 3. Pump – 4. Pump shaft – 5. Pump supply conduit – 6. Pressure regulator supply conduit – 7. Pressure regulator – 8. High pressure pump – 9. Fuel input connection from filter – 10. Fuel output connection to filter support – 11. Fuel input connection from centre heat exchanger – 12. Fuel output connection from mechanical pump to filter – 13. Supply mechanical pump

88072

Pressure regulator

When the engine control centre pilots the pressure regulator via the PWM signal, solenoid (1) is activated, which in its turn generates movement of magnetic core (2).




Core movement causes cylinder (3) axial displacement by fuel delivery partialization.

When solenoid (1) is not activated, the magnetic core is moved to its rest position by preload spring (6).

In these conditions, cylinder (3) is in a position to offer maximum fuel passage cross-section.

Control electro valve 78013 is connected to centre connector A pins 19 and 49.

Figure 209



1. Solenoid – 2. Magnetic core – 3. Cylinder – 4. Fuel input – 5. Fuel output – 6. Preload spring – 7. Connector

Rail (pressure accumulator) FIC


The hydraulic accumulator is mounted in the cylinder head on the side opposite aspiration.

By its volume, it damps fuel pressure oscillations owing to:

- high-pressure pump operation
- electro injector opening.

On hydraulic accumulator there is located the fuel pressure sensor.

Figure 210




88418

1. Rail – 2. Pressure sensor

Pressure sensor


Fitted to a rail end, it measures fuel pressure present to the purpose of determining existing fuel pressure. Pressure value is used to control pressure and determine injection electric control duration (85157). It is connected to the central unit at pins A 8/43/28. It is fed at 5 V.

Figure 211



PRESSURE LIMITER OPERATING GRAPH

Figure 212




003333t

GAUGE

1. Connector – 2. Gauge body – 3. Air input grid

Figure 213



003334t

TECHNICAL VIEW OF GAUGE CONNECTOR

Air delivery gauge with EGR

Used in the EGR version to replace the one mounted on the engine aspiration manifold.

The gauge is of the heated film type and is located on their aspiration conduit between the turbine and the air filter.

The gauge contains the aspired air temperature sensor.

It is connected to the central unit on connector "A".

Pin 1 sensor – Pin A37 – temperature signal

Pin 2 sensor – Power supply (+15)

Pin 3 sensor – Pin A44 – mass

Pin 4 sensor – Pin A29 – reference voltage

Pin 5 sensor – Pin A42 – pressure signal

* **If present**

The operating principle is based on a heated membrane inserted in a measurement canal through which air to the engine flows.

The hot film membrane is kept at a constant temperature some 120 °C above incoming air level by the heating resistor.

The air mass traversing the measurement canal tends to subtract heat from the membrane so current must cross the resistor to maintain constant film temperature.

Current absorbed is proportional to the air mass flowing to the engine and is measured with a Wheatstone bridge and the signal is forwarded to the electronic centre.

Air temperature/pressure sensor (without EGR)

This component incorporates a temperature sensor and a pressure sensor (85156).

It is fitted on the engine intake manifold and measures the maximum flow rate of the intake air which is used to accurately calculate the amount of fuel to be injected at each cycle.

It is connected to the central unit on connector "A".

- Pin 1 sensor – Pin A23 – earth –
- Pin 2 sensor – Pin A53 – temperature signal
- Pin 3 sensor – Pin A13 – 5V – supply –
- Pin 4 sensor – Pin A40 – 0 ÷ 5V pressure signal


Course of sensor in relation to the temperature

| Temperature | Resistance |
|-------------|------------|
| - 40 °C | 48.50 kOhm |
| - 20 °C | 15.67 kOhm |
| 0 °C | 5.86 kOhm |
| 20 °C | 2.50 kOhm |
| 40 °C | 1.17 kOhm |
| 60 °C | 0.59 kOhm |
| 80 °C | 0.32 kOhm |
| 100 °C | 0.18 kOhm |
| 120 °C | 0.11 kOhm |

Course of sensor in relation to the pressure:


See graph opposite.

Figure 214




AIR FLOW METER

Figure 215




AIR FLOW METER CONNECTION

Figure 216




AIR FLOW METER OPERATING GRAPH

Figure 217




COURSE OF SENSOR RESISTANCE IN RELATION TO TEMPERATURE

Figure 218



TECHNICAL VIEW OF ENGINE COOLANT TEMPERATURE SENSOR

Figure 219



NTC

WIRING DIAGRAM

Atmospheric pressure sensor

This is integrated inside the control unit.

It measures the atmospheric pressure to correct the flow rate in relation to the altitude.

Engine coolant temperature sensor

This is an NTC sensor located on the thermostat box.

It detects the temperature of the coolant fluid to give the control unit information about the engine temperature conditions.

It is connected to pins 58 and 41 of connector A of the control unit.

Course of the sensor in relation to the temperature:

| Temperature | Resistance |
|-------------|------------|
| - 40°C | 48.30 kOhm |
| - 20°C | 15.46 kOhm |
| 0°C | 5.89 kOhm |
| 20°C | 2.50 kOhm |
| 40°C | 1.17 kOhm |
| 60°C | 0.59 kOhm |
| 80°C | 0.32 kOhm |
| 100°C | 0.19 kOhm |
| 120°C | 0.11 kOhm |

Fuel temperature sensor


This is an NTC sensor located on the fuel filter.

It detects the temperature of the fuel to give the control unit information about the fuel oil temperature conditions.

It is connected to pins 52 and 51 of connector A of the control unit.

It is exactly the same as the engine coolant temperature sensor.

Figure 220



003324t

LOCATION OF ENGINE COOLANT TEMPERATURE SENSOR

1. EDC signal – 2. Signal instrument panel

Fuel filter

Cartridge degree of filtering: 5 micron


Differential operating pressure (obstruction indicator): 0.6 bar

The fuel temperature sent by the sensor to the electronic injection control unit allows very accurate calculation of the flow rate of the fuel to be injected in the cylinders.

It is located in a fairly accessible position in the left front part of the engine compartment.

1. Actuated by ECU via relay with fuel temperature below 3°C.
2. Filtering element
3. Shows presence of water through a warning lamp on instrument panel.
4. Differential pressure sensor calibrated at 0,6 bar : any clogging is shown by warning lamp
5. It is a NTC sensor connected to EDC for fuel temperature reading enabling electronic control to calculate the amount of diesel oil to be injected into the cylinders.
6. Installed on filter support for excess fuel return to tank.


Figure 221



003312t

1. Clogged filter sensor - 2. Fuel temperature sensor - 3. Water sensor - 4. Heater


Figure 222



003326t

I. Brake pedal switches

Figure 223



003327t

I. Clutch pedal switch

Brake pedal switches

On brake pedal there are two switches; an N.C. (53565) is directly connected to the central unit at pins K17–K80. It provides signals (voltages) in order to warn the central unit about occurred braking.

Second switch 53501 N.A. provides a voltage for turning on stop lights.

Clutch pedal switch

An N.C. switch connected to electronic centre pin K58 is mounted on the clutch pedal (42374).

The “clutch pedal actuated signal” is used by the centre to identify gear condition selected and gear shifts.

In absence of the pedal pressed switch signal, the centre disengages the Cruise Control function.

Injectors

The solenoid valve controls the lift of the atomiser needle.

On the fuel inlet union a filter protects the injector for impurities. The injector is constructively the same as conventional ones, except that there is no needle return spring.

Access to the injectors is gained by releasing the side soundproof cover from the cylinder head. The fuel recovery pipe has a quick coupling.

The injector comprises two parts:

- actuator – atomiser composed of pressure rod (1), pin (2) and nozzle (3)
- control solenoid valve comprising a coil (4) and drive valve (5).

1st phase: rest position

The coil (4) is not activated and the shutter (6) is in the closed position.

The same fuel pressure acts in both the control area (7) and in the pressure chamber (8), but as the shutter (6) is closed, the needle (2) cannot be raised.

2nd phase: start of injection

The coil (4) is energised and causes the shutter (6) to move upwards.

The fuel of the control volume (9) flows towards the backflow duct (10) causing a drop in the pressure in the control area (7).

At the same time, the pressure of the fuel in the pressure chamber (8) causes the needle (2) to rise, resulting in fuel injection to the cylinder.

3rd phase: end of injection

The coil (4) is not activated and makes the shutter (6) return to the closed position, which re-creates a balance of forces that makes the needle (2) return to the closed position and consequently end injection.


Injectors (78247)

The solenoid valve is of the N.C. type.

The injectors are connected individually to the control unit at the following pins:

- A16 / A47 cylinder 1 injector
- A2 / A31 cylinder 2 injector
- A1 / A46 cylinder 3 injector
- A17 / A33 cylinder 4 injector

Figure 224



INJECTOR WIRING DIAGRAM AND CROSS SECTION
 1. Pressure rod – 2. Needle – 3. Nozzle – 4. Coil – 5. Pilot valve – 6. ball shutter – 7. control area – 8. pressure chamber – 9. Control volume – 10. Backflow duct – 11. Control duct – 12. Supply duct – 13. Electrical connection – 14. High pressure fuel inlet – 15. Spring

Electromagnetic junction fan

The fan is provided with an electromagnetic junction monitored by the electronic centre pin A39 that activated the junction remote control switch, to optimise water cooling.

The electrical fan remote control switch is activated or deactivated by the centre according to the temperature of:

- the coolant
- over supply air
- the fuel

Engine coolant temperature

Activated at over 96 °C and deactivated at under 84 °C


Over supply air temperature

Activated at over 75 °C and deactivated at under 65 °C

Fuel temperature

Activated at over 20 °C and deactivated at under 10 °C

Figure 225



88064

ELECTROMAGNETIC JUNCTION TECHNICAL VIEW
1. Coil - 2. Connector

CLIMATE CONTROL

General


The function of the system is to automatically or manually control the temperature required in the cab.

According to the set required temperature the system controls:

- automatically:
 - air vent temperature
 - fan speed (continuous changing)

- manually:
 - fan speed
 - compressor on/off
 - outside air inlet/re-circulation
 - MAX DEF function (defrosting);
- totally manually (through bowden cables):
 - distribution of air flows to the air vents.

Figure 226



000250t


AIR FLOW DISTRIBUTION INSIDE THE CAB

Operating logic

A special electronic control unit controls automatic system operation checking the various parameters in order to provide the comfort required in the cab.

The control unit carries out and sets certain functions to obtain adaptation of the temperature of the cab to the one required depending on the requests received and the temperature conditions detected.

Figure 227



CLIMATE CONTROL ELECTRONIC CONTROL UNIT CONNECTIONS


1. Controls on dashboard: inside temperature sensor, re-circulation switch, "eco" switch, fan control potentiometer –
2. Outside temperature sensor – 3. Evaporator sensor – 4. Blown air sensor – 5. Digital display – 6. Fan electronic control module – 6A. Fan – 7. Compressor – 8. Gear motor for re-circulation function – 9. Air mixing gear motor –
10. Diagnostic connector – 11. EDC-EGR control unit – 12. Climate control electronic control unit

000251t

Air distribution knob

- A. Face area vents
- B. Face and floor area vents
- C. Floor area vents
- D. Floor and windscreen area vents
- E. Windscreen area vents


Figure 228



000252t

DETAIL OF AIR DISTRIBUTION KNOB

Figure 229




000241t

VENTILATION AND HEATING CONTROLS ASSEMBLY

1. Temperature adjustment knob – 2. Fan speed control knob – 3. Air distribution knob – 4. Outside air inlet or re-circulation

Figure 230




000254t

DETAIL OF AIR DISTRIBUTION KNOB

Air distribution knob with climate control system

- A. Face area vents
- B. Face and floor area vents
- C. Floor area vents
- D. Floor and windscreen area vents
- E. Windscreen area vents
- F. "Max def" function

Figure 231



00025et

CLIMATE CONTROL SYSTEM CONTROLS ASSEMBLY

- 1. Knob for setting required temperature – 2. Fan speed control knob – 3. Air distribution knob – 4. "Eco" function switch – 5. inside temperature sensor – 6. Re-circulation knob


Setting the required temperature

To set the required temperature, turn the corresponding knob (Figure 232) to the 18 °C – 30 °C range.

This knob is connected to a potentiometer which detects the different angular positions and transmits a signal to the electronic control unit.

There are fifteen different positions (one per degree centigrade) with two extremes "LO" and "HI" which correspond respectively to the coldest and warmest positions.

Figure 232



000255t

KNOB FOR SETTING REQUIRED TEMPERATURE


Setting the fan speed

To set the required fan speed, turn the corresponding knob (Figure 233) to the 0 to 4 range.

This knob is connected to a potentiometer which detects the different angular positions and transmits a signal to the electronic control unit.

There are six different positions, four of which are set manually (1, 2, 3, and 4), one for no air flow (0) and an automatic one controlled by the electronic control unit where the system itself selects the most suitable air flow to reach and/or maintain the required temperature (AUTO).

Figure 233



000256t

KNOB FOR SETTING FAN SPEED

“Auto” function

With the ventilation control knob in the “AUTO” position, the control unit will be able to control:

- The air temperature at the vents.
- Fan speed.

Function “0” (OFF)

With the ventilation control knob in the “0” position, the control unit acts as follows:

- No air flow (fan off).
- Mixing stopped in the previous position.
- Re-circulation on.
- Compressor off.
- “MAX DEF” function cut off if in progress.

“ECO” function

The engagement of this function is completely manual and is obtained through the special switch which makes it possible to disengage the compressor electromagnetic clutch.

Compressor control is however linked to other parameters, namely:

- Outside temperature (> 5 °C “ON”)
- Evaporator temperature (> 4 °C “ON”, < 3.5 °C “OFF”)
- Coolant fluid system pressure (min. 3.5 bar, max. 28 bar)
- EDC or EGR control unit (in versions where applicable).

“Re-circulation” function

The engagement of this function is completely manual and is obtained through the special switch which makes it possible to shut off the outside air inlet.

In the “MAX DEF” mode this function is cut off regardless of the position of the switch.

“MAX DEF” function

The engagement of this function is completely manual and is obtained turning the air distribution clockwise as far as the “MAX DEF” position.

The control unit will be informed of this request by the closing of a special N.O. microswitch in the rear part of the knob.

The engagement of this function involves:

- Maximum air flow, regardless of the position of the knob.
- Air distribution towards the windscreen through bowden cables.
- Mixing with the highest heat available (memorising the last position of the motor before leaving the adjustment state).
- Outside air inlet, regardless of the position of the re-circulation button.
- Compressor on, regardless of the position of the ECO button.

Switching this function off the gear motor moves back to the position memorised previously if the temperature adjustment knob is not at “LO” or “HI”.


If this function is already selected when the ignition key is turned on, no position will be memorised, and switching it off, the adjustment procedure will be started with the mixing gear motor in the “HI” condition.

Electronic control unit

This automatically controls the system monitoring the thermodynamic parameters in order to provide the suitable climate (temperature and humidity) required by the driver.

It is located on the lower part of the passenger's side duct unit.


Figure 234



000257t

| Connector | Pin | Function |
|-----------|-----|--|
| A | 1 | Signal from treated air temperature sensor |
| | 2 | Signal from required temperature potentiometer |
| | 3 | Signal from ventilation control potentiometer |
| | 4 | Earth |
| | 5 | Positive from "ECO" switch |
| | 6 | Positive from microswitch for "MAX DEF" function |
| | 7 | Signal earth |
| | 8 | Supply (+15/A) |
| | 9 | 5 V supply for ventilation, temperature and air mixing potentiometers |
| | 10 | Line L for 38-pin diagnostic connector pin 13 |
| | 11 | Line K for 38-pin diagnostic connector pin 14 |
| | 12 | Positive from switch for re-circulation |
| B | 1 | Positive (0 to 8 V) for fan electronic control module (0 to 6 V) |
| | 2 | Serial line for digital display (instrument cluster pin "B 11") |
| | 3 | Signal from evaporator temperature sensor |
| | 4 | Reference voltage from air mixing motor (0 to 5 V) |
| | 6 | Signal from outside temperature sensor |
| | 7 | Signal from inside temperature sensor |
| | 8 | Negative for fan electronic control module |
| | 10 | Supply (0 to 12 V) for re-circulation gear motor (+12 V for switching on re-circulation) |
| | 11 | Supply (0 to 12 V) for re-circulation gear motor (+12 V for switching on re-circulation) |
| | 12 | Key-operated positive supply |
| | 13 | Positive for compressor control relay |
| | 14 | Supply (0 to 12V) for air mixing gear motor (+12V with "HI" function) |
| | 15 | Supply (0 to 12V) for air mixing gear motor (+12V with "LO" function) |
| | 16 | Reference voltage from electronic fan control module (0 to 12 V) |

Figure 235



OUTSIDE TEMPERATURE SENSOR

Outside air temperature sensor

This is an NTC sensor on the left wing mirror (Figure 235) for both types of drive.

The resistance at 25 °C is 10 kOhm.

Operating range between – 30 °C and + 50 °C.

It is connected to pin 6 connector B of the control unit.

Inside temperature sensor

This is an NTC sensor located on the climate control module (Figure 237) between the two "Re-circulation" and "ECO" switches.

It is ventilated and contains a motor/fan so that the temperature reading is not affected by stagnating air inside the dashboard which is not realistic.


The resistance is 2.2 kOhm at 25 °C

Operating range between + 5 °C and + 45 °C

It is connected to pin 7 connector B of the control unit.

The motor **A**, fan **B** and sensor **C** are a single part and are connected to the wiring by a single connector at pin 12.


Figure 236



| Pin | Function |
|-----|--|
| 1 | Positive for motor |
| 2 | Negative for motor |
| 3 | Signal earth |
| 4 | Sensor signal for control unit (pin 7 connector B) |
| 5 | Positive from microswitch for "MAX DEF" function to control unit (pin 6 connector A) |
| 6 | — |
| 7 | Positive from "ECO" switch to control unit (pin 5 connector A) |
| 8 | Earth |
| 9 | +15/A supply |
| 10 | +15/A supply |
| 11 | Negative for lighting pictograms |
| 12 | Positive from re-circulation switch to control unit (pin 12 connector A) |

000260t

Figure 237



000255t

REQUIRED TEMPERATURE SETTING KNOB

Blown air temperature sensor

This is an NTC sensor positioned inside the distributor unit upstream of the air distribution ports to the various vents.

The resistance at 25 °C is 10 kOhm.

Operating range between 0 °C and – 80 °C

It is connected to pin 1 connector A of the control unit.

Evaporator temperature sensor

This is an NTC sensor positioned inside the distributor unit and it is fitted directly on the evaporator. It causes switching on (>4 °C) and switching off (>3.5 °C) of the compressor electromagnetic clutch. The resistance at 25 °C is 10 kOhm.

Operating range between 0 °C and +25 °C.

It is connected to pin 3 connector B of the control unit.

Required temperature potentiometer

This is a potentiometer connected to the required temperature setting knob on the climate control panel. It detects the various angular positions (Figure 238) and transmits a signal to the electronic control unit for a total of fifteen different positions (one per degree centigrade) two of which are the extremes "HI" and "LO" which correspond respectively to a request for the coldest and warmest positions.

It is supplied by the control unit at 5V.


Resistances R1 to R16 are approx. 700 Ohm.

Resistance R17 is approx. 1.1 Mohm

The total resistance R is approx. 11 kOhm.

It is connected to pin 2 and 9 connector A of the control unit.

Figure 238



000265t

POTENTIOMETER POSITION DETECTION LAYOUT

A. Signal earth (ms7) – B. Signal to control unit pin 2 connector A – C. positive from control unit pin 9 connector A

Ventilation control potentiometer

This is a potentiometer connected to the ventilation control knob positioned on the climate control panel.

It detects the various angular positions (Figure 240) and transmits a signal to the electronic control unit for a total of six different positions, four of which are manual flows (1, 2, 3, and 4), one no air flow (0) and one automatic (AUTO).

It is supplied by the control unit at 5 V.


The resistance R1 to R7 are approx. 1.5 kOhm.

Resistance R8 is approx. 1.1 Mohm.

The total resistance R is approx. 10.5 kOhm.

It is connected to pins 3 and 9 connector A of the control unit.


Figure 239



000256t

VENTILATION CONTROL KNOB

Figure 240




000266t

POTENTIOMETER POSITION DETECTION LAYOUT


A. Signal earth (ms7) – B. signal to control unit pin 3 connector A – C. Positive from control unit pin 9 connector A

Figure 241



LOCATION OF FAN ELECTRONIC CONTROL MODULE


Figure 242



ELECTRONIC FAN CONTROL MODULE CONNECTIONS

A. Electronic fan control module – B. Electronic climate control unit – C. Fan motor

Figure 243



GRAPH OF AIR FLOW RATE IN RELATION TO VOLTAGE

Electronic fan control module

This is an electronic circuit inside the distributor unit near the fan (Figure 241) and it adjusts the fan speed.

It is driven by the control unit with a voltage of between 0 and 5 Volt.

It drives the fans with a voltage of 0 to 12 Volt.

It is connected to pins 1 and 16 connector B of the control unit.

The graph (Figure 243) represents the air flow rate in relation to the control voltage from the control unit.

Air mixing gear motor

The gear motor formed of a motor and potentiometer is positioned inside the distributor unit and acts on the port that sends or does not send the flow of incoming air onto the heater radiator to be able to adjust the required temperature.

The potentiometer detects the actual position of the mixing port and informs the control unit of its position. The control unit reaches the two extreme positions, which correspond to the request for the coldest position "LO" and the warmest position "HI" inverting the polarity on pins 14 and 15 of connector B of the control unit.

+ 15 / - 14 for "LO" function

- 15 / + 14 for "HI" function.



Motor

This is supplied by the control unit at 12 V. It is connected to the control unit on pins 14 and 15 of connector B of the control unit. Loadless absorption is ≤ 60 mA, in D.C. it is ≤ 380 mA.

Potentiometer

It is supplied by the control unit at 5 V. The resistance is 4.7 kOhm. It is connected to the control unit on pins 7 and 9 connector A and on pin 4 connector B of the control unit.

Figure 244



8669

| Pin | Cable colour | Function |
|-----|--------------|---|
| 1 | White-Blue | Positive (5 V) for potentiometer from pin 9 connector A of the control unit |
| 2 | Grey-Black | Reference voltage (0 to 5 V) from pin 4 connector B of the control unit |
| 3 | Black | Signal earth |
| 4 | Yellow-Green | Supply (0 to 12 V) for motor from pin 15 connector B of the control unit |
| 5 | - | - |
| 6 | Blue-Red | Supply (0 to 12 V) for motor from pin 14 connector B of the control unit |

Re-circulation gear motor



The gear motor is located on the front part of the distributor unit and acts on the air inlet port.

The control unit opens or closes this port to control air inlet from outside or re-circulation inverting the polarity on pins 10 and 11 of connector B of the control unit.

+ 11 / - 10 to switch on re-circulation
- 10 / + 11 for outside air inlet.

There are no intermediate positions. It is supplied by the control unit at 12 V. It is connected to the control unit on pins 10 and 11 connector B of the control unit. Loadless absorption is ≤ 60 mA, in D.C. it is ≤ 380 mA.

Figure 245



8668

| Pin | Cable colour | Function |
|-----|--------------|---|
| 1 | Blue-Red | Supply (0/12 V) from pin 11 connector B of the control unit |
| 3 | Brown | Supply (0/12 V) from pin 10 connector B of the control unit |

Compressor

This is fitted on the left-hand side of the engine and it is a NIPPONDENSO SCROLL 08.

The fluid used is "Freon R 134A".

The quantity of fluid is 720 grams.

The type of oil used is solely ND Oil 08.


The quantity of oil is 80 grams.

Safety pressure switches

These are fitted directly on the dryer filter (Figure 248).

The minimum "A" and maximum "B" pressure switches make it possible to keep the pressure constant in the system between a minimum of 2 bar and a maximum of 27 bar, while the average set at 19 bar is used to switch on the condenser fan.


Figure 246



000274t

COMPRESSOR

Figure 247




8666

PRESSURE SWITCH UNIT WIRING DIAGRAM

A. Minimum = 2 bar – B. Maximum = 27 bar –

C. Average = 19 bar


Figure 248



8666a


PRESSURE SWITCH UNIT ON DRYER FILTER

Figure 249




CLIMATE CONTROLS ASSEMBLY
 A. Required temperature setting knob
 B. Speed control knob
 C. Air distribution knob

Figure 250



IGNITION SWITCH AND FAN SPEED CONTROL KNOB SETTING

Figure 251



DISPLAY ON INSTRUMENT CLUSTER

SYSTEM SELF-DIAGNOSTICS

Through suitable control logic the control unit is able to memorise and display a series of faults (present and/or intermittent) that may occur to the system.

In the event of these faults the control unit still continues controlling the system replacing the abnormal values detected with suitable "recovery" values which ensure minimal operation of the system.

As a fault arises, the control unit shows the wording "Error Cli" on the display on the instrument cluster.

- For preliminary information it is possible to show any faults on the display on the instrument cluster following a precise procedure.
- For complete more thorough diagnostics it is however necessary to use the diagnostic tools available to the service network such as MODUS.

Diagnostics through blink code

To find out which is the component concerned, proceed as follows:

Move the temperature setting knob to the "HI" position (Ref. A Figure 249).

Move the fan control knob to the "0" position (Ref. B Figure 249).

Move the air distribution knob to the "MAX DEF" position (Ref. C Figure 249)

Engage the ignition switch (Figure 250) at the services position (+15).

Within 10 seconds, operate the fan control knob (Figure 250) with the following sequence:


"0" => "AUTO" => "0" => "AUTO" => "0".

At this point the display on the instrument cluster (Figure 251) displays the error code. If more than one error is present, they are displayed every 3 seconds.

Blink codes

The table below shows the different error codes that may appear on the display on the instrument cluster instead of "CLI" during diagnostics.

Figure 252



000279t

| Codice | Description |
|--------|---|
| 14 | Short circuit or open circuit of blown air temperature sensor |
| 32 | Short circuit towards earth of outside temperature sensor |
| 34 | Short circuit or open circuit of outside air temperature sensor |
| 42 | Short circuit towards earth of inside temperature sensor |
| 44 | Short circuit or open circuit of inside air temperature sensor |
| 52 | Short circuit towards earth of evaporator temperature sensor |
| 54 | Short circuit or open circuit of evaporator temperature sensor |
| 65 | Air mixing gear motor failure |
| 82 | Short circuit towards earth of required temperature potentiometer |
| 84 | Short circuit or open circuit of required temperature potentiometer |
| 92 | Short circuit towards earth of ventilation control potentiometer |
| 94 | Short circuit or open circuit of ventilation control potentiometer |
| B2 | Short circuit towards earth of air mixing potentiometer signal |
| B4 | Short circuit or open circuit of air mixing potentiometer signal |
| D5 | Fan electronic control module failure |
| E2 | Short circuit towards earth of pin 9 of connector A of control unit for supplying potentiometers |
| E3 | Short circuit towards positive of pin 9 of connector A of control unit for supplying potentiometers |
| F6 | Supply voltage over maximum limit |
| F7 | Supply voltage below minimum limit |

AIR BAG

General

The air bag is a passive safety device comprising one or two cushions which, in the event of a head-on crash, inflate automatically setting themselves between the body of the occupants and the front structures of the cab.

The system is always integrated by seat belts with pretensioner, which are controlled by the air bag control unit, in the event of head-on crashes.


The system does not cut in for front crashes at low speed, side crash, overturning or crashes from behind.

NOTE The air bag is complementary to the use of the seat belts and not in replacement of them.

Inflation of the bags without the restraint of the belts compromises the safety of the driver and passengers.

The system components are connected to one another and with the rest of the electric system through a special harness, that can be easily recognised as it has a yellow sheath which is connected to the cab/bonnet cable by a 6-cell connector.

Figure 253



AIR BAG SYSTEM COMPONENTS

A. Driver's air bag module – B. Passenger's air bag module – C. 38-pin diagnostic connector – D. Electronic control unit – E. Air bag failure warning light on instrument cluster – F. Driver's reel with pretensioner – G. Centre reel with pretensioner – H. Passenger's side reel with pretensioner.

Operation

The air bag system consists of a cushion which inflates instantly contained in a special recess in the centre of the steering wheel for the driver and in the dashboard for the two passengers.

In the event of a head-on crash a deceleration sensor inside the air bag control unit activates the pretensioners and the instantaneous inflating device of the cushion or cushions which act as protective barrier between the body of the occupants and the vehicle structure. Immediately afterwards the driver's air bag and, if requested, the passenger's air bag deflate.

Deployment of the air bag system produces heat and a small amount of powder. This powder is not harmful and does not cause fire. In addition the surface of the


deployed bags and the inside of the vehicle may be covered with dust: this may irritate the skin and eyes. In the case of exposure, wash with neutral soap and water.

NOTE Turning the ignition switch to MAR, the air bag failure warning light turns on for four seconds as system self-diagnostics takes place.

Each time the system is activated, the control unit keeps the failure warning light on the instrument cluster on and it will be necessary to change the whole system (control unit, belts and pretensioners, bags and harness).

The system does not require any maintenance or checks.

Figure 254



LOCATION OF AIR BAG SYSTEM COMPONENTS AND CABLE

- A. 38-pin connector for diagnostics – B. Air bag failure warning light – C. Cock spring – D. Driver's air bag module – E. Connection between cab/bonnet cable and air bag cable – F. Passenger's air bag module – G. Passenger's reel with pretensioner – H. Centre reel with pretensioner – I. Air bag earth – J. electronic control unit – K. driver's reel with pretensioner – L. relay/fuse holder support

8556

Rules of safety to be followed for operations on vehicles fitted with the air bag system supplied to us by the supplier.



The following rules must absolutely be followed when doing any work concerning vehicles fitted with safety system with air bag.

Preliminary rules



Remember that air bag modules are devices to be handled with care. Their use, transport and storage are ruled by the following procedures.

Before starting any body repair work, welding, work requiring the removal of air bags or of the control unit, it is necessary to:

- move the ignition key to "STOP" and remove it
- always disconnect the battery, i.e.: disconnect the two terminals from their post and isolate them taping appropriately
- wait for at least 10 minutes before proceeding
- disconnect the control unit connector.

Store the modules with the cover upwards in a key-lockable metal cabinet. The cabinet, to be used for this purpose only, must not be used for storing other types of material, especially if inflammable.

All the connectors used and wired on air bag modules contain a short circuit clip. Up to the moment in which the air bag modules are connected to an appropriate source of energy, there is no possibility of undue activation of the units.

A system component not activated during an accident is to be considered still "active".

Therefore, undeployed components to be removed from vehicles (due to faults, guarantee expiry or other causes) must be returned to the special centre through the procedure described below.

NOTE The assembly or disassembly of components may ONLY be carried out by competent and authorised personnel.

The failure to follow the instructions given below may involve unwanted activation of the system, personal injury or unnecessary system repair. IT IS STRICTLY PROHIBITED TO DISASSEMBLE AIR BAG MODULES STRIPPING THEIR COMPONENTS.

All the system components have been specifically designed to work on vehicles of a specific brand and type. Therefore, air bags cannot be adapted, re-used or installed on other vehicles than the one for which they have been designed and manufactured.

NOTE Any attempt to re-use, adapt or install them on a different type of vehicle may cause serious or lethal harm to the occupants of the vehicle in the event of a crash.

Operations after an accident

NOTE If any component of the safety system is damaged following an accident, it should be replaced.
Do not attempt to repair the control unit, clock spring or air bag modules.

Accidents with or without deployment of the air bag device

Some system components should be inspected whether the system has been activated or not. These components are:

- steering column;
- steering column support;
- electronic control unit and modules retaining area;
- clock spring;
- dashboard (in the passenger's air bag area).

The component must be replaced in the presence of distortion, breakage and flexure.

Accidents with the deployment of the air bag device

If the vehicle has undergone a head-on crash involving the total deployment of the system, the following components must be replaced:

- air bag modules;
- pretensioners;
- electronic control unit;
- clock spring.

The harness and connectors should be inspected for signs of burns, melting of the outer insulation or damage due to excessive heat.

Any signs of damage on the clock spring in the control unit retaining area and on the air bag modules call for the replacement of the damaged components.

Painting work

No particular rules of safety are to be followed for painting work followed by oven drying, as the modules and pretensioners have been designed in such a way that they will not be damaged heating the outer surfaces of the vehicle with normal paint drying systems.

It is prohibited to use naked flames near the modules.

All electronic control units (including the air bag system) should always be removed if their temperature in certain environments may reach or exceed 85 °C.

Health hazards

The precautions to be taken when handling deployed air bags are the following:

- use protective polyethylene gloves and safety goggles;
- after touching triggered air bags, wash your hands and the parts of the body exposed with soap and water.

Effects of over-exposure

There is no potential hazard of exposure to the propellants as the system is completely sealed.

The propellant mixture is in the solid state, therefore inhalation is impossible even in the event of breakage of the gas generator cartridge.

Should any gas come out there is not health hazard.

Avoid any contact with the skin and do not swallow the propellant.

In the event of:

- contact with the skin wash immediately with soap and water;
- contact with the eyes: wash immediately with running water for at least 15 minutes;
- inhalation: take the person outdoors immediately;
- swallowing: induce vomit if the person is conscious.



Always call a doctor for all the above conditions.

Rules of safety in handling air bag modules

Under normal conditions the driver's and passenger's air bag are activated by the electronic triggering device during the crash. The gas developed (mainly nitrogen) under these conditions is not harmful.

Personnel carrying out operations on the device fitted on vehicles must absolutely adhere to the rules of safety given below.

Personnel operating on these devices must be suitably trained and follow the precautions given below:

- In open (exploded) air bag removal and replacement operations handle only one air bag at a time and for removal use polyethylene gloves and protective goggles.
- Always rest the air bag module with the opening lid and pre-split groove facing upwards. Do not put anything on top of this lid.
- Afterwards wash your hands carefully with neutral soap and in the event of contact with the eyes of residual powder, rinse immediately with running water.
- Before starting work on the system, disconnect the two battery cables (firstly the negative one) isolate the terminals with insulating tape and wait at least 10 minutes before proceeding.
- The metal components of an air bag that has just been deployed are very hot. Avoid touching these components for 20 minutes from the time of air bag deployment.
- Do not carry out repairs on air bag modules. Send all faulty modules to the supplier. Do not heat the air bag module for example by welding, hammering, drilling, mechanical machining etc.
- Never install on the vehicle air bags that have been dropped or show signs of any type of damage.
- It is prohibited to keep air bags together with inflammable material or fuel.
- The gas generators must not come into contact with acids, greases and heavy metals. Contact with these substances may cause the formation of poisonous, harmful gas or explosive compounds.
- Never use naked flames near air bag devices and system components.

Any spare parts should be stored in their original packing and temporary storage should follow the same procedure as for an undeployed air bag removed from the vehicle, i.e. a key-lockable metal cabinet must be used, especially for this purpose (metal, shock resistant cabinet with grilles to allow natural ventilation inside). The cabinet must have special warning notices (DANGER EXPLOSIVES – NO NAKED FLAMES – NOT TO BE OPENED BY UNAUTHORISED PERSONS).

Air bag module scrapping

The air bag modules fitted on the vehicle must not be scrapped with the vehicle itself, but removed beforehand and then deployed as described in the following pages.

Air bag units must not be scrapped without firstly deploying them.

If the air bag module has not been activated during a crash, the device is to be considered as still charged.

All unexploded material **MUST NOT BE ACTIVATED** and should be sent to a specialised centre with the following wording on the delivery note:

- AIR BAG DEVICE CONTAINING EXPLOSIVE CHARGE TO BE DEACTIVATED

The devices must absolutely be shipped in the same package in which the spares are received and if this is not available it is possible to ask the SPARES division for the package only.

Clearly in the case of replacing air bag devices the original packing should be kept intact for sending the undeployed device.

For FOREIGN MARKETS follow local regulations.



The failure to follow the procedures listed here may cause undue activation of the air bag units and personal injury. Undeployed air bag units must NOT be disposed of through the usual refuse disposal channels. Undeployed air bag units contain harmful substances for the health and may cause personal injury if the sealed container which contains them is damaged during disposal.

Rules of safety in handling pretensioners

In the event of a head-on crash, the driver's and passenger's pretensioners are activated an instant before the air bag modules.

The personnel that intervenes on the devices must be suitably trained and observe the following precautions:

- When handling activated pretensioners, i.e. when the propellant has already been triggered, use protective gloves and goggles.
- At the end of operations wash your hands carefully with neutral soap and in the event of contact of residual powder with the eyes, rinse immediately with running water.
- Disconnect the two battery cables (firstly the negative one) isolate the terminals with insulating tape and wait at least 10 minutes before proceeding.
- During activation the pretensioner develops heat; it is therefore necessary to wait at least 10 minutes after deployment, before touching them.
- During transport or handling, pretensioners should be protected from shocks or falling; pretensioners that have been knocked or dropped must not be used and must be returned to the supplier stating the reason.
- Pretensioners should not be carried by the belt.
- Pretensioners must be protected from sparks and naked flames; they should not contact surfaces for over 6 hours with temperatures above 100 °C .
- The gas generator propellant that is not burnt is inflammable, therefore, the parts of the generator should never be taken to pieces, damaged or tampered with.
- It is prohibited to store pretensioners with inflammable materials or fuel.
- The gas generators must not come into contact with acids, greases and heavy metals. Contact with these substances may cause the formation of poisonous, harmful gas or explosive compounds.
- Belts with pretensioners may only be stored in key-lockable places or cabinets, ventilated and away from naked flames and sources of heat.



After every crash in which the pretensioner has been activated, the belt is unserviceable and must be replaced.

Scrapping pretensioners

Undeployed pretensioners (not fitted on the vehicle) to be scrapped must firstly be deployed; those not activated but fitted on the vehicle must be removed and not scrapped with the vehicle.

If the pretensioner was not activated during a crash, the device is to be considered as still active; proceed as described in this manual.

Operations on system components

At the end of every operation on the system, it must be checked using Modus, I.W.T. or other diagnostic tools.

During assembly, the air bag components are labelled with a sticker with a removable part stating the date of installation of the system and components. The removable part is detached and the information on it is filed together with the system check report supplied by Modus, by the workshop that installed the components.

After 10 years from installation, unless the components are replaced before that time, a new air bag system (cable and components) should be installed. As mentioned previously, the data concerning the components and the date of system installation are to be filed.

Removing and scrapping an activated air bag module and pretensioner from a vehicle

Always wear gloves and safety goggles for handling an activated air bag or pretensioner. Wash the hands and exposed skin immediately with neutral soap and water after handling the components of an air bag module or pretensioner. In the case of exposure to secondary products, immediately rinse the eyes with running water. The failure to comply with these instructions may result in injury.

To remove and scrap an already activated air bag module and pretensioner:

1. Follow the instructions given in this manual for removing activated air bag module and pretensioners.
2. Disconnect the air bag module and pretensioner mechanical fastenings.
3. Disconnect the component connector from the air bag harness.
4. Place the air bag module and pretensioner in a special sealed polythene bag.
5. Send to the authorised collection/disposal centre.
6. Dispose of, recycle or scrap deployed air bag modules and pretensioners in the appropriate manner.

The residues left by combustion of the propellant require some consideration. They are mostly concentrated in the generator body or in small quantities in the bag. These residues may contain copper or chloride (e.g. potassium chloride). If the propellant is based on sodium azide or potassium nitrate, the combustion residues are highly alkaline and corrosive. **Always wear appropriate protection for the eyes and skin.** Deployed air bags should always be stored in dry, suitably ventilated places.

Removing or scrapping an air bag module that has not been deployed from a reparable vehicle



Do not cut cables or tamper with the connector between the vehicle harness and the air bag module. The connector contains a safety circuit.

If the connector is cut or removed from the air bag unit, the safety device is disabled and this could cause unforeseen activation with serious consequences for the physical integrity of people.

Air bag systems have a reserve power unit in the control unit. This must be deactivated disconnecting the two battery terminals and waiting for at least 10 minutes before doing any work on any components of the air bag.

When handling an air bag module, always keep the bag and outer cover away from the body. When positioning an active air bag on a bench or other surface, always place the bag and its cover upwards, not on the resting surface and away from people. Never put any object near an active air bag as it would become a bullet in the event of deployment.




Always keep active, undamaged, air bag modules and pretensioners in a cool, dry, locked and safe place. Do not expose to naked flames or temperatures above 150 °C. Do not cut, drill, braze weld an air bag module or its components with electric current. Never expose an air bag module or pretensioner to electric currents. The failure to comply with these instructions may damage the unit, cause fire, cause unforeseen deployment and serious harm to persons.

Active, damaged air bag modules and pretensioners (e.g. breakage of the electrical connection) must be kept away from corrosive or oxidising substances. The failure to comply with these instructions may cause fire, and/or serious harm to persons.

NOTE The air bag modules and pretensioners have an energy reserve. This device gives the electric pulse needed to deploy the bag if the battery or cables are damaged during the crash before the sensor activates the gas generator.

Figure 255



REMOTE DEPLOYMENT OF AIR BAG MODULES

C1 = air bag module connector

C2 = Connector to remote deployment device (connector for air bag with circuit clip; counterparts with male pins on air bag side)

Lb = bridle length – approx. 1 m

L = general cable, safety distance 10 m

A. Enclosed area

B. Remote deployment device

Deployment of an air bag

Remote activation

General instructions

1. The deployment procedure can be carried out in a suitably identified and enclosed open area away from potentially inflammable materials, fluids or other substances and from persons. Place the air bag module on a firm surface and clamp it closely.
2. Clean the area on which the module is placed from materials and bits (glass, instruments, pieces, etc.) which could be thrown out during deployment.
3. Make sure that connector C2 is disconnected from the remote deployment device (10 m).
4. Connect the electrical connector C1 specified by the vehicle manufacturer to the air bag module
5. Connect connector C2 to the remote deployment device.
6. Connect the remote deployment device to a 12 V circuit or equivalent device.
7. Make sure all persons are under shelter.
8. Wear accident prevention goggles and protective clothing.
9. Press the double deployment button
10. After deploying an air bag module, let it cool before touching it (about 20 min.).
11. Dispose of, recycle or scrap activated air bag modules according to the cases, as described in the corresponding chapters.

Deployment of air bag modules and electronic pretensioners still on board of irreparable vehicles

This procedure is followed when the vehicle with one or more active air bags needs to be scrapped. This procedure applies whether the air bag and/or pretensioner system is still intact or not.

It is advisable to deploy the explosive charges on the vehicle directly connecting the electric connector of the single module to the remote deployment system.




The deployment procedure must be carried out away from other persons in a suitably identified area. Check that no type of object has been left near the modules and pretensioners and make sure that there are no inflammable liquids in the vicinity. No-one should remain on board during deployment and remember to close the vehicle doors. Personnel should stay under shelter (e.g. behind a wall, vehicle, etc.) to protect themselves from any objects that may be thrown. Leave the generators and modules to cool after deployment (wait at least 20 min.). The failure to follow these instructions may result in serious physical harm.

General instructions

1. Follow all the WARNINGS, PRECAUTIONS and safety instructions given in this manual.
2. Take the vehicle to the area foreseen.
3. Remove all materials and bits (glass, instruments, pieces, etc.) around the air bag cover and check that there are no inflammable fluids in the immediate vicinity.
4. Disconnect the two battery cables (firstly the negative one) and wait at least 10 minutes before proceeding.
5. Use a connection bridle (L = approx. 1 m) with specific terminal connector for electrical connection with the module to be deployed.
6. Reach the electrical connection of the module in question (air bag or pretensioner) following the instructions given in this manual.
7. Disconnect connector C1 of the air bag module or pretensioner.
8. Check that connector C2 is disconnected from the remote deployment device.
9. Connect electric connector C1 of the air bag module or pretensioner to the connection bridle of the remote deployment device.
10. Connect connector C2 to the remote deployment device.
11. Make people go to a safe place.
12. Connect the remote deployment device to a 12 V circuit or equivalent device.

13. Press the double activation button to deploy all the air bag modules and pretensioners at the same time.
14. After deploying the air bag modules and pretensioners always let them cool before touching them (about 20 min.).
15. Once the modules and pretensioners have been deployed the vehicle can be scrapped – by squashing or crushing – and/or recycled depending on the cases.

Figure 256




8664

LAYOUT FOR DEPLOYING EXPLOSIVE CHARGES ON THE VEHICLE, SINGLE DEPLOYMENT

- ABG = driver's air bag
 ABP = passenger's air bag
 C2 = connector to remote deployment device
 C1 = specific connector to explosive charge
 L = general cable, safety distance 10 m
 Lb = bridle length
 PTG = driver's pretensioner

A. Remote deployment device


Figure 257



8547

BATTERY CABLE INSULATION


Figure 258



8548

REMOVING THE CONNECTOR FROM THE CONTROL UNIT

Figure 259



8549

REMOVING THE CONTROL UNIT

Electronic control unit

The electronic control unit is located on the floor at the side of the driver's seat between the gearshift lever and the parking brake lever; it is supplied at 12 Volt by a key-operated device, but it is still in a condition to be able to work for about 200 msec after a power cut off.

This is possible due to the presence of a buffer condenser inside which accumulates electric energy for normal operation of the control unit and generate the signal for triggering the explosive capsule.

This way system operation is guaranteed if the crash causes a power system failure (for example damage or breakage of the battery, power cable cut-off etc.).



The control unit must be directed with the arrow printed on the sticker facing the vehicle direction of travel. This is absolutely necessary as it determines the direction in which the deceleration sensor reads the values for defining the crash condition and thus triggering the air bag.


The electronic control unit should always be replaced after a crash that causes deployment of the complete system (air bag and pretensioners).

To remove the control unit:

- follow the rules of safety
- disconnect the battery cables (firstly the negative one then the positive) and isolate them taping the terminals
- wait at least ten minutes before proceeding
- remove the cover under which the control unit is to be found
- using a small screwdriver on the catch of the connector that locks the connector fastening lever, turn the latter outwards
- disconnect the connector from the control unit
- slacken the three screws fastening the control unit to the floor.

One-connector electronic control unit pin-out

Figure 260




000283t

| Pin | Function | Pin | Function |
|-----|---------------------------------------|-----|--|
| 1 | Positive for driver's pretensioner | 26 | Driver's pretensioner short circuit |
| 2 | Negative for driver's pretensioner | 27 | Driver's pretensioner short circuit |
| 3 | Positive for passenger's pretensioner | 28 | Passenger's pretensioner short circuit |
| 4 | Negative for passenger's pretensioner | 29 | Passenger's pretensioner short circuit |
| 5 | Key-operated positive supply | 30 | — |
| 6 | Earth | 31 | Earth short circuit |
| 7 | — | 32 | Short circuit |
| 8 | — | 33 | — |
| 9 | Line k for diagnostics | 34 | — |
| 10 | Positive for driver's bag | 35 | Driver's bag short circuit |
| 11 | Negative for driver's bag | 36 | Driver's bag short circuit |
| 12 | — | 37 | — |
| 13 | Positive for passenger's bag | 38 | Passenger's bag short circuit |
| 14 | Negative for passenger's bag | 39 | Passenger's bag short circuit |
| 15 | — | 40 | Failure warning light |
| 16 | Positive for centre pretensioner | 41 | Centre pretensioner short circuit |
| 17 | Negative for centre pretensioner | 42 | Centre pretensioner short circuit |
| 18 | — | 43 | — |
| 19 | — | 44 | — |
| 20 | — | 45 | — |
| 21 | — | 46 | — |
| 22 | — | 47 | — |
| 23 | — | 48 | — |
| 24 | Earth for diagnostics | 49 | — |
| 25 | — | 50 | — |

The figure shows the components of the AIRBAG system with two–connector control unit. This type of control unit shall be fitted on the vehicles in the future to replace the one–connector control unit.

Figure 261




AIR BAG SYSTEM COMPONENTS

A. Driver's air bag module – B. Passenger's air bag module – C. 38–pin diagnostic connector – D. Electronic control unit – E. Air bag failure warning light on instrument cluster – F. Driver's reel with pretensioner – G. Centre reel with pretensioner – H. Passenger's side reel with pretensioner

The two-connector control unit operates within a temperature range of -40 a $+85^{\circ}\text{C}$ with a maximum inclination angle tolerance at installation of $\pm 4^{\circ}$. The control unit weight is 200g max and features software version 4.4 and hardware version 1.1.0. The following figure represents a perspective view of the electronic control unit with two connectors (A and B).

Figure 262




73792

PERSPECTIVE VIEW OF THE ELECTRONIC CONTROL UNIT WITH TWO CONNECTORS
A. Black – B. Grey


ECU pin-out to the two connectors

Figure 263



| GREY CONNECTOR (A) | | BLACK CONNECTOR (B) | |
|--------------------|----------------------------------|---------------------|---|
| Pin | Function | Pin | Function |
| 1 | Ground | 1 | — |
| 2 | +15 power supply | 2 | — |
| 3 | K-line for diagnosis | 3 | — |
| 4 | — | 4 | — |
| 5 | — | 5 | — |
| 6 | — | 6 | — |
| 7 | — | 7 | — |
| 8 | — | 8 | — |
| 9 | — | 9 | — |
| 10 | Warning lamp | 10 | — |
| 11 | — | 11 | — |
| 12 | — | 12 | — |
| 13 | — | 13 | Driver side pre-tensioner positive |
| 14 | — | 14 | Driver side pre-tensioner negative |
| 15 | — | 15 | Front passenger seat pre-tensioner negative |
| 16 | — | 16 | Front passenger seat pre-tensioner positive |
| 17 | — | 17 | — |
| 18 | — | 18 | — |
| 19 | — | 19 | — |
| 20 | — | 20 | — |
| 21 | Driver front AIR-BAG positive | 21 | Front center pre-tensioner positive |
| 22 | Driver front AIR-BAG negative | 22 | Front center pre-tensioner negative |
| 23 | Passenger front AIR-BAG negative | 23 | — |
| 24 | Passenger front AIR-BAG positive | 24 | — |


Figure 264



8557

AIR BAG MODULE


Figure 265



8558

AIR BAG MODULE FASTENING SCREWS

Figure 266



8559

AIR BAG MODULE REMOVAL
A. Connector

Drivers air bag module

The module is at the centre of the steering wheel.

It mainly comprises the following:

- a bag inflation device, containing the triggering device and the explosive charge
- a synthetic fibre bag, folded in a special wrapping
- a plastic cover which at the centre and sides has pre-established splitting lines which allow the bag out.
- A plate that fastens the module to the steering wheel with two screws

Inflation of the bag takes place through the pre-established controlled expansion of the volume of inert harmless gas (ARGON), contained in a special module, after the heating caused by a charge of solid propellant.

The rear part of the bag has suitably-sized holes which deflate the bag immediately after inflation.

To remove the air bag module, proceed as follows:

- follow the rules of safety
- disconnect the battery cables (firstly the negative one then the positive) and isolate them taping the terminals;
- wait at least ten minutes before proceeding;
- slacken the two screws in the rear part of the steering wheel; to gain access to each screw, turn the steering wheel to be able to always work from the part of the upper steering column cover;
- lift the module enough to disconnect the connector in its centre;
- remove the module from the steering wheel.



After removal undeployed air bags must be stored in a special, key-lockable cabinet with the plate rested on the shelf.

Clock spring

The clock spring is a device fitted on the stalk unit ensuring electrical continuity between the driver's module and the air bag cable; it is formed of a container from which two cables lead. One is connected to the air bag cable and one to the driver's module. The container is composed of two overlaid plates; the lower one is fastened to the stalk unit by three screws and the upper one is made integral with the steering wheel through two appendices on its upper section.

Inside the two plates, the connection cables are wound in a coil to be able to allow the cables to follow the movements of the steering wheel. The clock spring also has a mechanism that automatically prevents it from turning when it is removed from the steering wheel; this consists in preventing the upper plate, no longer restrained, from turning freely causing unwinding or winding of the cables, with the possibility of breakage.

When the steering wheel is assembled the device locks automatically.


To remove the clock spring, proceed as follows:

- remove the driver's air bag module as described on the previous page
- align the wheels and keep them in this position throughout the whole operation
- slacken the nut fastening the steering wheel to the steering column
- still with the wheels aligned, mark the position between the steering wheel hub and the steering column
- remove the steering wheel taking care not to withdraw the clock spring cable



Make sure that removing the steering wheel cause the upper plate of the clock spring to raise. If the upper plate turns, it must be locked taking it outwards; a click will be heard during locking.


Figure 267



8560

REMOVING THE STEERING WHEEL FASTENING NUTS


Figure 268



8561

REFERENCE BETWEEN STEERING WHEEL HUB AND STEERING COLUMN


Figure 269



8562


REMOVING THE STEERING WHEEL

Figure 270




REMOVING THE STEERING COLUMN COVER HALVES

Figure 271



REMOVING THE CLOCK SPRING

Figure 272



CLOCK SPRING

- remove the steering column lower half cover slackening the three fastening screws (Figure 270)
- working from inside, remove the upper steering column half cover slackening the two fastening screws
- cut the strap that fastens the clock spring cable to the steering column and disconnect the connector of this cable from the air bag cable
- slacken the three screws fastening the clock spring to the stalk unit and remove it.



It is necessary to remove the clock spring without making it turn, holding the upper plate in place with a strap or adhesive tape.

To refit the clock spring, proceed as follows:

- make sure the wheels are aligned
- if replacement of the clock spring is not necessary, refit it, after removing the adhesive tape or strap put on previously, without making the upper plate turn, then tighten the three fastening screws
- in the case of fitting a new clock device, after fastening it to the stalk unit, tear the plastic tab to lock the upper plate and check that it does not turn
- connect the air bag cable connector to the clock spring cable and fasten the latter to the steering column using a suitable clamp
- assemble the two steering column halves fastening them on the support plate with their screws
- carefully insert the cable to be connected to the driver's air bag module through the slot provided on the steering wheel hub
- assemble the steering wheel making the reference marks made previously coincide.
- Tighten the steering wheel fastening nut to the specified torque.



Do not re-use the steering wheel fastening nut removed previously, replace it with a new one and caulk it.

NOTE If the stalk unit is changed it must be replaced by one inclusive of the clock spring.

Passenger's air bag module


This module is fitted on the dashboard and it is fastened on the body by a special bracket; the operating principle is the same as for the driver's module, only the size of the bag differs, as it has to protect two people.

To remove the air bag module, proceed as follows:

- follow the rules of safety
- disconnect the battery cables (firstly the negative one then the positive) and isolate them taping the terminals
- wait at least ten minutes before proceeding
- slacken the two screws fastening the dashboard cover
- remove the dashboard cover in such a way as to overcome the resistance of the snap button in the lower part of the cover
- disconnect the module cable connector from the air bag cable
- slacken the four screws two on either side, that fasten the module support bracket to the body and remove it.


NOTE If the passenger's air bag is not fitted as it is optional, a specific resistance is fitted on the connector during production to simulate the charge ($R = 2.15 \text{ Ohm} \pm 0.35$)

Figure 273




PASSENGER'S AIR BAG MODULE

Figure 274




REMOVING THE DASHBOARD COVER

Figure 275




REMOVING THE AIR BAG MODULE

Figure 276




REEL WITH PRETENSIONER

Figure 277

TECHNICAL VIEW OF REEL WITH PRETENSIONER
BEFORE DEPLOYMENT

A. Explosive charge – B. Propellant – C. Rack and pinion piston – D. Gears

Figure 278

TECHNICAL VIEW OF REEL WITH PRETENSIONER
AFTER DEPLOYMENT

Pretensioners

The pretensioner is an explosive device activated electrically with a signal leading from the electronic control unit; it is an integral part of the seat belt reel and forms a single component with it which is fastened to the vehicle pillar. It comes into action in the event of a crash of a certain entity, in order to take up the unavoidable slack in the seat belts due to the action of the weight of the body, keeping the body close to the seat back.

After cutting in the belt remains locked meaning that the device has been triggered.

Operating principle

The moment in which a determinate deceleration of the vehicle takes place, the electronic sensor in the control unit sends a signal which ignites the explosive charge (ref. A) of the gas generator (detonator).

The combustion of the propellant (ref. B) develops a gas, the pressure of which generates a force that pushes the rack and pinion piston (ref. C) upwards.

The upward movement of the piston makes the gears turn (ref. D) which reverse the direction of rotation of the belt rewinding it a few centimetres.

NOTE The belt is unserviceable after every crash and needs to be changed.

- The charge for the driver's pretensioner is connected to the control unit on pins 1/2.
- The charge for the passenger's pretensioner is connected to the control unit on pins 3/4.
- The charge for the centre pretensioner is connected to the control unit on pins 16/17.

Driver's/passenger's pretensioner




Do not use percussion screwing machines for the following operations on active pretensioners.

To remove the driver's or passenger's reel with pretensioner, proceed as follows:

- follow the rules of safety
- disconnect the battery cables (firstly the negative one then the positive) and isolate them taping the terminals
- wait at least ten minutes before proceeding
- slacken the screw fastening the tool kit under the seat
- slacken the seat fastening screw and remove it
- slacken the two screws fastening the step to the door pillar base
- partially remove the door weatherstrip
- slacken the screw fastening the seat belt
- remove the lower pillar trim overcoming the resistance of the two snap buttons in the upper part of the trim
- disconnect the pretensioner connector from the air bag cable (ref. A)
- connect the specific resistance on the air bag cable to simulate the presence of the pretensioner; this is to prevent the control unit from signalling a failure on the system that does not exist if the ignition switch is inadvertently turned to AVV or MAR.
- slacken the reel fastening screw (ref. B) and remove the reel.


Figure 279



STEP FASTENING SCREW

8550


Figure 280



REMOVING THE WEATHERSTRIP AND BELT FROM THE PILLAR

8551


Figure 281



REMOVING THE REEL WITH PRETENSIONER
A. Connector – B. Fastening screw

8552


Figure 282



8566

REMOVING THE TOOL KIT


Figure 283



8567

REMOVING THE SEAT

Figure 284



8568

REMOVING THE GUARD

Centre passenger's pretensioner




Do not use percussion screwing machines for the following operations on active pretensioners.

The centre passenger's reel with pretensioner has the same operating principle as the other two reels. To remove it proceed as follows:

- follow the rules of safety
- disconnect the battery cables (firstly the negative one then the positive) and isolate them taping the terminals
- wait at least ten minutes before proceeding
- slacken the screw fastening the tool kit under the seat
- slacken the seven screws fastening the seat
- disconnect the pretensioner connector from the air bag cable
- remove the seat
- connect the specific resistance on the air bag cable to simulate the presence of the pretensioner; this is to prevent the control unit from signalling a failure on the system that does not exist if the ignition switch is inadvertently turned to AVV or MAR.
- slacken the three screws fastening the guard on the rear part of the seat
- remove the guard
- slacken the reel and belt fastening screw, then remove the reel with pretensioner

Figure 285



8569

REMOVING THE REEL WITH PRETENSIONER

DOOR-BLOCKER WITH ANTI-THEFT PROTECTION

General information

The anti-theft protection is supplied with the door-blocker and consists of the following:

- a warning siren
- an (ultrasonic) electronic module for volumetric detection, including a LED for signalling that the anti-theft protection is ON
- an electronic central control unit (ECU) for the anti-theft/door-blocker, 433.92 MHz for the European market
- two remote-control keys.


When the anti-theft protection is activated/de-activated by means of the remote-control key, the doors (driver's and passenger's doors and, for the van version, the side and rear doors) of the vehicle close/open simultaneously.

To complete the system, in addition to the components already mentioned above there are the following:

- switches and motors for closing/opening the doors.
- switch for signalling that the bonnet is being opened.
- switch on a switchboard for locking the rear door.

In addition, the electronic central control unit is connected to the immobiliser control unit, to the direction indicator switch (indicator flashing lights) and to the 38-pin diagnostics connector (cell 12).

Figure 286




8572

LOCATION OF COMPONENTS

- A. Switch for signalling opening of the bonnet – B. Electronic central control unit (ecu) – C. Motor for closing/opening the lock on the passenger-side door – D. Electronic module for volumetric detection and led for signalling that the anti-theft protection is on – E. Motor for closing/opening lock on right-hand side door – F. Switch for signalling opening of rear door – G. Motor for closing/opening lock on rear door – H. Switch for signalling opening of right-hand side door – I. Switch for signalling opening of door on driver's side – J. Motor for closing/opening lock of door on driver's side – K. Switch for signalling opening of door on passenger's side – L. Switch for blocking rear door – M. Self-powered siren

System components

Figure 287



50288

| Ref. | Function |
|------|---------------------------------------|
| 1 | Driver door lock/release motor |
| 2 | Passenger lock/release motor |
| 3 | RH door lock/release motor |
| 4 | LH door lock/release motor |
| 5 | Rear door lock/release motor |
| 6 | Rear door button |
| 7 | Side doors button |
| 8 | Driver/passenger doors button |
| 9 | Engine bonnet button |
| 10 | Siren |
| 11 | Remote control key |
| 12 | Injection system control unit |
| 13 | Volumetric detector electronic module |
| 14 | Tester connector |
| 15 | Direction indicator telltale |
| 16 | Electronic control unit |

Operation

When the push-button on the remote-control key is activated, this is signalled by the LED on the key itself, and a radio-frequency (RF) signal is sent to the ECU. This signal controls closing of the doors by means of the motors, activates the volumetric sensor installed in the ceiling-lamp inside the cab and signals that the anti-theft protection has been activated by causing the indicator flashing lights to flash twice and the "anti-theft activated" LED to flash once. About ten seconds pass between the time when the signal is sent to the ECU and when the system is actually active. During this period of time, the ECU checks that all the necessary conditions (state of the doors, inside of the cab) for activating the anti-theft protection are met. Once the 10 seconds have elapsed the system is active and is constantly checked by the ECU.

If the ECU does not find all the conditions required for correct activation of the system while it carries out the anti-theft activation procedure (for example, if one of the doors is not closed), the state of the door will not be checked during the system monitoring that the ECU carries out upon completion of the activation procedure. Once the door has been closed, this too will be checked by the ECU, starting ten seconds from the time when it was closed.

The conditions in which the anti-theft protection switches on are the following:


- if the driver's/passenger's doors are opened
- if the rear door is opened
- if the bonnet is opened
- if the side door(s) is(are) opened
- if the engine is switched on
- if the volumetric detection module is activated.

If any of the above conditions occur, the sound of the self-powered siren and the flashing of the indicator flashing lights for five minutes will signal that the system has switched on.

In order to be able to open the doors and de-activate/switch off the anti-theft protection, it is necessary to press the push button on the remote-control key again. The ECU will de-activate the anti-theft protection. The indicator flashing lights will flash once and the signalling LED of the anti-theft protection will go off to confirm that it has been de-activated.

Arrangement of components

Figure 288



A. Engine bonnet switch – B. Volumetric detector electronic module – C. Door lock motor – D. Remote control key – E. Door switch – F. Electronic control unit – G. Siren

MAIN COMPONENTS OF THE SYSTEM

Remote-control key

The electronic device controlling the anti-theft protection with the door-blocker can be mounted in the grip of the key or in any suitable place for the remote-control function.

Features:

- transmission frequency 433.92 MHz
- transmission of combined code (fixed and variable)
- red LED for signalling transmission of the code
- 3V CR 2032 battery
- operation from $-30\text{ }^{\circ}\text{C}$ to $+60\text{ }^{\circ}\text{C}$
- retention of the "rolling-code" data (variable part of the combined code) in the memory of the microprocessor in the key during replacement of the battery
- maximum power transmitted: 10 mW.

On pressing the push button in the key, all the doors will be opened or closed and the anti-theft protection will be activated or de-activated. The red LED on the key will flash to signal transmission of the radio-frequency code to the ECU. If the pushbutton is activated for a time exceeding 20 minutes, transmission of the code to the ECU will be broken off, in order to prevent the battery of the remote-control key from going dead due to accidental activation of the push button.


As already stated, the remote-control key transmits a combined code (fixed and variable). The fixed code that is transmitted is always the same for each individual key, while the second part changes each time the pushbutton is pressed.

The keys supplied are two. It is important that they should both follow the correct key-learning procedure by means of the IVECO diagnostic tools with the +15 power supply on. The indicator flashing lights will flash once to signal that the code has been received by the ECU.

If the remote-control key gets partly or totally damaged, with the +15 power supply on, the immobiliser will send a signal to the ECU to de-activate it.

If the exchange of data between the transponder and the engine management is successfully completed, the immobiliser will send a $500\text{ msec} \pm 10\%$ message to the ECU. This signal will occur after $500\text{ msec} \pm 10\%$ from when the +15 power supply is switched on. If it is not, that is to say if the immobiliser signal does not fall within the range of values indicated above, the ECU will switch on the anti-theft protection. The impulses generated by the immobiliser after repeated switching on of the +15 power supply will be ignored.

Figure 289



50268

Remote control key battery

The key supplied as standard contains a 3 volt type CR2032 lithium battery. Battery life is about one year, since Bosch guarantees it for 50,000 working cycles at a temperature of between $-30\text{ }^{\circ}\text{C}$ to $+60\text{ }^{\circ}\text{C}$.

Batteries from competing brands can be easily found on the market, but the Bosch warranty is not valid unless only PANASONIC batteries are used.

Replacing the battery

Battery replacement should not take longer than 3 minutes. When fitting the new battery pay attention to battery polarity.

If you fail to comply with the foregoing instructions the **ROLLING CODE** necessary to transmit the signal from the key to the control unit will be deleted.

The ROLLING CODE can be reset by following the **key synchronisation** procedure.

Key synchronisation procedure

- introduce the key into the switch
- turn it to start
- press the remote control button

This procedure makes it possible to reset the ROLLING CODE

Electronic central control unit (ECU)

The central control unit is located underneath the central dashboard. It controls both centralised closing/opening of the doors and activation/de-activation of the anti-theft protection by means of the signal supplied to it by the remote-control key, with the consequent switching on of the remote-control switches located inside the actual control unit.

If one of the remote-control switches should be blocked (working contact blocked) during operation, causing continuous activation of the door-locking motor(s), the control unit will switch on remote-control switches that create bridges on the remote-control switch in question, in order to avoid serious damage to the motor(s) concerned. Once normal operation of the faulty remote-control switch is reinstated, then these remote-control switches will switch off.


The central unit is connected to the cable in the cab/bonnet by means of one 12-pin connector and one 28-pin connector. Each central unit has a pin code, which is programmed at the end of the line test. This pin code will consist of 5 digits, each of which will be a binary-coded decimal number from 0 to 9.

In addition, the ECU detects faults in the system, signalling the by causing the anti-theft signalling LED at the centre of the ceiling light to flash. It is possible to identify two types of failure: minor and major. In the first case, with the +15 power supply on, the LED will remain on without flashing, while in the second case, again with the +15 power supply on, the LED will flash. Major failures are those concerning the ECU, and are caused by:

- an error in the ROM/RAM check sum
- an error in the EEPROM check sum
- remote-control switch with working contact blocked.

Technical view of the ECU

Figure 290




50285

Pin out ECU

| Connector | Pin | Function |
|-----------|---|---|
| A | 1 | Door-blocker on driver's and passenger's side |
| | 2 | – |
| | 3 | +15 power supply |
| | 4 | – |
| | 5 | Rear door-blocker from switch on dashboard |
| | 6 | – |
| | 7 | Side and rear door-blocker |
| | 8 | Door-unblocker |
| | 9 | +30 power supply |
| | 10 | – |
| | 11 | Earth |
| | 12 | – |
| B | 1 ÷ 4 | – |
| | 5 | Siren |
| | 6 | Power supply to led for signalling activation of the anti-theft protection |
| | 7 | Earth |
| | 8 ÷ 11 | – |
| | 12 | Immobiliser disabling |
| | 13 | – |
| | 14 | Switching on of LED signalling activation of the anti-theft protection |
| | 15 | To switches for switching on the inside lights on driver's and passenger's side doors |
| | 16 | To the switches for switching on the inside lights on the right-hand side doors |
| | 17 | To the switches for switching on the inside lights on the rear door |
| | 18–19 | – |
| | 20 | To the switch signalling opening of the bonnet |
| | 21 | To the 38-pin diagnostics connector (cell 12) |
| | 22 | To the switch for switching on the inside lights on the left-hand side door |
| | 23 | Signal from electronic volumetric detection module |
| 24 | Switching on of indicator flashing lights | |
| 25 ÷ 28 | – | |

Arrangement of the switches

Figure 291



50284

A. Volumetric detector electronic module – B. Rear door button – C. Buttons on front doors – D. Engine bonnet button

Switches for signalling opening of doors and bonnet

These switches are the same, excluding the one for the bonnet, that controls switching on of the ceiling lights inside the cab and, for the van version, the loading platform. They send the signal indicating the status of the doors and of the bonnet to the ECU.

Door-blocker/unblocker motors

Each door has its own motor for closing/opening the lock on the door.

Operation of the motor is enabled by switching the remote-control switches on the circuit card of the ECU on/off for a pre-established period of time, programmable in the EEPROM of the ECU.

These motors can be activated in two different ways:


- by means of the pushbutton on the remote-control key (blocking/unblocking of all the doors)
- by means of the switch on the switch panel (blocking/unblocking of the rear door only, in the van version).

With the +15 power supply on, operation of the motors by pressing the pushbutton on the remote-control key is not possible. Activation of the motor of the rear door by means of the switch on the switch panel is possible, on the other hand, regardless of the presence or otherwise of the +15 power supply.

Pinout of a door blocker/unblocker motor


| Pin | Function | V | Time required |
|----------|------------|------|---------------|
| 1 | Blocking | +12V | ~ 750 sec. |
| | Unblocking | 0V | ~ 750 sec. |
| 2 | Blocking | 0V | ~ 750 sec. |
| | Unblocking | +12V | ~ 750 sec. |

Figure 292




50283

A. Door opening button



50282

B. Engine bonnet switch



50281

C. Door lock/release button

Electronic volumetric–detection module


This module carries out volumetric detection inside the cab, by means of the two sensors located on the sides of the ceiling–light (A) inside the cab, starting from when the anti–theft protection is activated. It sends the data to the ECU. Any changes in the state inside the cab due, for example, to the windows being smashed or an object being accidentally moved, will be transmitted to the ECU, which will command the anti–theft protection to switch on.

The module includes a LED for signalling that the anti–theft protection has been switched on. This is also mounted in the ceiling–light inside the cab (B), and in addition to the state of the anti–theft protection (active, inactive), it also signals that key learning has been accomplished and any failures in the system.

Pin out

| Pin | Function |
|-----|---|
| 1 | Power supply from ECU (connector B pin 6) |
| 2 | +30 power supply |
| 3 | Earth |
| 4 | Receiving and transmitting of serial data |
| 5 | Signal to ECU (connector B pin 23) |
| 6 | LED driver |

Figure 293



50280

Siren

The siren is located inside the engine compartment. It is self-powered by an internal battery that enables it to sound when it is disconnected from the vehicle, and it must comply with specific requisites, such as supplying a value greater than or equal to 100 dB at a distance of 1 metre from the siren after 5 minutes of operation.

The batteries of the siren are recharged in the following ways:

- trickle-charging
- rapid charging
- charging after disconnecting the siren from the vehicle

Trickle-charging is always activated in order to compensate for the normally occurring loss of charge of the batteries. The batteries will be charged by supplying a 12 mA current for one minute at intervals of one hour.

Rapid charging takes place for a duration of 14 hours with a current of 12 mA. This method is used when the siren is connected for the first time, or when it is reconnected to the system following maintenance operations on the vehicle that require the battery to be disconnected. Once the required time has elapsed, charging stops. This type of charging does not require the +15 power supply to be on.


With the third type of charging, if the siren of the vehicle is disconnected while it is not sounding, the whole time for which it remains disconnected will be the same required to recharge the batteries when it is connected to the system again. If, on the other hand, the siren is disconnected after it has been triggered, when it has to be reconnected to the system the batteries will be charged for 45 seconds for each second that the siren remained disconnected. This recharging process is only carried out with the +15 power supply off. If the batteries are below the minimum charging level, they will be recharged, with the +15 power supply on, for 14 hours at 12 mA.

Figure 294

Siren pin-out

| Pin | Function |
|-----|----------------------------|
| 1 | +15 power supply |
| 2 | +30 power supply |
| 3 | Serial input/output signal |
| 4 | Earth |

A. Horn
B. Siren



50279

Siren modes and states

Delivery mode/state

This mode indicates the state of the siren when it is delivered to IVECO. An acoustic signal emitted by the siren will signal its activation when it is connected to the system.

Idle mode/state

This state indicates when the siren has been disconnected and its operating state has been blocked, implementing the siren service mode described below. The siren is blocked in order to retain the charge of the batteries and its microprocessor is de-activated. An acoustic signal produced by the siren will signal its activation when it is reconnected to the system.

Siren disabled state

The siren always goes into an idle state when it is connected to the vehicle on the IVECO production line. In addition, the siren also goes into this state when the anti-theft protection is de-activated by the remote-control key.

Enabled state 1

This is the normal state of the siren, and it indicates that the anti-theft protection has not been activated and that the +15 power supply is off. In this state, the siren can still trigger off an alarm if it is disconnected from the vehicle.

Enabled state 2

In this state, the anti-theft protection is activated. The siren has already received a serial activation command from the ECU. In this state, if the siren is disconnected or the ECU detects a signal able to switch on the siren, this will be activated.

Alarm state 1

In this state the siren is on, however the ECU is not activated. The siren was activated because it was disconnected.

Alarm state 2

In this state the siren is on. The ECU is activated. The siren may have been caused to switch on by a signal from the ECU triggering anti-theft protection or because it was disconnected from the battery of the vehicle.

ERROR CODES


Any faults and their causes are detected by the ECU and stored in it. There is a diagnostics system that enables them to be identified, with the +15 power supply on, by detecting the number of times that the anti-theft signalling LED flashes. Correct interpretation of the flashing will lead to identification of the number of the error code. In order to do this, it is necessary to know that:

- the LED on for 1 second is equivalent to ten
- the LED on for 0.5 seconds is equivalent to one unit.

The time that passes between each time that the LED goes on and the next is 0.5 seconds. If two or more error codes should be detected, the time for which the LED remains off would be 2 seconds.

The error codes are signalled, if the corresponding fault is present, once only and in ascending order. Then, once all the active faults have been signalled, the LED will extinguish.

Figure 295



8597

ERROR CODE SEQUENCE

Error code table

| Error code | Type of improper functioning | Fault detection | Condition for detecting fault |
|------------|---|---|--|
| 11 | EEPROM of the ECU | Checksum error in the remote-control key code in the EEPROM of the ECU | Once for each time the +15 power supply is turned on. |
| 12 | ECU | RAM/ROM checksum error. Remote-control switch with working contact blocked | Checksum error on activation of the ECU. Each time the motor is operated the working contact blocks |
| 13 | No key programmed | No remote-control key programmed in the ECU | Once every second |
| 14 | No PIN code programmed | No EEPROM PIN code programmed | Once every second |
| 15 | Door-closing output signal shorted to earth or battery+ | Incorrect door-closing output signal | With remote-control switch on. Once every second |
| 16 | Output signal inside cab shorted to earth or battery + | Low output with remote-control switch on. High output with remote-control switch off | With remote-control switch on. Once every second |
| 17 | Rear door output signal shorted to earth or battery+. | Low output with remote-control switch on. High output with remote-control switch off | With remote-control switch on. Once every second |
| 18 | Left direction indicator output signal to earth | Low output with remote-control switch on | With remote-control switch on |
| 19 | Right direction indicator output signal to earth | Low output with remote-control switch on | With remote-control switch on |
| 20 | Led output signal shorted to earth or battery+ | Incorrect Led output signal | Once every second. For the 10 seconds required to activate the ECU |
| 21 | No response from ultrasonic module | No signal from ultrasonic module | For the 10 seconds required for activation |
| 22 | No response from siren | No signal from siren in response to ECU | For the 10 seconds required for activation |
| 23 | Siren batteries dead | Serial message from siren | For the 10 seconds required for activation |
| 24 | Siren self-test wrong | Serial message from siren | For the 10 seconds required for activation |
| 25 | Rolling code of remote-control key out of range | Rolling code transmitted in RF from the remote-control key not recognised by the EEPROM | On receiving the RF message |

AIR SUSPENSIONS ECAS

High-flexibility air suspension system with highly efficient vibration damping effect provided with self-adjusting feature that keeps constant chassis-to-road height, regardless of the load carried by the vehicle. A special push-button allows to change chassis-to-road surface distance, that is the height of the vehicle cargo compartment floor.

Besides the traditional advantages of any air suspension system, the ECAS system also allows:

- air consumption reduction
- prompt response to adjustment
- simple systems
- high safety
- complete system diagnosis.

The **ECAS (Electronically Controlled Air Suspension)** system automatically controls the vehicle air suspension system nominal level.

The features described above are bound to special operating and safety conditions of the associated systems.

The ECAS electronic control unit automatically checks chassis level (height from road surface) by reading the real values supplied by the sensors and comparing them to the rated values stored in the memory.


With any change of the vehicle trimming, the electronic control unit controls the electropneumatic units to bring the actual level to the level set or previously memorized by the driver.

| MODEL | MOTOR | ECAS | VTB |
|-------|-------------------------|------|-----|
| 29L | .10 .11 .12 .14 | X | |
| 35S | .10 .11 .12 .13 .14 .17 | X | |
| 35C | .10 .11 .12 .13 .14 .17 | | X |
| 40C | .10 .11 .12 .13 | | X |
| 45C | .11 .13 | | X |
| 50C | .11 .13 .14 .17 | | X |
| 60C | .15 | | X |
| 65C | .15 .17 | | X |

WABCO electronically controlled air suspensions (ECAS)

The system in figure is installed in the following vehicles:
29L – 35S.

Figure 296




SYSTEM OPERATING DIAGRAM

| Pin | Description | Component code |
|-----|--|----------------|
| 1 | ECAS electronic control unit | 86023 |
| 2 | Chassis manual leveling control push-button | 52090 |
| 3 | Chassis lifting control push-button | 53051 |
| 4 | Chassis lowering control push-button | 53052 |
| 5 | ECAS pilot lamp | 58713 |
| 6 | Stop light switch | 53501 |
| 7 | Tachometer – tachograph | 40001 – 40011 |
| 8 | RH air spring | – |
| 9 | RH level sensor | 40046 |
| 10 | Hydraulic brake action compensator | – |
| 11 | Brake action compensator actuator air cylinder | – |
| 12 | LH level sensor | 40046 |
| 13 | LH air spring | – |
| 14 | Electrocompressor unit | 78233 |
| 15 | RH chassis actuator solenoid valve | – |
| 16 | LH chassis actuator solenoid valve | – |
| 17 | Throttle valve | – |
| 18 | Dryer filter | – |
| 19 | Air spring relief solenoid valve | – |
| 20 | One-way valve | – |
| 21 | Compressor | – |
| 22 | One-way valve | – |
| 23 | Intake filter | – |
| 24 | Compressor motor | – |
| 25 | Motor relay | – |
| 26 | Diagnostic socket | 72008 |

Vehicles with braking system without ABS

Figure 297




000217t

1. ECAS warning lamp – 2. RH level sensor – 3. RH air spring – 4. Chassis lifting control push-button – 5. Chassis lowering control push-button – 6. ECAS ECU – 7. Chassis leveling control push-button – 8. Hydraulic brake action compensator – 9. Brake action compensator air cylinder – 10. LH air spring – 11. Air supply unit – 12. LH level sensor – 13. Centralized diagnostic socket

Vehicles with ABS system

Figure 298



000217t

1. ECAS warning lamp – 2. RH level sensor – 3. RH air spring – 4. Chassis lifting control push-button – 5. Chassis lowering control push-button – 6. ECAS ECU – 7. Manual chassis leveling control push-button – 8. LH air spring – 9. Air supply unit – 10. LH level sensor – 11. Centralized diagnostic socket.

Electronic Control Unit

The electronic control unit controls different chassis positions in accordance with the requests from the driver.

As the ignition key switch is turned to ON position, the electronic central unit runs a system check while the red warning lamp on the dashboard panel comes on for about 2 seconds.

If any failure is detected, this warning lamp can stay on fixed for serious system failure or flashing for compressor failure due to overtemperature.

The electronic control unit checks the level sensor at regular intervals in order to keep chassis level constant as required by the driver, and operates the necessary compensation when a deviation of more than 3 counts is detected.

The compensation shall be operated with the following delay:

~ 1 sec. with vehicle still

~ 30 sec. with vehicle moving

If the level is not restored within a maximum time of 30 seconds from the beginning of the compensation, the control unit memorizes a plausibility error and the warning lamp comes on fixed.

During braking, the electronic control unit detects the signal from the stop light switch and stops any chassis level automatic adjustment.


If a difference of more than 4 counts is detected between RH and LH sensors with vehicle still, after a delay of about 8 seconds, the control unit recognizes a "step" condition and stores the data in memory, keeping the chassis level as it is.

Besides a "blink code" option through the red warning lamp for preliminary diagnosis, the electronic control unit is provided with an advanced self-diagnosis system capable to detect and memorize any failures, depending on the concurrent conditions, including intermittent errors occurred in the system during operation and ensure a more appropriate and reliable servicing.

All interventions concerning diagnosis, programming, failures memory deletion, etc. can be performed by using available diagnosis instrument.

Electronic control unit pin out

Figure 299



000095t

| Pin | Function | Cable colour code |
|-----|--|-------------------|
| 1 | Battery positive supply | 7772 |
| 2 | "L" line to pin 15 of the 38-pole diagnostic connector | 1194 |
| 3 | – | – |
| 4 | "K" line to pin 16 of the 38-pole diagnostic connector | 2294 |
| 5 | – | – |
| 6 | – | – |
| 7 | – | – |
| 8 | RH level sensor positive | 5421 |
| 9 | Ignition switch positive supply | 8090 |
| 10 | – | – |
| 11 | (Positive to air reservoir solenoid valve supply) | 9445 |
| 12 | – | – |
| 13 | Positive to LH chassis control solenoid valve | 9425 |
| 14 | – | – |
| 15 | Positive to electric compressor control relay | 9444 |
| 16 | Positive from stop light switch | 1363 |
| 17 | – | – |
| 18 | – | – |
| 19 | Negative from chassis level push-button | 8420 |
| 20 | – | – |
| 21 | – | – |
| 22 | Vehicle speed signal | 5411 |
| 23 | – | – |
| 24 | – | – |
| 25 | LH level sensor positive | 5422 |
| 26 | Chassis lift/lower push-button communication line | 8091 |
| 27 | Negative | 0000 |
| 28 | – | – |
| 29 | Positive to relief solenoid valve | 9423 |
| 30 | – | – |
| 31 | Positive to RH chassis control solenoid valve | 9424 |
| 32 | – | – |
| 33 | Negative for failure warning lamp | 6008 |
| 34 | – | – |
| 35 | – | – |



Level sensor

The level sensor consists of a coil fastened to the chassis and a piston (Figure 300).

The piston is moved inside the coil by the action of a cam and a lever connected to the axle, this way varying the coil inductance.

These variations shall be used by the electronic control unit at the different stages of system operation.

Figure 300




000369t

LEVEL SENSOR

Here is shown the nominal characteristic curve of the sensor as a function of the angle displacement of the lever.


Figure 301



000370t

OPERATING DIAGRAM


Figure 302



000222t

INTERNAL COMPRESSED AIR DIAGRAM

Figure 303



000222t

SUPPLY UNIT

Pneumatic supply unit

This component produces, dries, supplies or discharges suspension spring air.

Components of the air supply unit

1. Relief solenoid valve
2. Electrical motor control relay
3. Intake filter
4. RH chassis control solenoid valve
5. LH chassis control solenoid valve
6. Compressor
7. Drier filter
8. Compressor electrical motor
9. Electrical connector



Brake action compensator

The vehicles not equipped with ABS / EBS / ABD system need a system providing a better control of the braking action on the rear wheels. This system includes an dual brake action compensator and a brake action compensator pneumatic actuator.

Depending on the load applied on the rear axle, as detected by the pneumatic actuator, the brake action compensator automatically adjust the braking torque applied to the axle by the brakes.

The diagram shows the compensation ratio corresponding to 0.15 as a function air spring variations.

Figure 304




000372t

BRAKE ACTION COMPENSATOR UNIT

- 1. Dual brake action compensator
- 2. Pneumatic actuator for brake action compensator

Figure 305




000371t

OPERATION DIAGRAM

- A. Hydraulic output pressure (bars) – B. Hydraulic control pressure (bars) – C. Pneumatic control pressure (bars) –
- D. Characteristic curve with 0.15 ratio (empty) –
- E. 1:1 ratio (loaded) – F. Characteristic curve of pneumatic pressure/load

“A” Braking action


Figure 306



000219t

“B” Braking action with empty vehicle


Figure 307



000220t

“C” Braking action with laden vehicle

Figure 308



000221t

Chassis lifting

This operation is allowed at a speed below 15 Km/h; as soon as this speed is exceeded, automatic chassis leveling is actuated.

Proceed as follow to lift the chassis:

- Press chassis lifting push-button and keep it pressed to enable the relay to close the switch and receive a 5A supply. Now, the control unit commands the relay to start the compressor (6) electrical motor (2). Air is then aspirated through the filter (3), compressed and delivered into the system via the one-way valve and the drying filter (7). Simultaneously, the control unit starts solenoid valves "4" and "5" so that the compressed air is supplied to the suspension air springs to lift the chassis.

During the entire operation, the red warning lamp on the dashboard panel shall flash to inform the driver that the chassis is off trim.


The warning lamp shall keep flashing until the chassis is off normal trim.

Chassis lowering is stopped as the push-button is released while the chassis level reached is maintained.

The maximum height is set by level sensors according to the calibration data memorized in the electronic control unit.

Maximum lifting actuation time is 2 minutes to prevent preheats that could damage the electro compressor.

Figure 309



000224t

SYSTEM OPERATION DIAGRAM

- 1. Exhaust solenoid valve – 2. Electrical motor control relay – 3. Intake filter – 4. RH chassis control solenoid valve –
- 5. LH chassis control solenoid valve – 6. Compressor – 7. Dryer filter – 8. Compressor control electrical motor –
- 9. Electrical connector

Chassis lowering

This operation is allowed at a speed below 15 Km/h; as soon as this speed is exceeded, automatic chassis leveling is actuated.

Proceed as follow to lower the chassis:

- Press the lowering push-button and keep it pressed to enable the relay to send a signal to the control unit to energize solenoid valves (4) and (5) and the exhaust valve (1).

The compressed air contained in the suspension air springs can flow back through the dryer filter "7" for cleaning and, as imposed by the closed one-way valve, flow to the relief solenoid valve to be released in the atmosphere through the intake filter.


During the entire operation, the red warning lamp on the dashboard panel shall flash to inform the driver that the chassis is off trim.

The warning lamp shall keep flashing until the chassis is off normal trim.

Chassis lowering is stopped as the push-button is released while the chassis level reached is maintained.

The maximum height is set by level sensors according to the calibration data memorized in the electronic control unit.

Figure 310



000223t

SYSTEM OPERATION DIAGRAM

1. Exhaust solenoid valve – 2. Electrical motor control relay – 3. Intake filter – 4. RH chassis control solenoid valve –
5. LH chassis control solenoid valve – 6. Compressor – 7. Dryer filter – 8. Compressor control electrical motor –
9. Electrical connector

Chassis leveling


Chassis leveling can be achieved with vehicle moving at a speed below 15 Km/h by pressing the leveling push-button.

This way, the control unit shall start the lifting or lowering action until the normal height is reached and maintained in accordance with the signals received from the level sensors and the calibration data stored in the control unit memory.

On achievement of the normal trim, the warning lamp on the dashboard panel shall stop flashing.

The same leveling shall be obtained automatically as the vehicle exceed the speed of 15 Km/h.

Figure 311



000363L


SYSTEM OPERATION DIAGRAM

1. Exhaust solenoid valve – 2. Electrical motor control relay – 3. Intake filter – 4. RH chassis control solenoid valve – 5. LH chassis control solenoid valve – 6. Compressor – 7. Dryer filter – 8. Compressor control electrical motor – 9. Electrical connector

VB TECHNIK PNEUMATIC SUSPENSIONS

The system illustrated is used in the following vehicles:
65C – 60C – 50C

Figure 312




004282t

OPERATION DIAGRAMS

| Pin | Description |
|-----|--|
| 1 | Electronic control unit |
| 2 | Manual mode actuation button |
| 3 | Lowering button |
| 4 | Lifting button |
| 5 | VBT signalling warning light |
| 6 | Tachograph |
| 7 | Electric motor control relays |
| 8 | Discharge solenoid valve (for washing) |
| 9 | Choking valve |
| 10 | Unidirectional discharge valve |
| 11 | Unidirection feed valve |
| 12 | Drier filter |
| 13 | Right-hand air spring |
| 14 | Pneumatic discharge valve |
| 15 | Compressor |
| 16 | Compressor actuation electric motor |
| 17 | Filter |
| 18 | Braking connector |
| 19 | Exhaust silencer |
| 20 | Exhaust solenoid valve |
| 21 | Left-hand air spring |
| 22 | Level sensor |

Vehicles with braking system without ABS

Figure 313




1. VBT warning lamp – 2. Suspension control unit (ECU, pneumatic supply unit) – 3. Chassis lifting switch – 4. Chassis lowering push-button – 5. Manual control button – 6. RH air spring – 7. Level sensor – 8. Pneumatic brake action compensator – 9. Brake action compensator – 10. LH air spring

85725

Vehicles with ABS system

Figure 314



1. VBT warning lamp – 2. Suspension control unit (ECU, pneumatic supply unit) – 3. Chassis lifting switch – 4. Chassis lowering push-button – 5. Manual control button – 6. RH air spring – 7. Level sensor – 8. LH air spring

85724

SYSTEM COMPONENTS

Electronic Control Unit (35C – 40C – 45C)

The electronic control unit controls different chassis positions in accordance with the driver's requests.


As the ignition key switch is turned to ON position, the electronic central unit runs a system check while the red warning lamp on the dashboard panel comes on for about 5 seconds.

If no failures are detected, this warning lamp shall turn off, otherwise an automatic blink code shall be started with the following meaning:

| | | |
|---------------|---|--|
| Slow blinking | – | Electric compressor overload due to prolonged manual actuation. |
| Fast blinking | – | Electric compressor overload |
| Fixed on | – | Level sensor cable |
| Off | – | Supply failure |
| Dimmed light | – | Wrong button operation (simultaneous action) or button connecting cabling failure. |


The control unit is fitted with a warning led "1" connected to the warning lamp on the dashboard panel, and a set of five connectors "2" of which only 1, 3 and 5 are used.

Figure 315



000373t


| Connector | Pin | Function | Cable colour |
|-----------|-----|--|--------------|
| 1 | 1 | Signal from level sensor | White |
| | 2 | Signal from level sensor | Brown |
| | 3 | Positive from level sensor | Yellow |
| | 4 | Negative from level sensor | Green |
| | 5 | – | – |
| | 6 | – | – |
| 3 | 1 | Signal from lifting switch | Grey |
| | 2 | Negative for trim variators | Green |
| | 3 | Signal from lowering switch | Brown |
| | 4 | Negative for failure warning light | Yellow |
| | 5 | Key-controlled positive | Pink |
| | 6 | Signal from handbrake switch | White |
| 5 | 1 | Electric compressor control remote-control switch positive | White |
| | 2 | Discharge solenoid valve control positive | Yellow |
| | 3 | Positive from battery | Red |
| | 4 | Negative from battery | Black |
| | 5 | – | – |
| | 6 | – | – |

Electronic control unit (60C – 65C – 50C)**Figure 316**

004283t

| Pin | Cable colour | Function |
|-----|--------------|---------------------------------------|
| 1 | Pink | +15 |
| 2 | Yellow | Warning light bulb |
| 3 | Green | Button negative |
| 4 | White | Signal from handbrake |
| 5 | Brown | Lowering button |
| 6 | Grey | Lifting button |
| 7 | – | Free |
| 8 | – | Free |
| 9 | – | Free |
| 10 | – | Free |
| 11 | – | Free |
| 12 | Black | Tachograph |
| 13 | White | Signal from level sensor for lifting |
| 14 | Brown | Signal from level sensor for lowering |
| 15 | Yellow | Positive for level sensor |
| 16 | Green | Negative for level sensor |
| 17 | Green | Earth |
| 18 | Pink | +30 |
| 19 | Brown | Discharge solenoid valve control |
| 20 | Grey | Compressor relay 2 control |
| 21 | Yellow | Discharge solenoid valve control |
| 22 | White | Compressor relay 2 control |



Figure 317



000374t

LEVEL SENSOR

Figure 318



000375t

PNEUMATIC SUPPLY UNIT

Level sensor

In accordance to the chassis height from floor, the level sensor shown sends the signals to start chassis leveling to the ECU.

It is connected to the control unit by means of four cables:

- White: Lifting signal
- Brown: Lowering signal
- Yellow: Positive
- Green: Negative

Pneumatic supply unit

The function of this component is that of distributing or discharging suspension spring air.

Shows the connection of its internal components of the supply unit..

Components of the pneumatic supply unit

- 1 - Air spring relief solenoid valve
- 2 - Dryer filter
- 3 - Compressor
- 4 - Supply filter
- 5 - Electrical motor
- 6 - Relief pneumatic valve
- 7 - Muffler


Brake action compensator

Those vehicles not equipped with ABS / EBS / ABD require the installation of a system providing better braking action on the rear wheels. This system includes an dual brake action compensator and a brake action compensator pneumatic actuator.

Depending on the load applied on the rear axle, as detected by the pneumatic actuator, the brake action compensator automatically adjust the braking torque applied to the axle by the brakes.

The correction ratio is calibrated at 0.25.

Figure 319



000376t

BRAKE ACTION COMPENSATION UNIT

1. Brake action compensator – 2. Pneumatic actuator for brake action compensator

ROTATING SLIDING DOOR

Description


The rotating sliding door consists of:

- Complete panel and door compartment frame

This aluminum extruded profile guarantees a rigid bearing structure to support all system components such as:

- access step;
- moving hinge;
- seals;
- two locks;
- the electronic center;
- door panel front lock pins;
- extension arm;
- compressed air sensitive edge (bus version only);
- motor unit.

Figure 320



73726

ROTATING SLIDING DOOR

SYSTEM COMPONENTS

Electronic center

The electronic center is located under the access step.


In addition to the motor reduction gear control, it also features a series of vehicle and door system communication inputs and outputs. A tachometer signal reading system for the following purposes is provided to prevent the door from being opened with the vehicle moving:

- to prevent the door from opening when the vehicle travels at over 5 Km/h;
- to generate a buzzer when the vehicle is moving and the door is open;
- for the absence of a tachometer signal involving the possibility of the door opening (after push button actuation) with the vehicle moving.

Electrical features

| | |
|-----------------------|---------------|
| Power | 12V dc |
| Stand-by absorption | 20 ÷ 30 mA |
| Operating absorption | 3.5 ÷ 5 mA |
| Operating temperature | -30°C ÷ +60°C |

Figure 321




73741

ECU LOCATION

Electronic center pin-out

| Pin | Description |
|-----|---|
| 1A | Free |
| 2A | Free |
| 3A | Tachometer signal |
| 4A | Open open/close push button |
| 5A | Centralized opening remote control input |
| 6A | Centralized opening remote control input |
| 7A | Free |
| 8A | Positive from battery |
| 1B | Free |
| 2B | Free |
| 3B | Positive input from key switch |
| 4B | Door open warning output |
| 5B | External emergency lock closed warning output |
| 6B | Door defect warning output |
| 7B | Free |
| 8B | Negative from battery |
| 1C | Free |
| 2C | Free |
| 3C | Free |
| 4C | Free |
| 5C | Free |
| 6C | Free |
| 7C | Ceiling light control output |
| 8C | Free |

Figure 322



73740


ECU LOCATION

Optical and sound warnings

Component location on instrument panel:

1. Door open warning light.
2. Emergency handle lock (yellow warning light).
3. Emergency handle lock activated (bus yellow warning light).
4. Door open/close control push button.


Figure 323



72609

COMPONENT LOCATION ON INSTRUMENT PANEL

Figure 324



73739

BUZZER

Sound device

This electronic center piloted device warns users of special operating conditions, such as the vehicle moving with the door open, for instance.

Description and operation

The open/close control is only activated with the vehicle moving, via the instrument panel push button.

If the vehicle is provided with a centralized closing system, door opening can be activated even with the vehicle stationary. In this case, opening and closing must be limited to prevent discharging the vehicle battery.

Opening with the instrument panel push button

The operator controls automatic door opening by actuating the instrument panel push button.

Pressing the push button sends an electrical impulse required for mechanical electro magnetic induced lock release.

At release end, the lock on travel end warning loses the signal and starts the motor reduction gear that makes the door panel rotate open and given visual warning of door open, with a warning light on the instrument panel.

Opening end is with the Complete Opening micro switch.

During door opening, a cam located on the lower part of the hinge and solidal with motor reduction gear rotation lowers the access step to its use position.

Closing with the instrument panel push button

The operator controls automatic door closing by actuating the instrument panel push button.

Pressing the push button sends an electrical impulse to the motor reduction gear that completes its closing travel.

During closing a double obstacle detection system operating on motor ammeter measurement and adjustable via a timer on the center is activated, another one is located on the compressed air sensitive edge of the two door compartment uprights.

Near door close a position reading sent to the tachometer on the door control motor disengages the ammeter controlled sensitive edge to enable otherwise impossible door closing.

The compressed air sensitive edge is activated until receipt of door closed micro switch signal, which activates a signal switching all center functions off.

When closing, the door enables rotation of the mobile step to its rest position with a return spring.

If the vehicle moves with the door open, its closing can be controlled with the push button even at speeds over 5 Km/h, in which case the buzzer remains active (inclusive of the door open warning light) until complete door closing.

Opening/closing with the remote control

The open/close control extends to all vehicle doors including the rotating sliding one.

Movement inversion

After door open/close push button actuation, in whatever position it may be, actuating the push button generates its controlled movement inversion.

Obstacle detection system

The system features motor ammeter control capable of detecting peaks of voltage and of the compressed air sensitive edge located on the front and back of the door compartment, for obstacle detection.

If an obstacle counters door panel movement during closing, over 150N force of compressed air transducer activation opens it.

If an obstacle counters door panel movement during opening, over 150N force of compressed air transducer activation closes it.

Since the door is equipped with the anti-squash function, reading the nearly closed door status signal generated by the motor encoder automatically cuts out this function to enable complete door closing.

Emergency operation

The door can be opened in case of system failure or power down by using the emergency lever from the inside of the lock close to the door panel from the outside.

In case of emergency operation, automatic door opening or closing is disabled until the system is restarted manually.

The outside emergency lock is provided with a key that can be used to secure the vehicle (Figure 325).

An internal buzzer is actuated if the starter switch is actuated in the service position with external opening emergency locked with the key.


Diagnosis

The system reports a failure when the failure warning light goes on.

This failure can be due to the following causes:

- Closing does not occur a maximum of ~20 sec after actuation
 - Possible causes:
 - Door open micro switch warning failed.
 - Electrical cabling cut.
- Over voltage when opening or closing
 - Possible causes:
 - Motor short circuit
- Door opening/closing travel abnormal.
 - Possible causes:
 - Motor encoder signals not recognized.
- Door does not open.
 - Possible causes:
 - Tachometer signal detective or down.


Figure 325



73720

EXTERNAL EMERGENCY OPENING


Figure 326



73718


STEP LIGHT

Figure 327




73718


1. Light – 2. Emergency openings

Description of opening

Description of closing cycle




Operating diagram




N.B.: As a consequence of use by IVECO of passive type door locks, disconnected operation may occur between operator and rotating sliding door opening and closing.

Figure 328




LOWER DASHBOARD SNAP-FITTED PANEL

Figure 329



LOWER PANEL FASTENING SCREWS

Figure 330



LOWER PANEL FASTENING SCREWS

ELECTRONIC TACHOGRAPH

Removing the lower dashboard cover


- Remove the snap-fitted panel (Ref. A) to gain access to the panel fastening screws (Ref. B).
- Slacken the 4 fastening screws, two on either side, of the lower panel (Ref. A).

Electronic tachograph control unit housing assembly

Fasten the control unit to the support, insert the 3 connectors, eliminating the bridges between the connectors (white, yellow and brown) and apply the seals (ref. A).



Figure 331



CONNECTIONS AND TACHOGRAPH CONTROL UNIT SUPPORT

Assembling the tachograph control unit support on the dashboard

Use the six screws to fasten the tachograph control unit support to the dashboard.

Figure 333




Figure 334




Figure 332






Figure 335



8787

UPPER TRIM FASTENING SCREW


Figure 336



8788

UPPER TRIM FASTENING SCREW

Figure 337



8789


UPPER TRIM FASTENING SCREW

Removing the instrument cluster module

To replace the module, proceed as follows:

1. Remove the upper trim working on the three screws shown by the arrows.
2. Lift and remove the trim taking care not to damage the velcro stoppers.


Figure 338



8790

TRIM REMOVAL

Figure 339



8791


INSTRUMENT CLUSTER

Work on the 4 screws, 2 on either side, to remove the cluster module with tachometer.

Disconnect the electrical connections and replace with the module for tachograph sealing the electrical connections concerning the wiring for tachograph.

Fasten the instrument cluster to the dashboard and refit the upper and lower trim.


Figure 340



8795

COMPLETE INSTRUMENT CLUSTER


Figure 341



8792

INSTRUMENT CLUSTER FASTENING


Figure 342



8793

REMOVING THE INSTRUMENT CLUSTER


Figure 343



8794

CONNECTIONS CONCERNING WIRING FOR TACHOGRAPH


Figure 344



8796

SENSOR REPLACEMENT ON GEARBOX


Figure 345



8797

CONNECTION OF SENSOR TO WIRING

Figure 346



8798

SENSOR TECHNICAL VIEW

Operations on gearbox

1. Replace the sensor on the gearbox with a suitable one for tachograph.
2. Seal with lead the electrical connection to the sensor and to the gearbox body.


If necessary, drill (4 mm) the ribbing on the gearbox (see arrow) for passing the wire.

Operation in bonnet

1. Disconnect the terminals of the power cables from the battery terminals.
2. Remove the battery from the engine compartment, after removing the fastening bracket.
3. Seal the connector between the frame and cab/bonnet cables with sealing wire.

4. Refit the battery, re-connect the terminals to the battery terminals, ensuring correct polarity and calibrate the tachograph using the special VDO tool.
5. In the front part, seal the tachograph control unit with the special red plug as shown.
6. Apply the labels; on the driver's door and on the tilting plate of the tachograph control unit.


Figure 347



8799

CONNECTOR BETWEEN CAB/BONNET AND FRAME CABLES

Figure 348



8800

FRONT VIEW OF TACHOGRAPH CONTROL UNIT

Circuit charts

| | Page |
|--|------|
| CIRCUIT CHARTS | 295 |
| NOTES AND SPECIFICATIONS | 295 |
| CHART 1A: START | 296 |
| CHART 1B: START (.10 – .12) | 297 |
| CHART 2A: PREHEATING (.9) | 298 |
| CHART 2B: PREHEATING (.11) | 299 |
| CHART 2C: PREHEATING (.13 – .15) | 300 |
| CHART 2D: PREHEATING (.10 – .12) | 301 |
| CHART 2E: PRE-HEATING (.10 – .12 – .14 – .17 – EDC16) | 302 |
| CHART 3: RECHARGE | 303 |
| CHART 4: INSTRUMENTS | 304 |
| CHART 5: TACHOMETER | 305 |
| CHART 6A: RPM COUNTER (.9) | 306 |
| CHART 6B: RPM COUNTER (.11) | 307 |
| CHART 6C: RPM COUNTER (.10 – .12 – .13 – .15) | 308 |
| CHART 6D: RPM COUNTER (.10 – .12 – .14 – .17 – EDC16) | 309 |
| CHART 7A: OPTICAL INDICATORS (.9 – .11) | 310 |
| CHART 7B: OPTICAL INDICATORS | 311 |
| CHART 8: OUTSIDE LIGHTING (CAB INSTRUMENTS) | 312 |
| CHART 9A: OUTSIDE LIGHTING (POSITION LIGHTS) | 313 |
| CHART 9B: OUTSIDE LIGHTING (CAB POSITION LIGHTS VAN) | 314 |
| CHART 10: FLOOD AND DIPPED LIGHTS .. | 315 |
| CHART 11A: BACK AND FRONT FOG LIGHTS | 316 |
| CHART 11B: BACK AND FRONT FOG LIGHTS (VAN) | 317 |

| | Page | | Page | | | | |
|------------|--|-------|------|------------|---|-------|-----|
| CHART 12: | FRONT LIGHT SETTING | | 318 | CHART 23B: | ENGINE COOLING (.11) | | 341 |
| CHART 13A: | DIRECTION AND EMERGENCY LIGHTS | | 319 | CHART 23C: | ENGINE COOLING (.13-.15) | ... | 342 |
| CHART 13B: | DIRECTION AND EMERGENCY LIGHTS (VAN) | | 320 | CHART 23D: | ENGINE COOLING (.10-.12) | .. | 343 |
| CHART 14A: | STOP LIGHTS | | 321 | CHART 23E: | ENGINE COOLING (.10-.12-.14-.17-EDC16) | | 344 |
| CHART 14B: | STOP LIGHTS (VAN) | | 322 | CHART 24A: | EGR/EXHAUST GAS ELECTRONIC CONTROL SYSTEM (.9) | | 345 |
| CHART 15A: | BACKUP LIGHTS | | 323 | CHART 24B: | EGR/EXHAUST GAS ELECTRONIC CONTROL SYSTEM FOR EDC (.13) | | 346 |
| CHART 15B: | BACKUP LIGHTS (VAN) | | 324 | CHART 24C: | EGR/EXHAUST GAS ELECTRONIC CONTROL SYSTEM FOR EDC (.10-.12) | | 347 |
| CHART 16: | HORN | | 325 | CHART 24D: | EGR EXHAUST GAS ELECTRONIC CONTROL SYSTEM FOR EDC (.10-.12-.14-.17-EDC16) | .. | 348 |
| CHART 17: | WINDSCREEN AND FRONT LIGHT WASHER | | 326 | CHART 25A: | SPARK LEAD VARIATOR (.9) | | 349 |
| CHART 18A: | WINDSCREEN DEFROSTER | | 327 | CHART 25B: | SPARK LEAD VARIATOR (.11) | ... | 350 |
| CHART 18B: | WINDSCREEN DEFROSTER (.10-.12) | | 328 | CHART 26A: | E.D.C. (.13) | | 351 |
| CHART 19: | RADIO SET | | 329 | CHART 26B: | E.D.C. WITH VGT (.15) | | 352 |
| CHART 20A: | INTERNAL LIGHTING AND CIGARETTE LIGHTER | | 330 | CHART 26C: | E.D.C. WITH WASTE GATE (.13) | | 353 |
| CHART 20B: | INTERNAL LIGHTING (VAN) | ... | 331 | CHART 26D: | E.D.C. WITHOUT EGR (.10-.12) | | 354 |
| CHART 20C: | INTERNAL LIGHTING 6+1 VEHICLE | | 332 | CHART 26E: | E.D.C. WITHOUT EGR (.10-.12-.14-.17-EDC16) | | 355 |
| CHART 20D: | INTERNAL LIGHTING AND CIGARETTE LIGHTER (FIA) | | 333 | CHART 27A: | HEATED FUEL FILTER (.9-.11) / OPT 2287 | | 356 |
| CHART 21A: | IMMOBILIZER (.9) | | 334 | CHART 27B: | HEATED FUEL FILTER (.13-.15) | . | 357 |
| CHART 21B: | IMMOBILIZER (.11) | | 335 | CHART 27C: | HEATED FUEL FILTER (.10-.12) | . | 358 |
| CHART 21C: | IMMOBILIZER (.10-.12-.13-.15) | | 336 | CHART 27D: | HEATED FUEL FILTER (.10-.12-.14-.17-EDC16) | | 359 |
| CHART 21D: | IMMOBILIZER (.10-.12-.14-.17-EDC16) | | 337 | CHART 28A: | POWER WINDOW OPERATOR AND PASSENGER SIDE / OPT 693 | | 360 |
| CHART 22A: | DIAGNOSIS CONNECTION (.9-.11) | | 338 | CHART 28B: | POWER WINDOW OPERATOR SIDE / OPT 4028 | | 361 |
| CHART 22B: | DIAGNOSIS CONNECTION (.10-.12-.13-.15-.14-.17) | | 339 | CHART 28C: | POWER WINDOW OPERATOR AND PASSENGER SIDE (.10-.12) | | 362 |
| CHART 23A: | ENGINE COOLING (.9) | | 340 | | | | |

| | Page | | Page | | |
|------------|---|-----|------------|--|-----|
| CHART 29: | HEATED REARVIEW MIRRORS / OPT 697 | 363 | CHART 39B: | REAR DIFFERENTIAL LOCK / OPT 131 | 383 |
| CHART 30: | REARVIEW MIRROR ADJUSTMENT / OPT 2714 | 364 | CHART 40: | 13-POLE POWER CONNECTION / OPT 6520 | 384 |
| CHART 31: | HEATED WINDSCREEN / OPT 685 | 365 | CHART 41A: | TOTAL PTO (.9 - .11) | 385 |
| CHART 32: | HEATED REAR WINDOW / OPT 6815 | 366 | CHART 41B: | TOTAL PTO (.10 - .12 - .13 - .15) | 386 |
| CHART 33: | ABS/EBD/ABD / OPT 2091 | 367 | CHART 41C: | TOTAL PTO (EDC 16) | 387 |
| CHART 34A: | E.C.A.S. WITHOUT RESERVE AIR RESERVOIR (.9-.10-.11-.12-.13-.14- .17) | 368 | CHART 42A: | HEATED OPERATOR SEAT BUS VERSION / OPT 6628 | 388 |
| CHART 34B: | E.C.A.S. WITH RESERVE AIR RESERVOIR (.9-.10-.11-.12-.13-.14-.17) | 369 | CHART 42B: | HEATED SEATS / OPT 6644 | 389 |
| CHART 34C: | VB TECHNIK (35C - 40C - 45C) | 370 | CHART 43: | DAY LIGHTS FOR NORTHERN EUROPE VEHICLES / OPT 2536 . | 390 |
| CHART 34D: | VB TECHNIK (60C - 65C - 50C) | 371 | CHART 44: | DOOR LOCK / OPT 6536 | 391 |
| CHART 35A: | AUTOMATIC CONDITIONER (.9) / OPT 6650 | 372 | CHART 45A: | TELMA SCUDATI RETARDER (.9 - .11) / OPT 235 | 392 |
| CHART 35B: | AUTOMATIC CONDITIONER (.11) / OPT 6650 | 373 | CHART 45B: | TELMA RETARDER (.10 - .12 - .13 - .15) / OPT 235 | 393 |
| CHART 35C: | AUTOMATIC CONDITIONER (.13-.15) / OPT 6650 | 374 | CHART 46: | ELECTRICAL BATTERY SECTIONER / OPT 2532 | 394 |
| CHART 35D: | AUTOMATIC CONDITIONER (.9 - .10 - .11 - .12 - .13 - .14 - .15 - .17) / OPT 6650 | 375 | CHART 47A: | CRUISE CONTROL | 395 |
| CHART 35E: | AUTOMATIC CONDITIONER (.10 - .12) / OPT 6650 | 376 | CHART 47B: | CRUISE CONTROL (EDC 16) ... | 396 |
| CHART 35F: | AUTOMATIC AIR CONDITIONING (.10 - .12 - .14 - .17 - EDC16) | 377 | CHART 48: | ENGINE WATER HEATER / OPT 6654 | 397 |
| CHART 36: | ELECTRONIC TACHOGRAPH / OPT 5130 - 5131 | 378 | CHART 49: | ELECTRICAL CONTROL SLIDING SIDE DOOR | 398 |
| CHART 37A: | AIR BAG AND PRE-TENSIONERS / OPT 4495 - 4496 | 379 | CHART 50: | ROTATING SLIDING DOOR ... | 399 |
| CHART 37B: | AIR BAG AND PRETENSIONERS | 380 | CHART 51: | ELECTRICAL PIT ON PAVILION / OPT 640 | 400 |
| CHART 38: | DOOR LOCK WITH ANTI-THEFT / OPT 6890 | 381 | CHART 52: | SCUDATI CENTRAL EMERGENCY CONTROL / OPT 2546 | 401 |
| CHART 39A: | FRONT DIFFERENTIAL LOCK / OPT 131 | 382 | CHART 53: | SYSTEM FOR NORTH AFRICA VEHICLES | 402 |
| | | | CHART 54: | SYSTEM FOR BUS VEHICLES WITH 2-TONE HORN | 403 |
| | | | CHART 55: | SYSTEM FOR RIGHT HAND DRIVE ROTATING SLIDING DOOR VEHICLES | 404 |

Page

CHART 56: ABS 8 405

CHART 57: ESP8 406

CHART 58: 6 AS 300 VD AUTOMATIC
GEARBOX 407

CIRCUIT CHARTS

Notes and specifications

Unless otherwise specified the charts are to be considered valid for all engines and for all truck and van versions.

The vehicle conditions considered for laying wiring circuitries are:

- engine off
- ignition key off
- handbrake on
- gearbox in neutral
- fluids at normal level
- doors closed

The relays used have an internal resistance (in parallel with the coil) of 680 Ω to reduce over-voltage on the system due to switching of the switches.

In charts 22 A–B the component distinguished by the symbol \times is the socket for the converter.

In chart 33 the connection distinguished by the symbol \blacktriangle is valid only for vehicles with "parallel" braking system.

In chart 34B the component distinguished by the symbol Δ is present only on vehicles with reserve air tank.

Chart 38 shows a van with sliding side doors.


Component codes concerning chart 35D (82010A/B/C connectors – for all tables)

- 1 Sensor on evaporator
- 2 Fan motor
- 3 Fan electronic control module
- 4 Air mixing gear motor
- 5 Re-circulation gear motor
- 6 Electronic climate control unit (82010)
- 7 Treated air sensor
- 8 Fan control potentiometer
- 9 Required temperature potentiometer
- 10 Climate control module
- 11 Microswitch for MAX DEF function
- 12 Control panel lighting

Colour codes for cabling not supplied by IVECO


| Code | Colour | Code | Colour |
|------|------------|------|--------|
| A | Light Blue | M | Brown |
| B | White | N | Black |
| C | Orange | R | Red |
| G | Yellow | S | Rose |
| H | Grey | V | Green |
| L | Blue | Z | Purple |

Chart IA: Start




49949

Chart 2A: Preheating (.9)




49948

Chart 2C: Preheating (.13 - .15)




49946

Chart 2D: Preheating (.10 - .12)




74257

Chart 3: Recharge




49945

Chart 4: Instruments




49944

Chart 6B: Rpm counter (.11)




49941

Chart 7A: Optical indicators (.9 - .11)




49939

Chart 7B: Optical indicators




49938

Chart 8: Outside lighting (cab instruments)




49937

Chart 9A: Outside lighting (position lights)




49936

Chart I0: Flood and dipped lights




49934

Chart 11A: Back and front fog lights




49933

Chart I I B: Back and front fog lights(van)




49932

Chart I2: Front light setting




49931

Chart I3A: Direction and emergency lights




49930

Chart I3B: Direction and emergency lights (van)




49929

Chart 14A: Stop lights




49928

Chart I4B: Stop lights (van)




49927

Chart 15A: Backup lights




49926

Chart I5B: Backup lights (van)




49925

Chart 16: Horn




49924

Chart 17: Windscreen and front light washer




49923

Chart 18A: Windscreen defroster




49922

Chart I8B: Windscreen defroster (.10 - .12)




74258

Chart 19: Radio set




49921

Chart 20A: Internal lighting and cigarette lighter



49920

Chart 20B: Internal lighting (van)



49919

Chart 20C: Internal lighting 6+1 vehicle






Chart 20D: Internal lighting and cigarette lighter (FIA)




74259

Chart 21A: Immobilizer (.9)




49917

Chart 21B: Immobilizer (.11)




49916

Chart 21C: Immobilizer (.10 - .12 - .13 - .15)




49915

Chart 21D: Immobilizer (.10-.12-.14 - .17 EDC16)




65106

Chart 22A: Diagnosis connection (.9 - .11)




49914

Chart 22B: Diagnosis connection (.10-.12-.13-.15-.14-.17)




85719

Chart 23B: Engine cooling (.11)




49911

Chart 23D: Engine cooling (.10 - .12)




74260

Chart 23E: Engine cooling (.10 - .12 - .14 - .17 - EDC16)




85717

Chart 24A: EGR/exhaust gas electronic control system (.9)




49909

Chart 24B: EGR/exhaust gas electronic control system for EDC (.13)




49908

Chart 24C: EGR/exhaust gas electronic control system for EDC (.10 - .12)




74261

Chart 25B: Spark lead variator (.11)




49906

Chart 26A: E.D.C. (.13)




49905

Chart 26B: E.D.C. with VGT (.15)




49904

Chart 26C: E.D.C. with WASTE GATE (.13)




49903

Chart 26D: E.D.C. without EGR (.10 - .12)




74262

Chart 27B: Heated fuel filter (.13 - .15)




49901

Chart 27D: Heated fuel filter (.10 - .12 - .14 - .17 - EDC16)




85720

Chart 28A: Power window operator and passenger side / OPT 693




49900

Chart 28B: Power window operator side / OPT 4028




49899

Chart 28C: Power window operator and passenger side (.10 - .12)




74264

Chart 30: Rearview mirror adjustment / OPT 2714




49897

Chart 31: Heated windscreen / OPT 685




49896

Chart 32: Heated rear window / OPT 6815




49895

Chart 33: ABS/EBD/ABD / OPT 209I




49894

Chart 34A: E.C.A.S. without reserve air reservoir (.9-.10-.11-.12-.13-.14-.17)




49893

Chart 34B: E.C.A.S. with reserve air reservoir (.9-.10-.11-.12-.13-.14-.17)




49892

Chart 34C: Vb Technik (35C - 40C - 45C)




86165

Chart 34D: Vb Technik (60C - 65C - 50C)




86196

Chart 35A: Automatic conditioner (.9) / OPT 6650




49890

Chart 35B: Automatic conditioner (.11) / OPT 6650




49889

Chart 35C: Automatic conditioner (.13-.15) / OPT 6650




49888

Chart 35E: Automatic conditioner (.10 - .12) / OPT 6650




74265

Chart 35F: Automatic air conditioning (.10 - .12 - .14 - .17 - EDC16)




85721

Chart 36: Electronic tachograph / OPT 5130 – 5131




49886

Chart 37A: Air bag and pre-tensioners / OPT 4495 - 4496




49885

Chart 39A: Front differential lock / OPT 131




49882

Chart 39B: Rear differential lock / OPT 131




49881

Chart 41A: Total PTO (.9 - .11)




49879

Chart 41C: Total PTO (EDC 16)




60190

Chart 42A: Heated operator seat bus version / OPT 6628




49877

Chart 42B: Heated seats / OPT 6644




49876

Chart 45A: Telma Scudati retarder (.9 - .11) / OPT 235




49873

Chart 45B: Telma retarder (.10 - .12 - .13 - .15) / OPT 235




49872

Chart 47A: Cruise Control




49870

Chart 47B: Cruise Control (EDC 16)




90162

Chart 49: Electrical control sliding side door




49868

Chart 50: Rotating sliding door




49867

Chart 51: Electrical pit on pavilion / OPT 640




49866

Chart 52: Scudati central emergency control / OPT 2546




49865

Chart 53: System for North Africa vehicles




49864

Chart 54: System for bus vehicles with 2-tone horn




49863

Chart 56: ABS 8




101883

Chart 57: ESP8



101884

Card 58: 6 AS 300 VD automatic gearbox



101885

