

# Important Service Bulletin

07/2005 GB

- Workshop consulting  Trade partners
- Quality engineering  Workshop-partners



## Shock absorbers: MB-Sprinter / VW-LT – Rear axle

32-H60-0 / 32-H61-0 / 32-H62-0 / 32-H63-0 / 32-H81-0 / 32-B71-0

Shock absorbers are available for vehicles of these ranges in 3 different lengths and in corresponding reinforced versions.

The part Nos. can be seen on the protective covers.

**If the shock absorbers can no longer be reliably identified by means of the external marking, then the following overview will help you.**



Part No. BOGE	Length extended compressed	Length	OE Part Numbers	
32-H60-0	524mm 324mm	<b>L1</b>	MB	901 320... 00 31 / 02 31 / 04 31 / 06 31 / 07 31
			VW	2D0 513 029_ / A / F / P
32-H61-0	524mm 324mm		MB	903 320 01 31 reinforced design / recreational vehicles
32-H63-0	524mm 324mm		VW	2D0 513 029 D / J / Q for reinforced chassis
32-H62-0	549mm 349mm	<b>L2</b>	MB	901 320 08 31
32-H81-0	515mm 325mm	<b>L3</b>	MB	904 320 03 31 for recreational vehicles
32-B71-0	515mm 325mm		MB	904 320 01 31 / 02 31, 904 326 01 00
			VW	2D0 513 029 C / M / N