

16:04-56

Edition 1

EDC MS6.2

Enhetsinsprutare

Unit Injector

Pumpe-Düse-Einheit

Eenheidsverstuivers



Unité injecteur complet

Inyectoras-bomba

Injector de unidade

Unità iniettori pompanti

Ruiskutinyksikko



Colour code of electric cables		Bulb tabular	
Code	Colour	Code	Type
BK	Black	A	W2, 1x5, 5x24V-2V
BN	Brown	B	BA9x-24V-2V
RD	Red	C	BA15x-24V-15V
OG	Orange	D	5x8, 5-24V-5V L-39
YE	Yellow	E	BA15x-24V-10V
GN	Green	G	24V-1, 2V
BU	Blue	H	BA15x-24V-21V
VT	Violet	K	PA31-24V-15/10w H4
GY	Grey	L	PA51-24V-55/50w B11x
WH	White	M	W2x4, 6x-24V-1, 2V
PK	Pink	N	BA7x-24V-3V
		P	PM22x-24V-70V H3
		R	BA15x-24V-21V

Des.	Pos.	Description
B25	D8	Switch
B26	D8	1x1xk-down
B34	E8	brake pedal
C2	A6	17-pole
C23	F8	Connector
C55	B6	Connection bl
C56	E6	Junction block
C61	E8	3-pole
C107	D6	5-pole
C114	D6	3x6-pole
C188	B6	17-pole
C189	D8	2-pole
C190	D8	3-pole
C240	E4	Joining sleeve
C431	E4	1-pole
D18	F6	Diode unit
D35	D8	Potentiometer throttle pedal sensor
E12	D4	Control unit EDC
G4	E8	Ground instr panel
G13	C6	Ground front plate
O4	E8	Tachograph
P2	F6	Central electric unit
R34	F6	Relay supply EDC
S51	F8	Switch cruise control
S52	F8	Switch diagnostics
T33	D2	Sensor coolant temperature
T47	C2	Sensor charger pressure/temp.
T74	C2	Sensor engine speed
T75	C2	Sensor engine speed 2
V14	E2	Solenoid valve cylinder 5
V15	E2	Solenoid valve cylinder 6
V16	E2	Solenoid valve cylinder 4
V26	E2	Solenoid valve cylinder 3
V27	D2	Solenoid valve cylinder 2
V28	D2	Solenoid valve cylinder 1
W27	E8	Control lamp Diagnostics

1) See wiring diagram standard equipment
2) See wiring diagram Opticruise

1403620

5251019