

16:12-01/1

Utgåva/Issue/Ausgabe/Uitgave/Edición/Edición/Edizione/Painos 1

Grundelsystem Komponentlista

Basic electrical system, list of components

Basis-Elektroanlage Komponentenverzeichnis

Elektrisch basissysteem Componentenlijst

Sistema eléctrico básico: Lista de componentes

Système électrique de base Liste des composants

Impianto elettrico di base Elenco delle componenti

Perussähköjärjestelmä Osaluettelo

Sistema eléctrico básico, lista de componentes

Podstawowy układ elektryczny lista części


Fordon tillverkade efter 0002
Vehicles manufactured after 0002
Fahrzeug gebaut nach 0002
Na 0200 gefabriceerde voertuigen
Vehículos fabricados después de 0002
Véhicules fabriqués après 0002
Veicoli realizzati dopo il 02/00
0002 jälkeen valmistetut ajoneuvot
Pojazdy produkowane po 0002
Veículos fabricados após 0002

Des.	Sheet	Pos.	Description
B1	2	C8	stop light
B6	2	A8	door
B7	2	C1	l hand
B23	2	A5	r hand
B25	2	B8	Switch
B32	2	C8	luggage box
B33	2	A4	luggage box
B33	2	A4	luggage box
C1	2.4	E8, E6	17-pole
C2	2.4	F1, F5	12-pole
C3	5	E3	2-pole
C4	5	B8	3x6-pole
C5	4	F5	2-pole
C6	2.4	E1, D5	2-pole
C7	4	F6	17-pole
C8	2.4	D1, C5	12-pole
C9	2.4	C1, B5	5-pole
C11	5	F5	9-pole
C12	2	C5	12-pole
C13	2.5	F2, F1	12-pole
C14	2.4	B6, B6	17-pole
C15	2.4	D8, D6	3-pole
C18	2.4	A8, A6	2-pole
C19	4	A7	2-pole
C20	5	B5	9-pole
C21	4	B2	2-pole
C22	2	C5	9-pole
C23	2	B5	3-pole
C24	2	D5	12-pole
C25	2.4	B1, B5	2-pole
C26	2	C5	2-pole
C28	2	D5	3-pole
C29	4	B7	6-pole
C30	4	A7	2-pole
C31	4	C2	3-pole
C32	4	C2	2-pole
C40	2	F3	3-pole
C44	4	F4	15-pole
C47	2	C8	5-pole
C48	2	C8	5-pole
C50	4	C4	1-pole
C51	4	F8	5-pole
C52	4	F2	1-pole
C55	2.4	F1, E5	5-pole
C56	2	C2	5-pole
C59	4	F8	1-pole
C60	4	F2	1-pole
C77	4	D8	1-pole
C89	2	D5	3-pole
C110	4	C2	7-pole, 24N
C111	4	C2	7-pole, 24S
C117	5	F4	1-pole
C118	5	F2	1-pole
C119	5	F4	1-pole
C120	5	E4	1-pole
C125	2	F3	4-pole
C126	4	D4	1-pole
C127	4	D4	1-pole
C129	4	C7	5-pole
C130	4	D2	5-pole
C131	4	B7	5-pole
C132	4	C2	2-pole
C133	4	B7	2-pole
C134	4	C2	9-pole
C135	5	C3	2-pole
C137	5	A6	2-pole
C138	4	A4	12-pole
C139	2.5	F2, F1	12-pole
C140	4	A3	8-pole
C148	5	A8	5-pole
C150	5	D6	2-pole
C151	5	D6	15-pole
C155	4	F4	2-pole
C162	4	B2	2-pole
C164	4	F3	1-pole
C166	4	E3	5-pole
C167	4	E3	2-pole
C175	5	E6	2-pole
C176	5	E1	2-pole
C180	2	D4	8-pole
C181	2	D5	17-pole
C182	5	E6	2-pole
C184	5	F8	8-pole
C185	5	F6	2-pole
C187	5	D1	2-pole
C189	2	B8	1-pole
C198	5	F2	1-pole
C199	5	E2	3-pole
C200	5	E1	5-pole
C204	5	E4	5-pole
C207	5	F7	1-pole
C208	5	F7	1-pole
C209	5	B6	1-pole
C210	5	B6	1-pole
C211	5	B6	1-pole
C212	5	D6	2-pole
C213	5	F7	1-pole
C214	5	A5	5-pole
C215	5	A4	2-pole
C217	5	D8	8-pole
C218	5	D1	8-pole
C222	5	D4	3-pole
C223	5	C4	3-pole
C224	5	D4	3-pole

Des.	Sheet	Pos.	Description
C225	5	C4	3-pole
C226	5	D3	5-pole
C252	5	C3	5-pole
C285	4	F6	2-pole
C286	4	E2	2-pole
C294	4	D8	2-pole
C295	4	D8	2-pole
C338	2	B5	4-pole
C372	4	E4	4-pole
C378	5	E4	1-pole
C379	5	E4	1-pole
C380	5	E4	1-pole
C381	5	E4	1-pole
C382	5	E5	5-pole
C383	5	E8	4-pole
C388	2	E4	4-pole
D1	2	F4	Resistor, fan
D25	5	C2	Light emitting diode
D26	5	C2	Light emitting diode
D33	2	B3	Diode
E4	2	E6	Impulse sensor
E33	5	B8	Radio
E34	5	B8	Voltage divider
E35	5	D8	CB-radio
E38	5	E8	Auxiliary voltage divider
F1	2	C4	Fuse panel
F2	2	B4	Fuse panel
G1	2	A7	instr panel
G2	2	A7	instr panel
G3	2	B7	instr panel
G4	2	B7	instr panel
G5	2	C7	instr panel
G6	2	C7	instr panel
G7	2	C7	instr panel
G8	2	D7	instr panel
G9	2	A3	instr panel
G10	2	E2	instr panel
G11	2	E2	instr panel
G12	2	C4	instr panel
G13	2.4	E1, E5	instr panel
G18	2	B5	instr panel
G20	4	B6	instr panel
G21	4	C6	instr panel
G22	4	C6	instr panel
G26	4	D5	instr panel
G27	4	E4	instr panel
G29	4	D3	instr panel
G30	4	B6	instr panel
G31	4	F3	instr panel
G32	4	D3	instr panel
G33	4	D3	instr panel
G34	4	D3	instr panel
G35	4	D3	instr panel
G37	4	D5	instr panel
G38	4	D5	instr panel
G39	4	D5	instr panel
G40	4	B4	instr panel
G41	4	F3	instr panel
G44	4	D3	instr panel
H1	2	D3	Cigarette lighter
H2	4	C8	El. heated rear view mirror
H3	4	D1	El. heated rear view mirror
H4	4	F6	Air dryer
H9	4	D1	El. heated wide-angle mirror
L1	4	F8	Dipped beam
L2	4	F1	Main beam
L3	4	F8	Main beam
L4	4	F1	Main beam
L5	2	A6	Luggage light
L6	2	A3	Position light
L7	4	F8	Position light
L8	4	F1	Position light
L9	4	F8	Position light
L10	4	F1	Position light
L11	4	E8	Distance light
L12	4	E1	Distance light
L13	4	E8	Distance light
L14	4	E1	Distance light
L15	5	B6	Work light
L16	5	B7	Work light
L17	5	B7	Work light
L18	2	E7	Rotating beacon
L19	5	B2	Symbol lighting
L20	5	B2	Symbol lighting
L21	2	E7	Symbol lighting
L22	2	E7	Symbol lighting
L23	2	D4	Symbol lighting
L25	2	D4	Symbol lighting
L26	2	D4	Symbol lighting
L27	2	D3	Symbol lighting
L29	2	D4	Symbol lighting
L30	2	D3	Symbol lighting
L32	4	A8	Boarding step light
L33	4	B1	Boarding step light
L35	2	E6	Instr lighting
L36	2	A5	Work light fifth wheel
L37	4	A4, A6	Direction indic
L38	4	A3, A4	Direction indic

Des.	Sheet	Pos.	Description
L39	4	A4, A6	Tail light
L40	4	A3, A4	Tail light
L41	4	A4, A6	Stop light
L42	4	A3, A4	Stop light
L43	4	A4, A6	Reverse light
L44	4	A4, A6	Rear fog light
L45	5	F4	End out marker light
L46	5	F3	End out marker light
L51	5	F8	Roof sign lighting
L52	5	A5	Reading lamp
L53	5	A3	Reading lamp
L54	5	A5	General lighting
L55	5	A3	General lighting
L56	5	D7	Bed lamp
L57	5	B2	Symbol lighting switch
L58	5	D7	Bed lamp
L59	5	C2	Reading lamp
L61	5	E7	Reading lamp
L62	5	E1	Reading lamp
L63	5	F4	Distance light
L64	5	F3	Distance light
L65	5	F8	Rotating beacon
L66	5	E1	Bed-head lamp
L84	5	F5	ID-light
L85	5	F3	Reverse light
L86	5	F2	Reverse light
L91	4	A3, A4	Rear fog light
L92	4	A3, A4	Rear fog light
L93	4	A6, A4	End out marker light
L94	4	A4, A3	End out marker light
L95	4	A6, A4	Number plate lighting
M1	4	D4	Starter motor
M2	2	F4	Windscreen wiper motor
M3	2	F4	Fan motor
M5	4	E8	Head lamp wiper motor
M6	4	E1	Windscreen washer motor
M7	4	E6	Windscreen washer motor
M8	4	E6	Head lamp washer motor
M9	4	B8	Motor el window winders
M10	4	C1	Motor el roof hatch
M12	5	F8	Motor el roof hatch
M13	4	C8	Motor el adjust rear mirror
M14	4	D1	Motor el adjust rear mirror
M21	4	F8	Motor light level control
M22	4	F1	Motor light level control
N1	3	F3	Buzzer
N2	4	F6	Signal horn
N3	5	C8	Loud speaker
N4	5	C8	Loud speaker
N5	5	D8	Loud speaker
N6	5	C8	Loud speaker
N7	5	C8	Loud speaker
N8	4	D2	Signal horn
N9	4	E2	Signal horn
O1	2	F5	Combination instrument
O3	2	F4	Speedometer
O4	2	F4	Tachograph
O5	2	E6	Tachometer
O6	2	E6	Fuel gauge
O7	2	E6	Temperature gauge
O8	2	E6	Oil pressure gauge
O9	2	E6	Ampere gauge
O10	2	E6	Air pressure gauge
O11	2	E6	Air pressure gauge
P1	4	D3	Battery
P2	2.3	C3, F8	Central electric unit
P3	4	D4	Alternator
R1	2	D2	Flasher relay
R2	2	B1	Power relay
R3	2	B3	Power relay
R4	3	F6	Power relay
R5	2	A3	Power relay
R6	3	F4	Power relay
R8	3	F4	Power relay
R14	3	F6	Power relay
R15	3	F2	Power relay
R19	3	F5	Power relay
R20	3	F7	Power relay
R21	3	F5	Power relay
R22	3	F4	Power relay
R24	3	F2	Power relay
R25	3	F1	Power relay
R28	2	C3	Power relay
R29	2	C3	Power relay
R33	2	B3	Power relay
R34	3	F3	Power relay
R37	5	B1	Power relay
R38	5	B1	Power relay
S1	2	F8	Switch
S2	2	D6	Switch
S3	2	E4	Switch
S4	2	B7	Switch
S5	2	E3	Switch
S7	2	D7	Switch
S8	2	F7	Switch
S9	2	F7	Switch
S10	2	E7	Switch
S18	2	E4	Switch

Des.	Sheet	Pos.	Description
S19	2	E8	Rheostat
S20	4	B8	Switch
S21	4	A8	Switch
S22	4	C1	Switch
S23	2	E3	Rheostat
S24	2	C7	Switch
S25	2	C7	Switch
S26	2	B7	Switch
S27	5	D5	Switch
S28	2	D3	Switch
S32	5	C1	Switch
S33	5	C1	Switch
S34	5	C1	Switch
S35	5	B5	Switch
S40	4	D3	Switch
S41	4	B8	Switch
S42	4	C1	Switch
S49	5	E5	Switch
S57	5	B5	Switch
S58	5	C5	Switch
S59	5	C5	Switch
S60	5	D5	Switch
T1	4	D8	Sensor/Monitor
T2	4	D8	Sensor/Monitor
T3	2	D6	Sensor/Monitor
T4	4	C8	Sensor/Monitor
T8	2	E4	Sensor/Monitor
T9	4	E4	Sensor/Monitor
T10	4	F4	Sensor/Monitor
T16	4	F3	Sensor
T27	4	E8	Sensor
U1	5	C7	Aerial
U2	5	F2	Aerial
V1	4	E3	Proport valve
V2	4	F4	Magnetic clutch
V17	4	F3	Solenoid valve
V25	4	E3	Solenoid valve
V44	2	B5	Solenoid valve
V45	4	F4	Solenoid valve
W1	2	F6	Warning lamp
W2	2	F6	Warning lamp
W3	2	F6	Warning lamp
W4	2	F6	Warning lamp
W5	2	F6	Warning lamp
W6	2	F6	Warning lamp
W7	2	F6	Warning lamp
W8	2	F6	Warning lamp
W9	2	F6	Warning lamp
W10	2	F6	Warning lamp
W11	2	F6	Warning lamp
W12	2	F6	Warning lamp
W14	2	F6	Warning lamp
W15	2	F6	Warning lamp
W16	2	F6	Warning lamp
W25	2	F6	Warning lamp



Code	Type	Code	Colour
A	W2 1x3, 50-24V-2W	BK	Black
B	BA9s-24V-2W	BN	Brown
C	BA15s-24V-15W	RD	Red
D	SV8, 5-24V-5W L=39	OG	Orange
E	BA15s-24V-10W	YE	Yellow
F	BA15s-24V-5W	GN	Green
G	24V-1,2W	BU	Blue
H	BA15s-24V-21W	VT	Violet
K	P43t-24V-75/70w H4	GY	Grey
L	P45t-24V-55/50W B1lux	WH	White
M	W2x4, 60-24V-1,2W	PK	Pink