



# 16:52-13

Edition 1

**Instrumentpanel och el i framparti**

**Instrument panel and electrics in front assembly**

**Armaturenbrett und E-System vorn**

**Instrumentenpaneel en electriciteit vóór**

**Tableau de bord et électricité de la section avant**

**Panel de instrumentos y electricidad en parte delantera**

**Painel de instrumentos e conexões na parte dianteira**

**Panelli strumenti e elettricità sulla zona anteriore**

**Kojetaulu ja etuosan sähkö**

**Tablica rozdzielcza i układ elektryczny, część przednia**

**K/L/N**

**From chassis No 1 839 512**

Electric centre in front

Instrument panel

- 15-supply
- Warn. lamp steering circuit 1
- Warn. lamp brake pressure
- Parking brake switch 2
- Display gearbox information
- Tacho rpm ratio
- Reduced instrument lighting
- Instrument engine speed
- Instrument coolant temperature
- Display oil pressure
- Instrument fuel contents
- Instrument brake pressure 1
- Instrument brake pressure 2
- Ground
- Warn. lamp warn brake lining
- Warn. lamp parking brake
- Warn. lamp dir. indicator bus
- Warn. lamp dir. indicator trailer
- Warn. lamp high gearbox temp.
- Warn. lamp engine fine
- Vehicle speed
- Warn. lamp hatch open
- Buzzer fixed tone gearbox
- Buzzer fixed tone
- 30-supply
- Ground
- Warn. lamp rear top light
- Warn. lamp accelerator -
- Warn. lamp accelerator +
- Warn. lamp TC
- Display inside temperature
- Display outside temperature
- Warn. lamp stop request
- Warn. lamp pres signal
- Warn. lamp height control
- Warn. lamp max. pivot angle
- Warn. lamp door open
- Warn. lamp bus stop brake
- Warn. lamp ABS
- Warn. lamp steering circuit 2
- Warn. lamp BNS
- Warn. lamp low washer liquid level
- Warn. lamp flame start
- Warn. lamp BLC failure
- Warn. lamp retarder failure +
- Warn. lamp retarder failure -
- Warn. lamp low oil pressure
- Warn. lamp low coolant level
- Warn. lamp main beam
- Warn. lamp coolant temperature
- Ground

