

A33	CAN communication
A80	Instrument cluster control module
A81	ECU
B114	Wheelspeed sensor 1 L
B115	Wheelspeed sensor 1 R
B116	Wheelspeed sensor 2 L
B117	Wheelspeed sensor 2 R
G11	Battery (positive)
G12	Battery (earth)
H20	ABS indicator lamp
S12	Ignition
X11	Diagnostic connector
X32	Collector plug
Y100	Control valve 2 L
Y101	Control valve 2 R
Y98	Control valve 1 L
Y99	Control valve 1R