

## *Fault-codes*

Model: FH 12 380

Motor: D12A 380 / ABS Basis 4 Channel

<b>Faultcode</b>	<b>Possible cause(s)</b>
136-SID 1, Wheel speed sensor 1L	FMI: 1,2,3,4,5,6,7,8,9,10,11 and 12,
136-SID 2, Wheel speed sensor 1R	FMI: 1,2,3,4,5,6,7,8,9,10,11 and 12,
136-SID 3, Wheel speed sensor 2L	FMI: 1,2,3,4,5,6,7,8,9,10,11 and 12,
136-SID 4, Wheel speed sensor 2R	FMI: 1,2,3,4,5,6,7,8,9,10,11 and 12,
136-SID 7, Control valve 1L	FMI: 1,3,5 and 6,
136-SID 8, Control valve 1R	FMI: 1,3,5 and 6,
136-SID 9, Control valve 2L	FMI: 1,3,5 and 6,
136-SID10, Control valve 2R	FMI: 1,3,5 and 6,
136-SID13, Auxiliary brake disconnection	FMI: 3,5 and 6,
136-SID14, Power supply to control valves	FMI: 4,5 and 7,
136-SID15, Power supply to control valves	FMI: 3,4,5 and 6,
136-SID18, Other DTCs	
136-SID19, Other DTCs	
136-SID23, ABS fault indicator	FMI: 5,
136-SID231, CAN communication	FMI: 5,6,9 and 12,
136-SID251, Voltage supply	FMI: 3,
136-SID253, EEPROM ABS	FMI: 2 and 12,
136-SID254, ABS control unit	FMI: 2,5,8,9 and 12,