

Removing the balancing weights on wheels



Work description

Work description

• Remove the lead balancing weights on all wheels.



Environment

Lead balancing weights should be disposed of in accordance with local regulations.

