


## General

Applies to 9, 11 and 12 litre engines with cylinder block generation 1.

## Work description

Remove the parts in the order below:

1. Radiator
2. Noise shield from below
3. Fan and fan bearing with bracket
4. Poly-V-belt and pulley (1)
5. Alternator (2)
6. Idler roller (3)
7. Oil sump (4)
8. Front cover



210 857