



Before bleeding:

Read Service Information. Check which version (A or B) applies to bleeding (Table 1).

Version	Bleed nipple (twistable)	Bleed nipple (fixed)
A	•	
B		•

Table 1: Bleeding versions

There are vehicles in which the bleeding system is not directly located at the slave cylinder or the CSC. The bleeding system in these vehicles is to be found at another location of the hydraulic system.

Version A

Bleeding the hydraulic system: Open bleed nipple.



Fig. 1: Example of version A



Fig. 2: Example of version A

1 Bleed nipple (twistable)



Version B

Bleeding the hydraulic system: Pull hydraulic line one notch.



Fig. 3: Example of version B

1 Bleed nipple (fixed)



Fig. 4: Example of version B

2 Retaining clamp

Bleeding the hydraulic system

CAUTION

Risk of intoxication due to toxic liquid.

Slight to moderate injury possible.

- ⇒ Avoid contact with the skin and eyes.
- ⇒ Do not drink liquid.
- ⇒ Always wear safety goggles, protective gloves and protective clothing.

NOTICE

Property damage due to use of incorrect liquid possible.

- ⇒ Use liquid with correct specifications.

Observe the vehicle manufacturer's provisions.

