



# 16:14-13

Utgåva/Issue/Ausgabe/Uitgave/Edición/Edizione/Edizione/Painos 1

**ETC med AC**

**ETC with A/C**

**ETC mit AC**

**ETC met AC**

**ETC con AC**

**ETC avec AC**



**ETC con AC**

**ETC com AC**

**ETC ja AC**

**ETC com AC**

**Fordon tillverkade efter 9804**  
**Vehicles manufactured after 9804**  
**Fahrzeug gebaut nach 9804**  
**Na 0498 gefabriceerde voertuigen**  
**Vehículos fabricados después de 9804**  
**Véhicules fabriqués après 9804**  
**Veicoli realizzati dopo il 04/98**  
**Ennen 9804 valmistetut ajoneuvot**  
**Veículos fabricados após 9804**



**Colour code of electric cables**

| Code | Colour |
|------|--------|
| BK   | Black  |
| BN   | Brown  |
| RD   | Red    |
| OR   | Orange |
| YE   | Yellow |
| GN   | Green  |
| BL   | Blue   |
| VT   | Violet |
| GR   | Grey   |
| WH   | White  |
| PK   | Pink   |

**Additional or optional equipment**  
Denote cable. Define detail

<sup>1)</sup> When the valve is closed, the current path in B4 is interrupted.  
<sup>2)</sup> When the valve is open, the current path in B5 is interrupted.

| Des. | Pos. | Description                            |
|------|------|--|
| B4   | E5   | Switch                                 |
| B5   | E5   | Recirc. damper closed *1)              |
| C2   | C3   | 17-pole                                |
| C24  | D8   | 3-pole                                 |
| C26  | C7   | 12-pole                                |
| C48  | A7   | 5-pole                                 |
| C43  | F6   | 5-pole                                 |
| C44  | B3   | 2-pole                                 |
| C53  | D6   | 2-pole                                 |
| C54  | F6   | 3-pole                                 |
| C56  | D6   | Junction block                         |
| C69  | B7   | Connector                              |
| C125 | B5   | Connector                              |
| C147 | E4   | Joining sleeve                         |
| C282 | A5   | Connector                              |
| D1   | C5   | Fan resistor unit                      |
| D20  | F8   | Potentiometer, set exhaust temperature |
| E17  | D5   | Control unit, ETC                      |
| F1   | D4   | Fuse panel                             |
| G4   | E5   | Instrument panel                       |
| G9   | C6   | Instrument panel                       |
| G12  | B3   | Central electric unit                  |
| G13  | B3   | Front plate                            |
| G18  | A7   | Floor connection plate                 |
| G27  | B3   | Engine                                 |
| H2   | A6   | Windscreen wiper motor                 |
| H3   | A5   | Fan motor                              |
| H4   | F5   | Shifting motor, recirculation valve    |
| P2   | D4   | Central electric unit                  |
| R23  | F4   | Shifting motor                         |
| R23  | E4   | Fan motor                              |
| S3   | D8   | Fan motor                              |
| S16  | E6   | Switch                                 |
| S47  | E6   | Flash light diagnosis                  |
| S68  | E6   | Recirculation                          |
| T6   | B4   | Low refrigerant pressure               |
| T7   | E6   | Low temperature                        |
| T8   | A5   | Low coolant level                      |
| T37  | D6   | Sensor, exhaust temperature            |
| V2   | B2   | Magnetic clutch, AC compressor         |
| V59  | B5   | Water valve                            |

110055

